			SG79V074H01	THE FOLLOWING SHOULD ALWAYS BE OBSERVED FO
MITSUBISHI ELECTRIC OPTIONAL DEFROST HEATER		Specifications		 Be sure to read these safety precautions and instructions. Be sure to observe the warnings and cautions specified here as they include impor After reading this manual, be sure to store it for future reference.
SPLIT-TYPE AIR CONDITIONERS	MAC-640BH-U	Rated Voltage	Electric Power	
OUTDOOR UNIT DEFROST HEATER INSTALLATION MANUAL	MAC-640BH-0	208 / 230 V	106 / 130 W	Do not install the unit by yourself (user). Incomplete installation could cause fire, electric shock, or injury due to the unit fa or leakage of water. Consult the dealer from whom you purchased the unit or a
BEFORE INSTALLATION	base. The base may freeze when the heating operation is performed fo	pralong time in venulow temp	oratura high humidity condition	 Ground the unit correctly. Do not connect the ground to a gas pipe, water pipe, lightning rod, or telephone ground. Defective grounding could cause electric shock.
 Wear protective equipment such as gloves for you Be careful not to cut your hands with the aluminur 	ir safety.	or a long time in very low temp	erature, nigh hunnung condition.	Â
 Be careful not to wet electrical parts with water or snow during installation. Wet electrical parts could cause malfunction. Do not install the outdoor unit directly on the ground. Install the outdoor unit on a raised platform, such as on racks, to suppress freezing. 				Depending on the installation area, install a Ground Fault Interrupt (GFI) circ breaker. If the Ground Fault Interrupt (GFI) circuit breaker is not installed, an electric shock
Components				could occur.
① Defrost heater 1 ④	Cable tie 1			
② Aluminum tape 1 5	Self drilling screw 2			
③ Heater support 1 6	Insulation 1			
 1. PREPARING FOR INSTALLATION Make sure to switch off the power supply or turn off the breaker. Remove the top panel, front panel, service panel, motor support, and elect assy. 				 3. FIXING THE WIRES (1) Place the lead wires of the defrost heater ①, fan motor, and ambient temp. th with the cable tie ④. * If the lead wires slacken, there is a possibility that they touch the propeller for safety. Cut off the surplus of the cable tie ④. (2) Apply the insulation ⑥ on the place indicated in the figure below. Secure all t (3) Install the elect assy on the fixed place. Connect the lead wires from the defrost heater ① to CN 722 on the inverter F



2. INSTALLING THE HEATER

- Hold the left lower side of the heat exchanger, and slightly lift up the heat exchanger.
 Insert the defrost heater ① under the heat exchanger, and align it with the groove on the base. After positioning the defrost heater ①, secure it to the base with the aluminum tape ②. In order to fix the defrost heater ① to the base, fix the heater support ③ to the base with 2 self drilling screws ⑤.
 Put the heat exchanger back in place, and install the motor support and the propeller fan. (Refer to the figure below for details.)



Motor support

- 4. AFTER INSTALLATION
- Reinstall the front panel, top panel, and service panel.
 Turn on the breaker, and perform test run to confirm that it works properly.
 * Do not install either drain socket which is provided with the outdoor unit or purchased separately. Inside of the drain hose and/or drain socket may freeze if the drain socket is installed.

Defrost heater ①

MITSUBISHI ELECTRIC CORPORATION

HEAD OFFICE: TOKYO BLDG., 2-7-3, MARUNOUCHI, CHIYODA-KU, TOKYO 100-8310, JAPAN

OR SAFETY

rtant items related to safety.

WARNING (Could lead to death, serious injury, etc.)

falling, quali-

■ Be sure to use the parts provided or specified parts for the installation work. Incomplete installation could cause fire, electric shock, or injury.

CAUTION (Could lead to serious injury in particular environments when operated incorrectly.)

cuit

hermistor as shown in the figure below. Secure them

fan. Be sure to secure the wires with the cable tie ④

the wires tightly with the clamp.

P.C. board.

Insulation Cable tie Clamp

Acc.45