

R410A

Models PURY-P72, P96, P120, P144T(Y)JMU-A PURY-P168, P192, P216, P240, P264, P288T(Y)SJMU-A

2nd edition

CITY MULTI

Safety Precautions

- *Before installing the unit, thoroughly read the following safety precautions.
- Observe these safety precautions for your safety.

MARNING

This symbol is intended to alert the user to the presence of important instructions that must be followed to avoid the risk of serious injury or death.

A CAUTION

This symbol is intended to alert the user to the presence of important instructions that must be followed to avoid the risk of serious injury or damage to the unit.

- •After reading this manual, give it to the user to retain for future reference.
- •Keep this manual for easy reference. When the unit is moved or repaired, give this manual to those who provide these services.

When the user changes, make sure that the new user receives this manual.

⚠ WARNING

Ask your dealer or a qualified technician to install the unit.

Improper installation by the user may result in water leakage, electric shock, smoke, and/or fire.

Properly install the unit on a surface that can withstand the weight of the unit.

Unit installed on an unstable surface may fall and cause injury.

Only use specified cables. Securely connect each cable so that the terminals do not carry the weight of the cable.

Improperly connected or fixed cables may produce heat and start a fire.

Take appropriate safety measures against strong winds and earthquakes to prevent the unit from falling.

If the unit is not installed properly, the unit may fall and cause serious injury to the person or damage to the unit.

Do not make any modifications or alterations to the unit. Consult your dealer for repair.

Improper repair may result in water leakage, electric shock, smoke, and/or fire.

Do not touch the heat exchanger fins.

The fins are sharp and dangerous.

In the event of a refrigerant leak, thoroughly ventilate the room.

If refrigerant gas leaks and comes in contact with an open flame, poisonous gases will be produced.

When installing the All-Fresh type units, take it into consideration that the outside air may be discharged directly into the room when the thermo is turned off.

Direct exposure to outdoor air may have an adverse effect on health. It may also result in food spoilage.

Properly install the unit according to the instructions in the installation manual.

Improper installation may result in water leakage, electric shock, smoke, and/or fire.

Have all electrical work performed by an authorized electrician according to the local regulations and instructions in this manual, and a dedicated circuit must be used.

Insufficient capacity of the power supply circuit or improper installation may result in malfunctions of the unit, electric shock, smoke, and/or fire.

⚠ WARNING

Securely attach the terminal block cover (panel) to the unit.

If the terminal block cover (panel) is not installed properly, dust and/or water may infiltrate and pose a risk of electric shock, smoke, and/or fire.

Only use the type of refrigerant that is indicated on the unit when installing or reinstalling the unit.

Infiltration of any other type of refrigerant or air into the unit may adversely affect the refrigerant cycle and may cause the pipes to burst or explode.

When installing the unit in a small room, exercise caution and take measures against leaked refrigerant reaching the limiting concentration.

Consult your dealer with any questions regarding limiting concentrations and for precautionary measures before installing the unit. Leaked refrigerant gas exceeding the limiting concentration causes oxygen deficiency.

Consult your dealer or a specialist when moving or reinstalling the unit.

Improper installation may result in water leakage, electric shock, and/or fire.

After completing the service work, check for a gas leak.

If leaked refrigerant is exposed to a heat source, such as a fan heater, stove, or electric grill, poisonous gases may be produced.

Do not try to defeat the safety features of the unit.

Forced operation of the pressure switch or the temperature switch by defeating the safety features of these devices, or the use of accessories other than the ones that are recommended by MITSUBISHI may result in smoke, fire, and/or explosion.

Only use accessories recommended by MITSUBISHI.

Ask a qualified technician to install the unit. Improper installation by the user may result in water leakage, electric shock, smoke, and/or fire.

Control box houses high-voltage parts.

When opening or closing the front panel of the control box, do not let it come into contact with any of the internal components. Before inspecting the inside of the control box, turn off the power, keep the unit off for at least 10 minutes, and confirm that the voltage between FT-P and FT-N on INV Board has dropped to DC20V or less. (It takes about 10 minutes to discharge electricity after the power supply is turned off.)

Precautions for handling units for use with R410A

! CAUTION

Do not use the existing refrigerant piping.

- •A large amount of chlorine that is contained in the residual refrigerant and refrigerator oil in the existing piping may cause the refrigerator oil in the new unit to deteriorate.
- •R410A is a high-pressure refrigerant and can cause the existing pipes to burst.

Use refrigerant pipes made of phosphorus deoxidized copper. Keep the inner and outer surfaces of the pipes clean and free of such contaminants as sulfur, oxides, dust, dirt, shaving particles, oil, and water.

These types of contaminants inside the refrigerant pipes may cause the refrigerant oil to deteriorate.

Store the pipes to be installed indoors, and keep both ends of the pipes sealed until immediately before brazing. (Keep elbows and other joints wrapped in plastic.)

Infiltration of dust, dirt, or water into the refrigerant system may cause the refrigerating machine oil to deteriorate or cause the unit to malfunction.

Use a small amount of ester oil, ether oil, or alkylbenzene to coat flares and flanges.

Infiltration of a large amount of mineral oil may cause the refrigerating machine oil to deteriorate.

Charge liquid refrigerant (as opposed to gaseous refrigerant) into the system.

If gaseous refrigerant is charged into the system, the composition of the refrigerant in the cylinder will change and may result in performance loss.

Use a vacuum pump with a reverse-flow check valve.

If a vacuum pump that is not equipped with a reverse-flow check valve is used, the vacuum pump oil may flow into the refrigerant cycle and cause the refrigerating machine oil to deteriorate.

Prepare tools for exclusive use with R410A. Do not use the following tools if they have been used with the conventional refrigerant (gauge manifold, charging hose, gas leak detector, reverse-flow check valve, refrigerant charge base, vacuum gauge, and refrigerant recovery equipment.).

- •If the refrigerant or the refrigerating machine oil left on these tools are mixed in with R410A, it may cause the refrigerating machine oil to deteriorate.
- •Infiltration of water may cause the refrigerating machine oil to deteriorate.
- •Gas leak detectors for conventional refrigerants will not detect an R410A leak because R410A is free of chlorine.

Do not use a charging cylinder.

If a charging cylinder is used, the composition of the refrigerant will change, and the unit may experience power loss.

Exercise special care when handling the tools for use with R410A.

Infiltration of dust, dirt, or water into the refrigerant system may cause the refrigerating machine oil to deteriorate.

Only use refrigerant R410A.

The use of other types of refrigerant that contain chlorine (i.e. R22) may cause the refrigerating machine oil to deteriorate.

Before installing the unit

! WARNING

Do not install the unit where a gas leak may occur.

If gaseous refrigerant leaks and piles up around the unit, it may be ignited.

Do not use the unit to keep food items, animals, plants, artifacts, or for other special purposes.

The unit is not designed to preserve food products.

Do not use the unit in an unusual environment.

- •Do not install the unit where a large amount of oil or steam is present or where acidic or alkaline solutions or chemical sprays are used frequently. Doing so may lead to a remarkable drop in performance, electric shock, malfunctions, smoke, and/or fire.
- •The presence of organic solvents or corrosive gas (i.e. ammonia, sulfur compounds, and acid) may cause gas leakage or water leakage.

When installing the unit in a hospital, take appropriate measures to reduce noise interference.

High-frequency medical equipment may interfere with the normal operation of the air conditioner or vice versa.

Do not install the unit on or over things that cannot get wet.

When the humidity level exceeds 80% or if the drainage system is clogged, the indoor unit may drip water. Drain water is also discharged from the outdoor unit. Install a centralized drainage system if necessary.

Before installing the unit (moving and reinstalling the unit) and performing electrical work

⚠ CAUTION

Properly ground the unit.

Do not connect the grounding wire to a gas pipe, water pipe, lightning rod, or grounding wire from a telephone pole. Improper grounding may result in electric shock, smoke, fire, and/or malfunction due to noise interference.

Do not put tension on the power supply wires.

If tension is put on the wires, they may break and result in excessive heat, smoke, and/or fire.

Install an earth leakage breaker to avoid the risk of electric shock.

Failure to install an earth leakage breaker may result in electric shock, smoke, and/or fire.

Use the kind of power supply wires that are specified in the installation manual.

The use of wrong kind of power supply wires may result in current leak, electric shock, and/or fire.

Use breakers and fuses (current breaker, remote switch <switch + Type-B fuse>, moulded case circuit breaker) with the proper current capacity.

The use of wrong capacity fuses, steel wires, or copper wires may result in malfunctions, smoke, and/or fire.

Do not spray water on the air conditioner or immerse the air conditioner in water.

Otherwise, electric shock and/or fire may result.

When handling units, always wear protective gloves to protect your hands from metal parts and high-temperature parts.

Periodically check the installation base for damage.

If the unit is left on a damaged platform, it may fall and cause injury.

Properly install the drain pipes according to the instructions in the installation manual. Keep them insulated to avoid dew condensation.

Improper plumbing work may result in water leakage and damage to the furnishings.

Exercise caution when transporting products.

- •Products weighing more than 20 kg should not be carried alone.
- •Do not carry the product by the PP bands that are used on some products.
- •Do not touch the heat exchanger fins. They are sharp and dangerous.
- •When lifting the unit with a crane, secure all four corners to prevent the unit from falling.

Properly dispose of the packing materials.

- Nails and wood pieces in the package may pose a risk of injury.
- Plastic bags may pose a risk of choking hazard to children. Tear plastic bags into pieces before disposing of them.

Before the test run

CAUTION

Turn on the unit at least 12 hours before the test run.

Keep the unit turned on throughout the season. If the unit is turned off in the middle of a season, it may result in malfunctions.

To avoid the risk of electric shock or malfunction of the unit, do not operate switches with wet hands.

Do not touch the refrigerant pipes with bare hands during and immediately after operation.

During or immediately after operation, certain parts of the unit such as pipes and compressor may be either very cold or hot, depending on the state of the refrigerant in the unit at the time. To reduce the risk of frost bites and burns, do not touch these parts with bare hands.

Do not operate the unit without panels and safety guards.

Rotating, high-temperature, or high-voltage parts on the unit pose a risk of burns and/or electric shock.

Do not turn off the power immediately after stopping the operation.

Keep the unit on for at least five minutes before turning off the power to prevent water leakage or malfunction.

Do not operate the unit without the air filter.

Dust particles may build up in the system and cause malfunctions.

CONTENTS

I Read Before Servicing	
[1] Read Before Servicing	
[2] Necessary Tools and Materials	
[3] Piping Materials[4] Storage of Piping	
[5] Pipe Processing	
[6] Brazing	
[7] Air Tightness Test	9
[8] Vacuum Drying (Evacuation)	
[9] Refrigerant Charging[10] Remedies to be taken in case of a Refrigerant Leak	12
[11] Characteristics of the Conventional and the New Refrigerants	12 13
[12] Notes on Refrigerating Machine Oil	14
II Destrictions	
II Restrictions	17
[1] System configuration[2] Types and Maximum allowable Length of Cables	17 18
[3] Switch Settings and Address Settings	19
[4] Sample System Connection	26
[5] An Example of a System to which an MA Remote Controller is connected	
[6] An Example of a System to which an ME Remote Controller is connected	42
[7] An Example of a System to which both MA Remote Controller and ME Remote Controller are connected	11
[8] Restrictions on Pipe Length	
III Outdoor Unit Components	
[1] Outdoor Unit Components and Refrigerant Circuit	61
[2] Control Box of the Outdoor Unit	
[4] BC Controller Components	
[5] Control Box of the BC Controller	83
[6] BC Controller Circuit Board	
IV Remote Controller	
	90
[1] Functions and Specifications of MA and ME Remote Controllers[2] Group Settings and Interlock Settings via the ME Remote Controller	
[3] Interlock Settings via the MA Remote Controller	
[4] Using the built-in Temperature Sensor on the Remote Controller	
V Electrical Wiring Diagram	
	00
[1] Electrical Wiring Diagram of the Outdoor Unit[2] Electrical Wiring Diagram of the BC Controller	99 104
[3] Electrical Wiring Diagram of Transmission Booster	114
VI Refrigerant Circuit	
[1] Refrigerant Circuit Diagram[2] Principal Parts and Functions	117
[2] Principal Parts and Functions	120
VII Control	
[1] Functions and Factory Settings of the Dipswitches	137
[2] Controlling the Outdoor Unit	144
[3] Controlling BC Controller	
[4] Operation Flow Chart	160
VIII Test Run Mode	
[1] Items to be checked before a Test Run	
[2] Test Run Method	170
[3] Operating Characteristic and Refrigerant Amount	
[4] Adjusting the Refrigerant Amount[5] Refrigerant Amount Adjust Mode	
[6] The following symptoms are normal.	
[7] Standard Operation Data (Reference Data)	
IX Troubleshooting	
<u> </u>	105
[1] Error Code Lists[2] Responding to Error Display on the Remote Controller	
[3] Investigation of Transmission Wave Shape/Noise	
[4] Troubleshooting Principal Parts	288
[5] Refrigerant Leak	
[6] Compressor Replacement Instructions	335

HWE0913A GB

CONTENTS

[7] Servicing the BC controller	. 350
[8] Troubleshooting Using the Outdoor Unit LED Error Display	. 353
X LED Monitor Display on the Outdoor Unit Board [1] How to Read the LED on the Service Monitor	

HWE0913A GB

I Read Before Servicing

[1]	Read Before Servicing	3
	Necessary Tools and Materials	
	Piping Materials	
	Storage of Piping	
	Pipe Processing	
[6]	Brazing	8
[7]	Air Tightness Test	9
[8]	Vacuum Drying (Evacuation)	. 10
[9]	Refrigerant Charging	. 12
[10]	Remedies to be taken in case of a Refrigerant Leak	. 12
[11]	Characteristics of the Conventional and the New Refrigerants	. 13
[12]	Notes on Refrigerating Machine Oil	. 14

HWE0913A

[1] Read Before Servicing

Check the type of refrigerant used in the system to be serviced.

Refrigerant Type

Multi air conditioner for building application CITY MULTI R2 TJMU-A, YJMU-A series R410A

2. Check the symptoms exhibited by the unit to be serviced.

Refer to this service handbook for symptoms relating to the refrigerant cycle.

- 3. Thoroughly read the safety precautions at the beginning of this manual.
- 4. Preparing necessary tools: Prepare a set of tools to be used exclusively with each type of refrigerant.

 Refer to "Necessary Tools and Materials" for information on the use of tools.(page 4)
- 5. Verification of the connecting pipes: Verify the type of refrigerant used for the unit to be moved or replaced.
 - *Use refrigerant pipes made of phosphorus deoxidized copper. Keep the inner and outer surfaces of the pipes clean and free of such contaminants as sulfur, oxides, dust, dirt, shaving particles, oil, and water.
 - •These types of contaminants inside the refrigerant pipes may cause the refrigerant oil to deteriorate.
- 6. If there is a leak of gaseous refrigerant and the remaining refrigerant is exposed to an open flame, a poisonous gas hydrofluoric acid may form. Keep workplace well ventilated.



CAUTION

- Install new pipes immediately after removing old ones to keep moisture out of the refrigerant circuit.
- •The use of refrigerant that contains chloride, such as R22, will cause the refrigerating machine oil to deteriorate.

[2] Necessary Tools and Materials

Prepare the following tools and materials necessary for installing and servicing the unit.

Tools for use with R410A (Adaptability of tools that are for use with R22 or R407C)

1. To be used exclusively with R410A (not to be used if used with R22 or R407C)

Tools/Materials	Use	Notes
Gauge Manifold	Evacuation and refrigerant charging	Higher than 5.09MPa[738psi] on the high-pressure side
Charging Hose	Evacuation and refrigerant charging	The hose diameter is larger than the conventional model.
Refrigerant Recovery Cylinder	Refrigerant recovery	
Refrigerant Cylinder	Refrigerant charging	The refrigerant type is indicated. The cylinder is pink.
Charging Port on the Refrigerant Cylinder	Refrigerant charging	The charge port diameter is larger than that of the current port.
Flare Nut	Connection of the unit with the pipes	Use Type-2 Flare nuts.

2. Tools and materials that may be used with R410A with some restrictions

Tools/Materials	Use	Notes
Gas Leak Detector	Gas leak detection	The ones for use with HFC refrigerant may be used.
Vacuum Pump	Vacuum drying	May be used if a check valve adapter is attached.
Flare Tool	Flare processing	Flare processing dimensions for the piping in the system using the new refrigerant differ from those of R22. Refer to I [3] Piping Materials.
Refrigerant Recovery Equipment	Refrigerant recovery	May be used if compatible with R410A.

3. Tools and materials that are used with R22 or R407C that may also be used with R410A

Tools/Materials	Use	Notes
Vacuum Pump with a Check Valve	Vacuum drying	
Bender	Bending pipes	
Torque Wrench	Tightening flare nuts	Only the flare processing dimensions for pipes that have a diameter of ø12.70 (1/2") and ø15.88 (5/8") have been changed.
Pipe Cutter	Cutting pipes	
Welder and Nitrogen Cylinder	Welding pipes	
Refrigerant Charging Meter	Refrigerant charging	
Vacuum Gauge	Vacuum level check	

4. Tools and materials that must not be used with R410A

Tools/Materials	Use	Notes
Charging Cylinder	Refrigerant charging	Prohibited to use

Tools for R410A must be handled with special care to keep moisture and dust from infiltrating the cycle.

[3] Piping Materials

Do not use the existing piping!

1. Copper pipe materials

O-material (Annealed)	Soft copper pipes (annealed copper pipes). They can easily be bent with hands.
1/2H-material (Drawn)	Hard copper pipes (straight pipes). They are stronger than the O-material (Annealed) at the same radial thickness.

[•]The distinction between O-materials (Annealed) and 1/2H-materials (Drawn) is made based on the strength of the pipes themselves.

2. Types of copper pipes

Maximum working pressure	Refrigerant type
3.45 MPa [500psi]	R22, R407C etc.
4.30 MPa [624psi]	R410A etc.

3. Piping materials/Radial thickness

Use refrigerant pipes made of phosphorus deoxidized copper.

The operation pressure of the units that use R410A is higher than that of the units that use R22.

Use pipes that have at least the radial thickness specified in the chart below.

(Pipes with a radial thickness of 0.7 mm [28mil] or less may not be used.)

Pipe siz	Pipe size (mm[in.]) Radial thickness (mm [mil])		Туре
ø6.35	[1/4"]	0.8t [32t]	
ø9.52	[3/8"]	0.8t [32t]	O-material (Annealed)
ø12.7	[1/2"]	0.8t [32t]	O-material (Armealed)
ø15.88	[5/8"]	1.0t [40t]	
ø19.05	[3/4"]	1.0t [40t]	
ø22.2	[7/8"]	1.0t [40t]	
ø25.4	[1"]	1.0t [40t]	
ø28.58	[1-1/8"]	1.0t [40t]	1/2H-material, H-material (Drawn)
ø31.75	[1-1/4"]	1.1t [44t]	
ø34.93	[1-3/8"]	1.2t [48t]	
ø41.28	[1-5/8"]	1.4t [56t]	

[•]The pipes in the system that uses the refrigerant currently on the market are made with O-material (Annealed), even if the pipe diameter is less than ø19.05 (3/4"). For a system that uses R410A, use pipes that are made with 1/2H-material (Drawn) unless the pipe diameter is at least ø19.05 (3/4") and the radial thickness is at least 1.2t.

[•]The figures in the radial thickness column are based on the Japanese standards and provided only as a reference. Use pipes that meet the local standards.

4. Thickness and refrigerant type indicated on the piping materials


Ask the pipe manufacturer for the symbols indicated on the piping material for new refrigerant.

5. Flare processing (O-material (Annealed) and OL-material only)

The flare processing dimensions for the pipes that are used in the R410A system are larger than those in the R22 system.

Flare processing dimensions (mm[in.])

Pipe size (mm[in.])		A dimension (mm)	
		R410A	R22, R407C
ø6.35	[1/4"]	9.1	9.0
ø9.52	[3/8"]	13.2	13.0
ø12.7	[1/2"]	16.6	16.2
ø15.88	[5/8"]	19.7	19.4
ø19.05	[3/4"]	24.0	23.3



(ø19.05 pipes should have a radial thickness of 1.2 t and be made of annealed materials.)


If a clutch-type flare tool is used to flare the pipes in the system using R410A, the length of the pipes must be between 1.0 and 1.5 mm. For margin adjustment, a copper pipe gauge is necessary.

6. Flare nut

The flare nut type has been changed to increase the strength. The size of some of the flare nuts have also been changed.

Flare nut dimensions (mm[in.])

Pipe size (mm[in.])		B dimension (mm)	
		R410A	R22, R407C
ø6.35	[1/4"]	17.0	17.0
ø9.52	[3/8"]	22.0	22.0
ø12.7	[1/2"]	26.0	24.0
ø15.88	[5/8"]	29.0	27.0
ø19.05	[3/4"]	36.0	36.0



The figures in the radial thickness column are based on the Japanese standards and provided only as a reference. Use pipes that meet the local standards.

[4] Storage of Piping


1. Storage location






Store the pipes to be used indoors. (Warehouse at site or owner's warehouse) If they are left outdoors, dust, dirt, or moisture may infiltrate and contaminate the pipe.

2. Sealing the pipe ends





Both ends of the pipes should be sealed until just before brazing. Keep elbow pipes and T-joints in plastic bags.

The new refrigerator oil is 10 times as hygroscopic as the conventional refrigerating machine oil (such as Suniso) and, if not handled with care, could easily introduce moisture into the system. Keep moisture out of the pipes, for it will cause the oil to deteriorate and cause a compressor failure.

[5] Pipe Processing

Use a small amount of ester oil, ether oil, or alkylbenzene to coat flares and flanges.


Note


- •Use a minimum amount of oil.
- •Use only ester oil, ether oil, and alkylbenzene.

[6] Brazing


No changes have been made in the brazing procedures. Perform brazing with special care to keep foreign objects (such as oxide scale, water, and dust) out of the refrigerant system.

Example: Inside the brazed connection





Use of inert gas during brazing



1. Items to be strictly observed

- •Do not conduct refrigerant piping work outdoors if raining.
- *Use inert gas during brazing.
- •Use a brazing material (BCuP-3) that requires no flux when brazing between copper pipes or between a copper pipe and
- •If installed refrigerant pipes are not immediately connected to the equipment, then braze and seal both ends.

2. Reasons


- •The new refrigerating machine oil is 10 times as hygroscopic as the conventional oil and is more likely to cause unit failure if water infiltrates into the system.
- •Flux generally contains chloride. Residual flux in the refrigerant circuit will cause sludge to form.

Notes

Do not use commercially available antioxidants because they may cause the pipes to corrode or refrigerating machine oil to deteriorate.

[7] Air Tightness Test

No changes have been made in the detection method. Note that a refrigerant leak detector for R22 will not detect an R410A leak.



1. Items to be strictly observed

- •Pressurize the equipment with nitrogen up to the design pressure (4.15MPa[601psi]), and then judge the equipment's air tightness, taking temperature variations into account.
- •Refrigerant R410A must be charged in its liquid state (vs. gaseous state).

2. Reasons

- •Oxygen, if used for an air tightness test, poses a risk of explosion. (Only use nitrogen to check air tightness.)
- •Refrigerant R410A must be charged in its liquid state. If gaseous refrigerant in the cylinder is drawn out first, the composition of the remaining refrigerant in the cylinder will change and become unsuitable for use.

3. Notes

Procure a leak detector that is specifically designed to detect an HFC leak. A leak detector for R22 will not detect an HFC(R410A) leak.

[8] Vacuum Drying (Evacuation)







(Photo2) 14010

Recommended vacuum gauge: ROBINAIR 14010 Thermistor Vacuum Gauge

1. Vacuum pump with a reverse-flow check valve (Photo1)

To prevent the vacuum pump oil from flowing into the refrigerant circuit during power OFF or power failure, use a vacuum pump with a reverse-flow check valve.

A reverse-flow check valve may also be added to the vacuum pump currently in use.

2. Standard of vacuum degree (Photo 2)

Use a vacuum pump that attains 0.5Torr(65Pa) or lower degree of vacuum after 5 minutes of operation, and connect it directly to the vacuum gauge. Use a pump well-maintained with an appropriate lubricant. A poorly maintained vacuum pump may not be able to attain the desired degree of vacuum.

3. Required precision of vacuum gauge

Use a vacuum gauge that registers a vacuum degree of 5Torr(650Pa) and measures at intervals of 1Torr(130Pa). (A recommended vacuum gauge is shown in Photo2.)

Do not use a commonly used gauge manifold because it cannot register a vacuum degree of 5Torr(650Pa).

4. Evacuation time

- After the degree of vacuum has reached 5Torr(650Pa), evacuate for an additional 1 hour. (A thorough vacuum drying removes moisture in the pipes.)
- •Verify that the vacuum degree has not risen by more than 1Torr(130Pa) 1hour after evacuation. A rise by less than 1Torr(130Pa) is acceptable.
- •If the vacuum is lost by more than 1Torr(130Pa), conduct evacuation, following the instructions in section 6. Special vacuum drying.

5. Procedures for stopping vacuum pump

To prevent the reverse flow of vacuum pump oil, open the relief valve on the vacuum pump side, or draw in air by loosening the charge hose, and then stop the operation.

The same procedures should be followed when stopping a vacuum pump with a reverse-flow check valve.

6. Special vacuum drying

- •When 5Torr(650Pa) or lower degree of vacuum cannot be attained after 3 hours of evacuation, it is likely that water has penetrated the system or that there is a leak.
- •If water infiltrates the system, break the vacuum with nitrogen. Pressurize the system with nitrogen gas to 0.5kgf/cm²G(0.05MPa) and evacuate again. Repeat this cycle of pressurizing and evacuation either until the degree of vacuum below 5Torr(650Pa) is attained or until the pressure stops rising.
- Only use nitrogen gas for vacuum breaking. (The use of oxygen may result in an explosion.)

7. Notes

•To evacuate air from the entire system

Applying a vacuum through the check joints at the refrigerant service valve on the high and low pressure sides (BV1 and 2) is not enough to attain the desired vacuum pressure.

Be sure to apply a vacuum through the check joints at the refrigerant service valve on the high and low pressure sides (BV1 and 2) and also through the check joints on the high and low pressure sides (CJ1 and 2).

•To evacuate air only from the outdoor units


Apply a vacuum through the check joints on the high and low pressure sides (CJ1, and 2).

•To evacuate air from the indoor units and extension pipes

Apply a vacuum through the check joints at the refrigerant service valve on the high and low pressure sides (BV1 and 2).


[9] Refrigerant Charging

Cylinder with a siphon





Cylinder color R410A is pink.

Cylinder without a siphon



Refrigerant charging in the liquid state





1. Reasons

R410A is a pseudo-azeotropic HFC blend (boiling point R32=-52°C[-62°F], R125=-49°C[-52°F]) and can almost be handled the same way as a single refrigerant, such as R22. To be safe, however, draw out the refrigerant from the cylinder in the liquid phase. If the refrigerant in the gaseous phase is drawn out, the composition of the remaining refrigerant will change and become unsuitable for use.

2. Notes

When using a cylinder with a siphon, refrigerant is charged in the liquid state without the need for turning it upside down. Check the type of the cylinder on the label before use.

[10] Remedies to be taken in case of a Refrigerant Leak

If the refrigerant leaks out, it may be replenished. The entire refrigerant does not need to be replaced. (Charge refrigerant in the liquid state.)

Refer to "IX [5] Refrigerant Leak."(page 333)

[11] Characteristics of the Conventional and the New Refrigerants

1. Chemical property

As with R22, the new refrigerant (R410A) is low in toxicity and chemically stable nonflammable refrigerant. However, because the specific gravity of vapor refrigerant is greater than that of air, leaked refrigerant in a closed room will accumulate at the bottom of the room and may cause hypoxia.

If exposed to an open flame, refrigerant will generate poisonous gases. Do not perform installation or service work in a confined area.

	New Refrigera	ant (HFC type)	Conventional Refriger- ant (HCFC type)
	R410A	R407C	R22
	R32/R125	R32/R125/R134a	R22
Composition (wt%)	(50/50)	(23/25/52)	(100)
Type of Refrigerant	Pseudo-azeotropic Refrigerant	Non-azeotropic Refrigerant	Single Refrigerant
Chloride	Not included	Not included	Included
Safety Class	A1/A1	A1/A1	A1
Molecular Weight	72.6	86.2	86.5
Boiling Point (°C/°F)	-51.4/-60.5	-43.6/-46.4	-40.8/-41.4
Steam Pressure (25°C,MPa/77°F,psi) (gauge)	1.557/226	0.9177/133	0.94/136
Saturated Steam Density (25°C,kg/m³/77°F,psi)	64.0	42.5	44.4
Flammability	Nonflammable	Nonflammable	Nonflammable
Ozone Depletion Coefficient (ODP)*1	0	0	0.055
Global Warming Coefficient (GWP)*2	1730	1530	1700
Refrigerant Charging Method	Refrigerant charging in the liquid state	Refrigerant charging in the liquid state	Refrigerant charging in the gaseous state
Replenishment of Refrigerant after a Refrigerant Leak	Available	Available	Available

^{*1} When CFC11 is used as a reference

2. Refrigerant composition

R410A is a pseudo-azeotropic HFC blend and can almost be handled the same way as a single refrigerant, such as R22. To be safe, however, draw out the refrigerant from the cylinder in the liquid phase. If the refrigerant in the gaseous phase is drawn out, the composition of the remaining refrigerant will change and become unsuitable for use.

If the refrigerant leaks out, it may be replenished. The entire refrigerant does not need to be replaced.

3. Pressure characteristics

The pressure in the system using R410A is 1.6 times as great as that in the system using R22.

	Pressure (gauge)				
Temperature (°C/°F)	R410A	R407C	R22		
	MPa/psi	MPa/psi	MPa/psi		
-20/-4	0.30/44	0.18/26	0.14/20		
0/32	0.70/102	0.47/68	0.40/58		
20/68	1.34/194	0.94/136	0.81/117		
40/104	2.31/335	1.44/209	1.44/209		
60/140	3.73/541	2.44/354	2.33/338		
65/149	4.17/605	2.75/399	2.60/377		

^{*2} When CO₂ is used as a reference

[12] Notes on Refrigerating Machine Oil

1. Refrigerating machine oil in the HFC refrigerant system

HFC type refrigerants use a refrigerating machine oil different from that used in the R22 system. Note that the ester oil used in the system has properties that are different from commercially available ester oil.

Refrigerant	Refrigerating machine oil
R22	Mineral oil
R407C	Ester oil
R410A	Ester oil

2. Effects of contaminants*1

Refrigerating machine oil used in the HFC system must be handled with special care to keep contaminants out. The table below shows the effect of contaminants in the refrigerating machine oil on the refrigeration cycle.

3. The effects of contaminants in the refrigerating machine oil on the refrigeration cycle.

Cau	ise	se Symptoms		Effects on the refrigerant cycle	
Water infiltration		Frozen expansion valve and capillary tubes		Clogged expansion valve and capillary tubes Poor cooling performance	
		Hydrolysis	Sludge formation and adhesion Acid generation Oxidization Oil degradation	Compressor overheat Motor insulation failure Burnt motor Coppering of the orbiting scroll Lock Burn-in on the orbiting scroll	
Air infiltration	Air infiltration		on adgradation		
	Dust, dirt	Adhesion to expansion valve and capillary tubes		Clogged expansion valve, capillary tubes, and drier Poor cooling performance Compressor overheat	
Infiltration of contaminants		Infiltration of contaminants into the compressor		Burn-in on the orbiting scroll	
	Mineral oil etc.	Sludge formation and adhesion oil		Clogged expansion valve and capillary tubes Poor cooling performance Compressor overheat	
		Oil degradation	1	Burn-in on the orbiting scroll	

^{*1.} Contaminants is defined as moisture, air, processing oil, dust/dirt, wrong types of refrigerant, and refrigerating machine oil.

II Restrictions

[1]	System configuration	17
[2]	Types and Maximum allowable Length of Cables	18
[3]	Switch Settings and Address Settings	19
[4]	Sample System Connection	26
[5]	An Example of a System to which an MA Remote Controller is connected	28
[6]	An Example of a System to which an ME Remote Controller is connected	42
[7]	An Example of a System to which both MA Remote Controller and	
	ME Remote Controller are connected	44
[8]	Restrictions on Pipe Length	47

[1] System configuration

1. Table of compatible indoor units

The table below summarizes the types of indoor units that are compatible with different types of outdoor units.

Outdoor units	Compos	ing units	Maximum total capacity of connectable indoor units	Maximum number of connectable indoor units	Types of connectable in- door units
72	-	-	36 - 108	18	P06 - P96 models
96	-	-	48 - 144	24	R410A series indoor units
120	-	-	60 - 180	30	
144	-	-	72 - 216	36	
168	96	72	84 - 252	42	
192	96	96	96 - 288	48	
216	120	96	108 - 324	50	
240	120	120	120 - 360	50	
264	144	120	132 - 396	50	
288	144	144	144 - 432	50	

Note

- 1) "Maximum total capacity of connectable indoor units" refers to the sum of the numeric values in the indoor unit model names.
- 2) If the total capacity of the indoor units that are connected to a given outdoor unit exceeds the capacity of the outdoor unit, the indoor units will not be able to perform at the rated capacity when they are operated simultaneously. Select a combination of units so that the total capacity of the connected indoor units is at or below the capacity of the outdoor unit whenever possible.


[2] Types and Maximum allowable Length of Cables


1. Wiring work

(1) Notes

- 1) Have all electrical work performed by an authorized electrician according to the local regulations and instructions in this manual.
- Install external transmission cables at least 5cm [1-31/32"] away from the power supply cable to avoid noise interference.
 (Do not put the control cable and power supply cable in the same conduit tube.)
- 3) Provide grounding for the outdoor unit as required.
- 4) Run the cable from the electric box of the indoor or outdoor unit in such way that the box is accessible for servicing.
- 5) Do not connect power supply wiring to the terminal block for transmission line. Doing so will damage the electronic components on the terminal block.
- 6) Use 2-core shielded cables as transmission cables.

Use a separate 2-core control cable for each refrigerant system. Do not use a single multiple-core cable to connect indoor units that belong to different refrigerant systems. The use of a multiple-core cable may result in signal transmission errors and malfunctions.





TB3: Terminal block for indoor-outdoor transmission line TB7: Terminal block for centralized control

(2) Control wiring

Different types of control wiring are used for different systems.

Refer to section "[5] An Example of a System to which an MA Remote Controller is connected - [7] An Example of a System to which both MA Remote Controller and ME Remote Controller are connected" before performing wiring work.

Types and maximum allowable length of cables

Control lines are categorized into 2 types: transmission line and remote controller line.

Use the appropriate type of cables and observe the maximum allowable length specified for a given system. If a given system has a long transmission line or if a noise source is located near the unit, place the unit away from the noise source to reduce noise interference.

1) M-NET transmission line

	T					
	Facility type	All facility types				
Cable tune	Туре	Shielded cable CVVS, CPEVS, MVVS				
Cable type Number of cores	2-core cable					
Cable size		Larger than 1.25mm ² [AWG16]				
Maximum transmission line distance between the outdoor unit and the farthest indoor unit		200 m [656ft] max.				
Maximum transmission line distance for centralized control and Indoor/outdoor transmission line (Maximum line distance via outdoor unit)		500 m [1640ft] max. *The maximum overall line length from the power supply unit on the transmission lines for centralized control to each outdoor unit or to the system controller is 200m [656ft] max.				

2) Remote controller wiring

		MA remote controller*1	ME remote controller
	Туре	VCTF, VCTFK, CVV, CVS, VVR, VVF, VCT	Shielded cable MVVS
Cable type	Number of cores	2-core cable	2-core cable
Cable type	Cable size	0.3 to 1.25mm ² * ² [AWG22 to 16] (0.75 to 1.25mm ²) * ³ [AWG18 to 16]	0.3 to 1.25mm ² * ² [AWG22 to 16] (0.75 to 1.25mm ²) * ³ [AWG18 to 16]
Maximum overall line length		200 m [656ft] max.	The section of the cable that exceeds 10m [32ft] must be included in the maximum indoor-outdoor transmission line distance.

^{*1} MA remote controller refers to MA remote controller (PAR-20MAU, PAR-21MAA), MA simple remote controller, and wireless remote controller.

[3] Switch Settings and Address Settings

1. Switch setting

Refer to section "[5] An Example of a System to which an MA Remote Controller is connected - [7] An Example of a System to which both MA Remote Controller and ME Remote Controller are connected" before performing wiring work. Set the switches while the power is turned off.

If the switch settings are changed while the unit is being powered, those changes will not take effect, and the unit will not function properly.

Units on which to set	the switches	Symbol	Units to which the power must be shut off
CITY MULTI indoor unit	CITY MULTI indoor unit Main/sub unit		Outdoor units *3 and Indoor units
LOSSNAY, OA processing ui	nit *1	LC	Outdoor units *3 and LOSSNAY
ME remote controller Main/sub remote controller		RC	Outdoor units *3
MA remote controller Main/sub remote controller		MA	Indoor units
CITY MULTI outdoor unit*2		OC,OS	Outdoor units *3
BC controller Main Sub1, 2		BC	Outdoor units *3 and BC controller
		BS1, BS2	Outdoor units *3 and BC controller

^{*1.} Applicable when LOSSNAY units are connected to the indoor-outdoor transmission line.

^{*2} The use of cables that are smaller than 0.75mm² [AWG18] is recommended for easy handling.

^{*3} When connected to the terminal block on the Simple remote controller, use cables that meet the cable size specifications shown in the parenthesis.

^{*2.} The outdoor units in the same refrigerant circuit are automatically designated as OC and OS in the order of capacity from large to small (if two or more units have the same capacity, in the order of address from small to large).

^{*3.} Turn off the power to all the outdoor units in the same refrigerant circuit.

2. M-NET Address settings

(1) Address settings table

The need for address settings and the range of address setting depend on the configuration of the system.

Uni	t or controller	Sym- bol	Address setting range	Setting method	Factory address setting
CITYMULTI indoor unit M-NET adapter M-NET control interface Free Plan adapter	Main/sub unit	IC	0, 01 to 50*1*4*6 Assign the smallest address to the main indoor unit in the group, and assign sequential address numbers to the rest of the indoor units in the same group. In an R2 system with a sub BC controller, make the settings for the indoor units in the following order. (i) Indoor unit to be connected to the main BC controller (ii) Indoor unit to be connected to sub BC controller 1 (iii) Indoor unit to be connected to sub BC controller 2 Make the settings for the indoor units in the way that the formula "(i) < (ii) < (iii)" is true.		00
LOSSNAY, C	OA processing unit	LC	0, 01 to 50*1 *4 *6	Assign an arbitrary but unique address to each of these units after assigning an address to all indoor units.	00
ME remote controller	Main remote controller	RC	101 to 150	Add 100 to the smallest address of all the indoor units in the same group.	101
	Sub remote controller	RC	151 to 200 ^{*3}	Add 150 to the smallest address of all the indoor units in the same group.	
MA remote controller		MA	No address settings required. (The main/sub setting must be made if 2 remote controllers are connected to the system.)		Main
CITY MULTI	outdoor unit	OC OS	0, 51 to 100*1 *2 *6	Assign an address that equals the lowest address of the indoor units in the same refrigerant circuit plus 50. Assign sequential addresses to the outdoor units in the same refrigerant circuit. The outdoor units in the same refrigerant circuit are automatically designated as OC and OS.	00
Auxiliary outdoor unit	BC controller (main)	BC	0, 51 to 100*1 *2 *6	 Assign an address that equals the address of the outdoor unit in the same refrigerant system plus 1. If a given address overlaps any of the addresses that are assigned to the outdoor units or to the sub BC controller, use a different, unused address within the setting range. 	00
	BC controller (sub1, 2)	BS1 BS2	51 to 100 *2	 Assign an address to both the sub BC controller 1 and 2 that equals the lowest address of the indoor units that are connected to each of them plus 50. If a sub BC controller is connected, the automatic startup function is not available. 	

^{*1.} If a given address overlaps any of the addresses that are assigned to other units, use a different, unused address within the setting range.

^{*2.} To set the outdoor unit address or the auxiliary outdoor unit address to "100," set the rotary switches to "50."

*3. To set the ME remote controller address to "200," set the rotary switches to "00."

*4. Some models of indoor units have two or three control boards.

Assign an address to the No.1, No. 2, and No. 3 control boards so that the No. 2 control board address equals the No. 1 control board address plus 1, and that the No. 3 control board address equals the No. 1 control board address plus 2.

*5. The outdoor units in the same refrigerant circuit are automatically designated as OC, and OS. They are designated as OC, and OS in the descending order of address if the consolition and or formatically designated as OC, and OS.

the descending order of capacity (ascending order of address if the capacities are the same).

*6. No address settings are required for units in a system with a single outdoor unit (with some exceptions).

Address setting is required if a sub BC controller is connected.

Uı	nit or controller	Sym- bol	Address setting range	Setting method	Factory address setting
System controller			_0.0	Assign an address that equals the sum of the smallest group number of the group to be controlled and 200.	201
	System remote controller	SR SC		Assign an arbitrary but unique address within the range listed on the left to each unit.	
	ON/OFF remote controller	AN SC		Assign an address that equals the sum of the smallest group number of the group to be controlled and 200.	
	Schedule timer (compatible with M-NET)	ST SC	1	Assign an arbitrary but unique address within the range listed on the left to each unit.	202
	Central controller AG-150A G(B)-50A GB-24A	TR SC	000 201 to 250	Assign an arbitrary but unique address within the range listed on the left to each unit. The address must be set to "000" to control the K-control unit.	000
	Expansion controller PAC-YG50ECA	TR	000 201 to 250	Assign an arbitrary but unique address within the range listed on the left to each unit. The address must be set to "000" to control the K-control unit.	000
	BM adapter BAC-HD150	SC	000 201 to 250	Assign an arbitrary but unique address within the range listed on the left to each unit. The address must be set to "000" to control the K-control unit.	000
	LM adapter LMAP03U	SC	201 to 250	Assign an arbitrary but unique address within the range listed on the left to each unit.	247

(2) Power supply switch connector connection on the outdoor unit (Factory setting: The male power supply switch connector is connected to CN41.)

There are limitations on the total number of units that are connectable to each refrigerant system. Refer to the System Design Manual for details.

System configuration	Connection to the system controller	Power supply unit for transmission lines	Group operation of units in a system with multiple outdoor units	Power supply switch connector connection
System with one outdoor unit	_	-	_	Leave CN41 as it is (Factory setting)
System with multi- ple outdoor units	Not connected	_	Not grouped	
pie outdoor units			Grouped	Disconnect the male connector from the fe-
	With connection to the indoor unit system	Not required	Grouped/not grouped	male power supply switch connector (CN41) and connect it to the female power supply switch connector (CN40) on only one of the outdoor units.*2
	With connection to the central- ized control sys- tem	Not required*1 (Powered from the outdoor unit)	Grouped/not grouped	*Connect the S (shielded) terminal on the terminal block (TB7) on the outdoor unit whose CN41 was replaced with CN40 to the ground terminal (//h) on the electric box.
		Required *1	Grouped/not grouped	Leave CN41 as it is (Factory setting)

^{*1} The need for a power supply unit for transmission lines depends on the system configuration.

(3) Settings for the centralized control switch for the outdoor unit (Factory setting: SW2-1 are set to OFF.)

System configuration	Centralized control switch settings *1
Connection to the system controller Not connected	Leave it to OFF. (Factory setting)
Connection to the system controller Connected*2	ON

^{*1.} Set SW2-1 on all outdoor units in the same refrigerant circuit to the same setting.

(4) Selecting the position of temperature detection for the indoor unit (Factory setting: SW1-1 set to "OFF".)

To stop the fan during heating Thermo-OFF (SW1-7 and 1-8 on the indoor units to be set to ON), use the built-in thermistor on the remote controller or an optional thermistor.

- 1) To use the built-in sensor on the remote controller, set the SW1-1 to ON.
 - •Some models of remote controllers are not equipped with a built-in temperature sensor.

Use the built-in temperature sensor on the indoor unit instead.

- •When using the built-in sensor on the remote controller, install the remote controller where room temperature can be detected. (Note) Factory setting for SW1-1 on the indoor unit of the All-Fresh Models is ON.
- 2) When an optional temperature sensor is used, set SW1-1 to OFF, and set SW3-8 to ON.
 - •When using an optional temperature sensor, install it where room temperature can be detected.

^{*2} The replacement of the power jumper connector from CN41 to CN40 must be performed on only one outdoor unit in the system.

^{*2.} When only the LM adapter is connected, leave SW2-1 to OFF (as it is).

(5) Various start-stop controls (Indoor unit settings)

Each indoor unit (or group of indoor units) can be controlled individually by setting SW 1-9 and 1-10.

Function	Operation of the indoor unit when the operation is resumed after the unit was stopped		Setting (SW1)*4 *5	
1 diletion			10	
Power ON/OFF by the plug*1,*2,*3	Indoor unit will go into operation regardless of its operation status before power off (power failure). (In approx. 5 minutes)	OFF	ON	
Automatic restoration after power failure	Indoor unit will go into operation if it was in operation when the power was turned off (or cut off due to power failure). (In approx. 5 minutes)	ON	OFF	
	Indoor unit will remain stopped regardless of its operation status before power off (power failure).	OFF	OFF	

- *1. Do not cut off power to the outdoor unit. Cutting off the power supply to the outdoor unit will cut off the power supply to the belt heater and may cause the compressor to malfunction when the unit is put back into operation.
- *2. Not applicable to units with a built-in drain pump or humidifier.
- *3. Models with a built-in drain pump cannot be turned on/off by the plug individually. All the units in the same refrigerant circuits will be turned on or off by the plug.
- *4. Requires that the dipswitch settings for all the units in the group be made.
- *5. To control the external input to and output from the air conditioners with the PLC software for general equipment via the G(B)-50A, set SW1-9 and SW1-10 to ON. With these settings made, the power start-stop function becomes disabled. To use the auto recovery function after power failure while these settings are made, set SW1-5 to ON.

(6) Miscellaneous settings

Cooling-only setting for the indoor unit: Cooling only model (Factory setting: SW3-1 "OFF.") When using indoor unit as a cooling-only unit, set SW3-1 to ON.

(7) Various types of control using input-output signal connector on the outdoor unit (various connection options)

Туре	Usage	Function	Terminal to be used*1	Option
Input	Prohibiting cooling/heating operation (thermo OFF) by an external input to the outdoor unit.	exter		Adapter for external input (PAC-
	Performs a low level noise operation of the outdoor unit by an external input to the outdoor unit. * It can be used as the silent operation device for each refrigerant system.	Low-noise mode (level)*3 *4		SC36NA-E)
	Forces the outdoor unit to perform a fan operation by receiving signals from the snow sensor. *5	Snow sensor signal input (level)	CN3S	
	Cooling/heating operation can be changed by an external input to the outdoor unit.	Auto-changeover	CN3N	
Out- put	How to extract signals from the outdoor unit *It can be used as an operation status display device. *It can be used for an interlock operation with external devices.	Operation status of the compressor *5	CN51	Adapter for external out-
	it can be used for an interiock operation with external devices.	Error status*6		put (PAC- SC37SA-E)

- *1. For detailed drawing, refer to "Example of wiring connection".
- *2. For details, refer to (1) through (4) shown below.
- *3. Low-noise mode is valid when Dip SW4-4 on the outdoor unit is set to OFF. When DIP SW4-4 is set to ON, 4 levels of on-DEMAND are possible, using different configurations of low-noise mode input and DEMAND input settings. When 2 or more outdoor units exist in one refrigerant circuit system, 8 levels of on-DEMAND are possible.
- *4. By setting Dip SW5-5, the Low-noise mode can be switched between the Capacity priority mode and the Low-noise priority mode.

When SW5-5 is set to ON: The low-noise mode always remains effective.

When SW5-5 is set to OFF: The low noise mode is cancelled when certain outside temperature or pressure criteria are met, and the unit goes into normal operation (capacity priority mode).

Low-noise mod is effective.		Capacity priority mode becomes effective.	
Cooling	Heating	Cooling	Heating
TH7<30°C[86°F] and 63HS1<32kg/cm ²	TH7>3°C[37°F] and 63LS>4.6kg/cm ²	TH7>35°C[95°F] or 63HS1>35kg/cm ²	TH7<0°C[32°F] or 63LS<3.9kg/cm ²

^{*5.} Each outdoor unit in the system with multiple outdoor units requires the signal input/output setting to be made.


^{*6.} Take out signals from the outdoor unit (OC) if multiple outdoor units exist in a single system.


⚠ CA


CAUTION


- 1) Wiring should be covered by insulation tube with supplementary insulation.
- 2) Use relays or switches with IEC or equivalent standard.
- 3) The electric strength between accessible parts and control circuit should have 2750V or more.

Example of wiring connection









(8) Demand control

1) General outline of control

Demand control is performed by using the external signal input to the 1-2 and 1-3 pins of CN3D on the outdoor units (OC and OS). Between 2 and 8 steps of demand control is possible by setting Dip SW4-4 on the outdoor units (OC and OS).

No	Demand control switch	DipSW4-4		Input to CN3D*2	
		ОС	OS	input to GIVOD	
1	2 steps (0-100%)	OFF	OFF	oc	
2	4 steps (0-50-75-100%)	ON	OFF	OC	
3	4 steps (0-50-75-10070)	OFF	ON	OS	
4	8 steps (0-25-38-50-63-75-88-100%)	ON	ON	OC and OS	

^{*1} Available demand functions

P72-P144T(Y)JMU-A models (single-outdoor-unit system): 2 and 4 steps shown in the rows 1 and 2 in the table above only. P168-P288T(Y)SJMU-A models (two-outdoor-unit system OC+OS): 2-8 steps shown in the rows 1, 2, 3, and 4 in the table above only.

*2 External signal is input to CN3D on the outdoor unit whose SW4-4 is set to ON. When SW4-4 is set to OFF on all outdoor units, the signal is input to the CN3D on the OC.

Outdoor units whose SW4-4 is set to ON are selectable in a single refrigerant system.

*3 If wrong sequence of steps are taken, the units may go into the Thermo-OFF (compressor stop) mode. Ex) When switching from 100% to 50% (Incorrect) 100%→0%→50% The units may go into the Thermo-OFF mode. (Correct) 100%→75%→50%

*4 The percentage of the demand listed in the table above is an approximate value based on the compressor volume and does not necessarily correspond with the actual capacity.

*5 Notes on using demand control in combination with the low-noise mode

To enable the low-noise mode, it is necessary to short-circuit 1-2 pin of CN3D on the outdoor unit whose SW4-4 is set to OFF. When SW4-4 is set to ON on all outdoor units, the following operations cannot be performed.

- •Performing 4-step demand in combination with the low-noise operation in a single-outdoor-unit system.
- Performing 8-step demand in combination with the low-noise operation in a two-outdoor-unit system.

2) Contact input and control content

2-step demand control

The same control as the Thermo-OFF is performed by closing 1-3 pin of CN3D.

CN3D	
1-3	
Open	100%
Close	0%

4-step demand control (When SW4-4 is set to ON on an outdoor unit)

Demand capacity is shown below.

CN3D	1-2P		
1-3P	Open	Close	
Open	100%	75%	
Close	0%	50%	

8-step demand control (When SW4-4 is set to ON on two outdoor units)

Demand capacity is shown below.

8-step demand		No.2 CN3D				
		1-2P	Oį	pen	Short	-circuit
No.1 CN3D	1-2P	1-3P	Open	Short-circuit	Open	Short-circuit
	Open	Open	100%	50%	88%	75%
		Short-circuit	50%	0%	38%	25%
	Short-circuit	Open	88%	38%	75%	63%
		Short-circuit	75%	25%	63%	50%

^{*1.} The outdoor units whose SW4-4 is set to ON are designated as No. 1 and No. 2 in the order of address from small to large. Ex) When outdoor units whose SW4-4 is set to ON are designated as OC and OS, OC=No. 1 and OS=No. 2.

[4] Sample System Connection

Examples of typical system connection are shown on pages [5] to [7]. Refer to the Installation Manual that came with each device or controller for details.

(1) An example of a system to which an MA remote controller is connected

	System configuration	Connection to the system controller Address start up for indoor and outdoor units		Notes
1	System with one out- door unit	NO	Automatic address setup	
2	System with one out- door unit	NO	Manual address setup	Connection of multiple LOSS- NAY units
3	Grouping of units in a system with multiple outdoor units	NO	Manual address setup	
4	System with one out- door unit	With connection to transmission line for centralized control	Manual address setup	
5	System with one out- door unit	With connection to indoor-outdoor transmission line	Manual address setup	
6	System with one out- door unit	With connection to transmission line for centralized control	Manual address setup	Connection of multiple LOSS- NAY units

(2) An example of a system to which an ME remote controller is connected

	System configuration	Connection to the system controller	Address start up for indoor and outdoor units	Notes
1	System with one out- door unit	With connection to transmission line for centralized control	Manual address setup	


(3) An example of a system to which both MA remote controller and ME remote controller are connected

	System configuration	Connection to the system controller	Address start up for in- door and outdoor units	Notes
1	System with one out- door unit	With connection to transmission line for centralized control	Manual address setup	

[5] An Example of a System to which an MA Remote Controller is connected

1. System with one outdoor unit (automatic address setup for both indoor and outdoor units)

(1) Sample control wiring



(2) Cautions

- ME remote controller and MA remote controller cannot both be connected to the same group of indoor units.
- 2) No more than 2 MA remote controllers can be connected to a group of indoor units.
- When the number of the connected indoor units is as shown in the table below, one or more transmission boosters (sold separately) are required.

To connect two transmission boosters, connect them in parallel. (Observe the maximum number of connectable indoor units that are listed in the specifications for each outdoor unit.)

	Number of transmission booster (sold separately) re- quired			
	1 unit	2 units		
When the P72 and P96 models are not included in the connected indoor units	27 - 50 units	-		
When the P72 and P96 models are included in the connected indoor units	21 - 39 units	40 - 50 units		

•The table above shows the number of transmission boosters that is required by the system with three BC controllers. For each BC controller that is subtracted from the above-mentioned system, two additional indoor units can be connected.

- Automatic address setup is not available if start-stop input(CN32, CN51, CN41) is used for a group operation of indoor units. Refer to "[5] 2. Manual address setup for both indoor and outdoor units"
- 5) To connect more than 2 LOSSNAY units to indoor units in the same system, refer to "[5] 2. An example of a system with one outdoor unit to which 2 or more LOSSNAY units are connected".

(3) Maximum allowable length

- Indoor/outdoor transmission line
 Maximum distance (1.25mm² [AWG16] or larger)
 L1 +L2+L3+L4+L5≤200m[656ft]
 L1 +L2+L3+L11+L12+L13≤200m[656ft]
- 2) Transmission line for centralized control

No connection is required.

MA remote controller wiring

Maximum overall line length
(0.3 to 1.25mm² [AWG22 to 16])

m1≤200m [656ft]

m2+m3≤200m [656ft]

m4+m5≤200m [656ft]

1) Indoor/outdoor transmission line

Daisy-chain terminals M1 and M2 of the terminal block for indoor-outdoor transmission line (TB3) on the outdoor units (OC and OS), of the terminal block for indoor-outdoor transmission line (TB02) on the main BC controller (BC), and of the terminal block for indoor-outdoor transmission line (TB5) on each indoor unit (IC). (Non-polarized two-wire)

Only use shielded cables.

Note

The outdoor units in the same refrigerant circuit are automatically designated as OC and OS in the order of capacity from large to small (if two or more units have the same capacity, in the order of address from small to large).

Shielded cable connection

Daisy-chain the ground terminal ($//_{\!\! T}$) on the outdoor units (OC and OS), the S terminal of the terminal block (TB02) on the BC controller (BC), and the S terminal of the terminal block (TB5) on the indoor unit (IC) with the shield of the shielded cable.

2) Transmission line for centralized control

No connection is required.

MA remote controller wiring

Connect terminals 1 and 2 on the terminal block for MA remote controller line (TB15) on the indoor unit (IC) to the terminal block on the MA remote controller (MA). (Non-polarized two-wire)

When 2 remote controllers are connected to the system

When 2 remote controllers are connected to the system, connect terminals 1 and 2 of the terminal block (TB15) on the indoor unit (IC) to the terminal block on the two MA remote controllers.

•Set one of the MA remote controllers as a sub controller. (Refer to the Instruction Manual for the MA remote controller for the setting method.)

Group operation of indoor units

To perform a group operation of indoor units (IC), daisy-chain terminals 1 and 2 on the terminal block (TB15) on all indoor units (IC) in the same group, and then connect terminals 1 and 2 on the terminal block (TB15) on the indoor unit on one end to the terminal block on the MA remotecontroller. (Non-polarized two-wire)

•When performing a group operation of indoor units that have different functions, "Automatic indoor/outdoor addresssetup" is not available.

4) LOSSNAY connection

Connect terminals M1 and M2 on the terminal block(TB5) on the indoor unit (IC) to the appropriate terminals on the terminal block (TB5) on LOSSNAY (LC). (Non-polarized two-wire)

- Interlock operation setting with all the indoor units in the same system will automatically be made. (It is required that the Lossnay unit be turned on before the outdoorunit.)
- •When performing an interlocked operation of part of the indoor units in the system with a LOSSNAY unit, using a LOSSNAY unit alone without interlocking it with any units, performing an interlock operation of more than 16 indoor units with a LOSSNAY unit, or connecting two or more LOSSNAY units to the same refrigerant system, the automatic IC/OC address setup function is not available.
- Switch setting

No address settings required.

(5) Address setting method

Proce- dures	Unit	or controller		Address set- ting range	Setting method	Notes	Factory setting
1	Indoor unit	Main unit	IC IC	No settings required.	-	Port number setting is required To perform a group operation of indoor units that feature different functions, the automatic IC/OC address setup function is not available.	00
2	LOSSNAY		LC	No settings required.	-		00
3	MA remote con- troller	Main remote con- troller	MA	No settings required.	-		Main
		Sub remote con- troller	MA	Sub remote con- troller	Settings to be made with the Sub/Main switch		
4	Outdoor unit		OC OS	No settings required.	-		00
5	Auxiliary outdoor unit	BC controller	ВС	No settings required.	-		00


Note

The outdoor units in the same refrigerant circuit are automatically designated as OC and OS.

They are designated as OC and OS in the descending order of capacity (ascending order of address if the capacities are the same).

2. An example of a system with one outdoor unit to which 2 or more LOSSNAY units are connected (manual address setup for both indoor and outdoor units)

(1) Sample control wiring



MA

* If the BC address overlaps any of the addresses that are assigned to either the OC, OS, or BS, use a different, unused address.

OC, OS, and BS addresses (lowest indoor unit address in the group plus +50) have higher priority than the BS address.

(2) Cautions

- ME remote controller and MA remote controller cannot both be connected to the same group of indoor units.
- No more than 2 MA remote controllers can be connected to a group of indoor units.
- When the number of the connected indoor units is as shown in the table below, one or more transmission boosters (sold separately) are required.

To connect two transmission boosters, connect them in parallel. (Observe the maximum number of connectable indoor units that are listed in the specifications for each outdoor unit.)

	Number of transmission booster (sold separately) required			
	1 unit	2 units		
When the P72 and P96 models are not included in the connected indoor units	27 - 50 units	-		
When the P72 and P96 models are included in the connected indoor units	21 - 39 units	40 - 50 units		

•The table above shows the number of transmission boosters that is required by the system with three BC controllers. For each BC controller that is subtracted from the above-mentioned system, two additional indoor units can be connected.

(3) Maximum allowable length

- 1) Indoor/outdoor transmission line Same as [5] 1.
- Transmission line for centralized control No connection is required.
- 3) MA remote controller wiring Same as [5] 1.

1) Indoor/outdoor transmission line

Daisy-chain terminals M1 and M2 of the terminal block for indoor-outdoor transmission line (TB3) on the outdoor units (OC and OS), of the terminal block for indoor-outdoor transmission line (TB02) on the main and sub BC controllers (BC and BS), and of the terminal block for indoor-outdoor transmission line (TB5) on each indoor unit (IC). (Non-polarized two-wire)

Only use shielded cables.

Note

The outdoor units in the same refrigerant circuit are automatically designated as OC and OS in the order of capacity from large to small (if two or more units have the same capacity, in the order of address from small to large).

Shielded cable connection

Daisy-chain the ground terminal (\not ___,) on the outdoor units (OC and OS), the S terminal of the terminal block (TB02) on BC and BS, and the S terminal of the terminal block (TB5) on the indoor unit (IC) with the shield of the shielded cable.

 Transmission line for centralized control No connection is required.

3) MA remote controller wiring

Same as [5] 1.

When 2 remote controllers are connected to the system

Same as [5] 1.

Group operation of indoor units

Same as [5] 1.

4) LOSSNAY connection

Connect terminals M1 and M2 on the terminal block (TB5) on the indoor unit (IC) to the appropriate terminals on the terminal block (TB5) on LOSSNAY (LC). (Non-polarized two-wire)

•Interlock setting between the indoor units and LOSS-NAY units must be entered on the remote controller. (Refer to "IV [3] Interlock Settings via the MA Remote Controller" or the installation manual for the MA remote controller for the setting method.)

Switch setting

Address setting is required as follows.

(5) Address setting method

Proce- dures	Unit or controller			Address setting range	Setting method	Notes	Fac- tory set- ting
1	Indoor unit	Main unit	IC	01 to 50	Assign the smallest address to the main unit in the group. In a system with a sub BC controller, make the settings for the indoor units in the following order. (i) Indoor unit to be connected to the main BC controller (ii) Indoor unit to be connected to sub BC controller 1 (iii) Indoor unit to be connected to sub BC controller 2 Make the settings for the indoor units in the way that the formula "(i) < (ii) < (iii)" is true.	Port number setting is required To perform a group operation of indoor units that feature different functions, designate the indoor unit in the group with the greatest number of functions as the main unit.	00
		Sub unit			Assign sequential numbers starting with the address of the main unit in the same group +1. (Main unit address +1, main unit address +2, main unit address +3, etc.)		
2	LOSSNAY		LC	01 to 50	Assign an arbitrary but unique address to each of these units after assigning an address to all indoor units.	None of these addresses may overlap any of the indoor unit addresses.	00
3	MA remote controller	Main remote controller	MA	No set- tings re- quired.	-		Main
		Sub remote controller	MA	Sub remote controller	Settings to be made with the Sub/ Main switch		
4	Outdoor unit		OC OS	51 to 100	Assign sequential address to the outdoor units in the same refrigerant circuit. The outdoor units are automatically designated as OC and OS.(Note)	To set the address to 100, set the rotary switches to 50. If the addresses that is assigned to the main BC controller overlaps any of the	00
5	Auxiliary outdoor unit	BCcon- troller (Sub)	BS	51 to 100	Assign an address that equals the sum of the smallest address of the indoor units that are connected to the sub BC controller and 50.	addresses that are assigned to the outdoor units or to the sub BC controller, use a different, unused address with in the setting range.	
		BC control- ler (Main)	ВС		OC (or OS if it exists) +1	•The use of a sub BC control- ler requires the connection of a main BC controller.	


Note

The outdoor units in the same refrigerant circuit are automatically designated as OC and OS.

They are designated as OC and OS in the descending order of capacity (ascending order of address if the capacities are the same).

3. Group operation of units in a system with multiple outdoor units

(1) Sample control wiring



(2) Cautions

- ME remote controller and MA remote controller cannot both be connected to the same group of indoor units.
- No more than 2 MA remote controllers can be connected to a group of indoor units.
- Do not connect the terminal blocks (TB5) on the indoor units that are connected to different outdoor units with each other.
- Replacement of male power jumper connector (CN41) must be performed only on one of the outdoor units.
- Provide grounding to S terminal on the terminal block for transmission line for centralized control (TB7) on only one of the outdoor units.
- 6) When the number of the connected indoor units is as shown in the table below, one or more transmission boosters (sold separately) are required.

To connect two transmission boosters, connect them in parallel. (Observe the maximum number of connectable indoor units that are listed in the specifications for each outdoor unit.)

	Number of transmission booster (sold separately) required			
	1 unit	2 units		
When the P72 and P96 models are not included in the connected indoor units	27 - 50 units	-		
When the P72 and P96 models are included in the connected indoor units	21 - 39 units	40 - 50 units		

•The left table shows the number of transmission boosters that is required by the system with three BC controllers. For each BC controller that is subtracted from the above-mentioned system, two additional indoor units can be connected.

(3) Maximum allowable length

- Indoor/outdoor transmission line
 Maximum distance (1.25mm² [AWG16] or larger)
 L11+L12≤200m [656ft]
 L21+L22≤200m [656ft]
- Transmission line for centralized control L31+L21≤200m [656ft]
- 3) MA remote controller wiring Same as [5] 1.
- 4) Maximum line distance via outdoor unit (1.25mm² [AWG16] or larger)
 L12(L11)+L31+L22(L21)≤500m [1640ft]

1) Indoor/outdoor transmission line

Same as [5] 2.

Shielded cable connection

Same as [5] 2.

Transmission line for centralized control

Daisy-chain terminals M1 and M2 on the terminal block for transmission line for centralized control (TB7) on the outdoor units (OC) in different refrigerant circuits and on the OC and OS (Note a) in the same refrigerant circuit. If a power supply unit is not connected to the transmission line for centralized control, replace the power jumper con-nector on the control board from CN41 to CN40 on only one of the outdoor units.

a) The outdoor units in the same refrigerant circuit are automatically designated as OC and OS in the order of capacity from large to small (if two or more units have the same capacity, in the order of address from small to large).
b) If TB7's on the outdoor units in the same refrigerant circuit

are not daisy-chained, connect the transmission line for the central control system to TB7 of the OC. (Note a).To maintain the central control even during an OC failure or a power failure, connect TB7 on OC and OS together. (If there is a

problem with the outdoor unit whose power jumper was moved from CN41 to CN40, central control is not possible, even if TB7's are daisy-chained.)

Only use shielded cables.

Shielded cable connection

Daisy-chain the S terminal on the terminal block (TB7) on the outdoor units (OC, OS) with the shield wire of the shielded cable. Short-circuit the earth terminal (,) and the S terminal on the terminal block (TB7) on the outdoor unit whose power jumper connector is mated with CN40.

MA remote controller wiring

Same as [5] 1.

When 2 remote controllers are connected to the system Same as [5] 1.

Group operation of indoor units

Same as [5] 1. LOSSNAY connection

Same as [5] 2.

Switch setting

Address setting is required as follows.

(5) Address setting method

Proce- dures	Unit or controller			Address setting range	Setting method	Notes	Fac- tory set- ting
1	Indoor unit	Main unit	IC	01 to 50	Assign the smallest address to the main unit in the group. In a system with a sub BC controller, make the settings for the indoor units in the following order. (i) Indoor unit to be connected to the main BC controller (ii) Indoor unit to be connected to sub BC controller 1 (iii) Indoor unit to be connected to sub BC controller 2 Make the settings for the indoor units in the way that the formula "(i) < (ii) < (iii)" is true. Assign sequential numbers starting with the address of the main unit in the same	Port number setting is required To perform a group operation of indoor units that feature different functions, designate the indoor unit in the group with the greatest number of functions as the main unit.	00
					group +1. (Main unit address +1, main unit address +2, main unit address +3, etc.)		
2	LOSSNAY LC		LC	01 to 50	Assign an arbitrary but unique address to each of these units after assigning an address to all indoor units.	None of these addresses may overlap any of the indoor unit addresses.	00
3	MA remote controller	Main remote controller	MA	No set- tings re- quired.	-		Main
		Sub remote controller	MA	Sub remote controller	Settings to be made with the Sub/ Main switch		
4			OC OS	51 to 100	Assign sequential address to the outdoor units in the same refrigerant circuit. The outdoor units are automatically designated as OC and OS.(Note)	To set the address to 100, set the rotary switches to 50. If the addresses that is assigned to the main BC controller overlage any of the set	00
5	Auxiliary outdoor unit	outdoor troller (Sub)		51 to 100	Assign an address that equals the sum of the smallest address of the indoor units that are connected to the sub BC controller and 50.	troller overlaps any of the addresses that are assigned to the outdoor units or to the sub BC controller, use a dif- ferent, unused address with- in the setting range.	
		BC control- ler (Main)	ВС		OC (or OS if it exists) +1	The use of a sub BC controller requires the connection of a main BC controller.	


Note

The outdoor units in the same refrigerant circuit are automatically designated as OC and OS.

They are designated as OC and OS in the descending order of capacity (ascending order of address if the capacities are the same).

4. A system in which a system controller is connected to the transmission line for centralized control and which is powered from an outdoor unit

(1) Sample control wiring



(2) Cautions

- ME remote controller and MA remote controller cannot both be connected to the same group of indoor units.
- No more than 2 MA remote controllers can be connected to a group of indoor units.
- Do not connect the terminal blocks (TB5) on the indoor units that are connected to different outdoor units with each other.
- Replacement of male power jumper connector (CN41) must be performed only on one of the outdoor units.
- 6) When the number of the connected indoor units is as shown in the table below, one or more transmission boosters (sold separately) are required.
 - To connect two transmission boosters, connect them in parallel. (Observe the maximum number of connectable indoor units that are listed in the specifications for each outdoor unit.)

	Number of transmission booster (sold separately) required		
	1 unit	2 units	
When the P72 and P96 models are not included in the connected indoor units	27 - 50 units	-	
When the P72 and P96 models are included in the connected indoor units	21 - 39 units	40 - 50 units	

- •The left table shows the number of transmission boosters that is required by the system with three BC controllers. For each BC controller that is subtracted from the above-mentioned system, two additional indoor units can be connected.
- When a power supply unit is connected to the transmission line for centralized control, leave the power jumper connector on CN41 as it is (factory setting).

(3) Maximum allowable length

- Indoor/outdoor transmission line Same as [5] 3.
- Transmission line for centralized control L31+L32(L21) ≤200m [656ft]
- 3) MA remote controller wiring Same as [5] 1.
- 4) Maximum line distance via outdoor unit (1.25mm² [AWG16] or larger)
 L32+L31+L12(L11) ≤500m [1640ft]
 L32+L22(L21) ≤500m [1640ft]
 L12(L11)+L31+L22(L21) ≤500m[1640ft]

1) Indoor/outdoor transmission line

Same as [5] 2.

Only use shielded cables.

Shielded cable connection

Same as [5] 2.

2) Transmission line for centralized control

Daisy-chain terminals A and B on the system controller, terminals M1 and M2 on the terminal block for transmission line for centralized control (TB7) on the outdoor units (OC) in different refrigerant circuits and on the outdoor units (OC and OS) in the same refrigerant circuit. (Note b)
If a power supply unit is not connected to the transmission

line for centralized control, replace the power jumper connector on the control board from CN41 to CN40 on only one of the outdoor units

If a system controller is connected, set the central control switch (SW2-1) on the control board of all outdoor units to "ON."

Note

a) The outdoor units in the same refrigerant circuit are automatically designated as OC and OS in the order of capacity from large to small (if two or more units have the same capacity, in the order of address from small to large)

b) If TB7's on the outdoor units in the same refrigerant circuit are not daisy-chained, connect the transmission line for the central control system to TB7 of the OC. (Note a). To maintain the central control even during an OC failure or a power failure, connect TB7 on OC and OS together. (If there is a problem with the outdoor unit whose power jumper was moved from CN41 to CN40, central control is not possible, even if TB7's are daisy-chained.)

Only use shielded cables.

Shielded cable connection

Daisy-chain the S terminal of the terminal block (TB7) on the system controller, OC, and OS with the shield of the shielded cable. Short-circuit the earth terminal (+,) and the S terminal (+,) minal on the terminal block (TB7) on the outdoor unit whose power jumper connector is mated with CN40.

MA remote controller wiring

Same as [5] 1.

When 2 remote controllers are connected to the system

Group operation of indoor units

Same as [5] 1. LOSSNAY connection

Connect terminals M1 and M2 on the terminal block (TB5) on the indoor unit (IC) to the appropriate terminals on the terminal block for indoor-outdoor transmission line (TB5) on LOSSNAY (LC). (Non-polarized two-wire)

- Indoor units must be interlocked with the LOSSNAY unit using the system controller. (Refer to the operation manual for the system controller for the setting method.) Interlock set-ting from the remote controller is required if the ON/OFF remote controller alone or the LM adapter alone is connected.
- Switch setting

Address setting is required as follows.

(5) Address setting method

Proce- dures	Unit or controller		Ad- dress setting range	Setting method	Notes	Fac- tory set- ting	
1	Indoor Main unit unit		IC	01 to 50	Assign the smallest address to the main unit in the group. In a system with a sub BC controller, make the settings for the indoor units in the following order. (i) Indoor unit to be connected to the main BC controller (ii) Indoor unit to be connected to sub BC controller 1 (iii) Indoor unit to be connected to sub BC controller 2 Make the settings for the indoor units in the way that the formula "(i) < (ii) < (iii)" is true.	Port number setting is required To perform a group operation of indoor units that feature different functions, designate the indoor unit in the group with the greatest number of functions as the main unit.	00
		Sub unit			Assign sequential numbers starting with the address of the main unit in the same group +1. (Main unit address +1, main unit address +2, main unit address +3, etc.)		
2	LOSSNAY LC		LC	01 to 50	Assign an arbitrary but unique address to each of these units after assigning an address to all indoor units.	None of these addresses may overlap any of the indoor unit addresses.	00
3	MA remote controller	Main remote con- troller	MA	No set- tings re- quired.	-	Make the same indoor unit group settings with the system controller as the ones that were made with the MA remote	Main
		Sub remote con- troller	MA	Sub remote controller	Settings to be made with the Sub/ Main switch	controller.	
4			OC OS	51 to 100	Assign sequential address to the outdoor units in the same refrigerant circuit. The outdoor units are automatically designated as OC and OS.(Note)	To set the address to 100, set the rotary switches to 50. If the addresses that is assigned to the main BC controller overlaps any of the	00
5	Auxiliary outdoor unit	outdoor troller (Sub)		51 to 100	Assign an address that equals the sum of the smallest address of the indoor units that are connected to the sub BC controller and 50.	addresses that are assigned to the outdoor units or to the sub BC controller, use a dif- ferent, unused address with-	
	ume	BC control- ler (Main)	OC (or OS if it exists) +1 in the setting rang. The use of a sub B ler requires the co		in the setting range. •The use of a sub BC controller requires the connection of a main BC controller.		


Note

The outdoor units in the same refrigerant circuit are automatically designated as OC and OS.

They are designated as OC and OŠ in the descending order of capacity (ascending order of address if the capacities are the same).

5. An example of a system in which a system controller is connected to the indoor-outdoor transmission line (except LM adapter)

(1) Sample control wiring



(2) Cautions

- ME remote controller and MA remote controller cannot both be connected to the same group of indoor units.
- No more than 2 MA remote controllers can be connected to a group of indoor units.
- Do not connect the terminal blocks (TB5) on the indoor units that are connected to different outdoor units with each other.
- Replacement of male power jumper connector (CN41) must be performed only on one of the outdoor units.
- Provide grounding to S terminal on the terminal block for transmission line for centralized control (TB7) on only one of the outdoor units.
- 6) A maximum of 3 system controllers can be connected to the indooroutdoor transmission line, with the exception that only one G(B)-50A may be connected.
- 7) When the total number of indoor units exceeds 20 (12 if one or more indoor units of the 72 model or above is connected), it may not be possible to connect a system controller to the indoor-outdoor transmission line.
- When the number of the connected indoor units is as shown in the table below, one or more transmission boosters (sold separately) are required.
 - To connect two transmission boosters, connect them in parallel. (Observe the maximum number of connectable indoor units that are listed in the specifications for each outdoor unit.)

	Number of transmission booster (sold separately) required			
	1 unit	2 units		
When the P72 and P96 models are not included in the connected indoor units	27 - 50 units	-		
When the P72 and P96 models are included in the connected indoor units	21 - 39 units	40 - 50 units		
T1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1				

•The table above shows the number of transmission boosters that is required by the system with three BC controllers. For each BC controller that is subtracted from the above-mentioned system, two additional indoor units can be connected.

(3) Maximum allowable length

1) Indoor/outdoor transmission line

Maximum distance (1.25mm² [AWG16] or larger) L11+L12≤200m [656ft] L21+L22≤200m [656ft] L25≤200m [656ft]

- 2) Transmission line for centralized control
 - L31+L21≤200m [656ft]
- 3) MA remote controller wiring

Same as [5] 1.

4) Maximum line distance via outdoor unit (1.25mm² [AWG16] or larger) L25+L31+L12(L11)≤500m [1640ft] L12(L11)+L31+L22(L21)≤500m [1640ft]

1) Indoor/outdoor transmission line

Daisy-chain terminals M1 and M2 of the terminal block for indooroutdoor transmission line (TB3) on the outdoor units (OC and OS) (Note a), of the terminal block for indoor-outdoor transmission line (TB02) on the main and sub BC controllers (BC and BS), of the terminal block for indoor-outdoor transmission line (TB5) on each indoor unit (IC), and the S terminal of the system controller.(Non-polarized two-wire)

Only use shielded cables.

Note

The outdoor units in the same refrigerant circuit are automatically designated as OC and OS in the order of capacity from large to small (if two or more units have the same capacity, in the order of address from small to large).

Shielded cable connection

Daisy-chain the ground terminal (//) on the outdoor units (OC and OS), the S terminal of the terminal block (TB02) on the BC and BS, and the S terminal of the terminal block (TB5) on the indoor unit (IC) with the shield of the shielded cable.

Transmission line for centralized control

Daisy-chain terminals M1 and M2 on the terminal block for transmission line for centralized control (TB7) on the outdoor units (OC) in different refrigerant circuits and on the OC and OS in the same re-

If a power supply unit is not connected to the transmission line for centralized control, replace the power jumper connector on the control board from CN41 to CN40 on only one of the outdoor units.

Set the central control switch (SW2-1) on the control board of all outdoor units to "ON.

Note

b) If TB7's on the outdoor units in the same refrigerant circuit are not

(5) Address setting method

daisy-chained, connect the transmission line for the central control system to TB7 of the OC. (Note a).To maintain the central control even during an OC failure or a power failure, connect TB7 on OC and OS together. (If there is a problem with the outdoor unit whose power jumper was moved from CN41 to CN40, central control is not possible, even if TB7's are daisy-chained.)

Only use shielded cables

Shielded cable connection

Daisy-chain the S terminal on the terminal block (TB7) on the out-door units (OC, OS) with the shield wire of the shielded cable. Shortdoor units (co., co) with the sine whee of the shielded cable. On the terminal of h) and the S terminal on the terminal block (TB7) on the outdoor unit whose power jumper connector is mated with CN40.

MA remote controller wiring

Same as [5] 1.

When 2 remote controllers are connected to the system Same as [5] 1.

Group operation of indoor units

Same as [5] 1. LOSSNAY connection

Connect terminals M1 and M2 on the terminal block (TB5) on the indoor units (IC) to the appropriate terminals on the terminal block for indoor-outdoor transmission line (TB5) on LOSSNAY (LC). (Non-po-

Indoor units must be interlocked with the LOSSNAY unit using the system controller. (Refer to the operation manual for the system controller for the setting method. Interlock setting from the remote controller is required if the ON/OFF remote controller alone is connected

Switch setting

Address setting is required as follows.


Proce- dures	Unit	or controller		Address setting range	Setting method	Notes	Facto- ry set- ting
1	Indoor unit	Main unit	IC	01 to 50	Assign the smallest address to the main unit in the group. In a system with a sub BC controller, make the settings for the indoor units in the following order. (i) Indoor unit to be connected to the main BC controller (ii) Indoor unit to be connected to sub BC controller 1 (iii) Indoor unit to be connected to sub BC controller 2 Make the settings for the indoor units in the way that the formula "(i) < (ii) < (iii)" is true.	Port number setting is required To perform a group operation of indoor units that feature different functions, designate the indoor unit in the group with the greatest number of functions as the main unit.	00
		Sub unit			Assign sequential numbers starting with the address of the main unit in the same group +1. (Main unit address +1, main unit address +2, main unit address +3, etc.)		
2	LOSSNAY		LC	01 to 50	Assign an arbitrary but unique address to each of these units after assigning an address to all indoor units.	None of these addresses may overlap any of the indoor unit addresses.	00
3	MA remote controller	Main remote con- troller	MA	No set- tings re- quired.	-	Make the same indoor unit group settings with the system controller as the ones that were made with the MA remote	Main
		Sub remote con- troller	MA	Sub remote controller	Settings to be made with the Sub/ Main switch	controller.	
4			OC OS	51 to 100	Assign sequential address to the outdoor units in the same refrigerant circuit. The outdoor units are automatically designated as OC and OS.(Note)	To set the address to 100, set the rotary switches to 50. If the addresses that is assigned to the main BC controller overlaps any of the	00
5	5 Auxiliary outdoor unit	outdoor troller (Sub)		51 to 100	Assign an address that equals the sum of the smallest address of the indoor units that are connected to the sub BC controller and 50.	addresses that are assigned to the outdoor units or to the sub BC controller, use a dif- ferent, unused address with-	
		BC control- ler (Main)	BC		OC (or OS if it exists) +1	in the setting range. •The use of a sub BC controller requires the connection of a main BC controller.	

Note

The outdoor units in the same refrigerant circuit are automatically designated as OC and OS.
They are designated as OC and OS in the descending order of capacity (ascending order of address if the capacities are the same).

6. A system with multiple BC controller connections (with a system controller connected to the centralized control line)

(1) Sample control wiring



(2) Cautions

- ME remote controller and MA remote controller cannot both be connected to the same group of indoor units.
- No more than 2 MA remote controllers can be connected to a group of indoor units.
- Do not connect the terminal blocks (TB5) on the indoor units that are connected to different outdoor units with each other.
- Replacement of male power jumper connector (CN41) must be performed only on one of the outdoor units.
- 5) Short-circuit the S (shield) terminal of the terminal block for the central control unit (TB7) and the ground terminal (1/17) on the outdoor unit whose power jumper was moved from CN41 to CN40.
- 6) When the number of the connected indoor units is as shown in the table below, one or more transmission boosters (sold separately) are required.

To connect two transmission boosters, connect them in parallel. (Observe the maximum number of connectable indoor units that are listed in the specifications for each outdoor unit.)

	Number of transmission booster (sold separately) required		
	1 unit	2 units	
When the P72 and P96 models are not included in the connected indoor units	27 - 50 units	-	
When the P72 and P96 models are included in the connected indoor units	21 - 39 units	40 - 50 units	

- •The table above shows the number of transmission boosters that is required by the system with three BC controllers. For each BC controller that is subtracted from the abovementioned system, two additional indoor units can be connected.
- When a power supply unit is connected to the transmission line for centralized control, leave the power jumper connector on CN41 as it is (factory setting).

(3) Maximum allowable length

- Indoor/outdoor transmission line
 Maximum distance (1.25mm² [AWG16] or larger)
 L11+L12≤200m [656ft]
 L21+L22≤200m [656ft]
- 2) Transmission line for centralized control L31+L32(L21) ≤200m [656ft]
- MA remote controller wiring

 Maximum overall line length
 (0.3 to 1.25mm² [AWG22 to 16])
 m1≤200m [656ft]
 m2+m3≤200m [656ft]
- 4) Maximum line distance via outdoor unit (1.25mm² [AWG16] or larger)
 L32+L31+L12(L11) ≤500m [1640ft]
 L32+L22(L21) ≤500m [1640ft]
 L12(L11)+L31+L22(L21) ≤500m[1640ft]

1) Indoor/outdoor transmission line

Daisy-chain terminals M1 and M2 of the terminal block for indoor-outdoor transmission line (TB3) on the outdoor units (OC and OS) (Note a), of the terminal block for indoor-outdoor transmission line (TB02) on the main and sub BC controllers (BC and BS), and of the terminal block for indoor-outdoor transmission line (TB5) on each indoor unit (IC). (Non-polarized two-wire)

Only use shielded cables.

Note

a) The outdoor units in the same refrigerant circuit are automatically designated as OC and OS in the order of capacity from large to small (if two or more units have the same capacity, in the order of address from small to large).

Shielded cable connection

Daisy-chain the ground terminal (H) on the outdoor units (OC and OS), the S terminal of the terminal block (TB02) on the BC and BS, and the S terminal of the terminal block (TB5) on the indoor unit (IC) with the shield of the shielded cable.

2) Transmission line for centralized control

Daisy-chain terminals A and B of the system controller, M1 and M2 terminals of TB7 (terminal block for centralized control system connection) on the outdoor units (OC) in different refrigerant systems, and M1 and M2 terminals of TB7 (terminal block for centralized control system connection) on the outdoor units (OC and OS) in the same refrigerant circuit. (Note b)

If a power supply unit is not connected to the transmission line for centralized control, replace the power jumper connector on the control board from CN41 to CN40 on only one of the outdoor units.

When connecting a system controller, set the centralized control switch (SW2-1) on the control board of all indoor units to "ON."

Note

b) If TB7's on the outdoor units in the same refrigerant circuit are not daisy-chained, connect the transmission line for the central control system to TB7 of the OC. (Note a). To maintain the central control even during an OC failure or a power failure, connect TB7 on OC and OS together. (If there is a problem with the outdoor unit whose power jumper was moved from CN41 to CN40, central control is not possible, even if TB7's are daisy-chained.)

Only use shielded cables.

Shielded cable connection

Daisy-chain the S terminal of the terminal block (TB7) on the system controller, OC, and OS with the shield of the shielded cable. Short-circuit the earth terminal ($_{/\!\!\!\!/}$) and the S terminal on the terminal block (TB7) on the outdoor unit whose power jumper connector is mated with CN40.

3) MA remote controller wiring

Same as [5] 1.

When 2 remote controllers are connected to the system

Same as [5] 1.

Group operation of indoor units

Same as [5] 1.

4) LOSSNAY connection

Connect terminals M1 and M2 on the terminal block (TB5) on the indoor unit (IC) to the appropriate terminals on the terminal block for indoor-outdoor transmission line (TB5) on LOSSNAY (LC). (Non-polarized two-wire)

- •Indoor units must be interlocked with the LOSSNAY unit using the system controller. (Refer to the operation manual for the system controller for the setting method.) Interlock setting from the remote controller is required if the ON/OFF remote controller alone or the LM adapter alone is connected.
- 5) Switch setting

Address setting is required as follows.

[II Restrictions]

(5) Address setting method

Pro- ce- dur es	Unit or controller		Address setting range	Setting method	Notes	Fac- tory set- ting	
1	Indoor unit	Main unit	IC	01 to 50	Assign the smallest address to the main unit in the group. In a system with a sub BC controller, make the settings for the indoor units in the following order. Indoor unit to be connected to the main BC controller Indoor unit to be connected to sub BC controller 1 Indoor unit to be connected to sub BC controller 1 Indoor unit to be connected to sub BC controller 2 Make the settings for the indoor units in the way that the formula "(i) < (ii) < (iii)" is true. Assign sequential numbers starting with the address of the main unit in the same group +1. (Main unit address +1, main unit address +2, main unit address +3, etc.)	Port number setting is required To perform a group operation of indoor units that feature different functions, designate the indoor unit in the group with the greatest number of functions as the main unit.	00
2	2 LOSSNAY LC		LC	01 to 50	Assign an arbitrary but unique address to each of these units after assigning an address to all indoor units.	None of these addresses may overlap any of the indoor unit addresses.	00
3	3 MA Main re- remote control-		MA	No set- tings re- quired.	-	Make the same indoor unit group settings with the system controller as the ones that were made with the MA remote controller.	Mai n
	ler	Sub re- mote con- troller	MA	Sub re- mote controller	Settings to be made with the Sub/Main switch	the MA remote controller.	
4	Outdoor	unit	OC OS	51 to 100	The sum of the smallest address of the indoor units in the same system and 50. Assign sequential address to the outdoor units in the same refrigerant circuit. The outdoor units are automatically designated as OC and OS.	•To set the address to 100, set the rotary switches to 50.	00
5	5 Auxilia- ry out- door BC controller (Sub)		BS	51 to 100	Assign an address that equals the sum of the smallest address of the indoor units that are connected to the sub BC controller and 50.	•To set the address to 100, set the rotary switches to 50. •If the addresses that is assigned to the maje PC controller	00
	unit	BC con- troller (Main)	ВС	51 to 100	OC (or OS if it exists) +1	to the main BC controller over- laps any of the addresses that are assigned to the outdoor units or to the sub BC control- ler, use a different, unused ad- dress within the setting range. The use of a sub BC controller requires the connection of a main BC controller.	


Note

The outdoor units in the same refrigerant circuit are automatically designated as OC and OS.

They are designated as OC and OS in the descending order of capacity (ascending order of address if the capacities are the same).

[6] An Example of a System to which an ME Remote Controller is connected

(1) Sample control wiring



(2) Cautions

- ME remote controller and MA remote controller cannot both be connected to the same group of indoor units.
- No more than 2 ME remote controllers can be connected to a group of indoor units.
- Do not connect the terminal blocks (TB5) on the indoor units that are connected to different outdoor units with each other.
- 4) Replace the power jumper connector of the control board from CN41 to CN40 on only one of the outdoor units.
- Provide an electrical path to ground for the S terminal on the terminal block for centralized control on only one of the outdoor units
- 6) When the number of the connected indoor units is as shown in the table below, one or more transmission boosters (sold separately) are required.

To connect two transmission boosters, connect them in parallel. (Observe the maximum number of connectable indoor units that are listed in the specifications for each outdoor unit.)

	Number of transmission booster (sold separately) required			
	1 unit	2 units	3 units	
When the P72 and P96 models are not included in the connected indoor units	15 - 34 units	35 - 50 units	-	
When the P72 and P96 models are included in the connected indoor units	11 - 26 units	27 - 42 units	43 - 50 units	

- •The left table shows the number of transmission boosters that is required by the system with three BC controllers. For each BC controller that is subtracted from the above-mentioned system, two additional indoor units can be connected.
- When a power supply unit is connected to the transmission line for centralized control, leave the power jumper connector on CN41 as it is (factory setting).

(3) Maximum allowable length

- 1) Indoor/outdoor transmission line Same as [5] 3.
- Transmission line for centralized control Same as [5] 4.
- 3) ME remote controller wiring

Maximum overall line length (0.3 to 1.25mm² [AWG22 to 16]) m1≤10m [32ft] m2+m3≤10m [32ft]

If the standard-supplied cable must be extended, use a cable with a diameter of 1.25mm² [AWG16]. The section of the cable that exceeds 10m [32ft] must be included in the maximum indoor-outdoor transmission line distance described in (1).

When connected to the terminal block on the Simple remote controller, use cables that meet the following cable size specifications: 0.75 - 1.25 mm² [AWG18-16].

 Maximum line distance via outdoor unit (1.25 mm² [AWG16] or large)
 Same as [5] 4.

[II Restrictions]

(4) Wiring method

1) Indoor/outdoor transmission line

Same as [5] 2.

Shielded cable connection

Same as [5] 2.

2) Transmission line for centralized control

Same as [5] 4.

Shielded cable connection

Same as [5] 4.

3) ME remote controller wiring

ME remote controller is connectable anywhere on the indoor-outdoor transmission line.

When 2 remote controllers are connected to the system

Refer to the section on Switch Setting.

Performing a group operation (including the group operation of units in different refrigerant circuits).

Refer to the section on Switch Setting.

4) LOSSNAY connection

Same as [5] 4.

5) Switch setting

Address setting is required as follows.

(5) Address setting method

Proce- dures	Unit or controller			Ad- dress setting range	Setting method	Notes	Fac- tory set- ting
1	Indoor unit	Main unit	IC	01 to 50	Assign the smallest address to the main unit in the group. In a system with a sub BC controller, make the settings for the indoor units in the following order. (i) Indoor unit to be connected to the main BC controller (ii) Indoor unit to be connected to sub BC controller 1 (iii) Indoor unit to be connected to sub BC controller 2 Make the settings for the indoor units in the way that the formula "(i) < (ii) < (iii)" is true.	Port number setting is required To perform a group operation of indoor units that have different functions, set the indoor unit in the group with the greatest number of functions as the main unit.	00
		Sub unit			Assign sequential numbers starting with the address of the main unit in the same group +1. (Main unit address +1, main unit address +2, main unit address +3, etc.)		
2	LOSSNAY	,	LC	01 to 50	Assign an arbitrary but unique address to each of these units after assigning an address to all indoor units.	None of these addresses may overlap any of the indoor unit addresses.	00
3	ME Main remote controller		RC	101 to 150	Add 100 to the main unit address in the group	*It is not necessary to set the 100s digit. *To set the address to 200, set the rotary switches to 00.	101
		Sub remote con- troller	RC	151 to 200	Add 150 to the main unit address in the group	set the rotary switches to ou.	
4	Outdoor u	nit	OC OS	51 to 100	Assign sequential address to the outdoor units in the same refrigerant circuit. The outdoor units are automatically designated as OC and OS.(Note)	To set the address to 100, set the rotary switches to 50. If the addresses that is assigned to the main BC controller overlaps any of the	00
5	outdoor unit troller (Su BC control		BS BC	51 to 100	Assign an address that equals the sum of the smallest address of the indoor units that are connected to the sub BC controller and 50. OC (or OS if it exists) +1	addresses that are assigned to the outdoor units or to the sub BC controller, use a dif- ferent, unused address with- in the setting range.	
		ler (Main)	50		CO (OF CO II IT EXISTS) 1	*The use of a sub BC controller requires the connection of a main BC controller.	


Note

The outdoor units in the same refrigerant circuit are automatically designated as OC and OS.

They are designated as OC and OS in the descending order of capacity (ascending order of address if the capacities are the same).

[7] An Example of a System to which both MA Remote Controller and ME Remote Controller are connected

(1) Sample control wiring



(2) Cautions

- 1) Be sure to connect a system controller.
- ME remote controller and MA remote controller cannot both be connected to the same group of indoor units.
- Assign to the indoor units connected to the MA remote controller addresses that are smaller than those of the indoor units that are connected to the ME remote controller.
- No more than 2 ME remote controllers can be connected to a group of indoor units.
- No more than 2 MA remote controllers can be connected to a group of indoor units.
- 6) Do not connect the terminal blocks (TB5) on the indoor units that are connected to different outdoor units with each other.
- Replace the power jumper connector of the control board from CN41 to CN40 on only one of the outdoor units.
- Provide an electrical path to ground for the S terminal on the terminal block for centralized control on only one of the outdoor units.
- When the number of the connected indoor units is as shown in the table below, one or more transmission boosters (sold separately) are required.

To connect two transmission boosters, connect them in parallel. (Observe the maximum number of connectable indoor units that are listed in the specifications for each outdoor unit.)

	Number of transmission booster (sold separately) required			
!	1 unit	2 units	3 units	
When the P72 and P96 models are not included in the connected indoor units	15 - 34 units	35 - 50 units	-	
When the P72and P96 models are included in the connected indoor units	11 - 26 units	27 - 42 units	43 - 50 units	

- •The left table shows the number of transmission boosters that is required by the system with three BC controllers. For each BC controller that is subtracted from the above-mentioned system, two additional indoor units can be connected.
- 10) When a power supply unit is connected to the transmission line for centralized control, leave the power jumper connector on CN41 as it is (factory setting).

(3) Maximum allowable length

- 1) Indoor/outdoor transmission line Same as [5] 3.
- Transmission line for centralized control Same as [5] 4.
- MA remote controller wiring Same as [5] 1.
- 4) ME remote controller wiring Same as [6]
- 5) Maximum line distance via outdoor unit (1.25 mm² [AWG16] or larger)
 Same as [5] 4.

1) Indoor/outdoor transmission line

Same as [5] 2.

Shielded cable connection

Same as [5] 2.

2) Transmission line for centralized control

Same as [5] 4.

Shielded cable connection

Same as [5] 4.

3) MA remote controller wiring

(When 2 remote controllers are connected to the system

Group operation of indoor units)

Same as [5] 1.

4) ME remote controller wiring

(When 2 remote controllers are connected to the system

Group operation of indoor units)

Same as [6]

5) LOSSNAY connection

Same as [5] 4.

6) Switch setting

Address setting is required as follows.

(5) Address setting method

Pro- ce- dure s	U	nit or coi	ntroller		Ad- dress set- ting range	Setting method	Notes	Facto- ry set- ting
1	Operation with the MA remote controller	In- door unit	Main unit	IC	01 to 50	Assign the smallest address to the main unit in the group. In a system with a sub BC controller, make the settings for the indoor units in the following order. Indoor unit to be connected to the main BC controller Indoor unit to be connected to sub BC controller 1 Indoor unit to be connected to sub BC controller 2 Make the settings for the indoor units in the way that the formula "(i) < (ii) < (iii)" is true.	Assign an address smaller than that of the indoor unit that is connected to the ME remote controller. Enter the same indoor unit group settings on the system controller as the ones that were entered on the MA remote controller. To perform a group operation of indoor units that have different functions, designate the indoor unit in the group with the greatest number of functions as the main unit. Port number setting is required.	00
			Sub unit	IC	01 to 50	Assign sequential numbers starting with the address of the main unit in the same group +1. (Main unit address +1, main unit address +2, main unit address +3, etc.)		
		MA re- mote con-	Main re- mote control- ler	MA	No set- tings re- quired.	-		Main
		troller	Sub remote control- ler	MA	Sub remote control- ler	Settings to be made according to the remote controller function selection		
2	Opera- tion with	In- door	Main unit	IC	01 to 50	Assign the smallest address to the main unit in the group.	*Assign an address higher than those of the indoor units that are connected to the MA remote controller.	00
	the ME re- mote controller	unit	Sub unit	IC	01 to 50	Assign sequential numbers starting with the address of the main unit in the same group +1. (Main unit address +1, main unit address +2, main unit address +3, etc.)	Make the initial settings for the indoor unit group settings via the system con-	
		ME re- mote con-	Main re- mote control- ler	RC	101 to 150	Add 100 to the main unit address in the group.	•It is not necessary to set the 100s digit. •To set the address to 200, set it to 00.	101
		troller	Sub remote control- ler	RC	151 to 200	Add 150 to the main unit address in the group.		
3	LOSSNAY		LC	01 to 50	Assign an arbitrary but unique address to each of these units after assigning an address to all indoor units.	None of these addresses may over- lap any of the indoor unit addresses.	00	
4	Outdoor unit		OC OS	51 to 100	Assign sequential address to the outdoor units in the same refrigerant circuit. The outdoor units are automatically designated as OC and OS.(Note)	To set the address to 100, set it to 50. If the addresses that is assigned to the main BC controller overlaps any of the addresses that are assigned to the outdoor units or to the sub BC controller, use a different, unused address within the setting range.	00	
5	Auxiliary outdoor unit	BCcontro	oller (Sub)	BS	51 to 100	Assign an address that equals the sum of the smallest address of the indoor units that are connected to the sub BC controller and 50.	The use of a sub BC controller requires the connection of a main BC controller.	
		BC conti (Main)	oller	ВС		OC (or OS if it exists) +1		


Note

The outdoor units in the same refrigerant circuit are automatically designated as OC and OS.

They are designated as OC and OS in the descending order of capacity (ascending order of address if the capacities are the same).

[8] Restrictions on Pipe Length

(1) System that requires 16 BC controller ports or fewer <System with only the main BC controller or standard BC controller>



Unit: m [ft]

	Operation		Pipe sections	Allowable length of pipes
Length	Total pipe length		A+B+a+b+c+d	Refer to the restrictions on the total piping length in the graph on the next page.
	Total pipe length fro to the farthest indo	om the outdoor unit or unit	A+B+d	165 [541] or less (Equivalent length 190 [623] or less)
	Between outdoor unit and BC control- ler		А	110 [360] or less
	Between BC controller and indoor unit		B+d	40 [131] or less*1
Height difference	Between indoor	Outdoor unit above indoor unit	Н	50 [164] or less
	and outdoor units	Outdoor unit be- low indoor unit	H'	40 [131] or less
	Between indoor unit and BC controller		h1	15[49](10[32]) or less*2
	Between indoor un	its	h2	15[49](10[32]) or less *2


^{*1.} When the overall pipe length between the BC controller and the farthest indoor unit exceeds 40m [131ft], observe the restrictions in the figure titled "Restrictions on pipe length" below. (Except the P96 models)

Note


- 1) To connect the P72 through P96 models of indoor units, use an optional twinning pipe kit (Model: CMY-R160-J) and merge the two ports before connecting them.
- 2) Do not connect the P72 or P96 models of indoor units and other models of indoor units at the same port.
- 3) Note the following when connecting multiple indoor units to a single port.
 - •Those indoor units connected to the same port must be installed in the same room.
 - •Set the indoor temperature via the connected remote controller, and when connecting multiple remote controllers, configure these controllers as a group by making appropriate settings. These indoor units can only be operated in the same mode.

^{*2.} When the capacity of the connected indoor units is P72 or above, use the figures in the parentheses as a reference.


■Restrictions on pipe length [PURY-P72, P96TJMU-A, PURY-P72, P96YJMU-A]



■The height difference and the pipe length between BC controller and indoor units



(2) System that requires more than 16 BC controller ports or with multiple BC controllers <Outdoor unit P144 model or below.>



Unit: m [ft]

Operation		Pipe sections	Allowable length of pipes	
Length	Total pipe length		A+B+C+D+E+a+b+c+d+e+f	Refer to the restrictions on the total piping length in the graphon the next page.
	Total pipe length door unit to the faunit		A+C+E+f	165 [541] or less (Equivalent length 190 [623] or less)
	Between outdoor unit and BC controller		Α	110 [360] or less
	Between BC controller and in- door unit		B+d or C+D+e or C+E+f	40 [131] or less*1
Height differ-ence	Between indoor and outdoor units	Outdoor unit above in- door unit	Н	50 [164] or less
		Outdoor unit below in- door unit	H'	40 [131] or less
	Between indoor unit and BC controller		h1	15 [49](10[32]) or less*2
	Between indoor units		h2	15 [49](10[32]) or less *2
	Between the BC controller (main or sub) and the sub BC controller		h3	15 [49] or less


^{*1.} When the overall pipe length between the BC controller and the farthest indoor unit exceeds 40m [131ft], observe the restrictions in the figure titled "Restrictions on pipe length" below. (Except the P96 models)


^{*2.} When the capacity of the connected indoor units is P72 or above, use the figures in the parentheses as a reference.

Note


- 1) A system that requires more than 16 BC controller ports requires two or three BC controllers (main and sub), and three pipes will be used between the main and the sub BC controllers.
- When connecting two sub BC controllers, observe the maximum allowable length in the table above.
- 3) When connecting two sub BC controllers, install them in parallel.
- 4) To connect the P72 through P96 models of indoor units, use an optional twinning pipe kit (Model: CMY-R160-J) and merge the two ports before connecting them.
- Do not connect the P72 or P96 models of indoor units and other models of indoor units at the same port.
- 6) Note the following when connecting multiple indoor units to a single port.
 - •Those indoor units connected to the same port must be installed in the same room.
 - *Set the indoor temperature via the connected remote controller, and when connecting multiple remote controllers, configure these controllers as a group by making appropriate settings. These indoor units can only be operated in the same mode.
- The maximum capacity of the indoor units that is connectable to the CMB-P-NU-GB types of sub BC controllers is P126 or below (when two GB type controllers are connected P126 or below for both combined).

The maximum total capacity of indoor units that is connectable to the sub BC controller CMB-P1016NU-HB is P126 or below. If at least one CMB-P1016NU-HB unit is connected, the maximum total capacity of connectable indoor units to a system with two sub controllers is P168 or below.





(3) System that requires more than 16 BC controller ports or with multiple BC controllers <Outdoor unit P168 model or above.>



Unit: m [ft]

Operation		Pipe sections	Allowable length of pipes	
Length	Total pipe length		F+G+A+B+C+D+E+a+b+c+d+e +f	Refer to the restrictions on the total piping length in the graph on the next page.
	Total pipe length from the out- door unit to the farthest indoor unit		F(G)+A+C+E+f	165 [541] or less (Equivalent length 190 [623] or less)
	Between outdoor controller	unit and BC	F(G)+A	110 [360] or less
	Between BC controller and in- door unit		B+d or C+D+e or C+E+f	40 [131] or less*1
	Between indoor u	ınits	F+G	5 [16] or less
Height differ-ence	Between indoor and outdoor units	Outdoor unit above in- door unit	Н	50 [164] or less
		Outdoor unit below in- door unit	H'	40 [131] or less
	Between indoor unit and BC controller		h1	15 [49](10[32]) or less*2
	Between indoor units		h2	15 [49](10[32]) or less *2
	Between the BC controller (main or sub) and the sub BC controller		h3	15 [49] or less
	Between outdoor	units	h4	0.1 [0.3] or less

^{*1.} When the overall pipe length between the BC controller and the farthest indoor unit exceeds 40m [131ft], observe the restrictions in the figure titled "Restrictions on pipe length" below. (Except the P96 models)


^{*2.} When the capacity of the connected indoor units is P72 or above, use the figures in the parentheses as a reference.


Note

- A system that requires more than 16 BC controller ports requires two or three BC controllers (main and sub), and three pipes will be used between the main and the sub BC controllers.
- 2) When connecting two sub BC controllers, observe the maximum allowable length in the table above.
- 3) When connecting two sub BC controllers, install them in parallel.
- 4) To connect the P72 through P96 models of indoor units, use an optional twinning pipe kit (Model: CMY-R160-J) and merge the two ports before connecting them.
- Do not connect the P72 or P96 models of indoor units and other models of indoor units at the same port.
- Note the following when connecting multiple indoor units to a single port.
 - •Those indoor units connected to the same port must be installed in the same room.
 - •Set the indoor temperature via the connected remote controller, and when connecting multiple remote controllers, configure these controllers as a group by making appropriate settings. These indoor units can only be operated in the same mode.
- 7) The maximum capacity of the indoor units that is connectable to the CMB-P-NU-GB types of sub BC controllers is P126 or below (when two GB type controllers are connected P126 or below for both combined).


The maximum total capacity of indoor units that is connectable to the sub BC controller CMB-P1016NU-HB is P126 or below. If at least one CMB-P1016NU-HB unit is connected, the maximum total capacity of connectable indoor units to a system with two sub controllers is P168 or below.

■ Restrictions on pipe length







[PURY-P216, P240TSJMU-A] [PURY-P216, P240YSJMU-A]



[PURY-P264, P288TSJMU-A] [PURY-P264, P288YSJMU-A]



■ The height difference and the pipe length between BC controller and indoor units



1. Refrigerant pipe size

(1) Between outdoor unit and the first twinning pipe (Part A)

Unit: mm [inch]

Outdoor units	Refrigerant pipe size		Connection to outdoor unit and BC controller	
Odlador units	Low-pressure pipe	High-pressure pipe	Low-pressure pipe	High-pressure pipe
72	ø19.05 [3/4"]	ø15.88 [5/8"]	ø19.05 [3/4"]	ø15.88 [5/8"]
96	ø22.2 [7/8"]	ø19.05 [3/4"]	ø22.2 [7/8"]	ø19.05 [3/4"]
120		19.03 [0/4]		913.03 [3/4]
144				
168	ø28.58 [1-1/8"]	ø22.2[7/8"]	ø28.58 [1-1/8"]	ø22.2 [7/8"]
192			Ø20.00 [1-1/0]	
216				
240		ø28.58 [1-1/8"]		ø28.58 [1-1/8"]
264	ø34.93 [1-3/8"]	ψ20.00 [1-1/0]	ø34.93 [1-3/8"]	2 20.30 [1-1/0]
288			### .00 [1-0/0]	

(2) Between BC controller and indoor unit (Sections a, b, c, d, e, and f)

Unit: mm [inch]

Indoor unit	Refrigerar	Refrigerant pipe size		Indoor unit connection (Flare connection for all models)	
	Liquid pipe	Gas pipe	Liquid pipe	Gas pipe	
P06, P08, P12, P15, P18	ø6.35 [1/4"]	ø12.7 [1/2"]	ø6.35 [1/4"]	ø12.7 [1/2"]	
P24, P27, P30	ø9.52 [3/8"]	ø15.88 [5/8"]	ø9.52 [3/8"]	a1E 00 [E/0"]	
P36, P48, P54	W9.52 [5/6]	Ø 9.32 [3/0]		ø15.88 [5/8"]	
P72		ø19.05 [3/4"]		ø19.05 [3/4"]	
P96	ø12.7 [1/2"]	ø22.2 [7/8"]	ø12.7 [1/2"]	ø22.2 [7/8"]	

(3) Between the main and sub BC controllers (Section C)

Unit: mm [inch]


Indoor unit	Refrigerant	Refrigerant pipe size (Brazed connection on all models)				
indoor driit	Liquid pipe	High-pressure gas pipe	Low-pressure gas pipe			
- P72	ø9.52 [3/8"]	ø15.88 [5/8"]	ø19.05 [3/4"]			
P73 - P108	₩9.32 [3/6]	ø19.05 [3/4"]	ø22.2 [7/8"]			
P109 - P126	ø12.7 [1/2"]	W 13.03 [3/4]				
P127 - P144	W12.7 [1/2]	ø22.2 [7/8"]	ø28.58 [1-1/8"]			
P145 - P168	ø15.88 [5/8"]	WZZ.Z [170]				

Select the proper size pipes for the main unit based on the total capacity of the indoor units that are connected to both sub BC controllers. Select the proper size pipes for the sub controller side based on the total capacity of the indoor units that are connected to the sub controller.

2. Connecting the BC controller

(1) Size of the pipe that fits the standard BC controller ports

P72 - P120 models



The ports of the BC controller accommodates the pipes on P24 - P54 models of indoor units. To connect other types of indoor units, follow the procedure below.

	Operation	Pipe sections		
Operation		High-pressure side (gas)	Low-pressure side (gas)	
Outdoor unit side	PURY-P72TJMU-A PURY-P72YJMU-A	ø15.88 [5/8"] (Brazed connection)	ø19.05 [3/4"] (Brazed connection)	
	PURY-P96TJMU-A PURY-P96YJMU-A	ø19.05 [3/4"]	ø22.2 [7/8"] (Brazed connection)	
	PURY-P120TJMU-A PURY-P120YJMU-A	(Brazed connection)	ø28.58 [1-1/8"] (Brazed connection)	
Indoor unit side		ø9.52 [3/8"] (Flare connection)	ø15.88 [5/8"] (Flare connection)	


^{*} BC controllers can only be connected to P72 - P120 models of outdoor units.


Note

 To connect P06 - P18 models of indoor units use the reducer that is supplied with the BC controller.

Note

To connect P72 - P96 models of indoor units (or when the total capacity of indoor units exceeds P55), use a junction pipe kit and merge the two nozzles.





Note) Use the flare nut that is supplied with the BC controller.


Note

- 3) To connect multiple indoor units to a port (or to a junction pipe)
 - •Maximum total capacity of connected indoor units: P54 or below (in a system with a junction pipe: P96 or below)
 - •Maximum number of connectable indoor units: 3 units
 - •Branch joint: Use CMY-Y102S-G2 (optional accessory).
 - •Refrigerant pipe selection (size of the pipes A and B in the previous page): Select the proper size pipes based on the total capacity of the downstream indoor units, using the table below as a reference.

Total capacity of indoor units	Liquid pipe	Gas pipe
P54 or below	ø9.52 [3/8"]	ø15.88 [5/8"]
P55 - P72	ø9.52 [3/8"]	ø19.05 [3/4"]
P73 - P96	ø9.52 [3/8"]	ø22.2 [7/8"]

(2) Size of the pipe that fits the main BC controller ports

P72 - P288 models



The ports of the BC controller accommodates the pipes on P24 - P54 models of indoor units. To connect other types of indoor units, follow the procedure below.

Note


- 1) To connect P06 P18 models of indoor units use the reducer that is supplied with the BC controller.
- 2) To connect the P72 through P96 models of indoor units (or when the total capacity of indoor units is P55 or above), use an optional twinning pipe kit (Model: CMY-R160-J) to merge two ports before connecting them.
- 3) To connect multiple indoor units to a port (or to a junction pipe)
 - •Maximum total capacity of connected indoor units: P54 or below (in a system with a junction pipe: P96 or below)
 - •Maximum number of connectable indoor units: 3 units
 - *Branch joint: Use CMY-Y102S-G2 (optional accessory).
 - •Refrigerant pipe selection (size of the pipes in sections A and B in the figure above): Select the proper based on the total capacity of the downstream indoor units, using the table below as a reference.

Unit: mm [inch]

Total capacity of indoor units	Liquid pipe	Gas pipe
P54 or below	ø9.52 [3/8"]	ø15.88 [5/8"]
P55 - P72	ø9.52 [3/8"]	ø19.05 [3/4"]
P73 - P96	ø9.52 [3/8"]	ø22.2 [7/8"]

Operation		Pipe sections		
		High pressure side (Liquid)	Low-pressure side (Gas)	
Outdoor unit side	PURY-P72TJMU-A PURY-P72YJMU-A	ø15.88 [5/8"] (Brazed connection)	ø19.05 [3/4"] (Brazed connection)	
	PURY-P96TJMU-A PURY-P96YJMU-A ø19.05 [3/4"]		ø22.2 [7/8"] (Brazed connection)	
	PURY-P120TJMU-A PURY-P120YJMU-A	(Brazed connection)		
	PURY-P144TJMU-A PURY-P144YJMU-A			
	PURY-P168TSJMU-A PURY-P168YSJMU-A	ø22.2 [7/8"] (Brazed connection)	ø28.58 [1-1/8"] (Brazed connection)	
	PURY-P192TSJMU-A PURY-P192YSJMU-A			
	PURY-P216TSJMU-A PURY-P216YSJMU-A			
	PURY-P240TSJMU-A PURY-P240YSJMU-A	ø28.58 [1-1/8"]	ø34.93 [1-3/8"] (Brazed connection)	
	PURY-P264TSJMU-A PURY-P264YSJMU-A	(Brazed connection)		
	PURY-P288TSJMU-A PURY-P288YSJMU-A			
Indoor unit side		ø9.52 [3/8"] (Flare connection)	ø15.88 [5/8"] (Flare connection)	

(3) Size of the pipe that fits the sub BC controller ports



The ports of the BC controller accommodates the pipes on P24 - P54 models of indoor units. To connect other types of indoor units, follow the procedure below.

Note

- 1) To connect P06 P18 models of indoor units use the reducer that is supplied with the BC controller.
- 2) To connect the P72 through P96 models of indoor units (or when the total capacity of indoor units is P55 or above), use an optional twinning pipe kit (Model: CMY-R160-J) to merge two ports before connecting them.
- 3) To connect multiple indoor units to a port (or to a junction pipe)
 - •Maximum total capacity of connected indoor units: P54 or below (in a system with a junction pipe: P96 or below)
 - •Maximum number of connectable indoor units: 3 units
 - *Branch joint: Use CMY-Y102S-G2 (optional accessory).
 - •Refrigerant pipe selection (size of the pipes in sections A and B in the figure above): Select the proper based on the total capacity of the downstream indoor units, using the table below as a reference.

Unit: mm [inch]

Total capacity of indoor units	Liquid pipe	Gas pipe
P54 or below	ø9.52 [3/8"]	ø15.88 [5/8"]
P55 - P72	ø9.52 [3/8"]	ø19.05 [3/4"]
P73 - P96	ø9.52 [3/8"]	ø22.2 [7/8"]


Operation		Pipe sections		
	Total capacity of the indoor units that are connected to the BC controller	High-pressure side (liquid)	Low-pressure side (gas)	Liquid pipe side
On the BC controller side	P72 model or below	ø15.88 [5/8"] (Brazed connection)	ø19.05 [3/4"] (Brazed connection)	ø9.52 [3/8"] (Brazed connection)
	P73 - P108	ø19.05 [3/4"] (Brazed connection)	ø22.2 [7/8"] (Brazed connection)	
	P109 - P126	(Brazed Corniection)		ø12.7 [1/2"] (Brazed connection)
	P127 - P144	ø22.2 [7/8"] (Brazed connection)	ø28.58 [1-1/8"] (Brazed connection)	
	P145 - P168			ø15.88 [5/8"] (Brazed connection)

III Outdoor Unit Components


[1]	Outdoor Unit Components and Refrigerant Circuit	.61
[2]	Control Box of the Outdoor Unit	. 66
[3]	Outdoor Unit Circuit Board	.70
[4]	BC Controller Components	. 80
[5]	Control Box of the BC Controller	. 83
[6]	BC Controller Circuit Board	84

[1] Outdoor Unit Components and Refrigerant Circuit

- 1. Front view of a outdoor unit
- (1) PURY-P72, P96TJMU-A PURY-P72, P96YJMU-A




(2) PURY-P120, P144TJMU-A PURY-P120, P144YJMU-A




2. Refrigerant circuit


(1) PURY-P72TJMU-A PURY-P72YJMU-A



(2) PURY-P96TJMU-A PURY-P96YJMU-A



(3) PURY-P120, P144TJMU-A PURY-P120, P144YJMU-A



The YJMU model has a transformer box.


[2] Control Box of the Outdoor Unit

<HIGH VOLTAGE WARNING>



- · Control box houses high-voltage parts.
- When opening or closing the front panel of the control box, do not let it come into contact with any of the internal components.
- Before inspecting the inside of the control box, turn off the power, keep the unit off for at least 10 minutes, and Check that the voltage across terminals FT-P and FT-N (YJMU) on the INV board or the voltage at both ends of the main capacitor (C1) (TJMU) is 20VDC or below.
 (It takes about 10 minutes to discharge electricity after the power supply is turned off.)


1. PURY-P72TJMU-A



Note

- 1) Exercise caution not to damage the bottom and the front panel of the control box. Damage to these parts affect the water-proof and dust proof properties of the control box and may result in damage to its internal components.
- Faston terminals have a locking function. Make sure the cable heads are securely locked in place. Press the tab on the terminals to remove them.


2. PURY-P96, P120, P144TJMU-A



Note

- 1) Exercise caution not to damage the bottom and the front panel of the control box. Damage to these parts affect the water-proof and dust proof properties of the control box and may result in damage to its internal components.
- 2) Faston terminals have a locking function. Make sure the cable heads are securely locked in place. Press the tab on the terminals to remove them.


3. PURY-P72, P96, P120, P144YJMU-A



Note


- 1) Exercise caution not to damage the bottom and the front panel of the control box. Damage to these parts affect the water-proof and dust proof properties of the control box and may result in damage to its internal components.
- Faston terminals have a locking function. Make sure the cable heads are securely locked in place. Press the tab on the terminals to remove them.

4. Transformer Box (PURY-P72, P96, P120, P144YJMU-A)




[3] Outdoor Unit Circuit Board

1. Outdoor unit control board




2. M-NET board



3. INV board


(1) PURY-P72TJMU-A



Note

Faston terminals have a locking function. Make sure the cable heads are securely locked in place. Press the tab on the terminals to remove them.


(2) PURY-P96, P120, P144TJMU-A



Note

Faston terminals have a locking function. Make sure the cable heads are securely locked in place. Press the tab on the terminals to remove them.

(3) PURY-P72, P96, P120, P144YJMU-A




Note


 Before inspecting the inside of the control box, turn off the power, keep the unit off for at least 10 minutes, and confirm that the voltage between FT-P and FT-N on INV Board has dropped to DC20V or less.
 (It takes about 10 minutes to discharge electricity after the power supply is turned off.)

4. Fan board

(1) PURY-P72, P96, P120, P144TJMU-A




(2) PURY-P72, P96, P120, P144YJMU-A




5. Noise Filter


(1) PURY-P72TJMU-A



(2) PURY-P96, P120, P144TJMU-A




(3) PURY-P72, P96, P120, P144YJMU-A




[4] BC Controller Components


- 1. CMB-P O NU-G, GA, HA
- (1) Front




(2) Rear view <G type>



(3) Rear view <GA type>




(4) Rear view <HA type>




2. CMB-P O NU-GB, HB

(1) Front




(2) Rear view




[5] Control Box of the BC Controller

1. CMB-P1016NU-G, GA, HA




[6] BC Controller Circuit Board


1. BC controller circuit board (BC board)



2. RELAY BOARD (RELAY 4 board)



3. RELAY BOARD (RELAY 10 board)



IV Remote Controller

[1]	Functions and Specifications of MA and ME Remote Controllers	.89
[2]	Group Settings and Interlock Settings via the ME Remote Controller	. 90
[3]	Interlock Settings via the MA Remote Controller	. 94
[4]	Using the built-in Temperature Sensor on the Remote Controller	. 95

[1] Functions and Specifications of MA and ME Remote Controllers

There are two types of remote controllers: ME remote controller, which is connected on the indoor-outdoor transmission line, and MA remote controller, which is connected to each indoor unit.

1. Comparison of functions and specifications between MA and ME remote controllers

Functions/specifications	MA remote controller*1*2	ME remote controller*2
Remote controller address settings	Not required	Required
Indoor/outdoor unit address settings	Not required (required only by a system with one outdoor unit)*3	Required
Wiring method	Non-polarized 2-core cable *To perform a group operation, daisy- chain the indoor units using non-polar- ized 2-core cables.	Non-polarized 2-core cable
Remote controller connection	Connectable to any indoor unit in the group	Connectable anywhere on the indoor-out-door transmission line
Interlock with the ventilation unit	Each indoor unit can individually be interlocked with a ventilation unit. (Set up via remote controller in the group.)	Each indoor unit can individually be interlocked with a ventilation unit. (Set up via remote controller.)
Changes to be made upon grouping change	MA remote controller wiring between indoor units requires rewiring.	Either the indoor unit address and remote controller address must both be changed, or the registration information must be changed via MELANS.

^{*1.} MA remote controller refers to MA remote controller (PAR-20MAU, PAR-21MAA), MA simple remote controller, and wire-less remote controller.

2. Remote controller selection criteria

MA remote controller and ME remote controller have different functions and characteristics. Choose the one that better suits the requirements of a given system. Use the following criteria as a reference.


MA remote controller*1*2	ME remote controller*1*2
 There is little likelihood of system expansion and grouping changes. Grouping (floor plan) has been set at the time of installation. 	 There is a likelihood of centralized installation of remote controllers, system expansion, and grouping changes. Grouping (floor plan) has not been set at the time of installation. To connect the remote controller directly to the OA processing unit.

^{*1.} ME remote controller and MA remote controller cannot both be connected to the same group of indoor units.

*2. A system controller must be connected to a system to which both MA remote controller and ME remote controller are connected.

<System with MA remote controller>

<System with ME remote controllers>



^{*2.} Either the MA remote controller or the ME remote controller can be connected when a group operation of units in a system with multiple outdoor units is conducted or when a system controller is connected.

^{*3.} Depending on the system configuration, some systems with one outdoor unit may require address settings.

[2] Group Settings and Interlock Settings via the ME Remote Controller

1. Group settings/interlock settings

Make the following settings to perform a group operation of units that are connected to different outdoor units or to manually set up the indoor/outdoor unit address.

(A) Group settings......Registration of the indoor units to be controlled with the remote controller,

and search and deletion of registered information.

(B) Interlock settings......Registration of LOSSNAY units to be interlocked with the indoor units, and search and deletion of registered information

[Operation Procedures]

(1) Address settings

Register the indoor unit to be controlled with the remote controller.

①Bring up either one of the following displays on the remote controller:

The blinking display of "HO," which appears when the power is turned on, or the normal display, which appears when the unit is stopped. The display window must look like one of the two figures below to proceed to the next step.





2)Bring up the "Group Setting" window.

-Press and hold buttons (a) [FILTER] and (B) [LOUVER] simultaneously for 2 seconds to bring up the display as shown below.




3 Select the unit address.

 Select the address of the indoor unit to be registered by pressing button © [SET TEMP. (▽) or (△)] to advance or go back through the addresses.

Register the indoor unit whose address appears on the display.

- Press button (1) [TEST] to register the indoor unit address whose address appears on the display.
- If registration is successfully completed, unit type will appear on the display as shown in the figure below.
- If the selected address does not have a corresponding indoor unit, an error message will appear on the display. Check the address, and try again.

<Successful completion of registration>




<Deletion error>



"## "Binks to indicate a registration error.

(Indicates that selected address does not have a corresponding unit.)

⑤ To register the addresses for multiple indoor units, repeat steps ③ and ④ above.



(B) Interlock Settings


6 Bring up the "Interlock Setting" window.

(C)

(G)

E

-Press button © [MODE] to bring up the following display. Press again to go back to the "Group Setting" window as shown under step ②




⑦Bring up the address of the indoor unit and the address of the LOSSNAY to be interlocked on the display.

- Select the address of the indoor unit to be registered by pressing button \bigcirc [SET TEMP. (∇) or (\triangle)] to advance or go back through the addresses.
- Select the address of the LOSSNAY unit to be interlocked by pressing button ⊕[TIMER SET (▽) or (△)] to advance or go back through the "interlocked unit addresses."



Make the settings to interlock LOSSNAY units with indoor units.

- Interlock setting can also be made by bringing up the LOSSNAY address in the indoor unit address display window and the indoor unit address in the interlocked unit address display window.



If registration is successfully completed, the two displays as shown on the left will appear alternately. If the registration fails, "88" will blink on the display. (Indicates that the selected

will blink on the display.
(Indicates that the selected address does not have a corresponding unit.)

NOTE: Interlock all the indoor units in the group with the LOSSNAY units; otherwise, the LOSSNAY units will not operate.



(C) To return to the normal display

When all the group settings and interlock settings are made, take the following step to go back to the normal display.

 $^{ ext{(I)}}$ Press and hold buttons $ilde{\mathbb{A}}$ [FILTER] and $ilde{\mathbb{B}}$ [LOUVER] simultaneously for 2 seconds to go back to the window as shown in step 1.

(2) Address search

To search for the address of indoor units that have been entered into the remote controller, follow steps 1 and 2.




(A) To search group settings

Bring up the "Group Setting" window.

- Each pressing of button (E) [TIMER] will bring up the address of a registered indoor unit and its unit type on the display.

<Entry found>



<No entries found>



- When only one unit address is registered, the same address will remain on the display regardless of how many times the button is pressed.
- When the address of multiple units are registered (i.e. "011," "012," "013"), they will be displayed one at a time in an ascending order with each pressing of button [E][TIMER].





To delete an address, go to section (3)"Address Deletion."

To go back to the normal display, follow step (10)



Repeat steps and in the previous page to interlock all the indoor units in a group with the LOSSNAY unit.



follow step (10)

To go back to the normal display, To search for an address, go to section (2) "Address Search."



(B) Interlock setting search

After performing step (6), proceed as follows:

12 Bring up the address of the indoor unit to be searched on


- Select the address of the indoor unit to be searched by pressing button (\Box) [TIMER SET (\bigtriangledown) or (\triangle)] to advance or go back through the interlocked addresses.



LOSSNAY can be searched in the same manner by bringing up the LOSSNAY address in the Interlocked unit address display window.

(3) Bring up on the display the address of the LOSSNAY unit that was interlocked with the indoor unit in step ②.


- With each pressing of button © [TIMER], the address of the LOSSNAY and indoor unit that is interlocked with it will be displayed alternately.



(4) Bring up the address of another registered unit on the display.

- After completing step (3), a subsequent pressing of button © [TIMER] will bring up the address of another registered unit

(The display method is the same as the one in step ③.)



go to section (3) "Address Deletion".

(3) Address deletion


The addresses of the indoor units that have been entered into the remote controller can be deleted by deleting the group settings.

The interlock settings between units can be deleted by deleting the interlock settings.

Follow the steps in section (2) "Address Search" to find the address to be deleted and perform deletion with the address being displayed in the display window. To delete an address, the address must first be bought up on the display.

Delete the registered indoor unit address or the interlock setting between units.

- Press button ♠ [CLOCK→ON→OFF] twice while either the indoor unit address or the address of the interlocked unit is displayed on the display to delete the interlock setting.



(4) Making (A) Group settings and (B) Interlock settings of a group from any arbitrary remote controller

(A) Group settings and (B) Interlock settings of a group can be made from any arbitrary remote controller. Refer to "(B) Interlock Settings" under section 1 "Group Settings/Interlock Settings" for operation procedures. Set the address as shown below.

(A) To make group settings

Interlocked unit address display window...Remote controller address

Indoor unit address display window.......The address of the indoor unit to be controlled with the remote controller

(B) To make interlock settings

Interlocked unit address display window...LOSSNAY address

Indoor unit address display window......The address of the indoor unit to be interlocked with the LOSSNAY

2. Remote controller function selection via the ME remote controller

In the remote controller function selection mode, the settings for three types of functions can be made or changed as necessary.

- 1) Operation mode display selection mode (<u>Display or non-display of COOL/HEAT during automatic operation mode</u>)
 When the automatic operation mode is selected, the indoor unit will automatically perform a cooling or heating operation based on the room temperature. In this case, "AUTO COOL" or "AUTO HEAT "will appear on the remote controller display.

 This setting can be changed so that only "AUTO" will appear on the display.
- 2) Room temperature display selection mode (Display or non-display of room temperature)

 Although the suction temperature is normally displayed on the remote controller, the setting can be changed so that it will not appear on the
- 3) Narrowed preset temperature range mode


The default temperature ranges are 67°F to 87°F in the cooling/dry mode and 63°F to 83°F in the heating mode.

By changing these ranges (raising the lower limit for the cooling/dry mode and lowering the upper limit for the heating mode), energy can be saved.

*The settable range varies depending on the unit to be connected.



On the PAR-F27MEA-US model, automatic operation mode cannot be selected while the unit is in the narrowed preset temperature range mode. Only the lower limit can be set for cooling/dry mode, and upper limit for heating mode.




[Operation Procedures]

- 1. Press the [ON/OFF] button on the remote controller to bring the unit to a stop. The display will appear as shown in the previous page (Normal display).
- 2. Press buttons ① [CHECK] and [MODE] simultaneously for 2 seconds to go into the "operation mode display selection mode" under the remote controller function selection mode. Press button ② [SET TEMP. (▽)] or ③ [SET TEMP. (△)] to go into the other three modes under the remote controller function selection mode.

Operation mode display selection mode (Display or non-display of room temperature on the remote controller.)

• "AUTO" "COOL/HEAT" will blink, and either "ON" or "OFF" will light up. Press button ⊕ [TIMER SET (△) or (▽)] in this state to switch between "ON" and "OFF."








- When it is set to "ON," "AUTO" and "COOL" or "AUTO" and "HEAT" will appear on the display during automatic operation mode.
- When it is set to "OFF," only "AUTO" will appear on the display during automatic operation mode.

Room temperature display selection mode (Display or non-display of room temperature)

• "88 °F" will blink in the room temperature display window, and either "ON" or "OFF" will light up. Press button ④ [TIMER SET (△) or (▽)] in this state to switch between "ON" and "OFF."







- When it is set to "ON," the room temperature will stay in the operation display window during operation.
- When it is set to "OFF," the room temperature will not appear in the operation display window during operation.

Narrowed preset temperature range mode (The range of preset temperature can be changed.)

1) Temperature range setting for the cooling/dry mode

"COOL/DRY" and "LIMIT TEMP." will light up in the display window, and the temperature range for the cooling/dry mode will appear on the display. The lower limit temperature will be blinking in the preset temperature display window. While it is blinking, the temperature setting can be changed. [Selection range for the lower limit temperature]: $67^{\circ}F \iff 87^{\circ}F$ (Medium temperature range indoor unit $57^{\circ}F \iff 87^{\circ}F$) (The upper limit temperature is fixed at $87^{\circ}F$. Only the lower limit temperature is changeable.)



[When the temperature range for the cooling or dry mode is set to 67°F to 87°F]

2) Press button 1 [TIMER SET 1 or 2] to set the lower limit temperature to the desired temperature.



[When the temperature range is changed to 75°F - 87°F]

3) After completing the step above, press button ② [SET TEMP. (▽)] to go into the temperature range setting mode to set the temperature range for the heating operation.

"HEAT" and "LIMIT TEMP" will light up, and the temperature range for the heating mode will appear on the screen. The upper limit temperature can be changed with button 4 [TIMER SET (\triangle) or (∇)]. [Selection range for the upper limit temperature] : $63^{\circ}F \iff 83^{\circ}F$ (Medium temperature range indoor unit $63^{\circ}F \iff 83^{\circ}F$) (The lower limit temperature is fixed at $63^{\circ}F$. Only the upper limit temperature is changeable.)

3. When all the necessary settings have been made, exit the remote controller function selection mode and go back to the Normal display by pressing and holding buttons ①[CHECK] and [MODE] simultaneously for 2 seconds.

[3] Interlock Settings via the MA Remote Controller

1. LOSSNAY interlock setting (Make this setting only when necessary.)

(1) MA Remote Controller (PAR-21MAA)

* When the upper controller is connected, make the setting using the upper controller.

NOTE: When using LOSSNAY units in conjunction, interlock the addresses of all indoor units within the group and address of LOSSNAY units.

Perform this operation to enter the interlock setting between the LOSSNAY and the indoor units to which the remote controller is connected, or to search and delete registered information.

In the following example, the address of the indoor unit is 05 and the address of the LOSSNAY unit is 30.

[Operation Procedures]

① Press the ①[ON/OFF] button on the remote controller to bring the unit to a stop.

The display window on the remote controller must look like the figure below to proceed to step 2.




② Press and hold the [FILTER] and [====] buttons simultaneously for two seconds to perform a search for the LOSSNAY that is interlocked with the indoor unit to which the remote controller is connected.



③ Search result

- The indoor unit address and the interlocked LOSSNAY address will appear alternately.



<Indoor unit address and indoor unit>

<LOSSNAY address and LOSSNAY>

- Without interlocked LOSSNAY settings



(4) If no settings are necessary, exit the window by pressing and holding the [FILTER] and [=====] buttons simultaneously for 2 seconds. Go to step 1. Registration Procedures to make the interlock settings with LOSSNAY units, or go to step 2. Search Procedures to search for a particular LOSSNAY unit.

Go to step 3. Deletion Procedures to delete any LOSSNAY settings.

< 1. Registration Procedures >

- ⑤ To interlock an indoor unit with a LOSSNAY unit, press the [ﷺETEMP. (▽) or (△)] button on the remote controller that is connected to the indoor unit, and select its address (01 to 50).
- **®** Press the [OCLOCK (\bigtriangledown) or (\triangle)] button to select the address of the LOSSNAY to be interlocked (01 to 50).



Indoor unit address LOSSNAY address


- ⑦ Press the [TEST] button to register the address of the selected indoor unit and the interlocked LOSSNAY unit.
 - Registration completed

The registered indoor unit address and "IC," and the interlocked LOSSNAY address and "LC" will appear alternately.



- Registration error

If the registration fails, the indoor unit address and the LOSSNAY address will be displayed alternately.



Registration cannot be completed: The selected unit address does not have a corresponding indoor unit or a LOSSNAY unit. Registration cannot be completed: Another LOSSNAY has already been interlocked with the selected indoor unit.

< 2. Search Procedures >


®To search for the LOSSNAY unit that is interlocked with a particular indoor unit, enter the address of the indoor unit into the remote controller that is connected to it.



<Indoor unit address>

- Search completed (With a LOSSNAY connection)


The indoor unit address and "IC," and the interlocked LOSSNAY address and "LC" will appear alternately.



- Search completed (No interlocked settings with a LOSSNAY exist.)




- The selected address does not have a corresponding indoor unit.



< 3. Deletion Procedures >


Take the following steps to delete the interlock setting between a LOSSNAY unit and the interlocked indoor unit from the remote controller that is connected to the indoor unit.

(1) Find the address of the LOSSNAY to be deleted (See section 2. Search Procedures.), and bring up the result of the search for both the indoor unit and LOSSNAY on the display.



- ①Press the [② ON/OFF] button twice to delete the address of the LOSSNAY unit that is interlocked with the selected indoor unit.
 - Registration completed

The indoor unit address and "--," and the interlocked LOSSNAY address and "--" will appear alternately.



-Deletion error

If the deletion fails



[4] Using the built-in Temperature Sensor on the Remote Controller

1. Selecting the position of temperature detection (Factory setting: SW1-1 on the controller board on the indoor unit is set to OFF.)

To use the built-in sensor on the remote controller, set the SW1-1 on the controller board on the indoor unit to ON.


- •Some models of remote controllers are not equipped with a built-in temperature sensor. Use the built-in temperature sensor on the indoor unit instead.
- •When using the built-in sensor on the remote controller, install the remote controller where room temperature can be detected.

V Electrical Wiring Diagram


[1]	Electrical Wiring Diagram of the Outdoor Unit	99
[2]	Electrical Wiring Diagram of the BC Controller	104
[3]	Electrical Wiring Diagram of Transmission Booster	114

[1] Electrical Wiring Diagram of the Outdoor Unit


(1) PURY-P72TJMU-A




(2) PURY-P96TJMU-A




(3) PURY-P120, P144TJMU-A



(4) PURY-P72, P96YJMU-A




(5) PURY-P120, P144YJMU-A



[2] Electrical Wiring Diagram of the BC Controller


(1) CMB-P104NU-G model




(2) CMB-P105,106NU-G models

bol Ni 1,12,15,16 Themis 1,3 Expansi 3,3 Pressuri VI.B board 1 Ternina 1 Ternina Circuit Ternina 2 (for power CaA,B,C Solenoic 6 Ternina	(Symbol explanation)	lion)
Transfor	Symbol	Name
12,15,16 Thermis 3 Expansi 8 Pressur 1.B Circuit 1.B Coard 1.Emina		ransformer
Expansi Pressur T.B Circuit Corruit Formina	-	Thermistor sensor
Circuit Circuit Court Co		Expansion valve
Circuit board learning (for pow learning for pow learning for pow learning for pow learning l		Pressure sensor
6A,B,C		Sircuit BC controller
2 ~6A,B,C 11 6		Terminal block (for power source)
~6A,B,C 11 6		Terminal block (for Transmission)
11		Solenoid valve
9		Solenoid valve
		erminal
F01 Fuse AC250V		Fuse AC250V 6.3A F


transmission	l block.	Never connect power	.:	2.The initial set values	of switch on CONT.B	ollows.		
Note: 1.TB02 is transmission	terminal block.	Never	line to it.	2.The initi	of switc	are as follows.	SW1:0	SW2.0




(3) CMB-P108,1010NU-G models




(4) CMB-P1013,1016NU-G models




(5) CMB-P108,1010NU-GA models




(6) CMB-P1013,1016NU-GA models




(7) CMB-P104NU-GB model




Note:1,TB02 is transmission terminal block.
Never connect power line to it.
2.The initial set values of switch on CONTB are as follows.
SWU:0
SW2:0




(8) CMB-P108NU-GB model




(9) CMB-P1016NU-HA model



(10) CMB-P1016NU-HB model



[3] Electrical Wiring Diagram of Transmission Booster




VI Refrigerant Circuit

[1]	Refrigerant Circuit Diagram	117
[2]	Principal Parts and Functions	126


[1] Refrigerant Circuit Diagram

1. Outdoor unit


(1) PURY-P72 model




(2) PURY-P96 model




(3) PURY-P120, P144 models




(4) PURY-P168 model




(5) PURY-P192 model



(6) PURY-P216 model




(7) PURY-P240, P264, P288 models




2. BC controller


(1) CMB-P104 - P1016NU-G




(2) CMB-P108, P1013, P1016NU-GA (main)




(3) CMB-P104, P108NU-GB (sub)



(4) CMB-P1016V-HA (main)



(5) CMB-P1016NU-HB (sub)



[2] Principal Parts and Functions

1. Outdoor unit

Part name	Symbols (functions)	Notes	Usage	Specifications	Check method
Com- pressor	MC1 (Comp1)		Adjusts the amount of circulating refrigerant by adjusting the operating frequency based on the operating pressure data	P72 model Low-pressure shell scroll compressor Wirewound resistance 20°C[68°F]: 0.20ohm (TJMU) 0.71ohm (YJMU) P96, P120, P144 models Low-pressure shell scroll compressor Wirewound resistance 20°C[68°F]: 0.092ohm (TJMU) 0.323ohm (YJMU)	
High pressure sensor	63HS1		Detects high pressure Regulates frequency and provides high-pressure protection	Connector Pressure [MPa] -4.15 MPa [601psi] \[\text{Vout 0.5-3.5V} \\ 0.071V/0.098 MPa [14psi] \text{Pressure [MPa]} -1.38 x Vout [V]-0.69 \text{Pressure [psi]} =(1.38 x Vout [V]-0.69) x 145 1 GND (Black) 2 Vout (White) \text{Vout (White)} \text{Voc (DC5V) (Red)}	
Low pressure sensor	63LS		Detects low pressure Provides low-pressure protection	Con- 1 23 Pressure 0-1.7 MPa [247psi] Vout 0.5-3.5V 0.1737/0.098 MPa [14psi] Pressure [MPa] 0.566 x Vout V] - 0.283 Pressure [psi] (0.566 x Vout V] - 0.283 x 145 1 GND (Black) Vout (White) 3 Vcc (DC5V) (Red)	
Pres- sure switch	63H1		Detects high pressure Provides high-pressure protection	4.15MPa[601psi] OFF setting	
Power supply trans- former	Trans former	YJMU only	Decreases the power supply voltage (460V) supplied to the circuit board	Primary rated voltage: 460V, 50/60Hz Secondary rated voltage: 229V (No-load voltage)	
Electro- magnet- ic contactor	52F	P120 and P144 only	Turns ON and OFF the output to the fan motor.	AC208-230V	(Refer to the section on troubleshooting the outdoor unit fan (page 295) for the ON/OFF pattern of the electromagnetic contactors.)

Part name	Symbols (functions)	Notes	Usage	Specifications	Check method
Thermis- tor	TH4 (Discharge)		Detects discharge air temper- ature Provides high-pressure pro- tection	Degrees Celsius R ₁₂₀ = 7.465k Ω R _{25/120} = 4057 R _t = 7.465exp{4057($\frac{1}{273+t}$ - $\frac{1}{393}$)}	Resistance check
			0°C[32°F]:698kohm 10°C[50°F]:413kohm 20°C[68°F]:250kohm 30°C[86°F]:160kohm 40°C[104°F]:104kohm 50°C[122°F]:70kohm 60°C[140°F]:48kohm 70°C[158°F]:34kohm 80°C[176°F]:24kohm 90°C[194°F]:17.5kohm 100°C[212°F]:13.0kohm	273+t 393"	
	TH3 (Pipe temperature)		Controls defrosting during heating operation 1) Detects outdoor air tempera-	$\begin{tabular}{lll} Degrees Celsius \\ R_0 &= 15 k \Omega \\ R_{0/80} = 3460 \\ R_t = 15 exp 3460 \; (\frac{1}{273+t} - \frac{1}{273}) \} \\ \end{tabular}$	Resistance check
	(Outdoor temperature)		ture 2) Controls fan operation Fan operated on the 63LS and	0°C[32°F] :15kohm 10°C[50°F] :9.7kohm	
	TH6		TH5 values. 20°C[68°F] :6.4kohm 25°C[77°F] :5.3kohm 30°C[86°F] :4.3kohm		
	TITLE		operation	40°C[104°F] :3.1kohm	
	THHS Inverter heat sink tem- perature	verter based on THHS temperature eat sink tem- based on THHS temperature $ \begin{array}{ccccccccccccccccccccccccccccccccccc$	$R_{50} = 17k\Omega$		
	THBOX Control box in- ternal tempera- ture detection			0°C[32°F]:161kohm 10°C[50°F]:97kohm 20°C[68°F]:60kohm 25°C[77°F]:48kohm 30°C[86°F]:39kohm 40°C[104°F]:25kohm	
Solenoid valve	SV1a Discharge-suc- tion bypass		High/low pressure bypass at start-up and stopping, and capacity control during low- load operation	AC208 - 230V Open while being powered/ closed while not being pow- ered	Continuity check with a tester
	SV2		High-pressure-rise prevention	*The SV4c on the P120 and P144 models closes when	
	SV4a - SV4d Heat exchanger capacity control		Controls outdoor unit heat exchanger capacity	energized and opens when de-energized.	
	SV5b Heat exchanger capacity control		Prevents high-pressure-rise Controls defrost cycle	AC208 - 230V Closed while being powered/ open while not being powered	
	SV5c		Allows the refrigerant to pass through the bypass pipe to prevent an accumulation of liquid refrigerant	AC208 - 230V Open while being powered/ closed while not being pow- ered	
	SV9		High-pressure-rise prevention	AC208 - 230V Open while being powered/ closed while not being pow- ered	

[VI Refrigerant Circuit]

Part name	Symbols (functions)	Notes	Usage	Specifications	Check method
Heater	CH11		Heats the refrigerant in the compressor	Belt heater P72 model 1511 ohm 35W P96, P120, P144 models 1280 ohm 45W	Resistance check
4-way valve	21S4a		Changeover between heating and cooling	AC208-230V Dead: cooling cycle Live: heating cycle	Continuity check with a tester
Fan mo- tor	FAN motor 1,2	FAN motor 2 is only on the P120 and P144 models.	Regulates the heat exchanger capacity by adjusting the operating frequency and operating the propeller fan based on the operating pressure.	(TJMU) AC180V, 50.5Hz, 920W (YJMU) AC414V, 50.5Hz, 920W	

2. Indoor Unit

Part Name	Symbol (functions)	Notes	Usage	Specification	Check method
Linear expan- sion valve	LEV		Adjusts superheat at the indoor heat exchanger outlet during cooling Adjusts subcool at the heat exchanger outlet of the indoor unit during cooling	DC12V Opening of stepping motor driving valve 0-(1400) puls- es	Refer to the section "Continuity Test with a Tester". Continuity between white, red, and or- ange. Continuity between yellow, brown, and blue. White Red Orange Yellow Brown Blue
Thermis- tor	TH1 (Suction air temperature)		Indoor unit control (Thermo)	R0=15kΩ R0/80=3460	Resistance check
	TH2 (Pipe temper- ature)		 Indoor unit control (Frost prevention, Hot adjust) LEV control during heating operation (subcool detection). 	Rt = 15exp{3460(\frac{1}{273+t} - \frac{1}{273})} 0°C [32°F]:15kohm 10°C [50°F]:9.7kohm 20°C [68°F]:6.4kohm 25°C [77°F]:5.3kohm	
	TH3 (Gas pipe temperature)		LEV control during cooling operation (superheat detection)	30°C [86°F] :4.3kohm 40°C [104°F] :3.1kohm	
	TH4 Outdoor air temperature)		Indoor unit control (Thermo)		
	Temperature sensor (In- door air tem- perature)		Indoor unit control (Thermo)		

3. BC controller

(1) G type

Part name	Symbols (functions)	Part code	Usage	Specifications	Check method
Pressure sensor	PS1 (High pressure side)		Detects high pressure LEV control	Pressure 0~4.15 MPa [601psi] vout 0.5~3.5V 0.0711/0.098 MPa [14psi]	
	PS3 (Intermediate pressure)		Detects intermediate pressure LEV control	Con- nector	
Thermistor	TH11 (Liquid inlet tempera- ture)		LEV control (Liquid level control)	$R_0 = 15k\Omega$ $R_{0/80} = 3460$ $R_1 = 15 \exp{3460 \left(\frac{1}{273 + t} - \frac{1}{273}\right)}$	
	TH12 (Bypass outlet tem- perature)		LEV control (Superheat)	0°C[32°F]: 15kohm 10°C[50°F]: 9.7kohm 20°C[68°F]: 6.4kohm 25°C[77°F]: 5.3kohm 30°C[86°F]: 4.3kohm 40°C[104°F]: 3.1kohm	
	TH15 (Bypass in- let tempera- ture)		LEV control (Superheat)		
	TH16 (Liquid re- frigerant tempera- ture)		LEV control (Subcool)		
Solenoid valve	SVM1		Opens during cooling and de- frost modes	AC208-230V Open while being powered/ closed while not being pow-	Continuity check with a tester
	SV∎A		Provides refrigerant to indoor unit in cooling operation	ered	tester
	SV∎B		Provides refrigerant to indoor unit in heating operation		
	SV■C		Provides refrigerant to indoor unit in cooling operation		
LEV	LEV1 LEV3		Liquid level control Pressure differential control	DC12V Opening of a valve driven by a stepping motor	Same as indoor LEV
			uoi	0-2000 pulses	

(2) GA type

Part name	Symbols (functions)	Part code	Usage	Specifications	Check method
Pressure sensor	PS1 (High pressure side)		Detects high pressure LEV control	Pressure 0~4.15 MPa [601psi] vout 0.5~3.5V 0.071/Vi0.098 MPa [14psi]	
	PS3 (Intermediate pressure)		Detects intermediate pressure LEV control	Connector Pressure [MPa] = 1.38 x Vout [V]-0.69 Pressure [psi] = (1.38 x Vout [V]-0.69) x 145 In Control (V) = 0.69) x 145	
Thermistor	TH11 (Liquid inlet tempera- ture)		LEV control (Liquid level control)	$R_0 = 15k\Omega$ $R_{0/80} = 3460$ $R_1 = 15 \exp{3460 \left(\frac{1}{273 + t} - \frac{1}{273}\right)}$	
	TH12 (Bypass outlet tem- perature)		LEV control (Superheat)	0°C[32°F]: 15kohm 10°C[50°F]: 9.7kohm 20°C[68°F]: 6.4kohm 25°C[77°F]: 5.3kohm 30°C[86°F]: 4.3kohm 40°C[104°F]: 3.1kohm	
	TH15 (Bypass in- let tempera- ture)		LEV control (Superheat)		
	TH16 (Liquid re- frigerant tempera- ture)		LEV control (Subcool)		
Solenoid valve	SVM1		Opens during cooling and de- frost modes	AC208-230V Open while being powered/	Continuity check with a tester
	SVM2		Pressure differential control	closed while not being pow- ered	lester
	SV∎A		Provides refrigerant to indoor unit in cooling operation	_	
	SV∎B		Provides refrigerant to indoor unit in heating operation		
	SV∎C		Provides refrigerant to indoor unit in cooling operation		
LEV	LEV1 LEV2		Liquid level control Pressure differential control	DC12V Opening of a valve driven by a stepping motor 0-2000 pulses	Same as indoor LEV
	LEV3		Subcool control		

(3) GB type

Part name	Symbols (functions)	Part code	Usage	Specifications	Check method
Thermistor	TH12 (Bypass outlet tem- perature)		LEV control (Superheat)	$R_0 = 15k\Omega$ $R_{0/60} = 3460$ $R_1 = 15 \exp{3460 \left(\frac{1}{273 + t} - \frac{1}{273}\right)}$	
(B	TH15 (Bypass in- let tempera- ture)		LEV control (Superheat)	0°C[32°F]: 15kohm 10°C[50°F]: 9.7kohm 20°C[68°F]: 6.4kohm 25°C[77°F]: 5.3kohm 30°C[86°F]: 4.3kohm 40°C[104°F]: 3.1kohm	
Solenoid valve	SV∎A		Provides refrigerant to indoor unit in cooling operation	AC208-230V Open while being powered/	Continuity check with a tester
	SV∎B		Provides refrigerant to indoor unit in heating operation	closed while not being pow- ered	tester
	SV∎C		Provides refrigerant to indoor unit in cooling operation		
LEV	LEV3		Pressure differential control	DC12V Opening of a valve driven by a stepping motor 0-2000 pulses	Same as indoor LEV

(4) HA type

Part name	Symbols (functions)	Part code	Usage	Specifications	Check method
sensor (PS1 (High pressure side)		Detects high pressure LEV control	Pressure 0~4.15 MPa [601psi] vout 0.5~3.5V 0.0711//0.098 MPa [14psi]	
	(Intermediate pressure pressure 2) LEV control	-1 20 × Vout DJ 0 60			
Thermistor	TH11 (Liquid inlet tempera- ture)		LEV control (Liquid level control)	$\begin{array}{l} R_0 &= 15k\Omega \\ R_{0/80} &= 3460 \\ R_1 &= 15\exp\{3460 \; (\frac{1}{273+t} - \frac{1}{273})\} \end{array}$	
	TH12 (Bypass outlet temperature) LEV control (Superheat) 0°C[32°F]: 15kohm 10°C[50°F]: 9.7kohm 20°C[68°F]: 6.4kohm	10°C[50°F] :9.7kohm			
	TH15 (Bypass in- let tempera- ture)		LEV control (Superheat)	30°C[86°F] :4.3kohm 40°C[104°F] :3.1kohm	
	TH16 (Liquid re- frigerant tempera- ture)		LEV control (Subcool)		
Solenoid valve	SVM1		Opens during cooling and de- frost modes	AC208-230V Open while being powered/	Continuity check with a
	SVM1b		Opens during cooling and de- frost modes	closed while not being pow- ered	tester
	SVM2		Pressure differential control		
	SVM2b		Pressure differential control		
	SV∎A		Provides refrigerant to indoor unit in cooling operation		
	SV∎B		Provides refrigerant to indoor unit in heating operation		
	SV∎C		Provides refrigerant to indoor unit in cooling operation		
LEV	LEV1 LEV2		Liquid level control Pressure differential control	DC12V Opening of a valve driven by a stepping motor 0-2000 pulses	Same as indoor LEV
•	LEV3		Subcool control	0-2000 puises	

(5) HB type

Part name	Symbols (functions)	Part code	Usage	Specifications	Check method
Thermistor	TH12 (Bypass outlet tem- perature)		LEV control (Superheat)	$\begin{array}{c} R_0 &= 15 k \Omega \\ R_{080} = 3460 \\ R_t = 15 exp [3460 \ (\frac{1}{273 + t} - \frac{1}{273})] \\ \\ 0^{\circ} C[32^{\circ} F] : 15 kohm \\ 10^{\circ} C[50^{\circ} F] : 9.7 kohm \\ 20^{\circ} C[68^{\circ} F] : 6.4 kohm \\ 25^{\circ} C[77^{\circ} F] : 5.3 kohm \\ 30^{\circ} C[86^{\circ} F] : 4.3 kohm \\ 40^{\circ} C[104^{\circ} F] : 3.1 kohm \end{array}$	
	TH15 (Bypass in- let tempera- ture)		LEV control (Superheat)		
Solenoid valve	SV∎A		Provides refrigerant to indoor unit in cooling operation	AC208-230V Open while being powered/ closed while not being pow- ered	Continuity check with a tester
	SV∎B		Provides refrigerant to indoor unit in heating operation		lester
	SV∎C		Provides refrigerant to indoor unit in cooling operation		
LEV	LEV3		Pressure differential control	DC12V Opening of a valve driven by a stepping motor 0-2000 pulses	Same as indoor LEV

VII Control

[1]	Functions and Factory Settings of the Dipswitches	137
[2]	Controlling the Outdoor Unit	144
[3]	Controlling BC Controller	159
[4]	Operation Flow Chart	160

[1] Functions and Factory Settings of the Dipswitches

1. Outdoor unit

(1) Control board

Switch Function		Function	Function according to switch setting		Switch setting timing		Units that require switch setting Note.2	
	OFF ON		OFF	ON	ОС	os		
SWU	1-2	Unit address setting	Set to 00 or 51-100 v	vith the dial switch	Before powe	r on	С	С
SW1	1-10	For self-diagnosis/ operation monitoring	Refer to the LED mo outdoor unit board.	nitor display on the	Anytime afte	r power on	С	С
	1	Centralized control switch	Without connection to the centralized controller	With connection to the centralized controller	Before powe	r on	В	В
	2	Deletion of connection information	Normal control	Deletion	Before powe	r on	Α	-
	3	Deletion of error history SW	(OC) Storage of IC/ OC error history	(OC) Deletion of IC/ OC error history	Anytime after power on (When switched from OFF		С	С
	3		(OS) Storage of OS error history	(OS) Deletion of OS error history	to ON)			
	4	Pump down mode	Normal control	Pump down mode	After being energized and while the compressor is stopped		A	-
SW2	5	-	-	-		-	-	-
0002	6	-	-	-		-	-	-
	7	Forced defrost (Note 3)	Normal control	Forced defrost starts	10 minutes after compressor startup Anytime after power on (When switched from OFF to ON)		А	A
	8	Defrost timer setting (Note 3)	50 minutes	90 minutes	Anytime after power on (When switched from OFF to ON)		В	В
	9	Target evaporating temperature setting (Note 4)	0°C [32°F]	-2°C [28°F] /-4°C [25°F] /-6°C [21°F]	Anytime after power on (When switched from OFF to ON)		A	-
	10					-	-	_

- 1) Unless otherwise specified, leave the switch to OFF where indicated by "-," which may be set to OFF for a reason.
- 2) A: Only the switch on either the OC or OS needs to be set for the setting to be effective on both units.
 - B: The switches on both the OC and OS need to be set to the same setting for the setting to be effective.
 - C: The setting is effective for the unit on which the setting is made.
- 3) Refer to "VII [2] Controlling the Outdoor Unit" for details.(page 144)
- 4) Target evaporating temperature will change as shown in the table below each time SW2-9 is turned ON and OFF.

SW2-9	\bigcirc OFF \rightarrow ON \rightarrow OFF \rightarrow ON \rightarrow OFF \rightarrow ON
Target evaporating temperature	$\begin{array}{cccccccccccccccccccccccccccccccccccc$

Swi	itch	Function	Function accordin	g to switch setting	Switch set	tting timing	Units that require switch setting Note.2	
			OFF	ON	OFF	ON	ОС	OS
	1	Test run mode: en- abled/disabled	SW3-2 disabled	SW3-2 enabled	Anytime afte	Anytime after power on		-
	2	Test run mode: ON/ OFF	Stops all ICs	Sends a test-run signal to all IC	Anytime afte	r power on	Α	-
	3	Defrost start temper- ature (Note 4)	<pre><p72> -10°C [14°F] <p96, p120,="" p144=""> -8°C [18°F]</p96,></p72></pre>	-5°C [23°F]	Anytime afte	r power on	В	В
	4	Defrost end temper-	<p72> 10°C [50°F]</p72>	<p72> 15°C [59°F]</p72>	Anytime afte	r power on	В	В
		(Note 4)	<p96, p120,="" p144=""> 7°C [45°F]</p96,>	<p96, p120,="" p144=""> 12°C [54°F]</p96,>	eration)	3		
SW3	5		-			-	-	
	6	Temperature unit setting	Centigrade	Fahrenheit	Anytime afte	r power on	С	С
	7	High heating power (at low outside temperature)	Ineffective	Effective	Anytime aft	А	-	
	8	-	-	-		-	-	-
	9	Model setting (High static pressure setting (outdoor))	Outdoor standard static pressure	Outdoor high static pressure	Before being energized		С	С
	10	Model setting (High static pressure setting (outdoor))	High static pressure 60Pa	High static pressure 30Pa	Before being energized		С	С
	1	Enable/disenable high sensible operation	Normal operation mode	High sensible heat operation mode	Before being energized		A	-
	2	-	-	-		-	-	-
	3	Refrigerant amount adjustment	Normal operation mode	Refrigerant amount adjust mode	gized (exceptial startup m Automaticall 90 minutes a	Anytime after being energized (except during initial startup mode. Automatically cancelled 90 minutes after compressor startup)		-
SW4	4	Low-noise mode/ step demand switch- ing	Low-noise mode (Note 3)	Step demand mode	Before being	Before being energized		С
	5	-	-	-		-	-	-
	6	Cumulative compressor operation time data deletion	Cumulative compressor operation time data is retained.	Cumulative compressor operation time data is deleted.	Anytime after power on (when the unit is turned on)		С	С
	7	-	-	-		-	-	-
	8	-	-	-		-	-	-
	9	-	-	-		-	-	-
	10	-	-	-		_	-	-

- 1) Unless otherwise specified, leave the switch to OFF where indicated by "-," which may be set to OFF for a reason.
- 2) A: Only the switch on either the OC or OS needs to be set for the setting to be effective on both units.
 - B: The switches on both the OC and OS need to be set to the same setting for the setting to be effective.
 - C: The setting is effective for the unit on which the setting is made.
- 3) The noise level is reduced by controlling the compressor frequency and outdoor fan rotation speed A setting of CN3D is required.(page 24)
- 4) Refer to "VII [2] Controlling the Outdoor Unit" -7- Defrost Operation Control.(page 147)

Switch		Function	Function accordir	Function according to switch setting		Switch setting timing		hat re- switch ting te.2	
			OFF	ON	OFF	ON	ОС	OS	
	1	-					-	-	
	2	-		To be set at the factory.					
	3	-		-	-				
	4	-		-	-				
SW5	5	Low-noise mode selection	Capacity priority mode(Note 3) Low-noise mode Before being energized			А	-		
	6	-	-	-	-	-	-	-	
	7	-		To be set at the fac	tory.		-	-	
	8	-	-	-	-	-		-	
	9	-	-	-	-	-	-	-	
	10	Backup heating	Disabled	Enabled	Anytime after	power on	Α	-	

Note

- 1) Unless otherwise specified, leave the switch to OFF where indicated by "-," which may be set to OFF for a reason.
- 2) A: Only the switch on either the OC or OS needs to be set for the setting to be effective on both units.
 - B: The switches on both the OC and OS need to be set to the same setting for the setting to be effective.
 - C: The setting is effective for the unit on which the setting is made.
- 3) When set to the capacity priority mode and if the following conditions are met, the quiet mode will terminate, and the unit will go back into the normal operation mode.

Cooling-only/Cooling-main: Outside temperature is high or high pressure is high.

Heating-only/Heating-main: Outside temperature is low or low pressure is low.

(2) INV board

1) PURY-P72, P96, P120, P144YJMU-A, PURY-P72TJMU-A

Functions are switched with the following connector.

Connector	Function	Function according to connector		Setting timing	
		Enabled	Disabled	Enabled	Disabled
CN6 short- circuit con- nector	Enabling/disabling the following error detection functions; ACCT sensor failure (5301 Detail No. 115) ACCT sensor circuit failure (5301 Detail No.117) IPM open/ACCT erroneous wiring (5301 Detail No. 119) Detection of ACCT erroneous wiring (5301 Detail No.120)	Error detection enabled	Error detection disable (No load operation is possible.)	Anytime after p	ower on

- •CN6 short-circuit connector is mated with the mating connector.
- •Leave the short-circuit connector on the mating connector during normal operation to enable error detection and protect the equipment from damage.

2) PURY-P96, P120, P144TJMU-A

Switch		Function		rding to switch ting	Switch setting timing		
			OFF	ON	OFF	ON	
SW1	1	Enabling/disabling the following error detection functions; ACCT/DCCT sensor failure (5301 Detail No. 115, 116) ACCT/DCCT sensor circuit failure (5301 Detail No.117,118) IPM open/Disconnected CNCT2 (5301 Detail No. 119) Detection of erroneous wiring (5301 Detail No.120)	Error detection enabled	Error detection disable (No load operation is possible.)	Anytime after power on		
	2	-	-	-	-	-	
	3	-	-	-	-	-	
	4	-	-	-	-	-	
	5	-	-	-	-	-	
	6	-	-	-	-	-	

[•]All are set to OFF at factory shipment. Unless otherwise specified, set the switch to OFF where indicated by "-," which may be set to a certain setting for a reason.

Leave SW1-1 to OFF during normal operation. If it is set to ON, errors cannot be detected and the unit may be damaged.

2. Function of the switch (Indoor unit)

(1) Dipswitches

1) SW1,3

Switch		Function	Function accordin	g to switch setting	Switch se	tting timing	Notes
			OFF	ON	OFF	ON	Notes
	1	Room temperature detection position	Indoor unit inlet	Built-in sensor on the remote controller			Set to ON (built-in sensor on the remote controller) on All Fresh (PEFY-VMH-F) model units
	2	Clogged filter detection	Not available	Available			
	3	Filter check reminder time setting	100h	2500h			
	4	Outside air intake	Disabled	Enabled			Always set to OFF on PKFY-AM model units
	5	Remote display option	Fan output	Thermo-ON signal			
SW1	6	Humidifier control	During heating operation	Always on while in the heating mode			
	_	Fan speed setting for Heating Thermo-OFF	Very Low	Low			
	7	Forced heating operation at OA temp of 5°C or below	Not available	Available			Applicable to All Fresh model units (PEFY-VMH-F) only
		Fan speed setting for Heating Thermo-OFF	According to the SW1-7 setting	Preset speed	While the unit is stopped (Remote controller OFF)		
	8	-	-	-			Applicable to All Fresh model units (PEFY-VMH-F) only
	9	Self-recovery after power failure	Disabled	Enabled			
	10	Power source start-stop	Disabled	Enabled			
	1	Unit model selection	Heat pump	Cooling only			
	2	Louver	Not available	Available			
	3	Vane	Not available	Available			
	4	Vane swing function	Not available	Available			Always set to OFF on PKFY-VAM model units
SW3	5	-	-	-			
	6	Vane angle limit setting for cooling operation	Downblow B,C	Horizontal			Always set to Downblow B or C on PKFY-VAM model units
		Initial vane position	Enabled	Disabled			PLFY-VLMD model only
	7	Automatic LEV value conversion function	Not available	Available			
	8	Heating 4 °C[7.2 °F] up	Enabled	d Disabled			Set to ON on floor-standing (PFFY) type units
	9	SHm setting	2	5			The setting depends on the model and type.
	10	SCm setting	10	15			The setting depends on the model and type.

Note 1. Settings in the shaded areas are factory settings. (Refer to the table below for the factory setting of the switches whose factory settings are not indicated by the shaded cells.)

Note 2. If both SW1-7 and SW1-8 are set to ON, the fan remains stopped during heating Thermo-OFF.

To prevent incorrect temperature detection due to a build-up of warm air around the indoor unit, use the built-in temperature sensor on the remote controller (SW1-1)

instead of the one on the indoor unit inlet thermistor.

Note 3. By setting SW3-1, SW1-7, and SW1-8 to a certain configuration, the fan can be set to remain stopped during cooling Thermo-OFF. See the table below for details.

Switch setting		Fan speed duri	ng Thermo-OFF			
SW3-1	SW1-7	SW1-8	Heating	Cooling	Cooling-only/heat pump	
	OFF	OFF	Very Low	Preset speed		
OFF	ON	OFF	Low		Heat pump	
	OFF	ON	Preset speed			
	ON	ON	Stop			
	OFF	055	_	Preset speed	0 - 1 1	
ON	ON	OFF	_	1 Teset speed	Cooling-only	
	OFF	ON	_	Stop		
	ON	ON	Stop	Stop	Heat pump	

(2) Address switch

Actual indoor unit address setting varies in different systems. Refer to the installation manual for the outdoor unit for details on how to make the address setting.

Each address is set with a combination of the settings for the 10's digit and 1's digit. (Example)


When setting the address to "3", set the 1's digit to 3, and the 10's digit to 0.

When setting the address to "25", set the 1's digit to 5, and the 10's digit to 2.

3. Function of the switch <Remote controller>

(1) MA remote controller (PAR-20MAU)

The SW is located at the bottom of the remote controller under the cover. Operate the switches to perform the remote controller main/sub setting or other function settings. Normally, do not change the settings of switches other than the SW1 (main/sub switching switch). (All the switches are set to "ON" at factory setting.)




Switch	Function	ON	OFF	Operation by switch settings	Switch setting timing
1	Remote controller main/sub setting	Main	Sub	Sub When two remote controllers are connected to one group, set either of the remote controllers to "Sub".	
2	At power on of the remote controller	Normal startup	Timer mode startup	When the program timer (only few stock products are available) is connected, set to "Timer mode startup" to resume the operation with timer mode after power is restored.	Before power on
3	Cooling/heating display set by automatic setting	Displayed	Not displayed	When the automatic mode is set and the "Cooling"/"Heating" display is not necessary, set to "Not displayed".	Before power on
4	Suction temperature display (discharge temperature display)	Displayed	Not displayed	When the suction temperature (discharge temperature) display is not necessary, set to "Not displayed".	Before power on

Note

The MA remote controller (PAR-21MAA) does not have the switches listed above. Refer to the installation manual for the function setting.

(2) ME remote controller (PAR-F27MEA-US)

Set the address of the remote controller with the rotary switch.



Example: In case of address 108

	Address setting range	Setting method
Main remote controller	101-150	Add 100 to the smallest address of all the indoor units in the same group.
Sub remote controller	151-200	Add 150 to the smallest address of all the indoor units in the same group.

Setting of rotary switch	Address No.
01-99 ^{*1}	101-199 with the 100's digit automatically being set to 1 ^{*2}
00	200

^{*1.} At factory shipment, the rotary switch is set to 01.

Note

To set addresses, use a precision slotted screw driver [2.0 mm [0.08 in] (w)], and do not apply than 19.6N. The use of any other tool or applying too much load may damage the switch.

4. Switch functions <BC controller> (Control board)

Sw	vitch	Function	Function according to switch setting		Switch setting timing	
34	VILCII	1 diletion	OFF	ON	Switch setting tirring	
	1	Model setting	R410A	-	Always leave this switch to OFF.	
SW4	2 - 5	-	-	-	-	
0	6	No. of ports *1	1	2	Before being energized	
	7, 8	-	-	-	-	
	1 - 6	-	-	-	-	
SW5	7	-	-	-	-	
	8	-	-	-	-	


^{*1.} When a junction pipe kit was used to merge two ports to connect the indoor units with a total capacity of between P31 and P54, turn DIP SW4-6 to ON. When connecting a main and a sub BC controller, change the SW setting on only the main BC controller. (It is not necessary to change the SW setting on the sub BC controller.)

^{*2.} The address range that can be set with the ME remote controller is between 101 and 200. When the dials are set to a number between 01 and 99, the 100's digit is automatically set to [1]. When the dials are set to 00, the 100's digit is automatically set to [2].

[2] Controlling the Outdoor Unit

-1- Outline of Control Method


- •The outdoor units are designated as OC and OS in the order of capacity from large to small (if two or more units have the same capacity, in the order of address from small to large).
- •The setting of outdoor unit can be verified by using the self-diagnosis switch (SW1).



- •The OC determines the operation mode and the control mode, and it also communicates with the indoor units.
- •The OS exercises autonomous distributed control (over defrost, error detection, and actuator control etc.) according to the operation/control mode signals that are sent from the OC.

-2- Startup sequence rotation

- •At the initial startup, outdoor units start up in the order of "OC and OS." When the cumulative operation time of the OC reaches two hours, the OS will start up before the OC at the next start up.
- *Startup sequence rotation is performed while all the indoor units are stopped. (Even after two hours of operation, startup sequence rotation is not performed while the compressor is in operation.)
- In a system with multiple outdoor units (OC and OS), when the integrated operation time of the unit in operation (either OC or OS) reaches one hour during a cooling operation at low outside temperature, that unit will stop and the other unit will go into operation.
- •Refer to [-10-Control at Initial Start-up] for the initial startup.
- *Performing startup sequence rotation does not change the basic operation of OC and OS. Only startup sequence is changed.
- *Startup sequence of the outdoor units can be checked with the self-diagnosis switch (SW1) on the OC.



-3- Initial Control

- •When the power is turned on, the initial processing of the microcomputer is given top priority.
- *During the initial processing, control processing of the operation signal is suspended. (The control processing is resumed after the initial processing is completed. Initial processing involves data processing in the microcomputer and initial setting of each of the LEV opening. This process will take up to 5 minutes.)
- *During the initial processing, the LED monitor on the outdoor unit's control board displays S/W version -> refrigerant type -> heat pump -> cooling only and capacity -> and communication address in turn every second.

-4- Control at Start-up

- •The upper limit of frequency during the first 3 minutes of the operation is 50 Hz.
- •When the power is turned on, normal operation will start after the initial start-up mode (to be described later) has been completed (with a restriction on the frequency).

-5- Bypass Control

Bypass solenoid valves (SV1a), which bypass the high- and low- pressure sides, perform the following functions.

(1) Bypass solenoid valve (SV1a) (ON = Open)

Operation	SV	SV1a		
Operation	ON	OFF		
When each indoor unit compressor startup	ON for 4	minutes.		
After the restoration of thermo or 3 minutes after restart	ON for 4 minutes.			
During cooling or heating operation with the compressor stopped	Always ON. Exception: OFF when 63HS1-63LS is 0.2MPa[29psi] or less			
After the operation has stopped	ON for 3 minutes. Exception: OFF when 63HS1-63LS is 0.2MPa[29psi] or less			
During defrost operation	С	N		
While the compressor is operating at the minimum frequency and when the low pressure (63LS) drops (3 or more minutes after compressor startup)	When low pressure (63LS) drops below 0.23MPa[33psi].	When low pressure (63LS) exceeds 0.38MPa[55psi].		
When high pressure (63HS1) rises	When 63HS1 exceeds 3.62MPa[525psi]	When 63HS1 is or below 3.43MPa[497psi] and 30 seconds have passed		

(2) Bypass solenoid valve (SV9) (ON = Open)

Operation	SV9		
Operation	ON	OFF	
When high pressure (63HS1) rises during the heating operation	When 63HS1 exceeds 3.50MPa When SV5b is ON and the property is 2.70MPa[391psi]or be		
Others	Always OFF		

(3) Bypass solenoid valve (SV2) (ON = Open)

Operation	SV2		
Operation	ON	OFF	
When high pressure (63HS1) rises during the heating operation	When SV5b is OFF and the pressure is 3.50MPa[507psi]or below	When 63HS1 exceeds 2.70MPa [391psi]	
When startup or resuming operation after a defrost cycle	OFF		
During defrost cycle	ON		
Others	Always OFF		

^{*}P72, P96 only

(4) Bypass solenoid valve (SV5b) (ON = Open)

Operation	SV5b		
Operation	ON	OFF	
When high pressure (63HS1) rises during the heating operation	When SV2 is OFF and the pressure is 2.70MPa[391psi]or below *	When SV9 is ON and the pressure is 3.50MPa[507psi]or below	
At startup	ON		
During defrost cycle	ON (open)		
When returning to normal operation after completion of the defrost cycle	ON for 5 minutes and goes OFF		
Others	Always OFF		

^{*}SV2 is present only on the P72 and P96 models.

(5) Bypass solenoid valve (SV5b) (ON = Open)

Operation	SI	SV5c		
Орегация	ON	OFF		
While the unit is stopped	Alwa	ys ON		
Cooling mode	When one or more of the following valves is turned OFF: SV4a through SV4c.	When the condition on the left is not met		
Defrost mode		Always OFF on the P72 and P96 models and always ON on the P120 and P144 models.		
Others	Alway	Always OFF		

-6- Compressor Frequency Control

- *Depending on the capacity required, the frequency of the compressor is controlled to keep constant evaporation temperature (0°C [32°F] = 0.71 MPa [103 psi]) during cooling operation, and condensing temperature (49°C [120°F] = 2.88 MPa [418 psi]) during heating operation.
- •The table below summarizes the operating frequency ranges of the inverter compressor during normal operation.
- •The OS in the multiple-outdoor-unit system operates at the actual compressor frequency value that is calculated by the OS based on the preliminary compressor frequency value that the OC determines.

Model	Frequency/cooling (Hz)		Frequency/heating (Hz)	
Wiodei	Max	Min	Max	Min
P72 model	43	14	52	19
P96 model	61	18	74	15
P120 model	75	18	86	15
P144 model	87	18	104	15

Note

The maximum frequency during heating operation depends on the outside air temperature and the dipswitch settings.

(1) Pressure limit

The upper limit of high pressure (63HS1) is preset, and when it exceeds the upper limit, the frequency is decreased every 15 seconds

•The actuation pressure is when the high-pressure reading on 63HS1 is 3.58MPa[519psi].

(2) Discharge temperature limit

Discharge temperature (TH4) of the compressor in operation is monitored, and when it exceeds the upper limit, the frequency is decreased every minute.

*Operating temperature is 115°C [239°F].

(3) Periodic frequency control

Frequency control other than the ones performed at start-up, upon status change, and for protection is called periodic frequency control (convergent control) and is performed in the following manner.

Periodic control cycle

Periodic control is performed after the following time has passed

- •30 seconds after either compressor start-up or the completion of defrost operation
- •30 seconds after frequency control based on discharge temperature or pressure limit

The amount of frequency change

The amount of frequency change is controlled to approximate the target value based on the evaporation temperature (Te) and condensing temperature (Tc).

-7- Defrost Operation Control

(1) Starting the defrost operation

•The defrost cycle will start when all of the three conditions (outside temperature, cumulative compressor operation time, and pipe temperature) under <Condition 1>, <Condition 2>, or <Condition 3> are met.

	Condition 1	Condition 2	Condition 3
Outside temperature (TH7)	-5°C [23°F] or above	-5°C [23°F] or below
Cumulative compressor operation time	50 minutes or more 90 minutes or more if the defrost prohibit timer is set to 90.		250 minutes or more
Pipe temperature (TH3)	The pipe temperature has stayed below the temperatures in the table below (Note1) for three minutes. The pipe temperature has stayed below the value obtained from the formula "Outside temperature (TH7) - 5°C [23°F]" for three minutes, or the 63LS reading has stayed below the value obtained from the formula "1.5 + 0.02 x (20+TH7)" for three minutes.		The pipe temperature has stayed below the temperatures in the table below (Note1) for three minutes

Note

1) Pipe temperature(TH3)

	P72	P96	P120	P144
SW3-3 OFF	-10°C	-10°C	-8°C	-8°C
SW3-3 ON	-5°C	-5°C	-5°C	-5°C

- •The defrost cycle will not start if other outdoor units are in the defrost cycle or until a minimum of 10 minutes have passed since the completion of the last defrost cycle.
- •If 10 minutes have passed since compressor startup or since the completion of a defrost cycle, a forced defrost cycle can be started by setting DIP SW2-7 to ON.
- •Even if the defrost-prohibit timer is set to 90 minutes (or 150 minutes for "Condition 3" to be met), the actual defrost-prohibit time for the next defrost cycle is 50 minutes if the last defrost cycle took 12 minutes.
- •All units in the heating mode will simultaneously go into the defrost cycle in a system with multiple units. The units that are not in operation may or may not go into the defrost cycle, depending on the cumulative operation time of their compressors.

(2) Defrost operation

Outdoou unit	Compressor frequency	Model	Compressor frequency	
		P72 model	60 Hz	
		P96 model	65 Hz	
		P120, P144 models	65 Hz	
	Outdoor unit fan	Stopped		
	SV1a	ON ((open)	
	SV2	P72, P96 models	ON (open)	
		P120, P144 models	N/A	
	SV5b	ON ((open)	
	SV5c	P72, P96 models	OFF (closed)	
		P120, P144 models	ON (open)	
	21S4a, 21S4b	OFF		
	SV9	OFF (closed)		
BC controller	LEV1	G type: 4000,	GA type: 6000	
	LEV3		GA type: 2000 60 (full closed)	
	SVM1	ON		
	SVM2	OFF		
	SVM1b	ON		
	SVM2b	OFF		
	SV■B	OFF		
	SV■A	SV A Ports that are connected to the indoor units in cooling Other ports : OFF		

(3) Stopping the defrost operation

- •The defrost cycle ends when 12 minutes have passed since the beginning of the cycle, or when the pipe temperature (TH3) is 10°C[50°F] or above has been continuously detected for 2 minutes.
- •The defrost cycle does not end for 2 minutes once started unless the pipe temperature exceeds α below within 2 minutes. 25°C \geq (α = Outdoor temperature(TH7) 25)°C \geq 5°C [77°F \geq (α = Outdoor temperature(TH7) 45)°F \geq 41°F] •In the multiple-outdoor-unit system, defrosting is stopped on all units at the same time.

(4) Problems during defrost operation

•If a problem is detected during defrost operation, the operation will be stopped, and the defrost prohibition time based on the integrated compressor operation time will be set to 20 minutes.

(5) Change in the number of operating indoor units during defrost operation

- •Even when there is a change in the number of operating indoor units during defrost operation, the operation will continue, and an adjustment will be made after the completion of the defrost operation.
- *Defrost operation will be continued, even if the indoor units stop or under the Thermo-OFF conditions until it has run its course.

-8- Refrigerant Recovery Control

Refrigerant recovery is performed for each BC port during heating operation to prevent the refrigerant from accumulating inside the units that are stopped (in the fan mode), in the cooling mode, or in the heating Thermo-OFF mode. It is also performed during cooling operation to prevent an excessive amount of refrigerant from accumulating in the outdoor heat exchanger.

Starting criteria for the refrigerant recovery cycle (during Cooling-only, Cooling-main, Heating-only, or Heating-main mode)

The refrigerant recovery mode starts when all of the following conditions are met:

 When 5 minutes have passed in the Heating-only or Heating-main mode or 30 seconds have passed in the Cooling-only or Cooling-main mode since the completion of the previous refrigerant recovery cycle AND the when following conditions are met.

TH4 > 105°C [221°F]

2) When the port is not in the 4-minute restart delay mode

Starting criteria for the refrigerant recovery cycle (during Cooling-only, Cooling-main, Heating-only, or Heating-main mode)

- When the port is in the cooling Thermo-OFF, fan, or stop mode SV■C at the port turns on for 30 seconds. (indicates port No.)
- 2) The opening of LEV1 and LEV3 is increased.

-9- Capacity Control of Outdoor Fan and Heat Exchanger

(1) Control method

- *Depending on the capacity required, the rotation speed of the outdoor unit fan is controlled by the inverter to keep a constant condensing temperature of (outside temperature +10°C [50°F]) during cooling operation and a constant evaporation temperature of (0°C [32°F] =0.71 <Pa [103psi]) during heating operation.
- •The OS in the multiple-outdoor-unit system operates at the actual outdoor unit fan control value that is calculated by the OS based on the preliminary outdoor unit fan control value that the OC determines.

(2) Control

- •Outdoor unit fan stops while the compressor is stopped (except in the presence of input from snow sensor).
- •The fan operates at full speed for 5 seconds after start-up.(Only when TH7<0°C [32°F])
- •The outdoor unit fan stops during defrost operation.
- •On the P120 and P144 models of outdoor units, before the second fan goes into operation, the capacity of the first fan is reduced to 50%.

(3) Outdoor unit heat exchanger capacity control patterns

Model	Operation mode	Operation	Solenoid valve				
iviodei		patterns	SV4a	SV4b	SV4c	SV4d	SV5c
P72 model	Cooling-only	1	OFF	OFF	-	ON	ON
	Cooling-main	2	OFF	OFF	-	OFF	ON
		3	OFF	ON	-	OFF	ON
		4	ON	OFF	-	OFF	ON
		5	ON	ON	-	OFF	OFF
	Heating-only	1	ON	ON	-	OFF	OFF
	Heating-main	1	ON	ON	-	ON	OFF
		2	ON	ON	-	OFF	OFF
	Defrost	1	ON	ON	-	OFF	OFF
P96 model	Cooling-only	1	OFF	OFF	OFF	ON	ON
	Cooling-main	2	OFF	OFF	OFF	OFF	ON
		3	OFF	OFF	ON	OFF	ON
		4	OFF	ON	ON	OFF	ON
		5	ON	ON	ON	OFF	OFF
	Heating-only	1	ON	ON	ON	OFF	OFF
	Heating-main	1	ON	ON	ON	ON	OFF
		2	ON	ON	ON	OFF	OFF
	Defrost	1	ON	ON	ON	OFF	OFF
P120, P144 models	Cooling-only	1	OFF	OFF	OFF	ON	ON
	Cooling-main	2	OFF	OFF	OFF	OFF	ON
		3	OFF	ON	OFF	OFF	ON
		4	ON	ON	OFF	OFF	ON
		5	ON	ON	ON	OFF	OFF
	Heating-only	1	ON	ON	ON	OFF	OFF
	Heating-main	1	ON	ON	ON	ON	OFF
		2	ON	ON	ON	OFF	OFF
	Defrost	1	ON	ON	ON	OFF	ON


^{*}SV4c turns on when energized on the P96 model, and it turns on when de-energized on the P120 and P144 models. (All other valves turn on when energized.)

-10- Control at Initial Start-up


- •When started up for the first time before 12 hours have elapsed after power on, the unit goes into the initial startup mode.
- •At the completion of the initial operation mode on the OC and OS, they will go into the normal control mode.

1. Flowchart of initial operation

(1) P72, P96, P120, P144 models



(2) P168, P192, P216, P240, P264, P288 models



*1 ∑Qj:Total capacity (models) code

Refer to the VII [1] 2. (1) Dipswitches for the capacity code. (page 141)

-11- Emergency Operation Mode

1. Problems with the outdoor unit

- •The P168 through P240 models of unit have a mode that allows the outdoor unit to perform an emergency operation when the other outdoor unit in the system malfunctions.
- •This mode can be started by performing an error reset via the remote controller.

(1) Starting the emergency operation

- 1) When an error occurs, the error source and the error code will be displayed on the display on the remote controller.
- 2) The error is reset using the remote controller.
- 3) If an error code appears that permits an emergency operation in step 1) above, (See the table below.), the retry operation starts.
- 4) If the same error is detected during the retry operation (step 3 above), an emergency operation can be started by resetting the error via the remote controller.

Error codes that permit an emergency operation (Applicable to both OC and OS)

Trouble source		Error codes that permit an emergency operation	Error code description
		0403	Serial communication error
		4220, 4225	Bus voltage drop
Compressor		4230	Heatsink overheat protection
Fan motor		4240	Overload protection
Inverter		4250, 4255	Overcurrent relay trip
		5110	Heatsink temperature sensor failure (THHS)
		5301	Current sensor/circuit failure
	TH2	5102	Subcool heat exchanger bypass outlet temperature sensor failure
	TH3	5103	Pipe temperature sensor failure
Thermistor	TH4	5104	Discharge temperature sensor failure
THEITHISTO	TH5	5105	Accumulator inlet temperature sensor failure
	TH6	5106	Subcool heat exchanger liquid outlet sensor failure
TH7 5		5107	Outside air temperature sensor failure
Dower	•	4102	Open phase
Power		4115	Power supply sync signal abnormality

Emergency operation pattern (2 outdoor units)

		OC failure pattern	OS failure pattern
OC		Trouble	Normal
os		Normal	Trouble
Emergency	Cooling	Permitted	Permitted
operation	Heating	Permitted	Permitted
Maximum total capacity of indoor units (Note 1)		60	0%

Note

1) If an attempt is made to put into operation a group of indoor units whose total capacity exceeds the maximum allowable capacity, some of the indoor units will go into the same condition as Thermo-OFF.

(2) Ending the emergency operation

1) End conditions

When one of the following conditions is met, emergency operation stops, and the unit makes an error stop.

- •When the integrated operation time of compressor in cooling mode has reached four hours.
- •When the integrated operation time of compressor in heating mode has reached two hours.
- *When an error is detected that does not permit the unit to perform an emergency operation.

2) Control at or after the completion of emergency operation

- •At or after the completion of emergency operation, the compressor stops, and the error code reappears on the remote controller.
- •If another error reset is performed at the completion of an emergency mode, the unit repeats the procedures in section (1) above.
- •To stop the emergency mode and perform a current-carrying operation after correcting the error, perform a power reset.

2. Communication circuit failure or when some of the outdoor units are turned off

This is a temporary operation mode in which the outdoor unit that is not in trouble operates when communication circuit failure occurs or when some of the outdoor units are turned off.

(1) Starting the emergency operation (When the OC is in trouble)

- 1) When an error occurs, the error source and the error code appear on the display on the remote controller.
- 2) Reset the error via the remote controller to start an emergency operation.

Precautions before servicing the unit

- •When the OC is in trouble, the OS temporarily takes over the OC's function and performs an emergency operation. When this happens, the indoor unit connection information are changed.
- •In a system that has a billing function, a message indicating that the billing system information has an error may appear on the TG-2000A. Even if this message appears, do not change (or set) the refrigerant system information on the TG-2000A. After the completion of an emergency operation, the correct connection information will be restored.

(2) Starting the emergency operation (When the OS is in trouble)

1) A communication error occurs. -> An emergency operation starts in approximately six minutes.

Error codes that permit an emergency operation (Applicable to both OC and OS)

Trouble source	Error codes that permit an emergency operation	Error code description	
Circuit board failure or the power	6607	No acknowledgement error	
to the outdoor units is off	6608	No response error	

Emergency operation pattern (2 outdoor units)

		OC failure pattern	OS failure pattern
OC		Trouble	Normal
os		Normal	Trouble
Emergency	Cooling	Permitted	Permitted
operation	Heating	Permitted	Permitted
Maximum total capacity of indoor units (Note 1)		Capacity the total cap operable out	pacity of the

Note


1) If an attempt is made to put into operation a group of indoor units whose total capacity exceeds the maximum allowable capacity, some of the indoor units will go into the same condition as Thermo-OFF.

(3) Ending the emergency operation

When communication is restored, the emergency mode is cancelled, and the units go into the normal operation mode.


-12- Control Method

The control system configuration for the PURY models is shown in the chart below.



Autonomous distributed control system: A system that consists of three independent sub control systems, instead of a single centralized control system, that work together to maintain the overall control of the entire system.

-13- Cooling/heating Circuit Control and General Function of System Equipment



-14- Operation Mode

(1) Indoor unit operation mode

The operation mode can be selected from the following 6 modes using the remote controller.

1	Cooling mode
2	Heating mode
3	Dry mode
4	Automatic cooling/heating mode
5	Fan mode
6	Stopping mode

(2) Outdoor unit operation mode


1	Cooling only mode	All indoor units in operation are in cooling mode.
2	Heating only mode	All indoor units in operation are in heating mode.
3	Cooling main mode	Coexistence of units in cooling and heating modes.
4	Heating main mode	Coexistence of units in cooling and heating modes.
5	Stopping mode	All indoor units are in fan mode or stopping mode.

<u>Note</u>


When units in cooing and heating coexist, the operation mode (cooling main mode or heating main mode) will be determined, based on the refrigerant pressure in the R2 refrigerant circuit and speed variation data.

(3) Operation pattern for automatic cooling/heating mode

When the automatic cooling/heating mode is selected from remote controller functions, the indoor temperature will be detected in pattern as shown in the figure below, and the operation mode (cooling or heating) will automatically be selected.



(4) Relationship between the operation mode and the load capacity (kW) (within a system)



-15- DEMAND Control

Cooling/heating operation can be prohibited (Thermo-OFF) by an external input to the indoor units.

Note

When DIP SW4-4 is set to ON, the 4-step DEMAND control is enabled. Eight-step demand control is possible in the system with two outdoor units.

Refer to Chapter II [3] 2. (7) "Various types of control using input-output signal connector on the outdoor unit (various connection options)" for details.(page 23)

[3] Controlling BC Controller

1. Control of SV■A, SV■ B, and SV ■C

SV ■A, SV ■ B, and SV ■C turn on or off depending on the operation mode of the branch.

		Mode			
		Cooling	Heating	Stopped	Defrost
	SV■A	ON	OFF	OFF	OFF
Port	SV∎B	OFF	ON	OFF	OFF
	SV■C	ON	OFF	OFF	OFF

2. Control of SVM1, SVM1b

SVM turns on or off depending on the operation mode.

Operation mode	Cooling only	Cooling main	Heating only	Heating main	Defrost	Stopped
SVM1,1b	ON	Pressure dif- ferential con- trol*1	OFF	OFF	ON	OFF

^{*1.} Pressure differential control: The detected differential pressure (PS1 and P3) is controlle every minute so as to be within a certain range.

3. Control of LEV■

LEV ■ opening (sj) is controlled as follows depending on the operation mode.

	Operation mode	Cooling only	Cooling main	Heating only	Heating main	Defrost	Stopped
	LEV1			110	110 ^{*3}	2000	
G,GA, HA	LEV2 (only GA,HA type)	2000	Liquid level control*1dif-				1200
type	LEV3	Superheat control*4	ferential control*2	Pressure differential control*2	Pressure dif- ferential con- trol*2	G:1000 GA,HA:2000	60
GB,HB type	LEV3	Superheat control*4	Superheat control*4	60	60	60	60

^{*1.} Liquid level control: The liquid level detected by the liquid inlet temperature (TH11 sensor) is controlled so as to be within a certain range.

4. Control of SVM2, SVM2b

Operation mode	Cooling only	Cooling main	Heating only	Heating main	Defrost	Stopped
SVM2,2b	OFF	OFF	Pressure differential control*1	Pressure differential control*1	OFF	OFF

^{*1.} Pressure differential control: The detected differential pressure (PS1 and P3) is controlled every minute so as to be within a certain range.


^{*2.} Pressure differential control: The detected differential pressure (PS1 and P3) is controlle every minute so as to be within a certain range.

^{*3.} Can be 110 or more due to pressure rise on the liquid side (PS1).

^{*4.} Superheat control: The amound of superheat that is calculated on the bypass inlet and outlet temperature (G, GA,HA:TH12,TH15, GB, HB: TH12, TH15) is controlled every minute so as to be within a certain range.

[4] Operation Flow Chart


- 1. Mode determination flowchart
- (1) Indoor unit (cooling, heating, dry, fan mode)



- *Note 1. Indoor unit LEV fully closed : Opening 41.
- *Note 2. The system may go into the error mode on either the indoor unit side or the BC controller or outdoor unit side.


 If some of the indoor units are experiencing a problem, only those indoor units that are experiencing the problem will stop. If the BC controller or the outdoor unit is experiencing a problem, all the connected units will stop.
- *Note 3. If multiple indoor units are connected to a port and there is a discrepancy in the operation mode between the indoor unit and the port, the operation will be prohibited. (Operation mode blinks on the remote controller, the Fan stops, indoor unit LEV becomes fully closed.)

(2) Outdoor unit (cooling only, heating only, cooling main and heating main modes)



- *Note 1. For about 3 minutes after power on, search for the indoor unit address, for the remote controller address, and for the group information will start. During this, "HO"/ "PLEASE WAIT" blinks on the display of the remote controller. When the indoor unit to be controlled by the remote controller is missing, "HO"/ "PLEASE WAIT" keeps blinking on the display of the remote controller even after 3 or more minutes after power on.
- *Note 2. The system may go into the error mode on either the indoor unit or the outdoor unit side. The outdoor stops only when all of the connected indoor units are experiencing problems. The operation of even a single indoor unit will keep the outdoor unit running. The error will be indicated on the LED display.
- *Note 3. The units will follow the operation mode commands from the BC controller
- *Note 4. When the operation mode commands from the BC controllers are mixed (both cooling and heating), the actual operation mode is determined by the outdoor unit.


(3) BC controller (cooling only, heating only, cooling main and heating main modes)



Note 1. The system may go into the error mode on either the indoor unit side or the BC controller or outdoor unit side. If some of the indoor units are experiencing a problem, only those indoor units that are experiencing the problem will stop. If the BC controller or the outdoor unit is experiencing a problem, all the connected units will stop.


2. Operations in each mode

(1) Cooling operation



*Note 1. The indoor fan operates at the set notch under cooling mode regardless of the ON/OFF state of the thermostat.

(2) Heating operation




*Note 1. When the outdoor unit goes into the defrost mode, defrost command is sent to the BC controller and indoor units.

Upon reception of the command, the indoor units will go into the defrost mode. When defrosting is completed and upon receiving the signal that indicates the completion of defrosting, indoor units will resume the heating operation.

*Note 2. Defrost end condition: 10 or more minutes must pass after defrost operation.
or Outdoor unit piping temperature: refer to "-7- Defrost operation control" of [2] Controlling the Outdoor Unit. (page 147)

(3) Dry operation



*Note 1.When the indoor unit inlet temperature exceeds 18°C [64°F], the outdoor unit (compressor) and the indoor unit fan start the intermittent operation simultaneously. When the indoor unit inlet temperature becomes 18°C [64°F],or less, the fan always runs (at low speed). The outdoor unit, the indoor unit, and the solenoid valve operate in the same way as they do in the cooling operation when the compressor is turned on

*Note 2.Thermostat is always kept on during test run mode, and indoor and outdoor unit intermittent operation (ON) time is a little longer than that of normal operation.

VIII Test Run Mode

[1]	Items to be checked before a Test Run	. 169
[2]	Test Run Method	. 170
[3]	Operating Characteristic and Refrigerant Amount	. 171
[4]	Adjusting the Refrigerant Amount	. 171
[5]	Refrigerant Amount Adjust Mode	.174
[6]	The following symptoms are normal.	.176
[7]	Standard Operation Data (Reference Data)	. 177

[1] Items to be checked before a Test Run

- (1) Check for refrigerant leak and loose cables and connectors.
- (2) Measure the insulation resistance between the power supply terminal block and the ground with a 500V megger and make sure it reads at least 1.0Mohm.

Note

- •Do not operate the unit if the insulation resistance is below 1.0Mohm.
- *Do not apply megger voltage to the terminal block for transmission line. Doing so will damage the controller board.
- •The insulation resistance between the power supply terminal block and the ground could go down to close to 1Mohm immediately after installation or when the power is kept off for an extended period of time because of the accumulation of refrigerant in the compressor.
- •If insulation resistance reads at least 1Mohm, by turning on the main power and powering the belt heater for at least 12 hours, the refrigerant in the compressor will evaporate and the insulation resistance will go up.
- •Do not measure the insulation resistance of the terminal block for transmission line for the unit remote controller.
- (3) Check that the valve on the gas pipe and liquid pipe are fully open.

Note

Securely tighten the cap.

- (4) Check the phase sequence and the voltage of the power supply.
- (5) [When a transmission booster is connected]

 Turn on the transmission booster before turning on the outdoor units.

Note

- •If the outdoor units are turned on first, the connection information for the refrigerant circuit may not be properly recognized.
- •In case the outdoor units are turned on before the transmission booster is turned on, perform a power reset on the outdoor units after turning on the power booster.
- (6) Turn on the main power to the unit at least 12 hours before test run to power the belt heater.


Note

Insufficient powering time may result in compressor damage.

(7) When a power supply unit is connected to the transmission line for centralized control, perform a test run with the power supply unit being energized. Leave the power jumper connector on CN41 as it is (factory setting).

[2] Test Run Method

The figure shows an MA remote controller (PAR-21MAA).



Operation procedures					
Turn on the main power.	\rightarrow	"PLEASE WAIT" appears on the LCD for up to five minutes. Leave the power on for 12 hours. (Energize the belt heater.)			
Press the Test button twice.	\rightarrow	Operation mode display "TEST RUN" and OPERATION MODE are displayed alternately.			
Press the Operation Mode button. ☐♣♦♦♦	\rightarrow	Make sure that the air is blowing out.			
Switch to cooling (or heating) operation by pressing the → Make sure that cold (or warm) air blows out.	Opera	ation Mode button. ロゆない			
Press the Fan Speed button.	\rightarrow	Make sure that the fan speed changes with each pressing of the button.			
Change the air flow direction by pressing the Ventilation	n butto	or the Louver button.			
ightarrow Make sure that the air flow direction changes with e	ach pr	essing of the button.			
→ Confirm the operation of outdoor unit fan.					
Confirm the operation of all interlocked equipment, such as ventilation equipment.					
Cancel the test run by pressing the ON/OFF button. → Stop					
Note 1: Refer to the following pages if an error code appears on the remote controller or when the unit malfunctions. 2: The OFF timer will automatically stop the test run after 2 hours. 3: The remaining time for the test run will be displayed in the time display during test run.					
4: The temperature of the liquid pipe on the indoor unit will be displayed in the room temperature display window on the remote controller during test run.					
5: On some models, "NOT AVAILABLE" may appe6: If an external input is connected, perform a test		ne display when the Vane Control button is pressed. This is normal. ng the external input signal.			
7: Test run all systems for at least 15 minutes to dete	ect pos	sible system errors.			

[3] Operating Characteristic and Refrigerant Amount

It is important to have a clear understanding of the characteristics of refrigerant and the operating characteristics of air conditioners before attempting to adjust the refrigerant amount in a given system.

1. Operating characteristic and refrigerant amount

The following table shows items of particular importance.

- 1) During cooling operation, the amount of refrigerant in the accumulator is the smallest when all indoor units are in operation.
- 2) During heating operation, the amount of refrigerant in the accumulator is the largest when all indoor units are in operation.
- 3) General tendency of discharge temperature
 - •Discharge temperature tends to rise when the system is short on refrigerant.
 - •Changing the amount of refrigerant in the system while there is refrigerant in the accumulator has little effect on the discharge temperature.
 - •The higher the pressure, the more likely it is for the discharge temperature to rise.
 - •The lower the pressure, the more likely it is for the discharge temperature to rise.
- 4) When the amount of refrigerant in the system is adequate, the compressor shell temperature is 10 to 60°C [18 to 108°F] higher than the low pressure saturation temperature (Te).
 - -> If the temperature difference between the compressor shell temperature and low pressure saturation temperature (Te) is smaller than 5°C [9°F], an overcharging of refrigerant is suspected.

[4] Adjusting the Refrigerant Amount

1. Symptoms

Overcharging or undercharging of refrigerant can cause the following symptoms:

Before attempting to adjust the amount of refrigerant in the system, thoroughly check the operating conditions of the system. Then, adjust the refrigerant amount by running the unit in the refrigerant amount adjust mode.

The system comes to an abnormal stop, displaying 1500 (overcharged refrigerant) on the controller.	Overcharged refrigerant
The operating frequency does not reach the set frequency, and there is a problem with performance.	Insufficient refrigerant amount
The system comes to an abnormal stop, displaying 1102 (abnormal discharge temperature) on the controller.	

2. Amount of refrigerant

(1) To be checked during operation

Operate all indoor units in either cooling-only or heating-only mode, and check such items as discharge temperature, subcooling, low pressure, suction temperature, and shell bottom temperature to estimate the amount of refrigerant in the system.

Symptoms	Conclusion
Discharge temperature is high. (Normal discharge temperature is below 95°C [203°F].)	Slightly under-
Low pressure is unusually low.	charged refrigerant
Suction superheat is large. (Normal suction superheat is less than 20°C [36°F].)	
Compressor shell bottom temperature is high. (The difference between the compressor shell bottom temperature and low pressure saturation temperature (Te) is greater than 60°C [108°F].)	
Discharge superheat is small. (Normal discharge superheat is greater than 10°C [18°F].)	Slightly overcharged
Compressor shell bottom temperature is low. (The difference between the compressor shell bottom temperature and low pressure saturation temperature (Te) is less than 5°C [9°F].)	refrigerant

3. Amount of refrigerant to be added

The amount of refrigerant that is shown in the table below is factory-charged to the outdoor units. The amount necessary for extended pipe (field piping) is not included and must be added on site.

Outdoor unit model	P72	P96	P120	P144
Amount of pre-charged refrigerant in the outdoor unit (kg)	10.5	11.8	11.8	11.8
Amount of pre-charged refrigerant in the outdoor unit [lbs-oz]	23-2	26-1	26-1	26-1

(1) Calculation formula

The amount of refrigerant to be added depends on the size and the length of field piping. (unit in m[ft])

Amount of added refrigerant (kg) =
$$(0.36 \times L_1) + (0.23 \times L_2) + (0.16 \times L_3) + (0.11 \times L_4) + (0.2 \times L_5) + (0.12 \times L_6) + (0.06 \times L_7) + (0.024 \times L_8) + \alpha_1 + \alpha_2 + \alpha_3 + \alpha_4$$

Amount of added refrigerant (oz) = $(3.88 \times L_1') + (2.48 \times L_2') + (1.73 \times L_3') + (1.19 \times L_4') + (2.16 \times L_5') + (1.30 \times L_6') + (0.65 \times L_7') + (0.26 \times L_8') + \alpha_1' + \alpha_2' + \alpha_3' + \alpha_4'$

L₁: Length of ø28.58[1-1/8"] high pressure pipe (m) L₂: Length of ø22.2[7/8"] high pressure pipe (m) L_3 : Length of ø19.05[3/4"] high pressure pipe (m) L₄: Length of ø15.88[5/8"] high pressure pipe (m) L₅: Length of ø15.88[5/8"] liquid pipe (m)

L₆: Length of ø12.7[1/2"] liquid pipe (m) L_7 : Length of ø9.52[3/8"] liquid pipe (m) L_8 : Length of ø6.35[1/4"] liquid pipe (m) $\alpha_1, \alpha_2, \alpha_3, \alpha_4, \alpha_1', \alpha_3', \alpha_4'$: Refer to the table below.

 L_{1}^{\prime} : Length of ø28.58[1-1/8"] high pressure pipe [ft] : Length of ø22.2[7/8"] high pressure pipe [ft] : Length of ø19.05[3/4"] high pressure pipe [ft] : Length of ø15.88[5/8"] high pressure pipe [ft] : Length of ø15.88[5/8"] liquid pipe [ft]

: Length of ø12.7[1/2"] liquid pipe [ft] : Length of ø9.52[3/8"] liquid pipe [ft] : Length of ø6.35[1/4"] liquid pipe [ft]

Outdoor unit total	Amount for the BC controllers (main/sub)			
ilidex	α ₁ (kg)	α ₁ ' (oz)		
P72 model	3.0	106		
P96 model				
P120 model	4.5	159		
P144 model				
P168 model	7.5	265		
P192 model				
P216 model				
P240 model	9.0	318		
P264 model				
P288 model]			

HA type	$\alpha_{2}(kg)$	α_2' (oz)			
1	2.0	71			
BC controller (sub)					
Total number of BC	lpha ₃ (kg)	α ₃ ' (oz)			

1.0

2.0

35

71

BC controller (main)


connec	Total capacity of connected indoor		Amount for the Indoor unit	
ι	ınits		$lpha_4(kg)$	α ₄ ' (oz)
	-	27	2.0	71
28	-	54	2.5	89
55	-	126	3.0	106
127	-	144	3.5	124
145	-	180	4.5	159
181	-	234	5.0	177
235	-	273	6.0	212
274	-	307	8.0	283
308	-	342	9.0	318
343	-	411	10.0	353
412	-		12.0	424

Round up the calculation result to the nearest 0.1kg. (Example: 18.04kg to 18.1kg)

1 2

Round up the calculation result in increments of 4oz (0.1kg) or round it up to the nearest 1oz. (Example: 78.21oz to 79oz)

(2) Example



(3) Sample calculation

	Outdoor unit1:96 model Outdoor unit2:72 model					
	Indoor unit1:30 model	A: φ28.58	[1-1/8"]	40m[131ft]	a:φ9.52 [3/8"]	10m[32ft]
When	Indoor unit2:96 model	B: \phi 9.52	[3/8"]	10m[32ft]	b: φ9.52 [3/8"]	5m[16ft]
VVIICII	Indoor unit3:12 model	C: ϕ 9.52	[3/8"]	20m[65ft]	c: \phi 6.35 [1/4"]	5m[16ft]
	Indoor unit4:15 model	$D: \phi 9.52$	[3/8"]	5m[16ft]	d: ϕ 6.35 [1/4"]	10m[32ft]
	Indoor unit5:12 model	$E: \phi 9.52$	[3/8"]	5m[16ft]	e: \$\phi 6.35 [1/4"]	5m[16ft]
	Indoor unit6:24 model	F: \phi 22.2	[7/8"]	3m[9ft]	f: \$\phi 9.52 [3/8"]	5m[16ft]
	`	G: ϕ 19.05	[3/4"]	1m[3ft]		

The aggregate length of each liquid pipe type.

The final result will be as follows:

Amount of refrigerant to be charged [kg] = $40 \times 0.36 + 3 \times 0.23 + 1 \times 0.16 + 50 \times 0.06 + 20 \times 0.024 + 7.5 + 2 + 5$ = 33.3kg Amount of refrigerant to be charged [oz] = $131 \times 3.88 + 9 \times 2.48 + 3 \times 1.73 + 164 \times 0.65 + 65 \times 0.26 + 265 + 71 + 177$

= 1173oz

HWE0913A - 173 - GB

[5] Refrigerant Amount Adjust Mode

1. Procedures

Follow the procedures below to add or extract refrigerant as necessary depending on the operation mode.

When the function switch (SW4-3) on the main board on the outdoor unit (OC only) is turned to ON, the unit goes into the refrigerant amount adjust mode, and the following sequence is followed.

Note

SW4-3 on the OS is invalid, and the unit will not go into the refrigerant amount adjust mode.

Operation

When the unit is in the refrigerant amount adjust mode, the LEV on the indoor unit does not open as fully as it normally does during cooling operation to secure subcooling.

Note


- 1) Adjust the refrigerant amount based on the values of TH4, SC11, SC16, and Tc, following the flowchart below. Check the TH4, SC11, SC16, and Tc values on the OC, OS by following the flowchart. The TH4, SC11, SC16, and Tc values can be displayed by setting the self-diagnosis switch (SW1) on the main board on the OC, OS.
- 2) There may be cases when the refrigerant amount may seem adequate for a short while after starting the unit in the refrigerant amount adjust mode but turn out to be inadequate later on (when the refrigerant system stabilizes).


When the amount of refrigerant is truly adequate.

Subcool (SC11 and SC16) of the BC controller is 5°C [9°F] or above and SH on the indoor unit is between 5 and 15°C [9 and 27°F].

The refrigerant amount may seem adequate at the moment, but may turn out to be inadequate later on. Subcool (SC11 and SC16) of the BC controller is 5°C [9°F] or less and SH on the indoor unit is 5°C [9°F] or less. Wait until the Subcool (SC11 and SC16) of the BC controller reaches 5°C [9°F] or above and the SH of the indoor unit is between 5 and 15°C [9 and 27°F] to determine that the refrigerant amount is adequate.

- •SC11: Subcool of liquid refrigerant at BC controller inlet; SC16: Subcool of liquid refrigerant at BC controller outlet
- 3) High pressure must be at least 2.0MPa [290psi] to enable a proper adjustment of refrigerant amount to be made.
- 4) Refrigerant amount adjust mode automatically ends 90 minutes after beginning. When this happens, by turning off the SW4-3 and turning them back on, the unit will go back into the refrigerant amount adjust mode.





! CAUTION

Do not release the extracted refrigerant into the air.

↑ CAUTION

Charge liquid refrigerant (as opposed to gaseous refrigerant) into the system.

•If gaseous refrigerant is charged into the system, the composition of the refrigerant in the cylinder will change and may result in performance loss.

[6] The following symptoms are normal.

Symptoms	Remote controller display	Cause
The indoor unit does not start after starting cooling (heating) operation.	"Cooling (heating)" icon blinks on the display.	The unit cannot perform a heating (cooling) operation when other indoor units are performing a cooling (heating) operation.
The auto vane adjusts its position by itself.	Normal display	After an hour of cooling operation with the auto vane in the vertical position, the vane may automatically move into the horizontal position. Louver blades will automatically move into the horizontal position while the unit is in the defrost mode, pre-heating stand-by mode, or when the thermostat triggers unit off.
The fan stops during heating operation.	Defrost	The fan remains stopped during defrost operation.
The fan keeps running after the unit has stopped.	Unlit	When the auxiliary heater is turned on, the fan operates for one minute after stopping to dissipate heat.
The fan speed does not reach the set speed when operation switch is turned on.	STAND BY	The fan operates at extra low speed for 5 minutes after it is turned on or until the pipe temperature reaches 35°C[95°F], then it operates at low speed for 2 minutes, and finally it operates at the set speed. (Pre-heating stand-by)
When the main power is turned on, the display shown on the right appears on the indoor unit remote controller for 5 minutes.	"HO" or "PLEASE WAIT" icons blink on the display.	The system is starting up. Wait until the blinking display of "HO" or "PLEASE WAIT" go off.
The drain pump keeps running after the unit has stopped.	Unlit	The drain pump stays in operation for three minutes after the unit in the cooling mode is stopped.
The drain pump is running while the unit is stopped.		When drain water is detected, the drain pump goes into operation even while the unit is stopped.
Indoor unit and BC controller make noise during cooling/ heating changeover.	Normal display	This noise is made when the refrigerant circuit is reversed and is normal.
Sound of the refrigerant flow is heard from the indoor unit immediately after starting operation.	Normal display	This is caused by the transient instability of the refrigerant flow and is normal.
Warm air sometimes comes out of the indoor units that are not in the heating mode.	Normal display	This is due to the fact that the LEVs on some of the indoor units are kept slightly open to prevent the refrigerant in the indoor units that are not operating in the heating mode from liquefying and accumulating in the compressor. It is part of a normal operation.

[7] Standard Operation Data (Reference Data)

- 1. Single unit
- (1) Cooling only operation

		Operation		Outdoor unit model		
	Operation			PURY-P72TJMU-A	PURY-P96TJMU-A	
Model name	of BC control	ler		CMB-P104NU-G	CMB-P104NU-G	
	Ambient tempera-			26.7°C/19.4°C [80 °F/67 °F]	26.7°C/19.4°C [80 °F/67 °F]	
ture		Outdoor	DB/WB	35°C/- [95 °F/-]	35°C/- [95 °F/-]	
		No. of connected units	Unit	3	2	
	Indoor unit	No. of units in operation	Offic	3	2	
Operating		Model	-	24/24/24	48/48	
conditions		Main pipe		5 [16-3/8"]	5 [16-3/8"]	
	Piping	Branch pipe	m	10 [32-3/4"]	10 [32-3/4"]	
		Total pipe length	[ft] -	35 [114-13/16"]	25 [82]	
	Fan speed		-	Hi	Hi	
	Amount of re	efrigerant	kg [lbs-oz]	19.1 [42]	21.3 [47]	
Electric curre		ent	Α	15.7	21.7	
Outdoor unit	Voltage		V	230	230	
	Compressor	frequency	Hz	43	61	
LEV open-	Indoor unit		Pulse	180/200/220	387/387	
ing	BC controlle	r (1/2/3)	i dise	2000/-/180	2000/-/170	
Pressure	High pressur Low pressur		MPa	2.65/0.92 [384/133]	2.78/0.90 [403/131]	
riessuie	BC controlle Intermediate	r on the liquid side(PS1)/ part(PS3)	[psi]	2.59/2.59 [375/375]	2.70/2.70 [392/392]	
		Discharge (TH4)		76 [169]	87 [189]	
		Heat exchanger outlet (TH3)		41 [106]	41 [106]	
_ ,	Outdoor	Accumulator inlet		14 [57]	8 [46]	
Temp. of each sec-	unit	Accumulator outlet	°C [°F]	14 [57]	8 [46]	
tion		Compressor inlet	ני־ן	23 [73]	19 [66]	
		Compressor shell bottom		34 [93]	40 [104]	
	Indoor unit	LEV inlet		24 [75]	19 [66]	
	indoor unit	Heat exchanger inlet		12 [54]	6 [43]	

		Operation		Outdoor unit model		
		Operation	-	PURY-P120TJMU-A	PURY-P144TJMU-A	
Model name	of BC controll	ler		CMB-P104NU-G	CMB-P108NU-GA	
	Ambient tempera-	Indoor	DB/WB	26.7°C/19.4°C [80 °F/67 °F]	26.7°C/19.4°C [80 °F/67 °F]	
	ture	Outdoor	06/446	35°C/- [95 °F/-]	35°C/- [95 °F/-]	
		No. of connected units	Unit	4	4	
	Indoor unit	No. of units in operation	Offic	4	4	
Operating		Model	-	30/30/30/30	36/36/36/36	
conditions		Main pipe		5 [16-3/8"]	5 [16-3/8"]	
	Piping	Branch pipe	m	10 [32-3/4"]	10 [32-3/4"]	
	, 3	Total pipe length	[ft]	45 [147-5/8"]	45 [147-5/8"]	
	Fan speed	Fan speed		Hi	Hi	
	Amount of refrigerant		kg [lbs-oz]	22.5 [50]	23.4 [52]	
	Electric current		Α	27.8	34.6	
Outdoor unit	Voltage		V	230	230	
	Compressor frequency		Hz	75	87	
LEV open-	Indoor unit		Pulse	230/230/230/230	275/275/275/275	
ing	BC controlle	r (1/2/3)	ruise -	2000/-/210	2000/2000/250	
Pressure		High pressure(63HS1)/ Low pressure(63LS)		2.82/0.94 [409/136]	2.87/0.96 [416/139]	
i ressure	BC controller on the liquid side(PS1)/ Intermediate part(PS3)		[psi]	2.73/2.72 [395/394]	2.80/2.80 [406/406]	
		Discharge (TH4)		82 [180]	83 [181]	
		Heat exchanger outlet (TH3)		43 [109]	44 [111]	
T	Outdoor unit	Accumulator inlet		10 [50]	10 [50]	
Temp. of each sec-	uiiit	Accumulator outlet	°C [°F]	10 [50]	10 [50]	
tion		Compressor inlet	[ר]	22 [72]	22 [72]	
		Compressor shell bottom		44 [111]	44 [111]	
	Indoor unit	LEV inlet		22 [72]	22 [72]	
	muoor unit	Heat exchanger inlet		13 [55]	13 [55]	

(2) Heating only operation

Operation				Outdoor u	ınit model
		Operation	-	PURY-P72TJMU-A	PURY-P96TJMU-A
Model name	of BC control	ler		CMB-P104NU-G	CMB-P104NU-G
	Ambient tempera-	Indoor	DB/WB	21.1°C/- [70 °F/-]	21.1°C/- [70 °F/-]
	ture	Outdoor	00/440	8.3°C/6.1°C [47 °F/43 °F]	8.3°C/6.1°C [47 °F/43 °F]
		No. of connected units	Unit	3	2
	Indoor unit	No. of units in operation	Offic	3	2
Operating		Model	-	24/24/24	48/48
conditions		Main pipe		5 [16-3/8"]	5 [16-3/8"]
	Piping	Branch pipe	m	10 [32-3/4"]	10 [32-3/4"]
		Total pipe length	[ft]	35 [114-13/16"]	25 [82]
	Fan speed	Fan speed		Hi	Hi
Amount of		efrigerant	kg [lbs-oz]	19.1 [42]	21.3 [47]
	Electric curre	ent	Α	17.1	24.1
Outdoor unit	Voltage		V	230	230
	Compressor	frequency	Hz	52	74
LEV open-	Indoor unit		Pulse	205/203/200	406/406
ing	BC controlle	r (1/2/3)	i uise	110/-/520	110/-/590
Pressure	High pressur Low pressur		MPa	2.52/0.7 [365/102]	2.52/0.63 [365/91]
Flessule	BC controller on the liquid side(PS1)/ Intermediate part(PS3)		[psi]	2.45/2.13 [355/309]	2.48/2.27 [360/329]
		Discharge (TH4)		68 [154]	78 [172]
		Heat exchanger outlet (TH6)		2 [36]	0 [32]
	Outdoor	Accumulator inlet	-	1 [34]	-2 [28]
Temp. of each sec-	unit	Accumulator outlet	°C	1 [34]	-3 [27]
tion		Compressor inlet	[°F]	1 [34]	-3 [27]
		Compressor shell bottom	ŀ	40 [104]	40 [104]
	Indoor unit	LEV inlet	ŀ	30 [86]	36 [97]
	muoor unit	Heat exchanger inlet	•	62 [144]	68 [154]

		Operation		Outdoor unit model		
		Operation		PURY-P120TJMU-A	PURY-P144TJMU-A	
Model name	of BC control	ler		CMB-P104NU-G	CMB-P108NU-GA	
1	Ambient tempera-	Indoor	DB/WB	21.1°C/- [70 °F/-]	21.1°C/- [70 °F/-]	
	ture	Outdoor	00/440	8.3°C/6.1°C [47 °F/43 °F]	8.3°C/6.1°C [47 °F/43 °F]	
		No. of connected units	Unit	4	4	
	Indoor unit	No. of units in operation	Offic	4	4	
Operating		Model	-	30/30/30/30	36/36/36/36	
conditions		Main pipe		5 [16-3/8"]	5 [16-3/8"]	
	Piping	Branch pipe	m	10 [32-3/4"]	10 [32-3/4"]	
		Total pipe length	[ft]	45 [147-5/8"]	45 [147-5/8"]	
	Fan speed	Fan speed		Hi	Hi	
Amount of r		efrigerant	kg [lbs-oz]	22.5 [50]	23.4 [52]	
	Electric curre	ent	Α	30.7	36.8	
Outdoor unit	Voltage		V	230	230	
	Compressor	frequency	Hz	86	104	
LEV open-	Indoor unit		Pulse	295/295/295/295	350/350/350/350	
ing	BC controlle	r (1/2/3)	Fuise	110/-/660	110/110/870	
Pressure	High pressur Low pressur		MPa	2.57/0.64 [372/92]	2.52/0.63 [365/91]	
i lessure	BC controller on the liquid side(PS1)/ Intermediate part(PS3)		[psi]	2.54/2.22 [368/321]	2.45/2.13 [355/309]	
		Discharge (TH4)		73 [163]	73 [163]	
		Heat exchanger outlet (TH6)		2 [36]	2 [36]	
T	Outdoor unit	Accumulator inlet		-1 [30]	-1 [30]	
Temp. of each sec-	uiiit	Accumulator outlet	°C [°F]	-1 [30]	-1 [30]	
tion		Compressor inlet	[ר]	-1 [30]	-1 [30]	
		Compressor shell bottom		40 [104]	40 [104]	
	Indoor unit	LEV inlet		28 [82]	28 [82]	
	inuoor unit	Heat exchanger inlet		67 [153]	67 [153]	

2. 2-unit combination

(1) Cooling only operation

				Outdoor u	ınit model	
		Operation		PURY-P168TSJMU-A		
				PURY-P96TJMU-A	PURY-P72TJMU-A	
Model name	of BC controll	er		CMB-P10	08NU-GA	
Ambient		Indoor		26.7°C/19.4°C	[80 °F/67 °F]	
	tempera- ture	Outdoor	DB/WB	35°C/-	[95 °F/-]	
		No. of connected units	Unit	ţ	5	
	Indoor unit	No. of units in operation	Offic	ţ	5	
Operating		Model	-	30/30/3	6/36/36	
conditions		Main pipe		5	[16-3/8"]	
	Piping	Branch pipe	m [ft]	10	[32-3/4"]	
		Total pipe length		55	[180-1/8"]	
	Fan speed		-	ŀ	li	
	Amount of refrigerant		kg [lbs-oz]	38.5 [85]		
	Electric curre	ent	Α	38	3.6	
Outdoor unit	Voltage		V	230		
	Compressor	frequency	Hz	61	43	
LEV open-	Indoor unit		Pulse	230/230/230/275/275		
ing	BC controller	r (1/2/3)	i uise	2000/2000/260		
Pressure	High pressure		MPa	2.78/0.91 [403/131]	2.65/0.91 [384/131]	
Fiessule	BC controller Intermediate	on the liquid side(PS1)/ part(PS3)	[psi]	2.65/2.65 [384/384]		
		Discharge (TH4)		87 [189]	76 [169]	
		Heat exchanger outlet (TH3)		41 [106]	41 [106]	
	Outdoor	Accumulator inlet		8 [46]	14 [57]	
Temp. of each sec-	unit	Accumulator outlet	°C [°F]	8 [46]	14 [57]	
tion		Compressor inlet	[ר]	19 [66]	23 [73]	
		Compressor shell bottom		40 [104]	34 [93]	
	Indoor unit	LEV inlet		22	[72]	
	indoor uniit	Heat exchanger inlet		9	[48]	

				Outdoor u	unit model	
		Operation		PURY-P19	2TSJMU-A	
				PURY-P96TJMU-A	PURY-P96TJMU-A	
Model name	of BC control	ler		CMB-P10	08NU-GA	
	Ambient	Indoor		26.7°C/19.4°C	[80 °F/67 °F]	
	tempera- ture	Outdoor	DB/WB	35°C/-	[95 °F/-]	
		No. of connected units	Unit	(6	
Indoor uni	Indoor unit	No. of units in operation	Unit	(6	
Operating		Model	-	30/30/30	/30/36/36	
conditions	_	Main pipe		5	[16-3/8"]	
Fan speed Amount of re	Branch pipe	m [ft]	10	[32-3/4"]		
		Total pipe length	.,	65	[213-1/4"]	
	Fan speed	Fan speed		F	l i	
	Amount of refrigerant		kg [lbs-oz]	42.4 [93]		
	Electric curre	Electric current		44	1.8	
Outdoor unit	Voltage		V	23	30	
	Compressor	Compressor frequency		61	61	
LEV open-	Indoor unit		Pulse	230/230/230/230/275/275		
ing	BC controlle	r (1/2/3)	Pulse	2000/2000/270		
Pressure	High pressur Low pressur	re(63HS1)/ e(63LS)	MPa	2.78/0.90 [403/131]	2.78/0.90 [403/131]	
riessuie	BC controller on the liquid side(PS1)/ Intermediate part(PS3)		[psi]	2.70/2.70 [392/392]		
		Discharge (TH4)		87 [189]	87 [189]	
		Heat exchanger outlet (TH3)		41 [106]	41 [106]	
_	Outdoor	Accumulator inlet		8 [46]	8 [46]	
Temp. of each sec-	unit	Accumulator outlet	°C [°F]	8 [46]	8 [46]	
tion		Compressor inlet	ו רין	19 [66]	19 [66]	
		Compressor shell bottom		42 [108]	40 [104]	
	Indoor unit	LEV inlet		19	[66]	
	indoor unit	Heat exchanger inlet		6	[43]	

				Outdoor u	ınit model			
		Operation		PURY-P21	6TSJMU-A			
				PURY-P120TJMU-A	PURY-P96TJMU-A			
Model name	of BC controll	er		CMB-P10	13NU-GA			
	Ambient	Indoor		26.7°C/19.4°C	[80 °F/67 °F]			
	tempera- ture	Outdoor	DB/WB	35°C/-	[95 °F/-]			
		No. of connected units	Unit	6	5			
	Indoor unit	No. of units in operation	Offic	6	3			
Operating		Model	-	36/36/36	/36/36/36			
conditions		Main pipe		5	[16-3/8"]			
	Piping	Branch pipe	m [ft]	10	[32-3/4"]			
		Total pipe length	[]	65	65 [213-1/4"]			
	Fan speed		-	Hi				
	Amount of refrigerant		kg [lbs-oz]	43.0 [95]				
	Electric curre	ent	Α	51	.0			
Outdoor unit	Voltage		V	23	30			
	Compressor frequency		Hz	75 61				
LEV open-	Indoor unit		Pulse	275/275/275/275/275				
ing	BC controlle	r (1/2/3)	ruise	2000/2000/280				
Pressure	High pressure(63HS1)/ Low pressure(63LS)		MPa	2.82/0.92 2.78/0.92 [409/133] [403/133]				
riessuie	BC controller on the liquid side(PS1)/ Intermediate part(PS3)		[psi]	2.73/2.72 [395/394]				
		Discharge (TH4)		82 [180]	82 [180]			
		Heat exchanger outlet (TH3)		43 [109]	39 [102]			
Temp. of each section	Outdoor	Accumulator inlet		8 [46]	8 [46]			
	unit	Accumulator outlet	°C [°F]	8 [46]	8 [46]			
		Compressor inlet	[רן	20 [68]	19 [66]			
		Compressor shell bottom		42 [108]	40 [104]			
	Indon : :::2	LEV inlet		22	[72]			
	Indoor unit	Heat exchanger inlet		9	[48]			

				Outdoor u	ınit model	
		Operation		PURY-P24	0TSJMU-A	
				PURY-P120TJMU-A	PURY-P120TJMU-A	
Model name	of BC controll	er		CMB-P10	13NU-GA	
	Ambient	Indoor	DD 44/D	26.7°C/19.4°C [80 °F/67 °F]		
	tempera- ture	Outdoor	DB/WB	35°C/-	[95 °F/-]	
		No. of connected units	Unit	7	7	
	Indoor unit	No. of units in operation	Offic	7	7	
Operating		Model	-	24/36/36/3	6/36/36/36	
conditions		Main pipe		5	[16-3/8"]	
	Piping	Branch pipe	m [ft]	10	[32-3/4"]	
		Total pipe length		75	[229-5/8"]	
	Fan speed		-	Hi		
	Amount of refrigerant		kg [lbs-oz]	44.6 [98]		
	Electric curre	ent	Α	57	·.4	
Outdoor unit	Voltage		V	230		
	Compressor frequency		Hz	75	75	
LEV open-	Indoor unit		Pulse	200/275/275/275/275/275		
ing	BC controller	r (1/2/3)	i uise	2000/2000/290		
Pressure	High pressure(63HS1)/ Low pressure(63LS)		MPa	2.82/0.94 2.82/0.94 [409/136] [409/136]		
Fiessule	BC controller on the liquid side(PS1)/ Intermediate part(PS3)		[psi]	2.73/2.73 [395/395]		
		Discharge (TH4)		82 [180]	82 [180]	
		Heat exchanger outlet (TH3)		43 [109]	43 [109]	
	Outdoor unit	Accumulator inlet		10 [50]	10 [50]	
Temp. of each sec-	dill	Accumulator outlet	°C [°F]	10 [50]	10 [50]	
tion		Compressor inlet	ניו	22 [72]	22 [72]	
		Compressor shell bottom		44 [111]	44 [111]	
	Indoor unit	LEV inlet		22	[72]	
	maoor unit	Heat exchanger inlet		13	[55]	

				Outdoor unit model				
		Operation		PURY-P26	4TSJMU-A			
				PURY-P144TJMU-A	PURY-P120TJMU-A			
Model name	of BC controll	ler		CMB-P10	16NU-HA			
	Ambient	Indoor		26.7°C/19.4°C	[80 °F/67 °F]			
	tempera- ture	Outdoor	DB/WB	35°C/-	[95 °F/-]			
		No. of connected units	Unit	3	3			
	Indoor unit	No. of units in operation	Offic	}	3			
Operating		Model	-	24/24/36/36	/36/36/36			
conditions		Main pipe		5	[16-3/8"]			
	Piping	Branch pipe	m [ft]	10	[32-3/4"]			
		Total pipe length	[]	75 [229-5/8"]				
	Fan speed		-	Hi				
	Amount of refrigerant		kg [lbs-oz]	44.6 [98]				
	Electric curre	ent	Α	64	1.4			
Outdoor unit	Voltage		V	23	30			
	Compressor frequency		Hz	87	75			
LEV open-	Indoor unit		Pulse	200/200/275/275/275/275/275/275				
ing	BC controlle	r (1/2/3)	Pulse	2000/2000/290				
Pressure	High pressure(63HS1)/ Low pressure(63LS)		MPa	2.87/0.95 2.82/0.95 [416/138] [409/138]				
Pressure	BC controller on the liquid side(PS1)/ Intermediate part(PS3)		[psi]	2.75/2.75 [399/399]				
		Discharge (TH4)		82 [180]	82 [180]			
		Heat exchanger outlet (TH3)		43 [109]	43 [109]			
Temp. of each section	Outdoor	Accumulator inlet		10 [50]	10 [50]			
	unit	Accumulator outlet	°C [°F]	10 [50]	10 [50]			
		Compressor inlet	[ר]	22 [72]	22 [72]			
		Compressor shell bottom		44 [111]	44 [111]			
	Indoor unit	LEV inlet		22	[72]			
	muoor unit	Heat exchanger inlet		13	[55]			

				Outdoor u	ınit model	
		Operation		PURY-P28	8TSJMU-A	
				PURY-P144TJMU-A	PURY-P144TJMU-A	
Model name	of BC controll	er		CMB-P10	16NU-HA	
	Ambient	Indoor	DD 44/D	26.7°C/19.4°C	[80 °F/67 °F]	
	tempera- ture	Outdoor	DB/WB	35°C/-	[95 °F/-]	
		No. of connected units	Unit	3	3	
	Indoor unit	No. of units in operation	Offic	3	3	
Operating		Model	-	36/36/36/36/	/36/36/36	
conditions		Main pipe		5	[16-3/8"]	
	Piping	Branch pipe	m [ft]	10	[32-3/4"]	
		Total pipe length		75	[229-5/8"]	
	Fan speed		-	Hi		
	Amount of refrigerant		kg [lbs-oz]	46.6 [103]		
	Electric curre	ent	Α	71	.4	
Outdoor unit	Voltage		V	23	30	
	Compressor frequency		Hz	87 87		
LEV open-	Indoor unit		Pulse	275/275/275/275/275/275/275		
ing	BC controlle	r (1/2/3)	i uise	2000/2000/290		
Pressure	High pressure(63HS1)/ Low pressure(63LS)		MPa	2.87/0.96 2.87/0.96 [416/139] [416/139]		
Fiessule	BC controller on the liquid side(PS1)/ Intermediate part(PS3)		[psi]	2.80/2.80 [406/406]		
		Discharge (TH4)		83 [181]	83 [181]	
		Heat exchanger outlet (TH3)		44 [111]	44 [111]	
	Outdoor unit	Accumulator inlet		10 [50]	10 [50]	
Temp. of each sec-	unit	Accumulator outlet	°C [°F]	10 [50]	10 [50]	
tion		Compressor inlet	ניו	22 [72]	22 [72]	
		Compressor shell bottom		44 [111]	44 [111]	
	Indoor unit	LEV inlet		22	[72]	
	maoor unit	Heat exchanger inlet		13	[55]	

(2) Heating only operation

				Outdoor unit model				
		Operation	-	PURY-P16	8TSJMU-A			
			-	PURY-P96TJMU-A	PURY-P72TJMU-A			
Model name of BC controller				CMB-P1	08NU-GA			
	Ambient	Indoor	DD AAAD	21.1°C/-	[70 °F/-]			
	tempera- ture	Outdoor	DB/WB	8.3°C/6.1°C	[47°F/43°F]			
		No. of connected units	Unit	:	5			
	Indoor unit	No. of units in operation	Offic		5			
Operating		Model	-	30/30/3	36/36/36			
conditions		Main pipe		5	[16-3/18"]			
	Piping	Branch pipe	m [ft]	10	[32-3/4"]			
		Total pipe length	[3	55 [180-1/8"]				
	Fan speed		-	Hi				
	Amount of refrigerant		kg [lbs-oz]	38.5 [85]				
	Electric curre	ent	Α	42	2.5			
Outdoor unit	Voltage		V	2	30			
	Compressor frequency		Hz	74	52			
LEV open-	Indoor unit		Pulse	295/295/350/350/350				
ing	BC controlle	r (1/2/3)	Puise -	110/1	10/980			
Dwagaywa	High pressure(63HS1)/ Low pressure(63LS)		MPa	2.52/0.63 2.52/0.70 [365/91] [365/102]				
Pressure	BC controller on the liquid side(PS1)/ Intermediate part(PS3)		[psi]	2.46/2.20 [357/319]				
-		Discharge (TH4)		78 [172]	68 [154]			
		Heat exchanger outlet (TH6)		0 [32]	2 [36]			
Temp. of each section	Outdoor	Accumulator inlet		-2 [28]	1 [34]			
	uill	Accumulator outlet	°C [°F]	-3 [27]	1 [34]			
		Compressor inlet	[רן	-3 [27]	1 [34]			
		Compressor shell bottom		40 [104]	40 [104]			
	Janela an en 2	LEV inlet		34	[93]			
	Indoor unit	Heat exchanger inlet			[149]			

				Outdoor u	unit model	
		Operation		PURY-P19	2TSJMU-A	
				PURY-P96TJMU-A	PURY-P96TJMU-A	
Model name	of BC controll	er		CMB-P1	08NU-GA	
	Ambient	Indoor		21.1°C/-	[70 °F/-]	
	tempera- ture	Outdoor	DB/WB	8.3°C/6.1°C	[47°F/43°F]	
		No. of connected units	Linit	(6	
	Indoor unit	No. of units in operation	Unit	(6	
Operating		Model	-	30/30/30	/30/36/36	
conditions		Main pipe		5	[16-3/18"]	
	Piping	Branch pipe	m [ft]	10	[32-3/4"]	
		Total pipe length		65	[213-1/4"]	
	Fan speed		-	ŀ	-li	
	Amount of refrigerant		kg [lbs-oz]	42.4 [93]		
	Electric curre	ent	Α	49	9.7	
Outdoor unit	Voltage		V	23	30	
	Compressor frequency		Hz	74 74		
LEV open-	Indoor unit		Pulse	295/295/295/350/350		
ing	BC controller	(1/2/3)	i uise	110/110/1050		
Pressure	High pressure(63HS1)/ Low pressure(63LS)		MPa	2.52/0.63 2.52/0.63 [365/91]		
Flessule	BC controller on the liquid side(PS1)/ Intermediate part(PS3)		[psi]	2.48/2.27 [360/329]		
		Discharge (TH4)		78 [172]	78 [172]	
		Heat exchanger outlet (TH6)		0 [32]	0 [32]	
	Outdoor unit	Accumulator inlet		-2 [28]	-2 [28]	
Temp. of each sec-	uiiit	Accumulator outlet	°C [°F]	-3 [27]	-3 [27]	
tion		Compressor inlet	ניו	-3 [27]	-3 [27]	
		Compressor shell bottom		40 [104]	40 [104]	
	Indoor unit	LEV inlet		36	[97]	
	indoor driit	Heat exchanger inlet		68	[154]	

				Outdoor u	ınit model	
		Operation		PURY-P21	6TSJMU-A	
				PURY-P120TJMU-A	PURY-P96TJMU-A	
Model name	of BC controll	er		CMB-P10	13NU-GA	
	Ambient	Indoor		21.1°C/-	[70 °F/-]	
	tempera- ture	Outdoor	DB/WB	8.3°C/6.1°C	[47°F/43°F]	
		No. of connected units	Linit	(3	
	Indoor unit	No. of units in operation	Unit	(6	
Operating		Model	-	36/36/36	/36/36/36	
conditions		Main pipe		5	[16-3/18"]	
	Piping	Branch pipe	m [ft]	10	[32-3/4"]	
		Total pipe length	[]	65	[213-1/4"]	
	Fan speed		-	Hi		
	Amount of refrigerant		kg [lbs-oz]	43.0 [95]		
	Electric curre	ent	Α	56	3.7	
Outdoor unit	Voltage		V	23	30	
	Compressor frequency		Hz	86 74		
LEV open-	Indoor unit		Pulse	350/350/350/350/350		
ing	BC controller	(1/2/3)	i uise	110/110/1120		
Pressure	High pressure(63HS1)/ Low pressure(63LS)		MPa	2.54/0.64 2.54/0.63 [368/92] [368/91]		
Fiessule	BC controller on the liquid side(PS1)/ Intermediate part(PS3)		[psi]	2.50/2.17 [363/315]		
_		Discharge (TH4)		69 [154]	69 [154]	
		Heat exchanger outlet (TH6)		2 [36]	0 [32]	
_	Outdoor	Accumulator inlet		-1 [30]	-2 [28]	
Temp. of each sec-	unit	Accumulator outlet	°C [°F]	-1 [30]	-3 [27]	
tion		Compressor inlet	ניו	-1 [30]	-3 [27]	
		Compressor shell bottom		40 [104]	40 [104]	
	Indoor unit	LEV inlet		33	[91]	
	muoor unit	Heat exchanger inlet		68	[154]	

				Outdoor unit model				
		Operation		PURY-P24	0TSJMU-A			
				PURY-P120TJMU-A	PURY-P120TJMU-A			
Model name	of BC controll	er		CMB-P10	13NU-GA			
	Ambient	Indoor		21.1°C/-	[70 °F/-]			
	tempera- ture	Outdoor	DB/WB	8.3°C/6.1°C	[47°F/43°F]			
		No. of connected units	Unit	7	7			
	Indoor unit	No. of units in operation	Offic	-	7			
Operating		Model	-	24/36/36/3	6/36/36/36			
conditions		Main pipe		5	[16-3/18"]			
	Piping	Branch pipe	m [ft]	10	[32-3/4"]			
		Total pipe length	[-7]	75	[229-5/8"]			
	Fan speed		-	Hi				
	Amount of refrigerant		kg [lbs-oz]	44.6 [98]				
	Electric curre	ent	Α	63	3.3			
Outdoor unit	Voltage		V	23	30			
	Compressor frequency		Hz	86	86			
LEV open-	Indoor unit		Pulse	203/350/350/350/350/350				
ing	BC controller	(1/2/3)	i uise	110/110/1190				
Pressure	High pressure(63HS1)/ Low pressure(63LS)		MPa	2.57/0.64 2.57/0.64 [372/92] [372/92]				
Fiessule	BC controller on the liquid side(PS1)/ Intermediate part(PS3)		[psi]	2.54/2.22 [368/321]				
		Discharge (TH4)		73 [163]	73 [163]			
		Heat exchanger outlet (TH6)		2 [36]	2 [36]			
	Outdoor unit	Accumulator inlet		-1 [30]	-1 [30]			
Temp. of each sec-	unit	Accumulator outlet	°C [°F]	-1 [30]	-1 [30]			
tion		Compressor inlet	ניו	-1 [30]	-1 [30]			
		Compressor shell bottom		40 [104]	40 [104]			
	Indoor unit	LEV inlet		28	[82]			
	indoor driit	Heat exchanger inlet		67	[153]			

				Outdoor (unit model		
		Operation		PURY-P26	4TSJMU-A		
				PURY-P144TJMU-A	PURY-P120TJMU-A		
Model name	of BC controll	er		CMB-P10	16NU-HA		
	Ambient	Indoor		21.1°C/-	[70 °F/-]		
	tempera- ture	Outdoor	DB/WB	8.3°C/6.1°C	[47°F/43°F]		
		No. of connected units	Unit	}	3		
	Indoor unit	No. of units in operation	Offic	}	3		
Operating		Model	-	24/24/36/36	/36/36/36		
conditions		Main pipe		5	[16-3/18"]		
	Piping	Branch pipe	m [ft]	10	[32-3/4"]		
		Total pipe length	[.4]	75 [229-5/8"]			
	Fan speed		-	Hi			
	Amount of refrigerant		kg [lbs-oz]	44.6 [98]			
	Electric curre	ent	Α	69).5		
Outdoor unit	Voltage		V	23	30		
	Compressor frequency		Hz	104 86			
LEV open-	Indoor unit		Pulse	203/203/350/350/350/350/350			
ing	BC controlle	r (1/2/3)	Fuise	110/11	0/1190		
Pressure	High pressure(63HS1)/ Low pressure(63LS)		MPa	2.55/0.63 2.55/0.64 [370/91] [370/92]			
riessuie	BC controller on the liquid side(PS1)/ Intermediate part(PS3)		[psi]	2.52/2.20 [365/319]			
		Discharge (TH4)		73 [163]	73 [163]		
		Heat exchanger outlet (TH6)		2 [36]	2 [36]		
Temp. of each section	Outdoor	Accumulator inlet		-1 [30]	-1 [30]		
	unit	Accumulator outlet	°C [°F]	-1 [30]	-1 [30]		
		Compressor inlet	ן נין	-1 [30]	-1 [30]		
		Compressor shell bottom		40 [104]	40 [104]		
	Indoor unit	LEV inlet		28	[82]		
	indoor unit	Heat exchanger inlet		67	[153]		
	1	i .					

				Outdoor u	ınit model		
		Operation		PURY-P28	8TSJMU-A		
				PURY-P144TJMU-A	PURY-P144TJMU-A		
Model name	of BC controll	er		CMB-P10	16NU-HA		
	Ambient	Indoor		21.1°C/-	[70 °F/-]		
	tempera- ture	Outdoor	DB/WB	8.3°C/6.1°C	[47°F/43°F]		
		No. of connected units	Unit	3	3		
	Indoor unit	No. of units in operation	Unit	3	3		
Operating		Model	-	36/36/36/36/	/36/36/36		
conditions		Main pipe		5	[16-3/18"]		
	Piping	Branch pipe	m [ft]	10	[32-3/4"]		
		Total pipe length		75	[229-5/8"]		
	Fan speed		-	Hi			
	Amount of refrigerant		kg [lbs-oz]	46.6 [103]			
	Electric curre	ent	Α	75	5.8		
Outdoor unit	Voltage		V	23	30		
	Compressor frequency		Hz	104	104		
LEV open-	Indoor unit		Pulse	350/350/350/350/350/350/350/350			
ing	BC controller	r (1/2/3)	Fuise	110/110/1190			
Pressure	High pressure(63HS1)/ Low pressure(63LS)		MPa	2.52/0.63 2.52/0.63 [365/91] [365/91]			
Flessule	BC controller on the liquid side(PS1)/ Intermediate part(PS3)		[psi]		2.45/2.13 [355/309]		
		Discharge (TH4)		73 [163]	73 [163]		
		Heat exchanger outlet (TH6)		2 [36]	2 [36]		
	Outdoor	Accumulator inlet		-1 [30]	-1 [30]		
Temp. of each sec-	unit	Accumulator outlet	°C [°F]	-1 [30]	-1 [30]		
tion		Compressor inlet	ן רו	-1 [30]	-1 [30]		
		Compressor shell bottom		40 [104]	40 [104]		
	Indoor unit	LEV inlet		28	[82]		
	middol dilit	Heat exchanger inlet		67	[153]		

IX Troubleshooting

[1]	Error Code Lists	195
[2]	Responding to Error Display on the Remote Controller	199
[3]	Investigation of Transmission Wave Shape/Noise	285
[4]	Troubleshooting Principal Parts	288
[5]	Refrigerant Leak	333
[6]	Compressor Replacement Instructions	335
[7]	Servicing the BC controller	350
[8]	Troubleshooting Using the Outdoor Unit LED Error Display	353

[1] Error Code Lists

						Sea	ched	l unit		
Error Code	Prelimi- nary error code	Error (prelim- inary) detail code	Error c	Error code definition		Indoor unit	BC controller	LOSSNAY	Remote controller	Notes
0403	4300 4305	01 05 (Note)	Serial communication error	error/Panel communication	0	0				
1102	1202	-	Discharge temperatur	e fault	0					
1301	-	-	Low pressure fault		0					
1302	1402	-	High pressure fault		0					
1500	1600	-	Refrigerant overcharg	е	0					
-	1605	-	Preliminary suction pr	essure fault	0					
2500	-	-	Drain sensor submerg	gence		0				
2502	-	-	Drain pump fault			0	0			
2503	-	-	Drain sensor (Thd) fa	ult		0		0		
2600	-	-	Water leakage					0		
2601	-	-	Water supply cutoff					0		
3121	-	-	Out-of-range outside	air temperature	0					
4102	4152	-	Open phase	Open phase						
4106	-	-	Transmission power s	supply fault	0					
4109	-	-	Fan operation status	detection error		0				
4115	-	-	Power supply signal s	ync error	0					
4116	-	-	RPM error/Motor erro	r		0		0		
		[108]	Abnormal bus voltage	drop	0					
4220 4225	4320 4325	[109]	Abnormal bus voltage	rise	0					
(Note)	(Note)	[111]	Logic error		0					
		[131]	Low bus voltage at sta	artup	0					
4230	4330	-	Heatsink overheat pro	tection	0					
4240	4340	-	Overload protection		0					
		[101]	IPM error		0					
		[103]	DCCT overcurrent (H	W detection)	0					
4250 4255	4350 4355	[104]	Short-circuited IPM/G	round fault	0					
(Note)	(Note)	[105]	Overcurrent error due	Overcurrent error due to short-circuited motor						
		[106]	Instantaneous overcurrent (S/W detection)		0					
		[107]	Overcurrent (effective value)(S/W detection)		0					
4260	-	-	Heatsink overheat pro	tection at startup	0					
5101	1202	_	Temperature sensor	Return air temperature (TH21)		0				
3101	1202	-	fault	OA processing unit inlet temperature (TH4)				0		

						Sea	rched	l unit		
Error Code	Prelimi- nary error code	Error (prelim- inary) detail code	Error code definition		Outdoor unit	Indoor unit	BC controller	LOSSNAY	Remote controller	Notes
5102	1217	_	Temperature sensor	Indoor unit pipe tempera- ture (TH22)		0				
3102	1217		fault	OA processing unit pipe temperature (TH2)				0		
				Indoor unit gas-side pipe temperature (TH23)		0				
5103	1205	00	Temperature sensor fault	OA processing unit gasside pipe temperature (TH3)				0		
				Pipe temperature at heat exchanger outlet (TH3)	0					
				OA processing unit intake air temperature (TH1)				0		
5104	1202	-	Temperature sensor fault	Outside temperature (TH24)		0				Detectable only by the All- Fresh type in- door units
				Outdoor unit discharge temperature (TH4)	0					
5105	1204	-	Temperature sensor fault	Accumulator inlet temperature (TH5)	0					
5106	1216	-	Temperature sensor fault	Heat exchanger inlet tem- perature (TH6)	0					
5107	1221	-	Temperature sensor fault	Outside temperature (TH7)	0					
5110	1214	01	Temperature sensor fault	Heatsink temperature (THHS)	0					
5111	-	-		Liquid inlet temperature (TH11)			0			
5112	-	-	Temperature sensor fault	Bypass outlet temperature (TH12)			0			
5115	-	-	(BC controller)	LEV3 outlet temperature (TH15)			0			
5116	-	-		LEV3 inlet temperature (TH16)			0			
5201	-	-	High-pressure sensor	fault (63HS1)	0					
5201	1402	-	High-pressure sensor fault (Outdoor unit HPS/BC controller PS1)		0		0			
5203	-	-	Intermediate pressure sensor fault (BC controller PS3)				0			
		[115]	ACCT sensor fault		0					
		[116]	DCCT sensor fault		0					
5301	4300	[117]	ACCT sensor circuit fa	ault	0					
3301	7000	[118]	DCCT sensor circuit fa	ault	0					
		[119] [120]	Open-circuited IPM/Loose ACCT connector		0					
			Faulty ACCT wiring		0					

					Sea	rched	l unit		
Error Code	Prelimi- nary error code	Error (prelim- inary) detail code	Error code definition Ontdoor unit		Indoor unit	BC controller	LOSSNAY	Remote controller	Notes
5401	-	-	Temperature sensor fault		0				
5701	-	-	Loose float switch connector		0				
6201	-	-	Remote controller board fault (nonvolatile memory error)					0	
6202	-	-	Remote controller board fault (clock IC error)					0	
6600	-	-	Address overlaps	0	0	0	0	0	
6601	-	-	Polarity setting error					0	
6602	-	-	Transmission processor hardware error	0	0	0	0	0	
6603	-	-	Transmission line bus busy error	0	0	0	0	0	
6606	-	-	Communication error between device and transmission processors	0	0	0	0	0	
6607	-	-	No ACK error	0	0	0	0	0	
6608	-	-	No response error	0	0	0	0	0	
6831	-	-	MA controller signal reception error (No signal reception)		0			0	
6832	-	-	MA remote controller signal transmission error (Synchronization error)		0			0	
6833	-	-	MA remote controller signal transmission error (H/ W error)		0			0	
6834	-	-	MA controller signal reception error (Start bit detection error)		0			0	
7100	-	-	Total capacity error	0					
7101	-	-	Capacity code setting error	0	0		0		
7102	-	-	Wrong number of connected units	0		0			
7105	-	-	Address setting error	0					
7106	-	-	Attribute setting error				0		
7107	-	-	Port setting error			0			
7110	-	-	Connection information signal transmission/reception error	0					
7111	-	-	Remote controller sensor fault		0		0		
7113	-	-	Function setting error O						
7117	-	-	Model setting error	0					
7130	-	-	Incompatible unit combination	0					

Note

The last digit in the check error codes in the 4000's and 5000's and two-digit detail codes indicate if the codes apply to inverter on fan inverter.

Example

Code 4225 (detail code 108): Bus voltage drop in the fan inverter system

Code 4230 : Heatsink overheat protection in the inverter system

The last digit	Inverter system
0 or 1	Compressor inverter system
5	Fan inverter system

[2] Responding to Error Display on the Remote Controller

1. Error Code

0403

(TJMU-A)

Serial communication error

2. Error definition and error detection method

Serial communication error between the control board and the INV board on the compressor, and between the control board and the Fan board

Detail code 01: Between the control board and the INV board Detail code 05: Between the control board and the Fan board

3. Cause, check method and remedy

(1) Faulty wiring

Check the following wiring connections.

1) Between Control board and Fan board

Control board	FAN board
CN2	CN21
CN4	CN4
CN332	CN18V

2) Between Fan board and INV board

FAN board	INV board
CN22	CN2
	CN5V
CN4	CN4

(2) INV board failure, Fan board failure and Control board failure

Replace the INV board or the Fan board or control board when the power turns on automatically, even if the power source is reset.

1. Error code

0403

(TJMU-A) (Indoor unit)

Panel communication error

2. Error definition and detection method

This error is detected when indoor units cannot successfully receive the signals from the Auto filter cleaning unit for one minute.

3. Cause, check method and remedy

	Cause	Check method and remedy
(1)	Incorrect switch setting on the indoor unit circuit board	Check SW3-3 on the indoor unit circuit board Set SW3-3 to ON only when connecting an auto filter cleaning unit.
(2)	Power wire that connects the circuit board on the indoor unit and the circuit board on the cleaning unit is loose.	Check the LED1 (cleaning unit circuit board (microcomputer power)). Lit: Power is supplied properly. Unlit: Check for loose or disconnected power wire between the indoor unit circuit board (CNAC) and the cleaning unit circuit board (CN3A).
(3)	Communication wire that connects the circuit board on the indoor unit and the circuit board on the cleaning unit is loose.	Check the LED4 (cleaning unit circuit board (communication)). Blinking: Normal communication Unlit: Check for loose or disconnected communication wire between the indoor unit circuit board (CN3G) and the cleaning unit
(4)	Panel transceiver circuit fault (cleaning unit)	circuit board (CN3G). If the LED blinks at irregular intervals (normally blinks at 0.5-sec-
(5)	Panel transceiver circuit fault (indoor unit)	ond intervals), electrical interference is suspected. Check the items above, turn the power off, and turn the power
(6)	Electrical interference on the cleaning unit's communication cable	back on. If the error persists, replace either the cleaning unit circuit board or the indoor unit circuit board.

Note

Refer to section -7- "Inverter (TJMU-A)" under part [4] Troubleshooting Principal Parts for error codes related to the inverter.(page 310)

0403 (YJMU-A)

Serial communication error

2. Error definition and error detection method

Serial communication error between the control board and the INV board on the compressor, and between the control board and the Fan board

Detail code 01: Between the control board and the INV board

Detail code 05: Between the control board and the Fan board

3. Cause, check method and remedy

(1) Faulty wiring

Check the following wiring connections.

1) Between Control board and Fan board

Control board	FAN board
CN2	CN21
CN4	CN5
CN332	CN18V

2) Between Fan board and INV board

FAN board	INV board
CN22	CN2
CNZZ	CNZ
	CN5V
CN4	CN4

(2) INV board failure, Fan board failure and Control board failure

Replace the INV board or the Fan board or control board when the power turns on automatically, even if the power source is reset.

1. Error Code

0403

(YJMU-A) (Indoor unit)

Panel communication error

2. Error definition and error detection method

This error is detected when indoor units cannot successfully receive the signals from the Auto filter cleaning unit for one minute.

3. Cause, check method and remedy

	Cause	Check method and remedy
(1)	Incorrect switch setting on the indoor unit circuit board	Check SW3-3 on the indoor unit circuit board Set SW3-3 to ON only when connecting an auto filter cleaning unit.
(2)	Power wire that connects the circuit board on the indoor unit and the circuit board on the cleaning unit is loose.	Check the LED1 (cleaning unit circuit board (microcomputer power)). Lit: Power is supplied properly. Unlit: Check for loose or disconnected power wire between the indoor unit circuit board (CNAC) and the cleaning unit circuit board (CN3A).
(3)	Communication wire that connects the circuit board on the indoor unit and the circuit board on the cleaning unit is loose.	Check the LED4 (cleaning unit circuit board (communication)). Blinking: Normal communication Unlit: Check for loose or disconnected communication wire between the indoor unit circuit board (CN3G) and the cleaning unit
(4) (5) (6)	Panel transceiver circuit fault (cleaning unit) Panel transceiver circuit fault (indoor unit) Electrical interference on the cleaning unit's communication cable	circuit board (CN3G). If the LED blinks at irregular intervals (normally blinks at 0.5-second intervals), electrical interference is suspected. Check the items above, turn the power off, and turn the power back on. If the error persists, replace either the cleaning unit circuit board or the indoor unit circuit board.

Note

Refer to section -7- "Inverter (YJMU-A)" under part [4] Troubleshooting Principal Parts for error codes related to the inverter.(page 320)



Discharge temperature fault

2. Error definition and error detection method

- 1) If the discharge temperature of 120 °C [248°F] or more is detected during the above operation (the first detection), the outdoor unit stops once, turns to anti-restart mode for 3 minutes, and restarts after 3 minutes automatically.
- 2) If the discharge temperature of 120° C [248°F] or more is detected again (the second detection) within 30 minutes after the second stop of the outdoor unit described above, the mode will be changed to 3 minute restart mode, then the outdoor unit will restart in 3 minutes.
- 3) If the discharge temperature of 120°C [248°F] or more is detected (the third detection) within 30 minutes after the stop of the outdoor unit described above (regardless of the first or the second stop), the outdoor unit will make an error stop, and the error code "1102" will be displayed.
- 4) If the discharge temperature of 120°C [248°F] or more is detected more than 30 minutes after the previous stop of the outdoor unit, the detection is regarded as the first detection, and the operation described in step 1 above will start.
- 5) For 30 minutes after the stop (the first stop or the second stop) of the outdoor unit, preliminary errors will be displayed on the LED display.

	Cause	Check method and remedy
(1)	Gas leak, gas shortage	Refer to the page on refrigerant amount evaluation.(page 171)
(2)	Overload operation	Check operating conditions and operation status of indoor/outdoor units.
(3) (4) (5) (6) (7) (8)	LEV failure on the indoor unit BC controller LEV malfunction Cooling only: LEV3 Cooling main: LEV1,2,3 Heating only or heating main: LEV3 Defrost: LEV3 BC controller SVM1 and 2 malfunction -> Cooling only or defrost BC controller SVA malfunction -> Cooling only or cooling main BC controller SVB malfunction -> Heating only or heating main Solenoid valve SV malfunction (4a-4c (P72 model), 4a-4d (P96, P120, P144 models))	Perform a heating operation and check the operation. Cooling: LEV on the indoor unit LEV1,2,3 SVM1,2 SVA,C Heating: LEV on the indoor unit LEV3 SVB SVB SV4a - 4d Refer to the page on troubleshooting LEV.(page 297)
(9)	:heating only, heating main Port address setting error.	Confirm the port address of the indoor unit.
` ′		'
(10)	Closed ball valve	Confirm that the ball valve is fully open.
(11)	Outdoor fan (including fan parts) failure, motor failure, or fan controller malfunction Rise in discharge temp. by low pressure drawing for (3) - (11).	Check the fan on the outdoor unit. Refer to the section on troubleshooting the outdoor unit fan.(page 295)
(12)	Gas leak between low and high pressures (4-way valve failure, Compressor failure, Solenoid valve (SV1a) failure)	Perform a cooling or heating operation and check the operation.
(13)	Thermistor failure (TH4)	Check the thermistor resistor.(page 234)
(14)	Input circuit failure on the controller board thermistor	Check the inlet air temperature on the LED monitor.

1301

Low pressure fault

2. Error definition and error detection method

When starting the compressor from Stop Mode for the first time if low pressure reads 0.098MPa [14psi] immediately before start-up, the operation immediately stops.

	Cause	Check method and remedy
(1)	Inner pressure drop due to a leakage.	Refer to the section on troubleshooting the low pressure
(2)	Low pressure sensor failure	sensor.(page 289)
(3)	Short-circuited pressure sensor cable due to torn outer rubber	
(4)	A pin on the male connector is missing.	
(5)	Disconnected wire	
(6)	Failure of the low pressure input circuit on the controller board	



High pressure fault 1 (Outdoor unit)

2. Error definition and error detection method

- 1) If the pressure of 3.78MPa [548psi] or higher is detected by the pressure sensor during operation (the first detection), the outdoor stops once, turns to antirestart mode for 3 minutes, and restarts after 3 minutes automatically.
- 2) If the pressure of 3.78MPa [548psi] or higher is detected by the pressure sensor again (the second detection) within 30 minutes after the first stop of the outdoor unit, the outdoor unit stops once, turns to anti-restart mode for 3 minutes, and restarts after 3 minutes automatically.
- 3) If the pressure of 3.87MPa [561psi] or higher is detected by the pressure sensor (the third detection) within 30 minutes of the second stop of the outdoor unit, the outdoor unit will make an error stop, and the error code "1302" will be displayed.
- 4) If the pressure of 3.78MPa [548psi] or higher is detected more than 30 minutes after the stop of the outdoor unit, the detection is regarded as the first detection, and the operation described in step 1 above will start.
- 5) For 30 minutes after the stop of the outdoor unit, preliminary errors will be displayed on the LED display.
- 6) The outdoor unit makes an error stop immediately when not only the pressure sensor but also the pressure switch detects 4.15^{+0,-0.15} MPa [601^{+0,-22} psi]
- 7) Open phase due to unstable power supply voltage may cause the pressure switch to malfunction or cause the units to come to an abnormal stop.

	Cause	Check method and remedy
(1)	Indoor unit LEV actuation failure	Perform a heating operation and check the op-
(2)	BC controller LEV malfunction Heating only or heating main : Indoor LEV 3 Defrost : LEV3	eration. Cooling: LEV on the indoor unit LEV1,2,3 SVM1,1b,2,2b
(3)	BC controller SVM1 and 2 malfunction ->Cooling only or defrost	SVA Heating: LEV on the indoor unit
(4)	BC controller SVA and SVC malfunction ->Cooling only or cooling main	LEV3 SVM2,2b SVB.SV4a - 4d
(5)	BC controller SVB malfunction ->Heating only or heating main Solenoid valve SV malfunction(4a-4c (P72 model),4a-4d(P96, P120, P144 models)) ->Cooling only or cooling main	Refer to the page on troubleshooting for LEV and solenoid valve.(page 297)
(6)	Port address setting error.	Confirm the port address of the indoor unit.
(7)	Refrigerant service valve actuation failure	Confirm that the refrigerant service valve is fully
(8)	Short cycle on the indoor unit side	Check the indoor units for problems and correct
(9)	Clogged filter on the indoor unit	them, if any.
(10)	Reduced air flow due to dirty fan on the indoor unit fan	
(11)	Dirty heat exchanger of the indoor unit	
(12)	Indoor fan (including fan parts) failure or motor failure Items (7) through (12) above reduce the condensing capability of the unit, resulting in high-pressure rise during heating operation.	
(13)	Short cycle on the outdoor unit	Check the outdoor units for problems and cor-
(14)	Dirty heat exchanger of the outdoor unit	rect them, if any.
(15)	Outdoor fan (including fan parts) failure, motor failure, or fan controller malfunction Items (13) through (15) above reduce the condensing capability of the unit, resulting in high-pressure rise during cooling operation.	Check the fan on the outdoor unit. Refer to the section on troubleshooting the outdoor unit fan.(page 295)
(16)	Solenoid valve (SV1a) malfunction The by-pass valve (SV1a) can not control rise in high pressure.	Refer to the section on troubleshooting the sole- noid valve.(page 290)
(17)	Thermistor failure (TH3, TH7)	Check the thermistor resistor.(page 234)
(18)	Pressure sensor failure	Refer to the page on the troubleshooting of the high pressure sensor. (page 288)
(19)	Failure of the thermistor input circuit and pressure sensor input circuit on the controller board	Check the sensor temperature/pressure on the LED monitor.
(20)	Thermistor mounting problem (TH3, TH7)	Check the sensor temperature/pressure on the
(21)	Disconnected male connector on the pressure switch (63H1) or disconnected wire	LED monitor.
(22)	Voltage drop caused by unstable power supply voltage	Check the input voltage at the power supply terminal block (TB1).
(23)	Electromagnetic contactor (52F) actuation failure (P120, P144 only)	Check the wiring between the FAN board, 52F, and fan motor.



High pressure fault 2 (Outdoor unit)

2. Error definition and error detection method

If the pressure of 0.098MPa [14psi] or lower is registered on the pressure sensor immediately before start-up, it will trigger an abnormal stop, and error code "1302" will be displayed.

3. Cause, check method and remedy

Cause		Check method and remedy	
(1)	Inner pressure drop due to a leakage.	Refer to the page on the troubleshooting of the high	
(2)	Pressure sensor failure	pressure sensor.(page 288)	
(3)	Shorted-circuited pressure sensor cable due to torn outer rubber		
(4)	A pin on the male connector on the pressure sensor is missing or contact failure		
(5)	Disconnected pressure sensor cable		
(6)	Failure of the pressure sensor input circuit on the controller board		

1. Error Code



Refrigerant overcharge

2. Error definition and error detection method

An error can be detected by the discharge temperature superheat.

- If the formula "TdSH ≤ 10°C [18°F]" is satisfied during operation (first detection), the outdoor unit stops, goes into the 3-minute restart mode, and starts up in three minutes.
- 2) If the formula "TdSH ≤ 10°C [18°F]" is satisfied again within 30 minutes of the first stoppage of the outdoor unit (second detection), the unit comes to an abnormal stop, and the error code "1500" appears.
- 3) If the formula "TdSH ≤ 10°C [18°F]" is satisfied 30 minutes or more after the first stoppage of the outdoor unit, the same sequence as Item "1 above (first detection) is followed.
- 4) For 30 minutes after the stop of the outdoor unit, preliminary errors will be displayed on the LED display.

Cause		Check method and remedy	
(1)	Overcharged refrigerant	Refer to the page on refrigerant amount evaluation.(page 171)	
(2)	Thermistor input circuit failure on the control board	Check the temperature and pressure readings on the sensor that are displayed on the LED monitor.	
(3)	Faulty mounting of thermistor (TH4)	Check the temperature and pressure readings on the thermistor that are displayed on the LED monitor.	



Drain sensor submergence (Models with a drain sensor)

2. Error definition and error detection method

- 1) If an immersion of the drain sensor in the water is detected while the unit is in any mode other than the Cool/Dry mode and when the drain pump goes from OFF to ON, this condition is considered preliminary water leakage. While this error is being detected, humidifier output cannot be turned on.(Applicable to the units manufactured in or after October 1996)
- 2) If the immersion of the sensor in the water is detected four consecutive times at an hour interval, this is considered water leakage, and "2500" appears on the monitor.
- 3) Detection of water leakage is also performed while the unit is stopped.
- 4) Preliminary water leakage is cancelled when the following conditions are met:
 - *One hour after the preliminary water leakage was detected, it is not detected that the drain pump goes from OFF to ON.
 - *The operation mode is changed to Cool/Dry.
 - *Liquid pipe temperature inlet temperature ≤ -10°C[-18°F]

	Cause		Check method and remedy
(1)	Drain water drainage problem Clogged drain pump Clogged drain piping Backflow of drain water from other units		Check for proper drainage.
(2)	Adhesion of water drops to the drain sensor Trickling of water along the lead wire Rippling of drain water caused by filter clogging	1) 2)	Check for proper lead wire installation. Check for clogged filter.
(3)	Failure of the relay circuit for the solenoid valve		Replace the relay.
(4)	Indoor unit control board failure *Drain sensor circuit failure		If the above item checks out OK, replace the indoor unit control board.



Drain sensor submergence (Models with a float switch)

2. Error definition and error detection method


- 1) If an immersion of the float switch in the water is detected while the unit is in any mode other than the Cool/Dry mode and when the drain pump goes from OFF to ON, this condition is considered preliminary water leakage. While this error is being detected, humidifier output cannot be turned on.
- 2) If the drain pump turns on within one hour after preliminary water leakage is detected and the above-mentioned condition is detected two consecutive times, water leakage error water leakage is detected, and "2500" appears on the monitor.
- 3) Detection of water leakage is also performed while the unit is stopped.
- 4) Preliminary water leakage is cancelled when the following conditions are met:
 - *One hour after the preliminary water leakage was detected, it is not detected that the drain pump goes from OFF to ON.
 - *The operation mode is changed to Cool/Dry.
 - *Liquid pipe temperature inlet temperature ≤ 10°C[-18°F]

3. Cause, check method and remedy

	Cause	Check method and remedy
(1)	Drain water drainage problem *Clogged drain pump *Clogged drain piping *Backflow of drain water from other units	Check for proper drainage.
(2)	Stuck float switch Check for slime in the moving parts of the float switch.	Check for normal operation of the float switch.
(3)	Float switch failure	Check the resistance with the float switch turned on and turned off.

<Reference>

Drain pump operation triggered by a submergence of the liquid level sensor (except during the Cooing/Dry mode)





Drain pump fault (Models with a drain sensor)

2. Error definition and error detection method

- 1) Make the drain sensor thermistor self-heat. If the temperature rise is small, it is interpreted that the sensor is immersed in water. This condition is considered to be a preliminary error, and the unit goes into the 3-minute restart delay mode.
- If another episode of the above condition is detected during the preliminary error, this is considered a drain pump error, and "2502" appears on the monitor.
- 3) This error is always detected while the drain pump is in operation.
- 4) The following criteria are met when the criteria for the forced stoppage of outdoor unit (system stoppage) are met.
 - *"Liquid pipe temperature inlet temperature ≤ 10 °C [-18°F] " has been detected for 30 minutes.
 - *The immersion of drain sensor is detected 10 consecutive times.
 - *The conditions that are listed under items 1) through 3) above are always met before the criteria for the forced stoppage of the outdoor unit.
- 5) The indoor unit that detected the conditions that are listed in item 4) above brings the outdoor unit in the same refrigerant circuit to an error stop (compressor operation prohibited), and the outdoor unit brings all the indoor units in the same refrigerant circuit that are in any mode other than Fan or Stop to an error stop. "2502" appears on the monitor of the units that came to an error stop.
- 6) Forced stoppage of the outdoor unit
 - Detection timing: The error is detected whether the unit is in operation or stopped.
- 7) Ending criteria for the forced stoppage of outdoor unit
 - Power reset the indoor unit that was identified as the error source and the outdoor unit that is connected to the same refrigerant circuit.

Forced stoppage of the outdoor unit cannot be cancelled by stopping the unit via the remote controller.

(Note) Items 1) - 3) and 4) - 7) are detected independently from each other.

Note

The address and attribute that appear on the remote controller are those of the indoor unit (or OA processing unit) that caused the error.

	Cause		Check method and remedy
(1)	Drain pump failure		Check for proper functioning of the drain pump.
(2)	Drain water drainage problem Clogged drain pump Clogged drain piping		Check for proper drainage.
(3)	Adhesion of water drops to the drain sensor *Trickling of water along the lead wire *Rippling of drain water caused by filter clogging	1) 2)	Check for proper lead wire installation. Check for clogged filter.
(4)	Indoor unit control board failure *Drain pump drive circuit failure *Drain heater output circuit failure		If the above item checks out OK, replace the indoor unit control board.
(5)	Items (1) through (4) above and an indoor unit electronic valve closure failure (leaky valve) occurred simultaneously.		Check the solenoid valves on the indoor unit for leaks.



Drain pump fault (Models with a float switch)

2. Error definition and error detection method

- 1) The immersion of sensor tip in water is detected by the ON/OFF signal from the float switch.
 - *Submergence of the sensor
 - When it is detected that the float switch has been ON for 15 seconds, it is interpreted that the sensor tip is immersed in water.
 - *Sensor in the air
 - When it is detected that the float switch has been OFF for 15 seconds, it is interpreted that the sensor tip is not immersed in water.
- 2) If it is detected that the float switch has been ON for 3 minutes after the immersion of the sensor tip was detected, this is considered a drain pump failure, and "2502" appears on the monitor.
 - *The total time it takes for this error to be detected is 3 minutes and 15 seconds, including the time it takes for the first immersion of the sensor tip to be detected.
- 3) Detection of drain pump failure is performed while the unit is stopped.
- 4) The following criteria are met when the criteria for the forced stoppage of outdoor unit (system stoppage) are met.
 - *"Liquid pipe temperature inlet temperature ≤ 10°C [-18°F] " has been detected for 30 minutes.
 - *It is detected by the float switch that the sensor tip has been immersed in water for 15 minutes or more.
 - *The conditions that are listed under items 1) through 3) above are always met before the criteria for the forced stoppage of the outdoor unit.
- 5) The indoor unit that detected the conditions that are listed in item 4) above brings the outdoor unit in the same refrigerant circuit to an error stop (compressor operation prohibited), and the outdoor unit brings all the indoor units in the same refrigerant circuit that are in any mode other than Fan or Stop to an error stop.
- 6) Forced stoppage of the outdoor unit
 - Detection timing: The error is detected whether the unit is in operation or stopped.
 - This error is detected whether the unit is in operation or stopped.
- 7) Ending criteria for the forced stoppage of outdoor unit
 - Power reset the indoor unit that was identified as the error source and the outdoor unit that is connected to the same refrigerant circuit.
 - Forced stoppage of the outdoor unit cannot be cancelled by stopping the unit via the remote controller.
 - (Note) Items 1) 3) and 4) 7) are detected independently from each other.

Note

The address and attribute that appear on the remote controller are those of the indoor unit (or OA processing unit) that caused the error.

	Cause	Check method and remedy
(1)	Drain pump failure	Check for proper functioning of the drain pump mechanism
(2)	Drain water drainage problem Clogged drain pump Clogged drain piping	Check for proper drainage.
(3)	Stuck float switch Check for slime in the moving parts of the float switch.	Check for normal operation of the float switch.
(4)	Float switch failure	Check the resistance with the float switch turned on and turned off.
(5)	Indoor unit control board failure •Drain pump drive circuit failure •Float switch input circuit failure	Replace indoor unit control board.
(6)	Items (1) through (5) above and an indoor unit electronic valve closure failure (leaky valve) occurred simultaneously.	Check the solenoid valves on the indoor unit for leaks.



Drain sensor (Thd) fault

2. Error definition and error detection method

- •If the open or short circuit of the thermistor has been detected for 30 seconds, this condition is considered to be a preliminary error, and the unit goes into the 3-minute restart delay mode.
- •If another episode of the above condition is detected during the preliminary error, this is considered a drain sensor error.(If the short or open circuit of the thermistor is no longer detected, normal operation will be restored in 3 minutes.)
- •This error is detected when one of the following conditions are met.
 - *During Cool/Dry operation
 - *Liquid pipe temperature minus inlet temperature is equal to or smaller than 10°C[-18°F] (except during the defrost cycle)
 - *When the liquid temperature thermistor or suction temperature thermistor or short or open circuited.
 - *Drain pump is in operation.
 - *One hour has elapsed since the drain sensor went off.

Short: 90 °C [194 °F] or above Open: - 20 °C [-4 °F] or below

	Cause		Check method and remedy
(1)	Faulty connector (CN31) insertion.	1)	Check for connector connection failure. Reinsert the connector, restart the operation, and check for proper operation.
(2)	Broken or semi-broken thermistor wire	2)	Check for a broken thermistor wire.
(3)	Thermistor failure	3)	Check the resistance of the thermistor. $0^{\circ}\text{C}[32\ ^{\circ}\text{F}]\text{:}6.0\text{k}\Omega$ $10^{\circ}\text{C}[50\ ^{\circ}\text{F}]\text{:}3.9\text{k}\Omega$ $20^{\circ}\text{C}[68^{\circ}\text{F}]\text{:}2.6\text{k}\Omega$ $30^{\circ}\text{C}[86^{\circ}\text{F}]\text{:}1.8\text{k}\Omega$ $40^{\circ}\text{C}[104\ ^{\circ}\text{F}]\text{:}1.3\text{k}\Omega$
(4)	Indoor unit control board (error detection circuit) failure	4)	Replace the indoor unit control board if the problem recurs when the unit is operated with the No1 and No2 pins on the drain sensor connector (CN31) being short-circuited. If the above item checks out OK, there are no problems with the drain sensor. Turn off the power and turn it back on.



Water leakage

2. Cause, check method and remedy

Check that water does not leak from the pipes in such as the humidifier.

1. Error Code



Water supply cutoff

	Cause	Check method and remedy
(1)	The water tank of the humidifier is empty.	Check the amount of supply water. Check for the solenoid valve and for the connection.
(2)	The solenoid valve for humidification is OFF.	Check the connector.
(3)	Disconnected float switch	Check the connecting part.
(4)	Poor operation of float switch	Check for the float switch.
(5)	Frozen water tank	Turn off the power source of the water tank to defrost, and turn it on again.



Out-of-range outside air temperature

2. Error definition and error detection method

- •When the thermistor temperature of -28°C[-18°F] or below has continuously been detected for 3 minutes during heating operation (during compressor operation), the unit makes an error stop and "3121" appears on the display. (Use the OC thermistor temperature to determine when two outdoor units are in operation.)
- •The compressor restarts when the thermistor temperature is -26°C[-15°F] or above (both OC and OS) during error stop. (The error display needs to be canceled by setting the remote controller.)
- •Outdoor temperature error is canceled if the units stop during error stop. (The error display needs to be canceled by setting the remote controller.)

3. Cause, check method and remedy

Check the following factors if an error is detected, without drop in the outdoor temperature.

	Cause	Check method and remedy
(1)	Thermistor failure	Check thermistor resistance.
(2)	Pinched lead wire	Check for pinched lead wire.
(3)	Torn wire coating	Check for wire coating.
(4)	A pin on the male connector is missing or contact failure	Check connector.
(5)	Disconnected wire	Check for wire.
(6)	Thermistor input circuit failure on the control board	Check the intake temperature of the sensor with the LED monitor. When the temperature is far different from the actual temperature, replace the control board.

<Reference>

 $\begin{tabular}{ll} Short detection & Open detection \\ TH7 & 110 \ ^{\circ}C \ [230 \ ^{\circ}F \] \ and \ above \ (0.4 \ k \ \Omega) & -40 \ ^{\circ}C \ [-40 \ ^{\circ}F \] \ and \ below \ (130 \ k \ \Omega) \\ \end{tabular}$

4102

(TJMU-A)

Open phase

2. Error definition and error detection method

- •An open phase of the power supply (L1 phase, L2 phase) was detected at power on. •The L3 phase current is outside of the specified range.

Note

The open phase of the power supply may not always be detected if a power voltage from another circuit is applied.

	Cause	Check method and remedy
(1)	Power supply problem Open phase voltage of the power supply Power supply voltage drop	Check the input voltage to the power supply terminal block TB1.
(2)	Noise filter problem Coil problem Circuit board failure	Check the coil connections. Check for coil burnout. Confirm that the voltage at the CN02 connector is 188 V or above.
(3)	Wiring failure	Confirm that the voltage at the control board connector CNAC is 188 V or above. If the voltage is below 188V, check the wiring connection between the noise filter board CN02 and control board CNAC. P72 model Confirm that the wiring between TB23 and INV board SC-T is put through CT3. P96, P120, P144 models Confirm that the wiring between the coil L3 and TB23 is put through ACCT3.
(4)	Blown fuse	Check F01 on the control board, F4, and F5 for a blown fuse>If a blown fuse is found, check for a short-circuiting or earth fault of the actuator.
(5)	CT3/ACCT3 failure	P72 model Replace the inverter if this problem is detected after the compressor has gone into operation.
(6)	Control board failure	Replace the control board if none of the above is causing the problem.

(YJMU-A) 4102

Open phase

2. Error definition and error detection method

- •An open phase of the power supply (L1 phase, L2 phase) was detected at power on. •The L3 phase current is outside of the specified range.

Note

The open phase of the power supply may not always be detected if a power voltage from another circuit is applied.

	Cause	Check method and remedy
(1)	Power supply problem Open phase voltage of the power supply Power supply voltage drop	Check the input voltage to the power supply terminal block TB1.
(2)	Noise filter problem Coil problem Circuit board failure	 Check the coil connections. Check for coil burnout. Check that the voltage across TB21 and TB22 on the noise filter board is 414V or above.
(3)	Wiring failure	Confirm that the voltage at the control board connector CNAC is 190 V or above. If the voltage is below 190, check the wiring between noise filter CN6, noise filter CN2, transformer box, and control board CNAC. Confirm that the wiring between noise filter TB23 and INV board SC-L3 is put through CT3.
(4)	Blown fuse	Check F01 on the control board, F4, and F5 for a blown fuse>If a blown fuse is found, check for a short-circuiting or earth fault of the actuator.
(5)	CT3 failure	Replace the inverter if this problem is detected after the compressor has gone into operation.
(6)	Control board failure	Replace the control board if none of the above is causing the problem.

4106

<Transmission power supply fault Error detail code FF (Outdoor unit)>

2. Error definition and error detection method

Transmission power output failure

3. Cause

- 1) Wiring failure
- 2) Transmission power supply cannot output voltage because overcurrent was detected.
- 3) Voltage cannot be output due to transmission power supply problem.
- 4) Transmission voltage detection circuit failure

4. Check method and remedy

Check the items in IX [4] -8- (2) Troubleshooting transmission power circuit of outdoor unit on all outdoor units in the same refrigerant circuit.

<Transmission power supply fault other than error detail code FF (Outdoor unit)>

2. Error definition and error detection method

Transmission power reception failure

3. Cause

One of the outdoor units stopped supplying power, but no other outdoor units start supplying power.

4. Check method and remedy

Check the items in IX [4] -8- (2) Troubleshooting transmission power circuit of outdoor unit on all outdoor units in the same refrigerant circuit.



Indoor unit fan operation error

2. Error definition and error detection method

1) During operation, it has been continuously detected for 100 seconds that the auxiliary relay (X13) for fan fault detection is not excited.

	Cause	Check method and remedy
(1)	Auxiliary relay (X13) fault	Coil failure, disconnected coil
(2)	Connector (CN28) is disconnected.	Check the connector for proper connection.
(3)	Blown fuse	Check the fuse on the control circuit board.
(4)	Motor error (thermistor error inside the motor)	Check the unit fan for proper operation in the test run mode. If no problems are found with items 1 through 3 above and the fan does not operate, replace the motor.

4115 (TJMU-A)

Power supply signal sync error


2. Error definition and error detection method

The frequency cannot be determined when the power is switched on.

3. Cause, check method and remedy

	Cause	Check method and remedy
(1)	Power supply error	Check the voltage of the power supply terminal block (TB1).
(2)	Noise filter problem Coil problem Circuit board failure	Check the coil connections. Check for coil burnout. Confirm that the voltage at the CN02 connector is 188 V or above.
(3)	Faulty wiring	Check fuse F01 on the control board.
(4)	Wiring failure Between noise filter board CN02 and control board CNAC	Confirm that the voltage at the control board connector CNAC is 188 V or above.
(5)	Control board failure	If none of the items described above is applicable, and if the trouble reappears even after the power is switched on again, replace the control board.

1. Error Code



Power supply signal sync error

2. Error definition and error detection method

The frequency cannot be determined when the power is switched on.

	Cause	Check method and remedy
(1)	Power supply error	Check the voltage of the power supply terminal block (TB1).
(2)	Noise filter problem •Coil problem •Circuit board failure	Check the coil connections. Check for coil burnout. Check that the voltage across TB21 and TB22 on the noise filter board is 414V or above.
(3)	Faulty wiring	Check F01 on the control board, F4, and F5 for a blown fuse.
(4)	Wiring failure Between noise filter CN3, noise filter CN2, transformer box, and control board CNAC	Confirm that the voltage at the control board connector CNAC is 190 V or above.
(5)	Control board failure	If none of the items described above is applicable, and if the trouble reappears even after the power is switched on again, replace the control board.



RPM error/Motor error

2. Error definition and error detection method

- *LOSSNAY
 - *The motor keep running even if the power is OFF.
 - *The thermal overload relay is ON. (Only for the three-phase model)
- Indoor unit

If detected less than 180rpm or more than 2000rpm, the indoor unit will restart and keep running for 3 minutes. If detected again, the display will appear.

	Cause	Check method and remedy
(1)	Board failure	Replace the board.
(2)	Motor malfunction	Check for the motor and the solenoid switch.
(3)	Solenoid switch malfunction	

4220 4225

(TJMU-A)

Abnormal bus voltage drop (Detail code 108)

2. Error definition and error detection method

If Vdc 160V or less is detected during Inverter operation. (S/W detection)

3. Cause, check method and remedy

(1) Power supply environment

Find out if there was a (momentary) power failure.

Check whether the power voltage is 188V or less across all phases.

(2) Voltage drop detected

4220

P72 model

- •Check the voltage between the tab terminal TB-P and TB-N on the INV board while the inverter is stopped. -> Check the following items if it is 253V or above.
 - 1) Confirm on the LED monitor that the bus voltage is above 160 V.

Replace the INV board if it is below 160 V.

- 2) Check the voltage at CN505 on the control board. ->Go to (3).
- 3) Check the coil connections (L1 L3) and for coil burnout.
- 4) Check the wiring connections between the following sections

Between the noise filter board and INV board. Between the INV board and DCL. Between the INV board and C1. Replace 72C if no problems are found.-> Check the following items if the voltage is below 253V.

- 1) Check the coil connections (L1 L3) and for coil burnout.
- 2) Check the wiring between the noise filter board and INV board.
- 3) Check the connection to SC-P1 and SC-P2 on the INV board.
- 4) Check the in-rush current resistor value. Replace the INV board if no problems are found.

P96, P120, P144 models

- *Check the voltage between SC-P1 and IPM N terminals on the INV board while the inverter is stopped.
- -> Check the following items if it is 253V or above.
 - 1) Confirm on the LED monitor that the bus voltage is above 160 V.

Replace the INV board if it is below 160 V.

- 2) Check the voltage at CN505 on the control board. ->Go to (3).
- 3) Check the coil connections (L1 L3) and coil burnout.
- 4) Check the resistance of the diode stack. ->Refer to IX [4] -7- (6).(page 318)
- 5) Check the wiring connections between the following sections:

Between the noise filter board and INV board. Between the INV board and C1.

Replace the noise filter board if no problems are found.

- -> Check the following items if the voltage is below 253 V.
- 1) Check the connection to SC-P1 and IPM N on the INV board.
- 2) Check the wiring between the noise filter board and INV board.
- 3) Check the resistance of the diode stack. ->Refer to IX [4] -7- (6).(page 318)
- 4) Check the in-rush current resistor value. ->Refer to IX [4] -7- (4).(page 316)
- 5) Replace the noise filter board.

4225

- •Check the voltage at CNVDC on the Fan board while the inverter is stopped.
- -> Check the following items if it is 253 V or above.
 - 1) Check the voltage at CN505 on the control board. ->Go to 3).
 - 2) Check the coil connections (L1 L3) and for coil burnout.
 - 3) Check the wiring connections.

Replace 72C if no problems are found.

(P96, P120, P144 models: Replace the noise filter board.)

If the problem recurs after replacing 72C, replace the Fan board.

- -> Check the following items if the voltage is below 253V.
- 1) Check the CNVDC connector connection.

(3) Control board failure

Confirm that a voltage of 208-230 VAC is applied to the connector CN505 on the control board during inverter operation. ->If voltage is absent, check the control board, fuse F01, or (F1, F2). If no problems are found, replace the control board.

Note |

Refer to section -7- "Inverter (TJMU-A)" under part [4] Troubleshooting Principal Parts for error codes related to the inverter.(page 310)

4220 4225

(YJMU-A)

Abnormal bus voltage drop (Detail code 108)

2. Error definition and error detection method

If Vdc 289V or less is detected during Inverter operation. (S/W detection)

3. Cause, check method and remedy

(1) Power supply environment

Find out if there was a (momentary) power failure.

Check whether the power voltage (Between L1 and L2, L2 and L3, and L1 and L3) is 414V or less across all phases.

(2) Voltage drop detected

4220

- •Check the voltage between the FT-P and FT-N terminals on the INV board while the inverter is stopped and if it is 420 V or above, check the following items.
 - 1) Confirm on the LED monitor that the bus voltage is above 289V.

Replace the INV board if it is below 289 V.

- 2) Check the voltage at CN72 on the control board. ->Go to (3).
- 3) Check the noise filter coil connections and for coil burnout.
- 4) Check the wiring connections between the following sections

Between the noise filter board and INV board. Between the INV board and DCL. Replace 72C if no problems are found.

- 5) Check the IGBT module resistance on the INV board (Refer to the Trouble shooting for IGBT module).
- •Check the voltage between the FT-P and FT-N terminals on the INV board while the inverter is stopped and if it is less than 420 V, check the following items.
 - 1) Check the coil connections and for coil burnout on the noise filter.
 - 2) Check the wiring between the noise filter board and INV board.
 - 3) Check the connection to SCP1 and SC-P2 on the INV board.
 - 4) Check the in-rush current resistor value.
 - 5) Check the 72C resistance value.
 - 6) Check the DCL resistance value.

Replace the INV board if no problems are found.

4225

- •Check the voltage at CNVDC on the Fan board while the inverter is stopped and if it is 420 V or above, check the following items.
 - 1) Check the voltage at CN72 on the control board. ->Go to 3).
 - 2) Check the noise filter coil connections and for coil burnout.
 - 3) Check the wiring connections between the following sections

Between the INV board and the Fan board.

4) Check contents 4220

Replace the Fan board if no problems are found.

- Check the voltage at CNVDC on the Fan board while the inverter is stopped and if it is less than 420 V, check the following items.
 - 1) Check the state of the wiring connections between the INV board and the Fan board.
 - 2) Check contents 4220

Replace the Fan board if no problems are found.

(3) Control board failure

Check that 12VDC is applied to connector CN72 on the control board while the inverter is operating. If voltage is absent or the wrong voltage is applied, check the fuse F01. Replace the control board if no problems are found with the fuse.

Note

Refer to section -7- "Inverter (YJMU-A)" under part [4] Troubleshooting Principal Parts for error codes related to the inverter.(page 320)

4220 4225 (T.

(TJMU-A)

Abnormal bus voltage rise (Detail code 109)

2. Error definition and error detection method

If Vdc ≥ 400V is detected during inverter operation.

3. Cause, check method and remedy

(1) Different voltage connection

Check the power supply voltage on the power supply terminal block (TB1).

(2) INV board failure

If the problem recurs, replace the INV board.

In the case of 4220: INV board In the case of 4225: Fan board

Note

Refer to section -7- "Inverter (TJMU-A)" under part [4] Troubleshooting Principal Parts for error codes related to the inverter.(page 310)

1. Error Code



(YJMU-A)

Abnormal bus voltage rise (Detail code 109)

2. Error definition and error detection method

If Vdc ≥ 830V is detected during inverter operation.

3. Cause, check method and remedy

(1) Different voltage connection

Check the power supply voltage on the power supply terminal block (TB1).

(2) INV board failure

If the problem recurs, replace the INV board.

In the case of 4220: INV board In the case of 4225: Fan board

Note

Refer to section -7- "Inverter (YJMU-A)" under part [4] Troubleshooting Principal Parts for error codes related to the inverter.(page 320)

4220 4225 (TJMU-A) (P96, P120, P144 models only)

VDC error (Detail code 110)

2. Error definition and error detection method

Bus voltage abnormality If Vdc ≥ 400V or Vdc ≤ 160V is detected. (H/W detection)

3. Cause, check method and remedy

Same as detail code No.108 and 109 of 4220 error

Note

Refer to section -7- "Inverter (TJMU-A)" under part [4] Troubleshooting Principal Parts for error codes related to the inverter (page 310)

4220 4225

(TJMU-A)

Logic error (Detail code 111)

2. Error definition and error detection method

H/W error

If only the H/W error logic circuit operates, and no identifiable error is detected.

3. Cause, Check method and remedy

In the case of 4220

	Cause	Check method and remedy
(1)	External noise	
(2)	INV board failure	Refer to IX [4] -7- (2) [1].(page 312)
(3)	IPM failure (P96, P120, P144 models only)	Replace the IPM.
(4)	DCCT failure (P96, P120, P144 models only)	Replace the DCCT.

In the case of 4225

	Cause	Check method and remedy
(1)	External noise	
(2)	Fan board failure	Refer to IX [4] -7- (2) [6].(page 314)

Note

Refer to section -7- "Inverter (TJMU-A)" under part [4] Troubleshooting Principal Parts for error codes related to the inverter.(page 310)

4220 4225

(YJMU-A)

Logic error (Detail code 111)

2. Error definition and error detection method

H/W erro

If only the H/W error logic circuit operates, and no identifiable error is detected.

3. Cause, Check method and remedy

In the case of 4220

Cause		Check method and remedy
(1)	External noise	
(2)	INV board failure	Refer to IX [4] -7- (2) [1].(page 322)

In the case of 4225

	Cause	Check method and remedy
(1)	External noise	
(2)	Fan board failure	Refer to IX [4] -7- (2) [6].(page 323)

Note

Refer to section -7- "Inverter (YJMU-A)" under part [4] Troubleshooting Principal Parts for error codes related to the inverter.(page 320)

1. Error Code

4220 4225

Low bus voltage at startup (Detail code 131)

2. Error definition and error detection method

When Vdc ≤160 V is detected just before the inverter operation.

3. Cause, check method and remedy

(1) Inverter main circuit failure

Same as detail code 108 of 4220 error

Note

Refer to section -7- "Inverter" under part [4] Troubleshooting Principal Parts for error codes related to the inverter.

4230 (TJMU-A)

Heatsink overheat protection

2. Error definition and error detection method

When the heat sink temperature (THHS) remains at or above TOH is detected.

Model	ТОН
P72 model	100°C [212°F]
P96, P120, P144 models	90°C [194°F]

3. Cause, check method and remedy

	Cause		Check method and remedy
(1)	Fan board failure		Refer to IX [4] -7- (2) [6].(page 314)
(2)	Outdoor unit fan failure		Check the outdoor unit fan operation. If any problem is found with the fan operation, check the fan motor>Refer to IX [4] -7- (2) [5].(page 314)
(3)	Air passage blockage		Check that the heat sink cooling air passage is not blocked
(4)	THHS failure		P72 model
		1)	Check for proper installation of the INV board IGBT. (Check for proper installation of the IGBT heatsink.)
		2)	Check for proper installation of the INV board IGBT>If an abnormal value appears, replace the INV board.
			P96, P120, P144 models
		3)	Check the THHS sensor reading on the LED monitor>If an abnormal value appears, check the sensor resistance, and replace the sensor as necessary.

Note

Refer to section -7- "Inverter (TJMU-A)" under part [4] Troubleshooting Principal Parts for error codes related to the inverter (page 310)

4230 (YJMU-A)

Heatsink overheat protection

2. Error definition and error detection method

When the heat sink temperature (THHS) remains at or above 100°C [212°F] is detected.

3. Cause, check method and remedy

	Cause		Check method and remedy
(1)	Fan board failure		Refer to IX [4] -7- (2) [6].(page 323)
(2)	Outdoor unit fan failure		Check the outdoor unit fan operation. If any problem is found with the fan operation, check the fan motor>Refer to IX [4] -7- (2) [5].(page 323)
(3)	Air passage blockage		Check that the heat sink cooling air passage is not blocked
(4)	THHS failure	1)	Check for proper installation of the INV board IGBT. (Check for proper installation of the IGBT heatsink.)
		2)	Check the THHS sensor reading on the LED monitor>If an abnormal value appears, replace the INV board.

Note

Refer to section -7- "Inverter (YJMU-A)" under part [4] Troubleshooting Principal Parts for error codes related to the inverter.(page 320)

4240 (TJMU-A)

Overload protection

2. Error definition and error detection method

If the output current of "(lac) >Imax (Arms)" or "THHS > TOL" is continuously detected for 10 minutes or more during inverter operation.

Model	Imax(Arms)
P72 model	35
P96, P120, P144 models	50

Model	TOL
P72 model	95°C [203°F]
P96, P120, P144 models	80°C [175°F]

3. Cause, check method and remedy

	Cause	Check method and remedy
(1)	Air passage blockage	Check that the heat sink cooling air passage is not blocked
(2)	Power supply environment	Power supply voltage is 188 V or above.
(3)	Inverter failure	Refer to IX [4] -7(page 310)
(4)	Current sensor (ACCT) failure	Refer to IX [4] -7- (4).
(5)	Compressor failure	Check that the compressor has not overheated during operation> Check the refrigerant circuit (oil return section). Refer to IX [4] -7- (2) [2].(page 312)

Note

Refer to section -7- "Inverter (TJMU-A)" under part [4] Troubleshooting Principal Parts for error codes related to the inverter.(page 310)

4240 (YJMU-A)

Overload protection

2. Error definition and error detection method

If the output current of "(lac) >Imax (Arms)" or "THHS > 95°C [203°F]" is continuously detected for 10 minutes or more during inverter operation.

Model	Imax(Arms)
P72 model	19
P96, P120, P144 models	27

3. Cause, check method and remedy

	Cause	Check method and remedy
(1)	Air passage blockage	Check that the heat sink cooling air passage is not blocked
(2)	Power supply environment	Power supply voltage is 414 V or above.
(3)	Inverter failure	Refer to IX [4] -7(page 320)
(4)	Compressor failure	Check that the compressor has not overheated during operation> Check the refrigerant circuit (oil return section). Refer to IX [4] -7- (2) [2].(page 322)

Note

Refer to section -7- "Inverter (YJMU-A)" under part [4] Troubleshooting Principal Parts for error codes related to the inverter.(page 320)

4250 4255

(TJMU-A)

IPM error (Detail code 101)

2. Error definition and error detection method

In the case of 4250

P72 model

Overcurrent is detected by the overcurrent detection resistor (RSH) on the INVboard.

P96, P120, P144 models

IPM error signal is detected.

In the case of 4255

IPM error signal is detected.

3. Cause, check method and remedy

In the case of 4250

P72 model

	Cause	Check method and remedy
(1)	Inverter output related	Refer to IX [4] -7- (2) [1] - [4].(page 312)

P96, P120, P144 models

	Cause	Check method and remedy
(1)	Inverter output related	Refer to IX [4] -7- (2) [1] - [4].(page 312)
(2)	Same as 4230 error	Same as 4230 error

In the case of 4255

	Cause	Check method and remedy
(1)	Fan motor abnormality	Refer to IX [4] -7- (2) [5].(page 314)
(2)	Fan board failure	Refer to IX [4] -7- (2) [6].(page 314)
(3)	Electromagnetic contactor (52F) actuation failure (P120, P144 only)	Check the wiring between the FAN board, 52F, and fan motor. (page 295)

Note

Refer to section -7- "Inverter (TJMU-A)" under part [4] Troubleshooting Principal Parts for error codes related to the inverter (page 310)

4250 4255 (YJMU-A)

IPM error (Detail code 101)

2. Error definition and error detection method

In the case of 4250

Overcurrent is detected by the overcurrent detection resistor (RSH) on the INV board.

In the case of 4255

IPM error signal is detected.

3. Cause, check method and remedy

In the case of 4250

	Cause	Check method and remedy
(1)	Inverter output related	Refer to IX [4] -7- (2) [1] - [4].(page 322)
		Check the IGBT module resistance value of the INV board, if no problems are found. (Refer to the Trouble shooting for IGBT module)

In the case of 4255

	Cause	Check method and remedy
(1)	Fan motor abnormality	Refer to IX [4] -7- (2) [5].(page 323)
(2)	Fan board failure	Refer to IX [4] -7- (2) [6].(page 323)
(3)	Electromagnetic contactor (52F) actuation failure (P120, P144 only)	Check the wiring between the FAN board, 52F, and fan motor. (page 295)

Note

Refer to section -7- "Inverter (YJMU-A)" under part [4] Troubleshooting Principal Parts for error codes related to the inverter (page 320)



DCCT overcurrent (H/W detection) (Detail code 103) Instantaneous overcurrent (Detail code 106) Overcurrent (effective value) (Detail code 107)

2. Error definition and error detection method

P72 model

Overcurrent 88 Apeak or 42 Arms and above is detected by the current sensor.

P96, P120, P144 models

Overcurrent 128 Apeak or 60 Arms and above is detected by the current sensor.

3. Cause, check method and remedy

	Cause	Check method and remedy
(*	Inverter output related	Refer to IX [4] -7- (2) [1] - [4].(page 312)

Note

Refer to section -7- "Inverter (TJMU-A)" under part [4] Troubleshooting Principal Parts for error codes related to the inverter (page 310)

4250

(YJMU-A)

Instantaneous overcurrent (Detail code 106) Overcurrent (effective value) (Detail code 107)

2. Error definition and error detection method

P72 model

Overcurrent 94 Apeak or 22 Arms and above is detected by the current sensor.

P96, P120, P144 models

Overcurrent 94 Apeak or 35 Arms and above is detected by the current sensor.

3. Cause, check method and remedy

	Cause	Check method and remedy
(1)	Inverter output related	Refer to IX [4] -7- (2) [1] - [4].(page 322)
		Check the IGBT module resistance value of the INV board, if no problems are found. (Refer to the Trouble shooting for IGBT module)

Note

Refer to section -7- "Inverter (YJMU-A)" under part [4] Troubleshooting Principal Parts for error codes related to the inverter.(page 320)

1. Error Code

4250 4255

Short-circuited IPM/Ground fault (Detail code 104)

2. Error definition and error detection method

When IPM/IGBT short damage or grounding on the load side is detected just before starting the inverter.

3. Cause, check method and remedy

In the case of 4250

	Cause	Check method and remedy
(1)	Grounding fault compressor	Refer to IX [4] -7- (2) [2].
(2)	Inverter output related	Refer to IX [4] -7- (2) [1] - [4].

In the case of 4255

	Cause	Check method and remedy
(1)	Grounding fault of fan motor	Refer to IX [4] -7- (2) [5].
(2)	Fan board failure	Refer to IX [4] -7- (2) [6].
(3)	Electromagnetic contactor (52F) actuation failure (P120, P144 only)	Check the wiring between the FAN board, 52F, and fan motor.

Note

Refer to section -7- "Inverter" under part [4] Troubleshooting Principal Parts for error codes related to the inverter.

4250 4255

Overcurrent error due to short-circuited motor (Detail code 105)

2. Error definition and error detection method

When a short is detected on the load side just before starting the inverter operation.

3. Cause, Check method and remedy

In the case of 4250

	Cause	Check method and remedy
(1)	Short - circuited compressor	Refer to IX [4] -7- (2) [2].
(2)	Output wiring	Check for a short circuit.

In the case of 4255

	Cause	Check method and remedy
(1)	Short - circuited fan motor	Refer to IX [4] -7- (2) [5].
(2)	Output wiring	Check for a short circuit.
(3)	Electromagnetic contactor (52F) actuation failure (P120, P144 only)	Check the wiring between the FAN board, 52F, and fan motor.

Note

Refer to section -7- "Inverter" under part [4] Troubleshooting Principal Parts for error codes related to the inverter.

1. Error Code



(TJMU-A)

Heatsink overheat protection at startup

2. Error definition and error detection method

The heatsink temperature (THHS) remains at or above TOH for 10 minutes or more at inverter startup.

Model	ТОН
P72 model	100°C [212°F]
P96, P120, P144 models	90°C [194°F]

3. Cause, check method and remedy

Same as 4230 error

1. Error Code



(YJMU-A)

Heatsink overheat protection at startup

2. Error definition and error detection method

The heatsink temperature (THHS) remains at or above 100°C [212°F] for 10 minutes or more at inverter startup.

3. Cause, check method and remedy

Same as 4230 error

5101

Return air temperature sensor (TH21) fault (Indoor unit) Return air temperature sensor (TH4) fault (OA processing unit)

5102

Pipe temperature sensor (TH22) fault (Indoor unit) Pipe temperature sensor (TH2) fault (OA processing unit)

5103

Gas-side pipe temperature sensor (TH23) fault (Indoor unit) Gas-side pipe temperature sensor (TH3) fault (OA processing unit)

5104

Intake air temperature sensor (TH1) fault (OA processing unit) Intake air temperature sensor (TH24) fault (All-fresh (100% outdoor air) type indoor unit)

2. Error definition and error detection method

•If a short or an open is detected during thermostat ON, the outdoor unit turns to anti-restart mode for 3 minutes. When the error is not restored after 3 minutes (if restored, the outdoor unit runs normally), the outdoor unit makes an error stop.

Short: detectable at 90°C [194°F] or higher

Open: detectable at -40°C [-40°F] or lower

- •Sensor error at gas-side cannot be detected under the following conditions.
 - *During heating operation
 - *During cooling operation for 3 minutes after the compressor turns on.

	Cause	Check method and remedy
(1)	Thermistor failure	Check the thermistor resistor.
(2)	Connector contact failure	0°C [32°F]: 15 kohm 10°C [50°F]: 9.7 kohm
(3)	Disconnected wire or partial disconnected thermistor wire	20°C [68°F] : 6.4 kohm 30°C [86°F] : 4.3 kohm 40°C [104°F] : 3.1 kohm
(4)	Unattached thermistor or contact failure	
(5)	Indoor board (detection circuit) failure	Check the connector contact. When no fault is found, the indoor board is a failure.

5103

Heat exchanger outlet temperature sensor (TH3) fault (Outdoor unit)

5104

Discharge temperature sensor (TH4) fault (Outdoor unit)

5105

Accumulator inlet temperature sensor (TH5) fault (Outdoor unit)

5106

Heat exchanger inlet temperature sensor (TH6) fault (Outdoor unit)

5107

Outside temperature sensor (TH7) fault (Outdoor unit)

2. Error definition and error detection method

- •When a short (high temperature intake) or an open (low temperature intake) of the thermistor is detected (the first detection), the outdoor unit stops, turns to anti-restart mode for 3 minutes, and restarts when the detected temperature of the thermistor.
- •When a short or an open is detected again (the second detection) after the first restart of the outdoor unit, the outdoor unit stops, turns to anti-restart mode for 3 minutes, and restarts in 3 minutes when the detected temperature is within the normal range.
- •When a short or an open is detected again (the third detection) after the previous restart of the outdoor unit, the outdoor unit makes an error stop.
- •When a short or an open of the thermistor is detected just before the restart of the outdoor unit, the outdoor unit makes an error stop, and the error code "5102", "5103", 5104", "5105", "5106"or "5107" will appear.
- During 3-minute antirestart mode, preliminary errors will be displayed on the LED display.
- •A short or an open described above is not detected for 10 minutes after the compressor start, during defrost mode, or for 3 minutes after defrost mode.

3. Cause, check method and remedy

	Cause	Check method and remedy
(1)	Thermistor failure	Check thermistor resistance.
(2)	Pinched lead wire	Check for pinched lead wire.
(3)	Torn wire coating	Check for wire coating.
(4)	A pin on the male connector is missing or contact failure	Check connector.
(5)	Disconnected wire	Check for wire.
(6)	Thermistor input circuit failure on the control board	Check the intake temperature of the sensor with the LED monitor. When the temperature is far different from the actual temperature, replace the control board.

<Reference>

Short detection		Open detection
гнз	110 °C [230 °E] and above (0.4 k o and helew)	-40 °C (-40° E) and below (130 k c

TH3	110 C [230 F] and above (0.4 K Ω and below)	-40 C[-40 F] and below (130 K Ω and above)
TH4	240 $^{\circ}\text{C}$ [464 $^{\circ}\text{F}$] and above (0.57 $\text{k}\Omega$ and below)	0 $^{\circ}$ C [32 $^{\circ}$ F] and below (698 k $_{\Omega}$ and above)
TH5	70 $^{\circ}$ C [158 $^{\circ}$ F] and above (0.4 k Ω and below)	-40 $^{\circ}\text{C}$ [-40 $^{\circ}\text{F}$] and below (130 k Ω and above)
TH6	70 $^{\circ}$ C [158 $^{\circ}$ F] and above (1.14 $k\Omega$ and below)	-40 $^{\circ}$ C [-40 $^{\circ}$ F] and below (130 k Ω and above)
TH7	110 °C [230 °F] and above (0.4 kΩ and below)	-40 °C [-40 °F] and below (130 $k\Omega$ and above)

5110 (TJMU-A)

Heatsink temperature sensor (THHS) fault (Detail code 01)

2. Error definition and error detection method

When a short or an open of THHS is detected just before or during the inverter operation.

3. Cause, check method and remedy

P72 model

	Cause	Check method and remedy
(1)	INV board failure	If the problem recurs when the unit is put into operation, replace the INV board.

P96, P120, P144 models

	Cause	Check method and remedy
(1)	THHS sensor failure	Check the THHS sensor reading on the LED monitor. Replace the sensor if it reads below - 30°C[-22°F] or above 150°C[302°F].
(2)	Contact failure	Check the connector connection (CNTH) on the INV board.

Note

Refer to section -7- "Inverter (TJMU-A)" under part [4] Troubleshooting Principal Parts for error codes related to the inverter.(page 310)

1. Error Code

5110 (YJMU-A)

Heatsink temperature sensor (THHS) fault (Detail code 01)

2. Error definition and error detection method

When a short or an open of THHS is detected just before or during the inverter operation.

3. Cause, check method and remedy

	Cause	Check method and remedy
(1)	INV board failure	If the problem recurs when the unit is put into operation, replace the INV board.

Note

Refer to section -7- "Inverter (YJMU-A)" under part [4] Troubleshooting Principal Parts for error codes related to the inverter.(page 320)

5111

Liquid inlet temperature sensor (TH11) fault (BC controller)

5112

Bypass outlet temperature sensor (TH12) fault (BC controller)

5115

LEV3 outlet temperature sensor (TH15) fault (BC controller)

5116

LEV3 inlet temperature sensor (TH16) fault (BC controller)

2. Error definition and error detection method

•If a shorted (high temperature intake) or open (low temperature intake) thermistor (TH11, TH12, TH15, or TH16) is detected during operation, the unit makes an error stop, and an error code "5111," "5112," "5115," or "5116" appears on the display.

*Detection of a short- or open-circuit as described above is suspended during the defrost cycle and for 3 minutes after the operation mode is changed.

3. Cause, check method and remedy

	Cause	Check method and remedy
(1)	Thermistor failure	Check thermistor resistance.
(2)	Pinched lead wire	Check for pinched lead wire.
(3)	Torn wire coating	Check for wire coating.
(4)	A pin on the male connector is missing or contact failure	Check connector.
(5)	Disconnected wire	Check for wire.
(6)	Thermistor input circuit failure on the control board	Check the intake temperature of the sensor with the LED monitor. When the temperature is far different from the actual temperature, replace the control board.

<Reference>

	Short detection	Open detection
TH11	110 $^{\circ}$ C [230 $^{\circ}$ F] and above (0.4 k Ω)	-40 °C [-40 °F] and below (130 k Ω)
TH12	110 $^{\circ}$ C [230 $^{\circ}$ F] and above (0.4 k Ω)	-40 °C [-40 °F] and below (130 k Ω)
TH15	70 °C [158 °F] and above (0.4 k Ω)	-40 °C [-40 °F] and below (130 k Ω)
TH16	110 °C [230 °F] and above (0.4 k Ω)	-40 $^{\circ}\text{C}$ [-40 $^{\circ}\text{F}$] and below (130 k $\Omega)$



High-pressure sensor fault (63HS1)

2. Error definition and error detection method

- •If the high pressure sensor detects 0.098MPa [14psi] or less during the operation, the outdoor unit stops once, turns to antirestart mode for 3 minutes, and restarts after 3 minutes when the detected high pressure sensor is 0.098MPa [14psi] or more.
- •If the high pressure sensor detects 0.098MPa [14psi] or less just before the restart, the outdoor unit makes an error stop, and the error code "5201" will appear.
- •During 3-minute antirestart mode, preliminary errors will be displayed on the LED display.
- •A error is not detected for 3 minutes after the compressor start, during defrost operation, or 3 minutes after defrost operation.

	Cause	Check method and remedy
(1)	High pressure sensor failure	Refer to the page on the troubleshooting of the high pressure sensor. (IX [4] -1- (page 288)
(2)	Pressure drop due to refrigerant leak	
(3)	Torn wire coating	
(4)	A pin on the male connector is missing or contact failure	
(5)	Disconnected wire	
(6)	High pressure sensor input circuit failure on the control board	



High-pressure sensor fault (Outdoor unit HPS/BC controller PS1)



Intermediate pressure sensor fault (BC controller PS3)

2. Error definition and error detection method

When a pressure sensor reading of 4.06 MPa [589 psi] or above is detected, error codes "5201" and "5203" will appear. The unit will continue its operation by using other sensors as a backup.

	Cause	Check method and remedy
(1)	High pressure sensor failure	Refer to the page on the troubleshooting of the high pressure sensor. (IX [4] -1-(page 288))
(2)	Pressure drop due to refrigerant leak	
(3) Torn wire coating		
(4) A pin on the male connector is missing or contact failure		
(5)	Disconnected wire	
(6)	High pressure sensor input circuit failure on the control board	

5301 (TJMU-A)

ACCT sensor fault (Detail code 115)

2. Error definition and error detection method

When the formula "output current < 2 Arms" remains satisfied for 10 seconds while the inverter is in operation.

3. Cause, check method and remedy

P72 model

	Cause	Check method and remedy
(1)	Inverter open output phase	Check the output wiring connections.
(2)	Compressor failure	Refer to IX [4] -7- (2) [2].(page 312)
(3)	INV board failure	Refer to IX [4] -7- (2) [1], [3], [4].(page 312)

P96, P120, P144 models

	Cause	Check method and remedy
(1)	Inverter open output phase	Check the output wiring connections.
(2)	Compressor failure	Refer to IX [4] -7- (2) [2].(page 312)
(3)	INV board failure	Refer to IX [4] -7- (2) [1], [3], [4].(page 312)
(4)	Contact failure	Check the connection of the connector (CNCT2) on the INV board-INV board.
(5)	ACCT sensor failure	Refer to IX [4] -7- (4).

Note

Refer to section -7-"Inverter (TJMU-A)" under part [4] Troubleshooting Principal Parts for error codes related to the inverter.(page 310)

5301 (YJMU-A)

ACCT sensor fault (Detail code 115)

2. Error definition and error detection method

When the formula "output current < 1.5 Arms" remains satisfied for 10 seconds while the inverter is in operation.

3. Cause, check method and remedy

	Cause	Check method and remedy
(1)	Inverter open output phase	Check the output wiring connections.
(2)	Compressor failure	Refer to IX [4] -7- (2) [2].(page 322)
(3)	INV board failure	Refer to IX [4] -7- (2) [1], [3], [4].(page 322)

Note

Refer to section -7-"Inverter (YJMU-A)" under part [4] Troubleshooting Principal Parts for error codes related to the inverter.(page 320)

1. Error Code

5301 (TJMU-A) (P96, P120, P144 models only)

DCCT sensor fault (Detail code116)

2. Error definition and error detection method

When the bus current less than 18 Apeak is detected at startup (6Hz)

3. Cause, check method and remedy

	Cause	Check method and remedy
(1)	Contact failure	Check the contact of the connector (CNCT) on the INV board, and the contact the connector on DCCT side.
(2)	Misorientation	Check the installation direction of DCCT.
(3)	DCCT sensor failure	Replace the DCCT sensor.
(4)	INV board failure	Replace the INV board.

Note

Refer to section -7-"Inverter (TJMU-A)" under part [4] Troubleshooting Principal Parts for error codes related to the inverter.(page 310)

1. Error Code

5301

ACCT sensor circuit fault (Detail code 117)

2. Error definition and error detection method

When an error value is detected with the ACCT detection circuit just before the inverter starts

3. Cause, check method and remedy

	Cause	Check method and remedy
(1)	INV board failure	Refer to IX [4] -7- (2) [1], [3], [4].
(2)	Compressor failure	Refer to IX [4] -7- (2) [2].

Note

Refer to section -7-"Inverter" under part [4] Troubleshooting Principal Parts for error codes related to the inverter.

5301 (TJMU-A) (P96, P120, P144 models only)

DCCT sensor circuit fault (Detail code118)

2. Error definition and error detection method

When an error value is detected with the DCCT detection circuit just before the inverter starts

3. Cause, check method and remedy

	Cause	Check method and remedy
(1)	Contact failure	Check for good contact of the INV board connector CNCT and the connector on the DCCT side.
(2)	INV board failure	Refer to IX [4] -7- (2) [1], [3], [4].(page 312)
(3)	DCCT sensor failure	Replace the DCCT sensor.
(4)	Compressor failure	Refer to IX [4] -7- (2) [2].(page 312)
(5)	Inverter failure	Refer to IX [4] -7(page 310)

Note

Refer to section -7- "Inverter (TJMU-A)" under part [4] Troubleshooting Principal Parts for error codes related to the inverter.(page 310)

1. Error Code

5301 (TJMU-A)

Open-circuited IPM/Loose ACCT connector (Detail code 119)

2. Error definition and error detection method

Presence of enough current cannot be detected during the self-diagnostic operation immediately before inverter startup.

3. Cause, check method and remedy

P72 model

	Cause	Check method and remedy
(1)	Inverter output wiring problem	Check output wiring connections. Confirm that the U- and W-phase output cables are put through CT12 and CT22 on the INV board respectively.
(2)	Inverter failure	Refer to IX [4] -7- (2) [3], [4].(page 313)
(3)	Compressor failure	Refer to IX [4] -7- (2) [2].(page 312)

P96, P120, P144 models

	Cause	Check method and remedy
(1)	ACCT sensor disconnection	Check the connection of the connector (CNCT2) on the INV board. Check for proper mounting of ACCT.
(2)	ACCT sensor failure	Refer to IX [4] -7- (4).(page 316)
(3)	Inverter failure	Refer to IX [4] -7- (2) [3], [4].(page 313)
(4)	Compressor failure	Refer to IX [4] -7- (2) [2].(page 312)

Note

Refer to section -7- "Inverter (TJMU-A)" under part [4] Troubleshooting Principal Parts for error codes related to the inverter (page 310)

5301 (YJMU-A)

Open-circuited IPM/Loose ACCT connector (Detail code 119)

2. Error definition and error detection method

Presence of enough current cannot be detected during the self-diagnostic operation immediately before inverter startup.

3. Cause, check method and remedy

	Cause	Check method and remedy
(1)	Inverter output wiring problem	Check output wiring connections. Confirm that the U- and W-phase output cables are put through CT12 and CT22 on the INV board respectively.
(2)	Inverter failure	Refer to IX [4] -7- (2) [3], [4].(page 322)
(3)	Compressor failure	Refer to IX [4] -7- (2) [2].(page 322)

Note

Refer to section -7- "Inverter (YJMU-A)" under part [4] Troubleshooting Principal Parts for error codes related to the inverter.(page 320)

1. Error Code

5301 (TJMU-A)

Faulty ACCT wiring (Detail code 120)

2. Error definition and error detection method

Presence of target current cannot be detected during the self-diagnostic operation immediately before startup. (Detection of improperly mounted ACCT sensor)

3. Cause, check method and remedy

P72 model

	Cause	Check method and remedy
(1)	Inverter output wiring problem	Check output wiring connections. Confirm that the U- and W-phase output cables are put through CT12 and CT22 on the INV board respectively.
(2)	Inverter failure	Refer to IX [4] -7- (2) [3], [4].(page 313)
(3)	Compressor failure	Refer to IX [4] -7- (2) [2].(page 312)
(4)	INV board failure	Replace the INV board.

P96, P120, P144 models

	Cause	Check method and remedy
(1)	Wrongly mounted ACCT sensor	Check for proper mounting of ACCT. Refer to IX [4] -7- (4).
(2)	ACCT sensor failure	Refer to IX [4] -7- (4).(page 316)
(3)	Inverter failure	Refer to IX [4] -7- (2) [3], [4].(page 313)
(4)	Compressor failure	Refer to IX [4] -7- (2) [2].(page 312)

Note

Refer to section -7- "Inverter (TJMU-A)" under part [4] Troubleshooting Principal Parts for error codes related to the inverter.(page 310)

5301 (YJMU-A)

Faulty ACCT wiring (Detail code 120)

2. Error definition and error detection method

Presence of target current cannot be detected during the self-diagnostic operation immediately before startup.

3. Cause, check method and remedy

	Cause	Check method and remedy
(1)	Inverter output wiring problem	Check output wiring connections. Confirm that the U- and W-phase output cables are put through CT12 and CT22 on the INV board respectively.
(2)	Inverter failure	Refer to IX [4] -7- (2) [3], [4].(page 322)
(3)	Compressor failure	Refer to IX [4] -7- (2) [2].(page 322)

Note

Refer to section -7- "Inverter (YJMU-A)" under part [4] Troubleshooting Principal Parts for error codes related to the inverter.(page 320)



Temperature sensor fault

2. Error definition and error detection method

•A short-circuit or an open-circuit of the humidity sensor is detected during operation.

3. Cause, check method and remedy

	Cause		Check method and remedy			
(1)	Connector contact failure (CN30) (Loose connector)	1)	Check the connector for proper contact. Reconnect the connector, and operate the unit to check for proper operation.			
(2)	Broken or partially broken humidity sensor wire	2)	Check for broken humidity sensor wire.			
(3)	Humidity sensor fault	3)	Check the output voltage across No. 1 and No. 3 pins of connector CN30 with the connector being connected to the indoor unit control board. 30%: 1.25V 40%: 1.52V 50%: 1.88V 60%: 2.19V 70%: 2.48V 80%: 2.79V			
(4)	Indoor unit control board (detection circuit) fault	4)	If the above items check out okay, replace the indoor unit control board.			

5701

Loose float switch connector

2. Error definition and error detection method

Detection of the disconnected float switch (open-phase condition) during operation

3. Cause, check method and remedy

(1) CN4F disconnection or contact failure

Check for disconnection of the connector (CN4F) on the indoor unit control board.

1. Error Code



Remote controller board fault (nonvolatile memory error)

2. Error definition and error detection method

This error is detected when the data cannot be read out from the built-in nonvolatile memory on the remote controller.

3. Cause, check method and remedy

(1) Remote controller failure

Replace the remote controller.

1. Error Code



Remote controller board fault (clock IC error)

2. Error definition and error detection method

This error is detected when the built-in clock on the remote controller is not properly functioning.

3. Cause, check method and remedy

(1) Remote controller failure

Replace the remote controller.



Address overlaps

2. Error definition and error detection method

An error in which signals from more than one indoor units with the same address are received

Note

The address and attribute that appear on the remote controller indicate the controller that detected the error.

3. Cause, check method and remedy

	Cause	Check method and remedy
(1)	Two or more of the following have the same address: Outdoor units, indoor units, LOSSNAY units, controllers such as ME remote controllers. <example> 6600 "01" appears on the remote controller Unit #01 detected the error. Two or more units in the system have 01 as their address.</example>	Find the unit that has the same address as that of the error source. Once the unit is found, correct the address. Then, turn off the outdoor units, indoor units, and LOSSNAY units, keep them all turned off for at least five minutes, and turn them back on.
(2)	Electrical noise on the transmission wire distorted the transmission signals.	

1. Error Code



Polarity setting error

2. Error definition and error detection method

The error detected when transmission processor cannot distinguish the polarities of the M-NET transmission line.

3. Cause, check method and remedy

	Cause	Check method and remedy
(1)	No voltage is applied to the M-NET transmission line that AG-150A/G-50A is connected to.	Check if power is supplied to the M-NET transmission line of the AG-150A/G-50A, and correct any problem found.
(2)	M-NET transmission line to which AG-150A/G-50A is connected is short-circuited.	



Transmission processor hardware error

2. Error definition and error detection method


Although "0" was surely transmitted by the transmission processor, "1" is displayed on the transmission line.

Note

The address/attribute appeared on the display on the remote controller indicates the controller where an error occurred.

3. Cause

- 1) When the wiring work of or the polarity of either the indoor or outdoor transmission line is performed or is changed while the power is on, the transmitted data will collide, the wave shape will be changed, and an error will be detected.
- 2) Grounding fault of the transmission line
- 3) When grouping the indoor units that are connected to different outdoor units, the male power supply connectors on the multiple outdoor units are connected to the female power supply switch connector (CN40).
- 4) When the power supply unit for transmission lines is used in the system connected with MELANS, the male power supply connector is connected to the female power supply switch connector (CN40) on the outdoor unit.
- 5) Controller failure of the source of the error
- 6) When the transmission data is changed due to the noise on the transmission line
- 7) Voltage is not applied on the transmission line for centralized control (in case of grouped indoor units connected to different outdoor units or in case of the system connected with MELANS)





Transmission line bus busy error

2. Error definition and error detection method

- •Generated error when the command cannot be transmitted for 4-10 minutes in a row due to bus-busy
- •Generated error when the command cannot be transmitted to the transmission line for 4-10 minutes in a row due to noise

Note

The address/attribute appeared on the display on the remote controller indicates the controller where an error occurred.

3. Cause, check method and remedy

	Cause	Check method and remedy					
(1)	The transmission processor cannot be transmitted as the short-wavelength voltage like noise exists consecutively on the transmission line.	Check the transmission wave shape and noise on the transmission line. See the section "Investigation of Transmission Wave Shape/Noise." -> No noise indicates that the error source controller is a failure. -> If noise exists, investigate the noise.					
(2)	Error source controller failure						

1. Error Code



Communication error between device and transmission processors

2. Error definition and error detection method

Communication error between the main microcomputer on the indoor unit board and the microcomputer for transmission

Note

The address/attribute appeared on the display on the remote controller indicates the controller where an error occurred.

3. Cause, check method and remedy

	Cause	Check method and remedy
(1)	Data is not properly transmitted due to accidental erroneous operation of the controller of the error source.	Turn off the power source of the outdoor and the indoor units. (When the power source is turned off separately, the microcomputer will not be reset, and the error will not be corrected.)
(2)	Error source controller failure	corrected.) -> If the same error occurs, the error source controller is a failure.



No ACK error

2. Error definition and error detection method

The error is detected when no acknowledgement (ACK signal) is received after the transmission. (eg. When the data is transmitted six times in a row with 30 seconds interval, the error is detected on the transmission side.)

Note

The address/attribute appeared on the display on the remote controller indicates the controller which did not provide the response (ACK).

3. System configuration

(1) System with one outdoor unit

Error source address	Error dis- play	Detection method		Cause	Check method and remedy		
Outdoor unit (OC)	ME re- mote con- troller (RC) MA re- mote con- troller (MA)	No ac- knowl- edgement (ACK) at IC trans- mission to OC	(1) (2) (3) (4)	Contact failure of transmission line of OC or IC Decrease of transmission line voltage/signal by exceeding acceptable range of transmission wiring. Farthest:200 m [656ft] or less Remote controller wiring: 10m [32ft] or less Erroneous sizing of transmission line (Not within the range below). Wire diameter: 1.25mm² [AWG16] or more Indoor unit control board failure	Turn off the power source of the outdoor unit, and turn it on again. If the error is accidental, it will run normally. If not, check the causes (1) - (4).		
BC controller (BC)	ME re- mote con- troller (RC) MA re- mote con- troller (MA)	No ac- knowl- edgement (ACK) at IC trans- mission to BC	(1) (2) (3) (4)	When BC controller address is changed or modified during operation. Faulty or disconnected transmission wiring of BC controller Disconnected connector of BC controller (CN02) Faulty control board of BC controller	Turn off the outdoor/indoor units for 5 or more minutes, and turn them on again. If the error is accidental, they will run normally. If not, check the causes (1) - (4).		
Indoor unit (IC)	ME re- mote con- troller (RC) MA re- mote con- troller (MA)	No ac- knowl- edgement (ACK) at RC trans- mission to IC	(1) (2) (3) (4) (5)	When IC unit address is changed or modified during operation. Faulty or disconnected IC transmission wiring Disconnected IC connector (CN2M) Indoor unit controller failure ME remote controller failure	Turn off the outdoor/indoor units for 5 or more minutes, and turn them on again. If the error is accidental, they will run normally. If not, check the causes (1) - (5).		
LOSS- NAY (LC)	ME re- mote con- troller (RC) MA re- mote con- troller (MA)	No ac- knowl- edgement (ACK) at IC trans- mission to LC	(1)(2)(3)(4)(5)	The power source of LOSSNAY has been shut off. When the address of LOSSNAY is changed in the middle of the operation Faulty or disconnected transmission wiring of LOSSNAY Disconnected connector (CN1) on LOSSNAY Controller failure of LOSSNAY	Turn off the power source of LOSSNAY and turn it on again. If the error is accidental, it will run normally. If not, check the causes (1) - (5).		
ME remote controller (RC)	ME remote controller (RC) (ACK) a MA remote controller (MA)		(1)(2)(3)(4)	Faulty transmission wiring at IC unit side. Faulty wiring of the transmission line for ME remote controller When the address of ME remote controller is changed in the middle of the operation ME remote controller failure	Turn off the power source of the outdoor unit for 5 minutes or more, and turn it on again. If the error is accidental, it will run normally. If not, check the causes (1) - (4).		



No ACK error

2. Error definition and error detection method

The error is detected when no acknowledgement (ACK signal) is received after the transmission. (eg. When the data is transmitted six times in a row with 30 seconds interval, the error is detected on the transmission side.)

Note

The address/attribute appeared on the display on the remote controller indicates the controller which did not provide the response (ACK).

3. System configuration

(2) Grouping of units in a system with multiple outdoor units

Error source address	Error display	Detection method		Cause		Check method and remedy
Outdoor unit (OC)	ME remote controller (RC) MA remote controller (MA)	No acknowl- edgement (ACK) at IC transmission to OC		Same cause as that for system with one outdoor unit		Same remedy as that for system with one outdoor unit
BC controller (BC)	ME remote controller (RC) MA remote controller (MA)	No acknowl- edgement (ACK) at IC transmission to BC		Same cause as that for system with one outdoor unit		Same remedy as that for system with one outdoor unit
Indoor unit (IC)	ME remote controller (RC) MA remote controller (MA)	No acknowl- edgement (ACK) at RC transmission to IC	(1)	Same causes as (1) - (5) for system with one outdoor unit	1)	Turn off the power sources of the outdoor and indoor units for 5 or more minutes, and turn them on again. If the error is accidental, the will run normal- ly.If not, check the cause 2).
			(2)	Disconnection or short circuit of the transmission line for the out- door unit on the terminal block for centralized control line connection (TB7)	2)	Check the causes of (1) - (5). If the cause is found, correct it. If no cause is found, check 3).
			(3)	When multiple outdoor units are connected and the power source of one of the outdoor units has been shut off.	3)	Check the LED displays for troubleshooting on other remote controllers whether an error occurs.
			(4)	The male power supply connector of the outdoor unit is not connected to the female power supply switch connector (CN40).		If an error is found, -> If an error is found, check the check code definition, and correct the error.
			(5)	The male power supply connectors on 2 or more outdoor units are connected to the female power supply switch connector (CN40) for centralized control.		If no error is found, -> Indoor unit board failure
				If an error occurs, after the unit runs normally once, the following causes may be considered. •Total capacity error (7100) •Capacity code error (7101) •Error in the number of connected units (7102) •Address setting error (7105)		



No ACK error

2. Error definition and error detection method

The error is detected when no acknowledgement (ACK signal) is received after the transmission. (eg. When the data is transmitted six times in a row with 30 seconds interval, the error is detected on the transmission side.)

Note

The address/attribute appeared on the display on the remote controller indicates the controller which did not provide the response (ACK).

3. System configuration

(2) Grouping of units in a system with multiple outdoor units

Error source address	Error display	Detection method		Cause		Check method and remedy
LOSS- NAY (LC)	ME remote controller (RC) MA remote controller (MA)	No acknowl- edgement (ACK) at IC transmission to LC	(1)	Factors (1) through (5) in the "Factors in system with one outdoor unit" (When performing an interlocked operation of the LOSSNAY unit and the indoor units that are connected to different outdoor units.)	1)	Turn off the power source of LOSSNAY for 5 or more minutes, and turn it on again. If the error is accidental, it will run normally. If not, check the cause 2).
			(2)	Disconnection or short circuit of the transmission line for the outdoor unit on the termi- nal block for centralized con- trol line connection (TB7)	2)	Check the causes of (1) - (5). If the cause is found, correct it. If no cause is found, check 3).
			(3)	When multiple outdoor units are connected and the power source of one of the outdoor units has been shut off.	3)	Same cause as that for indoor unit described in 3)
			(4)	The male power supply connector of the outdoor unit is not connected to the female power supply switch connector (CN40).		
			(5)	The male power supply connectors on 2 or more outdoor units are connected to the female power supply switch connector (CN40) for centralized control.		
				If an error occurs, after the unit runs normally once, the following causes may be considered. •Total capacity error (7100) •Capacity code error		
				(7101)Error in the number of connected units (7102)Address setting error (7105)		



No ACK error

2. Error definition and error detection method

The error is detected when no acknowledgement (ACK signal) is received after the transmission. (eg. When the data is transmitted six times in a row with 30 seconds interval, the error is detected on the transmission side.)

Note

The address/attribute appeared on the display on the remote controller indicates the controller which did not provide the response (ACK).

3. System configuration

(2) Grouping of units in a system with multiple outdoor units

Error source address	Error display	Detection method		Cause		Check method and remedy
ME re- mote con- troller (RC)	ME remote controller (RC) MA remote controller (MA)	No acknowl- edgement (ACK) at IC transmission to RC	(1)	Same causes as (1) - (4) for system with one outdoor unit	1)	Turn off the power source of LOSSNAY for 5 or more minutes, and turn it on again. If the error is accidental, it will run normally. If not, check the cause 2).
			(2)	Disconnection or short circuit of the transmission line for the outdoor unit on the termi- nal block for centralized con- trol line connection (TB7)	2)	Check the causes of (1) - (5). If the cause is found, correct it. If no cause is found, check 3).
			(3)	When multiple outdoor units are connected and the power source of one of the outdoor units has been shut off.	3)	Same cause as that for indoor unit described in 3)
			(4)	The male power supply connector of the outdoor unit is not connected to the female power supply switch connector (CN40).		
			(5)	The male power supply connectors on 2 or more outdoor units are connected to the female power supply switch connector (CN40) for centralized control.		
				If the problem recurs after normal operation is restored, the problem is caused by one of the following factors: •Total capacity error (7100) •Capacity code setting		
				error (7101) •Error in the number of connected units (7102) •Address setting error (7105)		



No ACK error

2. Error definition and error detection method

The error is detected when no acknowledgement (ACK signal) is received after the transmission. (eg. When the data is transmitted six times in a row with 30 seconds interval, the error is detected on the transmission side.)

Note

The address/attribute appeared on the display on the remote controller indicates the controller which did not provide the response (ACK).

3. System configuration

Error source address	Error display	Detection method	Cause	Check method and remedy
Out- door unit (OC)	ME remote controller (RC) System control- ler (SC) MA remote controller (MA)	No acknowl- edgement (ACK) at IC transmis- sion to OC	Same cause as that for system with one outdoor unit	Same remedy as that for system with one outdoor unit
BC controller (BC)	ME remote controller (RC) system control- ler (SC) MA remote controller (MA)	No acknowl- edgement (ACK) at IC transmis- sion to BC	Same cause as that for system with one outdoor unit	Same remedy as that for system with one outdoor unit



No ACK error

2. Error definition and error detection method

The error is detected when no acknowledgement (ACK signal) is received after the transmission. (eg. When the data is transmitted six times in a row with 30 seconds interval, the error is detected on the transmission side.)

Note

The address/attribute appeared on the display on the remote controller indicates the controller which did not provide the response (ACK).

3. System configuration

Error source address	Error display	Detection method		Cause	CI	heck method and remedy
Indoor unit (IC)	ME remote controller (RC) MA remote controller (MA)	No acknowl- edgement (ACK) at RC transmis- sion to IC		Same as grouping of units in a system with multiple outdoor units		Same remedy as that for grouping of units in a system with multiple outdoor units
	System control-	No acknowl-	1.	Error occurrence on some IC		Same remedy as that for
	ler (SC)	edgement (ACK) at SC transmis-	(1)	Same cause as that for system with one outdoor unit		system with one outdoor unit
		sion to IC	2.	Error occurrence on all IC in the system with one outdoor unit	1)	Check the LED display for troubleshooting on the outdoor unit.
			(1)	Total capacity error (7100)		 If an error is found, check the check code definition, and correct the error. If no error is found, check 2).
			(2)	Capacity code error (7101)		
			(3)	Error in the number of connected units (7102)		
			(4)	Address setting error (7105)		,
			(5)	Disconnection or short circuit of the transmission line for the outdoor unit on the terminal block for centralized control line connection (TB7)	2)	Check (5) - (7) on the left.
			(6)	Turn off the power source of the outdoor unit		
			(7)	Malfunction of electrical system for the outdoor unit		
			3.	Error occurrence on all IC		Check voltage of the transmission line for cen-
			(1)	Same causes as (1) - (7) described in 2.		tralized control.
			(2)	The male power supply connectors on 2 or more outdoor units are connected to the female power supply switch connector (CN40) for the transmission line for centralized control.		•20V or more: Check (1) and (2) on the left. •Less than 20V: Check (3) on the left.
			(3)	Disconnection or shutdown of the power source of the power supply unit for transmission line		
			(4)	System controller (MELANS) malfunction		



No ACK error

2. Error definition and error detection method

The error is detected when no acknowledgement (ACK signal) is received after the transmission. (eg. When the data is transmitted six times in a row with 30 seconds interval, the error is detected on the transmission side.)

Note

The address/attribute appeared on the display on the remote controller indicates the controller which did not provide the response (ACK).

3. System configuration

Error source address	Error display	Detection method		Cause	(Check method and remedy															
ME re- mote con- troller (RC)	ME remote controller (RC) System con- troller (SC) MA remote controller (MA)	No acknowl- edgement (ACK) at IC transmission to RC		Same as grouping of units in a system with multiple outdoor units		Same remedy as that for grouping of units in a system with multiple outdoor units															
	System controller (SC)	No acknowl- edgement (ACK) at MELANS	1. (1)	Error occurrence on some IC Same cause as that for system with one outdoor unit		Same remedy as that for system with one outdoor unit															
		transmission to RC	2.	Error occurrence on all IC in the system with one outdoor unit	1)	Check the LED display for troubleshooting on the outdoor unit.															
				(1)	An error is found by the outdoor unit. Total capacity error (7100) Capacity code error (7101) Error in the number of connected units (7102) Address setting error (7105)	•	 If an error is found, check the check code definition, and correct the error. If no error is found, check the cause 2). 														
			(2)	Disconnection or short circuit of the transmission line for the outdoor unit on the terminal block for centralized control line connection (TB7)	2)	Check (2) - (4) on the left.															
			(3)	Turn off the power source of the outdoor unit																	
			(4)	Malfunction of electrical system for the outdoor unit																	
																		3.	Error occurrence on all IC		Check (1) - (4) on the left.
					(1)	Same causes as (1) - (4) described in 2.															
			(2)	When the power supply unit for transmission lines is used and the male power supply connector is connected to the female power supply switch connector (CN40) for the transmission line for centralized control																	
			(3)	Disconnection or shutdown of the power source of the power supply unit for transmission line																	
			(4)	System controller (MELANS) mal- function																	



No ACK error

2. Error definition and error detection method

The error is detected when no acknowledgement (ACK signal) is received after the transmission. (eg. When the data is transmitted six times in a row with 30 seconds interval, the error is detected on the transmission side.)

Note

The address/attribute appeared on the display on the remote controller indicates the controller which did not provide the response (ACK).

3. System configuration

Error source address	Error display	Detection method		Cause	(Check method and remedy	
System controller	ME remote controller	No acknowl- edgement	1.	Error display on some displays on ME remote controllers		Check (1) - (3) on the left.	
(SC)	(RC) MA remote controller	(ACK) at IC transmission to SC	(1)	Faulty wiring of the transmission line for ME remote controller			
	(MA)		(2)	Disconnection or contact failure of the transmission connector for ME remote controller			
			(3)	ME remote controller failure			
			2.	Error occurrence on all IC in the system with one outdoor unit	1)	Check the LED display for troubleshooting on the outdoor unit.	
				An error is found by the outdoor unit. Total capacity error (7100) Capacity code error (7101) Error in the number of connected units (7102) Address setting error (7105)		 If an error is found, check the check code definition, and correct the error. If no error is found, check the cause 2) 	
			(2)	Disconnection or short circuit of the transmission line for the outdoor unit on the terminal block for centralized control line connection (TB7)	2)	Check (2) - (4) on the left.	
				(3)	Turn off the power source of the outdoor unit		
			(4)	Malfunction of electrical system for the outdoor unit			
				3.	Error display on all displays on ME remote controllers	1E Chec	Check (1) - (4) on the left
				(1)	Same causes as (1) - (4) described in 2.		
				When the power supply unit for transmission lines is used and the male power supply connector is connected to the female power supply switch connector (CN40) for the transmission line for centralized control			
			(3)	Disconnection or shutdown of the power source of the power supply unit for transmission line			
			(4)	System controller (MELANS) mal- function			



No ACK error

2. Error definition and error detection method

The error is detected when no acknowledgement (ACK signal) is received after the transmission. (eg. When the data is transmitted six times in a row with 30 seconds interval, the error is detected on the transmission side.)

Note

The address/attribute appeared on the display on the remote controller indicates the controller which did not provide the response (ACK).

3. System configuration

(4) Errors that are not limited to a particular system

Error source ad-	Error dis-	Detection		Cause		Check method and remedy
dress	play	method				2.135K Moulou and followy
Address which should not be existed	-	-	(1)	Although the address of ME remote controller has been changed after the group is set using ME remote controller, the indoor unit is keeping the memory of the previous address. The same symptom will appear for the registration with SC.		Delete unnecessary information of non-existing address which some indoor units have. Use either of the following two methods for deletion.
			(2)	Although the address of LOSSNAY has been changed after the interlock registration of LOSSNAY is made using ME remote controller, the indoor unit is keeping the memory of the previous address.	1)	Address deletion by ME remote controller Delete unnecessary address information using the manual setting function of ME remote controller. Refer to this service handbook "IV. [2]. Group Settings and Interlock Settings via the ME Remote Controller 1. (3) Address deletion".
					2)	Deletion of connection informa- tion of the outdoor unit by the deleting switch
						Note that the above method will delete all the group settings set via the ME remote controller and all the interlock settings between LOSS-NAY units and indoor units. *Turn off the power source of the outdoor unit, and wait for 5 minutes. *Turn on the dip switch (SW2-2) on the outdoor unit control board. *Turn on the power source of the outdoor unit, and wait for 5 minutes. *Turn off the power source of the outdoor unit, and wait for 5 minutes. *Turn off the dip switch (SW2-2) on the outdoor unit control board. *Turn on the power source of the outdoor unit control board.



No response error

2. Error definition and error detection method

- •When no response command is returned although acknowledgement (ACK) is received after transmission, an error is detected.
- •When the data is transmitted 10 times in a row with 3 seconds interval, an error is detected on the transmission side.

Note

The address/attribute appeared on the display on the remote controller indicates the controller where an error occurred.

3. Cause

- The transmission line work is performed while the power is on, the transmitted data will collide, and the wave shape will be changed.
- 2) The transmission is sent and received repeatedly due to noise.
- 3) Decrease of transmission line voltage/signal by exceeding acceptable range of transmission wiring.

Farthest:200m [656ft] or less

Remote controller wiring:12m [39ft] or less

4) The transmission line voltage/signal is decreased due to erroneous sizing of transmission line.

Wire diameter: 1.25mm²[AWG16] or more

4. Check method and remedy

- 1) When an error occurs during commissioning, turn off the power sources for the outdoor unit, indoor unit, BC controller, and LOSSNAY for 5 or more minutes, and then turn them on again.
 - When they return to normal operation, the cause of the error is the transmission line work performed with the power on.
 - If an error occurs again, check the cause 2).
- 2) Check 3) and 4) above.
 - •If the cause is found, correct it.
 - If no cause is found, check 3).
- 3) Check transmission wave shape/ noise on trans-mission line by following "IX [3] Investigation of Transmission Wave Shape/ Noise" (page 285).

Noise is the most possible cause of the error "6608".



MA controller signal reception error (No signal reception)

2. Error definition and error detection method

- *Communication between the MA remote controller and the indoor unit is not done properly.
- •No proper data has been received for 3 minutes.

3. Cause

- 1) Contact failure of the remote controller lines of MA remote controller or the indoor unit.
- 2) All the remote controllers are set to SUB.
- 3) Failure to meet wiring regulations
 - *Wire length
 - ·Wire size
 - Number of remote controllers
 - Number of indoor units
- 4) The remote controller is removed after the installation without turning the power source off.
- 5) Noise interference on the remote controller transmission lines
- 6) Faulty circuit that is on the indoor board and performs transmission/ reception of the signal from the remote controller
- 7) Problems with the circuit on the remote controller that sends or receives the signals from the remote controller

- 1) Check for disconnected or loose transmission lines for the indoor units or MA remote controllers.
- 2) Confirm that the power is supplied to the main power source and the remote controller line.
- 3) Confirm that MA remote controller's capacity limit is not exceeded.
- 4) Check the sub/main setting of the MA remote controllers. One of them must be set to MAIN.
- 5) Diagnose the remote controller (described in the remote controller installation manual).
 - [OK]: no problems with the remote controller (check the wiring regulations)
 - [NG]: Replace the MA remote controller.
 - [6832, 6833, ERC]: Due to noise interference <Go to 6)>
- 6) Check wave shape/noise on MA remote controller line by following "IX [3] Investigation of Transmission Wave Shape/Noise".(page 285)
- 7) When no problems are found with items 1) through 6), replace the indoor unit board or the MA remote controller. The following status can be confirmed on LED1 and 2 on the indoor unit board.
 - •If LED1 is lit, the main power source of the indoor unit is turned on.
 - •If LED2 is lit, the MA remote controller line is being powered.



MA remote controller signal transmission error (Synchronization error)

2. Error definition and error detection method

- •MA remote controller and the indoor unit is not done properly.
- •Failure to detect opening in the transmission path and unable to send signals
 - *Indoor unit: 3 minutes
 - *Remote controller: 6 seconds

3. Cause

- 1) Contact failure of the remote controller lines of MA remote controller or the indoor unit
- 2) 2 or more remote controllers are set to MAIN
- 3) Overlapped indoor unit address
- 4) Noise interference on the remote controller lines
- 5) Failure to meet wiring regulations
 - Wire length
 - *Wire size
 - Number of remote controllers
 - Number of indoor units
- 6) Problems with the circuit on the remote controller that sends or receives the signals from the remote controller

- 1) Check for disconnected or loose transmission lines for the indoor units or MA remote controllers.
- 2) Confirm that the power is supplied to the main power source and the remote controller line.
- 3) Confirm that MA remote controller's capacity limit is not exceeded.
- 4) Check the sub/main setting of the MA remote controllers. One of them must be set to MAIN.
- 5) Diagnose the remote controller (described in the remote controller installation manual).
 - [OK]: no problems with the remote controller (check the wiring regulations)
 - [NG]: Replace the MA remote controller.
 - [6832, 6833, ERC]: Due to noise interference <Go to 6)>
- 6) Check wave shape/noise on MA remote controller line by following "IX [3] Investigation of Transmission Wave Shape/Noise".(page 285)
- 7) When no problems are found with items 1) through 6), replace the indoor unit board or the MA remote controller. The following status can be confirmed on LED1 and 2 on the indoor unit board.
 - •If LED1 is lit, the main power source of the indoor unit is turned on.
 - •If LED2 is lit, the MA remote controller line is being powered.



MA remote controller signal transmission error (Hardware error)

2. Error definition and error detection method

- *Communication between the MA remote controller and the indoor unit is not done properly.
- •An error occurs when the transmitted data and the received data differ for 30 times in a row.

3. Cause

- 1) Contact failure of the remote controller lines of MA remote controller or the indoor unit
- 2) 2 or more remote controllers are set to MAIN
- 3) Overlapped indoor unit address
- 4) Noise interference on the remote controller lines
- 5) Failure to meet wiring regulations
 - ·Wire length
 - Wire size
 - •Number of remote controllers
 - Number of indoor units
- 6) Problems with the circuit on the remote controller that sends or receives the signals from the remote controller

- 1) Check for disconnected or loose transmission lines for the indoor units or MA remote controllers.
- 2) Confirm that the power is supplied to the main power source and the remote controller line.
- 3) Confirm that MA remote controller's capacity limit is not exceeded.
- 4) Check the sub/main setting of the MA remote controllers. One of them must be set to MAIN.
- 5) Diagnose the remote controller (described in the remote controller installation manual).
 - [OK]: no problems with the remote controller (check the wiring regulations)
 - [NG]: Replace the MA remote controller.
 - [6832, 6833, ERC]: Due to noise interference <Go to 6)>
- 6) Check wave shape/noise on MA remote controller line by following "IX [3] Investigation of Transmission Wave Shape/Noise".(page 285)
- 7) When no problems are found with items 1) through 6), replace the indoor unit board or the MA remote controller. The following status can be confirmed on LED1 and 2 on the indoor unit board.
 - •If LED1 is lit, the main power source of the indoor unit is turned on.
 - •If LED2 is lit, the MA remote controller line is being powered.



MA controller signal reception error (Start bit detection error)

2. Error definition and error detection method

- *Communication between the MA remote controller and the indoor unit is not done properly.
- •No proper data has been received for 2 minutes.

3. Cause

- 1) Contact failure of the remote controller lines of MA remote controller or the indoor unit.
- 2) All the remote controllers are set to SUB.
- 3) Failure to meet wiring regulations
 - •Wire length
 - ·Wire size
 - Number of remote controllers
 - Number of indoor units
- 4) The remote controller is removed after the installation without turning the power source off.
- 5) Noise interference on the remote controller transmission lines
- 6) Faulty circuit that is on the indoor board and performs transmission/ reception of the signal from the remote controller
- 7) Problems with the circuit on the remote controller that sends or receives the signals from the remote controller

- 1) Check for disconnected or loose transmission lines for the indoor units or MA remote controllers.
- 2) Confirm that the power is supplied to the main power source and the remote controller line.
- 3) Confirm that MA remote controller's capacity limit is not exceeded.
- 4) Check the sub/main setting of the MA remote controllers. One of them must be set to MAIN.
- 5) Diagnose the remote controller (described in the remote controller installation manual).
 - [OK]: no problems with the remote controller (check the wiring regulations)
 - [NG]: Replace the MA remote controller.
 - [6832, 6833, ERC]: Due to noise interference <Go to 6)>
- 6) Check wave shape/noise on MA remote controller line by following "IX [3] Investigation of Transmission Wave Shape/ Noise".(page 285)
- 7) When no problems are found with items 1) through 6), replace the indoor unit board or the MA remote controller. The following status can be confirmed on LED1 and 2 on the indoor unit board.
 - •If LED1 is lit, the main power source of the indoor unit is turned on
 - •If LED2 is lit, the MA remote controller line is being powered.



Total capacity error

2. Error definition and error detection method

The model total of indoor units in the system with one outdoor unit exceeds limitations.

Error source			Caus	е					Check method and remedy
Outdoor unit	(1)	 The model total of indoor units in the sys- tem with one outdoor unit exceeds the fol- lowing table. 						1)	Check the model total (capacity code total) of indoor units connected.
		P120 m P120 m P144 m P168 m P192 m P216 m P240 m P288 m	odel odel odel odel odel odel odel odel		108 144 180 216 252 288 324 360 396 432	otal		2)	Check the model name (capacity code) of the connected indoor unit set by the switch (SW2 on indoor unit board). When the model name set by the switch is different from that of the unit connected, turn off the power source of the outdoor and the indoor units, and change the setting of the model name (capacity code).
	(2)	The model selection switches (SW5-1 - 5-4) on the outdoor unit are set incorrectly.							Check the setting for the model selection switch on the outdoor unit (Dipswitches SW5-1 - 5-4 on the outdoor unit control board).
		Model		S۱	N5				
		Wiodei	1	2	3	4			
		72 model	OFF	ON	OFF	OFF			
		96 model	ON	ON	OFF	OFF			
		120 mode	OFF	OFF	ON	OFF			
		144 mode	ON	ON	ON	OFF			
	(3)	The outdoor u (OS) that is co are not proper	nnect	ed to t	the sa				Confirm that the TB3 on the OC and OS are properly connected.



Capacity code setting error

2. Error definition and error detection method

Connection of incompatible (wrong capacity code) indoor unit or outdoor unit

Error source			Caus	е					Check method and remedy
Outdoor unit Indoor unit	(1)	the switch (S' *The capacity confirmed by	ame (capacity code) set by W2) is wrong. y of the indoor unit can be the self-diagnosis function ion) of the outdoor unit.			be tion	1)	Check the model name (capacity code) of the indoor unit which has the error source address set by the switch (SW2 on indoor unit board). When the model name set by the switch is different from that of the unit connected, turn off the power source of the outdoor and the indoor units, and change the setting of the capacity code.	
Outdoor unit	(2) The model selection switches (SW5-1 - 5-4) on the outdoor unit are set incorrectly.								Check the setting for the model selection switch on the outdoor unit (Dipswitches SW5-1 - 5-4 on the outdoor unit control board).
		Model		S۱	N5				
		Model	1	2	3	4			
		72 model	OFF	ON	OFF	OFF			
		96 model	ON	ON	OFF	OFF			
		120 model	OFF	OFF	ON	OFF			
		144 model	ON	ON	ON	OFF			



Wrong number of connected units

2. Error definition and error detection method

The number of connected indoor units is "0" or exceeds the allowable value.

Error source	C	Cause	Check method and remedy
Outdoor unit	terminal block (TB3	nits connected to the outdoor) for indoor/ outdoor transmis- imitations described below.	Check whether the number of units connected to the outdoor terminal block (TB3) for indoor/ outdoor transmission lines does not exceed the limitation. (See (1) and (2) on the left.) Check (2) - (3) on the left.
	Number of units Total number of indoor units	Restriction on the number of units 1 - 18 : P72 model 1 - 24 : P96 model 1 - 30 : P120 model 1 - 36 : P144 model 1 - 42 : P168 model 1 - 48 : P192 model 2 - 50 : P216 model 2 - 50 : P240 model 2 - 50 : P264 model	 Check whether the transmission line for the terminal block for centralized control (TB7) is not connected to the terminal block for the indoor/outdoor transmission line (TB3). Check the setting for the model selection switch on the outdoor unit (Dipswitches SW5-7 on the outdoor unit control board).
	Number of BC controllers Number of Main BC controllers	2 - 50 : P288 model 1 (P72- P144 models only) 0 or 1	
	Number of Sub BC controllers Total number of LOSSNAY units (During auto address start-up only)	0,1 or 2 0 or 1	
	Total number of outdoor units	1 : P72 - P144 models 2 : P168 - P288 models	
	(2) Disconnected trans unit or BC controlle	mission line from the outdoor r	
	appear. ∙ME remote contro	oply, the following display will siller on the remote controller bewered.	
		n switch (SW5-7) on the out- FF. (Normally set to ON)	
		the same refrigerant circuit do	
	connected to a syst larger models of un than the HA type is	er than the GA or HA type is em that consists of P168 or its OR a BC controller other used as the main controller in sts of P264 or larger models of	

7105

Address setting error

2. Error definition and error detection method

Erroneous setting of OC unit address Erroneous setting of BC controller address

3. Cause, check method and remedy

Error source	Cause	Check method and remedy
Outdoor unit BC controller	Erroneous setting of OC unit address The address of outdoor unit is not being set to 51 - 100. The address of BC controller is not set to 51 - 100.	Check that the outdoor unit and BC controller addresses are set to 00 or a number between 51 and 100. If the outdoor unit address is out of the valid range, reset the address with the power to the outdoor unit turned off. If the BC controller address is out of the valid range, reset the address with the power to both the outdoor unit and BC controller turned off.

1. Error Code

7106

Attribute setting error

2. Error definition and error detection method

Error source	Cause	Check method and remedy				
-	A remote controller for use with indoor units, such as the MA remote controller, is connected to the OA processing unit whose attribute is FU.	To operate the OA processing unit directly via a remote controller for use with indoor units, such as the MA remote controller, set the DIP SW 3-1 on the OA processing unit to ON.				
		Operation Method SW3-1				
		Interlocked operation with the indoor unit OFF				
		Direct operation via the MA remote controller ON				

7107

Port setting error

2. Error definition and error detection method

The port with wrong number is connected to the indoor unit. The model total connected to the port is greater than the specification.

3. Cause, check method and remedy

Error source		Cause	Check method and remedy		
BC controller	(1)	Model total of indoor units per each port or per each port merge is greater than the specification. Total port number Model total Single branching 54 2 branches merge 96	Before resetting the port number using the port number setting switch or the model using the model (capacity code) setting switch, turn off the power of the outdoor unit, the BC controller and the indoor unit.		
	(2)	4 or more indoor units are connected to the same port.			
	(3)	When two ports are used, the port with the smaller number is not connected to the indoor unit.			
	(4)	For the address of the BC controller (Sub 1 or 2), 50 is not added to the smallest indoor unit address, which is connected to the BC controller (Sub1 or 2).			
	(5)	In the system to which multiple BC controllers are connected, the indoor unit address connected to the BC controller is not set as shown below. (i) The indoor unit address which is connected to the BC controller (main) (ii) The indoor unit address which is connected to the BC controller (Sub1) (iii) he indoor unit address which is connected to the BC controller (Sub2) Address setting (i)<(ii)<(iii) *(ii) and (iii) can be reversed.			
		Is there a BC controller (Sub)? NO Are 4 or more indoor units connected to the same port? NO Is the model total of indoor units connected to the same port units connected to the same port greater than the item (1)? NO Adjust the piping connection to the port.	For the address of the BC controller (Sub.) is 50 added to the smallest indoor unit address, which is connected to the BC controller (Sub.)? YES Change the BC controller (Sub.) address. Is the address of the indoor unit, which is connected to the the BC controller (Main) smaller than that of the indoor, which is connected to the BC controller (Sub.) address or connected to the BC controller (Sub.) address or connected to the BC controller address or connected to the BC controller (Sub.) address or connected to the BC controller address or connected to the BC controll		
		When two ports are used, Is the port with the smallest number connected to the indoor unit? NO The wrong model (capacity code) is set. Change the port No. Change the port No. Adjust the piping connection to the port.	YES Is the address of the indoor unit, which is connected to the the Bot controller (Main), smaller than that of the indoor, which is connected to the BC controller (Sub 1 or 2)? YES		

7110

Connection information signal transmission/reception error

2. Error definition and error detection method

The given indoor unit is inoperable because it is not properly connected to the outdoor unit in the same system.

3. Error source, cause, check method and remedy

Error source	Cause			Check method and remedy
Outdoor unit	(1)	Power to the transmission booster is cut off.	1)	Confirm that the power to the transmission booster is not cut off by the booster being connected to the switch on the indoor unit. (The unit will not function properly unless the transmission booster is turned on.)
	(2)	Power resetting of the transmission booster and outdoor unit.		->Reset the power to the outdoor unit.
	(3)	Wiring failure between OC and OS	2)	Confirm that the TB3 on the OC and OS are properly connected.
	(4)	Broken wire between OC and OS.		Check the model selection switch on the out-
	(5)	The model selection switch (SW5-7) on the outdoor unit is set to OFF. (Normally set to ON)		door unit (Dipswitch SW5-7 on the control board.).

1. Error Code



Remote controller sensor fault

2. Error definition and error detection method

This error occurs when the temperature data is not sent although the remote controller sensor is specified.

Error source	Cause	Check method and remedy
Indoor unit OA process- ing unit	The remote controller without the temperature sensor (the wireless remote controller or the ME compact remote controller (mounted type)) is used and the remote controller sensor for the indoor unit is specified. (SW1-1 is ON.)	Replace the remote controller with the one with built-in temperature sensor.

7113

Function setting error (incorrect resistor connection)

Error source		Cause		Check method and remedy
Outdoor unit	(1)	Wiring fault	(Det	ail code 15)
	(2)	Loose connectors, short-circuit, contact failure	1)	Check the connector CNTYP5 on the control board for proper connection.
			(Det	ail code 14)
	board (Incompatible control board and INV board (replacement with a wrong cir-	1)	Check the connector CNTYP4 on the control board for proper connection.
		cuit board)	2)	Check the connector CNTYP5 on the control board for proper connection.
	(4)	DIP SW setting error on the control board	3)	Check the settings of SW5-1 through SW5-4 on the control board.
			(Det	ail code 12)
			1)	Check the connector CNTYP2 on the control board for proper connection.
			2)	Check the connector CNTYP5 on the control board for proper connection.
			3)	Check the connector CNTYP4 on the control board for proper connection.
			4)	Check the settings of SW5-1 through SW5-4 on the control board.
			(Det	ail code 16)
			1)	Check the connector CNTYP on the INV board for proper connection.
			2)	Check the connector CNTYP5 on the control board for proper connection.
			3)	Check the connector CNTYP4 on the control board for proper connection.
			4)	Check the settings of SW5-1 through SW5-4 on the control board.
			5)	Check the wiring between the control board and INV board. (Refer to the section on Error code 0403.)
			(Det	ail code 00, 01, 05)
			1)	Check the wiring between the control board and INV board. (Refer to the section on Error code 0403.)
			2)	Check the settings of SW5-1 through SW5-4 on the control board.
			3)	Check the connector CNTYP5 on the control board for proper connection.
			4)	Check the connector CNTYP4 on the control board for proper connection.
			(Det	ail code Miscellaneous)
				*If a set-model-name identification error occurs, check the detail code on the unit on which the error occurred. The detail code that appears on other units will be dif- ferent from the ones shown above.

7117

Model setting error

Error source		Cause		Check method and remedy
Outdoor unit	(1)	Wiring fault	(Det	tail code 15)
	(2)	Loose connectors, short-circuit, contact failure	1)	Check the connector CNTYP5 on the control board for proper connection.
			(Det	tail code 14)
			1)	Check the connector CNTYP4 on the control board for proper connection.
			(Det	tail code 12)
			1)	Check the connector CNTYP2 on the control board for proper connection.
			2)	Check the connector CNTYP5 on the control board for proper connection.
			(Det	tail code 16)
			1)	Check the connector CNTYP on the INV board for proper connection.
			2)	Check the connector CNTYP5 on the control board for proper connection.
			3)	Check the connector CNTYP4 on the control board for proper connection.
			4)	Check the wiring between the control board and INV board. (Refer to the section on Error code 0403.)
			(Det	tail code 00, 01, 05)
			1)	Check the wiring between the control board and INV board. (Refer to the section on Error code 0403.)
			2)	Check the settings of SW5-1 through SW5-4 on the control board.
			3)	Check the connector CNTYP5 on the control board for proper connection.
			4)	Check the connector CNTYP4 on the control board for proper connection.
			(Det	tail code Miscellaneous)
				*If a set-model-name identification error occurs, check the detail code on the unit on which the error occurred. The detail code that appears on other units will be dif- ferent from the ones shown above.



Incompatible unit combination

2. Error definition and error detection method

The check code will appear when the indoor units for use with a different type of refrigerant or incompatible units are connected.

Error source	Cause	Check method and remedy
Outdoor unit	The connected indoor unit or BC controller is exclusively for use with R22 or R407C. An incompatible indoor unit or BC controller is connected. The M-NET connection adapter is connected to the indoor unit system in a system in which the Slim Model (A control) of units are connected to the M-NET. Incompatible units are connected.	Check the model names of the connected indoor unit and the BC controller. Check whether the connecting adapter for M-NET is not connected to the indoor unit. (Connect the connecting adapter for M-NET to the outdoor unit.)

-1- Troubleshooting according to the remote controller malfunction or the external input error In the case of MA remote controller

1. Phenomena

Even if the operation button on the remote controller is pressed, the display remains unlit and the unit does not start running.(Power indicator © does not appear on the screen.)

(1) Cause

- 1) The power is not supplied to the indoor unit.
 - •The main power of the indoor unit is not on.
 - •The connector on the indoor unit board has come off.
 - *The fuse on the indoor unit board has melted.
 - Transformer failure and disconnected wire of the indoor unit.
- 2) Incorrect wiring for the MA remote controller
 - *Disconnected wire for the MA remote controller or disconnected line to the terminal block.
 - *Short-circuited MA remote controller wiring
 - •Incorrect wiring of the MA remote controller cables
 - •Incorrect connection of the MA remote wiring to the terminal block for transmission line (TB5) on the indoor unit
 - •Wiring mixup between the MA remote controller cable and power supply cable
 - *Reversed connection of the wire for the MA remote controller and the M-NET transmission line on the indoor unit
- 3) The number of the MA remote controllers that are connected to an indoor unit exceeds the allowable range (2 units).
- 4) The length or the diameter of the wire for the MA remote controller are out of specification.
- 5) Short circuit of the wire for the remote display output of the outdoor unit or reversed polarity connection of the relay.
- 6) The indoor unit board failure
- 7) MA remote controller failure

- 1) Measure voltages of the MA remote controller terminal (among 1 to 3).
 - •If the voltage is between DC 9 and 12V, the remote controller is a failure.
 - •If no voltage is applied, check the causes 1) and 3) and if the cause is found, correct it. If no cause is found, refer to 2).
- 2) Remove the wire for the remote controller from the terminal block (TB15) on the MA remote controller for the indoor unit, and check voltage among 1 to 3.
 - •If the voltage is between DC 9 and 12 V, check the causes 2) and 4) and if the cause is found, correct it.
 - *If no voltage is applied, check the cause 1) and if the cause is found, correct it.
 - If no cause is found, check the wire for the remote display output (relay polarity).
 - If no further cause is found, replace the indoor unit board.

2. Phenomena


When the remote controller operation SW is turned on, the operation status briefly appears on the display, then it goes off, and the display lights out immediately, and the unit stops.

(1) Cause

- 1) The power for the M-NET transmission line is not supplied from the outdoor unit.
- 2) Short circuit of the transmission line.
- 3) Incorrect wiring of the M-NETtransmission line on the outdoorunit.
 - *Disconnected wire for the MA remote controller or disconnected line to the terminal block.
 - •The indoor transmission line is connected incorrectly to the transmission terminal block for centralized controller (TB7).
 - •The male power supply connectors on the multiple outdoor units are connected to the female power supply switch connector (CN40).
 - In the system to which the power supply unit for transmission lines is connected, the male power supply connector is connected to the female power supply switch connector (CN40) on the outdoor unit.
- 4) Disconnected M-NET transmission line on the indoor unit side.
- 5) Disconnected wire between the terminal block for M-NET line (TB5) of the indoor unit and the indoor unit board (CN2M) or disconnected connector.

(2) Check method and remedy

1) When 2) and 3) above apply, check code 7102 will be displayed on the self-diagnosis LED.



Refer to section IX [4] -8- (2) Troubleshooting transmission power circuit of outdoor unit for how to check the first item in the flowchart above.(page 329)(page 332)

3. Phenomena


"HO" or "PLEASE WAIT" display on the remote controller does not disappear, and no operation is performed even if the button is pressed. ("HO" or "PLEASE WAIT" display will normally turn off 5 minutes later after the power on.)

(1) Cause

- 1) The power for the M-NET transmission line is not supplied from the outdoor unit.
- 2) Short-circuited transmission line
- 3) Incorrect wiring of the M-NET transmission line on the outdoor unit.
 - *Disconnected wire for the MA remote controller or disconnected line to the terminal block.
 - •The indoor transmission line is connected incorrectly to the transmission terminal block for centralized controller (TB7).
 - •The male power supply connectors on the multiple outdoor units are connected to the female power supply switch connector (CN40).
 - In the system to which the power supply unit for transmission lines is connected, the male power supply connector is connected to the female power supply switch connector (CN40) on the outdoor unit
- 4) Disconnected M-NET transmission line on the indoor unit.
- 5) Disconnected wire between the terminal block for M-NET line (TB5) of the indoor unit and the indoor unit board (CN2M) or disconnected connector.
- 6) Incorrect wiring for the MA remote controller
 - Short-circuited wire for the MA remote controller
 - *Disconnected wire for the MA remote controller (No.2) and disconnected line to the terminal block.
 - *Reversed daisy-chain connection between groups
 - •Incorrect wiring for the MA remote controller to the terminal block for transmission line connection (TB5) on the indoor unit
- •The M-NET transmission line is connected incorrectly to the terminal block (TB13) for the MA remote controller.
- The sub/main setting of the MA remote controller is set to sub.
- 8) 2 or more main MA remote controllers are connected.
- 9) Indoor unit board failure (MA remote controller communication circuit)
- 10) Remote controller failure
- 11) Outdoor unit failure (Refer to IX [8] Troubleshooting Using the Outdoor Unit LED Error Display.)(page 353)

(2) Check method and remedy


1) When 2) and 3) above apply, check code 7102 will be displayed on the self-diagnosis LED.



Refer to section IX [4] -8- (2) Troubleshooting transmission power circuit of outdoor unit for how to check the first item in the flowchart above.(page 329)(page 332)

Flow chart

Even if the operation button on the remote controller is pressed, the indoor and the outdoor units do not start running.



1. Phenomena

Even if the operation button on the remote controller is pressed, the display remains unlit and the unit does not start running. (Power indicator © does not appear on the screen.)

(1) Cause

- 1) The power for the M-NET transmission line is not supplied from the outdoor unit.
- 2) Short circuit of the transmission line.
- 3) Incorrect wiring of the M-NET transmission line on the outdoor unit.
 - •Disconnected wire for the MA remote controller or disconnected line to the terminal block.
 - •The indoor transmission line is connected incorrectly to the transmission terminal block for centralized controller (TB7).
- 4) Disconnected transmission line on the remote controller.
- 5) Remote controller failure
- 6) Outdoor unit failure (Refer to IX [8] Troubleshooting Using the Outdoor Unit LED Error Display.)(page 353)

- 1) Check voltage of the transmission terminal block for of the ME remote controller.
 - •If voltage between is 17V and 30V -> ME remote controller failure
- When voltage is 17V or less -> Refer to IX [4] -8- (2) " Troubleshooting transmission power circuit of outdoor unit".
 2) When 2) and 3) above apply, check code 7102 will be displayed on the self-diagnosis LED.


2. Phenomena

When the remote controller operation SW is turned on, a temporary operation display is indicated, and the display lights out immediately.

(1) Cause

- 1) The power is not supplied to the indoor unit.
 - •The main power of the indoor unit (AC208/230V) is not on.
 - *The connector on the indoor unit board has come off.
 - •The fuse on the indoor unit board has melted.
 - •Transformer failure and disconnected wire of the indoor unit
 - •The indoor unit board failure
- 2) The outdoor control board failure

As the indoor unit does not interact with the outdoor unit, the outdoor unit model cannot be recognized.



*1. Refer to the parts catalog "transformer check".

3. Phenomena

"HO" display on the remote controller does not disappear, and no operation is performed even if the button is pressed.

(1) Cause

Without using MELANS

- 1) Outdoor unit address is set to "00"
- 2) A wrong address is set.
 - •The address of the indoor unit that is connected to the remote controller is incorrect. (It should equal the ME remote controller address plus 100.)
 - *A wrong address is set to the ME remote controller. (100 must be added to the address of the indoor unit.)
- 3) Faulty wiring of the terminal block for transmission line (TB5) of the indoor unit in the same group with the remote controller.
- 4) The centralized control switch (SW2-1) on the outdoor unit is set to ON.
- 5) Disconnection or faulty wiring of indoor unit transmission line.
- 6) Disconnection between the terminal block for M-NET line connection (TB5) of the indoor unit and the male connector (CN2M)
- 7) The male power supply connectors on 2 or more outdoor units are connected to the female power supply switch connector (CN40) for the transmission line for centralized control.
- 8) Outdoor unit control board failure
- 9) Outdoor unit control board failure
- 10) Remote controller failure


Interlocking control with MELANS

- 1) No group registration is made using MELANS. (The indoor unit and the ME remote controller are not grouped.)
- 2) Disconnected transmission line for centralized control (TB7) of the outdoor unit
- 3) The male power supply connector is connected to CN40 on more than one outdoor unit, or the connector is connected to CN40 on the outdoor unit in the system to which a power supply unit for transmission line is connected.

Using MELANS

When MELANS is used, "HO" display on the remote controller will disappear when the indoor unit and the local remote controller (ME remote controller) are grouped.

If "HO" does not disappear after the registration, check the causes (2) 1) - 3).



^{*1.} When the indoor unit address is set to 1 - 50, the address will be forcibly set to 100.

4. Phenomena

"88" appears on the remote controller when the address is registered or confirmed.

(1) Cause, check method and remedy

Cause			Check method and remedy	
An error occurs when the address is registered or confirmed. (common)				
1.	A wrong address is set to the unit to be coupled.	(1)	Confirm the address of unit to be coupled.	
2.	The transmission line of the unit to be coupled is disconnected or is not connected.	(2)	Check the connection of transmission line.	
3.	Circuit board failure of the unit to be coupled	(3)	Check voltage of the terminal block for transmission line of the unit to be coupled.	
		1)	Normal if voltage is between DC17 and 30V.	
4.	Improper transmission line work	2)	Check (5) in case other than 1).	
Generates at interlocking registration between LOSS-NAY and the indoor unit				
5.	The power of LOSSNAY is OFF.	(4)	Check for the main power of LOSSNAY.	
Generates at confirmation of controllers used in the system in which the indoor units connected to different outdoor units are grouped				
6.	The power of the outdoor unit to be confirmed has been cut off.	(5)	Check the power supply of the outdoor unit which is coupled with the unit to be confirmed.	
7.	Transmission line is disconnected from the terminal block for central control system connection (TB7) on the outdoor unit.	(6)	Check that the transmission line for centralized control (TB7) of the outdoor unit is not disconnected.	
8.	When the indoor units connected to different outdoor units are grouped without MELANS, the male power supply connector is not connected to the female power supply switch connector (CN40) for the transmission line for centralized control.	(7)	Check voltage of the transmission line for centralized control.	
9.	The male power supply connectors on 2 or more outdoor units are connected to the female power supply switch connector (CN40) for the transmission line for centralized control.	1)	Normal when voltage is between 10V and 30V	
10.	In the system to which MELANS is connected, the male power supply connector is connected to the female power supply switch connector (CN40) for the transmission line for centralized control.	2)	Check 8 - 11 described on the left in case other than 1).	
11.	Short circuit of the transmission line for centralized control			

Both for MA remote controller and ME remote controller

1. Phenomena

Although cooling operation starts with the normal remote controller display, the capacity is not enough

(1) Cause, check method and remedy

	Cause		Check method and remedy
1.	Compressor frequency does not rise sufficiently. Faulty detection of pressure sensor. Protection works and compressor frequency does not rise due to high discharge temperature Protection works and compressor frequency does not rise due to high pressure Pressure drops excessively.	(1) Note:	Check pressure difference between the detected pressure by the pressure sensor and the actual pressure with self-diagnosis LED. -> If the accurate pressure is not detected, check the pressure sensor. (Refer to the page on Trouble-shooting of Pressure Sensor). Lower inlet pressure by the low pressure sensor than the actual pressure sensor insufficient capacitation.
			than the actual pressure causes insufficient capacity. SW1 setting
			High pressure sensor SW1 ON 1 2 3 4 5 6 7 8 9 10 Low pressure sensor
			SW1 1 2 3 4 5 6 7 8 9 10 ON
		(2)	Check temperature difference between the evaporating temperature (Te) and the target evaporating temperature (Tem) with self-diagnosis LED.
		Note:	Higher Te than Tem causes insufficient capacity. SW1 setting
			Evaporating temperature Te SW1 1 2 3 4 5 6 7 8 9 10 ON ON
			Target evaporating temperature Tem SW1 1 2 3 4 5 6 7 8 9 10 ON
		Note:	Protection works and compressor frequency does not rise even at higher Te than Tem due to high dis- charge temperature and high pressure. At high discharge temperature: Refer to 1102.(page 201) At high pressure: Refer to 1302.(page 203)
2.	Indoor unit LEV malfunction		Refer to the page of LEV troubleshooting ([4] -5-
	 Insufficient refrigerant flows due to LEV malfunction (not enough opening) or protection works and compressor frequency does not rise due to pressure drop. Refrigerant leak from LEV on the stopping unit).(page 297)
	causes refrigerant shortage on the running unit.		
3.	RPM error of the outdoor unit FAN Motor failure or board failure, or airflow rate decrease due to clogging of the heat exchanger The fan is not properly controlled as the outdoor temperature cannot be precisely detected by the temperature sensor. The fan is not properly controlled as the pressure		Refer to the page on troubleshooting of the outdoor unit fan. Refer to 5106.(page 234) Refer to 1302.(page 203)
	cannot be precisely detected by the pressure sensor.		

	Cause	Check method and remedy
4.	Long piping length The cooling capacity varies greatly depending on the pressure loss. (When the pressure loss is large, the cooling capacity drops.)	Check the piping length to determine if it is contributing to performance loss. Piping pressure loss can be estimated from the temperature difference between the indoor unit heat exchanger outlet temperature and the satura-
5.	Piping size is not proper (thin)	tion temperature (Te) of 63LS>Correct the piping.
6.	Insufficient refrigerant amount Protection works and compressor frequency does not rise due to high discharge temperature.	Refer to 1-1. (Compressor frequency does not rise sufficiently.)(page 280) Refer to the page on refrigerant amount adjustment(page 171)
7.	Clogging by foreign object	Check the temperature difference between in front of and behind the place where the foreign object is clogging the pipe (upstream side and downstream side). When the temperature drops significantly, the foreign object may clog the pipe. -> Remove the foreign object inside the pipe.
8.	The indoor unit inlet temperature is excessively. (Less than 15°C [59°F] WB)	Check the inlet air temperature and for short cycling. Change the environment where the indoor unit is used.
9.	Compressor failure The amount of circulating refrigerant decreases due to refrigerant leak in the compressor.	Check the discharge temperature to determine if the refrigerant leaks, as it rises if there is a leak.
10.	LEV3 malfunction Sufficient liquid refrigerant is not be supplied to the indoor unit as sufficient sub cool cannot be secured due to LEV3 malfunction.	Refer to the page of LEV troubleshooting ([4] -5-).(page 297) It most likely happens when there is little difference or no difference between TH12 and TH15.
11.	TH12, TH15 and 63HS1 sensor failure or faulty wiring LEV3 is not controlled normally.	◆Check the thermistor. ◆Check wiring.

2. Phenomena

Although heating operation starts with the normal remote controller display, the capacity is not enough.

(1) Cause, check method and remedy

	Cause		Check method and remedy
1.	Compressor frequency does not rise sufficiently. •Faulty detection of pressure sensor. •Protection works and compressor frequency does not rise due to high discharge temperature •Protection works and compressor frequency does not rise due to high pressure.	(1)	Check pressure difference between the detected pressure by the pressure sensor and the actual pressure with self-diagnosis LED. -> If the accurate pressure is not detected, check the pressure sensor.(Refer to the page on Trouble-shooting of Pressure Sensor)
		Note:	Higher inlet pressure by the high pressure sensor than the actual pressure causes insufficient capacity. SW1 setting
			High pressure sensor SW1 1 2 3 4 5 6 7 8 9 10 ON ON
			Low pressure sensor SW1 1 2 3 4 5 6 7 8 9 10 ON
		(2)	Check the difference between the condensing temperature (Tc) and the target condensing temperature (Tcm) with self-diagnosis LED.
		Note:	Higher Tc than Tcm causes insufficient capacity. SW1 setting
			Condensing temperature Tc SW1 1 2 3 4 5 6 7 8 9 10 ON Target condensing temperature Tcm SW1 1 2 3 4 5 6 7 8 9 10 ON ON ON SW1 1 2 3 4 5 6 7 8 9 10 ON
		Note:	Protection works and compressor frequency does not rise even at lower Tc than Tcm due to high discharge temperature and high pressure. At high discharge temperature: Refer to 1102.(page 201) At high pressure: Refer to 1302.(page 203)

	Cause	Check method and remedy
2.	Indoor unit LEV malfunction Insufficient refrigerant flows due to LEV malfunction (not enough opening).	Refer to the page of LEV troubleshooting ([4] -5-).(page 297)
3.	Temperature reading error on the indoor unit piping temperature sensor If the temperature reading on the sensor is higher than the actual temperature, it makes the subcool seem smaller than it is, and the LEV opening decreases too much.	Check the thermistor.
4	RPM error of the outdoor unit FAN	Refer to the page on outdoor unit fan ([4] -4-
	 Motor failure or board failure, or airflow rate decrease, pressure drop due to clogging of the heat exchanger leading to high discharge temperature The fan is not properly controlled as the temperature cannot be precisely detected with the piping sensor.).(page 295)
5.	Insulation failure of the refrigerant piping	
6.	Long piping length Excessively long piping on the high pressure side causes pressure loss leading to increase in the high pressure.	Confirm that the characteristic of capacity drop due to piping length> Change the pipe
7.	Piping size is not proper (thin)	
8.	Clogging by foreign object	Check the temperature difference between the upstream and the downstream of the pipe section that is blocked. Since blockage in the extended section is difficult to locate, operate the unit in the cooling cycle, and follow the same procedures that are used to locate the blockage of pipe during cooling operation. ->Remove the blockage in the pipe.
9.	The indoor unit inlet temperature is excessively high.(exceeding 28°C [82°F])	Check the inlet air temperature and for short cycling. Change the environment where the indoor unit is used.
10.	Insufficient refrigerant amount Protection works and compressor frequency does not rise due to low discharge temperature Refrigerant recovery operation is likely to start.	Refer to 2 - 1. (Compressor frequency does not rise sufficiently.)(page 282) Refer to the page on refrigerant amount adjustment.(page 171)
11.	Compressor failure (same as in case of cooling)	Check the discharge temperature.
12.	LEV3 actuation failure A drop in the low pressure that is caused either by a blockage of liquid pipe or by a pressure loss and the resultant slowing of refrigerant flow causes a tendency for the discharge temperature to rise.	Refer to the page on troubleshooting the LEV ([4] - 5-).(page 297)

3. Phenomena

Outdoor unit stops at times during operation.

(1) Cause, check method and remedy

	Cause		Check method and remedy
	The first stop is not considered as an error, as the unit turns to anti-restart mode for 3 minutes as a preliminary error.	(1)	Check the mode operated in the past by displaying preliminary error history on LED display with SW1.
	Error mode	(2)	Reoperate the unit to find the mode that stops the
1)	Abnormal high pressure		unit by displaying preliminary error history on LED display with SW1.
2)	Abnormal discharge air temperature		-> Refer to the reference page for each error mode.
3)	Heatsink thermistor failure		*Display the indoor piping temperature table with
4)	Thermistor failure		SW1 to check whether the freeze proof operation runs properly, and check the temperature.
5)	Pressure sensor failure		
6)	Over-current break		
7)	Refrigerant overcharge		
Note1:	Frost prevention tripping only under cooling mode may be considered in addition to the above. (Freeze protection is detected by one or all indoor units.)		
Note2:	Even the second stop is not considered as an error when some specified errors occur. (eg. The third stop is considered as an error when the thermistor error occurs.)		

[3] Investigation of Transmission Wave Shape/Noise


1. M-NET transmission

Control is performed by exchanging signals between the outdoor unit and the indoor unit (ME remote controller) through M-NET transmission. Noise interference on the transmission line will interrupt the normal transmission, leading to erroneous operation.

(1) Symptoms caused by noise interference on the transmission line

Cause	Erroneous operation	Error code	Error code definition
	Signal is transformed and will be misjudged as the signal of another address.	6600	Address overlap
	Transmission wave pattern is transformed due to the noise creating a new signal	6602	Transmission processor hardware error
Noise interference on the transmission line	Transmission wave pattern is transformed due to the noise, and will not be received normally leading to no acknowledgement (ACK).	6607	No ACK error
	Transmission cannot be performed due to the fine noise.	6603	Transmission line bus busy error
	Transmission is successful; however, the acknowledgement (ACK) or the response cannot be received normally due to the noise.	6607 6608	No ACK error No response error

(2) Wave shape check



Wave shape check

Check the wave pattern of the transmission line with an oscilloscope. The following conditions must be met.

- Small wave pattern (noise) must not exist on the transmission signal. (Minute noise (approximately 1V) can be generated by DC-DC converter or the inverter operation; however, such noise is not a problem when the shield of the transmission line is grounded.)
- 2) The sectional voltage level of transmission signal should be as follows.

Logic	Voltage level of the transmission line
0	V _{HL} = 2.5V or higher
1	V _{BN} = 1.3V or below

(3) Check method and remedy

1) Measures against noise

Check the followings when noise exists on the wave or the errors described in (1) occur.

		Error code definition	Remedy
Check that the wiring work is performed according to wiring specifications.	1.	The transmission line and the power line are not wired too closely.	Isolate the transmission line from the power line (5cm [1-31/32"] or more). Do not insert them in the same conduit.
specifications.	2.	The transmission line is not bundled with that for another systems.	The transmission line must be isolated from another transmission line. When they are bundled, erroneous operation may be caused.
	3.	The specified wire is used for the transmission line.	Use the specified transmission line. Type: Shielded wire CVVS/CPEVS/MVVS (For ME remote controller) Diameter: 1.25mm ² [AWG16] or more (Remote controller wire: 0.3 - 1.25mm ² [AWG22-16])
	4.	When the transmission line is daisy-chained on the indoor unit terminals, are the shields daisy-chained on the terminals, too?	The transmission is two-wire daisy-chained. The shielded wire must be also daisy-chained. When the shielded cable is not daisy-chained, the noise cannot be reduced enough.
Check that the grounding work is performed according to grounding specifications.	5.	Is the shield of the indoor- outdoor transmission ca- ble grounded to the earth terminal on the outdoor unit?	Connect the shield of the indoor-outdoor transmission cable to the earth terminal (h) on the outdoor unit. If no grounding is provided, the noise on the transmission line cannot escape leading to change of the transmission signal.
	6.	Check the treatment method of the shield of the transmission line (for centralized control).	The transmission cable for centralized control is less subject to noise interference if it is grounded to the outdoor unit whose power jumper cable was moved from CN41 to CN40 or to the power supply unit. The environment against noise varies depending on the distance of the transmission lines, the number of the connected units, the type of the controllers to be connected, or the environment of the installation site. Therefore, the transmission line work for centralized control must be performed as follows.
			When no grounding is provided: Ground the shield of the transmission cable by connecting to the outdoor unit whose power jumper connector was moved from CN41 to CN40 or to the power supply unit.
			When an error occurs even though one point grounding is provided: Ground the shield on all outdoor units.

2) Check the followings when the error "6607" occurs, or "HO" appears on the display on the remote controller.

	Error code definition	Remedy
7.	The farthest distance of transmission line is 200m [656ft] or longer.	Check that the farthest distance from the outdoor unit to the indoor unit and to the remote controller is within 200m [656ft].
8.	The types of transmission lines are different.	Use the specified transmission line. Type: Shielded wire CVVS/CPEVS/MVVS (For ME remote controller) Diameter: 1.25mm ² [AWG16] or more (Remote controller wire: 0.3-1.25mm ² [AWG22-16])
9.	Outdoor unit circuit board failure	Replace the outdoor unit control board or the power supply board for the transmission line.
10.	Indoor unit circuit board failure or remote controller failure	Replace the indoor unit circuit board or the remote controller.
11.	The MA remote controller is connected to the M-NET transmission line.	Connect the MA remote controller to the terminal block for MA remote controller (TB15).


2. MA remote controller transmission


The communication between the MA remote controller and the indoor unit is performed with current tone burst.

(1) Symptoms caused by noise interference on the transmission line

If noise is generated on the transmission line, and the communication between the MA remote controller and the indoor unit is interrupted for 3 minutes in a row, MA transmission error (6831) will occur.

(2) Confirmation of transmission specifications and wave pattern






[4] Troubleshooting Principal Parts

-1- High-Pressure Sensor (63HS1, PS1, PS3)

Compare the pressure that is detected by the high pressure sensor, and the high-pressure gauge pressure to check for failure.

By configuring the digital display setting switch (SW1) as shown in the figure below, the pressure as measured by the high-pressure sensor appears on the LED1 on the control board.



(1) While the sensor is stopped, compare the gauge pressure and the pressure displayed on self-diagnosis LED1.

- 1) When the gauge pressure is between 0 and 0.098MPa [14psi], internal pressure is caused due to gas leak.
- 2) When the pressure displayed on self-diagnosis LED1 is between 0 and 0.098MPa [14psi], the connector may be defective or be disconnected. Check the connector and go to (4).
- 3) When the pressure displayed on self-diagnosis LED1 exceeds 4.15MPa [601psi], go to (3).
- 4) If other than 1), 2) or 3), compare the pressures while the sensor is running. Go to (2).

(2) Compare the gauge pressure and the pressure displayed on self-diagnosis LED1 while the sensor is running. (Compare them by MPa [psi] unit.)

- 1) When the difference between both pressures is within 0.098MPa [14psi], both the high pressure sensor and the control board are normal.
- When the difference between both pressures exceeds 0.098MPa [14psi], the high pressure sensor has a problem. (performance deterioration)
- 3) When the pressure displayed on self-diagnosis LED1 does not change, the high pressure sensor has a problem.
- (3) Remove the high pressure sensor from the control board to check the pressure on the self-diagnosis LED1.
- 1) When the pressure displayed on self-diagnosis LED1 is between 0 and 0.098MPa [14psi], the high pressure sensor has a problem.
- 2) When the pressure displayed on self-diagnosis LED1 is approximately 4.15MPa [601psi], the control board has a problem.
- (4) Remove the high pressure sensor from the control board, and short-circuit between the No.2 and 3 connectors (63HS1, PS1, PS3) to check the pressure with self-diagnosis LED1.
- 1) When the pressure displayed on the self-diagnosis LED1 exceeds 4.15MPa [601psi], the high pressure sensor has a problem.
- 2) If other than 1), the control board has a problem.


2. Pressure sensor configuration


The high pressure sensor consists of the circuit shown in the figure below. If DC 5V is applied between the red and the black wires, voltage corresponding to the pressure between the white and the black wires will be output, and the value of this voltage will be converted by the microcomputer. The output voltage is 0.071V per 0.098MPa [14psi].

Note

The pressure sensor on the body side is designed to connect to the connector. The connector pin number on the body side is different from that on the control board side.

	Body side	Control board side			
Vcc	Pin 1	Pin 3			
Vout	Pin 2	Pin 2			
GND	Pin 3	Pin 1			






-2- Low-Pressure Sensor (63LS)

Compare the pressure that is detected by the low pressure sensor, and the low pressure gauge pressure to check for failure.

By configuring the digital display setting switch (SW1) as shown in the figure below, the pressure as measured by the low-pressure sensor appears on the LED1 on the control board.



- (1) While the sensor is stopped, compare the gauge pressure and the pressure displayed on self-diagnosis LED1.
- 1) When the gauge pressure is between 0 and 0.098MPa [14psi], internal pressure is caused due to gas leak.
- 2) When the pressure displayed on self-diagnosis LED1 is between 0 and 0.098MPa [14psi], the connector may be defective or be disconnected. Check the connector and go to (4).
- 3) When the pressure displayed on self-diagnosis LED1 exceeds 1.7MPa [247psi], go to (3).
- 4) If other than 1), 2) or 3), compare the pressures while the sensor is running. Go to (2).
- (2) Compare the gauge pressure and the pressure displayed on self-diagnosis LED1 while the sensor is running.(Compare them by MPa [psi] unit.)
- 1) When the difference between both pressures is within 0.03MPa [4psi], both the low pressure sensor and the control board are normal.
- When the difference between both pressures exceeds 0.03MPa [4psi], the low pressure sensor has a problem. (performance deterioration)
- 3) When the pressure displayed on the self-diagnosis LED1 does not change, the low pressure sensor has a problem.
- (3) Remove the low pressure sensor from the control board to check the pressure with the self-diagnosis LED1 display.
- 1) When the pressure displayed on the self-diagnosis LED1 is between 0 and 0.098MPa [14psi], the low pressure sensor has a problem.
- 2) When the pressure displayed on self-diagnosis LED1 is approximately 1.7MPa [247psi], the control board has a problem.
 - •When the outdoor temperature is 30°C [86°F] or less, the control board has a problem.
 - •When the outdoor temperature exceeds 30°C [86°F], go to (5).
- (4) Remove the low pressure sensor from the control board, and short-circuit between the No.2 and 3 connectors (63LS:CN202) to check the pressure with the self-diagnosis LED1.
- 1) When the pressure displayed on the self-diagnosis LED1 exceeds 1.7MPa [247psi], the low pressure sensor has a problem.
- 2) If other than 1), the control board has a problem.
- (5) Remove the high pressure sensor (63HS1) from the control board, and insert it into the connector for the low pressure sensor (63LS) to check the pressure with the self-diagnosis LED1.
- 1) When the pressure displayed on the self-diagnosis LED1 exceeds 1.7MPa [247psi], the control board has a problem.
- 2) If other than 1), the control board has a problem.


2. Low-pressure sensor configuration


The low pressure sensor consists of the circuit shown in the figure below. If DC5V is applied between the red and the black wires, voltage corresponding to the pressure between the white and the black wires will be output, and the value of this voltage will be converted by the microcomputer. The output voltage is 0.173V per 0.098MPa [14psi].

Note

The pressure sensor on the body side is designed to connect to the connector. The connector pin number on the body side is different from that on the control board side.

	Body side	Control board side			
Vcc	Pin 1	Pin 3			
Vout	Pin 2	Pin 2			
GND	Pin 3	Pin 1			





-3- Solenoid Valve

Check whether the output signal from the control board and the operation of the solenoid valve match.

Setting the self-diagnosis switch (SW1) as shown in the figure below causes the ON signal of each relay to be output to the LED's. Each LED shows whether the relays for the following parts are ON or OFF. LEDs light up when relays are on.

Note

The circuits on some parts are closed when the relays are ON. Refer to the following instructions.

SW1		Display							
OWI	3,41		LD2	LD3	LD4	LD5	LD6	LD7	LD8
	Upper			CH11		SV1a		SV2	
SW1									
ON 2 3 4 5 6 7 8 9 10	Lower			21S4b	SV5b				
	Upper	SV4a	SV4b	SV4c	SV5c		SV4d	SV9	
SW1									
1 2 3 4 5 6 7 8 9 10 ON	Lower								52F

When a valve malfunctions, check if the wrong solenoid valve coil is not attached the lead wire of the coil is not disconnected, the connector on the board is not inserted wrongly, or the wire for the connector is not disconnected.

(1) In case of 21S4a, 21S4b (4-way switching valve)

About this 4-way valve

When not powered:

Conducts electricity between the oil separator outlet and heat exchanger AND the gas ball valve (BV1) and the accumulator to complete the circuit for the cooling cycle.

When powered:

The electricity runs between the oil separator and the gas ball valve, and between the heat exchanger and the accumulator. This circulation is for heating.

Check the LED display and the intake and the discharge temperature for the 4-way valve to check whether the valve has no faults and the electricity runs between where and where.Do not touch the pipe when checking the temperature, as the pipe on the oil separator side will be hot.

Note

Do not give an impact from outside, as the outer hull will be deformed leading to the malfunction of the inner valve.

(2) In case of SV1a (Bypass valve)

This solenoid valve opens when powered (Relay ON).

- 1) At compressor start-up, the SV1a turns on for 4 minutes, and the operation can be checked by the self-diagnosis LED display and the closing sound.
- 2) To check whether the valve is open or closed, check the change of the SV1a downstream piping temperature while the valve is being powered. Even when the valve is closed, high-temperature refrigerant flows inside the capillary next to the valve. (Therefore, temperature of the downstream piping will not be low with the valve closed.)

(3) In case of SV2 (Bypass valve)(P72, P96 models)


This solenoid valve opens when powered (Relay ON).


This valve turns on when low-pressure (LPS) drops to 0.25 MPa [36 psi] or below during Heating-only or Heating-main operation AND after 5 minutes have passed after compressor startup; OR when 63HS1 is above 3.5 MPa [507psi] with the SV9 turned on and SV5b turned off AND the frequency drops to the minimum.


To check whether the valve is open or closed, check the change of the SV1a downstream piping temperature while the valve is being powered. Even when the valve is closed, high-temperature refrigerant flows inside the capillary next to the valve.


(4) SV4a, 4b and 4d (P72 model), SV4a - 4d (P96, P120, P144 models)(Controls heat exchanger capacity)

- 1) Depending on the conditions during Cooling-only operation, at least one of the solenoid valves among SV4a through 4d turns on. Check for proper operation on the LED and by listening for the operation sound of the solenoid valve.
- 2) During Heating-only operation, SV4a through 4d all turn on. Check for proper operation on the LED and by listening for the operation sound of the solenoid valves.
- 3) Depending on the conditions during Cooling-main or Heating-main operation, at least one of the solenoid valves among SV4a through 4d turns on. Check for proper operation on the LED and by listening for the operation sound of the solenoid valve.
- 4) The diagram on the next page shows the refrigerant flow. This diagram shows the flow of the high-temperature (high-pressure) gas refrigerant in the Cooling-only and Cooling-main modes and the flow of the low-temperature gas/liquid refrigerant in the Heating-only and Heating-main modes. Refer to the refrigerant circuit diagram. Solenoid valves turns on and off according to such factors as the capacity of the indoor units in operation and outside temperature. Check the LED. Remove the SV coil, open the lid, and check the plunger. The type of pin face wrench that is listed in the service parts list is required to perform this task.
- 5) SV4c on the P72 and P96 models opens when energized, and the one on the P120 and P144 models closes when energized. The LED indicates the valve's opening. (It does not indicate if it is energized).























(5) In the case of SV5b (Bypass valve)

This solenoid valve closes when energized (when the relay is on).

This valve turns off for five minutes after the completion of the defrost cycle, or when SV9 is on turned ON and the value of 63HS1 is greater than 3.5 MPa [507psi] during Heating-only or Heating-main operation at the minimum frequency. The valve position can be determined by measuring and monitoring the changes in the pipe temperature on the downstream of SV5b while the unit is de-energized. When the valve is open, high-temperature gas refrigerant passes through the pipe. Do not attempt to check the pipe temperature by touching the pipe.

(6) In the case of SV5c (Bypass valve)

This solenoid valve opens when energized (when the relay is on).

This valve turns on, depending on the operating conditions during Cooling-main, Cooling-only, and defrost (P120 and P144 models only). Check for proper operation on the LED and by listening for the operation sound of the solenoid valve.

(7) In the case of SV9 (Bypass valve)


This solenoid valve opens when energized (when the relay is on)

This valve turns on when the value of 63HS1 is greater than 3.5 MPa [507psi] during Heating-only or Heating-main operation at the minimum frequency. The valve position can be determined by measuring and monitoring the changes in the pipe temperature on the downstream of SV9 while the unit is energized. When the valve is open, high-temperature gas refrigerant passes through the pipe. Do not attempt to check the pipe temperature by touching the pipe.

-4- Outdoor Unit Fan

(1) Fan motor

- •To check the revolution of the fan, check the inverter output state on the self-diagnosis LED, as the inverter on the outdoor fan controls the revolutions of the fan. The revolution of the fan is approximately 680rpm(P72 model), 790rpm(P96 model), 630rpm (P120 model), 750rpm (P144 model) at full speed.
- •When starting the fan, the fan runs at full speed for 5 seconds.
- •When setting the DIP SW1 as shown in the figure below, the inverter output [%] will appear. 100% indicates the full speed and 0% indicates the stopping.




- •As the revolution of the fan changes under control, at the interphase or when the indoor unit operation capacity is low, the revolution of the fan may change.
- •If the fan does not move or it vibrates, fan inverter board problem or fan motor problem is suspected. Refer to IX [4] -7- (2) [5] "Check the fan motor ground fault or the winding." and IX [4] -7- (2) [6] "Check the FAN board failure."

(2) Electromagnetic contactor (52F)(P120, P144 only)

- •If the outdoor unit fan is not operating correctly according to what is specified in the table below, check 52F for short-circuit. Use the flowchart to identify possible problems.
- •Check that the right and left connectors for the fan motor are connected to the appropriate connectors in the electromagnetic contactor.

Operation mode	No. of outdoor unit fans	4-way valve		Heat exchanger solenoid valve				52F
Operation mode	No. of outdoor unit fairs	21S4a	21S4b	SV4a	SV4b	SV4c	SV4d	321
Cooling-only/	1 (Left:Controller side)	OFF	OFF	OFF	OFF	ON	ON	OFF
Cooling-main	1 (Left:Controller side)	OFF	OFF	OFF	OFF	ON	OFF	OFF
	1 (Left:Controller side)	OFF	OFF	OFF	ON	ON	OFF	OFF
	2	OFF	OFF	ON	ON	ON	OFF	ON
	2	OFF	OFF	ON	ON	OFF	OFF	ON
Heating-only/	2	ON	ON	ON	ON	OFF	ON	ON
Heating-main	2	ON	ON	ON	ON	OFF	OFF	ON
Defrost	0	OFF	OFF	ON	ON	OFF	OFF	OFF

^{*}ON/OFF status shown in the table above indicates the relay output of the valve coil.



-5- LEV


LEV operation

LEV are stepping-motor-driven valves that operate by receiving the pulse signals from the indoor and outdoor unit control boards.

(1) Indoor LEV and BC controller LEV

The valve opening changes according to the number of pulses.

1) Control boards and the LEV



Note. The connector numbers on the intermediate connector and the connector on the control board differ. Check the color of the lead wire to judge the number.

2) Pulse signal output and valve operation

Output (phase)	Output state			
number	1	2	3	4
ø 1	ON	OFF	OFF	ON
φ 2	ON	ON	OFF	OFF
ø 3	OFF	ON	ON	OFF
φ 4	OFF	OFF	ON	ON


Output pulses change in the following orders when the

Valve is closed;
$$1 \rightarrow 2 \rightarrow 3 \rightarrow 4 \rightarrow 1$$

Valve is open; $4 \rightarrow 3 \rightarrow 2 \rightarrow 1 \rightarrow 4$

- *1. When the LEV opening angle does not change, all the output phases will be off.
- *2. When the output is open phase or remains ON, the motor cannot run smoothly, and rattles and vibrates.

3) LEV valve closing and opening operation



*When the power is turned on, the valve closing signal of 2200 pulses will be output from the indoor board to LEV to fix the valve position. It must be fixed at point ${\Large \textcircled{A}}$

When the valve operates smoothly, no sound from LEV or no vibration occurs, however, when the pulses change from E to A in the chart or the valve is locked, a big sound occurs.

*Whether a sound is generated or not can be determined by holding a screwdriver against it, then placing your ear against the handle.


(2) Judgment methods and possible failure mode

Malfunction mode	Judgment method	Remedy
Microcomputer driver circuit fail- ure	Disconnect the control board connector and connect the check LED as shown in the figure below.	When the drive circuit has a problem, replace the control board.
LEV mechanism is locked	If the LEV is locked, the drive motor runs idle, and makes a small clicking sound. When the valve makes a closing and opening sound, the valve has a problem.	Replace the LEV.
Disconnected or short-circuited LEV motor coil	Measure resistance between the coils (red - white, red -orange, brown - yellow, brown - blue) using a tester. They are normal if resistance is 150ohm ± 10%.	Replace the LEV coils.
Incomple sealing (leak from the valve)	When checking the refrigerant leak from the indoor LEV, run the target indoor unit in the fan mode, and the other indoor units in the cooling mode. Then, check the liquid temperature (TH22) with the self-diagnosis LED. When the unit is running in the fan mode, the LEV is fully closed, and the temperature detected by the thermistor is not low. If there is a leak, however, the temperature will be low. If the temperature is extremely low compared with the inlet temperature displayed on the remote controller, the LEV is not properly sealed, however, if there is a little leak, it is not necessary to replace the LEV when there are no effects to other parts.	If there is a large amount of leakage, replace the LEV.
Faulty wire con- nections in the connector or faulty contact	Check for loose pins on the connector and check the colors of the lead wires visually Disconnect the control board's connector and conduct a continuity check using a tester.	Check the continuity at the points where an error occurs.

-6- Troubleshooting Principal Parts of BC Controller

1. Pressure sensor

Troubleshooting flow chart for pressure sensor



Note

1) BC controller: Phenomena when the pressure sensor is connected wrongly (reverse connection of P1 and P3) to the board.

	Symptoms					
Cooling-only	Cooling	g-main	Hea	ating only	Hea	ating main
Normal	Non-cooling	SC16 small	Indoor heating SC small Heating indoor Thermo ON Especially noise is large.	00	Non-cooling Indoor heating SC small Heating indoor Thermo ON Especially noise is large.	SC11 large SC16 small △PHM large

Note

2) Check the self-diagnosis switch (Outdoor control board SW1).


Measurement data	Symbol	SW1 setting value
Outdoor high pressure	63HS1	1 2 3 4 5 6 7 8 9 10 ON
Outdoor low pressure	63LS	1 2 3 4 5 6 7 8 9 10 ON
BC controller pressure (liquid side)	PS1	1 2 3 4 5 6 7 8 9 10 ON
BC controller pressure (intermediate part)	PS3	1 2 3 4 5 6 7 8 9 10 ON

Note

- 3) Check whether CNP1 (liquid side) connector on the BC controller control board and the connector CNP2 (intermediate part) are not disconnected or not loose.
- 4) Check the pressure value on the self-diagnosis switch (same as note 2) with the connector of the applied pressure sensor is disconnected from the board.

2. Temperature sensor

Troubleshooting instructions for thermistor




Note

- 1) For the connectors on the board, TH11 and TH12 are connected to CN10, and TH15 and TH16 are connected to CN11. Disconnect the connector in trouble, and check the sensor of each number.
- 2)
- •Pull out the sensor connector from the I/O board, Do not pull the sensor by holding the lead wire.
- •Measure the resistance with such as a tester.
- *Compare the measured value with that of shown in the figure below. When the result is ± 10%, it is normal.
- 3) Check the self-diagnosis switch (Outdoor control board SW1).

	Measurement data	Symbol	SW1 setting value
	Liquid inlet temperature	TH11	1 2 3 4 5 6 7 8 9 10 ON
G, GA, HA (Standard / main)	Bypass outlet temperature	TH12	ON 1 2 3 4 5 6 7 8 9 10
	Bypass inlet temperature	TH15	1 2 3 4 5 6 7 8 9 10 ON
	Bypass inlet temperature	TH16	0 N 2 3 4 5 6 7 8 9 10
GB, HB	Bypass outlet temperature	TH12	0N 1 2 3 4 5 6 7 8 9 10
(Sub 1)	Bypass inlet temperature	TH15	0N 1 2 3 4 5 6 7 8 9 10
GB, HB	Bypass outlet temperature	TH12	0N 1 2 3 4 5 6 7 8 9 10
(Sub 2)	Bypass inlet temperature	TH15	0N 1 2 3 4 5 6 7 8 9 10

3. Troubleshooting flow chart for LEV Solenoid valve

(1) LEV



Note

1) BC controller: Phenomena when LEV is connected wrongly (reverse connection of LEV1 and LEV3) to the board.

	Phenomena				
Cooling-only	Cooling-main	Heating only	Heating main		
Non-cooling SH12 small, SC11 small SC16 small, branch pipe SC small BC controller sound	Non-cooling and non-heating SH12 small, SC11 small SC16 large, but branch pipe SC small BC controller sound △PHM large	Indoor heating SC small △ PHM large	Non-cooling Indoor heating SC small △ PHM large		


- 2) Check method of fully open state or fully closed state of LEV
 - •Check LEV opening (pulse) on the self-diagnosis LED (Outdoor control board SW1). Full open: 2000 pulses
 - Fully closed: 110 pulses (In the case of heating-only mode, however, the pulse may become 110 or more.)
 - •When LEV is fully open, measure the temperature at the upstream and downstream pipes of LEV, and make sure that there is no temperature difference.
 - •When LEV is fully closed, check that there is no refrigerant flowing sound.
- 3) Refer to the chart below to judge LEV opening controlled by the values of the differential pressure and of the superheat. (BC controller LEV basic operation characteristic)

	Part	Malfunction mode	Operation mode	Content	Standards of judgment on unit stable operation
		Inclined to close	T I I nressure (P1) and interme-		0.3 to 0.4MPa
	LEV1	Inclined to open	main Cooling- main	Difference between high pressure (P1) and intermediate pressure (P3) is small.	[44 to 58psi]
G, GA, HA	G. GA. HA		Cooling-only Cooling- main	SH12 is large.	SH12 < 20°C [36°F]
type	LEV3	Inclined to close	Heating only Heating- main	Difference between high pressure (P1) and intermediate pressure (P3) is small.	0.3 to 0.4MPa [44 to 58psi]
		Inclined to open	Cooling-only Cooling- main	SC16 and SH12 are small.	SC16 > 3°C [5.4°F] SH12 > 3°C [5.4°F]
			Heating only Heating- main	Difference between high pressure (P1) and intermediate pressure (P3) is large.	0.3 to 0.4MPa [44 to 58psi]
GB, HB	LEV3	Inclined to close	Cooling-only Cooling- main	SH22 is large.	SH22 < 20°C [36°F]
type)		Inclined to open	Cooling-only Cooling- main	SH22 is small.	SH22 > 3°C [5.4°F]


Self-diagnosis LED

	Measurement data	Symbol	SW1 setting value
	LEV1 opening	_	1 2 3 4 5 6 7 8 9 10 ON
	LEV2 opening	_	1 2 3 4 5 6 7 8 9 10 ON
G, GA, HA (Standard / main)	LEV3 opening	_	ON 1 2 3 4 5 6 7 8 9 10
	BC controller bypass outlet superheat	SH12	0N 1 2 3 4 5 6 7 8 9 10
	BC controller intermediate part subcool	SC16	ON 1 2 3 4 5 6 7 8 9 10
	BC controller liquid-side subcool	SC11	0N 1 2 3 4 5 6 7 8 9 10
GB, HB (Sub 1)	LEV3 opening	_	1 2 3 4 5 6 7 8 9 10 ON
GB, HB (Sub 2)	LEV3 opening	_	1 2 3 4 5 6 7 8 9 10 ON

Troubleshooting flow chart for solenoid valve body



(2) Solenoid valve (SVA, SVB, SVC)



Check whether the BC board output signal corresponds with the solenoid valve operation correspond.

Note

1) SVA, SVB, SVC

SVA, SVB, and SVC turn on or off according to the indoor unit operation mode.

				Mode		
		Cooling	Heating	Stopped	Defrost	Fan
	SVA	ON	OFF	OFF	OFF	OFF
Port	SVB	OFF	ON	OFF	OFF	OFF
	SVC	ON	OFF	OFF	OFF	ON

SVM1 and SVM2


SVM1 and SVM2 turn on or off according to the indoor unit operation mode.

Operation mode	Cooling only	Cooling main	Heating only	Heating main	Defrost	Stopped
SVM1	ON	Pressure dif- ferential con- trol OFF or ON	OFF	OFF	ON	OFF
SVM2	OFF	OFF	Pressure dif- ferential con- trol OFF or ON	Pressure dif- ferential con- trol OFF or ON	OFF	OFF


Note

2) SVA, SVB, SVC

Measure the temperature at the upstream and downstream pipes 1 and 2 of SVA. Measure the temperature at the upstream and downstream 1 pipes and 3 of SVB.



4. BC controller transformer



	Normal	Abnormal
CNTR(1)-(3)	about 58 ohm.	Open-phase or shorting
CN03(1)-(3)	about 1.6 ohm.	open phase of shorting

^{*} Before measuring the resistance, pull out the connector.

-7- Inverter (TJMU-A)

- •Replace only the compressor if only the compressor is found to be defective. (Overcurrent will flow through the inverter if the compressor is damaged, however, the power supply is automatically cut when overcurrent is detected, protecting the inverter from damage.)
- •Replace only the fan motor if only the fan motor is found to be defective. (Overcurrent will flow through the inverter if the fan motor is damaged, however, the power supply is automatically cut when overcurrent is detected, protecting the inverter from damage.)
- •Replace the defective components if the inverter is found to be defective.
- •If both the compressor and the inverter are found to be defective, replace the defective component(s) of both devices.

(1) Inverter-related problems: Troubleshooting and remedies

- 1) The INV board has a large-capacity electrolytic capacitor, in which residual voltage remains even after the main power is turned off, posing a risk of electric shock. Before inspecting the inverter-related items, turn off the main power, wait for 5 to 10 minutes, and confirm that the voltage at both ends of the electrolytic capacitor has dropped to a sufficiently low level.
- 2) The IPM on the inverter becomes damaged if there are loose screws are connectors. If a problem occurs after replacing some of the parts, mixed up wiring is often the cause of the problem. Check for proper connection of the wiring, screws, connectors, and Faston terminals.
- 3) To avoid damage to the circuit board, do not connect or disconnect the inverter-related connectors with the main power turned on.
- 4) Current sensors become damaged if electricity is passed through without them being connected to the circuit board. Connect the current sensor to the appropriate connectors on the circuit board before operating the inverter.
- 5) Faston terminals have a locking function. Make sure the terminals are securely locked in place after insertion.

Press the tab on the terminals to remove them.



- 6) When the IPM, diode stack, or IGBT is replaced, apply a thin layer of heat radiation grease that is supplied evenly to these parts. Wipe off any grease that may get on the wiring terminal to avoid terminal contact failure.
- 7) Faulty wiring to the compressor damages the compressor. Connect the wiring in the correct phase sequence.

	Error display/failure condition	Measure/inspection item
[1]	Inverter related errors 4250, 4255, 4220, 4225, 4230, 4240,4260, 5301, 0403	Check the details of the inverter error in the error log at X LED Monitor Display on the Outdoor Unit Board. Take appropriate measures to the error code and the error details in accordance with IX. [2] Responding to Error Display on the Remote Controller.
[2]	Main power breaker trip	<1> Check the breaker capacity.
		<2> Check whether the electrical system is short-circuited or ground-faulted.
		<3> If items cause is not <1>or <2> are not the causes of the problem, see (3)-[1].
[3]	Main power earth leakage breaker trip	<1> Check the earth leakage breaker capacity and the sensitivity current.
		<2> Meg failure for electrical system other than the inverter
		<3> If the cause is not <1>or <2>, see (3)-[1]
[4]	Only the compressor does not operate.	Check the inverter frequency on the LED monitor and proceed to (2) - [4] if the compressor is in operation.
[5]	The compressor vibrates violently at all times or makes an abnormal sound.	See (2)-[4].
[6]	Only the fan motor does not operate.	Check the inverter frequency on the LED monitor and proceed to (2)-[6] if the fan motor is in operation.
[7]	The fan motor shakes violently at all times or makes an abnormal sound.	Check the inverter frequency on the LED monitor and proceed to (2)-[6] if the fan motor is in operation.
[8]	Noise is picked up by the peripheral device	<1> Check that power supply wiring of the peripheral device does not run close to the power supply wiring of the outdoor unit.
		<2> Check that the inverter output wiring is not in close contact with the power supply wiring and the transmission lines.
		<3> Check that the shielded wire is used as the transmission line when it is required, and check that the grounding work is performed prop- erly on the shielded wire.
		<4> Meg failure for electrical system other than the inverter
		<5> Attach a ferrite core to the inverter output wiring. (Contact the factory for details of the service part settings.)
		<6> Provide separate power supply to the air conditioner and other electric appliances.
		<7> If the error occurred suddenly, a ground fault of the inverter output can be considered. See (2)-[4].
		*Contact the factory for cases other than those listed above.
[9]	Sudden malfunction (as a result of external noise.)	<1> Check that the grounding work is performed properly.
		<2>Check that the shielded wire is used as the transmission line when it is required, and check that the grounding work is performed prop- erly on the shielded wire.
		<3>Check that neither the transmission line nor the external connection wiring does not run close to another power supply system or does not run through the same conduit pipe.
		* Contact the factory for cases other than those listed above.

(2) Inverter output related troubles

	Items to be checked	Phenomena	Remedy
[1] Check the INV board error detection cir-	<p72 model=""></p72>	1) IPM/overcurrent breaker trip (4250 Detail code No. 101, 104, 105, 106, and 107)	Replace the INV board.
cuit.	(1) Disconnect the inverter output wire from the terminals of the INV board (SC-U, SC-V, SC-W).	2) Logic error (4220 Detail code No. 111)	Replace the INV board.
	(2) Put the outdoor unit into operation.	ACCT sensor circuit failure (5301 Detail code No.117)	Replace the INV board.
		4) IPM open (5301 Detail code No.119)	Normal
	<p96, mod-<br="" p120,="" p144="">els></p96,>	1) IPM/overcurrent breaker trip (4250 Detail code No. 101, 103, 104, 105, 106, and 107)	See the section "Troubleshooting the IPM" (Refer to - 7 - (5)). Replace the IPM, and put the outdoor unit back into operation. If the problem persists, replace the INV board.
	(1) Disconnect the inverter output wire from the output terminals (U, V, W) of the IPM.	2) Logic error (4220 Detail code No. 111)	See the section "Troubleshooting the IPM" (Refer to -7 - (5)). Replace the IPM, and put the outdoor unit back into operation. If the problem persists, replace the INV board. Replace the INV board, and put the outdoor unit back into operation. If the problem persists, replace the DCCT.
	(2) Put the outdoor unit into operation.	3) ACCT sensor circuit failure (5301 Detail code No.117)	Replace the INV board.
		4) DCCT sensor circuit failure (5301 Detail code No.118)	Replace the DCCT board. Replace the DCCT, and put the outdoor unit back into operation. If the problem persists, replace the INV board.
		5) IPM open (5301 Detail code No.119)	Normal
[2] Check for compressor ground fault or coil error.	Disconnect the compressor wiring, and check the compressor Meg, and coil resistance.	Compressor Meg failure Error if less than 1 Mohm. When no liquid refrigerant in the compressor	Replace the compressor Check that no liquid refrigerant in the compressor.
COII GITOI.		2) Compressor coil resistance failure Coil resistance value of 0.20 ohm (20°C [68°F]): P72 model Coil resistance value of 0.09 ohm (20°C [68°F]): P96 - P144 models	

		Items to be checked		Phenomena	Remedy
[3] Check whether the inverter is	<p72 model=""></p72>		1)	Inverter-related problems are detected.	Connect the short-circuit connector to CN6, and go to section [1].
damaged. (No load)	(1)	Disconnect the inverter output wire from the terminals of the INV board (SC-U, SC-V, SC-W).	2)	Inverter voltage is not output.	Replace the INV board.
	(2)	Disconnect the short-circuit connector from CN6 on the INV board.	3)	There is an voltage imbalance between the wires. Greater than 5% imbalance or 5V	Replace the INV board.
	(3)	Put the outdoor unit into operation. Check the inverter output voltage after the inverter output frequency has stabilized.	4)	There is no voltage imbalance between the wires.	Normal *Reconnect the short-circuit connector to CN6 after checking the voltage.
	<p9< td=""><td>6, P120 models></td><td>1)</td><td>Inverter-related problems are detected.</td><td>Turn off SW1-1 and go to [1]</td></p9<>	6, P120 models>	1)	Inverter-related problems are detected.	Turn off SW1-1 and go to [1]
	(1)	Disconnect the inverter output wire from the output terminals (U, V, W) of the IPM.	2)	Inverter voltage is not output.	Check the connection be- tween the IPM and the CNIPM on the INV board. Replace the IPM. If the problem persists, re- place the INV board.
	(2)	Turn on SW1-1 on the INV board.	3)	There is an voltage imbalance between the wires. Greater than 5% imbalance or 5V	Replace the IPM. If the problem persists, replace the INV board.
	(3)	Put the outdoor unit into operation.	4)	There is no voltage imbalance between the wires.	Normal *Turn off SW1-1

	Items to be checked	Phenomena	Remedy
[4] Check whether	Put the outdoor unit into operation.	Overcurrent-related problems oc- cur immediately after compressor	a. Check items [1] through [3].
the inverter is damaged. (During com-	Check the inverter output voltage after the inverter output frequency has stabilized.	startup. (4250 Details : No.101, 103, 106, 107)	b. Check that high and low pressures are balanced.
pressor opera- tion)			c. Check that no liquid refrigerant is present in the compressor. →Go to "d." when the problem persists after compressor startup was repeated several times. If normal operation is restored, check the belt heater for problems.
			d. Check that there is a pressure difference between high and low pressures after compressor startup. →Check the high pressure with LED monitor for changes. Replace the compressor if there is no pressure difference. (the compressor may be locked.)
		There is a voltage imbalance between the wires after the inverter output voltage is stabilized. Greater than the larger of the following values: imbalance of 5% or 5V	If there is a voltage imbalance <p72 model=""> Replace the INV board. <p96, models="" p120,="" p144=""> Replace the IPM. If the problem persists, replace the INV board. If the problem persists after replacing the above parts, go to section [2]. Check the belt heater for problems if there is no voltage imbalance. →When the error occurred, liquid refrigerant may have been present in the compressor.</p96,></p72>
[5] Check the fan motor ground fault or the	Remove the wire for the out- door fan motor, and check the fan motor megger and the winding resistance.	Fan motor megger failure Failure when the megger is 1Mohm or less.	Replace the fan motor.
winding.		2) Fan motor disconnection Standard: The winding resistance is approximately several ohm. (It varies depending on the temper- ature, or while the inner thermo is operating, it will be ∞ ohm)	
[6] Check the FAN board failure.	(1) Check the fan output wiring.	Connector contact failure •Board side (CNINV) •Fan motor side	Connect the connector.
	(2) Check the connector CN-VDC connection.	Cnnector contact failure	Connect the connector.
	(3) Check the FAN board failure.	The voltage imbalance among each motor wiring during operation (The voltage imbalance is greater than the larger of the values represented by 5% or 5 V.)	Replace the FAN board.
		The same error occurs even after the operation is restarted.	

(3) Trouble treatment when the main power breaker is tripped.

	Items to be checked		Phenomena	Remedy	
[1]	Perform Meg check between the terminals on the power terminal block TB1.		Zero to several ohm, or Meg failure	Check each part in the main inverter circuit. *Refer to "Simple checking Procedures for individual components of	
[2]	Turn on the power again and	1)	Main power breaker trip	main inverter circuit".	
	check again.	2)	No remote control display	Diode stack IPM Rush current protection resistor Electromagnetic relay DC reactor	
[3]	Turn on the outdoor unit and check that it operates normally.	1)	Operates normally without tripping the main breaker.	a) The wiring may have been short-circuited. Search for the wire that short-circuited, and repair it. b) If item a) above is not the cause of the problem, the compressor may have a problem.	
		2)	Main power breaker trip	A compressor ground fault can be considered. Go to (2)-[2].	

(4) Simple checking procedure for individual components of main inverter circuit

Note

Before checking, turn the power off and remove the parts to be checked from the control box.

Judgment method						
See "Troubleshooting for IGBT Module ". (IX [4] - 7 - (7))						
Refer to "Diode stack" (IX [4] - 7 - (6))	Refer to "Diode stack" (IX [4] - 7 - (6))					
Refer to "Intelligent power module (IPM)" (IX [4] -	7 - (5))					
<p96, models="" p120,="" p144=""> Measure the resistance between the + terminal on</p96,>	Measure the resistance between terminals: 22 ohm \pm 10% <p96, models="" p120,="" p144=""> Measure the resistance between the + terminal on the diode stack and terminal TB31. (*Can be mea-</p96,>					
	Note This electromagnetic relay is rated at 200VAC and is driven by a coil. The resistance between the coils in row A cannot be measured with a tester. Check only for shorting.					
Installation direction	<p72 mc<="" td=""><td>odel></td><td></td></p72>	odel>				
Rowi Row i Row i Row		Check point	Checking criteria			
A B C D E	Coil	Row A	Not to be short-circuited			
A2 44 34 24 14 14 14 15 15 15 15 1	Contact	Row B to Row E	With the test button turned off : ∞ With the test button turned on : 0Ω			
A1 43 33 23 13	<p96, models="" p120,="" p144=""></p96,>					
Test button		Check point	Checking criteria			
	Coil	Between No. 1 pin and No. 3 pin of the CN03 or the noise filter board	Not to be short-circuited			
	Contact	+ terminal on the diode stack and terminal TB31 on the noise filter	turried oil . 22 ½ ± 10 /0			
<p96, models="" p120,="" p144=""> Disconnect the CNCT2 connector and measure the resistance between terminals: 280 ohm ± 30 ohm 1 - 2 PIN (U-phase),3 - 4 PIN (W-phase) IPM W V U ACCT-W W V U *Check the ACCT connection phase and the</p96,>						
	Refer to "Diode stack" (IX [4] - 7 - (6)) Refer to "Intelligent power module (IPM)" (IX [4] - 4 - 4 - 4 - 4 - 4 - 4 - 4 - 4 - 4 -	Refer to "Diode stack" (IX [4] - 7 - (6)) Refer to "Intelligent power module (IPM)" (IX [4] - 7 - (5))	Refer to "Intelligent power module (IPM)" (IX [4] - 7 - (5))			

(5) Intelligent power module (P96, P120, P144 models)

Measure resistances between each pair of terminals on the IPM with a tester, and use the results for troubleshooting.

1) Notes on measurement

- •Check the polarity before measuring. (On the tester, black normally indicates plus.)
- •Check that the resistance is not open (∞ ohm) or not shorted (to 0 ohm).
- •The values are for reference, and the margin of errors is allowed.
- •The result that is more than double or half of the result that is measured at the same measurement point is not allowed.

2) Tester restriction

- •Use the tester whose internal electrical power source is 1.5V or greater
- •Use the dry-battery-powered tester.

Note

(The accurate diode-specific resistance cannot be measured with the button-battery-powered card tester, as the applied voltage is low.)


•Use a low-range tester if possible. A more accurate resistance can be measured.


Judgment value (reference)

			Black (+)					
		Р	N	U	V	W		
	Р	-	-	5 - 200 ohm	5 - 200 ohm	5 - 200 ohm		
	N	-	-	∞	∞	∞		
Red (-)	U	∞	5 - 200 ohm	-	-	-		
	V	∞	5 - 200 ohm	-	-	-		
	W	∞	5 - 200 ohm	-	-	-		

External view

Internal circuit diagram






(6) Diode stack (P96, P120, P144 models)

Measure resistances between each pair of terminals on the diode stack with a tester, and use the results for troubleshooting.Refer to (5) " Intelligent power module (IPM) " for notes on measurement and tester selection.


Judgment value (reference)

		Black (+)					
		+ (P)	- (N)	to (L1)	to (L2)	to (L3)	
	+ (P)	-	-	5 - 200 ohm	5 - 200 ohm	5 - 200 ohm	
	- (N)	-	-	∞	∞	8	
	to (L1)	8	5 - 200 ohm	-	-	-	
Red (-)	to (L2)	8	5 - 200 ohm	-	-	-	
	to (L3)	∞	5 - 200 ohm	-	-	-	

External view



Internal circuit diagram



(7) Troubleshooting for IGBT Module

Measure the resistances between each pair of terminals on the IGBT with a tester, and use the results for troubleshooting. The terminals on the inverter board are used for the measurement.

1) Notes on measurement

- •Check the polarity before measuring. (On the tester, black normally indicates plus.)
- •Check that the resistance is not open (∞ ohm) or not shorted (to 0 ohm).
- •The values are for reference, and the margin of errors is allowed.
- •The result that is more than double or half of the result that is measured at the same measurement point is not allowed.
- •Disconnect all the wiring connected the INV board, and make the measurement.

2) Tester restriction

- •Use the tester whose internal electrical power source is 1.5V or greater
- •Use the dry-battery-powered tester.

Note

(The accurate diode-specific resistance cannot be measured with the button-battery-powered card tester, as the applied voltage is low.)


*Use a low-range tester if possible. A more accurate resistance can be measured.

Judgment value (reference)

		Black (+)					
		SC-P1	TB-N	SC-R	SC-S	SC-T	
	SC-P1	-	-	5 - 200 ohm	5 - 200 ohm	5 - 200 ohm	
	TB-N	-	-	∞	∞	∞	
Red (-)	SC-R	∞	5 - 200 ohm	-	-	-	
	SC-S	∞	5 - 200 ohm	-	-	-	
	SC-T	∞	5 - 200 ohm	-	-	-	

				Black (+)		
		SC-P2	TB-N	SC-U	SC-V	SC-W
	SC-P2	-	-	5 - 200 ohm	5 - 200 ohm	5 - 200 ohm
	TB-N	-	-	∞	∞	∞
Red (-)	SC-U	∞	5 - 200 ohm	-	-	-
	SC-V	∞	5 - 200 ohm	-	-	-
	SC-W	∞	5 - 200 ohm	-	-	-

INV board external diagram



Note

Faston terminals have a locking function. Make sure the cable heads are securely locked in place. Press the tab on the terminals to remove them.

-7- Inverter (YJMU-A)

- •Replace only the compressor if only the compressor is found to be defective.
- •Replace only the fan motor if only the fan motor is found to be defective.
- •Replace the defective components if the inverter is found to be defective.
- •If both the compressor and the inverter are found to be defective, replace the defective component(s) of both devices.

(1) Inverter-related problems: Troubleshooting and remedies

- 1) The inverter board has a large-capacity electrolytic capacitor, in which residual voltage remains even after the main power is turned off, posing a risk of electric shock. Turn off the unit, leave it turned off for at least 10 minutes, and check that the voltage across FT-P and FT-N terminals on the INV board or the terminals at both ends of the electrolytic capacitor is 20V or below before checking inside the control box.
 - (It takes about 10 minutes to discharge electricity after the power supply is turn off.)
- 2) The IPM on the inverter becomes damaged if there are loose screws are connectors. If a problem occurs after replacing some of the parts, mixed up wiring is often the cause of the problem. Check for proper connection of the wiring, screws, connectors, and Faston terminals.
- To avoid damage to the circuit board, do not connect or disconnect the inverter-related connectors with the main power turned on.
- 4) Faston terminals have a locking function. Make sure the terminals are securely locked in place after insertion.

Press the tab on the terminals to remove them.



- 5) When the IPM or IGBT is replaced, apply a thin layer of heat radiation grease that is supplied evenly to these parts. Wipe off any grease that may get on the wiring terminal to avoid terminal contact failure.
- 6) Faulty wiring to the compressor damages the compressor. Connect the wiring in the correct phase sequence.

	Error display/failure condition	Measure/inspection item		
[1]	Inverter related errors 4250, 4255, 4220, 4225, 4230, 4240,4260, 5301, 0403	Check the details of the inverter error in the error log at X LED Monitor Display on the Outdoor Unit Board. Take appropriate measures to the error code and the error details in accordance with IX. [2] Responding to Error Display on the Remote Controller.		
[2]	Main power breaker trip	Refer to "(3) Trouble treatment when the main power breaker is tripped".		
[3]	Main power earth leakage breaker trip	Refer to "(4) Trouble treatment when the main power earth leakage breaker is tripped".		
[4]	Only the compressor does not operate.	Check the inverter frequency on the LED monitor and proceed to (2) - [4] if the compressor is in operation.		
[5]	The compressor vibrates violently at all times or makes an abnormal sound.	See (2)-[4].		
[6]	Only the fan motor does not operate.	Check the inverter frequency on the LED monitor and proceed to (2)-[6] if the fan motor is in operation.		
[7]	The fan motor shakes violently at all times or makes an abnormal sound.	Check the inverter frequency on the LED monitor and proceed to (2)-[6] if the fan motor is in operation.		
[8]	Noise is picked up by the peripheral device	<1> Check that power supply wiring of the peripheral device does not run close to the power supply wiring of the outdoor unit.		
		<2> Check if the inverter output wiring is not running parallel to the power supply wiring and the transmission lines.		
		<3> Check that the shielded wire is used as the transmission line when it is required, and check that the grounding work is performed prop- erly on the shielded wire.		
		<4> Meg failure for electrical system other than the inverter		
		<5> Attach a ferrite core to the inverter output wiring. (Contact the factory for details of the service part settings.)		
		<6> Provide separate power supply to the air conditioner and other electric appliances.		
		<7> If the error occurred suddenly, a ground fault of the inverter output can be considered. See (2)-[4].		
		*Contact the factory for cases other than those listed above.		
[9]	Sudden malfunction (as a result of external noise.)	<1> Check that the grounding work is performed properly.		
		<2>Check that the shielded wire is used as the transmission line when it is required, and check that the grounding work is performed prop- erly on the shielded wire.		
		<3>Check that neither the transmission line nor the external connection wiring does not run close to another power supply system or does not run through the same conduit pipe.		
		* Contact the factory for cases other than those listed above.		

(2) Inverter output related troubles

	It	ems to be checked		Phenomena	Remedy
Check the INV board er- ror detection ir		Disconnect the invert- er output wire from the terminals of the inverter board (SC-U, SC-V, SC-W).	1)	Overcurrent error (4250 Detail code No. 101, 104, 105, 106, and 107)	Replace the INV board.
	(2)	Put the outdoor unit into operation.	2)	Logic error (4220 Detail code No. 111)	Replace the INV board.
			3)	ACCT sensor circuit failure (5301 Detail code No.117)	Replace the INV board.
			4)	IPM open (5301 Detail code No.119)	Normal
[2] Check for compressor ground fault or coil error.	wiring	onnect the compressor g, and check the com- sor Meg, and coil resis- c.	1)	Compressor Meg failure Error if less than 1 Mohm.	Check that there is no liquid re- frigerant in the compressor. If there is none, replace the com- pressor.
or con error.			2)	Compressor coil resistance failure Coil resistance value of 0.71 ohm (20°C [68°F]): - P72 model Coil resistance value of 0.32 ohm (20°C [68°F]): P96 - P144 models	Replace the compressor.
[3] Check whether the inverter is damaged. (No load)	(1)	Disconnect the invert- er output wire from the terminals of the inverter board (SC-U, SC-V, SC-W).	1)	Inverter-related problems are detected.	Connect the short-circuit connector to CN6, and go to section [1].
	(2)	Disconnect the short-circuit connector from CN6 on the inverter board.	2)	Inverter voltage is not output at the terminals (SC-U, SC-V, and SC-W)	Replace the INV board.
	(3)	Put the outdoor unit into operation. Check the inverter output voltage after the inverter output frequency has stabilized.	3)	There is an voltage imbalance between the wires. Greater than 5% imbalance or 5V	Replace the INV board.
			4)	There is no voltage imbalance between the wires.	Normal *Reconnect the short-circuit connector to CN6 after checking the voltage.

	Items to be checked	Phenomena	Remedy
[4] Check whether the inverter is damaged. (During compressor opera-	Put the outdoor unit into operation. Check the inverter output voltage after the inverter output frequency has stabilized.	Overcurrent-related problems oc- cur immediately after compressor startup.Error code : 4250Detail code : 101, 106, 107	a.Check items [1] through [3] for problems. b.Check that high and low pressures are balanced.
tion)			c.Check that no liquid refrigerant is present in the compressor. →Go to "d." when the problem persists after compressor startup was repeated several times. If normal operation is restored, check the belt heater for problems.
			d.Check that there is a pressure difference between high and low pressures after compressor startup. →Check the high pressure with LED monitor for changes. Replace the compressor if there is no pressure difference. (the compressor may be locked.)
		2) There is a voltage imbalance between the wires after the inverter output voltage is stabilized. Greater than the larger of the following values: imbalance of 5% or 5V	Replace the INV board if there is a voltage imbalance. Check the belt heater for problems if there is no voltage imbalance. →When the error occurred, liquid refrigerant may have been present in the compressor.
[5] Check the fan motor ground	Remove the wire for the out- door fan motor, and check the fan motor megger and the	Fan motor megger failure Failure when the megger is 1Mohm or less.	Replace the fan motor.
fault or the winding.	winding resistance.	2) Fan motor disconnection Standard: The winding resistance is approximately several ohm. (It varies depending on the temperature, or while the inner thermo is operating, it will be ∞ ohm)	
[6] Checkthe FAN board failure.	(1) Check the fan output wiring.	Connector contact failure *Board side (CNINV) *Fan motor side	Connect the connector.
	(2) Check the connector CN- VDC connection.	Cnnector contact failure	Connect the connector.
	(3) Check the FAN board failure.	The voltage imbalance among each motor wiring during operation (The voltage imbalance is greater than the larger of the values represented by 5% or 5 V.)	Replace the FAN board.
		The same error occurs even after the operation is restarted.	

(3) Trouble treatment when the main power breaker is tripped

	Items to be checked	Phenomena	Remedy
[1]	Check the breaker capacity.	Use of a non-specified break- er	Replace it with a specified breaker.
[2]	Perform Meg check between the terminals on the power terminal block TB1.	Zero to several ohm, or Meg failure	Check each part and wiring. *Refer to (5) "Simple checking procedure for individual components of main inverter
[3]	Turn on the power again and	Main power breaker trip	circuit". *IGBT module
	check again.	2) No remote control display	Rush current protection resistor Electromagnetic relay DC reactor
[4]	Turn on the outdoor unit and check that it operates normally.	Operates normally without tripping the main breaker.	a) The wiring may have been short-circuited. Search for the wire that short-circuited
		2) Main power breaker trip	ed, and repair it. b) If item a) above is not the cause of the problem, refer to (2)-[1]-[6].

(4) Trouble treatment when the main power earth leakage breaker is tripped

	Items to be checked	Phenomena	Remedy
[1]	Check the earth leakage breaker capacity and the sensitivity current.	Use of a non-specified earth leakage breaker	Replace with a regulation earth leakage breaker.
[2]	Check the resistance at the power supply terminal block (TB1) with a megger.	Failure resistance value	Check each part and wiring. *Refer to (5) "Simple checking Procedures for individual components of main inverter circuit". •IGBT module •Rush current protection resistor •Electromagnetic relay •DC reactor
[3]	Disconnect the compressor wirings and check the resistance of the compressor with a megger.	Failure compressor if the insulating resistance value is not in specified range. Failure when the insulating resistance value is 1 Mohm or less.	Check that there is no liquid refrigerant in the compressor. If there is none, replace the compressor.
[4]	Disconnect the fan motor wirings and check the resistance of the fan motor with a megger.	Failure fan motor if the insulating resistance value is not in specified range. Failure when the insulating resistance value is 1 Mohm or less.	Replace the fan motor.

Note

The insulation resistance could go down to close to 1Mohm after installation or when the power is kept off for an extended period of time because of the accumulation of refrigerant in the compressor. If the earth leakage breaker is triggered, please use the following procedure to take care of this.

- •Disconnect the wires from the compressor's terminal block.
- •If the resistance is less than 1 Mohm, switch on the power for the outdoor unit with the wires still disconnected.
- *Leave the power on for at least 12 hours.
- •Check that the resistance has recovered to 1 Mohm or greater.

Earth leakage current measurement method

- •For easy on-site measurement of the earth leakage current, enable the filter with a measurement instrument that has filter functions as below, clamp all the power supply wires, and measure.
- Recommended measurement instrument: CLAMP ON LEAK HITESTER 3283 made by HIOKI E.E. CORPORATION
- •When measuring one device alone, measure near the device's power supply terminal block.

(5) Simple checking procedure for individual components of main inverter circuit

Note

Before inspecting the inside of the control box, turn off the power, keep the unit off for at least 10 minutes, and confirm that the voltage between FT-P and FT-N on INV Board has dropped to DC20V or less.

Part name	Judgment method				
IGBT module	See "Troubleshooting for IGBT Module ". (IX [4] - 7 - (6))				
Rush current protection resistor R1, R5	Measure the resistance between terminals R1 and R5: 22 ohm ± 10%				
Electromagnetic relay 72C	This electromagnetic relay is rated at DC12V and is driven by a coil. Check the resistance between terminals Upper 1 2 3 4 Check point Checking criteria(W) Coil Between Terminals 5 and 6 Not to be short-circuited (Center value 75 ohm) Contact Between Terminals 1 and 2 contact Between Terminals 3 and 4 cont				
DC reactor DCL	Measure the resistance between terminals: 10hm or lower (almost 0 ohm) Measure the resistance between terminals and the chassis: ∞				

(6) Troubleshooting for IGBT Module

Measure the resistances between each pair of terminals on the IGBT with a tester, and use the results for troubleshooting. The terminals on the inverter board are used for the measurement.

1) Notes on measurement

- •Check the polarity before measuring. (On the tester, black normally indicates plus.)
- •Check that the resistance is not open (∞ ohm) or not shorted (to 0 ohm).
- •The values are for reference, and the margin of errors is allowed.
- •The result that is more than double or half of the result that is measured at the same measurement point is not allowed.
- •Disconnect all the wiring connected the INV board, and make the measurement.

2) Tester restriction

- •Use the tester whose internal electrical power source is 1.5V or greater
- •Use the dry-battery-powered tester.

Note

(The accurate diode-specific resistance cannot be measured with the button-battery-powered card tester, as the applied voltage is low.)


•Use a low-range tester if possible. A more accurate resistance can be measured.

Judgment value (reference)

	Black (+)					
		SC-P1	FT-N	SC-L1	SC-L2	SC-L3
	SC-P1	-	-	5 - 200 ohm	5 - 200 ohm	5 - 200 ohm
	FT-N	-	-	∞	∞	∞
Red (-)	SC-L1	∞	5 - 200 ohm	-	-	-
	SC-L2	∞	5 - 200 ohm	-	-	-
	SC-L3	∞	5 - 200 ohm	-	-	-

		Black (+)				
		SC-P2	FT-N	SC-U	SC-V	SC-W
	SC-P2	-	-	5 - 200 ohm	5 - 200 ohm	5 - 200 ohm
	FT-N	-	-	∞	∞	∞
Red (-)	SC-U	∞	5 - 200 ohm	-	-	-
	SC-V	∞	5 - 200 ohm	-	-	-
	SC-W	∞	5 - 200 ohm	-	-	-


INV board external diagram



-8- Control Circuit (TJMU-A)

(1) Control power source function block


1) PURY-P72TJMU-A



^{*} MA remote controllers and ME remote controllers cannot be used together.

(Both the ME and MA remote controller can be connected to a system with a system controller.)

2) PURY-P96, P120, P144TJMU-A




^{*} MA remote controllers and ME remote controllers cannot be used together.


(Both the ME and MA remote controller can be connected to a system with a system controller.)

(2) Troubleshooting transmission power circuit of outdoor unit

1) PURY-P72TJMU-A




2) PURY-P96, P120, P144TJMU-A



-8- Control Circuit (YJMU-A)

- (1) Control power source function block
- 1) PURY-P72, P96, P120, P144YJMU-A




^{*} MA remote controllers and ME remote controllers cannot be used together.

(Both the ME and MA remote controller can be connected to a system with a system controller.)

(2) Troubleshooting transmission power circuit of outdoor unit

1) PURY-P72, P96, P120, P144YJMU-A



[5] Refrigerant Leak

- 1. Leak spot: In the case of extension pipe for indoor unit (Cooling season)
- 1) Mount a pressure gauge on the service check joint (CJ2) on the low-pressure side.
- 2) Stop all the indoor units, and close the high-pressure side refrigerant service valve (BV2) on the outdoor unit while the compressor is being stopped.
- 3) Stop all the indoor units; turn on SW2-4 on the outdoor unit control board while the compressor is being stopped.(Pump down mode will start, and all the indoor units will run in cooling test run mode.)
- 4) In the pump down mode (SW2-4 is ON), all the indoor units will automatically stop when the low pressure (63LS) reaches 0.383MPa [55psi] or less or 15 minutes have passed after the pump mode started. Stop all the indoor units and compressors when the pressure indicated by the pressure gauge, which is on the check joint (CJ2) for low-pressure service, reaches 0.383MPa [55psi] or 20 minutes pass after the pump down operation is started.
- 5) Close the service ball valve (BV1) on the low-pressure pipe on the outdoor unit.
- 6) Collect the refrigerant that remains in the extended pipe for the indoor unit. Do not discharge refrigerant into the atmosphere when it is collected.
- 7) Repair the leak.
- 8) After repairing the leak, vacuum*1 the extension pipe and the indoor unit.
- 9) To adjust refrigerant amount, open the ball valves (BV1 and BV2) inside the outdoor unit and turn off SW2-4.

2. Leak spot: In the case of outdoor unit (Cooling season)


- (1) Run all the indoor units in the cooling test run mode.
- 1) To run the indoor unit in test run mode, turn SW3-2 from ON to OFF when SW3-1 on the outdoor control board is ON.
- 2) Change the setting of the remote controller for all the indoor units to the cooling mode.
- 3) Check that all the indoor units are performing a cooling operation.

(2) Check the SC16 value.

(This valve can be displayed on the LED by setting the self-diagnosis switch (SW1) on the outdoor unit control board.)

- 1) When SC16 is 10°C [18°F] or above: Go to the next item (3).
- 2) When the SC16 value is below 10°C [18°F]: After the compressor has stopped, extract the refrigerant in the system, repair the leak, evacuate the air from the system *1, and charge the system with refrigerant. (If the leak is in the outdoor unit, follow the same procedure as listed under "heating season.")

SC16 self-diagnosis switch



- (3) Stop all the indoor units, and stop the compressor.
- 1) To stop all the indoor units and the compressors, turn SW3-2 from ON to OFF when SW3-1 on the outdoor control board is ON.
- 2) Check that all the indoor units are being stopped.
- (4) Close the ball valves (BV1 and BV2).
- (5) Collect the refrigerant that remains inside the outdoor unit.Do not discharge refrigerant into air into the atmosphere when it is collected.
- (6) Repair the leak.
- (7) After repairing the leak, replace the dryer with the new one, and perform evacuation *1 inside the outdoor unit.
- (8) To adjust refrigerant amount, open the ball valves (BV1 and BV2) inside the outdoor unit.

3. Leak spot: In the case of extension pipe for indoor unit (Heating season)

- (1) Run all the indoor units in heating test run mode.
- 1) To run the indoor unit in test run mode, turn SW3-2 from ON to OFF when SW3-1 on the outdoor control board is ON.
- Change the setting of the remote controller for all the indoor units to the heating mode.
- 3) Check that all the indoor units are performing a heating operation.

(2) Stop all the indoor units, and stop the compressor.

- 1) To stop all the indoor units and the compressors, turn SW3-2 from ON to OFF when SW3-1 on the outdoor control board is ON.
- 2) Check that all the indoor units are stopped.
- (3) Close the ball valves (BV1 and BV2).
- (4) Collect the refrigerant that remains inside the indoor unit. Do not discharge refrigerant into air into the atmosphere when it is collected.
- (5) Repair the leak.
- (6) After repairing the leak, perform evacuation of the extension pipe*1 for the indoor unit, and open the ball valves (BV1 and BV2) to adjust refrigerant.

4. Leak spot: In the case of outdoor unit (Heating season)

- 1) Collect the refrigerant in the entire system (outdoor unit, extended pipe and indoor unit). Do not discharge refrigerant into the atmosphere when it is collected.
- 2) Repair the leak.
- 3) Repair the leak, and evacuate the air from the entire system *1. Then, calculate the proper amount of refrigerant to be added (outdoor unit + extension pipe + indoor unit), and charge the system with that amount. Refer to Chapter VIII [4] 3. for the proper amount of refrigerant charge.

^{*1.} Refer to Chapter I [8] Vacuum Drying (Evacuation) for detailed procedure.

[6] Compressor Replacement Instructions


1. Compressor Replacement Instructions

[Compressor replacement procedures]


Follow the procedures below (Steps 1 through 6) to remove the compressor components and replace the compressor. Reassemble them in the reverse order after replacing the compressor.



1. Remove both the top and bottom service panels (front panels).



2. Remove the control box and the compressor cover (front).




3. Remove the wires that are secured to the frame, and remove the frame.


^{*1} Remove the transformer box from the P72, P96YJMU-A models.



4. Remove the compressor cover (top).



5. Remove the compressor wires, compressor covers (right and left), and belt heater.



Suction piping



 Place protective materials on the insulation lining of the compressor cover and on the sealing material on the compressor suction pipe to protect them from the torch flame, debraze the pipe, and replace the compressor.

- 1. Solenoid valve block ASSY (SV4a, SV4b, SV4d), Check valve (CV4a, CV6a, CV8a, CV9a, CV10a) replacement instructions
- * Following instructions show procedures for replacing service parts for Solenoid valve block ASSY (SV4a, SV4b, SV4d), Check valve (CV4a, CV6a, CV9a, CV10a). Replace them properly according to the procedures.

1. Applicable models

• PURY-P72TJMU-A (-BS), PURY-P72YJMU-A (-BS)

2. Parts to be serviced, Set-content

Following instructions are applicable to 1-3 service parts on the table below.

NO.	Parts to be serviced	Things required for replacing		
NO.	Parts to be serviced	Item	Numbers	
1	Solenoid valve block ASSY (SV4a, SV4b, SV4d)	Solenoid valve block service parts set [Set-content] • Replacement instructions • Solenoid valve block ASSY • Connecting pipe (\$\phi 9.52 [3/8"])	1 1 1	
2	Check valve (CV4a)	Service parts replacement instructions set		
3	Check valve (CV6a, CV8a, CV9a, CV10a)	[Set-content]	1 1	

3. Procedures


- * Precautions for starting replacement
- Check that the main power supply is OFF.
- · Check that no refrigerant is in the outdoor unit.

Remove each part according to the 1)-3) procedures on the next page before replacing service parts.

Mount the removed parts back in place in a reversed procedures of 1)-3) on the next page after replacing service parts.

(1) Solenoid valve block ASSY (SV4a, SV4b, SV4d) replacement procedures


- To remove Solenoid valve block ASSY
 - ① Remove the solenoid valve block coil cover, solenoid valve coil, and peripheral cables.
 - ② Remove the screw (M5) that fixes the solenoid valve block and the supporting plate for solenoid valve block.
 - ③ Cut the pipe at the position indicated on the next page with a pipe cutter. Remove the pipe from the brazed A part.
 - 4 Debraze B-G parts (total 6 places).
 - ⑤ Do not damage heat exchanger fins and peripheral piping devices when removing the Solenoid valve block ASSY.
- To install Solenoid valve block ASSY
 - (6) Mount the Solenoid valve block ASSY replacement to the unit with care not to damage heat exchanger fins and peripheral piping devices.
 - Fix the Solenoid valve block ASSY and the supporting plate with the fixing screw (M5).
 - ① Braze B-G part (total 6 places), and connect the solenoid valve block and the heat exchanger header with the connecting pipe (φ9.52 [3/8"]) that comes with the service parts set.
 - ® Mount the solenoid valve block coil cover, solenoid valve coil, and peripheral cables back in place.
 - * Precautions for replacing Solenoid valve block ASSY
 - · Be sure to perform no-oxidation brazing when brazing.
 - After brazing, check the condition around the brazing. After confirming no leakage, evacuate the air inside. (*1)
 - · Perform brazing with care of the flame direction so that it does not burn cables and plates etc. in the unit.
 - Remove the brazing part protecting heat exchanger fins from burning, and replace the service parts.
 - *1: Refer to Chapter I [8] Vacuum Drying (Evacuation) for detailed procedure.



^{*} Refer to the next page for Check valve (CV4a, CV6a, CV8a, CV9a, CV10a) replacement procedures.


(2) Check valve (CV4a, CV6a, CV8a, CV9a, CV10a) replacement procedures

- ① Remove the Solenoid valve block ASSY following "(1) Solenoid valve block ASSY (SV4a, SV4b, SV4d) replacement procedures" on the front page.
- ② Debraze H-M parts (total 6 places), and remove the Check valve ASSY.
- ③ Replace the Check valve (CV4a, CV6a, CV8a, CV9a, CV10a) to be serviced while it is removed from the unit.
 Braze the pipes as they were according to the angle of the pipes on the next page (Figure as viewed from point Q).
- Mount the solenoid valve block ASSY, coil cover, and peripheral cables back in place according to "(1) Solenoid valve block ASSY (SV4a, SV4b, SV4d) replacement procedures" on the front page.



* After removing Solenoid valve block ASSY

- * Precautions for replacing Check valve
- Be sure to perform no-oxidation brazing when brazing.
- Place a wet towel on the check valve when heating pipes to keep the temperature of the valve from exceeding 120°C [248°F].
- After brazing, check the condition around the brazing. After confirming no leakage, evacuate the air inside. (*1)
- Perform carefully with the flame direction so that it does not burn cables and plates etc. in the unit.
- Remove the brazing part protecting heat exchanger fins not to be burn, and replace the service parts.
- *1: Refer to Chapter I [8] Vacuum Drying (Evacuation) for detailed procedure.



2. Solenoid valve block ASSY (SV4a, SV4b, SV4c, SV4d), Check valve (CV4a, CV6a, CV8a, CV9a, CV10a) replacement instructions

* Following instructions show procedures for replacing service parts for Solenoid valve block ASSY (SV4a, SV4b, SV4c, SV4d), Check valve (CV4a, CV6a, CV8a, CV9a, CV10a). Replace them properly according to the procedures.

1. Applicable models

• PURY-P96TJMU-A (-BS), PURY-P96YJMU-A (-BS)

2. Parts to be serviced, Set-content

Following instructions are applicable to 1-4 service parts on the table below.

NO.	Parts to be serviced	Things required for replacing		
NO.	Parts to be serviced	Item	Numbers	
1	Solenoid valve block ASSY	Solenoid valve block service parts set [Set-content]	1	
	(SV4a, SV4b, SV4c, SV4d)	Replacement instructions Solenoid valve block ASSY		
		• Connecting pipe (φ9.52 [3/8"])	1	
2	Check valve (CV4a, CV8a)	Service parts replacement instructions set	1	
3	Check valve (CV9a)	[Set-content] • Replacement instructions	1	
4	Check valve (CV6a, CV10a)	• Connecting pipe (\$\phi 9.52 [3/8"])		

3. Procedures

- * Precautions for starting replacement
- · Check that the main power supply is OFF.
- · Check that no refrigerant is in the outdoor unit.

Remove each part according to the 1)-3) procedures on the next page before replacing service parts.


Mount the removed parts back in place in a reversed procedures of 1)-3) on the next page after replacing service parts.

(1) Solenoid valve block ASSY (SV4a, SV4b, SV4c, SV4d) replacement procedures

- To remove Solenoid valve block ASSY
 - ① Remove the solenoid valve block coil cover, solenoid valve coil, and peripheral cables.
 - ② Remove the screw (M5) that fixes the solenoid valve block and the supporting plate for solenoid valve block.
 - ③ Cut the pipe at the position indicated on the next page with a pipe cutter. Remove the pipe from the brazed A part.
 - 4 Debraze B-H parts (total 7 places).
 - ⑤ Do not damage heat exchanger fins and peripheral piping devices when removing the Solenoid valve block ASSY.

To install Solenoid valve block ASSY


- ⑥ Mount the Solenoid valve block ASSY replacement to the unit with care not to damage heat exchanger fins and peripheral piping devices.
 - Fix the Solenoid valve block ASSY and the supporting plate with the fixing screw (M5).
- \bigcirc Braze B-H part (total 7 places), and connect the solenoid valve block and the heat exchanger header with the connecting pipe (ϕ 9.52 [3/8"]) that comes with the service parts set.
- ® Mount the solenoid valve block coil cover, solenoid valve coil, and peripheral cables back in place.
- * Precautions for replacing Solenoid valve block ASSY
- · Be sure to perform no-oxidation brazing when brazing.
- After brazing, check the condition around the brazing. After confirming no leakage, evacuate the air inside. (*1)
- · Perform carefully with the flame direction so that it does not burn cables and plates etc. in the unit.
- Remove the brazing part protecting heat exchanger fins from burning, and replace the service parts.
- *1: Refer to Chapter I [8] Vacuum Drying (Evacuation) for detailed procedure.



* Refer to the next page for Check valve (CV4a, CV6a, CV8a, CV9a, CV10a) replacement procedures.


(2) Check valve (CV4a, CV6a, CV8a, CV9a, CV10a) replacement procedures

- ① Remove the solenoid valve block ASSY following "(1) Solenoid valve block ASSY (SV4a, SV4b, SV4c, SV4d) replacement procedures" on the front page.
- ② Debraze I-O parts (total 7 places), and remove the Check valve ASSY.
- ③ Replace the Check valve (CV4a, CV6a, CV8a, CV9a, CV10a) to be serviced while it is removed from the unit.
 Braze the pipes as they were according to the angle of the pipes on the figure below (Figure as viewed from point Q).
- 4 Mount the solenoid valve block ASSY, coil cover, and peripheral cables back in place according to "(1) Solenoid valve block ASSY (SV4a, SV4b, SV4c, SV4d) replacement procedures" on the front page.



* After removing Solenoid valve block ASSY

- * Precautions for replacing Check valve
- · Be sure to perform no-oxidation brazing when brazing.
- Place a wet towel on the check valve when heating pipes to keep the temperature of the valve from exceeding 120°C [248°F].
- After brazing, check the condition around the brazing. After confirming no leakage, evacuate the air inside. (*1)
- · Perform carefully with the flame direction so that it does not burn cables and plates etc. in the unit.
- Remove the brazing part protecting heat exchanger fins not to be burn, and replace the service parts.
- *1: Refer to Chapter I [8] Vacuum Drying (Evacuation) for detailed procedure.



- 3. Solenoid valve block ASSY (SV4a, SV4b, SV4d), Check valve (CV4a, CV6a, CV8a, CV9a) replacement instructions
- * Following instructions show procedures for replacing service parts for Solenoid valve block ASSY (SV4a, SV4b, SV4d), Check valve (CV4a, CV6a, CV8a, CV9a). Replace them properly according to the procedures.

1. Applicable models

• PURY-P120, P144TJMU-A (-BS), PURY-P120, P144YJMU-A (-BS)

2. Parts to be serviced, Set-content

Following instructions are applicable to 1-3 service parts on the table below.

NO.	Parts to be serviced	Things required for replacing		
NO.	Parts to be serviced	Item	Numbers	
1	Solenoid valve block ASSY (SV4a, SV4b, SV4d)	Solenoid valve block service parts set [Set-content] • Replacement instructions • Solenoid valve block ASSY	1 1 1	
2	Check valve (CV4a, CV8a, CV9a)	Service parts replacement instructions set [Set-content] Replacement instructions Check valve		
3	Check valve (CV6a)			

3. Procedures

- * Precautions for starting replacement
- · Check that the main power supply is OFF.
- · Check that no refrigerant is in the outdoor unit.

Remove each part according to the 1)-3) procedures on the next page before replacing service parts.


Mount the removed parts back in place in a reversed procedures of 1)-3) on the next page after replacing service parts.


(1) Solenoid valve block ASSY (SV4a, SV4b, SV4d) replacement procedures

- To remove Solenoid valve block ASSY
 - 1) Remove the solenoid valve block coil cover, solenoid valve coil, and peripheral cables.
 - ② Remove the M5 screws that are holding the solenoid valve block supporting plate and the base.
 - ③ Debraze A-G parts (total 7 places).
 - (4) Do not damage heat exchanger fins and peripheral piping devices when removing the Solenoid valve block ASSY.
 - ⑤ Remove the M5 screws that are holding the solenoid valve block and the solenoid valve block supporting plate.

■ To install Solenoid valve block ASSY

- 6 Remove the brazed pipe at section H in the figure.
- (7) Fix the solenoid valve block assembly and the supporting plate in place with the M5 screws.
- ® Using caution not to damage the heat exchanger fins and the surrounding pipes, hold the replacement solenoid valve block assembly inside the unit, and then fix the solenoid valve block supporting plate and the base in place with the M5 screws.
- 9 Braze the seven spots labeled A through C in the figure.
- (fi) Mount the solenoid valve block coil cover, solenoid valve coil, and peripheral cables back in place.
- * Precautions for replacing Solenoid valve block ASSY
- Be sure to perform no-oxidation brazing when brazing.
- Before heating the pipes, place a wet towel on the solenoid valve block to keep its temperature below 120°C [248°F].
- After brazing, check the condition around the brazing. After confirming no leakage, evacuate the air inside. (*1)
- · Perform carefully with the flame direction so that it does not burn cables and plates etc. in the unit.
- Remove the brazing part protecting heat exchanger fins from burning, and replace the service parts.
- *1: Refer to Chapter I [8] Vacuum Drying (Evacuation) for detailed procedure.






^{*} Refer to the next page for Check valve (CV4a, CV6a, CV8a, CV9a) replacement procedures.


(2) Check valve (CV4a, CV6a, CV8a, CV9a) replacement procedures

- ① Remove the solenoid valve block ASSY following "(1) Solenoid valve block ASSY (SV4a, SV4b, SV4c, SV4d) replacement procedures" on the front page.
- ② Debraze I-M parts (total 5 places), and remove the Check valve ASSY.
- ③ Replace the Check valve (CV4a, CV6a, CV8a, CV9a) to be serviced while it is removed from the unit.
 Braze the pipes as they were according to the angle of the pipes on the figure on the next page (Figure as viewed from point N).
- Mount the solenoid valve block ASSY, coil cover, and peripheral cables back in place according to "(1) Solenoid valve block ASSY (SV4a, SV4b, SV4c, SV4d) replacement procedures" on the front page.



* After removing Solenoid valve block ASSY

- * Precautions for replacing Check valve
- · Be sure to perform no-oxidation brazing when brazing.
- Place a wet towel on the check valve when heating pipes to keep the temperature of the valve from exceeding 120°C [248°F].
- After brazing, check the condition around the brazing. After confirming no leakage, evacuate the air inside. (*1)
- Perform carefully with the flame direction so that it does not burn cables and plates etc. in the unit.
- Remove the brazing part protecting heat exchanger fins not to be burn, and replace the service parts.
- *1: Refer to Chapter I [8] Vacuum Drying (Evacuation) for detailed procedure.



- 4. Solenoid valve (SV1a), Capillary tube ASSY (CP1) replacement instructions
- 1. Applicable models

PURY-P72TJMU-A(-BS), PURY-P72YJMU-A(-BS)

-Low pressure twinning kit (optional accessory) is built in.
- * The parts can be replaced without removing the Solenoid valve ASSY on the unit for the units that do not have built-in low pressure twinning kit (optional accessory).


2. Parts to be serviced

NO.	Item	Applicable models
1	Solenoid valve (SV1a)	PURY-P72TJMU-A(-BS)
2	Capillary tube ASSY (CP1)	PURY-P72YJMU-A(-BS)

3. Procedures

Removing the Solenoid valve (SV1a) and the Capillary tube ASSY (CP1) individually is difficult when the low pressure twinning kit (optional accessory) is built in. Refer to the procedures ①2 below and replace the parts.

- * Precautions for starting replacement
- · Check that the main power supply is OFF.
- · Check that no refrigerant is in the outdoor unit.



- Debraze A and B, and remove solenoid valve ASSY from the unit.
- ② Replace Solenoid valve (SV1a) or Capillary tube ASSY (CP1), and mount them again.

- * Precautions for brazing
- Be sure to perform no-oxidation brazing when brazing.
- After brazing, check the condition around the brazing. After confirming no leakage, evacuate the air inside. (*1)
- · Braze carefully with the flame direction so that it does not burn cables and plates etc. in the unit.
- *1: Refer to Chapter I [8] Vacuum Drying (Evacuation) for detailed proced

[7] Servicing the BC controller

1. Service panel

*Special care must be taken when replacing heavy parts.

Work procedure	Explanatory figure
Remove the two lock nuts on the control box, loosen the other two, and remove the control box. Remove the three fixing screws on the service panel, and remove the service panel. Remove the nine machine screws on the ceiling panel, and remove the ceiling panel.	Loosen Service panel Ceiling panel Control Box

2. Control box

Work procedure


(1) To check the inside of the control box, remove the two lock nuts on the control box cover.

- Check the terminal connection of the power wire or of the transmission line.
- 2) Check the transformer.
- 3) Check the address switch.
- (2) When the control board is replaced, the followings must be noted.
- (1) Check that the board type is G,GA(HA), or GB(HB).
- (2) Check that the wire and the connector are properly connected.

Note

It is not required to remove the two fixing screws on the control box when checking the inside.

Explanatory figure



CMB-1016NU-G, GA, HA

3. Thermistor (liquid pipe/gas pipe temperature detection)

*Special care must be taken when replacing heavy parts.

Work procedure Explanatory figure (1) Remove the service panel. 1) For TH11, TH12, and TH15, refer to 1. 1) - 2). 2) For TH16, refer to 1. 1) - 3) (GA type only) (2) Remove the lead wire of the piping sensor from the control board. TH16 1) TH11,TH12 (CN10) 2) TH15,TH16 (CN11) (3) Pull out the temperature sensor from the temperature sensor housing, and replace the temperature sensor with the new one. (4) Connect the lead wire of the temperature sensor securely on the control board. TH15 TH12 CMB-1016NU-GA

4. Pressure sensor

Work procedure	Explanatory figure
 (1) Remove the service panel. 1) For the pressure sensor PS1 and PS3, refer to 1. 1) - 2) (2) Remove the pressure sensor connector in trouble from the control board, and insulate the connector. 1) Liquid-side pressure sensor (CNP1) 2) Intermediate-part pressure sensor (CNP3) (3) Attach a new pressure sensor to the place which is shown in the figure, and insert the connector to the control board. Note When gas leaks from the pressure sensor, repair the leak, and follow the instructions above if required. 	PS3 PS3 SVM1

5. LEV

(1) Remove the service panel.(Refer to 1. 1) - 3) (2) Replace the LEV in trouble. Note Secure enough service space in the ceiling for welding operation, and conduct the work carefully.If required, dismount the unit from the ceiling, and conduct the work. LEV1 LEV2 SVM2 SVM2b

6. Solenoid valve

*Special care must be taken when replacing heavy parts.

Work procedure	Explanatory figure
 (1) Remove the service panel.(Refer to 1. 1) - 3) (2) Remove the connector of the solenoid valve in trouble. (3) Remove the solenoid valve coil. 1) The coils on the solenoid valves SVA, SVB, SVM1b, SVM2 and SVM2b can be serviced through the inspection door. SVC is accessible for replacement by removing the four mounting screws on the rear panel and removing the panel (if enough space is available on the back). (SVM1 is present only on the G and GA and HA types, SVM2 on the GA and HA types, SVM1b and 	Double-pipe heat exchanger
SVM2b is present only on the HA type units.)	CMB-1016NU-G Solenoid valve
	CMB-1016NU-GA

[8] Troubleshooting Using the Outdoor Unit LED Error Display

If the LED error display appear as follows while all the SW1 switches are set to OFF, check the items under the applicable item numbers below.

1. Error code appears on the LED display.

Refer to IX [2] Responding to Error Display on the Remote Controller.

2. LED is blank.

Take the following troubleshooting steps.

- (1) If the voltage between pins 1 and 3 of CNDC on the control board is outside the range between 220 VDC and 380 VDC, refer to IX [4] -8- (2) Troubleshooting transmission power circuit of outdoor unit.
- (2) If the LED error display becomes lit when the power is turned on with all the connectors on the control board except CNDC disconnected, there is a problem with the wiring to those connectors or with the connectors themselves.
- (3) If nothing appears on the display under item (2) above AND the voltage between pins 1 and 3 of CNDC is within the range between 220 VDC and 380 VDC, control board failure is suspected.
- 3. Only the software version appears on the LED display.
- (1) Only the software version appears while the transmission cables to TB3 and TB7 are disconnected.
- 1) Wiring failure between the control board and the transmission line power supply board.(CNIT, CNS2, CN102)
- 2) If item 1) checks out OK, the transmission line power supply board failure is suspected.
- 3) If items 1) and 2) check out OK, control board failure is suspected.
- (2) If the LED display appears as noted in "X [1] 2. LED display at Initial setting" (page 357) while the transmission cables to TB3 and TB7 are disconnected, failure with the transmission cable or the connected equipment is suspected.

X	L	ED	Mor	nitor	Disp	lav	on	the	Ou ¹	tdoor	Unit	Boa	rc
---	---	----	-----	-------	------	-----	----	-----	-----------------	-------	------	-----	----


[1]	How to Read th	e LED on the	Service Monitor	r	357
-----	----------------	--------------	-----------------	---	-----


[1] How to Read the LED on the Service Monitor

1. How to read the LED

By setting the DIP SW 1-1 through 1-10 (Switch number 10 is represented by 0), the operating condition of the unit can be monitored on the service monitor. (Refer to the table on the following pages for DIP SW settings.)

The service monitor uses 4-digit 7-segment LED to display numerical values and other types of information.





SW1-10 is represented as "0" in the table.


Pressure and temperature are examples of numerical values, and operating conditions and the on-off status of solenoid valve are examples of flag display.

1) Display of numerical values

Example: When the pressure data sensor reads 18.8kg/cm² (Item No. 58)


- *The unit of pressure is in kg/cm²
- Use the following conversion formula to convert the displayed value into a value in SI unit.

Value in SI unit (MPa) = Displayed value (kg/cm²) x 0.098




2) Flag display

Example: When 21S4a, 21S4b, SV1a are ON. (Item No. 3)



Example: 3-minutes restart mode (Item No. 14)



2. LED display at initial setting

From power on until the completion of initial settings, the following information will be displayed on the monitor screen. (Displays No. 1 through No. 4 in order repeatedly.)

No	Item	Display	Remarks
1	Software version		[0103] : Version 1.03
2	Refrigerant type		[410]: R410A
3	Model and capacity		[H-20]: Cooling/Heating 20 HP For the first few minutes after power on, the capacity of each outdoor unit is displayed. Thereafter, the combined capacity is displayed.
4	Communication address		[51]: Address 51

After the initial settings have been completed, the information on these items can be checked by making the switch setting that corresponds to No. 517 in the LED display table.

Note

Only item No. 1 "Software Version" appears on the display if there is a wiring failure between the control board and the transmission line power supply board or if the circuit board has failed.

3. Time data storage function

The outdoor unit has a simple clock function that enables the unit to calculate the current time with an internal timer by receiving the time set by the system controller, such as G(B)-50A.

If an error (including a preliminary error) occurs, the error history data and the error detection time are stored into the service memory.

The error detection time stored in the service memory and the current time can be seen on the service LED.

Note


- 1) Use the time displayed on the service LED as a reference.
- 2) The date and the time are set to "00" by default. If a system controller that sets the time, such as G(B)-50A is not connected, the elapsed time and days since the first power on will be displayed.
 - If the time set on a system controller is received, the count will start from the set date and the time.
- 3) The time is not updated while the power of the indoor unit is turned off. When the power is turned off and then on again, the count will resume from the time before the power was turned off. Thus, the time that differs the actual time will be displayed. (This also applies when a power failure occurs.)

The system controller, such as G(B)-50A, adjusts the time once a day. When the system controller is connected, the time will be automatically updated to the correct current time after the time set by the system controller is received. (The data stored into the memory before the set time is received will not be updated.)

(1) Reading the time data:

1) Time display


Example: 12 past 9



* Disappears if the time data is deviated due to a power failure, or if a system controller that sets the time is not connected.


2) Date display

•When the main controller that can set the time is connected Example: May 10, 2003



* Appears between the year and the month, and nothing appears when the date is displayed.

•When the main controller that can set the time is not connected Example: 52 days after power was turned on



LED monitor display

Current data HWE0913A

Current data	rt data													
No.	SW1		Item				Display	olay				Unit (A, B) *1	t)*1	Remarks
	1234567890	<u> </u>		LD1	LD2	FD3	LD4	FD5	PDP	LD7	FD8	00	SO	
C	0000000000	Relay outpu Lighting	Relay output display 1 Lighting	Comp in op- eration				72C		00	CPU in oper- ation	A	A	
_ _		Check (error) OC/OS error	Check (error) display 1 OC/OS error			0000 to 99	0000 to 9999 (Address and error codes highlighted)	d error codes hi	ighlighted)			В	В	
-	1000000000	Check (error)	Check (error) display 2 OC/OS error			0000 to 99	0000 to 9999 (Address and error codes highlighted)	d error codes hi	ighlighted)			∢	∢	Display of the latest pre- liminary error If no preliminary errors are detected, "" ap- pears on the display.
2	0100000000	Check (error) display: (Including IC and BC)	Check (error) display 3 (Including IC and BC)			0000 to 99	0000 to 9999 (Address and error codes highlighted)	d error codes hi	ighlighted)			В		If no errors are detected, "" appears on the display.
c	440000000	Relay out-	Тор	21S4a		CH11		SV1a		SV2		<	<	
n	0000000	putuispiay 2	Bottom			21S4b	SV5b					τ	۲	
4	001000000	Relay outputdisplay	Тор	SV4a	SV4b	SV4c	SV5c		SV4d	8/\8	Power supply for indoor transmission line	∢	٨	
			Bottom								52F			
5	1010000000													
9	0110000000													
7	1110000000	Special control	ntrol	Retry opera- tion	Emergency					Communica- tion error be- tween the OC and OS	Communication error 3-minute restart delay mode	В	В	
8	0001000000													
6	1001000000	Communication de- mand capacity	ation de-				0000 to 9999	9999 c				В		If not demanded controlled, "" [%] appears on the display.
10	0101000000	Contact poi capacity	Contact point demand capacity				0000 to 9999	9999				В		If not demanded controlled, "" [%] appears on the display.
** - \	ditio to acitibacco	0,00	2010010	ndividually D. T	+ 40 acitibacc	Seinger Caited Od!		20,000						

Current data

סמוופוור ממנמ	ו ממומ										•		•	
o	SW1	Item	Ē				Display	olay				Unit (A, B) *1	*	Remarks
	1234567890	T	•	LD1	LD2	FD3	LD4	FD5	9Q7	LD7	FD8	20	SO	
7	1101000000	External signal (Open input contact point)	nal	Contact point de- mand	Low-noise mode (Capacity priority)	Snow sensor	Cooling- heating changeover (Cooling)	Cooling- heating changeover (Heating)				∢	∢	
12	0011000000	External signal (Open input contact point)	nal contact								Low-noise mode (Quiet priori- ty)	∢	∢	
13	1011000000													
4	0111000000	Outdoor unit operation status	t operation	BC operation signal		3-minutes restart mode	Compressor in operation	Preliminary error	Error	3-minutes restart after instanta- neous power failure	Preliminary low pres- sure error	∢	∢	
15	1111000000	OC/OS identification	ıtification				SO/OO	SO,				∢	⋖	
4	00001	Indoorunit	Top	Unit No. 1	Unit No. 2	Unit No. 3	Unit No. 4	Unit No. 5	Unit No. 6	Unit No. 7	Unit No. 8	В		The lamp that corre-
2	00000	check	Bottom	Unit No. 9	Unit No. 10	Unit No. 11	Unit No. 12	Unit No. 13	Unit No. 14	Unit No. 15	Unit No. 16			sponds to the unit that came to an abnormal stop
41	100010000		Тор	Unit No. 17	Unit No. 18	Unit No. 19	Unit No. 20	Unit No. 21	Unit No. 22	Unit No. 23	Unit No. 24			lights. The lamp goes off when
=			Bottom	Unit No. 25	Unit No. 26	Unit No. 27	Unit No. 28	Unit No. 29	Unit No. 30	Unit No. 31	Unit No. 32			the error is reset.
18	010010000		Тор	Unit No. 33	Unit No. 34	Unit No. 35	Unit No. 36	Unit No. 37	Unit No. 38	Unit No. 39	Unit No. 40			Each unit that comes to an abnormal unit will be
2			Bottom	Unit No. 41	Unit No. 42	Unit No.43	Unit No. 44	Unit No. 45	Unit No. 46	Unit No. 47	Unit No. 48			given a sequential num-
19	1100100000		Тор	Unit No. 49	Unit No. 50									starting with 1.
!			Bottom											
UC	001010000	Indoorunit	Top	Unit No. 1	Unit No. 2	Unit No. 3	Unit No. 4	Unit No. 5	Unit No. 6	Unit No. 7	Unit No. 8	В		Lit during cooling
04		Operation	Bottom	Unit No. 9	Unit No. 10	Unit No. 11	Unit No. 12	Unit No. 13	Unit No. 14	Unit No. 15	Unit No. 16			Blinking during neating Unlit while the unit is
24	101010000		Тор	Unit No. 17	Unit No. 18	Unit No. 19	Unit No. 20	Unit No. 21	Unit No. 22	Unit No. 23	Unit No. 24			stopped or in the fan
7			Bottom	Unit No. 25	Unit No. 26	Unit No. 27	Unit No. 28	Unit No. 29	Unit No. 30	Unit No. 31	Unit No. 32			
22	041010000	ı	Тор	Unit No. 33	Unit No. 34	Unit No. 35	Unit No. 36	Unit No. 37	Unit No. 38	Unit No. 39	Unit No. 40			
7			Bottom	Unit No. 41	Unit No. 42	Unit No.43	Unit No. 44	Unit No. 45	Unit No. 46	Unit No. 47	Unit No. 48			
86	1110100000		Top	Unit No. 49	Unit No. 50									
3			Bottom											
*1 ^ Th	to acitibaco of	oi on or or or ic	مز امریراموزاه وز	The The Table of The	+ to acitibaco	the entire refrige	oi motoros tacrosintos	المريماموناه وز						

- 360 -

*1 A: The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerant system is displayed.

Current data

urrent data	. nata													
ON	SW1	Item	E				Display	olay				Unit (A, B) *1	t)*1	Remarks
	1234567890	1		LD1	LD2	FD3	LD4	FD5	9Q7	LD7	RD8	00	SO	
2	0000110000	٦it	Тор	Unit No. 1	Unit No. 2	Unit No. 3	Unit No. 4	Unit No. 5	Unit No. 6	Unit No. 7	Unit No. 8	В		Lit when thermostat is on
† 7		tnermo- stat	Bottom	Unit No. 9	Unit No. 10	Unit No. 11	Unit No. 12	Unit No. 13	Unit No. 14	Unit No. 15	Unit No. 16			Unlit when thermostat is off
70	1000110000	I	Тор	Unit No. 17	Unit No. 18	Unit No. 19	Unit No. 20	Unit No. 21	Unit No. 22	Unit No. 23	Unit No. 24			
S			Bottom	Unit No. 25	Unit No. 26	Unit No. 27	Unit No. 28	Unit No. 29	Unit No. 30	Unit No. 31	Unit No. 32			
90	010110000	Π	Тор	Unit No. 33	Unit No. 34	Unit No. 35	Unit No. 36	Unit No. 37	Unit No. 38	Unit No. 39	Unit No. 40			
0	00000		Bottom	Unit No. 41	Unit No. 42	Unit No.43	Unit No. 44	Unit No. 45	Unit No. 46	Unit No. 47	Unit No. 48			
7.0	1101100000	I	Тор	Unit No. 49	Unit No. 50									
Ĩ.			Bottom											
28	0011100000													
29	10111100000													
30	0111100000													
31	1111100000													
32	000010000													
33	1000010000													
34	0100010000													
35	1100010000													
36	0010010000													
37	1010010000	BC operation mode	n mode	Cooling-only ON	Cooling-only OFF	Heating-only ON	Heating-only OFF	Mixed-mode ON	Mixed-mode OFF	Fan	Stop	В		
38	0110010000													
39	1110010000	Outdoor unit Operation mode	t Operation	Permissible stop	Standby	Cooling	Cooling- main	Heating	Heating- main			∢	∢	
40	0001010000													
14	1001010000													
42	0101010000	Outdoor unit control mode	t control	Stop	Thermo OFF	Abnormal stop	Scheduled	Initial start up	Defrost	Oil balance	Low fre- quency oil recovery	∢	∢	
43	1101010000				Refrigerant recovery							Α	А	
44	0011010000													
A: The	A: The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerant system is displayed.	ner OC or OS is	s displayed in	ndividually. B: Th	ne condition of	the entire refrige	erant system is	displayed.						

a	
Ţ	
ಹ	
0	
=	
<u>_</u>	
æ	
-	
≐	
\neg	
()	

	י ממימ												
No.	SW1	Item				Dis	Display				Unit (A, B) *1) *1	Remarks
	1234567890		LD1	LD2	LD3	LD4	FD2	PD9	LD7	FD8	20	SO	
45	1011010000	TH4				-99.9 tr	-99.9 to 999.9				∢	Α	The unit is [°C]
46	0111010000	ТНЗ				-99.9 tr	-99.9 to 999.9				A	А	
47	1111010000	TH7				-99.9 tc	-99.9 to 999.9				4	Α	
48	0000110000	ТН6				-99.9 tc	-99.9 to 999.9				∢	4	
49	1000110000												
20	0100110000	TH5				-99.9 tc	-99.9 to 999.9				∢	A	
51	1100110000												
52	0010110000												
53	1010110000												
54	0110110000												
22	1110110000												
99	0001110000	THHS1				-99.9 tr	-99.9 to 999.9				∢	Α	The unit is [°C]
22	1001110000												
28	0101110000	High-pressure sensor data	_			-99.9 tr	-99.9 to 999.9				A	٧	The unit is [kgf/cm ²]
29	1101110000	Low-pressure sensor data				-99.9 tr	-99.9 to 999.9				A	⋖	
09	001111000												
61	1011110000												
62	0111110000												
63	1111110000												
64	0000001000												
9	1000001000												
99	0100001000												
29	1100001000												
89	0010001000												
69	1010001000												
20	0110001000												
71	1110001000												
*1 A: Th	ne condition of eith	*1 A: The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerant system is displayed.	ndividually. B: T.	he condition of t	the entire refrigε	erant system is	displayed.						

HWE0913A - 362 -

Current data

No.	SW1	Item					Display				Unit (A, B) *1	iit 3) *1	Remarks
	1234567890		LD1	LD2	FD3	LD4	FD5	9G7	LD7	RD8	၁၀	SO	
72	0001001000												
73	1001001000												
74	0101001000												
75	1101001000												
9/	0011001000												
77	1011001000												
78	0111001000	Σ Qj				0000	0000 to 9999				В	В	
62	1111001000	Σ Qjc				0000	0000 to 9999				В	В	
80	0000101000	∑ Qjh)000	0000 to 9999				В	В	
81	1000101000	Target Tc				5.66-	-99.9 to 999.9				В		The unit is [°C]
82	0100101000	Target Te				5.66-	-99.9 to 999.9				В		
83	1100101000	Tc				5.66-	-99.9 to 999.9				A	۷	
84	0010101000	Те				5.66-	-99.9 to 999.9				A	⋖	
85	1010101000												
98	0110101000	Total frequencies (OC+OS))000	0000 to 9999				В		Control data [Hz]
87	1110101000	Total frequency of each unit)000	0000 to 9999				٧	٨	
88	0001101000	COMP frequency)000	0000 to 9999				∢	⋖	
68	1001101000												
06	0101101000												
91	1101101000	COMP operating frequency				0000	0000 to 9999				Ą	٧	The unit is [rps]Output frequency of the inverter depends on the type of compressor and equals the integer multiples (v1
													frequency of the com- frequency of the com- pressor.
95	0011101000												
93	1011101000	All AK (OC+OS))000	0000 to 9999				В		
1 A: Th	e condition of eith	1 A: The condition of either OC or OS is displayed individually. B: The condition of	ndividually. B: 1	The condition of	the entire refr	the entire refrigerant system is displayed.	is displayed.						

Current data

o N	SW1	Item				Disk	Display				Unit (A, B) *1	iit *1	Remarks
	1234567890	1	LD1	LD2	LD3	LD4	FD5	9G7	LD7	PD8	20	SO	
94	0111101000	AK				0000 tc	0000 to 9999				∢	4	
92	1111101000	FAN				0000 tc	0000 to 9999				∢	٧	Fan output [%]
96	000011000	Fan inverter output frequency				0000 tc	0000 to 9999				∢	⋖	Twice the actual output frequency
26	1000011000												
86	0100011000												
66	1100011000												
100	00110011000												
101	1010011000												
102	0110011000												
103	1110011000												
104	000111000												
105	1001011000												
106	0101011000												
107	1101011000												
108	0011011000	COMP operating current (DC)				00.0 tc	00.0 to 999.9				⋖	A	Peak value[A]
109	1011011000												
110	0111011000												
111	1111011000	COMP bus voltage				00.0 tc	00.0 to 999.9				∢	A	The unit is [V]
112	0000111000												
113	1000111000												
114	0100111000												
115	1100111000												
116	0010111000	Number of times the unit went into the mode to remedy wet vapor suction				0000 to	0000 to 9999				В		
*1 A: T	ne condition of eith	*1 A: The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerant system is displayed.	ndividually. B: Ti	he condition of the	entire refrigers	ant system is	displayed.						

Current data

No.	SW1	Item				Display	olay				Unit (A, B) *1	iit 3) *1	Remarks
	1234567890		LD1	LD2	LD3	LD4	FD5	9Q7	LD7	PD8	00	SO	
117	1010111000	COMP Operation time Upper 4 digits				0000 tc	0000 to 9999				∢	4	The unit is [h]
118	0110111000	COMP Operation time Lower 4 digits				0000 to 9999	o 9999				∢	٧	
119	1110111000												
120	0001111000												
121	1001111000	Backup mode	Abnormal pressure rise	High-pres- sure drop	Low-pres- sure drop	Abnormal Td rise	High-pres- sure during defrost cycle	Control box temperature rise			∢	∢	Stays lit for 90 seconds after the completion of backup control
122	0101111000												
123	1101111000	COMP number of start- stop events Upper 4 digits				0000 to 9999	o 9999				∢	⋖	Count-up at start-up The unit is [Time]
124	0011111000	COMP number of start- stop events Lower 4 digits				0000 tc	0000 to 9999				A	Α	
125	1011111000												
126	0111111000												
127	1111111000												
128	0000000100												
129	1000000100	Integrated operation time of compressor (for rotation purpose)				0000 to 9999	6666 c				В		The unit is [h]
130	0100000100												
131	1100000100												
**	191 - 3		F C		a mindan anitana ani	al among a form	-						

^{*1} A: The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerant system is displayed.

Current data

סמוופוור ממנמ	ו מפופ												٠		
O	SW1	Ite	Item				Display	ılay				Unit (A, B) *1	t	Remarks	
	1234567890	1		LD1	LD2	FD3	LD4	FD5	9Q7	LD7	PD8	00	SO		
130	0040000400	Relay out-	Тор	SVM1	SVM2	SVM1b	SVM2b					α			
725	000000000000000000000000000000000000000	putdisplay BC(Main)	Bottom									۵	l		
122	1040000400	ı	Тор	SVA1	SVB1	SVC1	SVA2	SVB2	SVC2			٥			
3			Bottom	SVA3	SVB3	SVC3	SVA4	SVB4	SVC4			۵	l		
124	0110000100	ı	Тор	SVA5	SVB5	SVC5	SVA6	SVB6	SVC6			٥			
<u>+</u>			Bottom	SVA7	SVB7	SVC7	SVA8	SVB8	SVC8			۵	1		
125	77	1	Тор	SVA9	SVB9	SVC9	SVA10	SVB10	SVC10			٥			
2	00000		Bottom	SVA11	SVB11	SVC11	SVA12	SVB12	SVC12			۵	l		
136	00001000	ı	Тор	SVA13	SVB13	SVC13	SVA14	SVB14	SVC14			α			
2			Bottom	SVA15	SVB15	SVC15	SVA16	SVB16	SVC16			۵	l		
137	1001000100														
138	04000400	Relay out-	Тор	SVA1	SVB1	SVC1	SVA2	SVB2	SVC2			a			
9		BC(Sub1)	Bottom	SVA3	SVB3	SVC3	SVA4	SVB4	SVC4			۵	<u>I</u>		
130	1101000100	T	Тор	SVA5	SVB5	SVC5	SVA6	SVB6	SVC6			α			
5			Bottom	SVA7	SVB7	SVC7	SVA8	SVB8	SVC8			۵	l		
140	0041000100	ı	Тор	SVA9	SVB9	SVC9	SVA10	SVB10	SVC10			α			
5			Bottom	SVA11	SVB11	SVC11	SVA12	SVB12	SVC12			۵	l		
171	1041000100	ı	Тор	SVA13	SVB13	SVC13	SVA14	SVB14	SVC14			α			
<u>-</u>			Bottom	SVA15	SVB15	SVC15	SVA16	SVB16	SVC16			<u> </u>	l		
142	0111000100														
F . 4	die de moitibule e	00.00	" C C C C C C C C C	T. O	4+ to acitibace od	oninger oninge out	in all and a second	Los colos il							_

*1 A: The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerant system is displayed.

Current data

No.	SW1		Item				Display	ılay				Unit (A, B) *1	~	Remarks
•	1234567890			LD1	LD2	FD3	LD4	FD5	PDP	LD7	FD8	00	SO	
67.7	1111000100	Relay out-	Тор	SVA1	SVB1	SVC1	SVA2	SVB2	SVC2			α		
2		purdisplay BC(Sub2)	Bottom	SVA3	SVB3	SVC3	SVA4	SVB4	SVC4			<u> </u>		
77	0000000000	ı	Тор	SVA5	SVB5	SVC5	SVA6	SVB6	SVC6			α		
<u> </u>	00000		Bottom	SVA7	SVB7	SVC7	SVA8	SVB8	SVC8			ם		
145	1000100100		Тор	SVA9	SVB9	SVC9	SVA10	SVB10	SVC10			α		
2			Bottom	SVA11	SVB11	SVC11	SVA12	SVB12	SVC12			ם		
176	0010010010	1	Тор	SVA13	SVB13	SVC13	SVA14	SVB14	SVC14			a		
0	0010010		Bottom	SVA15	SVB15	SVC15	SVA16	SVB16	SVC16			Δ		
147	1100100100								•					
148	0010100100													
149	1010100100	BC(Main or standard) TH11	r standard)				-99.9 to 999.9	6.666				В		
150	0110100100	BC(Main)TH12	H12				-99.9 to 999.9	6.666				В		
151	1110100100	BC(Main)TH15	H15				-99.9 to 999.9	6.999.9				В		
152	0001100100	BC(Main)TH16	H16				-99.9 to 999.9	6.999.9				В		
153	1001100100	BC(Main)63HS1	3HS1				-99.9 to 999.9	6.999.9				В		
154	0101100100	BC(Main)63HS3	3HS3				-99.9 to 999.9	6.999.9				В		
155	1101100100	BC(Main)SC11	C11				-99.9 to 999.9	6.999.9				В		
156	0011100100	BC(Main)SH12	H12				-99.9 to 999.9	6.666				В		
157	1011100100	BC(Main)SH13	H13				-99.9 to 999.9	6.666				В		
158	0111100100	BC(Main)SC16	C16				-99.9 to 999.9	6.999.9				В		
159	1111100100	BC(Main)LEV1	EV1				0000 to 2000	, 2000				В	LE (F	LEV1 opening (Fully open:2000)
160	0000010100	BC(Main)LEV3	EV3				0000 to 2000	, 2000				В	# E	LEV3 opening (Fully open:2000)
161	1000010100	BC(Sub1)TH12	.H12				-99.9 to 999.9	6.666				В		
162	0100010100	BC(Sub1)TH15	.H15				-99.9 to 999.9	6.666				В		
163	1100010100	BC(Sub1)LEV3	EV3				0000 to 2000	, 2000				В	E E	LEV3 opening (Fully open:2000)
1 A: Th	1.4. The condition of either OC or OS is displayed individually. B. The condition of the entire refrigerant system is displayed	er OC or OS	is displayed in	ndividually. B: T	ne condition of t	he entire refrige	rant system is o	lisplayed						

*1 A: The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerant system is displayed.

	ı	ŗ	ū
	۲	b	
	_	S	Q
	7	C	2
	ij	Ċ	
	í	a	b
	ì	ī	_
	B	4	
	Ġ		2
ì	C		١

ſ														
	SW1	Item					Display	,				, (À	Unit (A, B) *1	Remarks
_	1234567890		LD1	LD2	FD3	LD4		FD5	PDP	LD7	PD8	00	SO	
_	0010010100	BC(Sub2)TH12				6-	-99.9 to 999.9	99.9				В		
_	1010010100	BC(Sub2)TH25				ô-	-99.9 to 999.9	99.9				ш		
	0110010100	BC(Sub2)LEV3				Ó	0000 to 2000	000				М		LEV3a opening (Fully open:2000)
	1110010100	BC(Main)LEV2				0	0000 to 2000	000				В		LEV2 opening (Fully open:2000)
	0001010100													
	1001010100													
	0101010100													
	1101010100													
	0011010100													
	1011010100													
	0111010100													
	1111010100													
	0000110100													
	1000110100													

Current data

Current data	t data												
No.	SW1	Item				Display	olay				Unit (A, B) *1	it .) *1	Remarks
	1234567890		LD1	LD2	FD3	LD4	FD5	9G7	LD7	PD8	00	SO	
178	0100110100	Error history 1				0000 to 9999	9666 0				В	В	Address and error codes
179	1100110100	Error details of inverter			Ш	Error details of inverter (0001-0120)	erter (0001-012)	0)			∢	⋖	nigniignted If no errors are detected,
180	0010110100	Error history 2				0000 to 9999	6666 0				В	В	" " appears on the dis-
181	1010110100	Error details of inverter			Ш	Error details of inverter (0001-0120)	erter (0001-012)	0)			∢	⋖	Preliminary error informa-
182	0110110100	Error history 3				0000 to 9999	9666				В	В	tion of the OS does not appear on the OC.
183	1110110100	Error details of inverter			Ш	Error details of inverter (0001-0120)	erter (0001-012t	(0			∢	A	Neither preliminary error
184	0001110100	Error history 4				0000 to 9999	9888				В	В	error information of the IC
185	1001110100	Error details of inverter			Ш	Error details of inverter (0001-0120)	erter (0001-012t	(0			∢	4	appears on the OS.
186	0101110100	Error history 5				0000 to 9999	9888				В	В	
187	1101110100	Error details of inverter			Ш	Error details of inverter (0001-0120)	erter (0001-012	(0			∢	А	
188	0011110100	Error history 6				0000 to 9999	6666 (В	В	
189	10111110100	Error details of inverter			Ш	Error details of inverter (0001-0120)	erter (0001-012	0)			∢	∢	
190	0111110100	Error history 7				0000 to 9999	9888				В	В	
191	1111110100	Error details of inverter			Ш	Error details of inverter (0001-0120)	erter (0001-012	(0			∢	⋖	
192	0000001100	Error history 8				0000 to 9999	6666 (В	В	
193	1000001100	Error details of inverter			Ш	Error details of inverter (0001-0120)	erter (0001-012	0)			∢	∢	
194	0100001100	Error history 9				0000 to 9999	9888				В	В	
195	1100001100	Error details of inverter			Ш	Error details of inverter (0001-0120)	erter (0001-012	(0			∢	⋖	
196	0010001100	Error history 10				0000 to 9999	9888				В	В	
197	1010001100	Error details of inverter			Ш	Error details of inverter (0001-0120)	erter (0001-0120	(0			∢	4	
198	0110001100	Error history of inverter (At the time of last data backup before error)				0000 to 9999	9999				Ф	В	
199	1110001100	Error details of inverter			Ш	Error details of inverter (0001-0120)	erter (0001-012)	(0			∢	∢	
200	0001001100												
*1 A·Th	dia on dition of aith	*1 A. The condition of either OC or OS is disclaved individually. B. The condition of the entire refrigerant evetem is disclaved	T.A. VIendividu	he condition of	the entire refric	nerant eyetem ie c	henleyed						

*1 A: The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerant system is displayed.

Data before error

Dale	Data perore error												
No.	SW1	Item				Display	olay				Unit (A, B) *1) *1	Remarks
	1234567890	ı	LD1	LD2	FD3	LD4	FD5	9U7	LD7	PD8	00	SO	
201	1001001100	Outdoor unit operation status	BC opera- tion signal		3-minutes restart mode	Compressor in operation	Preliminary error	Error	3-minutes restart after instanta- neous power failure	Preliminary low pres- sure error	∢	∢	
202	0101001100	OC/OS identification				SO/OO	SO/				٧	۷	
203	1101001100	BC operation mode	Cooling-only ON	Cooling-only OFF	Heating-only ON	Heating-only OFF	Mixed-mode ON	Mixed-mode OFF	Fan	Stop	∢	∢	
204	0011001100												
205	1011001100	Outdoor unit Operation mode	Permissible stop	Standby	Cooling	Cooling- main	Heating	Heating- main			∢	∢	
206	0111001100												
207	, 1111001100												
208	0000101100	Outdoor unit control mode	Stop	Thermo OFF	Abnormal stop	Scheduled	Initial start up	Defrost	Oil balance	Low fre- quency oil recovery	٧	٧	
209	1000101100			Refrigerant recovery							4	⋖	
210	0100101100												
211	1100101100	Relay output display 1 Lighting	Comp in op- eration				72C		00	Always lit	∢	∢	
212	0010101100	Relay out- putdisplay 2 Bottom Lighting	21S4a		CH11	SV5b	SV1a		SV2		∢	∢	
213	1010101100	Relay outputdisplay 3 Lighting	SV4a	SV4b	SV4c	SV5c		SV4d	6/\S	Lit while power to the indoor units is being sup- plied	∢	∢	
		Bottom								52F			
214													
215	1110101100												

*1 A: The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerant system is displayed.

HWE0913A - 370 -

Data before error

המומ הא													
No.	SW1	ltem				Display	olay				Unit (A, B) *1	it () *1	Remarks
	1234567890		LD1	LD2	LD3	LD4	FD5	PD9	LD7	FD8	00	SO	
216	0001101100	TH4				-99.9 to 999.9	6.666.0				∢	٧	The unit is [°C]
217	1001101100	TH3				-99.9 tc	-99.9 to 999.9				∢	٧	
218	011101100	TH7				-99.9 tc	-99.9 to 999.9				∢	٧	
219	1101101100	TH6				-99.9 tc	-99.9 to 999.9				∢	٧	
220	0011101100												
221	1011101100	TH5				-99.9 to 999.9	6.666.0				∢	A	
222	0111101100												
223	111111100												
224	0000011100												
225	1000011100												
226	0100011100												
227	1100011100	THHS1				-99.9 to 999.9	6.666.0				∢	4	The unit is [°C]
228	0011100100												
229	1010011100	High-pressure sensor data				-99.9 tc	-99.9 to 999.9				٨	A	The unit is [kgf/cm²]
230	01110011100	Low-pressure sensor data				-99.9 to 999.9	999.9				∢	٨	
231	1110011100												
232	0001011100												
233	1001011100												
234	0101011100												
235	1101011100												
236	0011101100												
237	1011011100												
238	0111011100												
239	1111011100												
240	0000111100												
241	1000111100												
242	0100111100												
*1 A: T	he condition of eith	*1 A: The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerant system is displayed.	individually. B: T	The condition of t	the entire refrige	erant system is	displayed.						

HWE0913A - 371

Data before error

Dala D	Data perofe effor												
No.	SW1	Item				Dis	Display				Unit (A, B) *1	it	Remarks
	1234567890	I	LD1	LD2	FD3	LD4	FD5	9G7	LD7	PD8	00	SO	
243	1100111100												
244	001111100												
245	1010111100												
246	0110111100												
247	1110111100												
248	0001111100												
249	1001111100	Σαj				0000	0000 to 9999				В	В	
250	0101111100	Σ Qjc				0000	0000 to 9999				В	В	
251	1101111100	Σ Qjh				0000	0000 to 9999				В	В	
252	0011111100	Target Tc				-99.9 tc	-99.9 to 999.9				В		The unit is [°C]
253	1011111100	Target Te				-99.9 te	-99.9 to 999.9				В		
254	0111111100	Tc				-99.9 tr	-99.9 to 999.9				∢	۷	The unit is [°C]
255	111111100	Те				-99.9 t	-99.9 to 999.9				Α	Α	
256	0000000010												
257	1000000010	Total frequencies (OC+OS)				0000 t	0000 to 9999				В		Control data [Hz]
258	0100000010	Total frequency of each unit				0000 t	0000 to 9999				٨	4	
259	1100000010	COMP frequency				0000	0000 to 9999				∢	4	
260	0010000010												
261	1010000010												
262	0110000010												
263	1110000010												
264	00001000010	All AK (OC+OS)				1 0000	0000 to 9999				В		
265	1001000010	АК				1 0000	0000 to 9999				A	А	
266	0101000010	FAN				0000 t	0000 to 9999				٨	Ą	Fan inverter output [%]
267	110100010	Fan inverter output frequency				0000 t	0000 to 9999				∢	٧	Twice the actual output frequency
*4 A. Tho	ho condition of oit	ther OC or OS is displayed in	A VIII DE LE	The condition of the	the entire refrie	si motava tacaar	povelusion						

Data before error

חמום הו	Data perore error												
No.	SW1	Item				ΙΩ	Display				Unit (A, B) *1	it ;) *1	Remarks
	1234567890		LD1	LD2	FD3	LD4	FD5	9Q7	LD7	PD8	00	SO	
268	0011000010												
269	1011000010												
270	0111000010												
271	1111000010												
272	0000100010												
273	1000100010												
274	0100100010												
275	1100100010												
276	0010100010												
277	1010100010												
278	0110100010												
279	1110100010	COMP operating current (DC)				0.00	00.0 to 999.9				∢	∢	Peak value[A]
280	0001100010												
281	1001100010												
282	01001100010	COMP bus voltage				0.00	00.0 to 999.9				∢	4	The unit is [V]
283	1101100010												
284	0011100010												
285	1011100010												
286	0111100010												
287	1111100010												
288	0000010010	COMP Operation time Upper 4 digits				0000	0000 to 9999				⋖	٨	The unit is [h]
289	1000010010	COMP Operation time Lower 4 digits				0000	0000 to 9999				∢	⋖	
290	0100010010												
291	1100010010												
292	0010010010												
293	1010010010												
*1 A: T	ne condition of eitl	*1 A: The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerant system is displayed.	ndividually. B: 7	The condition of	the entire refr	igerant system	is displayed.						

HWE0913A - 373 -

Data before error

No.	SW1	Item				Dis	Display				Unit (A, B) *1	it)*1	Remarks
	1234567890		LD1	LD2	FD3	LD4	FD5	9G7	LD7	PD8	00	SO	
294	0110010010	COMP number of start- stop events Upper 4 digits				1 0000	0000 to 9999				∢	٧	Count-up at start-up The unit is [Time]
295	1110010010	COMP number of start- stop events Lower 4 digits				1 0000	0000 to 9999				∢	٧	
296	0001010010												
297	1001010010												
298	010101010												
299	1101010010												
300	0011010010	Integrated operation time of compressor (for rotation purpose)				1 0000	0000 to 9999				В		The unit is [h]
i													

9	Q
7	σ
7	3
4	_
3	Ξ
3	_
1	=
2	₹

No.	SW1	ltem				Display				Unit (A, B)*1	it 3)*1	Remarks
	1234567890		LD1	LD2	LD3 LD4	FD2	9D7	LD7	FD8	00	SO	
301	1011010010	Power supply unit			0/20	OC/OS <-> Address				В		
302	0111010010	Start-up unit			0/00	OC/OS <-> Address				В		
303	1111010010											
304	0000110010											
305	1000110010											
306	0100110010											
307	1100110010											
308	0010110010											
309	1010110010											
310	0110110010											
311	1110110010											
312	0001110010											
313	1001110010											
314	0101110010											
315	1101110010											
316	0011110010											
317	1011110010											
318	0111110010											
319	1111110010											
320	0000001010	BC(Main)TH11			6-	-99.9 to 999.9				В		
321	1000001010	BC(Main)TH12			6-	-99.9 to 999.9				В		
322	0100001010	BC(Main)TH15			6-	-99.9 to 999.9				В		
323	1100001010	BC(Main)TH16			6-	-99.9 to 999.9				В		
324	0010001010	BC(Main)PS1			6-	-99.9 to 999.9				В		
325	1010001010	BC(Main)PS3			6-	-99.9 to 999.9				В		
326	0110001010											
327	1110001010											
1 A: T	ne condition of eitl	1 A: The condition of either OC or OS is displayed individually. B: The condition of	ndividually. B:	The condition of the e	the entire refrigerant system is displayed	em is displayed.						

HWE0913A - 375 -

Current data

Current data	ır data												
O	SW1	ltem				Display	olay				Unit (A, B)*1	it 3)*1	Remarks
	1234567890		LD1	LD2	FD3	LD4	FD5	9U7	LD7	PD8	00	SO	
328	0001001010												
329	1001001010												
330	0101001010	BC(Main)LEV1				0000 to 2000	5 2000				В		
331	1101001010	BC(Main)LEV3				0000 to 2000	5 2000				В		
332	0011001010	BC(Sub1)TH12				-99.9 tc	-99.9 to 999.9				В		
333	1011001100	BC(Sub1)TH15				-99.9 tc	-99.9 to 999.9				В		
334	0111001010	BC(Sub1)LEV3				0000 to 2000	5 2000				В		
335	1111001010	BC(Sub2)TH12				-99.9 tc	-99.9 to 999.9				В		
336	0000101010	BC(Sub2)TH15				-99.9 tc	-99.9 to 999.9				В		
337	1000101010	BC(Sub2)LEV3				0000 to 2000	5 2000				В		
338	0100101010	BC(Main)LEV2				0000 tc	0000 to 2000				В		
339	1100101010												
340	0010101010												
341	1010101010												
342	0110101010												
343	1110101010												
344	0001101010												
345	1001101010												
346	0101101010												
347	1101101010												
348	0011101010												
349	1011101010												
350	0111101010												
*4	drie de meitikenen en	:	H . C	14 3 14 (4	minhan anitana a alt	of one has so her one	L 01.10 11.0						

*1 A: The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerant system is displayed.

Data on indoor unit system

												-	
No.	SW1	ltem				Display	ılay				Unit (A, B) *1	,* (Remarks
	1234567890		LD1	LD2	FD3	LD4	FD5	PDP	LD7	FD8	00	SO	
351	1111101010	IC1 Address/capacity code		0000 to 9999	6666			0000 to 9999	6666		В		Displayed alternately ev-
352	0000011010	IC2 Address/capacity code		0000 to 9999	6666			0000 tc	0000 to 9999				ery 5 seconds
353	1000011010	IC3 Address/capacity code		0000 to 9999	6666			0000 to 9999	6666				
354	0100011010	IC4 Address/capacity code		0000 to 9999	6666			0000 to 9999	6666				
355	1100011010	IC5 Address/capacity code		0000 to 9999	6666			0000 tc	0000 to 9999				
356	0010011010	IC6 Address/capacity code		0000 to 9999	6666			0000 to 9999	6666				
357	1010011010	IC7 Address/capacity code		0000 to 9999	6666			0000 to 9999	6666				
358	0110011010	IC8 Address/capacity code		0000 to 9999	6666			0000 to 9999	6666				
359	1110011010	IC9 Address/capacity code		0000 to 9999	6666			0000 to 9999	6666				
360	0001011010	IC10 Address/capacity code		0000 to 9999	6666			0000 to 9999	6666				
361	1001011010	IC11 Address/capacity code		0000 to 9999	6666			0000 to 9999	6666				
362	0101011010	IC12 Address/capacity code		0000 to 9999	6666			0000 to 9999	6666				
363	1101011010	IC13 Address/capacity code		0000 to 9999	6666			0000 to 9999	6666				
364	0011011010	IC14 Address/capacity code		0000 to 9999	6666			0000 to 9999	6666				
365	1011011010	IC15 Address/capacity code		0000 to 9999	6666			0000 to 9999	6666				
366	0111011010	IC16 Address/capacity code		0000 to 9999	6666			0000 to 9999	6666				
367	1111011010	IC17 Address/capacity code		0000 to 9999	6666			0000 to 9999	6666				
*	dio to acitibaco od	*4 A. The condition of either OP or OS is displayed individually D. The condition of the paties reference and an ablanced	II. B. The con	dition of the on	tacacociatos cait	- 0:00000000000000000000000000000000000	00,00				-		

Data on indoor unit system

0 0 0	Item							(A, B)		Remarks
1234567890	T	LD1	LD2	LD3 LD4	FD5	7 PDP PDP	FD8	00	SO	
0000111010	10 IC18 Address/capacity code		0000 to 9999	66		0000 to 9999	_	В		Displayed alternately ev-
1000111010	10 IC19 Address/capacity code		0000 to 9999	66		0000 to 9999				ery 5 seconds
0100111010	10 IC20 Address/capacity code		0000 to 9999	66		0000 to 9999				
1100111010	10 IC21 Address/capacity code		0000 to 9999	66		0000 to 9999				
0010111010	10 IC22 Address/capacity code		0000 to 9999	66		0000 to 9999				
1010111010	10 IC23 Address/capacity code		0000 to 9999	66		0000 to 9999				
0110111010	10 IC24 Address/capacity code		0000 to 9999	66		0000 to 9999				
1110111010	10 IC25 Address/capacity code		0000 to 9999	66		0000 to 9999				
0001111010	10 IC26 Address/capacity code		0000 to 9999	66		0000 to 9999				
1001111010	10 IC27 Address/capacity code		0000 to 9999	66		0000 to 9999				
0101111010	10 IC28 Address/capacity code		0000 to 9999	66		0000 to 9999				
1101111010	10 IC29 Address/capacity code		0000 to 9999	66		0000 to 9999				
0011111010	10 IC30 Address/capacity code		0000 to 9999	66		0000 to 9999				
1011111010	10 IC31 Address/capacity code		0000 to 9999	66		0000 to 9999				
0111111010	10 IC32 Address/capacity code		0000 to 9999	66		0000 to 9999				
1111111010	10 IC33 Address/capacity code		0000 to 9999	66		0000 to 9999				
0000000110	10 IC34 Address/capacity code		0000 to 9999	66		0000 to 9999				
1000000110	10 IC35 Address/capacity code		0000 to 9999	66		0000 to 9999				
0100000110	10 IC36 Address/capacity code		0000 to 9999	66		0000 to 9999				
1100000110	10 IC37 Address/capacity code		0000 to 9999	96		0000 to 9999				
0010000110	10 IC38 Address/capacity code		0000 to 9999	66		0000 to 9999				
1010000110	10 IC39 Address/capacity code		0000 to 9999	66		0000 to 9999				
0110000110	10 IC40 Address/capacity code		0000 to 9999	66		0000 to 9999				
1110000110	10 IC41 Address/capacity code		0000 to 9999	66		0000 to 9999				
0001000110	10 IC42 Address/capacity code		0000 to 9999	66		0000 to 9999				
1001000110	10 IC43 Address/capacity code		0000 to 9999	66		0000 to 9999				
0101000110	10 IC44 Address/capacity code		0000 to 9999	66		0000 to 9999				
1101000110	10 IC45 Address/capacity code		0000 to 9999	66		0000 to 9999				

Data on indoor unit system

	ltem				Dis	Display				Unit (A, B) *1	ıit 3) *1	Remarks
Т		LD1	LD2	FD3	LD4	FD5	9Q7	LD7	LD8	00	SO	
0011000110	IC46 Address/capacity code		0000	0000 to 9999			0000 tc	0000 to 9999		В		Displayed alternately ev-
1011000110	IC47 Address/capacity code		0000	0000 to 9999			0000 tc	0000 to 9999				ery 5 seconds
01110001110	IC48 Address/capacity code		0000	0000 to 9999			0000 tc	0000 to 9999				
1111000110	IC49 Address/capacity code		0000	0000 to 9999			0000 tc	0000 to 9999				
0000100110	IC50 Address/capacity code		0000	0000 to 9999			0000 tc	0000 to 9999				
1000100110												
0100100110												
1100100110												
0010100110												
1010100110												
0110100110												
1110100110												
0001100110	IC1 Suction temperature				-99.9 tc	-99.9 to 999.9				В		The unit is [°C]
1001100110	IC2 Suction temperature				-99.9 tc	-99.9 to 999.9						
0101100110	IC3 Suction temperature				-99.9 tc	-99.9 to 999.9						
1101100110	IC4 Suction temperature				-99.9 tc	-99.9 to 999.9						

- 379 -

Data on indoor unit system

	6												
No.	SW1	ltem				Disp	Display				Unit (A, B) *1	t 1,1	Remarks
	1234567890		LD1	LD2	FD3	LD4	FD5	PDP PDP	LD7	PD8	00	SO	
412	0011100110	IC5 Suction temperature				-99.9 tc	-99.9 to 999.9				В		The unit is [°C]
413	1011100110	IC6 Suction temperature				-99.9 tc	-99.9 to 999.9						
414	01111001110	IC7 Suction temperature				-99.9 tc	-99.9 to 999.9						
415	1111100110	IC8 Suction temperature				-99.9 tc	-99.9 to 999.9						
416	0000010110	IC9 Suction temperature				-99.9 tc	-99.9 to 999.9						
417	1000010110	IC10 Suction temperature				-99.9 tc	-99.9 to 999.9						
418	0100010110	IC11 Suction temperature				-99.9 tc	-99.9 to 999.9						
419	1100010110	IC12 Suction temperature				-99.9 tc	-99.9 to 999.9						
420	0010010110	IC13 Suction temperature				-99.9 tc	-99.9 to 999.9						
421	1010010110	IC14 Suction temperature				-99.9 tc	-99.9 to 999.9						
422	0110010110	IC15 Suction temperature				-99.9 tc	-99.9 to 999.9						
423	1110010110	IC16 Suction temperature				-99.9 tc	-99.9 to 999.9						
424	0001010110	IC17 Suction temperature				-99.9 tc	-99.9 to 999.9						
425	1001010110	IC18 Suction temperature				-99.9 tc	-99.9 to 999.9						
426	0101010110	IC19 Suction temperature				-99.9 tc	-99.9 to 999.9						
427	1101010110	IC20 Suction temperature				-99.9 tc	-99.9 to 999.9						
428	0011010110	IC21 Suction temperature				-99.9 tc	-99.9 to 999.9						
429	1011010110	IC22 Suction temperature				-99.9 tc	-99.9 to 999.9						
430	0111010110	IC23 Suction temperature				-99.9 tc	-99.9 to 999.9						
431	11110101110	IC24 Suction temperature				-99.9 tc	-99.9 to 999.9						
432	0000110110	IC25 Suction temperature				-99.9 tc	.99.9 to 999.9						
433	1000110110	IC26 Suction temperature				-99.9 tc	.99.9 to 999.9						
434	0100110110	IC27 Suction temperature				-99.9 tc	-99.9 to 999.9						
435	1100110110	IC28 Suction temperature				-99.9 tc	-99.9 to 999.9						
1 A: Th	ne condition of eith	1 A. The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerant system is displayed	ally. B: The cor	ndition of the	entire refrigerant	system is disp	olayed.						

Data on indoor unit system

				Unit		
No.	SW1	ltem	Display	(A, B) *1	_	Remarks
	1234567890		LD1 LD2 LD3 LD4 LD5 LD6 LD7 LD8	00	SO	
436	0010110110	IC29 Suction temperature	-99.9 to 999.9	В	F	The unit is [°C]
437	1010110110	IC30 Suction temperature	-99.9 to 999.9			
438	0110110110	IC31 Suction temperature	-99.9 to 999.9			
439	1110110110	IC32 Suction temperature	-99.9 to 999.9			
440	0001110110	IC33 Suction temperature	-99.9 to 999.9			
441	1001110110	IC34 Suction temperature	-99.9 to 999.9			
442	0101110110	IC35 Suction temperature	-99.9 to 999.9			
443	1101110110	IC36 Suction temperature	-99.9 to 999.9			
444	0011110110	IC37 Suction temperature	-99.9 to 999.9			
445	1011110110	IC38 Suction temperature	-99.9 to 999.9			
446	01111110110	IC39 Suction temperature	-99.9 to 999.9			
447	1111110110	IC40 Suction temperature	-99.9 to 999.9			
448	0000001110	IC41 Suction temperature	-99.9 to 999.9			
449	1000001110	IC42 Suction temperature	-99.9 to 999.9			
450	0100001110	IC43 Suction temperature	-99.9 to 999.9			
451	1100001110	IC44 Suction temperature	-99.9 to 999.9			
452	0010001110	IC45 Suction temperature	-99.9 to 999.9			
453	1010001110	IC46 Suction temperature	-99.9 to 999.9			
454	0110001110	IC47 Suction temperature	-99.9 to 999.9			
455	1110001110	IC48 Suction temperature	-99.9 to 999.9			
456	0001001110	IC49 Suction temperature	-99.9 to 999.9			
457	1001001110	IC50 Suction temperature	-99.9 to 999.9			
458	0101001110	IC1 Liquid pipe temperature	-99.9 to 999.9	В	F	The unit is [°C]
459	110101110	IC2 Liquid pipe temperature	-99.9 to 999.9			
460	0011001110	IC3 Liquid pipe temperature	-99.9 to 999.9			
461	1011001110	IC4 Liquid pipe temperature	-99.9 to 999.9			
462	0111001110	IC5 Liquid pipe temperature	-99.9 to 999.9			
463	1111001110	IC6 Liquid pipe temperature	-99.9 to 999.9			
*1 A: T	he condition of eith	*1 A: The condition of either OC or OS is displayed individually. B: The condition of	ally. B: The condition of the entire refrigerant system is displayed.			

Data on indoor unit system

	<u></u>		-		-	-
No.	SW1	ltem	Display		Unit (A, B) *1	Remarks
	1234567890		LD1 LD2 LD3 LD4 LD5 LI	LD6 LD7 LD8	00 00	
464	0000101110	IC7 Liquid pipe temperature	-99.9 to 999.9		В	The unit is [°C]
465	1000101110	IC8 Liquid pipe temperature	-99.9 to 999.9			
466	0100101110	IC9 Liquid pipe temperature	-99.9 to 999.9			
467	1100101110	IC10 Liquid pipe temperature	-99.9 to 999.9			
468	0010101110	IC11 Liquid pipe temperature	-99.9 to 999.9			
469	1010101110	IC12 Liquid pipe temperature	-99.9 to 999.9			
470	0110101110	IC13 Liquid pipe temperature	-99.9 to 999.9			
471	1110101110	IC14 Liquid pipe temperature	-99.9 to 999.9		1	
472	0001101110	IC15 Liquid pipe temperature	-99.9 to 999.9			
473	1001101110	IC16 Liquid pipe temperature	-99.9 to 999.9			
474	0101101110	IC17 Liquid pipe temperature	-99.9 to 999.9			
475	1101101110	IC18 Liquid pipe temperature	-99.9 to 999.9			
476	0011101110	IC19 Liquid pipe temperature	-99.9 to 999.9			
477	1011101110	IC20 Liquid pipe temperature	-99.9 to 999.9			
478	0111101110	IC21 Liquid pipe temperature	-99.9 to 999.9			
479	1111101110	IC22 Liquid pipe temperature	-99.9 to 999.9			
480	0000011110	IC23 Liquid pipe temperature	-99.9 to 999.9			
481	1000011110	IC24 Liquid pipe temperature	-99.9 to 999.9			
482	0100011110	IC25 Liquid pipe temperature	-99.9 to 999.9			
483	1100011110	IC26 Liquid pipe temperature	-99.9 to 999.9			
484	0010011110	IC27 Liquid pipe temperature	-99.9 to 999.9			
485	1010011110	IC28 Liquid pipe temperature	-99.9 to 999.9			
486	011001110	IC29 Liquid pipe temperature	-99.9 to 999.9			
487	1110011110	IC30 Liquid pipe temperature	-99.9 to 999.9			
488	0001011110	IC31 Liquid pipe temperature	-99.9 to 999.9			
489	1001011110	IC32 Liquid pipe temperature	-99.9 to 999.9			
490	0101011110	IC33 Liquid pipe temperature	-99.9 to 999.9		<u> </u>	
491	1101011110	IC34 Liquid pipe temperature	-99.9 to 999.9			
*1 A:	The condition of eith	her OC or OS is displayed individua	*1 A: The condition of either OC or OS is displayed individually. B: The condition of the entire refricerant system is displayed.			

*1 A: The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerant system is displayed.

Data on indoor unit system

Location Internation Location Locati	240												Juit		$\overline{\Gamma}$
101 102 103 104 105 106 106 107 108 0C 0S	SW1	Item					Disp	lay				(₹	B) *1	Remarks	
99.9 to 999.9 9 -99.9 to 999.9 9	1234567890			LD1	LD2	D3	LD4	FD5	9G7	LD7	FD8	00	SO		
	0011011110 IC35 Liquid pipe te	IC35 Liquid pipe te	emperature				-99.9 to	6.666		-	-	В		The unit is [°C]	
	1011011110 IC36 Liquid pipe t	IC36 Liquid pipe t	emperature				-99.9 to	6.666							
	0111011110 IC37 Liquid pipe t	IC37 Liquid pipe t	emperature				-99.9 to	6.666				ı			
	1111011110 IC38 Liquid pipe	IC38 Liquid pipe	temperature				-99.9 to	6.666				1			
	0000111110 IC39 Liquid pipe	IC39 Liquid pipe	temperature				-99.9 to	6.666				ı			
	1000111110 IC40 Liquid pipe	IC40 Liquid pipe	temperature				-99.9 to	6.666				ı			
	0100111110 IC41 Liquid pipe	IC41 Liquid pipe	temperature				-99.9 to	6.666				ı			
	1100111110 IC42 Liquid pipe	IC42 Liquid pipe	temperature				-99.9 to	6.666				ı			
	0010111110 IC43 Liquid pip	IC43 Liquid pip	e temperature				-99.9 to	6.666				ı			
	1010111110 IC44 Liquid pip	IC44 Liquid pip	e temperature				-99.9 to	6.666				ı			
	0110111110 IC45 Liquid pip	IC45 Liquid pip	e temperature				-99.9 to	6.666				1			
	1110111110 IC46 Liquid pip	IC46 Liquid pip	e temperature				-99.9 to	6.666				ı			
	0001111110 IC47 Liquid pip	IC47 Liquid pip	oe temperature				-99.9 to	6.666				ı			
	100111110 IC48 Liquid pi	IC48 Liquid pi	oe temperature				-99.9 to	6.666							
	010111110 IC49 Liquid pi	IC49 Liquid pip	oe temperature				-99.9 to	6.666				ı			
	110111110 IC50 Liquid pip	IC50 Liquid pip	e temperature				-99.9 to	6.666				ı			
	0011111110														
	1011111110														
	011111110														
	111111110														

^{*1} A: The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerant system is displayed.

Setting data

,												•	
	SW1	ltem				Display	ılay				Unit (A, B) ^{*1}	t)*1	Remarks
	1234567890		LD1	LD2	LD3	LD4	FD2	9 0 7	ZO1	FD8	00	SO	
	0000000001	Self-address			Alternate	Alternate display of self address and unit model	address and ur	iit model			∢	4	
	1000000001	IC/FU address			Count-up	Count-up display of number of connected units	ber of connect	ed units			В		
	0100000001	RC address			Count-up	Count-up display of number of connected units	ber of connect	ed units			В		
	1100000001	BC/BS/TU address			Count-up	Count-up display of number of connected units	ber of connect	ed units			В		
	001000001	OS address			Count-up	Count-up display of number of connected units	ber of connect	ed units			В		
	1010000001	Version/Capacity		S/W versic	n -> Refrigeran	S/W version -> Refrigerant type -> Model and capacity -> Communication address	and capacity ->	· Communicatio	n address		∢	4	
	0110000001	OC address				OC address display	ss display					В	
	1110000001												
	0001000001												
	1001000001												
	0101000001												

*1 A: The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerant system is displayed.

Data on indoor unit system

ata ol	Jata on Indoor Unit system	stem												_
No.	SW1	Item				Display	olay				Unit (A, B) *1	<u>*</u>	Remarks	
	1234567890		LD1	LD2	FD3	LD4	LD5	9Q7	LD7	FD8	00	SO		
523	1101000001	IC1 Gas pipe temperature				-99.9 tc	-99.9 to 999.9				В		The unit is [°C]	
524	0011000001	IC2 Gas pipe temperature				-99.9 tc	-99.9 to 999.9							
525	1011000001	IC3 Gas pipe temperature				-99.9 tc	-99.9 to 999.9							
526	0111000001	IC4 Gas pipe temperature				-99.9 tc	-99.9 to 999.9							
527	1111000001	IC5 Gas pipe temperature				-99.9 tc	-99.9 to 999.9							
528	0000100001	IC6 Gas pipe temperature				-99.9 tc	-99.9 to 999.9							
529	1000100001	IC7 Gas pipe temperature				-99.9 tc	-99.9 to 999.9							
530	0100100001	IC8 Gas pipe temperature				-99.9 tc	-99.9 to 999.9							
531	1100100001	IC9 Gas pipe temperature				-99.9 tc	-99.9 to 999.9							
532	0010100001	IC10 Gas pipe temperature				-99.9 tc	-99.9 to 999.9							
533	1010100001	IC11 Gas pipe temperature				-99.9 tc	-99.9 to 999.9							
534	0110100001	IC12 Gas pipe temperature				-99.9 tc	-99.9 to 999.9							
535	1110100001	IC13 Gas pipe temperature				-99.9 tc	-99.9 to 999.9							
536	0001100001	IC14 Gas pipe temperature				-99.9 tc	-99.9 to 999.9							
537	1001100001	IC15 Gas pipe temperature				-99.9 tc	-99.9 to 999.9							
538	0101100001	IC16 Gas pipe temperature				-99.9 tc	-99.9 to 999.9							
539	1101100001	IC17 Gas pipe temperature				-99.9 tc	-99.9 to 999.9							
540	0011100001	IC18 Gas pipe temperature				-99.9 tc	-99.9 to 999.9							
541	1011100001	IC19 Gas pipe temperature				-99.9 tc	-99.9 to 999.9							
542	0111100001	IC20 Gas pipe temperature				-99.9 tc	-99.9 to 999.9							
543	1111100001	IC21 Gas pipe temperature				-99.9 tc	-99.9 to 999.9							
544	0000010001	IC22 Gas pipe temperature				-99.9 tc	-99.9 to 999.9							
545	1000010001	IC23 Gas pipe temperature				-99.9 tc	-99.9 to 999.9							
546	0100010001	IC24 Gas pipe temperature				-99.9 tc	-99.9 to 999.9							
547	1100010001	IC25 Gas pipe temperature				-99.9 tc	-99.9 to 999.9							
548	0010010001	IC26 Gas pipe temperature				-99.9 tc	-99.9 to 999.9							
549	1010010001	IC27 Gas pipe temperature				-99.9 tc	-99.9 to 999.9							
1 A: T	ne condition of eith	1 A: The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerant system is displayed.	ually. B: The cα	ondition of the €	entire refrigerant	system is displa	ayed.							1

HWE0913A - 385 -

Data on indoor unit system

,													
No.	SW1	Item				Display	olay				Unit (A, B) *1	t)*1	Remarks
	1234567890		LD1	LD2	FD3	LD4	FD5	9Q7	LD7	PD8	00	SO	
250	0110010001	IC28 Gas pipe temperature				-99.9 tc	-99.9 to 999.9				В		The unit is [°C]
551	1110010001	IC29 Gas pipe temperature				-99.9 tc	-99.9 to 999.9						
552	0001010001	IC30 Gas pipe temperature				-99.9 tc	-99.9 to 999.9						
553	1001010001	IC31 Gas pipe temperature				-99.9 tc	-99.9 to 999.9						
554	0101010001	IC32 Gas pipe temperature				-99.9 tc	.99.9 to 999.9						
555	1101010001	IC33 Gas pipe temperature				-99.9 tc	.99.9 to 999.9						
556	0011010001	IC34 Gas pipe temperature				-99.9 tc	-99.9 to 999.9						
222	1011010001	IC35 Gas pipe temperature				-99.9 tc	-99.9 to 999.9						
258	0111010001	IC36 Gas pipe temperature				-99.9 tc	-99.9 to 999.9						
259	1111010001	IC37 Gas pipe temperature				-99.9 tc	-99.9 to 999.9						
260	0000110001	IC38 Gas pipe temperature				-99.9 tc	.99.9 to 999.9						
561	1000110001	IC39 Gas pipe temperature				-99.9 tc	-99.9 to 999.9						
562	0100110001	IC40 Gas pipe temperature				-99.9 tc	-99.9 to 999.9						
563	1100110001	IC41 Gas pipe temperature				-99.9 tc	-99.9 to 999.9						
564	0010110001	IC42 Gas pipe temperature				-99.9 tc	.99.9 to 999.9						
292	1010110001	IC43 Gas pipe temperature				-99.9 tc	.99.9 to 999.9						
999	0110110001	IC44 Gas pipe temperature				-99.9 tc	-99.9 to 999.9						
292	1110110001	IC45 Gas pipe temperature				-99.9 tc	-99.9 to 999.9						
268	0001110001	IC46 Gas pipe temperature				-99.9 tc	-99.9 to 999.9						
269	1001110001	IC47 Gas pipe temperature				-99.9 tc	.99.9 to 999.9						
220	0101110001	IC48 Gas pipe temperature				-99.9 tc	-99.9 to 999.9						
571	11011110001	IC49 Gas pipe temperature				-99.9 tc	.99.9 to 999.9						
572	0011110001	IC50 Gas pipe temperature				-99.9 tc	-99.9 to 999.9						
*1 A·T	The condition of eit	*1 A: The condition of either OC or OS is displayed individually. B: The condition of	hally R. The cr		the entire refricerant system is displayed	evetem is disnla	שיינ						

A: The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerant system is displayed.

Data on indoor unit system

ata Ol	sata on macor ann system											
o N	SW1	Item				Display	ılay				Unit (A, B)*1	Remarks
	1234567890		LD1	LD2	FD3	LD4	FD5	TD9 PT	PD7 LD8	900	so	
573	1011110001	IC1SH				-99.9 to 999.9	6.666			В		The unit is [°C]
574	0111110001	IC2SH				-99.9 to 999.9	6.666					
575	1111110001	IC3SH				-99.9 to 999.9	6.666					
929	0000001001	IC4SH				-99.9 to 999.9	6.666					
277	1000001001	IC5SH				-99.9 to 999.9	6.666					
879	0100001001	IC6SH				-99.9 to 999.9	6.666					
629	1100001001	IC7SH				-99.9 to 999.9	6.666					
280	0010001001	IC8SH				-99.9 to 999.9	6.666					
581	1010001001	IC9SH				-99.9 to 999.9	6.666					
582	0110001001	IC10SH				-99.9 to 999.9	6.666					
583	1110001001	IC11SH				-99.9 to 999.9	6.666					
584	0001001001	IC12SH				-99.9 to 999.9	6.666					
585	1001001001	IC13SH				-99.9 to 999.9	6.666					
586	0101001001	IC14SH				-99.9 to 999.9	6.666					
287	1101001001	IC15SH				-99.9 to 999.9	6.666					
588	0011001001	IC16SH				-99.9 to 999.9	6.666					
589	1011001001	IC17SH				-99.9 to 999.9	6.666					
290	0111001001	IC18SH				-99.9 to 999.9	6.666					
591	1111001001	IC19SH				-99.9 to 999.9	6.666					
592	0000101001	IC20SH				-99.9 to 999.9	6.666					
593	1000101001	IC21SH				-99.9 to 999.9	6.666					
594	0100101001	IC22SH				-99.9 to 999.9	6.666					
262	1100101001	IC23SH				-99.9 to 999.9	6.666					
969	0010101001	IC24SH				-99.9 to 999.9	6.666					
265	101010101	IC25SH				-99.9 to 999.9	6.666					
298	0110101001	IC26SH				-99.9 to 999.9	6.666					
669	1110101001	IC27SH				-99.9 to 999.9	6.666					
1 A: Th	e condition of eith	1 A: The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerant system is displayed.	ndividually. B: T	he condition of th	he entire refrige	rant system is	displayed.					

HWE0913A - 387 -

Data on indoor unit system

Data o	Data on Indoor unit system	stem											
No.	SW1	Item				Disk	Display				Unit (A, B)*1	t)*1	Remarks
	1234567890	T	LD1	LD2	FD3	LD4	FD5	907	LD7	PD8	00	SO	
009	0001101001	IC28SH				-99.9 tc	-99.9 to 999.9				В		The unit is [°C]
601	1001110101	IC29SH				-99.9 tc	-99.9 to 999.9						
602	0101101001	IC30SH				-99.9 tc	-99.9 to 999.9						
603	1101101001	IC31SH				-99.9 tc	-99.9 to 999.9						
604	0011101001	IC32SH				-99.9 tc	-99.9 to 999.9						
909	10111101001	IC33SH				-99.9 tc	-99.9 to 999.9						
909	0111101001	IC34SH				-99.9 tc	-99.9 to 999.9						
209	11111101001	IC35SH				-99.9 tc	-99.9 to 999.9						
809	0000011001	IC36SH				-99.9 tc	-99.9 to 999.9						
609	1000011001	IC37SH				-99.9 tc	-99.9 to 999.9						
610	0100011001	IC38SH				-99.9 tc	-99.9 to 999.9						
611	1100011001	IC39SH				-99.9 tc	-99.9 to 999.9						
612	0010011001	IC40SH				-99.9 tc	-99.9 to 999.9						
613	1010011001	IC41SH				-99.9 tc	-99.9 to 999.9						
614	0110011001	IC42SH				-99.9 tc	-99.9 to 999.9						
615	1110011001	IC43SH				-99.9 tc	-99.9 to 999.9						
616	0001011001	IC44SH				-99.9 tc	-99.9 to 999.9						
617	100111001	IC45SH				-99.9 tc	-99.9 to 999.9						
618	0101011001	IC46SH				-99.9 tc	-99.9 to 999.9						
619	1101011001	IC47SH				-99.9 tc	-99.9 to 999.9						
620	0011011001	IC48SH				-99.9 tc	-99.9 to 999.9						
621	1011011001	IC49SH				-99.9 tc	-99.9 to 999.9						
622	0111011001	IC50SH				-99.9 tc	-99.9 to 999.9						
*1 A: T	he condition of eith	*1 A. The condition of either OC or OS is displayed individually. B. The condition of the entire refrigerant system is displayed	individually. B:	The condition o	f the entire refri	gerant system is	displayed						

*1 A: The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerant system is displayed.

Data on indoor unit system

	SW1					Display				Unit	2	
No.		Item			-	-				(A, B)	_	Remarks
	1234567890		LD1	LD2	LD3	LD4	LD5 LD	LD6 LD7	FD8	00	SO	
623	1111011001	IC1SC				-99.9 to 999.9	6.6			В		The unit is [°C]
624	0000111001	IC2SC				-99.9 to 999.9	6.6					
625	1000111001	IC3SC				-99.9 to 999.9	6.6					
626	0100111001	IC4SC				-99.9 to 999.9	6.9					
627	1100111001	ICESC				-99.9 to 999.9	6.9					
628	0010111001	Cesc				-99.9 to 999.9	6.9					
629	1010111001	IC7SC				-99.9 to 999.9	6.9					
630	0110111001	IC8SC				-99.9 to 999.9	6.9					
631	1110111001	28621				-99.9 to 999.9	6.9					
632	0001111001	IC10SC				-99.9 to 999.9	6.6					
633	1001111001	IC11SC				-99.9 to 999.9	6.9					
634	0101111001	IC12SC				-99.9 to 999.9	6.6					
635	11011111001	IC13SC				-99.9 to 999.9	6.6					
989	0011111001	IC14SC				-99.9 to 999.9	6.6					
637	1011111001	IC15SC				-99.9 to 999.9	6.6					
638	0111111001	IC16SC				-99.9 to 999.9	6.6					
629	1111111001	IC17SC				-99.9 to 999.9	6.6					
640	0000000101	IC18SC				-99.9 to 999.9	6.6					
641	1000000101	IC19SC				-99.9 to 999.9	6.6					
642	0100000101	IC20SC				-99.9 to 999.9	6.6					
643	1100000101	IC21SC				-99.9 to 999.9	6.6					
644	0010000101	IC22SC				-99.9 to 999.9	6.6					
645	1010000101	IC23SC				-99.9 to 999.9	6.6					
646	0110000101	IC24SC				-99.9 to 999.9	6.6					
647	1110000101	IC25SC				-99.9 to 999.9	6.6					
648	0001000101	IC26SC				-99.9 to 999.9	6.6					
649	1001000101	IC27SC				-99.9 to 999.9	6.6					
*1 A: T	ne condition of eith	*1 A: The condition of either OC or OS is displayed individually. B: The condition of	ndividually. B: T	he condition of t	the entire refrigerant system is displayed	system is disp	olayed.			_	•	

HWE0913A - 389 -

Data on indoor unit system

Data c	Data on Indoor unit system	stem											
No.	SW1	ltem				Display	olay				Unit (A, B)*1	*	Remarks
	1234567890		LD1	LD2	FD3	LD4	FD5	9Q7	LD7	PD8	00	SO	
650	0101000101	IC28SC				-99.9 to 999.9	6.666.0				В		The unit is [°C]
651	1101000101	IC29SC				-99.9 to 999.9	6.666.0						
652	0011000101	IC30SC				-99.9 to 999.9	6.666						
653	1011000101	IC31SC				-99.9 to 999.9	6.666						
654	0111000101	IC32SC				-99.9 to 999.9	6.666.0						
655	1111000101	IC33SC				-99.9 to 999.9	6.666.0						
929	0000100101	IC34SC				-99.9 to 999.9	6.666						
657	1000100101	IC35SC				-99.9 to 999.9	6.666.0						
658	0100100101	1C36SC				-99.9 to 999.9	6.666.0						
629	1100100101	IC37SC				-99.9 to 999.9	6.666.0						
099	0010100101	IC38SC				-99.9 to 999.9	6.666.0						
661	101010101	IC39SC				-99.9 to 999.9	6.666.0						
662	0110100101	IC40SC				-99.9 to 999.9	6.666.0						
663	1110100101	IC41SC				-99.9 to 999.9	6.666.0						
664	0001100101	IC42SC				-99.9 to 999.9	6.666.0						
665	1001100101	IC43SC				-99.9 to 999.9	6.666						
999	0101100101	IC44SC				-99.9 to 999.9	6.666.0						
299	1101100101	IC45SC				-99.9 to 999.9	6.666.0						
899	0011100101	IC46SC				-99.9 to 999.9	6.666.0						
699	1011100101	IC47SC				-99.9 to 999.9	6.666.0						
029	0111100101	IC48SC				-99.9 to 999.9	6.666.0						
671	1111100101	IC49SC				-99.9 to 999.9	6.666.0						
672	0000010101	IC50SC				-99.9 to 999.9	6.666.0						
673	1000010101												
674	0100010101												
675	1100010101												
*1 A·T	He condition of	*1 A: The condition of either OC or OS is displayed individually. B: The condition of t	T.A viloribivibe			he entire refriderant system is displayed	henleyed				•		

*1 A: The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerant system is displayed.

Setting data

	,													_
No.	SW1	Item				Disp	Display				Unit (A, B) ^{* 1}	lit 8)* 1	Remarks	
	1234567890		LD1	LD2	FD3	FD7	FD5	PDP	LD7	FD8	00	SO		
929	0010010101	INV board S/W version				0.00 to	0.00 to 99.99				∢	∢		
677	1010010101													
829	0110010101													
629	1110010101	Fan board S/W version				0.00 to	0.00 to 99.99				∢	∢		
089	0001010101													
681	1001010101													
682	0101010101													
683	1101010101													
684	0011010101													
685	1011010101													
989	0111010101													
289	1111010101													
*1 A: T	The condition of eith	*1 A: The condition of either OC or OS is displayed individually. B: The condition of the	dually. B: The	condition of the	ne entire refrigerant system is displayed.	nt system is die	splayed.							

HWE0913A - 391 -

æ
Ħ
0
ō
₽
둦
മ

LD3 LD4 LD5 LD6 LD7 LD8 OC OS	SW1				Disi	Display				Unit	# *;	
LD4	Item	Item			2	piay				(A, E	3)* 1	Remarks
< < < < < < < < < < < < < < < < < < <	1234567890 LD1 LD2	LD1	LD2	FD3	LD4	FD5	PDP	LD7	8 0 7	00	SO	
	0000110101 Current time				00:00 t	to 23:59				∢	⋖	Hour: minute
	1000110101 Current time -2	Current time -2			00.00 to 99	9.12/1 to 31						Year and month, and date alternate display
	0100110101 Time of error detection 1				00:00 t	to 23:59						Hour: minute
	1100110101 Time of error detection 1-2	Time of error detection 1-2			00.00 to 95	9.12/1 to 31						Year and month, and date alternate display
	0010110101 Time of error detection 2				00:00 t	to 23:59						Hour: minute
	1010110101 Time of error detection 2-2				00.00 to 99	9.12/1 to 31						Year and month, and date alternate display
	0110110101 Time of error detection 3				00:00 t	to 23:59						Hour: minute
	1110110101 Time of error detection 3-2	Time of error detection 3-2			00.00 to 99	9.12/1 to 31						Year and month, and date alternate display
	0001110101 Time of error detection 4				00:00 t	to 23:59						Hour: minute
	1001110101 Time of error detection 4-2	Time of error detection 4-2			00.00 to 95	9.12/1 to 31						Year and month, and date alternate display
	0101110101 Time of error detection 5	Time of error detection 5			00:00 t	to 23:59						Hour: minute
	1101110101 Time of error detection 5-2	Time of error detection 5-2			00.00 to 99	9.12/1 to 31						Year and month, and date alternate display
	0011110101 Time of error detection 6				00:00 t	to 23:59						Hour: minute
	1011110101 Time of error detection 6-2	Time of error detection 6-2			00.00 to 99	9.12/1 to 31						Year and month, and date alternate display

*1 A: The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerant system is displayed.

Setting data

	LED N	/loni	tor [Display	on /	the O	utdo	or Uni	t Bo	ard]					
	Remarks		Hour: minute	Year and month, and date alternate display	Hour: minute	Year and month, and date alternate display	Hour: minute	Year and month, and date alternate display	Hour: minute	Year and month, and date alternate display	Hour: minute	Year and month, and date alternate display			
	t * 1	SO	⋖				•		•						
	Unit (A, B) ^{* 1}	20	∢												
		FD8													
		LD7													
		9Q7													
	Display	FD5	00:00 to 23:59	00.00 to 99.12/1 to 31	00:00 to 23:59	00.00 to 99.12/1 to 31	00:00 to 23:59	00.00 to 99.12/1 to 31	00:00 to 23:59	00.00 to 99.12/1 to 31	00:00 to 23:59	00.00 to 99.12/1 to 31			porclas
	Dis	LD4	00:00 t	00.00 to 99	00:00 t	00.00 to 99	00:00 t	00.00 to 99	00:00 t	00.00 to 99	00:00	00.00 to 99			ovelessing refrigers to create significant
		LD3													
		LD2													opposition of the
		LD1													idiolly B. Tho
	Item		Time of error detection 7	Time of error detection 7-2	Time of error detection 8	Time of error detection 8-2	Time of error detection 9	Time of error detection 9-2	Time of error detection 10	Time of error detection 10-2	Time of last data backup before error	Time of last data backup before error -2			1 A. The condition of either OC or OS is displayed individually B. The condition of the
	SW1	1234567890	0111110101	1111110101	0000001101	1000001101	0100001101	1100001101	0010001101	1010001101	0110001101	1110001101	0001001101	1001001101	dio to acitibaco
)	No.		702	703	704	705	902	707	208	602	710	711	712	713	7. Y.

*1 A: The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerant system is displayed.

Data on indoor unit system

2	SW1	-				Display				Unit (A.B)*1	ř; 1	-
2	1234567890	<u> </u>	LD1	LD2	LD3	LD4	LD5	1D6 LD7	TD8	00	OS	NGII GINS
14.4	0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	, L		!			3			} ()	0000
7.14	1011001010	IC1 LEV opening				0000 to 9999	666			מ		Fully open: 2000
715	1101001101	IC2 LEV opening				0000 to 9999	666					
716	0011001101	IC3 LEV opening				0000 to 9999	666					
717	1011001101	IC4 LEV opening				0000 to 9999	666					
718	0111001101	IC5 LEV opening				0000 to 9999	666					
719	1111001101	IC6 LEV opening				0000 to 9999	666					
720	0000101101	IC7 LEV opening				0000 to 9999	666					
721	1000101101	IC8 LEV opening				0000 to 9999	666					
722	0100101101	IC9 LEV opening				0000 to 9999	666					
723	1100101101	IC10 LEV opening				0000 to 9999	666					
724	0010101101	IC11 LEV opening				0000 to 9999	666					
725	1010101101	IC12 LEV opening				0000 to 9999	666					
726	0110101101	IC13 LEV opening				0000 to 9999	666					
727	1110101101	IC14 LEV opening				0000 to 9999	666					
728	0001101101	IC15 LEV opening				0000 to 9999	666					
729	1001101101	IC16 LEV opening				0000 to 9999	666					
730	0101101101	IC17 LEV opening				0000 to 9999	666					
731	1101101101	IC18 LEV opening				0000 to 9999	666					
732	0011101101	IC19 LEV opening				0000 to 9999	666					
733	1011101101	IC20 LEV opening				0000 to 9999	666					
734	0111101101	IC21 LEV opening				0000 to 9999	666					
735	1111101101	IC22 LEV opening				0000 to 9999	666					
736	0000011101	IC23 LEV opening				0000 to 9999	666					
737	1000011101	IC24 LEV opening				0000 to 9999	666					
738	0100011101	IC25 LEV opening				0000 to 9999	666					
739	1100011101	IC26 LEV opening				0000 to 9999	666					
740	0010011101	IC27 LEV opening				0000 to 9999	666					
*1 A: T	he condition of eit	*1 A: The condition of either OC or OS is displayed individually. B: The condition of	individually. B: T	The condition of	the entire refrigerant system is displayed	ıt system is dis	played.					

HWE0913A - 394 -

Data on indoor unit system

741 1034567890 742 1010011101 IC28 LEV opening 743 1110011101 IC29 LEV opening 744 0010111101 IC31 LEV opening 745 1001011101 IC31 LEV opening 746 0101011101 IC32 LEV opening 749 1011011101 IC32 LEV opening 750 0110111101 IC32 LEV opening 750 011011101 IC32 LEV opening 750 0110111101 IC32 LEV opening 751 1111011101 IC32 LEV opening 752 0000111101 IC32 LEV opening 753 1000111101 IC40 LEV opening 754 0100111101 IC41 LEV opening 755 1100111101 IC42 LEV opening 757 1010111101 IC45 LEV opening 759 1110111101 IC45 LEV opening 760 0001111101 IC47 LEV opening 760 1001111101 IC48 LEV opening 761 1001111101 IC48 LEV opening	aning	LD2	80	Fully open: 2000
1010011101 1110011101 1110011101 10001011101 1101011101 101101	aning		L.	ully open: 2000
0110011101 1110011101 0001011101 1101011101 0011011101	aning	0000 to 9999		
1110011101 0001011101 1001011101 1101011101 1011011101	aning	0000 to 9999		
0001011101 1001011101 1101011101 0011011	aning	0000 to 9999		
1001011101 1101011101 1001011101 1011011	aning	6666 ot 0000 6666 ot 0000		
0010011101 1101011101 0011011101 1011011	aning aning aning aning aning aning aning aning aning	0000 to 9999		
1101011101 0011011101 1011011101 111101110	aning aning aning aning aning aning aning aning	6666 ot 0000 6666 ot 0000 6666 ot 0000 6666 ot 0000 6666 ot 0000 6666 ot 0000 6666 ot 0000		
0011011101 1011011101 011011101 1111011101 0000111101 1100111101 0010111101 11101111101 11101111101 1001111101 1001111101	aning aning aning aning aning aning aning	0000 to 9999		
1011011101 1111011101 0000111101 1000111101 1100111101 1010111101 1110111101 11001111101 11101111101 11001111101	aning aning aning aning aning aning	9696 ot 0000 9696 ot 0000 9696 ot 0000 9696 ot 0000 9696 ot 0000 9696 ot 0000		
0111011101 1111011101 0000111101 1100111101 1010111101 11101111101 11001111101 11001111101 11001111101	aning aning aning aning aning	0000 to 9999		
1111011101 0000111101 1000111101 1100111101 0010111101 1010111101 1110111101 1001111101	aning aning aning aning	9999 0000 9999 0000 9999 0000 9999 0000		
0000111101 1000111101 0100111101 1100111101 0010111101 1110111101 1001111101 1001111101	aning aning aning aning	0000 to 9999 0000 to 9999 0000 to 9999		
0100111101 1100111101 0010111101 1010111101 1110111101 1001111101	ening ening ening	9999 0000 0000 0000 0000 0000 0000 000	_	
0100111101 1100111101 0010111101 1010111101 1110111101 1001111101	ening ening	0000 to 9999 0000 to 9999		
1100111101 0010111101 1010111101 1110111101 0001111101	ening	0000 ot 0000		
0010111101 1010111101 0110111101 1110111101 1001111101	_			
0110111101 1110111101 0001111101 1001111101	ening	0000 to 9999		
0110111101 1110111101 0001111101 1001111101	ening	0000 to 9999		
1110111101 0001111101 1001111101	guine	0000 to 9999		
0001111101	ening	0000 to 9999		
1001111101	guine	0000 to 9999		
0101111101	ening	0000 to 9999		
	ening	0000 to 9999		
763 110111101 IC50 LEV opening	guine	0000 to 9999		
764 0011111101 IC1 Operation mode	n mode	8	F	The four LDs on the left
765 101111101 IC2 Operation mode	n mode		<u> </u>	(LD1-4) display operation mode, and the four LDs
766 0111111101 IC3Operation mode	mode	0000 : Stop 0001 : Ventilation 0002 : Cooling 0003 : Heating 0004 : Dry	ō :ō	on the right (LD5-LD8)
767 11111111 IC4 Operation mode	n mode		ם)	(Displayed alternately ev-
768 000000011 IC5 Operation mode	n mode		Φ	ery five seconds)

Data on indoor unit system

	6												
No.	SW1	Item				Ĭ	Display				Unit (A, B) ^{* 1}	it)*1	Remarks
	1234567890	ı	LD1	LD2	FD3	LD4	FD5	9Q7	LD7	FD8	00	SO	
269	1000000011	IC6 Operation mode									В		The four LDs on the left
770	0100000011	IC7 Operation mode											(LD1-4) display opera- tion mode, and the four
771	110000011	IC8 Operation mode											LDs on the right (LD5-
772	2 0010000011	IC9 Operation mode											LDδ) display poπ address.
773	3 1010000011	IC10 Operation mode	•										(Displayed alternately
774	1 0110000011	IC11 Operation mode	•										every live seconds)
775	1110000011	IC12 Operation mode											
776	3 0001000011	IC13 Operation mode	•										
777	7 100100011	IC14 Operation mode											
778	3 0101000011	IC15 Operation mode											
779	1101000111	IC16 Operation mode	•										
780	0011000011	IC17 Operation mode	•										
781	1011000011	IC18 Operation mode											
782	2 0111000011	IC19 Operation mode	•		2. 5000	,000 20;10];100,		, H					
783	3 1111000011	IC20 Operation mode			. 1000 dois	veninauon ooo.	occo . Stop occo . Verillation occo . Cooling occo . Meaning occo . Cry						
784	4 0000100011	IC21 Operation mode	•										
785	5 1000100011	IC22 Operation mode											
786	3 0100100011	IC23 Operation mode											
787	110010011	IC24 Operation mode											
788	3 0010100011	IC25 Operation mode											
789	1010100011	IC26 Operation mode											
790	0110100011	IC27 Operation mode											
791	1110100011	IC28 Operation mode											
792	2 0001100011	IC29 Operation mode	•										
793	3 1001100011	IC30 Operation mode											
794	4 0101100011	IC31 Operation mode											
795	1101100011	IC32 Operation mode											
296	3 0011100011	IC33 Operation mode											
*1	The condition of eith	ther OC or OS is displaying	ad individually R. The	ondition of	the entire refri	refricerant exetem i	evetem is displayed						

*1 A: The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerant system is displayed.

Data on indoor unit system

	•												
No.	SW1	Item				ΞÜ	Display				Unit (A, B)*1	it ()*1	Remarks
	1234567890		LD1	LD2	FD3	LD4	FD5	9G7	LD7	PD8	00	SO	
797	1011100011	IC34 Operation mode				-					В		The four LDs on the left
798	0111100011	IC35 Operation mode											(LD1-4) display opera- tion mode, and the four
799	1111100011	IC36 Operation mode	•										LDs on the right (LD5-
800	0000010011	IC37 Operation mode	•										LU8) display port address.
801	1000010011	IC38 Operation mode	·										(Displayed alternately
802	0100010011	IC39 Operation mode	•										every live seconds)
803	1100010011	IC40 Operation mode	•										
804	0010010011	IC41 Operation mode	•										
805	1010010011	IC42 Operation mode	•	0000	Stop 0001:	Ventilation 000.	Stop 0001: Ventilation 0002: Cooling 0003: Heating 0004: Dry	: Heating 000	t : Dry				
908	0110010011	IC43 Operation mode	•										
807	1110010011	IC44 Operation mode	•										
808	0001010011	IC45 Operation mode	•										
808	100101011	IC46 Operation mode	•										
810	0101010011	IC47 Operation mode	•										
811	110101011	IC48 Operation mode	•										
812	0011010011	IC49 Operation mode	•										
813	1011010011	IC50 Operation mode	•										
814	0111010011	IC1 filter				0000	0000 to 9999				В		Hours since last mainte-
815	1111010111	IC2 filter				0000	0000 to 9999						nance [n]
816	1100110000	IC3 filter				0000	0000 to 9999						
817	1000110011	IC4 filter				0000	0000 to 9999						
818	0100110011	IC5 filter				0000	0000 to 9999						
819	1100110011	IC6 filter				0000	0000 to 9999						
820	0010110011	IC7 filter				0000	0000 to 9999						
821	1010110011	IC8 filter				0000	0000 to 9999						
822	0110110011	IC9 filter				0000	0000 to 9999						
823	1110110111	IC10 filter				0000	0000 to 9999						
824	0001110011	IC11 filter				0000	0000 to 9999						
*1 A: T	ne condition of eith	*1 A: The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerant system is displayed	Individually. B: 1	The condition of	the entire refi	rigerant system i	s displayed.						

Data on indoor unit system

Jala UI	Data on muoor unit system	ereili Steili											
No.	SW1	ltem				Display	lay				Unit (A, B) ^{* 1}	+ + +	Remarks
	1234567890		LD1	LD2	FD3	LD4	LD5	PD9	LD7	PD8	00	SO	
825	1001110011	IC12 filter				0000 to 9999	6666				В		Hours since last mainte-
826	0101110011	IC13 filter				0000 to 9999	6666						nance [n]
827	1101110011	IC14 filter				0000 to 9999	6666						
828	0011110011	IC15 filter				0000 to 9999	6666						
829	1011110011	IC16 filter				0000 to 9999	6666						
830	0111110011	IC17 filter				0000 to 9999	6666						
831	1111110011	IC18 filter				0000 to 9999	6666						
832	0000001011	IC19 filter				0000 to 9999	6666						
833	100000111	IC20 filter				0000 to 9999	6666						
834	0100001011	IC21 filter				0000 to 9999	6666						
835	110000111	IC22 filter				0000 to 9999	6666						
836	0010001011	IC23 filter				0000 to 9999	6666						
837	1010001011	IC24 filter				0000 to 9999	6666						
838	0110001011	IC25 filter				0000 to 9999	6666						
839	111000111	IC26 filter				0000 to 9999	6666						
840	0001001011	IC27 filter				0000 to 9999	6666						
841	1001001011	IC28 filter				0000 to 9999	6666						
842	0101001011	IC29 filter				0000 to 9999	6666						
843	1101001011	IC30 filter				0000 to 9999	6666						
844	0011001011	IC31 filter				0000 to 9999	6666						
845	1011001111	IC32 filter				0000 to 9999	6666						
846	0111001001	IC33 filter				0000 to 9999	6666						
847	1111001011	IC34 filter				0000 to 9999	6666						
848	0000101011	IC35 filter				0000 to 9999	6666						
849	1000101011	IC36 filter				0000 to 9999	6666						
850	0100101011	IC37 filter				0000 to 9999	6666						
851	1100101011	IC38 filter				0000 to 9999	6666						
852	0010101011	IC39 filter				0000 to 9999	6666						
1 A: Th	ne condition of eith	1 A: The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerant system is displayed.	individually. B:	The condition of t	the entire refrige	rant system is o	displayed.						

A: The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerar

Data on indoor unit system

LD1 LD2 LD3 LD4 LD5 LD6 LD6 LD7 LD8 OC OS	—	SW1	ten.				Display	olay				Unit (A, B)*1	it .)* 1	Remarks
ICA1 filter 0000 to 9999 B ICA2 filter 0000 to 9999 B ICA3 filter 0000 to 9999 B ICA4 filter 0000 to 9999 B ICA5 filter 0000 to 9999 B ICA5 filter 0000 to 9999 B ICA5 filter 0000 to 9999 B ICA9 filter 0000 to 9999 B ICA9 filter 0000 to 9999 B ICA9 filter 0000 to 9999 B	12	34567890		LD1	LD2	FD3	LD4	FD5	9Q7	LD7	FD8	00	SO	
1C42 filter 0000 to 9999 1C42 filter 0000 to 9999 1C43 filter 0000 to 9999 1C44 filter 0000 to 9999 1C45 filter 0000 to 9999 1C47 filter 0000 to 9999 1C48 filter 0000 to 9999 1C49 filter 0000 to 9999 1C50 filter 0000 to 9999	1)10101011	IC40 filter				0000 tc	6666				В		Hours since last mainte-
10:42 filter 10:43 filter 10:44 filter 10:45 filter 10:48 filter 10:49 filter 10:50 filter	Ó	110101011	IC41 filter				0000 tc	6666						nance [h]
1C43 filter 1C44 filter 1C45 filter 1C46 filter 1C48 filter 1C49 filter 1C50 filter	_	110101011	IC42 filter				0000 tc	6666						
1C44 filter 1C45 filter 1C46 filter 1C47 filter 1C47 filter 1C48 filter 1C49 filter 1C50 filter	0	001101011	IC43 filter				0000 tc	6666						
IC45 filter IC46 filter IC47 filter IC48 filter IC49 filter IC50 filter	_	001101011	IC44 filter				0000 tc	6666						
IC46 filter IC47 filter IC48 filter IC49 filter IC50 filter	0	10110111	IC45 filter				0000 tc	6666						
IC48 filter IC49 filter IC50 filter	_	10110111	IC46 filter				0000 tc	6666						
IC48 filter IC49 filter IC50 filter	ō	011101011	IC47 filter				0000 tc	6666						
IC49 filter IC50 filter	7	011101011	IC48 filter				0000 tc	6666						
IC50 filter	Ò	111101011	IC49 filter				0000 tc	6666						
	=	111101011	IC50 filter				0000 tc	6666						

HWE0913A - 399 -

Other types of data

No.	SW1	Item				Di	Display				Unit (A, B) ^{*1}	nit 3)*1	Remarks
	1234567890		LD1	LD2	FD3	LD4	FD5	9Q7	LD7	RD3	00	SO	
864	0000011011												
865	1000011011												
866	0100011011												
867	1100011011												
898	0010011011												
869	1010011011												
870	0110011011												
871	1110011011	U-phase current effective value 1				6.66-	-99.9 to 999.9				∢	∢	The unit is [A]
872	0001011011	W-phase current effectiive value 1				6.66-	-99.9 to 999.9				∢	⋖	
873	1001011011	Power factor phase angle 1				6.66-	-99.9 to 999.9				∢	⋖	The unit is [deg]
874	0101011011												
875	1101011011												
876	0011011011												
877	1011011011												
878	0111011011												
879	1111011011												
880	0000111011	Control board Reset counter				0 t	0 to 254				4	4	The unit is [time]
881	1000111011	INV board Reset counter				0 t	0 to 254				٨	A	
882	0100111011												
883	1100111011												
884	0010111011	Fan board Reset counter				0 t	0 to 254				٨	A	The unit is [time]
885	1010111011												
886	0110111011												
*1 A: T	he condition of eit	*1 A: The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerant system is displayed.	dividually. B: T.	he condition of t	he entire refriç	yerant system is	s displayed.						

HWE0913A - 400 -

,	:	V	
	Ç	ĺ	
•	٠		
	(
	2	ĺ	
	5		
,	•		
	ċ	į	
;	٩		

		F										-	
No.	SW1	ltem					Display				Unit (A, B) *1	it () *1	Remarks
	1234567890		LD1	LD2	FD3	LD4	FD2	PDP	LD7	FD8	8	SO	
887	1110111011												
888	0001111011												
889	1001111011												
890	0101111011												
891	1101111011												
892	0011111011												
893	1011111011												
894	0111111011												
895	111111111												
968	0000000111												
897	1000000111												
868	0100000111												
899	1100000111												
006	0010000111												
901	1010000111												
905	0110000111												
606	1110000111												
904	0001000111												
906	1001000111												
906	0101000111												
206	1101000111												
1020	001111111												
1021	101111111												
1022	011111111												
1023	111111111												
*1 A: 1	The condition of eith	*1 A: The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerant system is displayed.	ndividually. B: T	he condition of	the entire re	frigerant system	is displayed.						

HWE0913A - 401 -



▲ MITSUBISHI ELECTRIC CORPORATION