

AIR CONDITIONER

**2024** R410A

# Service Handbook

### Model

PQHY-P72, P96, P120, P144, P168, P192ZLMU-A1/B PQHY-P144, P168, P192, P216, P240, P288, P312, P336, P360ZSLMU-A1/B

PQRY-P72, P96, P120, P144, P168, P192ZLMU-A1/B PQRY-P144, P168, P192, P216, P240, P288, P312, P336ZSLMUA1/B

4th edition

# Safety Precautions

- Before installing the unit, thoroughly read the following safety precautions.
- Observe these safety precautions for your safety.

# **!** WARNING

This symbol is intended to alert the user to the presence of important instructions that must be followed to avoid the risk of serious injury or death.

# **A** CAUTION

This symbol is intended to alert the user to the presence of important instructions that must be followed to avoid the risk of serious injury or damage to the unit.

- •After reading this manual, give it to the user to retain for future reference.
- •Keep this manual for easy reference. When the unit is moved or repaired, give this manual to those who provide these services.

When the user changes, make sure that the new user receives this manual.

# **⚠** WARNING

# Ask your dealer or a qualified technician to install the unit.

Improper installation by the user may result in water leakage, electric shock, smoke, and/or fire.

#### Properly install the unit on a surface that can withstand the weight of the unit.

Unit installed on an unstable surface may fall and cause injury.

Only use specified cables. Securely connect each cable so that the terminals do not carry the weight of the cable.

Improperly connected or fixed cables may produce heat and start a fire.

Take appropriate safety measures against strong winds and earthquakes to prevent the unit from falling.

If the unit is not installed properly, the unit may fall and cause serious injury to the person or damage to the unit.

Do not make any modifications or alterations to the unit. Consult your dealer for repair.

Improper repair may result in water leakage, electric shock, smoke, and/or fire.

Do not touch the heat exchanger fins.

The fins are sharp and dangerous.

In the event of a refrigerant leak, thoroughly ventilate the room.

If refrigerant gas leaks and comes in contact with an open flame, poisonous gases will be produced.

When installing the All-Fresh type units, take it into consideration that the outside air may be discharged directly into the room when the thermo is turned off.

Direct exposure to outdoor air may have an adverse effect on health. It may also result in food spoilage.

Properly install the unit according to the instructions in the installation manual.

Improper installation may result in water leakage, electric shock, smoke, and/or fire.

Have all electrical work performed by an authorized electrician according to the local regulations and instructions in this manual, and a dedicated circuit must be used.

Insufficient capacity of the power supply circuit or improper installation may result in malfunctions of the unit, electric shock, smoke, and/or fire.

# **. MARNING**

# Securely attach the terminal block cover (panel) to the unit.

If the terminal block cover (panel) is not installed properly, dust and/or water may infiltrate and pose a risk of electric shock, smoke, and/or fire.

# Only use the type of refrigerant that is indicated on the unit when installing or reinstalling the unit.

Infiltration of any other type of refrigerant or air into the unit may adversely affect the refrigerant cycle and may cause the pipes to burst or explode.

#### When installing the unit in a small room, exercise caution and take measures against leaked refrigerant reaching the limiting concentration.

Consult your dealer with any questions regarding limiting concentrations and for precautionary measures before installing the unit. Leaked refrigerant gas exceeding the limiting concentration causes oxygen deficiency.

#### Consult your dealer or a specialist when moving or reinstalling the unit.

Improper installation may result in water leakage, electric shock, and/or fire.

# After completing the service work, check for a gas leak.

If leaked refrigerant is exposed to a heat source, such as a fan heater, stove, or electric grill, poisonous gases may be produced.

#### Do not try to defeat the safety features of the unit.

Forced operation of the pressure switch or the temperature switch by defeating the safety features of these devices, or the use of accessories other than the ones that are recommended by MITSUBISHI may result in smoke, fire, and/or explosion.

#### Only use accessories recommended by MITSUBISHI.

Ask a qualified technician to install the unit. Improper installation by the user may result in water leakage, electric shock, smoke, and/or fire.

#### Control box houses high-voltage parts.

When opening or closing the front panel of the control box, do not let it come into contact with any of the internal components. Before inspecting the inside of the control box, turn off the power, keep the unit off for at least 10 minutes, and confirm that the voltage between FT-P and FT-N on INV Board has dropped to DC20V or less. (It takes about 10 minutes to discharge electricity after the power supply is turned off.)

### Precautions for handling units for use with R410A

# **CAUTION**

#### Do not use the existing refrigerant piping.

A large amount of chlorine that is contained in the residual refrigerant and refrigerator oil in the existing piping may cause the refrigerator oil in the new unit to deteriorate.
R410A is a high-pressure refrigerant and can cause the existing pipes to burst.

Use refrigerant pipes made of phosphorus deoxidized copper. Keep the inner and outer surfaces of the pipes clean and free of such contaminants as sulfur, oxides, dust, dirt, shaving particles, oil, and water.

These types of contaminants inside the refrigerant pipes may cause the refrigerant oil to deteriorate.

Store the pipes to be installed indoors, and keep both ends of the pipes sealed until immediately before brazing. (Keep elbows and other joints wrapped in plastic.)

Infiltration of dust, dirt, or water into the refrigerant system may cause the refrigerating machine oil to deteriorate or cause the unit to malfunction.

Use a small amount of ester oil, ether oil, or alkylbenzene to coat flares and flanges.

Infiltration of a large amount of mineral oil may cause the refrigerating machine oil to deteriorate.

Charge liquid refrigerant (as opposed to gaseous refrigerant) into the system.

If gaseous refrigerant is charged into the system, the composition of the refrigerant in the cylinder will change and may result in performance loss.

#### Use a vacuum pump with a reverse-flow check valve.

If a vacuum pump that is not equipped with a reverse-flow check valve is used, the vacuum pump oil may flow into the refrigerant cycle and cause the refrigerating machine oil to deteriorate.

Prepare tools for exclusive use with R410A. Do not use the following tools if they have been used with the conventional refrigerant (gauge manifold, charging hose, gas leak detector, reverse-flow check valve, refrigerant charge base, vacuum gauge, and refrigerant recovery equipment.).

- •If the refrigerant or the refrigerating machine oil left on these tools are mixed in with R410A, it may cause the refrigerating machine oil to deteriorate.
- Infiltration of water may cause the refrigerating machine oil to deteriorate.
- Gas leak detectors for conventional refrigerants will not detect an R410A leak because R410A is free of chlorine.

#### Do not use a charging cylinder.

If a charging cylinder is used, the composition of the refrigerant will change, and the unit may experience power loss.

# Exercise special care when handling the tools for use with R410A.

Infiltration of dust, dirt, or water into the refrigerant system may cause the refrigerating machine oil to deteriorate.

#### Only use refrigerant R410A.

The use of other types of refrigerant that contain chlorine (i.e. R22) may cause the refrigerating machine oil to deteriorate.

### Before installing the unit

# **!** WARNING

#### Do not install the unit where a gas leak may occur.

If gaseous refrigerant leaks and piles up around the unit, it may be ignited.

Do not use the unit to keep food items, animals, plants, artifacts, or for other special purposes.

The unit is not designed to preserve food products.

#### Do not use the unit in an unusual environment.

- •Do not install the unit where a large amount of oil or steam is present or where acidic or alkaline solutions or chemical sprays are used frequently. Doing so may lead to a remarkable drop in performance, electric shock, malfunctions, smoke, and/or fire.
- •The presence of organic solvents or corrosive gas (i.e. ammonia, sulfur compounds, and acid) may cause gas leakage or water leakage.

# When installing the unit in a hospital, take appropriate measures to reduce noise interference.

High-frequency medical equipment may interfere with the normal operation of the air conditioner or vice versa.

# Do not install the unit on or over things that cannot get wet.

When the humidity level exceeds 80% or if the drainage system is clogged, the indoor unit may drip water. Drain water is also discharged from the heat source unit. Install a centralized drainage system if necessary.

# Before installing the unit (moving and reinstalling the unit) and performing electrical work

# **⚠** CAUTION

#### Properly ground the unit.

Do not connect the grounding wire to a gas pipe, water pipe, lightning rod, or grounding wire from a telephone pole. Improper grounding may result in electric shock, smoke, fire, and/or malfunction due to noise interference.

#### Do not put tension on the power supply wires.

If tension is put on the wires, they may break and result in excessive heat, smoke, and/or fire.

# Install an earth leakage breaker to avoid the risk of electric shock.

Failure to install an earth leakage breaker may result in electric shock, smoke, and/or fire.

# Use the kind of power supply wires that are specified in the installation manual.

The use of wrong kind of power supply wires may result in current leak, electric shock, and/or fire.

# Use breakers and fuses (current breaker, remote switch <switch + Type-B fuse>, moulded case circuit breaker) with the proper current capacity.

The use of wrong capacity fuses, steel wires, or copper wires may result in malfunctions, smoke, and/or fire.

#### Do not spray water on the air conditioner or immerse the air conditioner in water.

Otherwise, electric shock and/or fire may result.

When handling units, always wear protective gloves to protect your hands from metal parts and high-temperature parts.

#### Tighten terminal screws to the specified torque.

Loose screws and poor contact can result in smoke and fire.

#### Periodically check the installation base for damage.

If the unit is left on a damaged platform, it may fall and cause injury.

Properly install the drain pipes according to the instructions in the installation manual. Keep them insulated to avoid dew condensation.

Improper plumbing work may result in water leakage and damage to the furnishings.

#### Exercise caution when transporting products.

- •Products weighing more than 20 kg should not be carried alone.
- •Do not carry the product by the PP bands that are used on some products.
- •Do not touch the heat exchanger fins. They are sharp and dangerous.
- •When lifting the unit with a crane, secure all four corners to prevent the unit from falling.

#### Properly dispose of the packing materials.

- •Nails and wood pieces in the package may pose a risk of injury
- Plastic bags may pose a risk of choking hazard to children. Tear plastic bags into pieces before disposing of them.

### Before the test run

# **A** CAUTION

#### Turn on the unit at least 12 hours before the test run.

Keep the unit turned on throughout the season. If the unit is turned off in the middle of a season, it may result in malfunctions.

To avoid the risk of electric shock or malfunction of the unit, do not operate switches with wet hands.

# Do not touch the refrigerant pipes with bare hands during and immediately after operation.

During or immediately after operation, certain parts of the unit such as pipes and compressor may be either very cold or hot, depending on the state of the refrigerant in the unit at the time. To reduce the risk of frost bites and burns, do not touch these parts with bare hands.

# Do not operate the unit without panels and safety guards.

Rotating, high-temperature, or high-voltage parts on the unit pose a risk of burns and/or electric shock.

# Do not turn off the power immediately after stopping the operation.

Keep the unit on for at least five minutes before turning off the power to prevent water leakage or malfunction.

#### Do not operate the unit without the air filter.

Dust particles may build up in the system and cause malfunctions.

# **CONTENTS**

I Read Before Servicing	
[1] Read Before Servicing	3
[2] Necessary Tools and Materials	4
[3] Piping Materials	
[4] Storage of Piping[5] Pipe Processing	
[6] Brazing	
[7] Air Tightness Test	8
[8] Vacuum Drying (Evacuation)	9
[9] Refrigerant Charging	11
[10] Remedies to be taken in case of a Refrigerant Leak	11
[11] Differences in Refrigerant Properties	12
[12] Notes on Refrigerating Machine Oil	
[13] Precautions for servicing[14] Inspection and maintenance	
II Restrictions	10
[1] System configuration	21
[2] Types and Maximum allowable Length of Cables	23
[3] Switch Settings and Address Settings	25
[4] Sample System Connection	
[5] An Example of a System to which an MA Remote Controller is connected	32
[6] An Example of a System to which an ME Remote Controller is connected	54
[7] An Example of a System to which both MA Remote Controller and ME Remote	Controller
are connected	
[8] Restrictions on Pipe Length	63
III Heat source Unit Components	
[1] Heat source Unit Components and Refrigerant Circuit	81
[2] Control Box of the Heat source Unit	87
[3] Heat source Unit Circuit Board	89
[4] BC Controller Components	94
[5] Control Box of the BC Controller	
[6] BC Controller Circuit Board	98
IV Remote Controller  [1] Functions and Specifications of MA and ME Remote Controllers	104
V Electrical Wiring Diagram	
[1] Electrical Wiring Diagram of the Heat source Unit	113
[2] Electrical Wiring Diagram of the BC Controller	
[3] Electrical Wiring Diagram of Transmission Booster	124
VI Refrigerant Circuit	
[1] Refrigerant Circuit Diagram	127
[2] Principal Parts and Functions	131
VII Control	
[1] Functions and Factory Settings of the Dipswitches	141
[2] Controlling the Heat source Unit	148
[3] Controlling BC Controller	
[4] Operation Flow Chart	104
VIII Test Run Mode	
[1] Items to be checked before a Test Run	177
[2] Test Run Method	178
[3] Operating Characteristic and Refrigerant Amount	181
[4] Adjusting the Refrigerant Amount	
[5] Refrigerant Amount Adjust Mode	189
[6] The following symptoms are normal	
[7] Standard Operation Data (Reference Data)	194
IX Troubleshooting	
[1] Error Code Lists	243
[2] Responding to Error Display on the Remote Controller	
[3] Checking Transmission Waveform and for Electrical Noise Interference	322
[4] Troubleshooting Principal Parts	

HWE1515C GB

# CONTENTS

[5] Refrigerant Leak	360
[6] Compressor Replacement Instructions	364
[7] Servicing the BC controller	373
[8] Troubleshooting Using the Heat source Unit LED Error Display	376
X LED Monitor Display on the Heat source Unit Board	
[1] How to Read the LED on the Service Monitor	379
	379

HWE1515C GB

# I Read Before Servicing

[1]	Read Before Servicing	3
	Necessary Tools and Materials	
[3]	Piping Materials	5
[4]	Storage of Piping	6
[5]	Pipe Processing	6
[6]	Brazing	7
[7]	Air Tightness Test	8
[8]	Vacuum Drying (Evacuation)	9
[9]	Refrigerant Charging	11
[10]	Remedies to be taken in case of a Refrigerant Leak	11
[11]	Differences in Refrigerant Properties	12
[12]	Notes on Refrigerating Machine Oil	13
[13]	Precautions for servicing	14
[14]	Inspection and maintenance	15

### [1] Read Before Servicing

1. Check the type of refrigerant used in the system to be serviced.

#### Refrigerant Type

Multi air conditioner for building application CITY MULTI WY/WR2 Z(S)LMU-A1/B series: R410A

2. Check the symptoms exhibited by the unit to be serviced.

Refer to this service handbook for symptoms relating to the refrigerant cycle.

- 3. Thoroughly read the safety precautions at the beginning of this manual.
- 4. Preparing necessary tools: Prepare a set of tools to be used exclusively with each type of refrigerant.

  Refer to "Necessary Tools and Materials" for information on the use of tools.(page 4)
- 5. Verification of the connecting pipes: Verify the type of refrigerant used for the unit to be moved or replaced.
  - •Use refrigerant pipes made of phosphorus deoxidized copper. Keep the inner and outer surfaces of the pipes clean and free of such contaminants as sulfur, oxides, dust, dirt, shaving particles, oil, and water.
  - •These types of contaminants inside the refrigerant pipes may cause the refrigerant oil to deteriorate.
- 6. If there is a leak of gaseous refrigerant and the remaining refrigerant is exposed to an open flame, a poisonous gas hydrofluoric acid may form. Keep workplace well ventilated.



- Install new pipes immediately after removing old ones to keep moisture out of the refrigerant circuit.
- •The use of refrigerant that contains chloride, such as R22, will cause the refrigerating machine oil to deteriorate.
- 7. Specifications and system requirements may differ for products manufactured at different times. Refer to the relevant chapters for specification details. Production periods can be found from the serial number as follows.



### [2] Necessary Tools and Materials

Prepare the following tools and materials necessary for installing and servicing the unit.

#### Tools for use with R410A (Adaptability of tools that are for use with R22 or R407C)

#### 1. To be used exclusively with R410A (not to be used if used with R22 or R407C)

Tools/Materials	Use	Notes
Gauge Manifold	Evacuation and refrigerant charging	Higher than 5.09MPa[738psi] on the high-pressure side
Charging Hose	Evacuation and refrigerant charging	The hose diameter is larger than the conventional model.
Refrigerant Recovery Cylinder	Refrigerant recovery	
Refrigerant Cylinder	Refrigerant charging	The refrigerant type is indicated. The cylinder is pink.
Charging Port on the Refrigerant Cylinder	Refrigerant charging	The charge port diameter is larger than that of the current port.
Flare Nut	Connection of the unit with the pipes	Use Type-2 Flare nuts.

#### 2. Tools and materials that may be used with R410A with some restrictions

Tools/Materials	Use	Notes
Gas Leak Detector	Gas leak detection	The ones for use with HFC refrigerant may be used.
Vacuum Pump	Vacuum drying	May be used if a check valve adapter is attached.
Flare Tool	Flare processing	Flare processing dimensions for the piping in the system using refrigerant R410A differ from those of R22. Refer to I [3] Piping Materials.
Refrigerant Recovery Equipment	Refrigerant recovery	May be used if compatible with R410A.

#### 3. Tools and materials that are used with R22 or R407C that may also be used with R410A

Tools/Materials	Use	Notes
Vacuum Pump with a Check Valve	Vacuum drying	
Bender	Bending pipes	
Torque Wrench	Tightening flare nuts	Only the flare processing dimensions for pipes that have a diameter of ø12.70 (1/2") and ø15.88 (5/8") have been changed.
Pipe Cutter	Cutting pipes	
Welder and Nitrogen Cylinder	Welding pipes	
Refrigerant Charging Meter	Refrigerant charging	
Vacuum Gauge	Vacuum level check	

#### 4. Tools and materials that must not be used with R410A

Tools/Materials	Use	Notes
Charging Cylinder	Refrigerant charging	Prohibited to use
Tools containing abrasive materials	Pipe cutting, cut edge treatment	Prohibited to use

Tools for R410A must be handled with special care to keep moisture and dust from infiltrating the cycle.

### [3] Piping Materials

# Do not use the existing piping!

#### 1. Copper pipe materials

O-material (Annealed)	Soft copper pipes (annealed copper pipes). They can easily be bent with hands.
1/2H-material (Drawn)	Hard copper pipes (straight pipes). They are stronger than the O-material (Annealed) at the same radial thickness.

<sup>•</sup>The distinction between O-materials (Annealed) and 1/2H-materials (Drawn) is made based on the strength of the pipes themselves.

#### 2. Types of copper pipes

Maximum working pressure	Refrigerant type
3.45 MPa [500psi]	R22, R407C etc.
4.30 MPa [624psi]	R410A etc.

#### 3. Piping materials/Radial thickness

Select piping materials that meet the requirements set forth in ASTM B280.

#### 4. Thickness and refrigerant type indicated on the piping materials

Ask the pipe manufacturer for the symbols indicated on the piping material for refrigerant R410A.

#### 5. Flare processing

Select piping materials that meet the requirements set forth in ASTM.

#### 6. Flare nut

Select piping materials that meet the requirements set forth in ASTM.

### [4] Storage of Piping


#### 1. Storage location






Store the pipes to be used indoors. (Warehouse at site or owner's warehouse) If they are left outdoors, dust, dirt, or moisture may infiltrate and contaminate the pipe.

#### 2. Sealing the pipe ends





Both ends of the pipes should be sealed until just before brazing. Keep elbow pipes and T-joints in plastic bags.

Refrigerant oil is highly hygroscopic and is likely to degrade and cause compressor failure if moisture infiltrates into the system. Storage of piping materials requires stringent management.

### [5] Pipe Processing

Use a small amount of ester oil, ether oil, or alkylbenzene to coat flares and flanges.

Prevent the particles that are generated during pipe cutting or cut edge treatment from entering the pipes. If abrasive materials contained in sandpaper or cutting tools, hard foreign matter in concrete, gravel, etc. enter the refrigerant circuit, they may cause the compressor, valves, or other refrigerant circuit components to fail.

#### Note


- ◆Use a minimum amount of oil.
- •Use only ester oil, ether oil, and alkylbenzene.
- •To deburr pipes, use a reamer or other deburring tools, not sandpaper.
- •To cut pipes, use a pipe cutter, not a grinder or other tools that use abrasive materials.
- •When cutting or deburring pipes, do not allow cutting chips or other foreign matters to enter the pipes.
- •If cutting chips or other foreign matters enter pipes, wipe them off the inside of the pipes.

### [6] Brazing


No changes have been made in the brazing procedures. Perform brazing with special care to keep foreign objects (such as oxide scale, water, and dust) out of the refrigerant system.

Example: Inside the brazed connection

Use of oxidized solder for brazing



Use of non-oxidized solder for brazing



#### 1. Items to be strictly observed

- •Do not conduct refrigerant piping work outdoors if raining.
- \*Use non-oxidized solder.
- •Use a brazing material (BCuP-3) that requires no flux when brazing between copper pipes or between a copper pipe and copper coupling
- •If installed refrigerant pipes are not immediately connected to the equipment, then braze and seal both ends.

#### 2. Reasons


- •The new refrigerating machine oil is 10 times as hygroscopic as the conventional oil and is more likely to cause unit failure if water infiltrates into the system.
- •Flux generally contains chloride. Residual flux in the refrigerant circuit will cause sludge to form.

#### 3. Notes

Do not use commercially available antioxidants because they may cause the pipes to corrode or refrigerating machine oil to deteriorate.

### [7] Air Tightness Test

No changes have been made in the detection method. Note that a refrigerant leak detector for R22 will not detect an R410A leak.



#### 1. Items to be strictly observed

- •Pressurize the equipment with nitrogen up to the design pressure (4.15MPa[601psi]), and then judge the equipment's air tightness, taking temperature variations into account.
- •Refrigerant R410A must be charged in its liquid state (vs. gaseous state).

#### 2. Reasons

- •Oxygen, if used for an air tightness test, poses a risk of explosion. (Only use nitrogen to check air tightness.)
- •Refrigerant R410A must be charged in its liquid state. If gaseous refrigerant in the cylinder is drawn out first, the composition of the remaining refrigerant in the cylinder will change and become unsuitable for use.

#### 3. Notes

Procure a leak detector that is specifically designed to detect an HFC leak. A leak detector for R22 will not detect an HFC(R410A) leak.

### [8] Vacuum Drying (Evacuation)







(Photo2) 14010

Recommended vacuum gauge: ROBINAIR 14010 Thermistor Vacuum Gauge

#### 1. Vacuum pump with a reverse-flow check valve (Photo1)

To prevent the vacuum pump oil from flowing into the refrigerant circuit during power OFF or power failure, use a vacuum pump with a reverse-flow check valve.

A reverse-flow check valve may also be added to the vacuum pump currently in use.

#### 2. Standard of vacuum degree (Photo 2)

Use a vacuum pump that attains 0.5Torr(65Pa) or lower degree of vacuum after 5 minutes of operation, and connect it directly to the vacuum gauge. Use a pump well-maintained with an appropriate lubricant. A poorly maintained vacuum pump may not be able to attain the desired degree of vacuum.

#### 3. Required precision of vacuum gauge

Use a vacuum gauge that registers a vacuum degree of 5Torr(650Pa) and measures at intervals of 1Torr(130Pa). (A recommended vacuum gauge is shown in Photo2.)

Do not use a commonly used gauge manifold because it cannot register a vacuum degree of 5Torr(650Pa).

#### 4. Evacuation time

•After the degree of vacuum has reached 5Torr(650Pa), evacuate for an additional 1 hour. (A thorough vacuum drying removes moisture in the pipes.) When the outside temperature drops below 1°C (or when the saturation pressure drops below 656 Pa), continue vacuum drying for another 1 hour after the vacuum degree has reached the saturated vapor pressure of the water (ice) at the outside temperature. When performing vacuum drying at a low outside temperature, use a vacuum gauge appropriate for the temperature range.

#### Degree of vacuum (reference)

Outdoor temp.	-20°C (-4°F)	-15°C (5°F)	-10°C (14°F)	-5°C (23°F)	0°C (32°F)
Degree of vacuum	0.77 Torr (103 Pa)	1.24 Torr (165 Pa)	1.95 Torr (260 Pa)	3.01 Torr (402 Pa)	4.58 Torr (611 Pa)

<sup>\*</sup> Degrees of vacuum shown above are obtained based on the saturated vapor pressure of ice.

- •Verify that the vacuum degree has not risen by more than 1Torr(130Pa) 1hour after evacuation. A rise by less than 1Torr(130Pa) is acceptable.
- •If the vacuum is lost by more than 1Torr(130Pa), conduct evacuation, following the instructions in section 6. Special vacuum drying.

#### 5. Procedures for stopping vacuum pump

To prevent the reverse flow of vacuum pump oil, open the relief valve on the vacuum pump side, or draw in air by loosening the charge hose, and then stop the operation.

The same procedures should be followed when stopping a vacuum pump with a reverse-flow check valve.

#### 6. Special vacuum drying

- •When 5Torr(650Pa) or lower degree of vacuum cannot be attained after 3 hours of evacuation, it is likely that water has penetrated the system or that there is a leak.
- •If water infiltrates the system, break the vacuum with nitrogen. Pressurize the system with nitrogen gas to 0.5kgf/cm<sup>2</sup>G(0.05MPa) and evacuate again. Repeat this cycle of pressurizing and evacuation either until the degree of vacuum below 5Torr(650Pa) is attained or until the pressure stops rising.
- Only use nitrogen gas for vacuum breaking. (The use of oxygen may result in an explosion.)

<sup>\*</sup> In a system using water heat exchangers, circulate water to prevent the water in the heat exchangers from freezing during vacuum drying.

#### 7. Notes

•To evacuate air from the entire system

Applying a vacuum through the check joints at the refrigerant service valve (BV1 and 2) is not enough to attain the desired vacuum pressure.

Be sure to apply a vacuum through the check joints at the refrigerant service valve (BV1 and 2) and also through the check joints on the high and low pressure sides (CJ1 and 2).

•To evacuate air only from the heat source units

Apply a vacuum through the check joints on the high and low pressure sides (CJ1, and 2).


◆To evacuate air from the indoor units and extension pipes

Apply a vacuum through the check joints at the refrigerant service valve (BV1 and 2).

•When performing the maintenance work, such as vacuum drying, pumping down, or refrigerant recovery, on the heat-source unit, operate the water circuit pump and circulate the water to prevent the water side of the heat exchanger from freezing.


### [9] Refrigerant Charging

Cylinder with a siphon




Cylinder color R410A is pink.





Refrigerant charging in the liquid state





#### 1. Reasons

R410A is a pseudo-azeotropic HFC blend (boiling point R32=-52°C[-62°F], R125=-49°C[-52°F]) and can almost be handled the same way as a single refrigerant, such as R22. To be safe, however, draw out the refrigerant from the cylinder in the liquid phase. If the refrigerant in the gaseous phase is drawn out, the composition of the remaining refrigerant will change and become unsuitable for use.

#### 2. Notes

When using a cylinder with a siphon, refrigerant is charged in the liquid state without the need for turning it upside down. Check the type of the cylinder on the label before use.

#### [10] Remedies to be taken in case of a Refrigerant Leak

If the refrigerant leaks out, it may be replenished. The entire refrigerant does not need to be replaced. (Charge refrigerant in the liquid state.)

Refer to "IX [5] Refrigerant Leak."(page 360)

### [11] Differences in Refrigerant Properties

#### 1. Chemical property

As with R22, R410A is low in toxicity and chemically stable nonflammable refrigerant.

However, because the specific gravity of vapor refrigerant is greater than that of air, leaked refrigerant in a closed room will accumulate at the bottom of the room and may cause hypoxia.

If exposed to an open flame, refrigerant will generate poisonous gases. Do not perform installation or service work in a confined area.

	HFC Refrigerant		HCFC Refrigerant
	R410A	R407C	R22
	R32/R125	R32/R125/R134a	R22
Composition (wt%)	(50/50)	(23/25/52)	(100)
Type of Refrigerant	Pseudo-azeotropic Refrigerant	Non-azeotropic Refrigerant	Single Refrigerant
Chloride	Not included	Not included	Included
Safety Class	A1/A1	A1/A1	A1
Molecular Weight	72.6	86.2	86.5
Boiling Point (°C/°F)	-51.4/-60.5	-43.6/-46.4	-40.8/-41.4
Steam Pressure (25°C,MPa/77°F,psi) (gauge)	1.557/226	0.9177/133	0.94/136
Saturated Steam Density (25°C,kg/m <sup>3</sup> /77°F,psi)	64.0	42.5	44.4
Flammability	Nonflammable	Nonflammable	Nonflammable
Ozone Depletion Coefficient (ODP)*1	0	0	0.055
Global Warming Coefficient (GWP)*2	2088	1774	1810
Refrigerant Charging Method	Refrigerant charging in the liquid state	Refrigerant charging in the liquid state	Refrigerant charging in the gaseous state
Replenishment of Refrigerant after a Refrigerant Leak	Available	Available	Available

<sup>\*1</sup> When CFC11 is used as a reference

#### 2. Refrigerant composition

R410A is a pseudo-azeotropic HFC blend and can almost be handled the same way as a single refrigerant, such as R22. To be safe, however, draw out the refrigerant from the cylinder in the liquid phase. If the refrigerant in the gaseous phase is drawn out, the composition of the remaining refrigerant will change and become unsuitable for use.

If the refrigerant leaks out, it may be replenished. The entire refrigerant does not need to be replaced.

#### 3. Pressure characteristics

The pressure in the system using R410A is 1.6 times as great as that in the system using R22.

	Pressure (gauge)		
Temperature (°C/°F)	R410A	R407C	R22
	MPa/psi	MPa/psi	MPa/psi
-20/-4	0.30/44	0.18/26	0.14/20
0/32	0.70/102	0.47/68	0.40/58
20/68	1.34/194	0.94/136	0.81/117
40/104	2.31/335	1.44/209	1.44/209
60/140	3.73/541	2.44/354	2.33/338
65/149	4.17/605	2.75/399	2.60/377

<sup>\*2</sup> When CO<sub>2</sub> is used as a reference

### [12] Notes on Refrigerating Machine Oil

#### 1. Refrigerating machine oil in the HFC refrigerant system

HFC type refrigerants use a refrigerating machine oil different from that used in the R22 system. Note that the ester oil used in the system has properties that are different from commercially available ester oil.

Refrigerant	Refrigerating machine oil
R22	Mineral oil
R407C	Ester oil
R410A	Ester oil

#### 2. Effects of contaminants\*1

Refrigerating machine oil used in the HFC system must be handled with special care to keep contaminants out. The table below shows the effect of contaminants in the refrigerating machine oil on the refrigeration cycle.

### 3. The effects of contaminants in the refrigerating machine oil on the refrigeration cycle.

Cause		Symptoms		Effects on the refrigerant cycle	
Water infiltration  Air infiltration		Frozen expansion valve and capillary tubes		Clogged expansion valve and capillary tubes Poor cooling performance Compressor overheat	
		Hydrolysis	Sludge formation and adhesion Acid generation Oxidization Oil degradation	Motor insulation failure Burnt motor Coppering of the orbiting scroll Lock Burn-in on the orbiting scroll	
		Oxidization	On dogradation		
	Dust, dirt	Adhesion to expansion valve and capillary tubes		Clogged expansion valve, capillary tubes, and drier Poor cooling performance Compressor overheat	
Infiltration of contaminants		Infiltration of contaminants into the compressor		Burn-in on the orbiting scroll	
	Mineral oil etc.	Sludge formati	on and adhesion	Clogged expansion valve and capillary tubes Poor cooling performance Compressor overheat	
		Oil degradation		Burn-in on the orbiting scroll	

<sup>\*1.</sup> Contaminants is defined as moisture, air, processing oil, dust/dirt, wrong types of refrigerant, and refrigerating machine oil.

#### [13] Precautions for servicing

- •Control boxes house high-voltage and high-temperature electrical parts.
- •They may still remain energized or hot after the power is turned off.
- •When opening or closing the front cover of the control box, keep out of contact with the internal parts.

  Before inspecting the inside of the control box, turn off the power, leave the unit turned off for at least 10 minutes, and check that the voltage of the electrolytic capacitor (inverter main circuit) has dropped to 20 VDC or less.
- •When the power is on, the compressor or heater is energized even while the compressor is stopped. The liquid refrigerant in the compressor will evaporate by energizing the compressor or heater.
- •When replacing the internal electrical components of the control box, tighten the screws to the recommended tightening torque as specified below.

Recommended tightening torque for the internal electrical components of the control box

Screw	Recommended tightening torque (N·m)
М3	0.69
M3.5	0.95
M4	1.47
M5	2.55
M6	2.75
M8	6.20

- \*1 When replacing the inverter board, apply heatsink grease to the semiconductor module on the back of the inverter board evenly, pretighten the screws to hold semiconductor module to one-third of the specified torque, and then tighten the screws to the specified torque.
- \*2 Deviating from the recommended tightening torque may cause damage to the unit or its parts.

Take the following steps to ensure that the screws are properly tightened.

1) Ensure that the spring washers are parallel to the terminal block.

Even if the tightening torque is observed, if the washers are not parallel to the terminal block, then the semiconductor module is not installed properly.




- 2) Check the wires are securely fastened to the screw terminals.
  - \*Screw the screws straight down so as not to damage the screw threads.

Hold the two round terminals back to back to ensure that the screw will screw down straight.

\*After tightening the screw, mark a line through the screw head, washer, and terminals with a permanent marker.

#### Example



Poor contact caused by loose screws may result in overheating and fire. Continued use of the damaged circuit board may cause overheating and fire.

### [14] Inspection and maintenance

### 1. Guideline for preventive maintenance

The following maintenance intervals indicate the estimated intervals of parts replacement and repair to be required as a result of periodic inspections. They do not necessarily mean that replacement is required at the maintenance intervals.

The maintenance intervals do not indicate the warranty period.

Unit	Parts	Inspection interval	Maintenance interval	Daily inspection	Maintenance inspection	Remarks
	Compressor				0	
Heat source unit	Electronic expansion valve		20,000 hours		0	
	Valve				0	
	Heat exchanger	1 year	5 years		0	
	Sensor		20,000 hours		0	
	Electric board		25,000 hours		0	
	Smoothing capacitor		10 years		0	

#### 2. Recommended parts inspection interval

Unit	Parts	Inspection interval	Inspection items	Criteria	Measures
	Compressor		*Auditory check of operating sounds     *Measurement of insulation resistance     *Visual check for loose terminals	No abnormal sounds Insulation resistance must be 1 MΩ or above. No loose terminals	Replace the compressor if an insulation problem is found when the refrigerant is not stagnating. Retighten loose terminals.
	Electronic expansion valve		Operation check using operation data	Temperature must change in proportion to the valve position. (Check the temperature variation with the centralized controller.)	Replace the valve if the operation data show an operation failure due to valve problems.
Heat source unit	Valve	1 уеаг	Operation check using operation data	Temperature must change according to the valve position.(Check the temperature variation when the operation mode is switched between cooling and heating.)	Replace the valve if the operation data show an operation failure due to valve problems.
	Heat exchanger		Check for clogging, contamination, and damage	Clogging, contamina- tion, and damage	Perform cleaning.
	Sensor		Check for breakage and deterioration of the cables, and for disconnection of the connectors.     Measurement of insulation resistance	No breakage or deterioration of the cables or disconnected connectors.	Replace the sensor if the cable is broken, short-circuited, or se- verely deteriorated, or an insulation problem is found.
	Electric board		•Check the appearance	•No sedimentary re- mains	Clean with a brush if deposits are attached
	Smoothing capacitor *1		Check the appearance of electrolytic capaci- tors	No liquid leakage, de- formation, or sleeve (outer film) shrinkage	Replace the electrolytic capacitor if there is leakage, deformation, or shrinkage of the sleeve (outer film).

- •The inspection intervals depend on the usage and environment.
- The inspection intervals do not indicate the warranty period.
- •The maintenance and inspection items may differ depending on maintenance providers. Please check with your maintenance provider when concluding a maintenance contract.
- •Repairs outside the warranty period will be charged, even if periodic inspections have been performed at the recommended intervals.
- \*1 If the performance of the electrolytic capacitor deteriorates due to long-term use, the internal temperature of the capacitor may rise and the explosion-proof valve may operate.

The operation of the explosion-proof valve may cause the electrolyte inside to leak and make other electrical components unusable. (The operation of the explosion-proof valve may cause the electrolyte to spurt out as liquid or gas.)

As a preventive maintenance, if the integrated operation time of the compressor exceeds 25,000 hours, or if 10 years have passed since the start of use, it is recommended to replace the electrolytic capacitor (or, depending on the model, the board with the capacitor mounted).

Even if the integrated operation time is less than 25,000 hours, the electrolytic capacitor may deteriorate quickly due to environmental influences (power supply imbalance, temperature, or humidity), resulting in shrinkage of the exterior film, exposure of the aluminum case, and liquid leakage. If any of the conditions shown in Photos 2 and 4 are found, please replace the capacitor promptly.

- \* For the location of the smoothing capacitor, refer to the following page(s). [III Heat source Unit Components](page 81)
- \* The integrated operation time of compressor can be monitored on service LED on the control board.

  For details on how to read the LED, refer to the following page(s). [X LED Monitor Display on the Heat source Unit Board](page 379)




Photo 4. Deteriorated

# **II Restrictions**

[1]	System configuration	. 21
[2]	Types and Maximum allowable Length of Cables	. 23
[3]	Switch Settings and Address Settings	. 25
[4]	Sample System Connection	.31
[5]	An Example of a System to which an MA Remote Controller is connected	. 32
[6]	An Example of a System to which an ME Remote Controller is connected	. 54
[7]	An Example of a System to which both MA Remote Controller and ME Remote Controller are connected	58
[8]	Restrictions on Pipe Length	.63

### [1] System configuration

### 1. Table of compatible indoor units <PQHY>

The table below summarizes the types of indoor units that are compatible with different types of heat source units.

Heat source units	Compos	ing units	Maximum total capacity of connectable indoor units	Maximum number of connectable indoor units	Types of connectable in- door units
P72	-	-	36 - 93	1 - 18	P04 - P96 models
P96	-	-	48 - 124	1 - 24	R410A series indoor units
P120	-	-	60 - 156	1 - 30	
P144	-	-	72 - 187	1 - 36	
P168	-	-	84 - 218	1 - 42	
P192	-	-	96 - 249	1 - 48	
P144	P72	P72	72 - 187	1 - 36	
P168	P96	P72	84 - 218	1 - 42	
P192	P96	P96	96 - 249	1 - 48	
P216	P120	P96	108 - 280	2 - 50	
P240	P120	P120	120 - 312		
P288	P144	P144	144 - 374		
P312	P168	P144	156- 405	2 - 50	
P336	P168	P168	168 - 436		
P360	P192	P168	180 - 468		

#### Note

- 1) "Maximum total capacity of connectable indoor units" refers to the sum of the numeric values in the indoor unit model names.
- 2) If the total capacity of the indoor units that are connected to a given heat source unit exceeds the capacity of the heat source unit, the indoor units will not be able to perform at the rated capacity when they are operated simultaneously. Select a combination of units so that the total capacity of the connected indoor units is at or below the capacity of the heat source unit whenever possible.
- 3) PQHY-P-Z(S)LMU-A, PQHY-P-Z(S)LMU-A1 and PQHY-P-Z(S)LMU-B heat source units cannot be used in combination.

#### 1. Table of compatible indoor units <PQRY>

The table below summarizes the types of indoor units that are compatible with different types of heat source units.

Heat source units	Compos	ing units	Maximum total capacity of connectable indoor units	Maximum number of connectable indoor units	Types of connectable in- door units
P72	-	-	36- 108	1 - 18	P04 - P96 models
P96	-	-	48 - 144	1 - 24	R410A series indoor units
P120	-	-	60 - 180	1 - 30	
P144	-	-	72- 216	1 - 36	
P168	-	-	84 - 252	1 - 42	
P192	-	-	96 - 288	1 - 48	
P144	P72	P72	72 - 216	1 - 36	
P168	P96	P72	84 - 252	1 - 42	
P192	P96	P96	96 - 288	1 - 48	
P216	P120	P96	108 - 324		
P240	P120	P120	120 - 360		
P288	P144	P144	144 - 432	2 - 50	
P312	P168	P144	156 - 468		
P336	P168	P168	168 - 504		

#### Note

- 1) "Maximum total capacity of connectable indoor units" refers to the sum of the numeric values in the indoor unit model names.
- 2) If the total capacity of the indoor units that are connected to a given heat source unit exceeds the capacity of the heat source unit, the indoor units will not be able to perform at the rated capacity when they are operated simultaneously. Select a combination of units so that the total capacity of the connected indoor units is at or below the capacity of the heat source unit whenever possible.
- 3) PQRY-P-Z(S)LMU-A, PQRY-P-Z(S)LMU-A1 and PQRY-P-Z(S)LMU-B heat source units cannot be used in combination.


#### [2] Types and Maximum allowable Length of Cables


#### 1. Wiring work

#### (1) Notes

- 1) Have all electrical work performed by an authorized electrician according to the local regulations and instructions in this man-
- Install external transmission cables at least 5cm [1-31/32"] away from the power supply cable to avoid noise interference.
   (Do not put the control cable and power supply cable in the same conduit tube.)
- 3) Provide grounding for the heat source unit as required.
- 4) Run the cable from the electric box of the indoor or heat source unit in such way that the box is accessible for servicing.
- 5) Do not connect power supply wiring to the terminal block for transmission line. Doing so will damage the electronic components on the terminal block.
- 6) Use 2-core shielded cables as transmission cables.

Use a separate 2-core control cable for each refrigerant system. Do not use a single multiple-core cable to connect indoor units that belong to different refrigerant systems. The use of a multiple-core cable may result in signal transmission errors and malfunctions.





TB3: Terminal block for indoor-heat source transmission line TB7: Terminal block for centralized control

- 7) When extending the transmission cable, be sure to connect the shield.
- 8) When opening or closing the front cover of the control box, keep out of contact with the internal parts.Before inspecting the inside of the control box, turn off the power, leave the unit turned off for at least 10 minutes, and check that the voltage of the electrolytic capacitor (inverter main circuit) has dropped to 20 VDC or less.
- 9) Control boxes house high-voltage and high-temperature electrical parts. Use caution not to come in contact with them.
- 10) Before turning on the power, disconnect the power wires from the terminal block of the compressor and measure the insulation resistance of the compressor. Check that the compressor does not have a ground fault. If the insulation resistance is below 1  $M\Omega$ , connect the power wires of the compressor and turn on the power of the heat source unit. (The liquid refrigerant in the compressor will evaporate by energizing the compressor or heater.)
- 11) Read Chapter I [13] Precautions for servicing (page 14), and tighten screws to the appropriate torque. Loose screws and poor contact can result in overheating and fire.

#### (2) Control wiring

Different types of control wiring are used for different systems.

Refer to section "[5] An Example of a System to which an MA Remote Controller is connected - [7] An Example of a System to which both MA Remote Controller and ME Remote Controller are connected" before performing wiring work.

#### Types and maximum allowable length of cables

Control lines are categorized into 2 types: transmission line and remote controller line.

Use the appropriate type of cables and observe the maximum allowable length specified for a given system. If a given system has a long transmission line or if a noise source is located near the unit, place the unit away from the noise source to reduce noise interference.

#### 1) M-NET transmission line

Туре	2-core shielded cable CVVS, CPEVS, or MVVS
Size	1.25 mm <sup>2</sup> [AWG 16], or ø1.2 mm or above
Length	Max. 200 m [656 ft]
Remarks	The maximum allowable length of transmission cables via heat source units (both centralized control transmission cables and indoor-outdoor transmission cables) is 500 m [1640 ft]*1. The maximum allowable length of transmission cables from the power supply unit to each heat source unit or to the system controller is 200 m [656 ft].

<sup>\*</sup> Do not use a single multiple-core cable to connect indoor units that belong to different refrigerant systems. The use of a multiple-core cable may result in signal transmission errors and malfunctions.

#### 2) Remote controller wiring

	MA remote controller	ME remote controller
Туре	2-core cable VCTF, VCTFK, CVV, VVR, VVF, or VCT	2-core shielded cable CVVS, CPEVS, or MVVS
Size	0.3 to 1.25 mm <sup>2</sup> [AWG 22 to 16] *1 *4	0.3 to 1.25 mm <sup>2</sup> [AWG 22 to 16] *1 *5
Length	Max. 200 m [656 ft] *2 *3	The section of the cable that exceeds 10 m [32 ft] must be included in the maximum indoor-outdoor transmission line distance.

<sup>\*1</sup> The use of cables that are smaller than 0.75 mm<sup>2</sup> [AWG 18] is recommended for easy handling.

<sup>\*</sup> Ensure shield continuity when extending the transmission cable.

<sup>\*1</sup> When extending the length of the transmission cables to 1000 m [3280 ft], consult your dealer.

<sup>\*2</sup> Max. 70 m [229 ft] for PAR-CT01MA series

<sup>\*3</sup> Max. 150 m [492 ft] for PAR-FS01MA series

<sup>\*4</sup> To wire PAR-CT01MA series, PAR-FS01MA series, PAR-4"x"MA series, PAR-3"x"MA series ("x" represents 0 or later), or Simple MA remote controller, use a cable with a size of 0.3 mm<sup>2</sup> [AWG 22].

<sup>\*5</sup> When connected to the terminal block on the Simple remote controller, use a cable with a size of 0.75 to 1.25 mm<sup>2</sup> [AWG18 to 16].

### [3] Switch Settings and Address Settings

#### 1. Switch setting

Refer to section "[5] An Example of a System to which an MA Remote Controller is connected - [7] An Example of a System to which both MA Remote Controller and ME Remote Controller are connected" before performing wiring work. Set the switches while the power is turned off.

If the switch settings are changed while the unit is being powered, those changes will not take effect, and the unit will not function properly.

Units on which to se	t the switches	Symbol	Units to which the power must be shut off
CITY MULTI indoor unit	Main/sub unit	IC	Heat source units *3 and Indoor units
LOSSNAY, OA processing u	nit *1	LC	Heat source units *3 and LOSSNAY
M-NET remote controller	Main/sub remote controller	RC	Heat source units *3
MA remote controller Main/sub remote controller		MA	Indoor units
CITY MULTI heat source unit <sup>*2</sup>		OC,OS	Heat source units *3
BC controller Main		ВС	Heat source units *3 and BC controller
	Sub1 - 11	BS1 - 11	Heat source units *3 *4 and BC controller

<sup>\*1.</sup> Applicable when LOSSNAY units are connected to the indoor-heat source transmission line.

<sup>\*2.</sup> The heat source units in the same refrigerant circuit are automatically designated as OC and OS in the order of capacity from large to small (if two or more units have the same capacity, in the order of address from small to large).

<sup>\*3.</sup> Turn off the power to all the heat source units in the same refrigerant circuit.

<sup>\*4.</sup> When setting the switch SW4 of the control board, set it with the heat source unit power on. Refer to the following page(s). VII [1] Functions and Factory Settings of the Dipswitches (page 141)

#### 2. M-NET Address settings

### (1) Address settings table

The need for address settings and the range of address setting depend on the configuration of the system.

Uni	t or controller	Sym- bol	Address setting range	Setting method	Factory address setting
CITY MULTI indoor unit M-NET adapter M-NET control interface Free Plan adapter	Main/sub unit	IC	0, 01 to 50*1*4*6	Assign the smallest address to the main indoor unit in the group, and assign sequential address numbers to the rest of the indoor units in the same group.  In an R2 system with a sub BC controller, make the settings for the indoor units in the following order.  (i) Indoor unit to be connected to the main BC controller (ii) Indoor unit to be connected to sub BC controller 1 (iii) Indoor unit to be connected to sub BC controller 2 Make the settings for the indoor units in the way that the formula "(i) < (ii) < (iii) "is true.  When using additional BC controllers (3 to 11 BC controllers), make the same settings.	00
LOSSNAY, C	OA processing unit	LC	0, 01 to 50 <sup>*1</sup> *4 *6	Assign an arbitrary but unique address to each of these units after assigning an address to all indoor units.	00
M-NET re- mote con-	Main remote controller	RC	101 to 150	Add 100 to the smallest address of all the indoor units in the same group.	101
troller	Sub remote controller	RC	151 to 200 <sup>*3</sup>	Add 150 to the smallest address of all the indoor units in the same group.	
MA remote co	ontroller	MA		ss settings required. (The main/sub setting must be made if controllers are connected to the system.)	Main
CITY MULTI	heat source unit	OC OS	0, 51 to 100*1*2 *6	Assign an address that equals the lowest address of the indoor units in the same refrigerant circuit plus 50.     Assign sequential addresses to the heat source units in the same refrigerant circuit. The heat source units in the same refrigerant circuit are automatically designated as OC and OS.	00
Auxiliary heat source unit	BC controller (main)	BC	0, 51 to 100*1*2 *6	Assign an address that equals the address of the heat source unit in the same refrigerant system plus 1.     If a given address overlaps any of the addresses that are assigned to the heat source units or to the sub BC controller, use a different, unused address within the setting range.	00
	BC controller (sub)	BS1 BS2 BS11	51 to 100 *2	Assign an address to both the sub BC controller 1 and 2 that equals the lowest address of the indoor units that are connected to each of them plus 50.      If a sub BC controller is connected, the automatic startup function is not available.	
System controller	Group remote con- troller	GR SC	201 to 250	Assign an address that equals the sum of the smallest group number of the group to be controlled and 200.	201
	System remote controller	SR SC		Assign an arbitrary but unique address within the range listed on the left to each unit.	
	ON/OFF remote controller	AN SC		Assign an address that equals the sum of the smallest group number of the group to be controlled and 200.	
	Schedule timer (compatible with M-NET)	ST SC		Assign an arbitrary but unique address within the range listed on the left to each unit.	202
	Central controller AG-150A, G(B)-50A, GB-24A	TR SC	0, 201 to 250	Assign an arbitrary but unique address within the range listed on the left to each unit. The address must be set to "0" to control the K-control unit.	000
	Expansion controller PAC-YG50ECA				
	BM adapter BAC-HD150	SC			
	LM adapter	SC	201 to 250	Assign an arbitrary but unique address within the range listed on the left to each unit.	247

- \*5. The heat source units in the same refrigerant circuit are automatically designated as OC, and OS. They are designated as OC, and OS in the descending order of capacity (ascending order of address if the capacities are the same).
- \*6. No address settings are required for units in a system with a single heat source unit (with some exceptions). Address setting is required if a sub BC controller is connected.

# (2) Power supply switch connector connection on the heat source unit (Factory setting: The male power supply switch connector is connected to CN41.)

There are limitations on the total number of units that are connectable to each refrigerant system. Refer to the DATABOOK for details.

System configuration	Connection to the system con- troller	Power supply unit for transmission lines	Group operation of units in a sys- tem with multiple heat source units	Power supply switch connector connection
System with one heat source unit	-	-	-	Leave CN41 as it is (Factory setting)
System with multiple heat source units	Not connected	-	Not grouped	
			Grouped	Disconnect the male connector from the female power supply switch connector (CN41) and connect it to the female power supply switch connector (CN40) on only one of the heat source units. 2  *Connect the S (shielded) terminal on the terminal block (TB7) on the heat source unit whose CN41 was replaced with CN40 to the ground terminal (六) on the electric box.
	With connection to the indoor- heat source transmission line	Not required	Grouped/not grouped	
	to the central- ized control sys-	Not required*1 (Powered from the heat source unit)	Grouped/not grouped	
		Required *1	Grouped/not grouped	Leave CN41 as it is (Factory setting)

<sup>\*1</sup> The need for a power supply unit for transmission lines depends on the system configuration.

### (3) Settings for the centralized control switch for the heat source unit (Factory setting: SW5-1 are set to OFF.)

System configuration	Centralized control switch settings *1	
Connection to the system controller Not connected	Leave it to OFF. (Factory setting)	
Connection to the system controller Connected*2	ON	

<sup>\*1.</sup> Set SW5-1 on all heat source units in the same refrigerant circuit to the same setting.

#### (4) Selecting the position of temperature detection for the indoor unit (Factory setting: SW1-1 set to "OFF".)

To stop the fan during heating Thermo-OFF (SW1-7 and 1-8 on the indoor units to be set to ON), use the built-in thermistor on the remote controller or an optional thermistor.

- 1) To use the built-in sensor on the remote controller, set the SW1-1 to ON.
  - •Some models of remote controllers are not equipped with a built-in temperature sensor. Use the built-in temperature sensor on the indoor unit instead.
  - •When using the built-in sensor on the remote controller, install the remote controller where room temperature can be detected. (Note) Factory setting for SW1-1 on the indoor unit of the All-Fresh Models is ON.
- 2) When an optional temperature sensor is used, set SW1-1 to OFF, and set SW3-8 to ON.
  - When using an optional temperature sensor, install it where room temperature can be detected.

<sup>\*2</sup> The replacement of the power jumper connector from CN41 to CN40 must be performed on only one heat source unit in the system.

<sup>\*2.</sup> When only the LM adapter is connected, leave SW5-1 to OFF (as it is).

## (5) Various start-stop controls (Indoor unit settings)

Each indoor unit (or group of indoor units) can be controlled individually by setting SW 1-9 and 1-10.

Function	Operation of the indoor unit when the operation is resumed after the unit	Setting (SW1)*4 *5		
	was stopped		10	
Power ON/OFF by the plug*1,*2,*3	Indoor unit will go into operation regardless of its operation status before power off (power failure). (In approx. 5 minutes)	OFF	ON	
Automatic restoration after power failure	Indoor unit will go into operation if it was in operation when the power was turned off (or cut off due to power failure). (In approx. 5 minutes)	ON	OFF	
	Indoor unit will remain stopped regardless of its operation status before power off (power failure).	OFF	ON	

<sup>\*1.</sup> Do not cut off power to the heat source unit. Cutting off the power supply to the heat source unit will cut off the power supply to the crankcase heater and may cause the compressor to malfunction when the unit is put back into operation.

\*2. Not applicable to units with a built-in drain pump and humidifier.

\*4. Requires that the dipswitch settings for all the units in the group be made.

#### (6) Miscellaneous settings

Cooling-only setting for the indoor unit: Cooling only model (Factory setting: SW3-1 "OFF.") When using indoor unit as a cooling-only unit, set SW3-1 to ON.

## (7) Various types of control using input-output signal connector on the heat source unit (various connection options)

Туре	Usage	Function	Terminal to be used*1	Option	
Input	Prohibiting cooling/heating operation (thermo OFF) by an external input to the heat source unit.  * Usable for demand control of each refrigerant system	DEMAND (level)	CN3D*2	Adapter for exter- nal input	
	Performs a low level noise operation of the heat source unit by an external input to the heat source unit.  * It can be used as the silent operation device for each refrigerant system.	Low-noise mode (level)*3 *4		(PAC- SC36NA- E)	
	Cooling/heating operation can be changed by an external input to the heat source unit (OC).	Auto-changeover	CN3N		
	Receives interlock operation signal input from the water circuit pump (field-supplied)	Pump interlock operation signal input	TB-8 (between poles 3 and 4) *Minimum guaranteed current at no-voltage input contact: 5 mA or below	-	
Out- put	Outputs signals to perform interlocked operation of heat source unit and water circuit pump Signal output patterns  *When DIP SW4 No.917 (SW6-10: ON) is set to off (factory setting) Signals are output while the compressor is in operation.  *When DIP SW4 No.917 (SW6-10: ON) is set to ON Signals are output while receiving cooling or heating signal from the controller.  *Signals are output even if the thermostat is OFF. (when the compressor is not operating)	Pump interlock operation signal	TB-8 (between poles 1 and 2) *Contact rating: 208/230VAC 1A or below	-	
	How to extract signals from the heat source unit *It can be used as an operation status display device. *It can be used for an interlock operation with external devices.	Operation status of the compressor Error status	CN51	Adapter for exter- nal output (PAC- SC37SA- E)	

<sup>\*1.</sup> For detailed drawing, refer to "Example of wiring connection".

<sup>\*3.</sup> Models with a built-in drain pump cannot be turned on/off by the plug individually. All the units in the same refrigerant circuits will be turned on or off by the plug.

<sup>\*5.</sup> Set SW1-9 and SW1-10 to ON to control the external input from/output to the air conditioning units via AG-150A or G(B)-50A using the PLC software for general equipment. With these settings made, the power start-stop function becomes disabled. To use the auto recovery function after power failure while these settings are made, set SW1-5 to ON.

<sup>\*2.</sup> For details, refer to the next section "Demand control".

- \*3. Low-noise mode is valid when Dip SW6-8 on the heat source unit is set to OFF. When DIP SW6-8 is set to ON, 4 levels of on-DEMAND are possible, using different configurations of low-noise mode input and DEMAND input settings. When 2 or more heat source units exist in one refrigerant circuit system, 8 levels of on-DEMAND are possible. When 3 heat source units exist in one refrigerant circuit system, 12 levels of on-DEMAND are possible.
- \*4. By setting Dip SW6-7, the Low-noise mode can be switched between the Capacity priority mode and the Low-noise priority mode.

When SW6-7 is set to ON: The low-noise mode always remains effective.

When SW6-7 is set to OFF: The low noise mode is cancelled when certain operation pressure criteria are met, and the unit goes into normal operation (capacity priority mode).


Low-noise mod is effective.		Capacity priority mode becomes effective.		
Cooling	Cooling Heating		Heating	
63HS1<32kg/cm <sup>2</sup>	63LS>4.6kg/cm <sup>2</sup>	63HS1>35kg/cm <sup>2</sup>	63LS<3.9kg/cm <sup>2</sup>	

\*5. When multiple heat source units exist in one refrigerant circuit system, settings on every heat source unit (signal input) are required.

# **⚠** CAUTION

- 1) Wiring should be covered by insulation tube with supplementary insulation.
- 2) Use relays or switches with IEC or equivalent standard.
- 3) The electric strength between accessible parts and control circuit should have 2750V or more.

#### **Example of wiring connection**



#### (8) Demand control

#### 1) General outline of control

Demand control is performed by using the external signal input to the 1-2 and 1-3 pins of CN3D on the heat source units (OC and OS).

Between 2 and 12 steps of demand control is possible by setting DIP SW6-8 on the heat source units (OC and OS).

#### Table.1

No	Demand control switch	DipS	W6-8	Input to CN3D *2
140	Demand control switch	ОС	os	input to ONOB 2
(a)	2 steps(0-100%)	OFF	OFF	ОС
(b)	4 steps(0-50-75-100%)	ON	OFF	ОС
(c)		OFF	ON	OS
(d)	8 steps(0-25-38-50-63-75-88-100%)	ON	ON	OC and OS

# \*1. Available demand functions

P72-P240TLMU/YLMU models (single-heat source-unit system): 2 and 4 steps shown in the rows (a) and (b) in the table above only.

P144-P360TLMU/YLMU models (two-heat source-unit system OC+OS): 2-8 steps shown in the rows (a), (b), (c), and (d) in the table above only.

\*2. External signal is input to CN3D on the heat source unit whose SW6-8 is set to ON. When SW6-8 is set to OFF on all heat source units, the signal is input to the CN3D on the OC.

Heat source units whose SW6-8 is set to ON are selectable in a single refrigerant system.

- \*3. If wrong sequence of steps are taken, the units may go into the Thermo-OFF (compressor stop) mode.
  - Ex) When switching from 100% to 50%

(Incorrect) 100% to 0% to 50% : The units may go into the Thermo-OFF mode. (Correct) 100% to 75% to 50%

- \*4. The percentage of the demand listed in the table above is an approximate value based on the compressor volume and does not necessarily correspond with the actual capacity.
- \*5. Notes on using demand control in combination with the low-noise mode

To enable the low-noise mode, it is necessary to short-circuit 1-2 pin of CN3D on the heat source unit whose SW6-8 is set to OFF.

When SW6-8 is set to ON on all heat source units, the following operations cannot be performed.

- •Performing 4-step demand in combination with the low-noise operation in a single-heat source-unit system.
- •Performing 8-step demand in combination with the low-noise operation in a two-heat source-unit system.
- \*Performing 12-step demand in combination with the low-noise operation in a three-heat source-unit system.

#### 2) Contact input and control content

#### 2-step demand control

The same control as the Thermo-OFF is performed by closing 1-3 pin of CN3D.

CN3D	
1-3P	
Open	x = 100%
Close	x = 0%

## 4-step demand control (When SW6-8 is set to ON on an heat source unit)

Demand capacity is shown below.

CN3D	1-2P				
1-3P	Open	Close			
Open	100%	75%			
Close	0%	50%			

### 8-step demand control (When SW6-8 is set to ON on two heat source units)

Demand capacity is shown below.

8-step demand		No.2 CN3D						
		1-2P	Open		Short-circuit			
No.1 CN3D	1-2P	1-3P	Open	Short-circuit	Open	Short-circuit		
	Open	Open	100%	50%	88%	75%		
		Short-circuit	50%	0%	38%	25%		
	Short-circuit	Open	88%	38%	75%	63%		
		Short-circuit	75%	25%	63%	50%		

<sup>\*1.</sup> The heat source units whose SW6-8 is set to ON are designated as No. 1 and No. 2 in the order of address from small to large.

# [4] Sample System Connection

Examples of typical system connection are shown on pages [5] to [7]. Refer to the Installation Manual that came with each device or controller for details.

## (1) An example of a system to which an MA remote controller is connected

	System configuration	Connection to the system controller	Address start up for indoor and heat source units	Notes
1	System with one heat source unit	NO	Automatic address setup	
2	System with one heat source unit	NO	Manual address setup	Connection of multiple LOSSNAY units
3	Grouping of units in a system with multiple heat source units	NO	Manual address setup	
4	System with one heat source unit	With connection to transmission line for centralized control	Manual address setup	
5	System with one heat source unit	With connection to indoor-heat source transmission line	Manual address setup	
6	System with one heat source unit	With connection to transmission line for centralized control	Manual address setup	Connection of multiple LOSSNAY units

## (2) An example of a system to which an ME remote controller is connected

	System configuration	Connection to the system controller	Address start up for indoor and heat source units	Notes
1	System with one heat source unit	With connection to transmission line for centralized control	Manual address setup	

# (3) An example of a system to which both MA remote controller and ME remote controller are connected

	System configuration	Connection to the system controller	Address start up for indoor and heat source units	Notes
1	System with one heat source unit	With connection to transmission line for centralized control	Manual address setup	


<sup>\*</sup>MA remote controller and ME remote controller cannot both be connected to the same group.

Ex) When heat source units whose SW6-8 is set to ON are designated as OC and OS, OC = No. 1 and OS = No. 2.

# [5] An Example of a System to which an MA Remote Controller is connected

### 1. System with one heat source unit (automatic address setup for both indoor and heat source units) <PQHY>

#### (1) Sample control wiring



### (2) Cautions

- ME remote controller and MA remote controller cannot both be connected to the same group of indoor units.
- 2) No more than 2 MA remote controllers can be connected to a group of indoor units.
  - When the PAR-CT01MA series, PAR-FS01MA series, PAR-4"x"MA series, or PAR-3"x"MA series ("x" represents 0 or later) is connected to a group, no other MA remote controllers can be connected to the same group.
- A transmission booster is required in a system to which more than 32 indoor units (26 units if one or more indoor units of the 72 model or above is connected) are connected.
- 4) Automatic address setup is not available if start-stop input (CN32, CN51, CN41) is used for a group operation of indoor units. Refer to "[5] 2. An example of a system with one heat source unit to which 2 or more LOSSNAY units are connected (manual address setup for both indoor and heat source units)".(page 34)
- 5) To connect more than 2 LOSSNAY units to indoor units in the same system, refer to the next section "[5] 2. An example of a system with one heat source unit to which 2 or more LOSSNAY units are connected".(page 34)

## (3) Maximum allowable length

- Indoor-heat source transmission line
   Maximum distance (1.25mm² [AWG16] or larger)
   L1 +L2+L3+L4≤200m[656ft]
   L1 +L2+L11+L12+L13≤200m[656ft]
   \*If the power-supply distance exceeds the distance limit of 200 meters, a transmission booster (PAC-SF46EPA-G) is required.
- 2) Transmission line for centralized control
  - No connection is required.
- MA remote controller wiring Maximum overall line length (0.3 to 1.25mm<sup>2</sup> [AWG22 to 16])

m1≤200m [656ft] m2+m3≤200m [656ft]

m4+m5≤200m [656ft] \*1 \*2

- \*1 Max. 70 m [229 ft] for PAR-CT01MA series
- \*2 Max. 150 m [492 ft] for PAR-FS01MA series
- \*When connecting PAR-CT01MA, PAR-FS01MA, PAR-4"x"MA, PAR-3"x"MA ("x" represents 0 or later), use sheathed cables with a minimum thickness of 0.3 mm<sup>2</sup>.

1) Indoor-heat source transmission line

Daisy-chain terminals M1 and M2 on the terminal block for indoor-heat source transmission line (TB3) on the heat source units (OC, OS) (Note 1), and terminals M1 and M2 on the terminal block for indoor-heat source transmission line (TB5) on each indoor unit (IC). (Non-polarized two-wire)

Only use shielded cables.

#### Note

a) The heat source units in the same refrigerant circuit are automatically designated as OC and OS in the order of capacity from large to small (if two or more units have the same capacity, in the order of address from small to large).

#### Shielded cable connection

Daisy-chain the ground terminal (  $//_{7}$ ) on the heat source units (OC, OS), and the S terminal on the terminal block (TB5) on the indoor unit (IC) with the shield wire of the shielded cable.

2) Transmission line for centralized control

No connection is required.

3) MA remote controller wiring

Connect terminals 1 and 2 on the terminal block for MA remote controller line (TB15) on the indoor unit (IC) to the terminal block on the MA remote controller (MA). (Nonpolarized two-wire)

# When 2 remote controllers are connected to the system

When 2 remote controllers are connected to the system, connect terminals 1 and 2 of the terminal block (TB15) on the indoor unit (IC) to the terminal block on the two MA remote controllers.

•Set one of the MA remote controllers to sub. (Refer to the Instruction Manual for the MA remote controller for the setting method.)

#### Group operation of indoor units

To perform a group operation of indoor units (IC), daisychain terminals 1 and 2 on the terminal block (TB15) on all indoor units (IC) in the same group, and then connect terminals 1 and 2 on the terminal block (TB15) on the indoor unit on one end to the terminal block on the MA remote controller. (Non-polarized two-wire)

•When performing a group operation of indoor units that have different functions, "Automatic indoor-heat source address setup" is not available.

#### 4) LOSSNAY connection

Connect terminals M1 and M2 on the terminal block (TB5) on the indoor unit (IC) to the appropriate terminals on the terminal block (TB5) on LOSSNAY (LC). (Non-polarized two-wire)

- Interlock operation setting with all the indoor units in the same system will automatically be made. (It is required that the LOSSNAY unit be turned on before the heat source unit.)
- •Refer to "[5] 2. An example of a system with one heat source unit to which 2 or more LOSSNAY units are connected (manual address setup for both indoor and heat source units)" in the following cases: performing an interlock operation of part of the indoor units in the system with a LOSSNAY unit, using LOSSNAY alone without interlocking it with any units, performing an interlock operation of more than 16 indoor units with a LOSSNAY unit, or connecting two or more LOSSNAY units to indoor units in the same system.
- Switch setting

No address settings required.

## (5) Address setting method

Proce- dures	Unit or controller		Address setting range	Setting method	Notes	Factory setting	
1	Indoor unit	Main unit	IC	No settings re-	-	To perform a group opera-	00
		Sub unit	IC	quired.		tion of indoor units that have different functions, refer to [5] 2.	
2	LOSSNAY		LC	No settings required.	-		00
3	MA remote con- troller	Main remote con- troller	MA	No settings required.	-		Main
		Sub remote con- troller	MA	Sub remote controller	Settings to be made with the Sub/Main switch		
4	Heat source unit (Note)		OC OS	No settings required.	-		00


## Note

The heat source units in the same refrigerant circuit are automatically designated as OC and OS.

The heat source units are designated as OC and OS in the order of capacity from large to small (if two or more units have the same capacity, in the order of address from small to large).

# 2. An example of a system with one heat source unit to which 2 or more LOSSNAY units are connected (manual address setup for both indoor and heat source units) <PQHY>

## (1) Sample control wiring



## (2) Cautions

- ME remote controller and MA remote controller cannot both be connected to the same group of indoor units.
- 2) No more than 2 MA remote controllers can be connected to a group of indoor units.
  - When the PAR-CT01MA series, PAR-FS01MA series, PAR-4"x"MA series, or PAR-3"x"MA series ("x" represents 0 or later) is connected to a group, no other MA remote controllers can be connected to the same group.
- A transmission booster is required in a system to which more than 32 indoor units (26 units if one or more indoor units of the 72 model or above is connected) are connected.

- Indoor-heat source transmission line Same as [5] 1.
- Transmission line for centralized control No connection is required.
- MA remote controller wiring Same as [5] 1.

1) Indoor-heat source transmission line

Same as [5] 1.

Shielded cable connection

Same as [5] 1.

2) Transmission line for centralized control

No connection is required.

3) MA remote controller wiring

Same as [5] 1.

When 2 remote controllers are connected to the system

Same as [5] 1.

Group operation of indoor units

Same as [5] 1.

# (5) Address setting method

# 4) LOSSNAY connection

Connect terminals M1 and M2 on the terminal block (TB5) on the indoor unit (IC) to the appropriate terminals on the terminal block (TB5) on LOSSNAY (LC). (Non-polarized two-wire)

•Interlock setting between the indoor units and LOSSNAY units must be entered on the remote controller. (Refer to "IV [3] Interlock Settings via the MA Remote Controller" or the installation manual for the MA remote controller for the setting method.)

5) Switch setting

Address setting is required as follows.

Proce- dures	Unit o	r controller		Address setting range	Setting method	Notes	Factory setting		
1	1 Indoor unit Main unit		I -				Assign the smallest address to the main unit in the group.	To perform a group opera- tion of indoor units that have different functions,	00
		Sub unit			Assign sequential numbers starting with the address of the main unit in the same group +1. (Main unit address +1, main unit address +2, main unit address +3, etc.)	designate the indoor unit in the group with the great- est number of functions as the main unit.			
2	LOSSNAY		LC	01 to 50	Assign an arbitrary but unique address to each of these units after assigning an address to all indoor units.	None of these addresses may overlap any of the indoor unit addresses.	00		
3	MA remote con- troller	Main remote control- ler	MA	No settings re- quired.	-		Main		
		Sub remote control- ler	MA	Sub remote controller	Settings to be made with the Sub/Main switch				
4			OC OS	51 to 100	Assign sequential address to the heat source units in the same refrigerant circuit. The heat source units are automatically designated as OC and OS. (Note)	To set the address to 100, set the rotary switches to 50.	00		


# Note

The heat source units in the same refrigerant circuit are automatically designated as OC and OS.

The heat source units are designated as OC and OS in the order of capacity from large to small (if two or more units have the same capacity, in the order of address from small to large).

## 3. Group operation of units in a system with multiple heat source units <PQHY>

#### (1) Sample control wiring



# (2) Cautions

- ME remote controller and MA remote controller cannot both be connected to the same group of indoor units.
- 2) No more than 2 MA remote controllers can be connected to a group of indoor units.
  - When the PAR-CT01MA series, PAR-FS01MA series, PAR-4"x"MA series, or PAR-3"x"MA series ("x" represents 0 or later) is connected to a group, no other MA remote controllers can be connected to the same group.
- Do not connect the terminal blocks (TB5) on the indoor units that are connected to different heat source units with each other.
- Replacement of male power jumper connector (CN41) must be performed only on one of the heat source units.
- Provide grounding to S terminal on the terminal block for transmission line for centralized control (TB7) on only one of the heat source units.
- A transmission booster is required in a system to which more than 32 indoor units (26 units if one or more indoor units of the 72 model or above is connected) are connected.
  - •Refer to the DATABOOK for further information about how many booster units are required for a given system.

- Indoor-heat source transmission line Maximum distance (1.25mm² [AWG16] or larger) L11+L12≤200m [656ft] L21+L22≤200m [656ft]
- Transmission line for centralized control L31+L21≤200m [656ft]
- 3) MA remote controller wiring Same as [5] 1.
- 4) Maximum line distance via heat source unit (1.25mm² [AWG16] or larger)
  L12+L31+L22≤500m [1640ft]<sup>\*1</sup>
  L11+L31+L21≤500m [1640ft]<sup>\*1</sup>
  - \*1 When the wiring length exceeds 500 m [1640 ft], consult the sales office.

1) Indoor-heat source transmission line

Same as [5] 1.

Only use shielded cables.

#### Shielded cable connection

Same as [5] 1.

2) Transmission line for centralized control

Daisy-chain terminals M1 and M2 on the terminal block for transmission line for centralized control (TB7) on the heat source units (OC) in different refrigerant circuits and on the OC and OS in the same refrigerant circuit. If a power supply unit is not connected to the transmission line for centralized control, replace the power jumper connector on the control board from CN41 to CN40 on only one of the heat source units.

## Note

- a) The heat source units in the same refrigerant circuit are automatically designated as OC and OS in the order of capacity from large to small (if two or more units have the same capacity, in the order of address from small to large).
- b) If TB7's on the heat source units in the same refrigerant circuit are not daisy-chained, connect the transmission line for the central control system to TB7 of the OC. (Note a).To maintain the central control even during an OC failure or a power failure, connect TB7 on OC and OS together. (If there is a problem with the heat source unit

whose power jumper was moved from CN41 to CN40, central control is not possible, even if TB7's are daisy-chained.)

Only use shielded cables.

#### Shielded cable connection

Daisy-chain the S terminal on the terminal block (TB7) on the heat source units (OC, OS) with the shield wire of the shielded cable. Short-circuit the earth terminal ( $_{r}$ ) and the S terminal on the terminal block (TB7) on the heat source unit whose power jumper connector is mated with CN40.

3) MA remote controller wiring

Same as [5] 1.

When 2 remote controllers are connected to the system

Same as [5] 1.

#### Group operation of indoor units

Same as [5] 1.

4) LOSSNAY connection

Same as [5] 2.

5) Switch setting

Address setting is required as follows.

### (5) Address setting method

Proce- dures	Unit or controller		Address setting range	Setting method	Notes	Factory setting	
1	Indoor unit	Main unit	IC	01 to 50	Assign the smallest address to the main unit in the group.	To perform a group operation of indoor units that have differ-	00
		Sub unit			Assign sequential numbers starting with the address of the main unit in the same group +1. (Main unit address +1, main unit address +2, main unit address +3, etc.)	ent functions, designate the indoor unit in the group with the greatest number of functions as the main unit.	
2	LOSSNAY		LC	01 to 50	Assign an arbitrary but unique address to each of these units after assigning an address to all indoor units.	None of these addresses may overlap any of the indoor unit addresses.	00
3	3 MA main remote controller controller Sub remote controller  4 Heat source unit		MA	No settings required.	-		Main
			MA	Sub remote controller	Settings to be made with the Sub/Main switch		
4			OC OS	51 to 100	Assign sequential address to the heat source units in the same refrigerant circuit. The heat source units are automatically designated as OC and OS. (Note)	To set the address to 100, set the rotary switches to 50.	00


## Note |

The heat source units in the same refrigerant circuit are automatically designated as OC and OS.

The heat source units are designated as OC and OS in the order of capacity from large to small (if two or more units have the same capacity, in the order of address from small to large).

# 4. A system in which a system controller is connected to the transmission line for centralized control and which is powered from a heat source unit <PQHY>

#### (1) Sample control wiring



### (2) Cautions

- ME remote controller and MA remote controller cannot both be connected to the same group of indoor units.
- No more than 2 MA remote controllers can be connected to a group of indoor units.

   No more than 2 MA corries DAD 5501MA sories.

   No more than 2 MA corries DAD 5501MA sories.
  - When the PAR-CT01MA series, PAR-FS01MA series, PAR-4"x"MA series, or PAR-3"x"MA series ("x" represents 0 or later) is connected to a group, no other MA remote controllers can be connected to the same group.
- Do not connect the terminal blocks (TB5) on the indoor units that are connected to different heat source units with each other.
- Replacement of male power jumper connector (CN41) must be performed only on one of the heat source units.
- 5) Short-circuit the shield terminal (S terminal) and the earth terminal ( , , ) on the terminal block for transmission line for centralized control (TB7) on the heat source unit whose power jumper connector is mated with CN40.
- 6) A transmission booster is required in a system to which more than 32 indoor units (26 units if one or more indoor units of the 72 model or above is connected) are connected.
- 7) When a power supply unit is connected to the transmis-

- sion line for centralized control, leave the power jumper connector on CN41 as it is (factory setting).
- •Refer to the DATABOOK for further information about how many booster units are required for a given system.

- 1) Indoor-heat source transmission line Same as [5] 3.
- Transmission line for centralized control L31+L32(L21) ≤200m [656ft]
- 3) MA remote controller wiring
  - Same as [5] 1.
- 4) Maximum line distance via heat source unit
  - $\begin{array}{l} \text{(1.25mm}^2 \, [\text{AWG16}] \, \text{or larger}) \\ \text{L32+L31+L12(L11)} \leq & 500 \text{m} \, [1640 \text{ft}] \,^{*1} \\ \text{L32+L22(L21)} \leq & 500 \text{m} \, [1640 \text{ft}] \,^{*1} \\ \text{L12(L11)+L31+L22(L21)} \leq & 500 \text{m} [1640 \text{ft}] \,^{*1} \end{array}$
  - \*1 When the wiring length exceeds 500 m [1640 ft], consult the sales office.

1) Indoor-heat source transmission line

Same as [5] 1.

Only use shielded cables.

#### Shielded cable connection

Same as [5] 1.

2) Transmission line for centralized control

Daisy-chain terminals A and B on the system controller, terminals M1 and M2 on the terminal block for transmission line for centralized control (TB7) on the heat source units (OC) in different refrigerant circuits and on the heat source units (OC and OS) in the same refrigerant circuit.

If a power supply unit is not connected to the transmission line for centralized control, replace the power jumper connector on the control board from CN41 to CN40 on only one of the heat source units.

If a system controller is connected, set the central control switch (SW5-1) on the control board of all heat source units to "ON."

#### Note

a) The heat source units in the same refrigerant circuit are automatically designated as OC and OS in the order of capacity from large to small (if two or more units have the same capacity, in the order of address from small to large).

b) If TB7's on the heat source units in the same refrigerant circuit are not daisy-chained, connect the transmission line for the central control system to TB7 of the OC. (Note a). To maintain the central control even during an OC failure or a power failure, connect TB7 on OC and OS together. (If there is a problem with the heat source unit whose power jumper

was moved from CN41 to CN40, central control is not possible, even if TB7's are daisychained.)

•Only use shielded cables.

#### Shielded cable connection

Daisy-chain the S terminal on the terminal block (TB7) on the heat source units (OC, OS) with the shield wire of the shielded cable. Short-circuit the earth terminal ( $\frac{1}{17}$ ) and the S terminal on the terminal block (TB7) on the heat source unit whose power jumper connector is mated with CN40.

3) MA remote controller wiring

Same as [5] 1.

# When 2 remote controllers are connected to the system

Same as [5] 1.

#### Group operation of indoor units

Same as [5] 1.

4) LOSSNAY connection

Connect terminals M1 and M2 on the terminal block (TB5) on the indoor unit (IC) to the appropriate terminals on the terminal block for indoor-heat source transmission line (TB5) on LOSSNAY (LC). (Non-polarized 2-core cable)

•Indoor units must be interlocked with the LOSSNAY unit using the system controller. (Refer to the operation manual for the system controller for the setting method.) Interlock setting from the remote controller is required if the ON/OFF remote controller alone or the LM adapter alone is connected.

Switch setting

Address setting is required as follows.

### (5) Address setting method

Proce- dures	Unit or controller		Address setting range	Setting method	Notes	Factory setting	
1	1 Indoor unit Mair		IC	01 to 50	Assign the smallest address to the main unit in the group.	To perform a group operation of indoor units that have different functions,	00
		Sub unit			Assign sequential numbers starting with the address of the main unit in the same group +1. (Main unit address +1, main unit address +2, main unit address +3, etc.)	designate the indoor unit in the group with the greatest number of functions as the main unit.	
2	LOSSNAY		LC	01 to 50	Assign an arbitrary but unique address to each of these units after assigning an address to all indoor units.	None of these addresses may overlap any of the indoor unit addresses.	00
3	MA remote con- troller	Main remote control- ler	MA	No settings re- quired.	-	Enter the same indoor unit group settings on the system controller as the ones that were entered	Main
		Sub remote control- ler	MA	Sub remote con- troller	Settings to be made with the Sub/Main switch	on the MA remote con- troller.	
4	Heat source unit		OC OS	51 to 100	Assign sequential address to the heat source units in the same refrigerant circuit. The heat source units are automatically designated as OC and OS. (Note)	To set the address to 100, set the rotary switches to 50.	00


# Note

The heat source units in the same refrigerant circuit are automatically designated as OC and OS.

The heat source units are designated as OC and OS in the order of capacity from large to small (if two or more units have the same capacity, in the order of address from small to large).

# An example of a system in which a system controller is connected to the indoor-heat source transmission line (except LM adapter) <PQHY>

## (1) Sample control wiring



### (2) Cautions

- ME remote controller and MA remote controller cannot both be connected to the same group of indoor units.
- 2) No more than 2 MA remote controllers can be connected to a group of indoor units.
  - When the PAR-CT01MA series, PAR-FS01MA series, PAR-4"x"MA series, or PAR-3"x"MA series ("x" represents 0 or later) is connected to a group, no other MA remote controllers can be connected to the same group.
- Do not connect the terminal blocks (TB5) on the indoor units that are connected to different heat source units with each other.
- Replacement of male power jumper connector (CN41) must be performed only on one of the heat source units.
- Provide grounding to S terminal on the terminal block for transmission line for centralized control (TB7) on only one of the heat source units.
- A maximum of three system controllers can be connected to the indoor-outdoor transmission line. (AE-200, AG-150A, GB-50ADA, or G(B)-50A are not connectable.)
- When the total number of indoor units exceeds 26, it may not be possible to connect a system controller on the indoor-heat source transmission line.
- 8) In a system to which more than 18 indoor units including one or more indoor units of 72 model or above are connected, there may be cases in which the system control-

ler cannot be connected to the indoor-heat source transmission line.

•Refer to the DATABOOK for further information about how many booster units are required for a given system.

- Indoor-heat source transmission line
   Maximum distance (1.25mm<sup>2</sup> [AWG16] or larger)
   L11+L12≤200m [656ft]
   L21+L22≤200m [656ft]
   L25≤200m [656ft]
- Transmission line for centralized control L31+L21≤200m [656ft]
- 3) MA remote controller wiring Same as [5] 1.
- 4) Maximum line distance via heat source unit (1.25mm² [AWG16] or larger) L25+L31+L12(L11)≤500m [1640ft] \*1 L12(L11)+L31+L22(L21)≤500m [1640ft] \*1 L25+L22(L21)≤500m [1640ft] \*1
  - \*1 When the wiring length exceeds 500 m [1640 ft], consult the sales office.

1) Indoor-heat source transmission line

Daisy-chain terminals M1 and M2 on the terminal block for indoor-heat source transmission line (TB3) on the heat source units (OC, OS) (Note 1), terminals M1 and M2 on the terminal block for indoor-heat source transmission line (TB5) on each indoor unit (IC), and the S terminal on the system controller. (Non-polarized two-wire) •Only use shielded cables.

#### Note

a) The heat source units in the same refrigerant circuit are automatically designated as OC and OS in the order of capacity from large to small (if two or more units have the same capacity, in the order of address from small to large).

#### Shielded cable connection

Daisy-chain the ground terminal (  $\not$ <sub>th</sub>) on the heat source units (OC, OS), the S terminal on the terminal block (TB5) on the indoor unit (IC), and the S terminal on the system controller with the shield wire of the shielded cable

2) Transmission line for centralized control

board of all heat source units to "ON."

Daisy-chain terminals M1 and M2 on the terminal block for transmission line for centralized control (TB7) on the heat source units (OC) in different refrigerant circuits and on the OC and OS in the same refrigerant circuit. If a power supply unit is not connected to the transmission line for centralized control, replace the power jumper connector on the control board from CN41 to CN40 on only one of the heat source units.

Set the central control switch (SW5-1) on the control

#### Note |

o) If TB7's on the heat source units in the same refrigerant circuit are not daisy-chained, connect the transmission

line for the central control system to TB7 of the OC. (Note a). To maintain the central control even during an OC failure or a power failure, connect TB7 on OC and OS together. (If there is a problem with the heat source unit whose power jumper was moved from CN41 to CN40, central control is not possible, even if TB7's are daisy-chained.)

Only use shielded cables.

#### Shielded cable connection

MA remote controller wiring

Same as [5] 1.

# When 2 remote controllers are connected to the system

Same as [5] 1.

## Group operation of indoor units

Same as [5] 1.

4) LOSSNAY connection

Connect terminals M1 and M2 on the terminal block (TB5) on the indoor units (IC) to the appropriate terminals on the terminal block for indoor-heat source transmission line (TB5) on LOSSNAY (LC). (Non-polarized two-wire)

- •Indoor units must be interlocked with the LOSSNAY unit using the system controller. (Refer to the operation manual for the system controller for the setting method.) Interlock setting from the remote controller is required if the ON/OFF remote controller alone is connected.
- Switch setting

Address setting is required as follows.

## (5) Address setting method

Proce- dures	Unit or controller		Unit or controlle		er	Address set- ting range	Setting method	Notes	Factory setting
1	Indoor unit	Main unit	IC	01 to 50	Assign the smallest address to the main unit in the group.	To perform a group operation of indoor units that have	00		
		Sub unit			Assign sequential numbers starting with the address of the main unit in the same group +1. (Main unit address +1, main unit address +2, main unit address +3, etc.)	different functions, designate the indoor unit in the group with the greatest number of functions as the main unit.			
2	LOSSNAY		LC	01 to 50	Assign an arbitrary but unique address to each of these units after assigning an address to all indoor units.	None of these addresses may overlap any of the indoor unit addresses.	00		
3	MA remote control- ler	Main remote controller	MA	No settings re- quired.	-	Enter the same indoor unit group settings on the sys- tem controller as the ones that were entered on the MA	Main		
	iei	Sub remote controller	MA	Sub remote con- troller	Settings to be made with the Sub/Main switch	remote controller.			
4	Heat source unit		OC OS	51 to 100	Assign sequential address to the heat source units in the same refrigerant circuit. The heat source units are automatically designated as OC and OS. (Note)	To set the address to 100, set the rotary switches to 50.	00		


#### Note

The heat source units in the same refrigerant circuit are automatically designated as OC and OS.

The heat source units are designated as OC and OS in the order of capacity from large to small (if two or more units have the same capacity, in the order of address from small to large).

## 6. System with one heat source unit (automatic address setup for both indoor and heat source units) <PQRY>

### (1) Sample control wiring



## (2) Cautions

- ME remote controller and MA remote controller cannot both be connected to the same group of indoor units.
- No more than 2 MA remote controllers can be connected to a group of indoor units.
   When the PAR-CT01MA series, PAR-FS01MA series,

PAR-4"x"MA series, or PAR-3"x"MA series ("x" represents 0 or later) is connected to a group, no other MA remote controllers can be connected to the same group.

 When the number of the connected indoor units is as shown in the table below, one or more transmission boosters (sold separately) are required.

To connect two transmission boosters, connect them in parallel. (Observe the maximum number of connectable indoor units that are listed in the specifications for each heat source unit.)

	Number of tran booster (sold s quired	
	1 unit	2 units
When the P72 and P96 models are not included in the connected indoor units	27 - 50 units	-
When the P72 or P96 model is included in the connected indoor units	21 - 39 units	40 - 50 units

•The table above shows the number of transmission boosters that is required by the system with three BC controllers. For each BC controller that is subtracted from the above-mentioned system, two additional indoor units can be connected.

- 4) Automatic address setup is not available if start-stop input(CN32, CN51, CN41) is used for a group operation of indoor units. Refer to "[5] 7. An example of a system with one heat source unit to which 2 or more LOSSNAY units are connected (manual address setup for both indoor and heat source units)"
- 5) To connect more than 2 LOSSNAY units to indoor units in the same system, refer to the next section "[5] 7. An example of a system with one heat source unit to which 2 or more LOSSNAY units are connected".

# (3) Maximum allowable length

Indoor-heat source transmission line
 Maximum distance (1.25mm<sup>2</sup> [AWG16] or larger)

L1 +L2+L3+L4+L5≤200m[656ft]

L1 +L2+L3+L11+L12+L13≤200m[656ft]

- \*If the power-supply distance exceeds the distance limit of 200 meters, a transmission booster (PAC-SF46EPA-G) is required.
- Transmission line for centralized control

No connection is required.

3) MA remote controller wiring

Maximum overall line length (0.3 to 1.25mm<sup>2</sup> [AWG22 to 16]) m1≤200m [656ft] m2+m3≤200m [656ft]

m2+m3≤200m [656ft] m4+m5≤200m [656ft] \*1 \*1

- \*1 Max. 70 m [229 ft] for PAR-CT01MA series \*2 Max. 150 m [492 ft] for PAR-FS01MA series
- \*When connecting PAR-CT01MA, PAR-FS01MA, PAR-4"x"MA, PAR-3"x"MA ("x" represents 0 or later), use sheathed cables with a minimum thickness of 0.3 mm<sup>2</sup>.

#### 1) Indoor-heat source transmission line

Daisy-chain terminals M1 and M2 of the terminal block for indoor-heat source transmission line (TB3) on the heat source units (OC and OS), of the terminal block for indoor-heat source transmission line (TB02) on the main BC controller (BC), and of the terminal block for indoor-heat source transmission line (TB5) on each indoor unit (IC). (Non-polarized two-wire)

Only use shielded cables.

## Note |

a) The heat source units in the same refrigerant circuit are automatically designated as OC and OS in the order of capacity from large to small (if two or more units have the same capacity, in the order of address from small to large).

#### Shielded cable connection

Daisy-chain the ground terminal (  $//_7$  ) on the heat source units (OC and OS), the S terminal of the terminal block (TB02) on the BC controller (BC), and the S terminal of the terminal block (TB5) on the indoor unit (IC) with the shield of the shielded cable.

2) Transmission line for centralized control

No connection is required.

3) MA remote controller wiring

Connect terminals 1 and 2 on the terminal block for MA remote controller line (TB15) on the indoor unit (IC) to the terminal block on the MA remote controller (MA). (Non-polarized two-wire)

# When 2 remote controllers are connected to the system

When 2 remote controllers are connected to the system, connect terminals 1 and 2 of the terminal block (TB15) on the indoor unit (IC) to the terminal block on the two MA

remote controllers.

Set one of the MA remote controllers as a sub controller.
 (Refer to the Instruction Manual for the MA remote controller for the setting method.)

#### Group operation of indoor units

To perform a group operation of indoor units (IC), daisychain terminals 1 and 2 on the terminal block (TB15) on all indoor units (IC) in the same group, and then connect terminals 1 and 2 on the terminal block (TB15) on the indoor unit on one end to the terminal block on the MA remote controller. (Non-polarized two-wire)

•When performing a group operation of indoor units that have different functions, "Automatic indoor-heat source address setup" is not available.

#### 4) LOSSNAY connection

Connect terminals M1 and M2 on the terminal block(TB5) on the indoor unit (IC) to the appropriate terminals on the terminal block (TB5) on LOSSNAY (LC). (Non-polarized two-wire)

- Interlock operation setting with all the indoor units in the same system will automatically be made. (It is required that the LOSSNAY unit be turned on before the heat source unit.)
- •When performing an interlocked operation of part of the indoor units in the system with a LOSSNAY unit, using a LOSSNAY unit alone without interlocking it with any units, performing an interlock operation of more than 16 indoor units with a LOSSNAY unit, or connecting two or more LOSSNAY units to the same refrigerant system, the automatic address setup function is not available.
- 5) Switch setting

No address settings required.

## (5) Address setting method

Proce- dures	Unit or controller			Address set- ting range	Setting method	Notes	Factory setting
1	Indoor unit	Main unit Sub unit	IC IC	No settings required.	-	Port number setting is required To perform a group operation of indoor units that feature different functions, the automatic IC/OC address setup function is not available.	00
2	LOSSNAY		LC	No settings required.	-		00
3	MA remote con- troller	Main remote con- troller	MA	No settings required.	-		Main
		Sub remote con- troller	MA	Sub remote con- troller	Settings to be made with the Sub/Main switch		
4	Heat source	unit	OC OS	No settings required.	-		00
5	Auxiliary heat source unit	BC controller	ВС	No settings required.	-		00


#### Note

The heat source units in the same refrigerant circuit are automatically designated as OC and OS.

They are designated as OC and OS in the descending order of capacity (ascending order of address if the capacities are the same).

# 7. An example of a system with one heat source unit to which 2 or more LOSSNAY units are connected (manual address setup for both indoor and heat source units) <PQRY>

## (1) Sample control wiring



\* If the BC address overlaps any of the addresses that are assigned to either the OC, OS, or BS, use a different, unused address. OC, OS, and BS addresses (lowest indoor unit address in the group plus +50) have higher priority than the BS address.

# (2) Cautions

- ME remote controller and MA remote controller cannot both be connected to the same group of indoor units.
- No more than 2 MA remote controllers can be connected to a group of indoor units.

When the PAR-CT01MA series, PAR-FS01MA series, PAR-4"x"MA series, or PAR-3"x"MA series ("x" represents 0 or later) is connected to a group, no other MA remote controllers can be connected to the same group.

3) When the number of the connected indoor units is as shown in the table below, one or more transmission boosters (sold separately) are required. To connect two transmission boosters, connect them in parallel. (Observe the maximum number of connectable indoor units that are listed in the specifications for each heat source unit.)

	Number of tra booster (sold a quired	nsmission separately) re-
	1 unit	2 units
When the P72 and P96 models are not included in the connected indoor units	27 - 50 units	-
When the P72 or P96 model is included in the connected indoor units	21 - 39 units	40 - 50 units

- •The left table shows the number of transmission boosters that is required by the system with three BC controllers. For each BC controller that is subtracted from the above-mentioned system, two additional indoor units can be connected.
- •Refer to the DATABOOK for further information about how many booster units are required for a given system.

- Indoor-heat source transmission line Same as [5] 6.
- Transmission line for centralized control No connection is required.
- 3) MA remote controller wiringSame as [5] 6.

1) Indoor-heat source transmission line

Daisy-chain terminals M1 and M2 of the terminal block for indoor-heat source transmission line (TB3) on the heat source units (OC and OS), of the terminal block for indoor-heat source transmission line (TB02) on the main and sub BC controllers (BC and BS), and of the terminal block for indoor-heat source transmission line (TB5) on each indoor unit (IC). (Non-polarized two-wire)

Only use shielded cables.

#### Note

a) The heat source units in the same refrigerant circuit are automatically designated as OC and OS in the order of capacity from large to small (if two or more units have the same capacity, in the order of address from small to large).

#### Shielded cable connection

- Transmission line for centralized control No connection is required.
- 3) MA remote controller wiring

Same as [5] 6.

When 2 remote controllers are connected to the system

Same as [5] 6.

#### Group operation of indoor units

Same as [5] 6.

4) LOSSNAY connection

Connect terminals M1 and M2 on the terminal block (TB5) on the indoor unit (IC) to the appropriate terminals on the terminal block (TB5) on LOSSNAY (LC). (Non-polarized two-wire)

- •Interlock setting between the indoor units and LOSSNAY units must be entered on the remote controller. (Refer to "IV [3] Interlock Settings via the MA Remote Controller" or the installation manual for the MA remote controller for the setting method.)
- Switch setting

Address setting is required as follows.

### (5) Address setting method

Proce- dures	Unit or controller		Address setting range	Setting method	Notes	Fac- tory set- ting	
1	Indoor unit	Main unit	IC	01 to 50	Assign the smallest address to the main unit in the group. In a system with a sub BC controller, make the settings for the indoor units in the following order.  (i) Indoor unit to be connected to the main BC controller  (ii) Indoor unit to be connected to sub BC controller 1  (iii) Indoor unit to be connected to sub BC controller 2  Make the settings for the indoor units in the way that the formula "(i) < (ii) < (iii)" is true.  When using additional BC controllers (3 to 11 BC controllers), make the same settings.	Port number setting is required To perform a group operation of indoor units that feature different functions, designate the indoor unit in the group with the greatest number of functions as the main unit.	00
		Sub unit			Assign sequential numbers starting with the address of the main unit in the same group +1. (Main unit address +1, main unit address +2, main unit address +3, etc.)		
2	LOSSNAY	•	LC	01 to 50	Assign an arbitrary but unique address to each of these units after assigning an address to all indoor units.	None of these addresses may overlap any of the indoor unit addresses.	00
3	MA remote controller	Main remote controller	MA	No set- tings re- quired.	-		Main
		Sub remote controller	MA	Sub remote controller	Settings to be made with the Sub/ Main switch		
4	Heat source unit		OC OS	51 to 100	Assign sequential address to the heat source units in the same refrigerant circuit.      The heat source units are automatically designated as OC and OS.(Note)	To set the address to 100, set the rotary switches to 50. If the addresses that is assigned to the main BC controller overlaps any of the addresses that are assigned.	00
5	Auxiliary heat source unit	BC control- ler (Sub)	BS	51 to 100	Assign an address that equals the sum of the smallest address of the indoor units that are connected to the sub BC controller and 50.	to the heat source units or to the sub BC controller, use a different, unused address within the setting range.  •The use of a sub BC control-	
	Gill	BC control- ler (Main)	ВС		OC (or OS if it exists) +1	ler requires the connection of a main BC controller.	


#### Note

The heat source units in the same refrigerant circuit are automatically designated as OC and OS.

They are designated as OC and OS in the descending order of capacity (ascending order of address if the capacities are the same).

## 8. Group operation of units in a system with multiple heat source units <PQRY>

#### (1) Sample control wiring



## (2) Cautions

- ME remote controller and MA remote controller cannot both be connected to the same group of indoor units.
- No more than 2 MA remote controllers can be connected to a group of indoor units.
  - When the PAR-CT01MA series, PAR-FS01MA series, PAR-4"x"MA series, or PAR-3"x"MA series ("x" represents 0 or later) is connected to a group, no other MA remote controllers can be connected to the same group.
- 3) Do not connect the terminal blocks (TB5) on the indoor units that are connected to different heat source units with each other.
- Replacement of male power jumper connector (CN41) must be performed only on one of the heat source units.
- Provide grounding to S terminal on the terminal block for transmission line for centralized control (TB7) on only one of the heat source units.
- 6) When the number of the connected indoor units is as shown in the table below, one or more transmission boosters (sold separately) are required.
  - To connect two transmission boosters, connect them in parallel. (Observe the maximum number of connectable indoor units that are listed in the specifications for each heat source unit.)

	Number of transmission booster (sold separately) required			
	1 unit	2 units		
When the P72 and P96 models are not included in the connected indoor units	27 - 50 units	-		
When the P72 or P96 model is included in the connected indoor units	21 - 39 units	40 - 50 units		

- •The left table shows the number of transmission boosters that is required by the system with three BC controllers. For each BC controller that is subtracted from the above-mentioned system, two additional indoor units can be connected.
- •Refer to the DATABOOK for further information about how many booster units are required for a given system.

- Indoor-heat source transmission line
   Maximum distance (1.25mm² [AWG16] or larger)
   L11+L12≤200m [656ft]
   L21+L22≤200m [656ft]
- Transmission line for centralized control L31+L21≤200m [656ft]
- MA remote controller wiring
  - Same as [5] 6.
- 4) Maximum line distance via heat source unit (1.25mm² [AWG16] or larger)
  - L12+L31+L22≤500m [1640ft]  $^{*1}$ L11+L31+L21≤500m [1640ft]  $^{*1}$
  - \*1 When the wiring length exceeds 500 m [1640 ft], consult the sales office.

1) Indoor-heat source transmission line

Same as [5] 7.

#### Shielded cable connection

Same as [5] 7.

Transmission line for centralized control

Daisy-chain terminals M1 and M2 on the terminal block for transmission line for centralized control (TB7) on the heat source units (OC) in different refrigerant circuits and on the OC and OS in the same refrigerant circuit. If a power supply unit is not connected to the transmission line for centralized control, replace the power jumper connector on the control board from CN41 to CN40 on only one

of the heat source units.

#### Note

The heat source units in the same refrigerant circuit are automatically designated as OC and OS in the order of capacity from large to small (if two or more units have the same capacity, in the order of address from small to large).

b) If TB7's on the heat source units in the same refrigerant circuit are not daisy-chained, connect the transmission line for the central control system to TB7 of the OC. (Note a). To maintain the central control even during an OC failure or a power failure, connect TB7 on OC and OS together. (If there is a problem with the heat source unit whose power jumper

was moved from CN41 to CN40, central control is not possible, even if TB7's are daisychained.)

Only use shielded cables.

#### Shielded cable connection

Daisy-chain the S terminal on the terminal block (TB7) on the heat source units (OC, OS) with the shield wire of the shielded cable. Short-circuit the earth terminal ( $_{+\!-}$ ) and the S terminal on the terminal block (TB7) on the heat source unit whose power jumper connector is mated with CN40

3) MA remote controller wiring

Same as [5] 6.

When 2 remote controllers are connected to the system

Same as [5] 6.

# Group operation of indoor units

Same as [5] 6.

4) LOSSNAY connection

Same as [5] 7.

Switch setting

Address setting is required as follows.

#### (5) Address setting method

Proce- dures	Unit or controller			Address setting range	Setting method	Notes	Fac- tory set- ting
1	Indoor unit	Main unit	IC	01 to 50	Assign the smallest address to the main unit in the group. In a system with a sub BC controller, make the settings for the indoor units in the following order.  (i) Indoor unit to be connected to the main BC controller  (ii) Indoor unit to be connected to sub BC controller 1  (iii) Indoor unit to be connected to sub BC controller 2  Make the settings for the indoor units in the way that the formula "(i) < (ii) < (iii)" is true.  When using additional BC controllers (3 to 11 BC controllers), make the same settings.  Assign sequential numbers starting with	Port number setting is required     To perform a group operation of indoor units that feature different functions, designate the indoor unit in the group with the greatest number of functions as the main unit.	00
					the address of the main unit in the same group +1. (Main unit address +1, main unit address +2, main unit address +3, etc.)		
2	LOSSNAY	,	LC	01 to 50	Assign an arbitrary but unique address to each of these units after assigning an address to all indoor units.	None of these addresses may overlap any of the indoor unit addresses.	00
3	MA remote controller	Main remote controller	MA	No set- tings re- quired.	-		Main
		Sub remote controller	MA	Sub remote controller	Settings to be made with the Sub/ Main switch		
4	Heat source unit		OC OS	51 to 100	Assign sequential address to the heat source units in the same refrigerant circuit.      The heat source units are automatically designated as OC and OS.(Note)	To set the address to 100, set the rotary switches to 50. If the addresses that is assigned to the main BC controller overlaps any of the addresses that are assigned.	00
5	Auxiliary heat source unit	BC control- ler (Sub)	BS	51 to 100	Assign an address that equals the sum of the smallest address of the indoor units that are connected to the sub BC controller and 50.	to the heat source units or to the sub BC controller, use a different, unused address within the setting range.  The use of a sub BC control-	
		BC control- ler (Main)	ВС		OC (or OS if it exists) +1	ler requires the connection of a main BC controller.	


#### Note

The heat source units in the same refrigerant circuit are automatically designated as OC and OS.

They are designated as OC and OS in the descending order of capacity (ascending order of address if the capacities are the same).

### A system in which a system controller is connected to the transmission line for centralized control and which is powered from a heat source unit <PQRY>

#### (1) Sample control wiring



#### (2) Cautions

- ME remote controller and MA remote controller cannot both be connected to the same group of indoor units.
- No more than 2 MA remote controllers can be connected to a group of indoor units.
  - When the PAR-CT01MA series, PAR-FS01MA series, PAR-4"x"MA series, or PAR-3"x"MA series ("x" represents 0 or later) is connected to a group, no other MA remote controllers can be connected to the same aroup.
- Do not connect the terminal blocks (TB5) on the indoor units that are connected to different heat source units with each other.
- Replacement of male power jumper connector (CN41) must be performed only on one of the heat source units.
- Short-circuit the shield terminal (5 terminal) and the earth terminal ( 17 on the terminal block for transmission line for centralized control (TB7) on the heat source unit whose power jumper connector is mated with CN40.
- When the number of the connected indoor units is as shown in the table below, one or more transmission boosters (sold separately) are required. To connect two transmission boosters, connect them in parallel. (Observe the maximum number of connectable indoor units that are listed in the specifications for each heat source unit.)

	Number of transmission booster (sold separately) required			
	1 unit	2 units		
When the P72 and P96 models are not included in the connected indoor units	27 - 50 units	-		
When the P72 or P96 model is included in the connected indoor units	21 - 39 units	40 - 50 units		

- •The left table shows the number of transmission boosters that is required by the system with three BC controllers. For each BC controller that is subtracted from the above-mentioned system, two additional indoor units can be connected. •Refer to the DATABOOK for further information about how many booster units are required for a given system.
- When a power supply unit is connected to the transmission line for centralized control, leave the power jumper connector on CN41 as it is (factory setting).

- Indoor-heat source transmission line Same as [5] 8.
- Transmission line for centralized control Maximum line distance via heat source unit (1.25 mm<sup>2</sup> [AWG16] min.)
  - L31+L32(L21) ≤200m [656ft]
- 3) MA remote controller wiring Same as [5] 6.
- 4) Maximum line distance via heat source unit (1.25mm² [AWG16] or larger) L32+L31+L12(L11) ≤500m [1640ft] \*1 L32+L22(L21) ≤500m [1640ft] \*1 L12(L11)+L31+L22(L21) ≤500m[1640ft] \*1
  - \*1 When the wiring length exceeds 500 m [1640 ft], consult the sales office.

1) Indoor-heat source transmission line

Same as [5] 7.

Only use shielded cables.

#### Shielded cable connection

Same as [5] 7.

2) Transmission line for centralized control

Daisy-chain terminals A and B on the system controller, terminals M1 and M2 on the terminal block for transmission line for centralized control (TB7) on the heat source units (OC) in different refrigerant circuits and on the heat source units (OC and OS) in the same refrigerant circuit.

If a power supply unit is not connected to the transmission line for centralized control, replace the power jumper connector on the control board from CN41 to CN40 on only one of the heat source units

If a system controller is connected, set the central control switch (SW5-1) on the control board of all heat source units to "ON."

#### Note

a) The heat source units in the same refrigerant circuit are automatically designated as OC and OS in the order of capacity from large to small (if two or more units have the same capacity, in the order of address from small to large.)

the order of address from small to large).

b) If TB7's on the heat source units in the same refrigerant circuit are not daisy-chained, connect the transmission line for the central control system to TB7 of the OC. (Note a).To maintain the central control even during an OC failure or a power failure, connect TB7 on OC and OS together. (If there is a problem with the heat source unit whose power jumper was moved from CN41 to

CN40, central control is not possible, even if TB7's are daisychained.)

Only use shielded cables.

#### Shielded cable connection

Daisy-chain the S terminal of the terminal block (TB7) on the system controller, OC, and OS with the shield of the shielded cable. Short-circuit the earth terminal (  $\frac{1}{12}$ ) and the S terminal on the terminal block (TB7) on the heat source unit whose power jumper connector is mated with CN40.

MA remote controller wiring

Same as [5] 6.

When 2 remote controllers are connected to the system Same as [5] 6.

#### Group operation of indoor units

Same as [5] 6.

#### 4) LOSSNAY connection

Connect terminals M1 and M2 on the terminal block (TB5) on the indoor unit (IC) to the appropriate terminals on the terminal block for indoor-heat source transmission line (TB5) on LOSSNAY (LC). (Non-polarized two-wire)

- •Indoor units must be interlocked with the LOSSNAY unit using the system controller. (Refer to the operation manual for the system controller for the setting method.) Interlock setting from the remote controller is required if the ON/OFF remote controller alone or the LM adapter alone is connected.
- 5) Switch setting

Address setting is required as follows.

#### (5) Address setting method

Proce- dures	Unit or controller			Ad- dress setting range	Setting method	Notes	Fac- tory set- ting
1	Indoor unit	Main unit	IC	01 to 50	Assign the smallest address to the main unit in the group. In a system with a sub BC controller, make the settings for the indoor units in the following order.  (i) Indoor unit to be connected to the main BC controller  (ii) Indoor unit to be connected to sub BC controller 1  (iii) Indoor unit to be connected to sub BC controller 2  Make the settings for the indoor units in the way that the formula "(i) < (ii) < (iii)" is true. When using additional BC controllers (3 to 11 BC controllers), make the same settings.	Port number setting is required  To perform a group operation of indoor units that feature different functions, designate the indoor unit in the group with the greatest number of functions as the main unit.	00
		Sub unit			Assign sequential numbers starting with the address of the main unit in the same group +1. (Main unit address +1, main unit address +2, main unit address +3, etc.)		
2	LOSSNAY	,	LC	01 to 50	Assign an arbitrary but unique address to each of these units after assigning an address to all indoor units.	None of these addresses may overlap any of the indoor unit addresses.	00
3	MA remote controller	Main remote con- troller	MA	No set- tings re- quired.	-	Make the same indoor unit group settings with the system controller as the ones that were made with the MA remote	Main
		Sub remote con- troller	MA	Sub remote controller	Settings to be made with the Sub/ Main switch	controller.	
4	Heat source (Note)	ce unit	OC OS	51 to 100	Assign sequential address to the heat source units in the same refrigerant circuit.     The heat source units are automatically designated as OC and OS.(Note)	To set the address to 100, set the rotary switches to 50. If the addresses that is assigned to the main BC controller overlaps any of the	00
5	Auxiliary heat source	BC control- ler (Sub)	BS	51 to 100	Assign an address that equals the sum of the smallest address of the indoor units that are connected to the sub BC controller and 50.	addresses that are assigned to the heat source units or to the sub BC controller, use a different, unused address	
	unit	BC control- ler (Main)	BC		OC (or OS if it exists) +1	within the setting range.  •The use of a sub BC controller requires the connection of a main BC controller.	


### Note

The heat source units in the same refrigerant circuit are automatically designated as OC and OS.

They are designated as OC and OS in the descending order of capacity (ascending order of address if the capacities are the same).

## 10. An example of a system in which a system controller is connected to the indoor-heat source transmission line (except LM adapter) <PQRY>

#### (1) Sample control wiring



#### (2) Cautions

- ME remote controller and MA remote controller cannot both be connected to the same group of indoor units.
- No more than 2 MA remote controllers can be connected to a group of indoor units
  - When the PAR-CT01MA series, PAR-FS01MA series, PAR-4"x"MA series, or PAR-3"x"MA series ("x" represents 0 or later) is connected to a group, no other MA remote controllers can be connected to the same group.
- Do not connect the terminal blocks (TB5) on the indoor units that are connected to different heat source units with each other.
- Replacement of male power jumper connector (CN41) must be performed only on one of the heat source units.
- Provide grounding to S terminal on the terminal block for transmission line for centralized control (TB7) on only one of the heat source
- A maximum of three system controllers can be connected to the indoor-outdoor transmission line. (AE-200, AG-150A, GB-50ADA, or G(B)-50A are not connectable.)
- When the total number of indoor units exceeds 20 (12 if one or more indoor units of the 72 model or above is connected), it may not be possible to connect a system controller to the indoor-heat source transmission line.
- When the number of the connected indoor units is as shown in the right table, one or more transmission boosters (sold separately) are required.
  - To connect two transmission boosters, connect them in parallel. (Observe the maximum number of connectable indoor units that are listed in the specifications for each heat source unit.)

	Number of transmission booster (sold separately) required		
	1 unit	2 units	
When the P72 and P96 models are not included in the connected indoor units	27 - 50 units	-	
When the P72 or P96 model is included in the connected indoor units	21 - 39 units	40 - 50 units	

- •The table above shows the number of transmission boosters that is required by the system with three BC controllers. For each BC controller that is subtracted from the above-mentioned system, two additional indoor units can be connected.
  •Refer to the DATABOOK for further information about how many
- booster units are required for a given system.

# (3) Maximum allowable length

Indoor-heat source transmission line

Maximum distance (1.25mm<sup>2</sup> [AWG16] or larger) L11+L12≤200m [656ft] L21+L22≤200m [656ft] L25≤200m [656ft]

- Transmission line for centralized control
- L31+L21≤200m [656ft]
- MA remote controller wiring
- Same as [5] 6.
- Maximum line distance via heat source unit (1.25mm² [AWG16] or larger)  $L25+L31+L12(L11) \le 500 \text{m} [1640 \text{ft}]^{*1}$  $L12(L11)+L31+L22(L21) \le 500 \text{m} [1640 \text{ft}]^{*1}$ 
  - \*1 When the wiring length exceeds 500 m [1640 ft], consult the sales

#### 1) Indoor-heat source transmission line

Daisy-chain terminals M1 and M2 of the terminal block for indoor-heat source transmission line (TB3) on the heat source units (OC and OS), of the terminal block for indoor-heat source transmission line (TB02) on the main and sub BC controllers (BC and BS), of the terminal block for indoor-heat source transmission line (TB5) on each indoor unit (IC), and the S terminal of the system controller.(Non-polarized two-wire)

•Only use shielded cables.

#### Note

a) The heat source units in the same refrigerant circuit are automatically designated as OC and OS in the order of capacity from large to small (if two or more units have the same capacity, in the order of address from small to large).

#### Shielded cable connection

Daisy-chain the ground terminal (  $//_{7}$ ) on the heat source units (OC and OS), the S terminal of the terminal block (TB02) on the BC and BS, and the S terminal of the terminal block (TB5) on the indoor unit (IC) with the shield of the shielded cable.

#### Transmission line for centralized control

Daisy-chain terminals M1 and M2 on the terminal block for transmission line for centralized control (TB7) on the heat source units (OC) in different refrigerant circuits and on the OC and OS in the same refrigerant circuit.

If a power supply unit is not connected to the transmission line for centralized control, replace the power jumper connector on the control board from CN41 to CN40 on only one of the heat source units. Set the central control switch (SW5-1) on the control board of all heat source units to "ON."

### Note

b) If TB7's on the heat source units in the same refrigerant circuit are

# (5) Address setting method

not daisy-chained, connect the transmission line for the central control system to TB7 of the OC. (Note a). To maintain the central control even during an OC failure or a power failure, connect TB7 on OC and OS together. (If there is a problem with the heat source unit whose power jumper was moved from CN41 to CN40, central control is not possible, even if TB7's are daisychained.)

Only use shielded cables.

#### Shielded cable connection

Daisy-chain the S terminal on the terminal block (TB7) on the heat source units (OC, OS) with the shield wire of the shielded cable. Short-circuit the earth terminal (  $\frac{1}{r-1}$ ) and the S terminal on the terminal block (TB7) on the heat source unit whose power jumper connector is mated with CN40.

#### MA remote controller wiring

Same as [5] 6.

# When 2 remote controllers are connected to the system Same as [5] 6.

#### Group operation of indoor units

Same as [5] 6.

#### 4) LOSSNAY connection

Connect terminals M1 and M2 on the terminal block (TB5) on the indoor units (IC) to the appropriate terminals on the terminal block for indoor-heat source transmission line (TB5) on LOSSNAY (LC). (Non-polarized two-wire)

•Indoor units must be interlocked with the LOSSNAY unit using the system controller. (Refer to the operation manual for the system controller for the setting method.) Interlock setting from the remote controller is required if the ON/OFF remote controller alone is connected.

#### 5) Switch setting

Address setting is required as follows.

Proce- dures	Unit or controller		Ad- dress setting range	Setting method	Notes	Fac- tory set- ting	
1	Indoor unit	Main unit	IC	01 to 50	Assign the smallest address to the main unit in the group. In a system with a sub BC controller, make the settings for the indoor units in the following order.  (i) Indoor unit to be connected to the main BC controller  (ii) Indoor unit to be connected to sub BC controller 1  (iii) Indoor unit to be connected to sub BC controller 2  Make the settings for the indoor units in the way that the formula "(i) < (ii) < (iii)" is true. When using additional BC controllers (3 to 11 BC controllers), make the same settings.  Assign sequential numbers starting with the address of the projection.	Port number setting is required     To perform a group operation of indoor units that feature different functions, designate the indoor unit in the group with the greatest number of functions as the main unit.	00
					address of the main unit in the same group +1. (Main unit address +1, main unit address +2, main unit address +3, etc.)		
2	LOSSNAY		LC	01 to 50	Assign an arbitrary but unique address to each of these units after assigning an address to all indoor units.	None of these addresses may overlap any of the indoor unit addresses.	00
3	MA remote controller	Main remote con- troller	MA	No set- tings re- quired.	-	Make the same indoor unit group settings with the system controller as the ones that were made with the MA remote	Main
		Sub remote con- troller	MA	Sub remote controller	Settings to be made with the Sub/ Main switch	controller.	
4	Heat source	ce unit	OC OS	51 to 100	Assign sequential address to the heat source units in the same refrigerant circuit. The heat source units are automatically designated as OC and OS.(Note)	To set the address to 100, set the rotary switches to 50. If the addresses that is assigned to the main BC controller overlaps any of the	00
5	Auxiliary heat source	BC control- ler (Sub)	BS	51 to 100	Assign an address that equals the sum of the smallest address of the indoor units that are connected to the sub BC controller and 50.	addresses that are assigned to the heat source units or to the sub BC controller, use a different, unused address	
	unit	BC control- ler (Main)	ВС		OC (or OS if it exists) +1	within the setting range.  The use of a sub BC controller requires the connection of a main BC controller.	


# Note

The heat source units in the same refrigerant circuit are automatically designated as OC and OS.

They are designated as OC and OS in the descending order of capacity (ascending order of address if the capacities are the same).

# 11. A system with multiple BC controller connections (with a system controller connected to the centralized control line) <PQRY>

# (1) Sample control wiring



#### (2) Cautions

- ME remote controller and MA remote controller cannot both be connected to the same group of indoor units.
- No more than 2 MA remote controllers can be connected to a group of indoor units.
  - When the PAR-CT01MA series, PAR-FS01MA series, PAR-4"x"MA series, or PAR-3"x"MA series ("x" represents 0 or later) is connected to a group, no other MA remote controllers can be connected to the same group.
- Do not connect the terminal blocks (TB5) on the indoor units that are connected to different heat source units with each other.
- Replacement of male power jumper connector (CN41) must be performed only on one of the heat source units.
- 5) Short-circuit the S (shield) terminal of the terminal block for the central control unit (TB7) and the ground terminal (,+,) on the heat source unit whose power jumper was moved from CN41 to CN40.
- 6) When the number of the connected indoor units is as shown in the table below, one or more transmission boosters (sold separately) are required.

To connect two transmission boosters, connect them in parallel. (Observe the maximum number of connectable indoor units that are listed in the specifications for each heat source unit.)

	Number of tr booster (sold required	
	1 unit	2 units
When the P72 and P96 models are not included in the connected indoor units	27 - 50 units	-
When the P72 or P96 model is included in the connected indoor units	21 - 39 units	40 - 50 units

- •The table above shows the number of transmission boosters that is required by the system with three BC controllers. For each BC controller that is subtracted from the abovementioned system, two additional indoor units can be connected.
- Refer to the DATABOOK for further information about how many booster units are required for a given system.

 When a power supply unit is connected to the transmission line for centralized control, leave the power jumper connector on CN41 as it is (factory setting).

## (3) Maximum allowable length

- Indoor-heat source transmission line
   Maximum distance (1.25mm² [AWG16] or larger)
   L11+L12≤200m [656ft]
   L21+L22≤200m [656ft]
- Transmission line for centralized control L31+L32(L21) ≤200m [656ft]
- 3) MA remote controller wiring

Maximum overall line length (0.3 to 1.25mm<sup>2</sup> [AWG22 to 16]) m1≤200m [656ft] m2+m3≤200m [656ft]

4) Maximum line distance via heat source unit (1.25mm² [AWG16] or larger)
L32+L31+L12(L11) ≤500m [1640ft] \*1
L32+L22(L21) ≤500m [1640ft] \*1
L12(L11)+L31+L22(L21) ≤500m[1640ft] \*1

\*1 When the wiring length exceeds 500 m [1640 ft], consult the sales office.

Indoor-heat source transmission line

Daisy-chain terminals M1 and M2 of the terminal block for indoorheat source transmission line (TB3) on the heat source units (OC and OS), of the terminal block for indoor-heat source transmission line (TB02) on the main and sub BC controllers (BC and BS), and of the terminal block for indoor-heat source transmission line (TB5) on each indoor unit (IC). (Non-polarized two-wire)

#### Shielded cable connection

#### Note

The heat source units in the same refrigerant circuit are automatically designated as OC and OS in the order of capacity from large to small (if two or more units have the same capacity, in the order of address from small to large).

Daisy-chain the ground terminal ( $\frac{1}{17}$ ) on the heat source units (OC and OS), the S terminal of the terminal block (TB02) on the BC and BS, and the S terminal of the terminal block (TB5) on the indoor unit (IC) with the shield of the shielded cable.

Only use shielded cables.

Transmission line for centralized control

Daisy-chain terminals A and B on the terminal block for transmission line for centralized control (TB7) on the heat source units (OC) in different refrigerant circuits and on the OC and OS (Note) in the same

If a power supply unit is not connected to the transmission line for centralized control, replace the power jumper connector on the control board from CN41 to CN40 on only one of the heat source units. Set the central control switch (SW5-1) on the control board of all heat source units to "ON."

#### Note

If TB7's on the heat source units in the same refrigerant circuit are

not daisy-chained, connect the transmission line for the central control system to TB7 of the OC. (Note a). To maintain the central control even during an OC failure or a power failure, connect TB7 on OC and OS together. (If there is a problem with the heat source unit whose power jumper was moved from CN41 to CN40, central control is not possible, even if TB7's are daisychained.)

Only use shielded cables

#### Shielded cable connection

Daisy-chain the S terminal of the terminal block (TB7) on the system controller, OC, and OS with the shield of the shielded cable. Shortcircuit the earth terminal ( $\frac{1}{100}$ ) and the S terminal on the terminal block (TB7) on the heat source unit whose power jumper connector is mated with CN40.

MA remote controller wiring

Same as [5] 6

When 2 remote controllers are connected to the system Same as [5] 6.

#### Group operation of indoor units

Same as [5] 6. LOSSNAY connection

Connect terminals M1 and M2 on the terminal block (TB5) on the indoor unit (IC) to the appropriate terminals on the terminal block for indoor-heat source transmission line (TB5) on LOSSNAY (LC). (Non-polarized two-wire)

- Indoor units must be interlocked with the LOSSNAY unit using the system controller. (Refer to the operation manual for the system controller for the setting method.) Interlock setting from the remote controller is required if the ON/OFF remote controller alone or the LM adapter alone is connected.
- Switch setting

Address setting is required as follows.

### (5) Address setting method

Pro- ce- dur es	Unit	Unit or controller		Unit or controller		Unit or controller		Address setting range	Setting method	Notes	Fac- tory set- ting
1	1 Indoor Main unit		IC	01 to 50	Assign the smallest address to the main unit in the group. In a system with a sub BC controller, make the settings for the indoor units in the following order.  Indoor unit to be connected to the main BC controller in Indoor unit to be connected to sub BC controller 1 in Indoor unit to be connected to sub BC controller 1 Make the settings for the indoor units in the way that the formula "(i) < (ii) < (iii)" is true.  When using additional BC controllers (3 to 11 BC controllers), make the same settings.	Port number setting is required     To perform a group operation of indoor units that feature different functions, designate the indoor unit in the group with the greatest number of functions as the main unit.	00				
		Sub unit			Assign sequential numbers starting with the address of the main unit in the same group +1. (Main unit address +1, main unit address +2, main unit address +3, etc.)						
2	2 LOSSNAY		LC	01 to 50	Assign an arbitrary but unique address to each of these units after assigning an address to all indoor units.	None of these addresses may overlap any of the indoor unit addresses.	00				
3	MA remote control-	Main re- mote controller		No set- tings re- quired.	-	Make the same indoor unit group settings with the system controller as the ones that were made with the MA remote controller.	Mai n				
	ler	Sub re- mote con- troller	MA	Sub re- mote controller	Settings to be made with the Sub/Main switch						
4	Heat sou	irce unit	oc os	51 to 100	The sum of the smallest address of the indoor units in the same system and 50. Assign sequential address to the heat source units in the same refrigerant circuit. The heat source units are automatically designated as OC and OS.(Note)	•To set the address to 100, set the rotary switches to 50.	00				
5	Auxilia- ry heat source	ry heat controller (Sub)	51 to 100	Assign an address that equals the sum of the smallest address of the indoor units that are connected to the sub BC controller and 50.	To set the address to 100, set the rotary switches to 50.  If the addresses that is assigned to the main BC controller over-	00					
	unit		BC controller (Main)	ВС	51 to 100	OC (or OS if it exists) +1	laps any of the addresses that are assigned to the heat source units or to the sub BC controller, use a different, unused address within the setting range.  The use of a sub BC controller requires the connection of a main BC controller.				

# Note


The heat source units in the same refrigerant circuit are automatically designated as OC and OS.

They are designated as OC and OS in the descending order of capacity (ascending order of address if the capacities are the same).

# [6] An Example of a System to which an ME Remote Controller is connected

## 1. A system in which a system controller is connected to the centralized control transmission line <PQHY>

## (1) Sample control wiring



#### (2) Cautions

- ME remote controller and MA remote controller cannot both be connected to the same group of indoor units.
- No more than 3 ME remote controllers can be connected to a group of indoor units.
- Do not connect the terminal blocks (TB5) on the indoor units that are connected to different heat source units with each other.
- Replace the power jumper connector of the control board from CN41 to CN40 on only one of the heat source units.
- Provide an electrical path to ground for the S terminal on the terminal block for centralized control on only one of the heat source units.
- 6) A transmission booster must be connected to a system in which the total number of connected indoor units exceeds 20.
- A transmission booster is required in a system to which more than 16 indoor including one or more indoor units of the 72 model or above are connected.
  - •Refer to the DATABOOK for further information about how many booster units are required for a given system.
- When a power supply unit is connected to the transmission line for centralized control, leave the power jumper connector on CN41 as it is (factory setting).

#### (3) Maximum allowable length

- Indoor-heat source transmission line Same as [5] 3.
- 2) Transmission line for centralized control Same as [5] 4.
- 3) ME remote controller wiring

Same as [5] 4.

Maximum overall line length (0.3 to 1.25mm<sup>2</sup> [AWG22 to 16]) m1≤10m [32ft] m2+m3≤10m [32ft]

If the standard-supplied cable must be extended, use a cable with a diameter of 1.25mm<sup>2</sup> [AWG16]. The section of the cable that exceeds 10m [32ft] must be included in the maximum indoor-heat source transmission line distance described in 1).

When connected to the terminal block on the Simple remote controller, use cables that meet the following cable size specifications: 0.75 - 1.25 mm<sup>2</sup> [AWG18-14].

 Maximum line distance via heat source unit (1.25mm<sup>2</sup> or larger)

## [II Restrictions]

## (4) Wiring method

1) Indoor-heat source transmission line Same as [5] 1.

Shielded cable connection

Same as [5] 1.

2) Transmission line for centralized control Same as [5] 4.

Shielded cable connection

Same as [5] 4.

3) ME remote controller wiring

ME remote controller is connectable anywhere on the indoor-heat source transmission line.

# When 2 remote controllers are connected to the system

Refer to the section on Switch Setting.

Performing a group operation (including the group operation of units in different refrigerant circuits).

Refer to the section on Switch Setting.

4) LOSSNAY connection

Same as [5] 4.

5) Switch setting

Address setting is required as follows.

# (5) Address setting method


Proce- dures	Unit or controller		Address setting range	Setting method	Notes	Factory setting	
1	Indoor unit	Main unit	IC	01 to 50	Assign the smallest address to the main unit in the group.	To perform a group operation of indoor units that have differ-	00
		Sub unit			Assign sequential numbers starting with the address of the main unit in the same group +1. (Main unit address +1, main unit address +2, main unit address +3, etc.)	ent functions, designate the indoor unit in the group with the greatest number of functions as the main unit.	
2	LOSSNAY	,	LC	01 to 50	Assign an arbitrary but unique address to each of these units after assigning an address to all indoor units.	None of these addresses may overlap any of the indoor unit addresses.	00
3	ME re- mote controller	Main remote controller	RC	101 to 150	Add 100 to the main unit address in the group	•It is not necessary to set the 100s digit. •To set the address	101
		Sub remote controller	RC	151 to 200	Add 150 to the main unit address in the group	to 200, set the rota- ry switches to 00.	
4	Heat source unit		OC OS	51 to 100	Assign sequential address to the heat source units in the same refrigerant circuit. The heat source units are automatically designated as OC and OS. (Note)	To set the address to 100, set the rotary switches to 50.	00

## Note

The heat source units in the same refrigerant circuit are automatically designated as OC and OS.

## 2. A system in which a system controller is connected to the centralized control transmission line <PQRY>

### (1) Sample control wiring



#### (2) Cautions

- ME remote controller and MA remote controller cannot both be connected to the same group of indoor units.
- No more than 3 ME remote controllers can be connected to a group of indoor units.
- Do not connect the terminal blocks (TB5) on the indoor units that are connected to different heat source units with each other.
- Replace the power jumper connector of the control board from CN41 to CN40 on only one of the heat source units.
- Provide an electrical path to ground for the S terminal on the terminal block for centralized control on only one of the heat source units.
- 6) When the number of the connected indoor units is as shown in the table below, one or more transmission boosters (sold separately) are required.

To connect two transmission boosters, connect them in parallel. (Observe the maximum number of connectable indoor units that are listed in the specifications for each heat source unit.)

	Number of transmission booster (sold separately) required				
	1 unit	2 units	3 units		
When the P72 and P96 models are not included in the connected indoor units	15 - 34 units	35 - 50 units	-		
When the P72 or P96 model is included in the connected indoor units	11 - 26 units	27 - 42 units	43 - 50 units		

- •The left table shows the number of transmission boosters that is required by the system with three BC controllers. For each BC controller that is subtracted from the above-mentioned system, two additional indoor units can be connected. •Refer to the DATABOOK for further information about how many booster units are required for a given system.
- When a power supply unit is connected to the transmission line for centralized control, leave the power jumper connector on CN41 as it is (factory setting).

## (3) Maximum allowable length

- Indoor-heat source transmission line Same as [5] 8.
- 2) Transmission line for centralized control Same as [5] 9.
- 3) ME remote controller wiring

Maximum overall line length (0.3 to 1.25mm<sup>2</sup> [AWG22 to 16]) m1≤10m [32ft]

m2+m3≤10m [32ft]

If the standard-supplied cable must be extended, use a cable with a diameter of 1.25mm<sup>2</sup> [AWG16]. The section of the cable that exceeds 10m [32ft] must be included in the maximum indoor-heat source transmission line distance described in 1).

When connected to the terminal block on the Simple remote controller, use cables that meet the following cable size specifications: 0.75 - 1.25 mm<sup>2</sup> [AWG18-16].

 4) Maximum line distance via heat source unit (1.25 mm<sup>2</sup> [AWG16] or large)
 Same as [5] 9.

#### [II Restrictions]

# (4) Wiring method

1) Indoor-heat source transmission line Same as [5] 7.

Shielded cable connection

Same as [5] 6.

2) Transmission line for centralized control Same as [5] 9.

Shielded cable connection

Same as [5] 9.

3) ME remote controller wiring

ME remote controller is connectable anywhere on the indoor-heat source transmission line.

# When 2 remote controllers are connected to the system

Refer to the section on Switch Setting.

Performing a group operation (including the group operation of units in different refrigerant circuits).

Refer to the section on Switch Setting.

4) LOSSNAY connection

Same as [5] 9.

5) Switch setting

Address setting is required as follows.

## (5) Address setting method

Proce- dures	Unit or controller		Ad- dress setting range	Setting method	Notes	Fac- tory set- ting	
1	Indoor unit	Main unit	IC	01 to 50	Assign the smallest address to the main unit in the group. In a system with a sub BC controller, make the settings for the indoor units in the following order.  Indoor unit to be connected to the main BC controller Indoor unit to be connected to sub BC controller Indoor unit to be connected to sub BC controller 2 Make the settings for the indoor units in the way that the formula "(i) < (ii) < (iii)" is true. When using additional BC controllers (3 to 11 BC controllers), make the same settings.	Port number setting is required To perform a group operation of indoor units that have different functions, set the indoor unit in the group with the greatest number of functions as the main unit.	00
		Sub unit			Assign sequential numbers starting with the address of the main unit in the same group +1. (Main unit address +1, main unit address +2, main unit address +3, etc.)		
2	LOSSNAY	,	LC	01 to 50	Assign an arbitrary but unique address to each of these units after assigning an address to all indoor units.	None of these addresses may overlap any of the indoor unit addresses.	00
3	ME remote controller	Main remote con- troller	RC	101 to 150	Add 100 to the main unit address in the group	It is not necessary to set the 100s digit.     To set the address to 200, set the rotary switches to 00.	101
		Sub remote con- troller	RC	151 to 200	Add 150 to the main unit address in the group	octulo lotally ownerloo to oc.	
4	Heat source	ce unit	OC OS	51 to 100	Assign sequential address to the heat source units in the same refrigerant circuit. The heat source units are automatically designated as OC and OS.(Note)	To set the address to 100, set the rotary switches to 50. If the addresses that is assigned to the main BC controller overlaps any of the	00
5	Auxiliary heat source	eat ler (Sub)	51 to 100	Assign an address that equals the sum of the smallest address of the indoor units that are connected to the sub BC controller and 50.	addresses that are assigned to the heat source units or to the sub BC controller, use a different, unused address		
	unit	BC control- ler (Main)	BC		OC (or OS if it exists) +1	within the setting range.  The use of a sub BC controller requires the connection of a main BC controller.	

## Note


The heat source units in the same refrigerant circuit are automatically designated as OC and OS.

They are designated as OC and OS in the descending order of capacity (ascending order of address if the capacities are the same).

# [7] An Example of a System to which both MA Remote Controller and ME Remote Controller are connected

#### 1. PQHY

## (1) Sample control wiring



### (2) Cautions

- 1) Be sure to connect a system controller.
- ME remote controller and MA remote controller cannot both be connected to the same group of indoor units.
- Assign to the indoor units connected to the MA remote controller addresses that are smaller than those of the indoor units that are connected to the ME remote controller.
- No more than 2 ME remote controllers can be connected to a group of indoor units.
- 5) No more than 2 MA remote controllers can be connected to a group of indoor units.
  - When the PAR-CT01MA series, PAR-FS01MA series, PAR-4"x"MA series, or PAR-3"x"MA series ("x" represents 0 or later) is connected to a group, no other MA remote controllers can be connected to the same group.
- 6) Do not connect the terminal blocks (TB5) on the indoor units that are connected to different heat source units with each other.
- Replace the power jumper connector of the control board from CN41 to CN40 on only one of the heat source units.
- 8) Provide an electrical path to ground for the S terminal on the terminal block for centralized control on only one of the heat source units.
- A transmission booster must be connected to a system in which the total number of connected indoor units exceeds 20.
- 10) A transmission booster is required in a system to which

more than 16 indoor including one or more indoor units of the 72 model or above are connected.

- Refer to the DATABOOK for further information about how many booster units are required for a given system.
- 11) When a power supply unit is connected to the transmission line for centralized control, leave the power jumper connector on CN41 as it is (factory setting).

- Indoor-heat source transmission line Same as [5] 3.
- 2) Transmission line for centralized control Same as [5] 4.
- MA remote controller wiring Same as [5] 1.
- 4) ME remote controller wiring Same as [5] 1.
- Maximum line distance via heat source unit (1.25mm<sup>2</sup> or larger) Same as [5] 4.

1) Indoor-heat source transmission line Same as [5] 1.

## Shielded cable connection

Same as [5] 1.

2) Transmission line for centralized control Same as [5] 4.

## Shielded cable connection

Same as [5] 4.

3) MA remote controller wiring

Same as [5] 1.

When 2 remote controllers are connected to the system

Same as [5] 1.

## Group operation of indoor units

Same as [5] 1.

4) ME remote controller wiring

Same as [6] 1.

When 2 remote controllers are connected to the system

Same as [6] 1.

# Group operation of indoor units

Same as [6] 1.

5) LOSSNAY connection

Same as [5] 4.

6) Switch setting

Address setting is required as follows.

# (5) Address setting method


Proce- dures	Unit or controller			Address setting range	Setting method	Notes	Factory setting											
1	Operation with the MA remote control-	In- door unit	Main unit Sub unit	IC	01 to 50	Assign the smallest address to the main unit in the group.  Assign sequential numbers starting with the address of the main unit in the same group +1. (Main unit address +1, main unit address +2, main unit ad-	*Assign an address smaller than that of the indoor unit that is connected to the ME remote controller.     *Enter the same indoor unit group settings on the system controller as the ones that were entered on the MA remote controller.      *To perform a group operation	00										
						dress +3, etc.)	of indoor units that have differ- ent functions, designate the indoor unit in the group with the greatest number of func- tions as the main unit.											
		MA re- mote con-	Main re- mote con- troller	MA	No settings required.	-		Main										
			Sub remote controller	MA	Sub remote controller	Settings to be made with the Sub/Main switch												
2	tion with the ME remote controller	ion door with the ME remote control-	Main unit	IC	01 to 50	Assign the smallest address to the main unit in the group.	*Enter the indoor unit group settings on the system controller (MELANS).     *Assign an address larger than those of the indoor units that	00										
			Sub unit			Assign sequential numbers starting with the address of the main unit in the same group +1. (Main unit address +1, main unit address +2, main unit address +3, etc.)	are connected to the MA remote controller.  •To perform a group operation of indoor units that have different functions, designate the indoor unit in the group with the greatest number of functions as the main unit.											
									İ			ME re- mote con-	Main re- mote con- troller	RC	101 to 150	Add 100 to the main unit address in the group.	•It is not necessary to set the 100s digit. •To set the address to 200, set the rotary switches to	101
		troller	Sub remote controller	RC	151 to 200	Add 150 to the main unit address in the group.	00.											
3	LOSSNAY			LC	01 to 50	Assign an arbitrary but unique address to each of these units after assigning an address to all indoor units.	None of these addresses may overlap any of the indoor unit addresses.	00										
4	Heat source unit				51 to 100	Assign sequential address to the heat source units in the same refrigerant circuit. The heat source units are automatically designated as OC and OS.(Note)	To set the address to 100, set the rotary switches to 50.	00										

# <u>Not</u>e

The heat source units in the same refrigerant circuit are automatically designated as OC and OS.

#### 2. PQRY

## (1) Sample control wiring



#### (2) Cautions

- 1) Be sure to connect a system controller.
- ME remote controller and MA remote controller cannot both be connected to the same group of indoor units.
- Assign to the indoor units connected to the MA remote controller addresses that are smaller than those of the indoor units that are connected to the ME remote controller.
- No more than 2 ME remote controllers can be connected to a group of indoor units.
- No more than 2 MA remote controllers can be connected to a group of indoor units.
  - When the PAR-CT01MA series, PAR-FS01MA series, PAR-4"x"MA series, or PAR-3"x"MA series ("x" represents 0 or later) is connected to a group, no other MA remote controllers can be connected to the same group.
- Do not connect the terminal blocks (TB5) on the indoor units that are connected to different heat source units with each other.
- Replace the power jumper connector of the control board from CN41 to CN40 on only one of the heat source units.
- Provide an electrical path to ground for the S terminal on the terminal block for centralized control on only one of the heat source units.
- 9) When the number of the connected indoor units is as shown in the table below, one or more transmission boosters (sold separately) are required. To connect two transmission boosters, connect them in parallel. (Observe the maximum number of connectable indoor units that are listed in the specifications for each heat source unit.)

	Number of transmission booster (sold separately) required			
	1 unit	2 units	3 units	
When the P72 and P96 models are not included in the connected indoor units	15 - 34 units	35 - 50 units	-	
When the P72 or P96 model is included in the connected indoor units	11 - 26 units	27 - 42 units	43 - 50 units	

- •The left table shows the number of transmission boosters that is required by the system with three BC controllers. For each BC controller that is subtracted from the above-mentioned system, two additional indoor units can be connected.
- •Refer to the DATABOOK for further information about how many booster units are required for a given system.
- When a power supply unit is connected to the transmission line for centralized control, leave the power jumper connector on CN41 as it is (factory setting).

- Indoor-heat source transmission line Same as [5] 8.
- Transmission line for centralized control Same as [5] 9.
- 3) MA remote controller wiring Same as [5] 6.
- 4) ME remote controller wiring Same as [6] 2.
- Maximum line distance via heat source unit (1.25 mm<sup>2</sup> or larger)
   Same as [5] 4.

1) Indoor-heat source transmission line

Same as [5] 7.

# Shielded cable connection

Same as [5] 6.

2) Transmission line for centralized control

Same as [5] 9.

# Shielded cable connection

Same as [5] 9.

3) MA remote controller wiring

When 2 remote controllers are connected to the system

## Group operation of indoor units

Same as [5] 6.

4) ME remote controller wiring

When 2 remote controllers are connected to the system

# Group operation of indoor units

Same as [6] 1.

5) LOSSNAY connection

Same as [5] 9.

6) Switch setting

Address setting is required as follows.

# (5) Address setting method

Pro- ce- dure s	U	nit or coi	ntroller		Ad- dress set- ting range	Setting method	Notes	Facto- ry set- ting
1	Operation with the MA remote controller	In- door unit	Main unit	IC	01 to 50	Assign the smallest address to the main unit in the group. In a system with a sub BC controller, make the settings for the indoor units in the following order.  Indoor unit to be connected to the main BC controller  Indoor unit to be connected to sub BC controller 1  Indoor unit to be connected to sub BC controller 2  Make the settings for the indoor units in the way that the formula "(i) < (ii) < (iii) * (iii) * is true.  When using additional BC controllers (3 to 11 BC controllers), make the same settings.	*Assign an address smaller than that of the indoor unit that is connected to the ME remote controller.     *Enter the same indoor unit group settings on the system controller as the ones that were entered on the MA remote controller.     *To perform a group operation of indoor units that have different functions, designate the indoor unit in the group with the greatest number of functions as the main unit.     *Port number setting is required.	00
			Sub unit	IC	01 to 50	Assign sequential numbers starting with the address of the main unit in the same group +1. (Main unit address +1, main unit address +2, main unit address +3, etc.)		
		MA re- mote	Main re- mote control- ler	MA	No set- tings re- quired.	-		Main
		con- troller	Sub remote control- ler	MA	Sub remote control- ler	Settings to be made with the Sub/Main switch		
2	Opera- tion with the	In- door	Main unit	IC	01 to 50	Assign the smallest address to the main unit in the group.	Assign an address higher than those of the indoor units that are connected to the MA remote controller.	00
	ME re- mote controller	re- ote	Sub unit	IC	01 to 50	Assign sequential numbers starting with the address of the main unit in the same group +1. (Main unit address +1, main unit address +2, main unit address +3, etc.)	Make the initial settings for the indoor unit group settings via the system controller.     To perform a group operation of indoor units that have different functions, designate the indoor unit in the group with the greatest number of functions as the main unit.     Port number setting is required.     Addresses that are assigned to the indoor units that are connected to the sub BC controller should be higher than the addresses that are assigned to the indoor units that are connected to the main BC controller.	
		ME re- mote con-	Main re- mote control- ler	RC	101 to 150	Add 100 to the main unit address in the group.	•It is not necessary to set the 100s digit. •To set the address to 200, set it to 00.	101
		troller	Sub remote control- ler	RC	151 to 200	Add 150 to the main unit address in the group.		
3	LOSSNAY		DSSNAY LO		01 to 50	Assign an arbitrary but unique address to each of these units after assigning an address to all indoor units.	None of these addresses may over- lap any of the indoor unit addresses.	00
4	Heat source unit		OC OS	51 to 100	Assign sequential address to the heat source units in the same refrigerant circuit.     The heat source units are automatically designated as OC and OS.(Note)	To set the address to 100, set it to 50. If the addresses that is assigned to the main BC controller overlaps any of the addresses that are assigned to the heat source units or to the sub BC controller, use a different, unused address within the setting range.	00	
5	Auxiliary heat source unit	BC conti	roller (Sub)	BS	51 to 100	Assign an address that equals the sum of the smallest address of the indoor units that are connected to the sub BC controller and 50.	The use of a sub BC controller requires the connection of a main BC controller.	
	uniit	BC conti (Main)	roller	ВС		OC (or OS if it exists) +1		

## Note


The heat source units in the same refrigerant circuit are automatically designated as OC and OS.

They are designated as OC and OS in the descending order of capacity (ascending order of address if the capacities are the same).

# [8] Restrictions on Pipe Length

# (1) End branching <PQHY>

P72 - P192 models



Unit: m [ft]

	Operation		Pipe sections	Allowable length of pipes
Length	Total pipe length		A+B+C+D +a+b+c+d+e+f	P72-P120 300 [984] or less P144-P192 500 [1640] or less
	Total pipe length (L) from the farthest indoor unit	al pipe length (L) from the heat source unit to farthest indoor unit  A+B+C+c or A+D+f		165 [541] or less (Equivalent length 190 [623] or less)
	Total pipe length from thest indoor unit ( ℓ )	he first branch to the far-	B+C+c or D+f	40 [131] or less*1
Height difference	Between indoor and heat source units	Heat source unit above indoor unit	Н	50 [164] or less
		Heat source unit below indoor unit	H'	40 [131] or less
	Between indoor units	•	h	15 [49] or less

<sup>\*1. 90</sup> m [295 ft] is available. If the piping length exceeds 40 m [131 ft] (but does not exceed 90 m [295 ft]), use onesize larger pipes for all the liquid pipes beyond 40 m [131 ft]. In the figure above, the pipes whose size should be increased by one size are indicated by "C," "b," and "c" when the piping length exceeds 40 m [131 ft] at point C.

# P144 - P360 models

Provide a trap on the pipe (gas pipe only) within 2 m from the Note1 Install the pipe that connects the branch pipe and the heat source units joint pipe if the total length of the pipe that connects the joint in the way that it has a downward inclination toward the branch pipe. pipe and the heat source unit exceeds 2 m. To indoor unit To indoor unit Downward inclination 2m [6ft] Joint pipe Trap (gas pipe only) B To indoor unit To indoor unit Upward inclination 2m [6ft] Max. Joint pipe (Note) Heat source Twinning kit CMY-Y100CBK3: Heat source unit P144 to P240 CMY-Y200CBK2: Heat source unit P288 to P360 To downstream units First branch Indoor Indoor Indoor Indoor Note: "Total capacity of the downstream units" in the 4 3 table is the sum of the model numbers of the units after point E in the figure. h Indoor Indoor Indoor Indoor 5 6 8

Unit: m [ft]

	Operation	Pipe sections	Allowable length of pipes
Length	Between heat source units	A+B	10 [32] or less
	Total pipe length	A+B+C+D+E+F+G+I+J +a+b+c+d+e+f+g+i	500 [1640] or less
	Total pipe length (L) from the heat source unit to the farthest indoor unit	A+C+G+I+J+i	165 [541] or less (Equivalent length 190 [623] or less)
	Total pipe length from the first branch to the farthest indoor unit ( $\uplambda$ )	G+l+J+i	40 [131] or less*1
Height difference Between indoor and heat source units		Н	50 [164] or less (40 [131] or below if heat source unit is be- low indoor unit)
	Between indoor units	h1	15 [49] or less
	Between heat source units	h2	0.1[0.3] or less

<sup>\*1. 90</sup> m [295 ft] is available. If the piping length exceeds 40 m [131 ft] (but does not exceed 90 m [295 ft]), use one-size larger pipes for all the liquid pipes beyond 40 m [131 ft]. In the figure above, the pipes whose size should be increased by one size are indicated by "I," "J,","f","g" and "i" when the piping length exceeds 40 m [131 ft] at point I.

# 1. Refrigerant pipe size <PQHY>

# (1) Diameter of the refrigerant pipe between the heat source unit and the first branch (heat source unit pipe size)

Heat source unit set name	Liquid pipe size (mm) [inch]	Gas pipe size (mm) [inch]
P72 model	ø9.52 [3/8"]	ø19.05 [3/4"]
P96 model	ø9.52 [3/8"] <sup>*1</sup>	ø22.2 [7/8"]
P120 model	ø9.52 [3/8"] <sup>*2</sup>	ø22.2 [7/8"]
P144 model	ø12.7 [1/2"]	ø28.58 [1-1/8"]
P168 - 240 model	ø15.88 [5/8"]	ø28.58 [1-1/8"]
P288 - 312models	ø19.05 [3/4"]	ø34.93 [1-3/8"]
P336 - 360 models	ø19.05 [3/4"]	ø41.28 [1-5/8"]

<sup>\*1.</sup> Use  $\emptyset$ 12.7 [1/2"] pipes if the piping length exceeds 90 m [295 ft].

# (2) Size of the refrigerant pipe between the first branch and the indoor unit (indoor unit pipe size)

Indoor unit model	Pipe diameter (mm) [inch]		
04 - 18 models	Liquid pipe	ø6.35 [1/4"]	
	Gas pipe	ø12.7 [1/2"]	
24 - 54 models	Liquid pipe	ø9.52 [3/8"]	
	Gas pipe	ø15.88 [5/8"]	
72 model	Liquid pipe	ø9.52 [3/8"]	
	Gas pipe	ø19.05 [3/4"]	
96 model	Liquid pipe	ø9.52 [3/8"]	
	Gas pipe	ø22.2 [7/8"]	

# (3) Size of the refrigerant pipe between the branches for connection to indoor units


Total capacity of the downstream units	Liquid pipe size (mm) [inch]	Gas pipe size (mm) [inch]
- P54	ø9.52 [3/8"]	ø15.88 [5/8"]
P55 - P72	ø9.52 [3/8"]	ø19.05 [3/4"]
P73 - P108	ø9.52 [3/8"]	ø22.2 [7/8"]
P109 - P144	ø12.7 [1/2"]	ø28.58 [1-1/8"]
P145 - P240	ø15.88 [5/8"]	ø28.58 [1-1/8"]
P241 - P308	ø19.05 [3/4"]	ø34.93 [1-3/8"]
P309 -	ø19.05 [3/4"]	ø41.28 [1-5/8"]

<sup>\*2.</sup> Use ø12.7 [1/2"] pipes if the piping length exceeds 40 m [131 ft].

# (4) Size of the refrigerant pipe between the distributor and heat source units

Heat source unit model	Composing unit models	Liquid pipe (mm) [inch]	Gas pipe (mm) [inch]
P144	P72	ø9.52 [3/8"]	ø19.05 [3/4"]
	P72		
P168	P96	ø9.52 [3/8"]	ø22.2 [7/8"]
	P72		
P192	P96		
	P96		
P216	P120	ø12.7 [1/2"]	ø22.2 [7/8"]
	P96		
P240	P120		
	P120		
P288	P144	ø12.7 [1/2"]	ø28.58 [1-1/8"]
	P144		
P312	P168	ø15.88 [5/8"]	ø28.58 [1-1/8"]
	P144		
P336	P168		
	P168		
P360	P192		
	P168		

# (1) System that requires 16 BC controller ports or fewer <System with only the main BC controller or standard BC controller> <PQRY>



Unit: m [ft]

	Operation		Pipe sections	Allowable length of pipes
Length	Total pipe length  Total pipe length from the heat source unit to the farthest indoor unit  Between heat source unit and BC controller  Between BC controller and indoor unit		A+B+C+D+E+a+b+c +d+e+f+g+i	Refer to the restrictions on the total piping length in the graph on the next page.
			A+D+E+i	165 [541] or less (Equivalent length 190 [623] or less)
			А	110 [360] or less
			D+E+i	40 [131] or less <sup>*1</sup>
Height difference	Between indoor and heat source	Heat source unit above indoor unit	Н	50 [164] or less
	units	Heat source unit below indoor unit	H'	40 [131] or less
	Between indoor unit and BC controller		h1	15[49](10[32]) or less <sup>*2</sup>
	Between indoor units		h2	30[98](20[65]) or less *2

<sup>\*1.</sup> When the overall pipe length between the BC controller and the farthest indoor unit exceeds 40m [131ft], observe the restrictions in the figure titled "Restrictions on pipe length" below (except the P72, P96 models).

# Note


<sup>\*2.</sup> When the capacity of the connected indoor units is P72 or above, use the figures in the parentheses as a reference.

<sup>1)</sup> Indoor unit sized P72 or P96 should be connected to BC controller via Y shape joint CMY-R160-J1. Set DIP-SW 4-6 to ON of BC controller, in case of connected indoor unit sized P72 or P96 with 2 ports.


<sup>2)</sup> Indoor unit sized P72 or P96 does NOT share BC controller ports with other indoor units.

<sup>3)</sup> Do not connect multiple indoor units to the same port when operating each of them in different mode (cooling, heating, stop, and thermo-off). The indoor units connected to the same port must be set to operate in the same mode. Set them in the same group to make them run/stop in the same mode all together. For other options, enable the thermo setting on the remote controller, or set the common thermostat (optional) to run/stop the units in the same mode based on a representative temperature.


■ Restrictions on pipe length




■ The height difference and the pipe length between BC controller and indoor units




■ Restrictions on pipe length






■ The height difference and the pipe length between BC controller and indoor units



# (2) System that requires more than 16 BC controller ports or with multiple BC controllers <Heat source unit P120 model or below>



HU: Heat source unit, IU: Indoor unit

Unit: m [ft]

	Operation		Operation		Pipe sections	Allowable length of pipes
Length	Total pipe length		A+B+C+D+E+F+G+J+K+a+b+c +d+e+f+g+i+j+k+m+n	Refer to the restrictions on the total piping length in the graph on the next page.		
	Total pipe length from the heat source unit to the farthest indoor unit		A+F+G+J+K+n	165 [541] or less (Equivalent length 190 [623] or less)		
	Between heat source unit and BC controller		А	110 [360] or less		
	Between BC controller and indoor unit		D+E+i	40 [131] or less*1		
Height differ-ence	Between indoor and heat source	Heat source unit above indoor unit	Н	50 [164] or less		
units	Heat source unit below indoor unit	H'	40 [131] or less			
	Between indoor unit and BC controller		h1	15 [49](10[32]) or less*2 *3		
	Between indoor units  Between the BC controller (main or sub) and the sub BC controller		h2	30 [98](20[65]) or less *2		
			h3	15 [49](10[32]) or less *4		

<sup>\*1.</sup> When the overall pipe length between the BC controller and the farthest indoor unit exceeds 40m [131ft], observe the restrictions in the figure titled "Restrictions on pipe length" below (except the P72, P96 models).

<sup>\*2.</sup> When the capacity of the connected indoor units is P72 or above, use the figures in the parentheses as a reference.


<sup>\*3.</sup> Applies to the height differences between indoor units connected to BC controllers (main and sub).

<sup>\*4.</sup> When using 2 or more Sub BC controllers, max. height "h3" should be considered.


#### Note

- 1) A system that requires more than 16 BC controller ports requires two or three BC controllers (main and sub), and three pipes will be used between the main and the sub BC controllers.
- 2) When connecting two sub BC controllers, observe the maximum allowable length in the table above.
- 3) When connecting two sub BC controllers, install them in parallel.
- 4) To connect the P72 or P96 model of indoor units, use an optional junction pipe kit (Model: CMY-R160-J1) and merge the two ports before connecting them.
- 5) Do not connect the P72 or P96 model of indoor units and other models of indoor units at the same port.
- 6) All the units that are connected to the same ports can only be operated in the same operation mode (cooling/heating).
- 7) The maximum capacity of the indoor units that is connectable to the CMB-P-NU-KB1/2 types of sub BC controllers is P126 or below (when two KB1/2 type controllers are connected P126 or below for both combined).


### ■ Restrictions on pipe length




■The height difference and the pipe length between BC controller and indoor units



### ■ Restrictions on pipe length



■The height difference and the pipe length between BC controller and indoor units



### Piping length and height between IU and BC controller





Fig. 2







Fig. 3

- \*1. When the piping length or the vertical separation exceeds the limit specified in Fig. 2, connect a sub BC to the system.
  - The restriction for a system with a sub BC connection is shown in Fig. 3. When a given system configuration falls within the shaded area in Fig. 3, increase the size of the high-pressure pipe and the liquid pipe between the main BC and sub BC by one size. The maximum liquid branch pipe diameter is ø19.05. If a given system already has a ø19.05-pipe between the main BC and sub BC, there is no need to increase the pipe size. When using P12, P15, P18, P36, or P48 model of indoor units, increase the size of the liquid

When using indoor models P54 or larger, the restrictions shown in Fig. 2 cannot be exceeded.

# (3) System that requires more than 16 BC controller ports or with multiple BC controllers <Heat source unit P144 model or above>



HU: Heat source unit, IU: Indoor unit

Unit: m [ft]

	Operation		Pipe sections	Allowable length of pipes
Length	Total pipe length		L+M+A+B+C+D+E+F+G+J+K +a+b+c+d+e+f+g+i+j+k+m+n	Refer to the restrictions on the total piping length in the graph on the next page.
	Total pipe length from the heat source unit to the farthest indoor unit		L(M)+A+F+G+J+K+n	165 [541] or less (Equivalent length 190 [623] or less)
	Between heat sou BC controller	ırce unit and	L(M)+A	110 [360] or less
	Between BC controller and in- door unit		D+E+i	40 [131] or less*1
	Between heat sou	ırce units	L+M or N	5 [16] or less
Height differ-ence	differ-	Heat source unit above indoor unit	Н	50 [164] or less
		Heat source unit below indoor unit	H'	40 [131] or less
	Between indoor unit and BC controller		h1	15 [49](10[32]) or less <sup>*2 *3</sup>
	Between indoor units  Between the BC controller (main or sub) and the sub BC controller  Between heat source units		h2	30 [98](20[65]) or less *2
			h3	15 [49](10[32]) or less *4
			h4	0.1 [0.3] or less


<sup>\*1.</sup> When the overall pipe length between the BC controller and the farthest indoor unit exceeds 40m [131ft], observe the restrictions in the figure titled "Restrictions on pipe length" below (except the P72, P96 models).

- \*2. When the capacity of the connected indoor units is P72 or above, use the figures in the parentheses as a reference.
- \*3. Applies to the height differences between indoor units connected to BC controllers (main and sub).
- \*4. When using 2 or more Sub BC controllers, max. height "h3" should be considered.


#### Note

- 1) A system that requires more than 16 BC controller ports requires two or three BC controllers (main and sub), and three pipes will be used between the main and the sub BC controllers.
- 2) When connecting two sub BC controllers, observe the maximum allowable length in the table above.
- 3) When connecting two sub BC controllers, install them in parallel.
- 4) To connect the P72 or P96 model of indoor units, use an optional junction pipe kit (Model: CMY-R160-J1) and merge the two ports before connecting them.
- 5) Do not connect the P72 or P96 model of indoor units and other models of indoor units at the same port.
- 6) All the units that are connected to the same ports can only be operated in the same operation mode (cooling/heating).
- 7) The maximum capacity of the indoor units that is connectable to the CMB-P-NU-KB1/2 types of sub BC controllers is P126 or below (when two KB1/2 type controllers are connected, P126 or below for both combined).

#### ■ Restrictions on pipe length



■The height difference and the pipe length between BC controller and indoor units



#### Piping length and height between IU and BC controller





Fig. 2






Fig. 3

- \*1. When the piping length or the vertical separation exceeds the limit specified in Fig. 2, connect a sub BC to the system.
  - The restriction for a system with a sub BC connection is shown in Fig. 3. When a given system configuration falls within the shaded area in Fig. 3, increase the size of the high-pressure pipe and the liquid pipe between the main BC and sub BC by one size. The maximum liquid branch pipe diameter is ø19.05. If a given system already has a ø19.05-pipe between the main BC and sub BC, there is no need to increase the pipe size.

When using P12, P15, P18, P36, or P48 model of indoor units, increase the size of the liquid branch pipe between the sub BC and indoor unit by one size.

When using indoor models P54 or larger, the restrictions shown in Fig. 2 cannot be exceeded.

# 2. Refrigerant pipe size <PQRY>

# (1) Between heat source unit and the first twinning pipe (Part A)

Unit: mm [inch]

Heat source unit	Refrigerant pipe size		
rieat source unit	High-pressure pipe	Low-pressure pipe	
P72	ø15.88 [5/8"]	ø19.05 [3/4"]	
P96	ø19.05 [3/4"]	ø22.2 [7/8"]	
P120	Ø 10.00 [0/∓ ]	\$22.2 [170 ]	
P144 - P192	ø22.2[7/8"]	ø28.58 [1-1/8"]	
P216	ø22.2[7/8"] <sup>*1</sup>	\$20.00[1 1/0]	
P240	\$22.2[170 ]	ø34.93 [1-3/8"]	
P288 - P312	ø28.58 [1-1/8"]	\$04.00 [1-0/0 ]	
P336	923.30 [1-1/0]	ø41.28 [1-5/8"]	

<sup>\*1.</sup> When the piping length exceeds 65 meters [213 ft], use Ø28.58 [1-1/8"] pipes for the section of the piping that exceeds 65 meters.

# (2) Between BC controller and indoor unit (Sections a, b, c, d, e, f, g, i, j, k, m, and n)

Unit: mm [inch]

Indoor unit	Refrigera	nt pipe size	Indoor unit connection (Brazed connection for all models)	
	Liquid pipe	Gas pipe	Liquid pipe	Gas pipe
04 - 18 models	ø6.35 [1/4"]	ø12.7 [1/2"]	ø6.35 [1/4"]	ø12.7 [1/2"]
24 - 54 models		ø15.88 [5/8"]		ø15.88 [5/8"]
72 model	ø9.52 [3/8"]	ø19.05 [3/4"]	ø9.52 [3/8"]	ø19.05 [3/4"]
96 model		ø22.2[7/8"]		ø22.2[7/8"]

# (3) Between the main and sub BC controllers (Section F, G, J and K)

Unit: mm [inch]


Indoor unit	Refrigerant pipe size (Brazed connection on all models)			
maoor and	Liquid pipe	High-pressure gas pipe	Low-pressure gas pipe	
- P72	ø9.52 [3/8"]	ø15.88 [5/8"]	ø19.05 [3/4"]	
P73 - P108	99.52 [5/0]	ø19.05 [3/4"]	ø22.2 [7/8"]	
P109 - P126	ø12.7 [1/2"]	19.00 [0/4]	ø28.58 [1-1/8"]	
P127 - P144	912.7 [1/2]	ø22.2 [7/8"]		
P145 - P216	ø15.88 [5/8"]			
P217 - P234				
P235 - P288	ø19.05 [3/4"]	ø28.58 [1-1/8"]	ø34.93 [1-3/8"]	
P289 -	19.03 [5/4]		ø41.28 [1-5/8"]	

Select the proper size pipes for the main unit based on the total capacity of the indoor units that are connected to both sub BC controllers. Select the proper size pipes for the sub controller side based on the total capacity of the indoor units that are connected to the sub controller.

# 3. Connecting the BC controller <PQRY>

# (1) Size of the pipe that fits the standard BC controller ports

P72 - P120 models




The ports of the BC controller accommodates the pipes on P54 model or below of indoor units. To connect other types of indoor units, follow the procedure below.

Unit: mm [inch]

Operation		Pipe se	Pipe sections	
		High-pressure side (liquid)	Low-pressure side (gas)	
Heat source unit side P72		ø15.88 [5/8"] (Brazed connection)	ø19.05 [3/4"] (Brazed connection)	
	P96 P120	ø19.05 [3/4"] (Brazed connection)	ø22.2 [7/8"] (Brazed connection)	
Indoor unit side		ø9.52 [3/8"] (Brazed connection)	ø15.88 [5/8"] (Brazed connection)	

<sup>\*</sup> BC controllers can only be connected to P72 - P120 models of heat source units.

# Note



Be sure to have pipe expansion of indoor unit connecting port by cutting the piping at the cutting point which depends on the indoor unit capacity.

®Cutting point : ø9.52 (Liquid side) or ø15.88 (Gas side)

(Indoor unit model : bigger than P18)

©Cutting point : ø6.35 (Liquid side) or ø12.7 (Gas side)

(Indoor unit model : P18 or smaller)

©Cut the piping at the cutting point

©Have pipe expansion of indoor unit connecting port

**©Field pipe** 


Note:

Remove burr after cutting the piping to prevent entering the piping.

Check that there is no crack at the pipe expansion part.

### Note

2) To connect P72 - P96 models of indoor units (or when the total capacity of indoor units exceeds P55), use a junction pipe kit and merge the two nozzles.



### Note


- 3) To connect multiple indoor units to a port (or to a junction pipe)
  - •Maximum total capacity of connected indoor units: P54 or below (in a system with a junction pipe: P96 or below)
  - •Maximum number of connectable indoor units: 3 units
  - •Branch joint: Use CMY-Y102SS-G2 (optional accessory).
  - •Refrigerant pipe selection (size of the pipes in sections A and B in the figure above): Select the proper size pipes based on the total capacity of the downstream indoor units, using the table below as a reference.

Unit: mm [inch]

Total capacity of indoor units	Liquid pipe	Gas pipe
P54 or below	ø9.52 [3/8"]	ø15.88 [5/8"]
P55 - P72	ø9.52 [3/8"]	ø19.05 [3/4"]
P73 - P96	ø9.52 [3/8"]	ø22.2 [7/8"]

### (2) Size of the pipe that fits the main BC controller ports

P72 - P336 models



The ports of the BC controller accommodates the pipes on P54 model or below of indoor units. To connect other types of indoor units, follow the procedure below.

### Note

- 1) Be sure to have pipe expansion of indoor unit connecting port by cutting the piping at the cutting point which depends on the indoor unit capacity.
- 2) To connect the units between the P72 and P96 models of indoor units (or when the total capacity of indoor units is P31 or above), use a junction pipe kit and merge the two nozzles.
- 3) To connect multiple indoor units to a port (or to a junction pipe)
  - •Maximum total capacity of connected indoor units: P54 or below (in a system with a junction pipe: P96 or below)
  - •Maximum number of connectable indoor units: 3 units
  - \*Branch joint: Use CMY-Y102SS-G2 (optional accessory).
  - •Refrigerant pipe selection (size of the pipes in sections A and B in the figure above): Select the proper based on the total capacity of the downstream indoor units, using the table below as a reference.

Unit: mm [inch]


Total capacity of indoor units	Liquid pipe	Gas pipe
P54 or below	ø9.52 [3/8"]	ø15.88 [5/8"]
P55 - P72	ø9.52 [3/8"]	ø19.05 [3/4"]
P73 - P96	ø9.52 [3/8"]	ø22.2 [7/8"]

Unit: mm [inch]

Model		Pipe se	Pipe sections		
		High pressure side (Liquid)	Low-pressure side (Gas)		
Heat source unit side	P72	ø15.88 [5/8"] (Brazed connection)	ø19.05 [3/4"] (Brazed connection)		
	P96	ø19.05 [3/4"]	ø22.2 [7/8"]		
	P120	(Brazed connection)	(Brazed connection)		
	P144	00.0 5=4011			
	P168	ø22.2 [7/8"] (Brazed connection)	ø28.58 [1-1/8"] (Brazed connection)		
	P192	·			
	P216	ø22.2 [7/8"] *1			
	P240	(Brazed connection)			
	P288		ø34.93 [1-3/8"]		
	P312	ø28.58 [1-1/8"] (Brazed connection)	(Brazed connection)		
	P336	(Diazed connection)	ø41.28 [1-5/8"] (Brazed connection)		
Indoor unit side		ø9.52 [3/8"] (Brazed connection)	ø15.88 [5/8"] (Brazed connection)		

When the piping length exceeds 65 meters [213 ft], use Ø28.58 [1-1/8"] pipes for the section of the piping that exceeds 65 meters.

### (3) Size of the pipe that fits the sub BC controller ports



The ports of the BC controller accommodates the pipes on P54 model or below of indoor units. To connect other types of indoor units, follow the procedure below.

### Note

- 1) Be sure to have pipe expansion of indoor unit connecting port by cutting the piping at the cutting point which depends on the indoor unit capacity.
- 2) To connect the units between the P72 and P96 models of indoor units (or when the total capacity of indoor units is P31 or above), use a junction pipe kit and merge the two nozzles.
- 3) To connect multiple indoor units to a port (or to a junction pipe)
  - •Maximum total capacity of connected indoor units: P54 or below (in a system with a junction pipe: P96 or below)
  - •Maximum number of connectable indoor units: 3 units
  - •Branch joint: Use CMY-Y102SS-G2 (optional accessory).
  - •Refrigerant pipe selection (size of the pipes in sections A and B in the figure above): Select the proper based on the total capacity of the downstream indoor units, using the table below as a reference.

Unit: mm [inch]

Total capacity of indoor units	Liquid pipe	Gas pipe
P54 or below	ø9.52 [3/8"]	ø15.88 [5/8"]
P55 - P72	ø9.52 [3/8"]	ø19.05 [3/4"]
P73 - P96	ø9.52 [3/8"]	ø22.2 [7/8"]

Unit: mm [inch]

Operation		Pipe sections		
	Total capacity of indoor units connected to down-stream BC controller	High-pressure side (gas)	Low-pressure side (gas)	Liquid pipe side
Main BC controller side	- P72	ø15.88 [5/8"] (Brazed connection)	ø19.05 [3/4"] (Brazed connection)	ø9.52 [3/8"] (Brazed connection)
	P73 - P108	ø19.05 [3/4"] (Brazed connection)	(Brazed connection) ø12.7 [1	
	P109 - P126	ø22.2 [7/8"]		ø12.7 [1/2"]
	P127 - P144		ection)   @28.58 [1-1/8"]   ` ection)   (Brazed connection)   @	(Brazed connection)
	P145 - P216	(Brazed connection)		ø15.88 [5/8"]
	P217 - P234			(Brazed connection)
	P235 - P288	ø28.58 [1-1/8"] (Brazed connection)	ø34.93 [1-3/8"] (Brazed connection)	ø19.05 [3/4"]
	P289 -		ø41.28 [1-5/8"] (Brazed connection)	(Brazed connection)


Select the proper size pipes for the main unit based on the total capacity of the indoor units that are connected to both sub BC controllers. Select the proper size pipes for the sub controller side based on the total capacity of the indoor units that are connected to the sub controller.

# **III Heat source Unit Components**


[1]	Heat source Unit Components and Refrigerant Circuit	81
[2]	Control Box of the Heat source Unit	87
[3]	Heat source Unit Circuit Board	89
[4]	BC Controller Components	94
[5]	Control Box of the BC Controller	97
[6]	BC Controller Circuit Board	98

# [1] Heat source Unit Components and Refrigerant Circuit

- 1. Front view of a heat source unit
- (1) PQHY-P72, 96, 120ZLMU-A1/B, PQRY-P72, 96, 120ZLMU-A1/B




# (2) PQHY-P144, 168, 192ZLMU-A1/B, PQRY-P144, 168, 192ZLMU-A1/B




# 2. Refrigerant circuit


# (1) PQHY-P72, 96, 120ZLMU-A1/B




# (2) PQRY-P72, 96, 120ZLMU-A1/B



# (3) PQHY-P144, 168, 192ZLMU-A1/B



# (4) PQRY-P144, 168, 192ZLMU-A1/B




# [2] Control Box of the Heat source Unit

### 1. Control Box

# <HIGH VOLTAGE WARNING>




- · Control box houses high-voltage parts.
- When opening or closing the front panel of the control box, do not let it come into contact with any of the internal components.
- Before inspecting the inside of the control box, turn off the power, keep the unit off for at least 10 minutes, and confirm that the voltage between FT-P and FT-N on INV Board has dropped to DC20V or less. (It takes about 10 minutes to discharge electricity after the power supply is turned off.)




### Note

- Handle the control box carefully. Deformation of the control box bottom may allow water and dust to enter the control box and lead to component damage.
- 2) Faston terminals have a locking function. Make sure the cable heads are securely locked in place. Press the tab on the terminals to remove them.
- 3) Control box houses high temperature parts. Be well careful even after turning off the power source.
- 4) When the power is turned on, the compressor or heater is energized even while the compressor is not operating. Before turning on the power, disconnect all power supply wires from the compressor terminal block, and measure the insulation resistance of the compressor. Check the compressor for a ground fault. If the insulation resistance is below 1 MΩ, connect all power supply wires to the compressor and turn on the power to the heat source unit. The liquid refrigerant in the compressor will evaporate by energizing the compressor or heater.


# 2. Transformer Box






# [3] Heat source Unit Circuit Board

### 1. Heat source unit control board




For information about the display of SW4 function settings, refer to section VII [1] Functions and Factory Settings of the Dipswitches (page 141).

# 2. M-NET board



### 3. INV board




#### Note


- 1) Before inspecting the inside of the control box, turn off the power, keep the unit off for at least 10 minutes, and confirm that the voltage between FT-P and FT-N on INV Board has dropped to DC20V or less.

  (It takes about 10 minutes to discharge electricity after the power supply is turned off.)
- 2) Faston terminals have a locking function. Make sure the cable heads are securely locked in place. Press the tab on the terminals to remove them.
- 3) When the power is turned on, the compressor or heater is energized even while the compressor is not operating. Before turning on the power, disconnect all power supply wires from the compressor terminal block, and measure the insulation resistance of the compressor. Check the compressor for a ground fault. If the insulation resistance is below 1 MΩ, connect all power supply wires to the compressor and turn on the power to the heat source unit. The liquid refrigerant in the compressor will evaporate by energizing the compressor or heater.

# 4. I/O board




# 5. Noise Filter




# [4] BC Controller Components

# 1. CMB-P \cap NU-J1/2, JA1/2, KA1/2


# (1) Front




# (2) Rear view <J1/2 type>



# (3) Rear view <JA1/2 type>




# (4) Rear view <KA1/2 type>




# 2. CMB-P O NU-KB1/2

# (1) Front




# (2) Rear view




# [5] Control Box of the BC Controller


# 1. CMB-P1016V-J1/2, JA1/2, KA1/2




# [6] BC Controller Circuit Board

# 1. BC Board






# 2. Four-Relay Board



# 3. Ten-Relay Board



# **IV Remote Controller**

[1]	Functions and Specifications of MA and ME Remote Controllers	103
[2]	Group Settings and Interlock Settings via the ME Remote Controller	104
[3]	Interlock Settings via the MA Remote Controller	108
[4]	Using the built-in Temperature Sensor on the Remote Controller	109

# [1] Functions and Specifications of MA and ME Remote Controllers

There are two types of remote controllers: ME remote controller, which is connected on the indoor-heat source transmission line, and MA remote controller, which is connected to each indoor unit.

### 1. Comparison of functions and specifications between MA and ME remote controllers

Functions/specifications	MA remote controller*1*2	ME remote controller*2*3
Remote controller address settings	Not required	Required
Indoor-heat source unit address settings	Not required (required only by a system with one heat source unit) 4	Required
Wiring method	Non-polarized 2-core cable  *To perform a group operation, daisy- chain the indoor units using non-polar- ized 2-core cables.	Non-polarized 2-core cable
Remote controller connection	Connectable to any indoor unit in the group	Connectable anywhere on the indoor-heat source transmission line
Interlock with the ventilation unit	Each indoor unit can individually be interlocked with a ventilation unit. (Set up via remote controller in the group.)	Each indoor unit can individually be interlocked with a ventilation unit. (Set up via remote controller.)
Changes to be made upon grouping change	MA remote controller wiring between indoor units requires rewiring.	Either the indoor unit address and remote controller address must both be changed, or the registration information must be changed via MELANS.

<sup>\*1.</sup> MA remote controller refers to MA remote controller (PAR-CT01MA series, PAR-FS01MA series, PAR-4"x"MA series, or PAR-3"x"MA series ("x" represents 0 or later)), MA simple remote controller, and wireless remote controller.

#### 2. Remote controller selection criteria

MA remote controller and ME remote controller have different functions and characteristics. Choose the one that better suits the requirements of a given system. Use the following criteria as a reference.


MA remote controller*1*2	ME remote controller*1*2
<ul> <li>There is little likelihood of system expansion and grouping changes.</li> <li>Grouping (floor plan) has been set at the time of installation.</li> </ul>	<ul> <li>There is a likelihood of centralized installation of remote controllers, system expansion, and grouping changes.</li> <li>Grouping (floor plan) has not been set at the time of installation.</li> <li>To connect the remote controller directly to the OA processing unit.</li> </ul>

<sup>\*1.</sup> ME remote controller and MA remote controller cannot both be connected to the same group of indoor units.

\*2. A system controller must be connected to a system to which both MA remote controller and ME remote controller are connected.

<System with MA remote controller>

<System with ME remote controllers>



<sup>\*2.</sup> Either the MA remote controller or the ME remote controller can be connected when a group operation of units in a system with multiple heat source units is conducted or when a system controller is connected.

<sup>\*3.</sup> ME remote controller refers to ME remote controller and ME simple remote controller.

<sup>\*4.</sup> Depending on the system configuration, some systems with one heat source unit may require address settings.

# [2] Group Settings and Interlock Settings via the ME Remote Controller

#### 1. Group settings/interlock settings

Make the following settings to perform a group operation of units that are connected to different heat source units or to manually set up the indoor/heat source unit address

(A) Group settings......Registration of the indoor units to be controlled with the remote controller,

and search and deletion of registered information.


(B) Interlock settings.... ..Registration of LOSSNAY units to be interlocked with the indoor units, and search and deletion of registered information

#### [Operation Procedures]

#### (1) Address settings

Register the indoor unit to be controlled with the remote controller.

DBring up either one of the following displays on the remote controller: The blinking display of "HO," which appears when the power is turned on, or the normal display, which appears when the unit is stopped. The display window must look like one of the two figures below to proceed to the next step.





#### 2)Bring up the "Group Setting" window.

-Press and hold buttons (A [FILTER] and (B)[LOUVER] simultaneously for 2 seconds to bring up the display as




#### 3Select the unit address.

- Select the address of the indoor unit to be registered by pressing button  $\hbox{$\bar{\mathbb{C}}$}$  [SET TEMP. (  $\bigtriangledown$  ) or (  $\bigtriangleup$  )] to advance or go back through the addresses.

# 4 Register the indoor unit whose address appears on the

- Press button (D) [TEST] to register the indoor unit address whose address appears on the display.
- If registration is successfully completed, unit type will appear on the display as shown in the figure below.
- If the selected address does not have a corresponding indoor unit, an error message will appear on the display. Check the address, and try again.

<Successful completion of registration>



<Deletion error>



"88" blinks to indicate a registration error. (Indicates that selected address does not have a corresponding unit.)

#### 5 To register the addresses for multiple indoor units, repeat steps 3 and 4 above.






#### 6 Bring up the "Interlock Setting" window.

(C)

(G)

-Press button @[MODE] to bring up the following display. Press again to go back to the "Group Setting" window as shown under step (2)




#### 7 Bring up the address of the indoor unit and the address of the LOSSNAY to be interlocked on the display.

- Select the address of the indoor unit to be registered by pressing button  $\bigcirc$  [SET TEMP.  $(\bigtriangledown)$  or  $(\triangle)$ ] to advance or go back through the addresses.
- Select the address of the LOSSNAY unit to be interlocked by pressing button  $\textcircled{\sc H}[\sc TIMER\ SET\ (\bigtriangledown)\ or\ (\triangle)]$  to advance or go back through the "interlocked unit addresses."



# 8 Make the settings to interlock LOSSNAY units with indoor

- Press button D [TEST] while both the indoor unit address and the address of the LOSSNAY units to be interlocked are displayed to enter the interlock setting.
- Interlock setting can also be made by bringing up the LOSSNAY address in the indoor unit address display window and the indoor unit address in the interlocked unit address display window.



If registration is successfully completed, the two displays as shown on the left will appear alternately. If the registration fails, "88"

will blink on the display. (Indicates that the selected address does not have a corresponding unit.)

NOTE: Interlock all the indoor units in the group with the LOSSNAY units; otherwise, the LOSSNAY units will not operate.



#### (C) To return to the normal display

When all the group settings and interlock settings are made, take the following step to go back to the normal display.

(I) Press and hold buttons (A) [FILTER] and (B) [LOUVER] simultaneously for 2 seconds to go back to the window as shown in step 1.

## (2) Address search

To search for the address of indoor units that have been entered into the remote controller, follow steps 1 and 2.




#### (A) To search group settings

#### 11 Bring up the "Group Setting" window.

- Each pressing of button (E) [TIMER] will bring up the address of a registered indoor unit and its unit type on the display.

<Entry found>



<No entries found>



- When only one unit address is registered, the same address will remain on the display regardless of how many times the button is pressed.
- When the address of multiple units are registered (i.e. "011," "012," "013"), they will be displayed one at a time in an ascending order with each pressing of button (E) [TIMER].





To delete an address, go to section (3)"Address deletion."

To go back to the normal display, follow step (10)



#### Repeat steps and in the previous page to interlock all the indoor units in a group with the LOSSNAY unit.



To go back to the normal display, To search for an address, follow step (10)

go to section (2) "Address Search."

#### (B) Interlock setting search

After performing step (6), proceed as follows:

#### ② Bring up the address of the indoor unit to be searched on the display.


 Select the address of the indoor unit to be searched by pressing button  $\bigoplus$  [TIMER SET  $(\nabla)$  or  $(\triangle)$ ] to advance or go back through the interlocked addresses.



LOSSNAY can be searched in the same manner by bringing up the LOSSNAY address in the Interlocked unit address display window.

#### (3) Bring up on the display the address of the LOSSNAY unit that was interlocked with the indoor unit in step 12.


- With each pressing of button (E) [TIMER], the address of the LOSSNAY and indoor unit that is interlocked with it will be displayed alternately.



#### Bring up the address of another registered unit on the display.

- After completing step ③, a subsequent pressing of button [TIMER] will bring up the address of another registered

(The display method is the same as the one in step (13).)



To delete an address go to section (3) "Address deletion "

# (3) Address deletion


The addresses of the indoor units that have been entered into the remote controller can be deleted by deleting the group settings.

The interlock settings between units can be deleted by deleting the interlock settings.

Follow the steps in section (2) "Address Search" to find the address to be deleted and perform deletion with the address being displayed in the display window. To delete an address, the address must first be bought up on the display.

### Delete the registered indoor unit address or the interlock setting between units.

- Press button € [CLOCK→ ON→ OFF] twice while either the indoor unit address or the address of the interlocked unit is displayed on the display to delete the interlock setting.



#### (4) Making (A) Group settings and (B) Interlock settings of a group from any arbitrary remote controller

- (A) Group settings and (B) Interlock settings of a group can be made from any arbitrary remote controller. Refer to "(B) Interlock Settings" under section 1 "Group Settings/Interlock Settings" for operation procedures. Set the address as shown below.
- (A) To make group settings

Interlocked unit address display window...Remote controller address

Indoor unit address display window.......The address of the indoor unit to be controlled with the remote controller

(B) To make interlock settings

Interlocked unit address display window...LOSSNAY address

Indoor unit address display window......The address of the indoor unit to be interlocked with the LOSSNAY

#### 2. Remote controller function selection via the ME remote controller

In the remote controller function selection mode, the settings for three types of functions can be made or changed as necessary.

- 1) Operation mode display selection mode (<u>Display or non-display of COOL/HEAT during automatic operation mode</u>)
  When the automatic operation mode is selected, the indoor unit will automatically perform a cooling or heating operation based on the room temperature. In this case, "AUTO COOL" or "AUTO HEAT" will appear on the remote controller display.

  This setting can be changed so that only "AUTO" will appear on the display.
- 2) Room temperature display selection mode (<u>Display or non-display of room temperature</u>)
  Although the suction temperature is normally displayed on the remote controller, the setting can be changed so that it will not appear on the remote controller.
- 3) Narrowed preset temperature range mode


The default temperature ranges are 67°F to 87°F in the cooling/dry mode and 63°F to 83°F in the heating mode.

By changing these ranges (raising the lower limit for the cooling/dry mode and lowering the upper limit for the heating mode), energy can be saved.

\*The settable range varies depending on the unit to be connected.



On the PAR-F27MEA-US model, automatic operation mode cannot be selected while the unit is in the narrowed preset temperature range mode. Only the lower limit can be set for cooling/dry mode, and upper limit for heating mode.




[Operation Procedures]

- 1. Press the [ON/OFF] button on the remote controller to bring the unit to a stop. The display will appear as shown in the previous page (Normal display).
- 2. Press buttons ① [CHECK] and [MODE] simultaneously for 2 seconds to go into the "operation mode display selection mode" under the remote controller function selection mode. Press button (2) [SET TEMP. (7)] or (3) [SET TEMP. (7)] to go into the other three modes under the remote controller function selection mode.

#### Operation mode display selection mode (Display or non-display of room temperature on the remote controller.)

• "AUTO" "COOL/HEAT "will blink, and either "ON" or "OFF" will light up. Press button ⊕ITIMER SET (∧) or (▽) in this state to switch between "ON" and "OFF.








- When it is set to "ON," "AUTO" and "COOL" or "AUTO" and "HEAT" will appear on the display during automatic operation mode.
- When it is set to "OFF," only "AUTO "will appear on the display during automatic operation mode.

#### Room temperature display selection mode (Display or non-display of room temperature)

• "88°F" will blink in the room temperature display window, and either "ON "or "OFF" will light up. Press button ④ [TIMER SET (△) or (▽)] in this state to switch between "ON" and "OFF.







- When it is set to "ON," the room temperature will stay in the operation display window during operation.
  When it is set to "OFF," the room temperature will not appear in the operation display window during operation.

#### Narrowed preset temperature range mode (The range of preset temperature can be changed.)

1) Temperature range setting for the cooling/dry mode

"COOL/DRY" and "LIMIT TEMP." will light up in the display window, and the temperature range for the cooling/dry mode will appear on the display. The lower limit temperature will be blinking in the preset temperature display window. While it is blinking, the temperature setting can be changed. [Selection range for the lower limit temperature] : 67°F  $\iff$  87°F (Medium temperature range indoor unit 57°F  $\iff$  87°F) (The upper limit temperature is fixed at 87°F. Only the lower limit temperature is changeable.)



[When the temperature range for the cooling or dry mode is set to 67°F to 87°F]

2) Press button 4 [TIMER SET  $\textcircled{\triangle}$ ) or  $\textcircled{\nabla}$ ] to set the lower limit temperature to the desired temperature.



[When the temperature range is changed to 75°F - 87°F]

3) After completing the step above, press button ② [SET TEMP. (▽)] to go into the temperature range setting mode to set the temperature range for the heating operation.

"HEAT" and "LIMIT TEMP" will light up, and the temperature range for the heating mode will appear on the screen. The upper limit temperature can be changed with button 4 [TIMER SET  $(\triangle)$  or  $(\nabla)$ ]. [Selection range for the upper limit temperature] : 63° F ⇔ 83° F (Medium temperature range indoor unit 63° F ⇔ 83° F) (The lower limit temperature is fixed at 63°F. Only the upper limit temperature is changeable.)

3. When all the necessary settings have been made, exit the remote controller function selection mode and go back to the Normal display by pressing and holding buttons (1) [CHECK] and [MODE] simultaneously for 2 seconds.

# [3] Interlock Settings via the MA Remote Controller

### 1. LOSSNAY interlock setting (Make this setting only when necessary.)

\* When the upper controller is connected, make the setting using the upper controller.

NOTE: When using LOSSNAY units in conjunction, interlock the addresses of all indoor units within the group and address of LOSSNAY units.

Perform this operation to enter the interlock setting between the LOSSNAY and the indoor units to which the remote controller is connected, or to search and delete registered information.

In the following example, the address of the indoor unit is 05 and the address of the LOSSNAY unit is 30.

#### [Operation Procedures]

1) Press the ①[ON/OFF] button on the remote controller to bring the unit to a stop.

The display window on the remote controller must look like the figure below to proceed to step (2).




2) Press and hold the [FILTER] and [ ====] buttons simultaneously for two seconds to perform a search for the LOSSNAY that is interlocked with the indoor unit to which the remote controller is connected.



(3) Search result

- The indoor unit address and the interlocked LOSSNAY address will appear alternately.



<Indoor unit address and indoor unit>

- Without interlocked LOSSNAY settings



(4) If no settings are necessary, exit the window by pressing and holding the [FILTER] and [ -====] buttons simultaneously for 2 seconds. Go to step 1. Registration Procedures to make the interlock settings with LOSSNAY units, or go to step 2. Search Procedures to search for a particular LOSSNAY unit.

Go to step 3. Deletion Procedures to delete any LOSSNAY settings.

#### < 1. Registration Procedures >


- ⑤ To interlock an indoor unit with a LOSSNAY unit, press the [ ∰TEMP. (▽) or (△)] button on the remote controller that is connected to the indoor unit, and select its address (01 to 50).
- 6 Press the [OCLOCK (riangle) or (riangle)] button to select the address of the LOSSNAY to be interlocked (01 to 50).



Indoor unit address LOSSNAY address


- Press the [TEST] button to register the address of the selected indoor unit and the interlocked LOSSNAY unit.
  - Registration completed

The registered indoor unit address and "IC," and the interlocked LOSSNAY address and "LC" will appear alternately.



- Registration error

If the registration fails, the indoor unit address and the LOSSNAY address will be displayed alternately.



Registration cannot be completed: The selected unit address does not have a corresponding indoor unit or a LOSSNAY unit. Registration cannot be completed: Another LOSSNAY has already been interlocked with the selected indoor unit.

#### < 2. Search Procedures >


(3) To search for the LOSSNAY unit that is interlocked with a particular indoor unit, enter the address of the indoor unit into the remote controller that is connected to it.



<Indoor unit address>

- - Search completed (With a LOSSNAY connection)

The indoor unit address and "IC," and the interlocked LOSSNAY address and "LC" will appear alternately.



- Search completed (No interlocked settings with a LOSSNAY exist.)




- The selected address does not have a corresponding indoor unit.




#### < 3. Deletion Procedures >

Take the following steps to delete the interlock setting between a LOSSNAY unit and the interlocked indoor unit from the remote controller that is connected to the indoor unit.




- ①Press the [② ON/OFF] button twice to delete the address of the LOSSNAY unit that is interlocked with the selected indoor unit.
  - Registration completed

The indoor unit address and "--," and the interlocked LOSSNAY address and "--" will appear alternately.



-Deletion error



### [4] Using the built-in Temperature Sensor on the Remote Controller

1. Selecting the position of temperature detection (Factory setting: SW1-1 on the controller board on the indoor unit is set to OFF.)

To use the built-in sensor on the remote controller, set the SW1-1 on the controller board on the indoor unit to ON.


- •Some models of remote controllers are not equipped with a built-in temperature sensor. Use the built-in temperature sensor on the indoor unit instead.
- •When using the built-in sensor on the remote controller, install the remote controller where room temperature can be detected.

# V Electrical Wiring Diagram


[1]	Electrical Wiring Diagram of the Heat source Unit	113
[2]	Electrical Wiring Diagram of the BC Controller	115
[3]	Electrical Wiring Diagram of Transmission Booster	124

# [1] Electrical Wiring Diagram of the Heat source Unit

# (1) PQHY-P72, 96, 120, 144ZLMU-A1




# (2) PQHY-P72, 96, 120, 144ZLMU-B



# [2] Electrical Wiring Diagram of the BC Controller


# (1) CMB-P104NU-J1/2 model




Note 1. TB02 is transmission terminal block.

te 1. TB02 is transmission terminal blo Never connect power line to it. 2. The initial set values of switch on CONT. B are as follows. SW1:0


SW2:0




# (2) CMB-P106NU-J1/2 model



# (3) CMB-P108NU-J1/2 model



### (4) CMB-P1012, P1016NU-J1/2 models




Note 1. TB02 is transmission terminal block.

Never connect power line to it.

2. The initial set values of switch on CONT. B are as follows. SW1:0
SW2:0

# (5) CMB-P108NU-JA1/2 model



Note 1. TB02 is transmission terminal block.


Never connect power line to it.

2. The initial set values of switch on CONT. B are as follows.

SW1:0

SW2:0

# (6) CMB-P1012, P1016NU-JA1/2 models




Note 1. TB02 is transmission terminal block.

Never connect power line to it.

2. The initial set values of switch on CONT. B are as follows.

### (7) CMB-P1016NU-KA1/2 model




Never connect power line to it.


The initial set values of switch on CONT. B are as follows. SW1:0 ۲,

SW2:0


# (8) CMB-P104NU-KB1/2 model



# (9) CMB-P108NU-KB1/2 model



# [3] Electrical Wiring Diagram of Transmission Booster




# **VI Refrigerant Circuit**


[1]	Refrigerant Circuit Diagram	127
[2]	Principal Parts and Functions	131

# [1] Refrigerant Circuit Diagram


- 1. Heat source unit
- (1) PQHY-P72, P96, P120 models




### (2) PQRY-P72, P96, P120 models



# (3) PQHY-P144, P168, P192 models




# (4) PQRY-P144, P168, P192 models




# 2. BC controller


# (1) CMB-P104, 106, 108, 1012, P1016NU-J1/2




# (2) CMB-P108, 1012, P1016NU-JA1/2 (main)



# (3) CMB-P1016NU-KA1/2 (main)



# (4) CMB-P104, 108NU-KB1/2 (sub)



# [2] Principal Parts and Functions

# 1. Heat source unit

Part name	Symbols (functions)	Notes	Usage	Specifications	Check method
Com- pressor	MC1 (Comp1)		Adjusts the amount of circulating refrigerant by adjusting the operating frequency based on the operating pressure data	Low-pressure shell scroll compressor Wirewound resistance 20°C[68°F]: 0.71ohm (P72,P96,P120 models) 0.30ohm (P144,P168,P192 models)	
High pres- sure sensor	63HS1		Detects high pressure     Regulates frequency and provides high-pressure protection	Connector   Pressure   0~4.15 MPa [601psi]   Vout 0.5~3.5V   12.3   0.071/0.098 MPa [14psi]   Pressure [MPa]   = 1.38 x Vout [V]-0.69   Pressure [psi]   = (1.38 x Vout [V] - 0.69) x 145   GND (Black)   Vout (White)   Voc (DC5V) (Red)   Voc (DC5V) (Red)   Voc (DC5V) (Red)   Voc (DC5V)   Vo	
Low pres- sure sensor	63LS		Detects low pressure     Provides low-pressure protection	Con-   nector   Pressure   0-1.7 MPa [247psi]   vout 0.5~3.5V   0.173V/0.098 MPa [14psi]   Pressure   MPa   0.566 x Vout   V  - 0.283   Pressure   psi   = (0.566 x Vout   V  - 0.283 x 145   1   GND (Black)   Vout (White)   Vcc (DC5V) (Red)   GND (Red)   Conditions   Condition	
Pres- sure switch	63H1		Detects high pressure     Provides high-pressure protection	4.15MPa[601psi] OFF set- ting	
Thermis- tor	TH4 (Discharge)		Detects discharge air temperature     Provides high-pressure protection	Degrees Celsius $R_{120} = 7.465k\Omega$ $R_{25/120} = 4057$ $R_t = 7.465 \exp\{4057(\frac{1}{273 + t} - \frac{1}{393})\}$	Resistance check
			0°C[32°F]:698kohm 10°C[50°F]:413kohm 20°C[68°F]:250kohm 30°C[86°F]:160kohm 40°C[104°F]:104kohm 50°C[122°F]:70kohm 60°C[140°F]:48kohm 70°C[158°F]:34kohm 80°C[176°F]:24kohm 90°C[194°F]:17.5kohm 100°C[212°F]:13.0kohm 110°C[230°F]:9.8kohm	2/3+1 393"	

Part name	Symbols (functions)	Notes	Usage	Specifications	Check method
Thermistor	TH2	PQHY only	LEV1 is controlled based on the TH2, TH3, and TH6 values	Degrees Celsius $R_0 = 15k\Omega$	Resistance check
	TH3 (Pipe temperature)	PQHY only	Controls defrosting during heating operation  1) Frequency control  2) LEV1 is controlled according to the amount of subcool at the heat exchanger outlet, which is calculated based on the HPS data and TH3 value.	$\begin{array}{c} \text{Ro}_{180} = 3460 \\ \text{Rt} = 15 \text{exp} \{3460 \ (\frac{1}{273 + t} - \frac{1}{273})\} \\ \\ \text{0°C}[32^{\circ}\text{F}]: \ 15 \text{kohm} \\ \text{10°C}[50^{\circ}\text{F}]: \ 9.7 \text{kohm} \\ \text{20°C}[68^{\circ}\text{F}]: \ 6.4 \text{kohm} \\ \text{25°C}[77^{\circ}\text{F}]: \ 5.3 \text{kohm} \\ \text{30°C}[86^{\circ}\text{F}]: \ 4.3 \text{kohm} \\ \text{40°C}[104^{\circ}\text{F}]: \ 3.1 \text{kohm} \end{array}$	
	TH7 (Water inlet temperature)		Detects water inlet temperature     Protects water heat exchanger from high and low temperatures     Controls water heat exchanger		
	TH8 (Water outlet temperature)		Detects water inlet temperature     Protects water heat exchanger from freezing up		
	TH5		Water heat exchanger is controlled based on the 63LS and TH5 values.		
	TH6	PQHY only	LEV1 is controlled based on the TH2, TH3, and TH6 values		
	TH15 (Compressor shell bottom temperature)		Detects compressor shell bottom temperature		
	THINV		Determines the LEV that controls refrigerant flow on the component cooler		
	THHS Inverter heat sink tem- perature		Controls inverter cooling fan based on THHS temperature	$\begin{array}{c} \text{Degrees Celsius} \\ \text{R}_{50} &= 17 k \Omega \\ \text{R}_{25/120} &= 4016 \\ \text{R}_{t} &= 17 \text{exp} \{4016 \ (\frac{1}{273 + t} - \frac{1}{323}) \} \end{array}$	
				0°C[32°F]: 161kohm 10°C[50°F]: 97kohm 20°C[68°F]: 60kohm 25°C[77°F]: 48kohm 30°C[86°F]: 39kohm 40°C[104°F]: 25kohm	

Part name	Symbols (functions)	Notes	Usage	Specifications	Check method
Sole- noid valve	SV1a Discharge-suc- tion bypass		High/low pressure bypass at start-up and stopping, and capacity control during low-load operation     High-pressure-rise prevention	AC208 - 230V Open while being powered/ closed while not being pow- ered	Continuity check with a tester
	SV4a, SV4b, SV4d Heat exchanger capacity control	PQRY only	Controls heat source unit heat exchanger capacity		
	SV7a,7b Heat exchanger capacity control		Controls heat source unit heat exchanger capacity	AC208 - 230V Open while being powered/ closed while not being pow- ered	
	SV7c Heat exchanger capacity control	P144 P168 P192 models only	Controls heat source unit heat exchanger capacity	AC208 - 230V Open while being powered/ closed while not being pow- ered	
	SV9	PQRY only	High-pressure-rise prevention	AC208 - 230V Closed while being powered/ open while not being pow- ered	
Crank- case Heater	CH11	B mod- els only	Heat the compressor shell to make liquid refrigerant in the compressor evaporate.	•P72, P96, P120 AC230V, 35W •P144, P168, P192 AC240V, 45W	Continuity check with a tester
4-way	21S4a		Changeover between heating AC208-230V		Continuity check with a tester
valve	21S4b	P144 P168 P192 models only	and cooling	Dead: cooling cycle Live: heating cycle	with a tester
Elec- tronic expan-	LEVINV		Controlling the refrigerant flow in the inverter cooling heat exchanger	12 VDC Stepping motor driven valve opening	Same as with the indoor LEV. The resistance
sion valve	LEV1 (for SC control)	PQHY only	Regulates the amount of bypass flow from the heat source unit liquid pipe during cooling	0-480 pulses (direct driven)	values differs from that of the LEVs on indoor unit. (Refer to the section on Trou- bleshooting the LEV(page 330))
	LEV6		changer capacity	12 VDC	Continuity be- tween white and
	LEV7			Stepping motor driven valve opening 41 - 3000 pulses	orange. Continuity be- tween yellow, brown, and blue.
					White M Orange Yellow Brown Blu

# 2. Indoor Unit

Part Name	Symbol (functions)	Notes	Usage	Specification	Check method
Linear expan- sion valve	LEV		<ol> <li>Adjusts superheat at the indoor heat exchanger outlet during cooling</li> <li>Adjusts subcool at the heat exchanger outlet of the indoor unit during heating</li> </ol>	DC12V Opening of stepping motor driving valve 0-(1400) puls- es	Continuity between white, red, and orange. Continuity between yellow, brown, and blue.  White Mark Mark Mark Mark Mark Mark Mark Mark
Thermis- tor	TH1 (Suction air temperature)		Indoor unit control (Thermo)	Ro=15kΩ Ro/80=3460	Resistance check
	TH2 (Pipe tem- perature)		<ol> <li>Indoor unit control (Frost prevention, Hot adjust)</li> <li>LEV control during heating operation (subcool detection).</li> </ol>	Rt = 15exp{3460(\frac{1}{273+t} - \frac{1}{273})}  0°C [32°F]:15kohm 10°C [50°F]:9.7kohm 20°C [68°F]:6.4kohm 25°C [77°F]:5.3kohm 30°C [86°F]:4.3kohm 40°C [104°F]:3.1kohm	
	TH3 (Gas pipe temperature)		LEV control during cooling operation (superheat detection)		
	TH4 Outdoor air temperature)		Indoor unit control (Thermo)		
	Temperature sensor (In- door air tem- perature)		Indoor unit control (Thermo)		

# 3. BC controller

# (1) J type

Part name	Symbols (functions)	Part code	Usage	Specifications	Check method
Pressure sensor	PS1 (High pressure side)		Detects high pressure     LEV control	Pressure 0~4.15 MPa [601psi] Vout 0.5~3.5V 0.071V/0.098 MPa [14psi]	
	PS3 (Intermediate pressure)		Detects intermediate pressure     LEV control	Connector	
Thermistor	TH11 (Liquid inlet tempera- ture)		LEV control (Liquid level control)	$R_0 = 15k\Omega$ $R_{0/80} = 3460$ $R_t = 15 \exp[3460 \ (\frac{1}{273 + t} - \frac{1}{273})]$	
	TH12 (Bypass outlet tem- perature)		LEV control (Superheat)	0°C[32°F] : 15 kΩ 10°C[50°F] :9.7 kΩ 20°C[68°F] :6.4 kΩ 25°C[77°F] :5.3 kΩ	
	TH15 (Bypass in- let tempera- ture)		LEV control (Superheat)	30°C[86°F] :4.3 kΩ 40°C[104°F] :3.1 kΩ	
	TH16 (Liquid re- frigerant tempera- ture)		LEV control (Subcool)		
Solenoid valve	SVA		Provides refrigerant to indoor unit in cooling operation	AC208-230V Open while being powered/ closed while not being pow-	Continuity check with a tester
	SVB		Provides refrigerant to indoor unit in heating operation	ered	tester
	SVC		Provides refrigerant to indoor unit in cooling operation		
LEV	LEV1		Liquid level control	DC12V	Same as
	LEV3		Pressure differential control	Opening of a valve driven by a stepping motor 41-3000 pulses	indoor LEV

## (2) JA type

Part name	Symbols (functions)	Part code	Usage	Specifications	Check method
Pressure sensor	PS1 (High pressure 2) LEV control		Pressure   P-4.15 MPa [601psi]		
	PS3 (Intermediate pressure)		Detects intermediate pressure     LEV control	Connector   Fressure [n/Fa]	
Thermistor	TH11 (Liquid inlet tempera- ture)		LEV control (Liquid level control)	$R_0 = 15k\Omega$ $R_{0/80} = 3460$ $R_1 = 15 \exp{3460 \left(\frac{1}{273 + t} - \frac{1}{273}\right)}$	
	TH12 (Bypass outlet tem- perature)		LEV control (Superheat)	0°C[32°F] : 15 kΩ 10°C[50°F] :9.7 kΩ 20°C[68°F] :6.4 kΩ 25°C[77°F] :5.3 kΩ	
	TH15 (Bypass in- let tempera- ture)		LEV control (Superheat)	30°C[86°F] :4.3 kΩ 40°C[104°F] :3.1 kΩ	
	TH16 (Liquid re- frigerant tempera- ture)		LEV control (Subcool)		
Solenoid valve	SVM1		Opens during cooling and de- frost modes	AC208-230V Open while being powered/	Continuity check with a
	SVM1b		Opens during cooling and de- frost modes	closed while not being pow- ered	tester
	SVA		Provides refrigerant to indoor unit in cooling operation		
	SVC		Provides refrigerant to indoor unit in heating operation		
			Provides refrigerant to indoor unit in cooling operation		
LEV	LEV1 1) Liquid level control			DC12V	Same as
	LEV3		Pressure differential control	Opening of a valve driven by a stepping motor	indoor LEV
	LEV4		Subcool control	41 - 3000 pulses	

# (3) KA type

Part name	Symbols (functions)	Part code	Usage	Specifications	Check method
Pressure sensor	PS1 (High pressure 2) LEV control		Pressure   P-4.15 MPa [601psi]		
	PS3 (Intermediate pressure)		Detects intermediate pressure     LEV control	Connector   Fressure [n/Fa]	
Thermistor	TH11 (Liquid inlet tempera- ture)		LEV control (Liquid level control)	$R_0 = 15k\Omega$ $R_{0/80} = 3460$ $R_1 = 15 \exp{3460 \left(\frac{1}{273 + t} - \frac{1}{273}\right)}$	
	TH12 (Bypass outlet tem- perature)		LEV control (Superheat)	0°C[32°F] : 15 kΩ 10°C[50°F] :9.7 kΩ 20°C[68°F] :6.4 kΩ 25°C[77°F] :5.3 kΩ	
	TH15 (Bypass in- let tempera- ture)		LEV control (Superheat)	30°C[86°F] :4.3 kΩ 40°C[104°F] :3.1 kΩ	
	TH16 (Liquid re- frigerant tempera- ture)		LEV control (Subcool)		
Solenoid valve	SVM1		Opens during cooling and de- frost modes	AC208-230V Open while being powered/	Continuity check with a
	SVM1b		Opens during cooling and de- frost modes	closed while not being pow- ered	tester
	SVA		Provides refrigerant to indoor unit in cooling operation		
	SVC		Provides refrigerant to indoor unit in heating operation		
			Provides refrigerant to indoor unit in cooling operation		
LEV	LEV1 1) Liquid level control			DC12V	Same as
	LEV3		Pressure differential control	Opening of a valve driven by a stepping motor	indoor LEV
	LEV4		Subcool control	41 - 3000 pulses	

# (4) KB type

Part name	Symbols (functions)	Part code	Usage	Specifications	Check method
Pressure sensor	PS3 (Intermediate pressure)		Detects intermediate pressure     LEV control	Pressure [0-4.15 MPa [601psi] Vout 0.5-3.5V 0.071V/0.098 MPa [14psi] Pressure [MPa] = 1.38 x Vout [V]-0.69 Pressure [psi] = (1.38 x Vout [V]-0.69) x 145 1 GND (Black) 2 Vout (White) 3 Vcc (DC5V) (Red)	
Thermistor	TH12 (Bypass outlet tem- perature)		LEV control (Superheat)	R <sub>0</sub> = 15kΩ R <sub>0/80</sub> = 3460 R <sub>1</sub> = 15 exp{3460 $(\frac{1}{273 + t} - \frac{1}{273})}$	
	TH15 (Bypass in- let tempera- ture)		LEV control (Superheat)	0°C[32°F] : 15 kΩ 10°C[50°F] :9.7 kΩ 20°C[68°F] :6.4 kΩ 25°C[77°F] :5.3 kΩ	
	TH16 (Liquid re- frigerant tempera- ture)		LEV control (Subcool)	30°C[86°F] :4.3 kΩ 40°C[104°F] :3.1 kΩ	
Solenoid valve	SVA		Provides refrigerant to indoor unit in cooling operation	AC208-230V Open while being powered/	Continuity check with a
	SVB		Provides refrigerant to indoor unit in heating operation	closed while not being pow- ered	tester
	SVC		Provides refrigerant to indoor unit in cooling operation		
LEV	LEV3		Pressure differential control	DC12V Opening of a valve driven by a stepping motor 0-2000 pulses	Same as indoor LEV

# **VII Control**

[1]	Functions and Factory Settings of the Dipswitches	141
[2]	Controlling the Heat source Unit	148
[3]	Controlling BC Controller	163
[4]	Operation Flow Chart	164

## [1] Functions and Factory Settings of the Dipswitches

#### 1. Heat source unit

#### (1) Control board

Switch		Function	Function according	g to switch setting	Switch setting timing	Units that require switch setting		
Sw	Switch 1 direction		OFF	ON	Switch setting timing	(Note 2)		
SWU	1-2	Unit address set- ting	Set to 00 or 51-100	Set to 00 or 51-100 with the dial switch		С		
	1	Centralized control switch	without connection to the centralized controller  Without connection to the centralized controller  With connection to the centralized controller		Before power on	В		
	2	Deletion of connection information	Normal control	Normal control Deletion Before pow		A		
SW5	3	-						
	4	-		-				
	5	-		-				
	6	-	-					
	7	-						
	6	-		Preset before shipme	ent	-		
	7	Performance-prior- ity/low-noise mode setting	Performance-priority mode (Note 3)	Quiet-priority mode	Anytime after power on	A		
SW6	SW6 8	Low-noise mode/ step demand switching	Low-noise mode (Note 4)	Step demand mode	Before power on	С		
	10	Self-diagnosis/ function setting No. display setting	Self-diagnosis monitor display	Function setting No. display	Anytime after power on	С		

#### Note

- Unless otherwise specified, leave the switch to OFF where indicated by "-" or where the cells are blank, which may be set to
- 2) A: Only the switch on OC needs to be set for the setting to be effective.
  - B: The switches on both the OC and OS need to be set to the same seeing for the setting to be effective.
  - C: The switches on both the OC and OS need to be set.
- 3) When set to the performance-priority mode, the low-noise mode will be terminated, and the units will operate in the normal mode.
  - Cooling: Inlet water temperature or the high pressure is high.
  - Heating: Inlet water temperature or the low pressure is low.(page 29)
- 4) Operation noise is reduced by controlling the compressor frequency.
  - Requires CN3D to be set.(page 29)
- 5) Settings in the shaded areas are factory settings.

Switch		Function			ccording to setting	Switch cotting timing	Units that require switch setting (Note 2)	
				OFF (LED3 Unlit)	ON (LED3 Lit)	Switch setting timing		
SW4 SW6-10: OFF	1-10		Self-diagnosis/opetion monitor	era-	Refer to the LED monitor display on the heat source unit heat source unit heat source unit board.		Anytime after power on	С
	No.769	1000000011	Test run mode: Of OFF	N/	Stops all ICs	Sends a test- run signal to all IC	Anytime after power on	А
	No.810	0101010011	Outputs circulating ter flow rate control		0 V: Fully open 10 V: Fully closed	0 V: Fully closed 10 V: Fully open	After power on and while the compressor is stopped	С
	No.832	0000001011	Cumulative compr sor operation time tion		Retained	Cleared	Anytime after power on (OFF→ON)	С
	No.896	0000000111	Clearance of er-	ос	Retained (IC/ OC)	Deleted (IC/ OC)	Anytime after power on (OFF→ON)	С
			Tor matory	os	Retained (OS)	Deleted (OS)	(OI I → OIV)	
	No.901	1010000111	Changes signal output when all heat source units (OC/OS) go into Thermo-OFF		Water flow rate control valve remains open when all heat source units (OC/OS) go into Thermo-OFF. (Minimum water flow rate)	Water flow rate control valves will close when all heat source units (OC/OS) go into Thermo-OFF.	After power on and while the compressor is stopped	С
SW4 1-10 [0:OFF,	No.912	0000100111	Pump down function	Pump down function  CN51-3,5 signal output switch		Pump down operation	After being energized and while the compressor is stopped	А
1:ON] (Note 1) SW6-10: ON	No.914	0100100111				Water heat ex- changer cou- pling prevention out- put	Anytime after power on	С
	No.917	1010100111	Power on signal output switch		Signals are output while the compressor is in operation.	Signals are output while receiving cooling or heating signal from the controller. *Signals are output even if the thermostat is OFF. (when the compressor is not operating)	Anytime after power on	А
	No.921	1001100111	Temperature unit dis- play		°C	°F	Anytime after power on	С
	No.922 0101100111 Refrigerant amount adjustment		Normal control	Refrigerant amount adjust mode	Anytime after power on (except during initial start- up/becomes ineffective 60 minutes after compres- sor started up.)	A		
	No.932	0010010111	Heating backup		Disabled	Enabled	Anytime after power on	Α
	No.981	1010101111	Water heat exchar freeze prevention	nger	Ineffective	Effective Note 4	Anytime after power on	А

#### Note

1) To change the settings, set SW6-10 to ON, set SW4, and press and hold SWP01 for 2 seconds or longer (OFF→ON). LED3 will light up when the switch setting is ON, and lights off when OFF.

Use the LED3 display to confirm that the settings are properly made.

The settings will need to be set again when the control board is replaced. Write down the settings on the electrical wiring drawing label.

- 2) A: Only the switch on OC needs to be set for the setting to be effective.
  - B: The switches on both the OC and OS need to be set to the same seeing for the setting to be effective.
  - C: The switches on both the OC and OS need to be set.
  - D: The switch on either the OC or OS needs to be set.

- 3) The settings that are configured with SW4 (SW6-10: ON) will automatically be stored on the indoor units that support the new function\*. The stored settings will automatically be restored when the heat source unit control board is replaced. If none of the connected indoor units supports the new function, no configuration information will be saved. If this is the case, manually record the settings configuration on the control box panel.
  - \*The new function is supported on most units that are manufactured in April of 2012 and later. Depending on the model, this function may be added on later date. Ask your dealer for further details.
- 4) If the inlet water temperature (TH7) drops below 5°C [41°F] or the outlet water temperature (TH8) drops below 3°C [37°F] while the compressor is stopped, the heat-source unit will operate in the Cooling-only mode to prevent freeze-ups while the indoor units remain stopped.
  - This operation will terminate when one of the following conditions is met: 1) Both the TH7 and TH8 readings (water temperature) exceed 10°C [50°F], 2) Two hours have passed since the beginning of the Cooling-only operation, or 3) Signal to resume normal operation is received.
- 5) Make this setting at the completion of test run with the ball valves BV1 and BV2 on the heat source unit being open.
- 6) To use the functions above, be sure to set the switches in the following combinations. \*Set SW4(901) to OFF and SW4(917) to ON to keep the pumps on all heat source units (OC/OS) to operate during Thermo-OFF and to keep the water flow rate control valve open. \*Set SW4(901) to ON and SW4(917) to OFF to stop the pumps on all heat source units (OC/OS) during Thermo-OFF and to close the water flow rate control valve.
- 7) When performing the maintenance work, such as vacuum drying, pumping down, or refrigerant recovery, on the heat-source unit, operate the water circuit pump and circulate the water to prevent the water side of the heat exchanger from freezing.
- 8) Settings in the shaded areas are factory settings.

## (2) INV board

Functions are switched with the following connector.

Connector	Function		ding to connec- or	Setting timing	
		Enabled	Disabled	Enabled	Disabled
CN6 short- circuit con- nector	Enabling/disabling the following error detection functions; ACCT sensor failure (5301 Detail No. 115) ACCT sensor circuit failure (5301 Detail No.117) IPM open/ACCT erroneous wiring (5301 Detail No. 119) Detection of ACCT erroneous wiring (5301 Detail No.120)	Error detection enabled	Error detection disable (No load operation is possible.)	Anytime after p	ower on

#### Note

- •CN6 short-circuit connector is mated with the mating connector.
- •Leave the short-circuit connector on the mating connector during normal operation to enable error detection and protect the equipment from damage.

## 2. Function of the switch (Indoor unit)

## (1) Dipswitches

1) SW1,3

Swi	tch	Function	Function accordin	g to switch setting	Switch se	tting timing	Notes	
			OFF	ON	OFF	ON	Notes	
	1	Room temperature detection position	Indoor unit inlet	Built-in sensor on the remote controller			Set to ON (built-in sensor on the remote controller) on All Fresh (PEFY-P-NMHU-E-F) model units	
	2	Clogged filter detection	Not available	Available				
	3	Filter check reminder time setting	100h	2500h				
	4	Outside air intake	Disabled	Enabled			Always set to OFF on PKFY-P-NBMU-E model units	
	5	Remote display option	Fan output	Thermo-ON signal				
SW1	6	Humidifier control	During heating operation	Always on while in the heating mode				
	7	Fan speed setting for Heating Thermo-OFF	Very Low	Low				
	/	Forced heating operation at OA temp of 5°C or below	Not available	Available	While the unit is stopped		Applicable to All Fresh model units (PEFY-P-NMHU-E-F) only	
		Fan speed setting for Heating Thermo-OFF	According to the SW1-7 setting	Preset speed				
	8	-	-	-			Applicable to All Fresh model units (PEFY-P-NMHU-E-F) only	
	9	Self-recovery after power failure	Disabled	Enabled	(Remote controller OFF)			
	10	Power source start-stop	source start-stop Disabled Enabled					
	1	Unit model selection	Heat pump	Cooling only				
	2	Louver	Not available	Available				
	3	Vane	Not available	Available				
	4	Vane swing function	Not available	Available			Always set to OFF on PKFY-P-NBMU-E model units	
SW3	5	-	-	-				
	6	Vane angle limit setting for cooling operation	Downblow B,C	Horizontal			Always set to Downblow B or C on PKFY-P-NBMU-E model units	
	Initial vane position		Enabled	Disabled			PLFY-P-NLMU-E model only	
	7	Automatic LEV value conversion function Not available Available						
	8	Heating 4 °C[7.2 °F] up Enabled		Disabled			Set to OFF on floor-standing (PFFY) type units	
	9	SHm setting	2 5				The setting depends on the model and type.	
	10	SCm setting	10	15			The setting depends on the model and type.	

Note 1. Settings in the shaded areas are factory settings. (Refer to the table below for the factory setting of the switches whose factory settings are not indicated by the shaded cells.)

Note 2. If both SW1-7 and SW1-8 are set to ON, the fan remains stopped during heating Thermo-OFF.

To prevent incorrect temperature detection due to a build-up of warm air around the indoor unit, use the built-in temperature sensor on the remote controller (SW1-1)

instead of the one on the indoor unit inlet thermistor.

Note 3. By setting SW3-1, SW1-7, and SW1-8 to a certain configuration, the fan can be set to remain stopped during cooling Thermo-OFF. See the table below for details.

Switch setting		Fan speed duri	ng Thermo-OFF			
SW3-1	SW1-7	SW1-8	Heating	Cooling	Cooling-only/heat pump	
	OFF	OFF	Very Low		Heat pump	
OFF	ON	OFF	Low	Preset speed		
	OFF	ON	Preset speed			
	ON	ON	Stop			
	OFF	055	-	Preset speed	Cooling-only	
ON	ON	OFF	-	1 Teset speed		
	OFF	ON	-	Stop		
	ON	ON	Stop	Stop	Heat pump	

#### (2) Address switch

Actual indoor unit address setting varies in different systems. Refer to the installation manual for the heat source unit for details on how to make the address setting.

Each address is set with a combination of the settings for the 10's digit and 1's digit. (Example)


When setting the address to "3", set the 1's digit to 3, and the 10's digit to 0.

When setting the address to "25", set the 1's digit to 5, and the 10's digit to 2.

#### 3. Function of the switch <Remote controller>

## (1) MA simple remote controller (PAC-YT53CRAU)

There are switches on the back of the top case. Remote controller Main/Sub and other function settings are performed using these switches. Ordinarily, only change the Main/Sub setting of SW1. (The factory settings are ON for SW1, 2, and 3 and OFF for SW4.)






The figure at left shows that the switches 1 through 5 are set to ON and 6 through 10 are set to OFF.

SW No.	SW contents Main	ON	OFF	Comment	Switch setting timing
1	Remote controller Main/Sub setting	Main	Sub	Set one of the two remote controllers at one group to "ON".	Before power on
2	Temperature display units setting	Celsius	Fahrenheit	When the temperature is displayed in [Fahrenheit], set to "OFF".	Before power on
3	Cooling/heating display in AUTO mode	Yes	No	When you do not want to display "Cooling" and "Heating" in the AUTO mode, set to "OFF".	Before power on
4	Indoor temperature display	Yes	No	When you want to display the indoor temperature, set to "ON".	Before power on

#### Note

The MA remote controllers (PAR-CT01MA series, PAR-FS01MA series, PAR-4"x"MA series, or PAR-3"x"MA series ("x" represents 0 or later)) do not have the switches listed above. Refer to the installation manual for the function setting.

## (2) ME remote controller (PAR-U01MEDU)



Address range		Address setting method		
Main remote controller	101 to 150	Address that equals the lowest address of the group plus 100		
Sub remote controller	151 to 200	Address that equals the lowest address of the group plus 150		

Rotary switch setting	Address
01 to 99	101-199 with the 100's digit automatically set to 1
00	200

<sup>\*</sup> The factory setting for the rotary switches is 01.

Group information for indoor units and AHC units will be deleted, but the rest of the information will be retained.

## Note

To set the address, turn the rotary switch with a precision slotted screwdriver [(-), 2.0 mm (1/16 in) (W)] to a torque of less than 19.6 N to avoid the damage to the rotary switches.

#### 4. Switch functions <BC controller> (Control board)

Su	vitch	Function	Function according	g to switch setting	Switch setting timing
30	VILCII	1 unction	OFF	ON	- Switch setting timing
	1 Model setting		R410A	-	Always leave this switch to OFF.
SW4	2-5 -		-	-	-
3004	6	No. of ports	1	2	Before being energized
	7, 8	-	-	-	-
	1 - 6	-			-
SW5	7	Model setting	Refer to the table below	٧.	Before being energized
	8 Model setting Refer to the table below.			Before being energized	

## Model setting

		SW	/5-8
		OFF	ON
SW5-7	OFF	J type	
GVV3-7	ON	JA (KA) type	KB type

<sup>\*\*</sup> M-NET address can be changed with or without the power being applied to the controller.

The screen will jump to the [Start-up] screen.

## [2] Controlling the Heat source Unit

#### -1- Outline of Control Method

- •The heat source units are designated as OC and OS in the order of capacity from large to small (if two or more units have the same capacity, in the order of address from small to large).
- •The setting of heat source unit can be verified by using the self-diagnosis switch SW4 (SW6-10: OFF).

SW4 (SW6-10: OFF)	Display			
ON	■ The unit is designated as the OC: "oc" appears on the display. ■ The unit is designated as OS: "oS" appears on the display			



The figure at left shows that the switches 1 through 5 are set to ON and 6 through 10 are set to OFF.

- •The OC determines the operation mode and the control mode, and it also communicates with the indoor units.
- •The OS exercises autonomous distributed control (over defrost, error detection, and actuator control etc.) according to the operation/control mode signals that are sent from the OC.

#### -2- Startup sequence rotation

- •At the initial startup, heat source units start up in the order of "OC and OS."
- \*Startup sequence rotation is performed while all the indoor units are stopped. (Even after two hours of operation, startup sequence rotation is not performed while the compressor is in operation.)

In a system with multiple heat source units (OC and OS), when the integrated operation time of the unit in operation (either OC or OS) reaches one hour during a cooling operation at low inlet water temperature, that unit will stop and the other unit will go into operation.

- •Refer to [-12-Control at Initial Start-up] for the initial startup.
- •Performing startup sequence rotation does not change the basic operation of OC and OS. Only startup sequence is changed.
- •Startup sequence of the heat source units can be checked with the self-diagnosis switch SW4 (SW6-10: OFF) on the OC.

SW4 (SW6-10: OFF)	Display
	<ul> <li>OC→OS: "oc" and the "OC" address appear alternately on the display.</li> <li>OS→OC: "oS" and the "OS" address appear alternately on the display.</li> </ul>



The figure at left shows that the switches 1 through 5 are set to ON and 6 through 10 are set to OFF.

#### -3- Initial Control

- •When the power is turned on, the initial processing of the microcomputer is given top priority.
- •During the initial processing, control processing of the operation signal is suspended. (The control processing is resumed after the initial processing is completed. Initial processing involves data processing in the microcomputer and initial setting of each of the LEV opening. This process will take up to 5 minutes.)
- \*During the initial processing, the LED monitor on the heat source unit's control board displays S/W version -> refrigerant type -> heat pump -> cooling only and capacity -> and communication address in turn every second.

#### -4- Control at Start-up

- •The upper limit of frequency during the first 3 minutes of the operation is 50 Hz.
- •When the power is turned on, normal operation will start after the initial start-up mode (to be described later) has been completed (with a restriction on the frequency).

## -5- Bypass Control

Bypass solenoid valves, which bypass the high- and low- pressure sides, perform the following functions.

## (1) Bypass solenoid valve (SV1a) (ON = Open)

Operation	SV	/1a		
Operation	ON	OFF		
When the compressor on each heat source unit starts up	ON for 4 minutes.			
After the restoration of thermo or 3 minutes after restart	ON for 4 minutes.			
During cooling or heating operation with the compressor stopped	Always ON. Exception: OFF when 63HS1-63LS is 0.2MPa[29psi] or less			
After the operation has stopped	ON for 3 minutes. Exception: OFF when 63HS1-63LS is 0.2MPa[29psi] or less			
During defrost operation	ON			
While the compressor is operating at the minimum frequency and when the low pressure (63LS) drops (3 or more minutes after compressor startup)	When low pressure (63LS) drops below 0.23MPa[33psi].	When low pressure (63LS) exceeds 0.38MPa[55psi].		
When high pressure (63HS1) rises	When 63HS1 exceeds 3.62MPa[525psi] When 63HS1 is or below 3.43MPa[497psi] and 30 so have passed			

## (2) Bypass solenoid valve (SV9) (ON = Close)

Operation	SV9				
Operation	OFF	ON			
After the operation has stopped	OFF while the unit is stopped	ON while the unit is in operation			

#### -6- Compressor Frequency Control

- \*Depending on the capacity required, the frequency of the compressor is controlled to keep constant evaporation temperature (0°C [32°F] = 0.71 MPa [103 psi]) during cooling operation, and condensing temperature (49°C [120°F] = 2.88 MPa [418 psi]) during heating operation.
- •The table below summarizes the operating frequency ranges of the inverter compressor during normal operation.
- •The OS in the multiple-heat source-unit system operates at the actual compressor frequency value that is calculated by the OS based on the preliminary compressor frequency value that the OC determines.

Model	Frequency/	cooling (Hz)	Frequency/heating (Hz)		
iviodei	Max	Min	Max	Min	
P72 model	40	10	42	10	
P96 model	56	10	52	10	
P120 model	73	10	64	10	
P144 model	86	16	72	16	
P168 model	99	16	87	16	
P192 model	111	16	101	16	

#### Note

The maximum frequency during heating operation is affected by the water temperature to a certain extent.

#### (1) Pressure limit

The upper limit of high pressure (63HS1) is preset, and when it exceeds the upper limit, the frequency is decreased every 15 seconds.

•The actuation pressure is when the high-pressure reading on 63HS1 is 3.58MPa[519psi].

#### (2) Discharge temperature limit

Discharge temperature (TH4) of the compressor in operation is monitored, and when it exceeds the upper limit, the frequency is decreased every minute.

•Operating temperature is 115°C [239°F].

#### (3) Periodic frequency control

Frequency control other than the ones performed at start-up, upon status change, and for protection is called periodic frequency control (convergent control) and is performed in the following manner.

#### Periodic control cycle

Periodic control is performed after the following time has passed

- •30 seconds after compressor start-up
- +30 seconds after frequency control based on discharge temperature or pressure limit

#### The amount of frequency change

The amount of frequency change is controlled to approximate the target value based on the evaporation temperature (Te) and condensing temperature (Tc).

#### -7- Refrigerant Recovery Control <PQHY>

Recovery of refrigerant is performed during heating operation to prevent the refrigerant from accumulating inside the unit while it is stopped (unit in fan mode), or inside the indoor unit that is in cooling mode or in heating mode with thermo off. It is also performed during cooling operation to prevent an excessive amount of refrigerant from accumulating in the heat source heat exchanger.

#### (1) During heating operation


#### Starting refrigerant recovery mode

The refrigerant recovery mode in heating starts when all of the following three conditions are met:

- •15 minutes have passed since the completion of previous refrigerant recovery.
- •TH4 > 115°C [239°F]
- Frequencies below 50 Hz

#### Refrigerant recovery

 Refrigerant is recovered with the LEV on the applicable indoor unit (unit under stopping mode, fan mode, cooling, heating with thermo off) being opened for 30 seconds.



2) Periodic capacity control of the heat source units and periodic LEV control of the indoor units will be suspended during refrigerant recovery operation; they will be performed after the recovery has been completed.

#### (2) During cooling operation

## Starting refrigerant recovery mode

The refrigerant recovery mode starts when all the following conditions are met:

- •30 minutes have passed since the completion of previous refrigerant recovery.
- •When the unit keeps running for 3 minutes in a row or more with high discharge temperature
- •TH4 > 105°C [221°F] or 63HS1 > 3.43 MPa [497 psi] (35 kg/cm<sup>2</sup>G) and SC0 > 10°C [18°F]

#### Refrigerant recovery

The opening of LEV1 is increased and periodic control begins again.

## -8- Refrigerant Recovery Control <PQRY>

Refrigerant recovery is performed for each BC port during heating operation to prevent the refrigerant from accumulating inside the units that are stopped (in the fan mode), in the cooling mode, or in the heating Thermo-OFF mode. It is also performed during cooling operation to prevent an excessive amount of refrigerant from accumulating in the heat source heat exchanger.

# Starting criteria for the refrigerant recovery cycle (during Cooling-only, Cooling-main, Heating-only, or Heating-main mode)

The refrigerant recovery mode starts when all of the following conditions are met:

 When 5 minutes have passed in the Heating-only or Heating-main mode or 30 seconds have passed in the Cooling-only or Cooling-main mode since the completion of the previous refrigerant recovery cycle AND the when following conditions are met.

TH4 > 105°C [221°F]

2) When the port is not in the 4-minute restart delay mode

# Starting criteria for the refrigerant recovery cycle (during Cooling-only, Cooling-main, Heating-only, or Heating-main mode)

- When the port is in the cooling Thermo-OFF, fan, or stop mode SV■C at the port turns on for 30 seconds. ( indicates port No.)
- 2) The opening of LEV1 and LEV3 is increased.

## -9- Capacity Control of Heat Exchanger<PQHY>

#### (1) Control method

- \*Depending on the capacity required, the heat exchanger capacity of the heat source unit is controlled by the solenoid valve and LEV to keep a constant condensing temperature of (water temperature +10°C [50°F]) during cooling operation and a constant evaporation temperature of (4°C [39°F] =0.80 <Pa [116psi]) during heating operation.
- •The OS in the multiple-heat source-unit system operates at the actual heat exchanger capacity control value that is calculated by the OS based on the preliminary heat exchanger capacity control value that the OC determines.

## (2) Heat source unit heat exchanger capacity control patterns

Model	Operation mode PQRY PQHY		Operation		Sol	enoid va	lve		LE	ΞV		
Wodel			HY pattern	SV4a	SV4b	SV4d	SV7a	SV7b	LEV6	LEV7		
P72-P120	Cooling-		1	OFF	OFF	ON	OFF	OFF	41 pulses	41-3000 pulses		
models	only Cooling-		2	OFF	OFF	ON	OFF	OFF				
	main		3	OFF	OFF OFF ON ON							
		4	OFF	OFF	OFF	OFF	ON					
		-	5	OFF	OFF	OFF	OFF	ON				
					6	OFF	OFF	OFF	ON	OFF		
							7	OFF	OFF	OFF	ON	OFF
			8	OFF	OFF	OFF	ON	OFF				
			9	OFF	OFF	OFF	ON	OFF				
	Cooling- only	Cooling	10	OFF	OFF	OFF	OFF	OFF				
	Heating- only Heating- main	Heating	1	OFF	OFF	OFF	OFF	OFF	41-3000pulses	PQRY: 41 pulses PQHY: 3000 pulses		

Model	Operation	on mode	Operation		Solenoid valve				LEV	
Model	PQRY	PQHY	pattern	SV4a	SV4b	SV4d	SV7a	SV7b	LEV6	LEV7
P144-	Cooling-		1	OFF	ON	ON	ON	ON	41 pulses	41-3000 pulses
P192 models	only Cooling-		2	OFF	ON	ON	ON	OFF		(SV7c*1)
	main		3	OFF	ON	ON	ON	OFF		
			4	OFF	ON	ON	OFF	OFF		
			5	OFF	ON	OFF	OFF	ON		
			6	OFF	OFF	ON	ON	ON		
			7	OFF	OFF	ON	ON	ON		
			8	OFF	OFF	ON	OFF	ON		
			9	OFF	OFF	ON	ON	OFF		
			10	OFF	OFF	ON	ON	OFF		
			11	OFF	OFF	ON	OFF	OFF		
		_	12	OFF	OFF	ON	OFF	OFF		
		_	13	OFF	OFF	OFF	ON	ON		
			14	OFF	OFF	OFF	OFF	ON		
			15	OFF	OFF	OFF	OFF	ON		
			16	OFF	OFF	OFF	ON	OFF		
			17	OFF	OFF	OFF	ON	OFF		
			18	OFF	OFF	OFF	ON	OFF		
			19	OFF	OFF	OFF	ON	OFF		
			20	OFF	OFF	OFF	ON	OFF		
			21	OFF	OFF	OFF	ON	OFF		
			22	OFF	OFF	OFF	ON	OFF		
			23	OFF	OFF	OFF	ON	OFF		
			24	OFF	OFF	OFF	ON	OFF		
	Cooling- only	Cooling	25	OFF	OFF	OFF	OFF	OFF		
	Heating- only Heating- main	Heating	1	OFF	OFF	OFF	OFF	OFF	41-3000 pulses	PQRY: 41 pulses (SV7c: OFF) PQHY: 3000 pulses (SV7c: ON)

<sup>\*1</sup> Solenoid valve SV7c may open to increase the refrigerant flow to the heat exchanger.

#### -10- Subcool Coil Control (Linear Expansion Valve <LEV1>) <PQHY only>

- •The OC and OS controls the subcool coil individually.
- •The LEV is controlled every 30 seconds to maintain constant the subcool at the heat source unit heat exchanger outlet that is calculated from the values of high pressure (63HS1) and liquid piping temperature (TH3), or the superheat that is calculated from the values of low pressure (63LS) and the bypass outlet temperature (TH2) of the subcool coil.
- \*LEV opening is controlled based on the values of the inlet (TH6) and the outlet (TH3) temperatures of the subcool coil, high pressure (63HS1), and discharge temperature (TH4). In a single-heat source-unit system, the LEV is closed (0) in the heating mode, while the compressor is stopped, and during cooling Thermo-OFF. In a multiple-heat source-unit system, the LEV closes (0) during heating operation, while the compressor is stopped, or during cooling Thermo-OFF. The LEV opens to a specified position when 15 minutes have passed after Thermo-OFF. (65 pulses)

## -11- Refrigerant flow control (Linear expansion valve <LEV7>)<PQHY only>


- •Refrigerant flow is controlled by each unit in the combined models during heating. Refrigerant flow control is performed by the OC and OS individually. The valve opens to a specified angle during cooling (Opening: 3000 pulses)
- •Valve opening is controlled based on the values of high pressure (63HS1), discharge temperature (TH4), low pressure (63LS), and piping temperature (TH5).
- •The valve moves to the predetermined position while the unit is stopped.

#### -12- Control at Initial Start-up


- •When started up for the first time before 12 hours have elapsed after power on, the unit goes into the initial startup mode.
- •At the completion of the initial operation mode on the OC and OS they will go into the normal control mode.

#### 1. Flowchart of initial operation

#### (1) System with a single heat-source unit



#### (2) System with two heat-source units



\*1 ∑Qj:Total capacity (model name) code

## -13- Emergency Operation Mode

#### 1. Problems with the heat source unit

- •Emergency operation mode is a temporary operation mode in which the heat source unit that is not in trouble operates when one of the heat source units in the system with two heat-source units is in trouble or when one or two of the heat source units in the system with three heat-source units are in trouble.
- •This mode can be started by performing an error reset via the remote controller.

#### (1) Starting the emergency operation

- 1) When an error occurs, the error source and the error code will be displayed on the display on the remote controller.
- 2) The error is reset using the remote controller.
- 3) If an error code appears that permits an emergency operation in step 1) above, (See the table below.), the retry operation starts.
- 4) If the same error is detected during the retry operation (step 3 above), an emergency operation can be started by resetting the error via the remote controller.

Error codes that permit an emergency operation (Applicable to both OC and OS)

Trouble source		Error codes that permit an emergency operation	Error code description		
		0403	Serial communication error		
		4220	Bus voltage drop		
Compressor		4230	Heatsink overheat protection		
Inverter		4240	Overload protection		
		4250	Overcurrent relay trip		
		5110	Heatsink temperature sensor failure (THHS)		
		5301	Current sensor/circuit failure		
	TH2	5102	Subcool heat exchanger bypass outlet temperature sensor failure		
	TH3	5103	Pipe temperature sensor failure		
	TH4	5104	Discharge temperature sensor failure		
	TH5	5105	Accumulator inlet temperature sensor failure		
Thermistor	TH6	5106	Subcool heat exchanger liquid outlet sensor failure		
	TH7	5107	Water inlet temperature sensor failure		
TH8 TH15		5108	Water outlet temperature sensor fault		
		5115	Compressor shell bottom temperature sensor fault		
Power		4102	Open phase		
Fowel		4115	Power supply sync signal abnormality		

Emergency operation pattern (2 heat source units)

		OC failure pattern	OS failure pattern
ОС		Trouble	Normal
os		Normal	Trouble
Emergency	Cooling	Permitted	Permitted
operation	Heating	Permitted	Permitted
Maximum total		60	0%

#### (2) Ending the emergency operation

#### 1) End conditions

When one of the following conditions is met, emergency operation stops, and the unit makes an error stop.

- •When the integrated operation time of compressor in cooling mode has reached four hours.
- •When the integrated operation time of compressor in heating mode has reached two hours.
- •When an error is detected that does not permit the unit to perform an emergency operation.

#### 2) Control at or after the completion of emergency operation

- •At or after the completion of emergency operation, the compressor stops, and the error code reappears on the remote controller
- •If another error reset is performed at the completion of an emergency mode, the unit repeats the procedures in section (1) above
- •To stop the emergency mode and perform a current-carrying operation after correcting the error, perform a power reset.

#### 2. Communication circuit failure or when some of the heat source units are turned off

This is a temporary operation mode in which the heat source unit that is not in trouble operates when communication circuit failure occurs or when some of the heat source units are turned off.

#### (1) Starting the emergency operation (When the OC is in trouble)

- 1) When an error occurs, the error source and the error code appear on the display on the remote controller.
- 2) Reset the error via the remote controller to start an emergency operation.

#### Precautions before servicing the unit

- •When the OC is in trouble, the OS temporarily takes over the OC's function and performs an emergency operation. When this happens, the indoor unit connection information are changed.
- •In a system that has a billing function, a message indicating that the billing system information has an error may appear on the TG-2000A. Even if this message appears, do not change (or set) the refrigerant system information on the TG-2000A. After the completion of an emergency operation, the correct connection information will be restored.

#### (2) Starting the emergency operation (When the OS is in trouble)

1) A communication error occurs. -> An emergency operation starts in approximately six minutes.

Error codes that permit an emergency operation (Applicable to both OC and OS)

Trouble source	Error codes that permit an emergency operation	Error code description		
Circuit board failure or the power	6607	No acknowledgement error		
to the heat source units is off	6608	No response error		

#### Emergency operation pattern (2 heat source units)


		OC failure pattern	OS failure pattern	
OC		Trouble	Normal	
os		Normal	Trouble	
Emergency	Cooling	Permitted	Permitted	
operation	Heating	Permitted Permitte		
Maximum total capacity of indoor units (Note 1)		Capacity that matches the total capacity of the operable heat source units		

#### (3) Ending the emergency operation

When communication is restored, the emergency mode is cancelled, and the units go into the normal operation mode.


## -14- Control Method <PQRY only>

The control system configuration for the PQRY models is shown in the chart below.



Autonomous distributed control system: A system that consists of three independent sub control systems, instead of a single centralized control system, that work together to maintain the overall control of the entire system.

## -15- Cooling/heating Circuit Control and General Function of System Equipment



## -16- Operation Mode <PQHY>

## (1) Indoor unit operation mode

The operation mode can be selected from the following 5 modes using the remote controller.

1	Cooling mode
2	Heating mode
3	Dry mode
4	Fan mode
5	Stopped mode

## (2) Heat source unit operation mode

1	Cooling mode	All indoor units in operation are in cooling mode.
2	Heating mode	All indoor units in operation are in heating mode.
3	Stopped mode	All indoor units are in fan mode or stopping mode.

## Note

When the heat source unit is performing a cooling operation, the operation mode of the connected indoor units that are not in the cooling mode (Stopped, Fan, Thermo-OFF) cannot be changed to heating from the remote controller. If this attempt is mode, "Heating" will flash on the remote controller. The opposite is true when the heat source unit is performing a heating operation. (The first selection has the priority.)

## -17- Operation Mode <PQRY>

#### (1) Indoor unit operation mode

The operation mode can be selected from the following 6 modes using the remote controller.

1	Cooling mode
2	Heating mode
3	Dry mode
4	Automatic cooling/heating mode
5	Fan mode
6	Stopping mode

#### (2) Heat source unit operation mode


1	Cooling only mode	All indoor units in operation are in cooling mode.
2	Heating only mode	All indoor units in operation are in heating mode.
3	Cooling main mode	Coexistence of units in cooling and heating modes.
4	Heating main mode	Coexistence of units in cooling and heating modes.
5	Stopping mode	All indoor units are in fan mode or stopping mode.

#### Note


When units in cooing and heating coexist, the operation mode (cooling main mode or heating main mode) will be determined by the heat source unit, based on the refrigerant pressure and speed variation data.

#### (3) Operation pattern for automatic cooling/heating mode

When the automatic cooling/heating mode is selected from remote controller functions, the indoor temperature will be detected in pattern as shown in the figure below, and the operation mode (cooling or heating) will automatically be selected.



## (4) Relationship between the operation mode and the load capacity (kW) (within a system)



## -18- DEMAND Control

Cooling/heating operation can be prohibited (Thermo-OFF) by an external input to the heat source units.

## Note

When DIP SW6-8 is set to ON, the 4-step DEMAND control is enabled.

Eight-step demand control is possible in the system with two heat source units. Twelve-step demand control is possible in the system with three heat source units.

Refer to Chapter II [3] 2.(7) "Various types of control using input-output signal connector on the heat source unit (various connection options)" for details.(page 28)

## [3] Controlling BC Controller

#### 1. Control of SVA, SVB, and SVC

SVA, SVB, and SVC turn on or off depending on the operation mode of the branch.

		Mode				
		Cooling	Heating	Stopped	Defrost	
Port	SVA	ON	OFF	OFF	OFF	
	SVB	OFF	ON	OFF	OFF	
	SVC	ON	OFF	OFF	OFF	

#### 2. Control of SVM1 snd SVM1b

SVM turns on or off depending on the operation mode.

Operation mode	Cooling only	Cooling main	Heating only	Heating main	Defrost	Stopped
SVM1,1b	ON	Pressure dif- ferential con- trol*1	OFF	OFF	ON	OFF

<sup>\*1.</sup> Pressure differential control: The detected differential pressure (PS1 and PS3) is controlled every minute so as to be within a certain range.

#### 3. Control of LEV

LEV opening (sj) is controlled as follows depending on the operation mode.

	Operation mode	Cooling only	Cooling main	Heating only	Heating main	Defrost	Stopped
J, JA, KA type	LEV1	3000	Liquid level	85 <sup>*3</sup>	85 <sup>*3</sup>	3000	900
	LEV3	Superheat control*4	control*1dif- ferential control*2	Pressure differential control <sup>*2</sup>	Pressure dif- ferential con- trol*2	3000	41
	LEV4 (JA and KA types only)	41	41	Pressure differential control <sup>*2</sup>	Pressure dif- ferential con- trol*2	3000	41
KB type	LEV3	Superheat control*4	Superheat control*4	60	60	60	60

<sup>\*1.</sup> Liquid level control: The liquid level detected by the liquid inlet temperature (TH11 sensor) is controlled so as to be within a certain range.


<sup>\*2.</sup> Pressure differential control: The detected differential pressure (PS1 and PS3) is controlled every minute so as to be within a certain range.

<sup>\*3.</sup> Can be 85 or more due to pressure rise on the liquid side (PS1).

<sup>\*4.</sup> Superheat control: The amound of superheat that is calculated on the bypass inlet and outlet temperature (TH12, TH15) is controlled every minute so as to be within a certain range.

## [4] Operation Flow Chart

- 1. Mode determination flowchart <PQHY>
- (1) Indoor unit (cooling, heating, dry, fan mode)




<sup>\*</sup>Note 1. Indoor unit LEV fully closed : Opening 41.

<sup>\*</sup>Note 2. The system may go into the error mode on either the indoor unit or the heat source unit side. If some of the indoor units are experiencing a problem (except water leakage), only those indoor units that are experiencing the problems will stop.

If the heat source unit is experiencing a problem, all connected indoor units will stop.

<sup>\*</sup>Note 3. The operation will be prohibited when the set cooling/heating mode is different from that of the heat source unit.

#### (2) Heat source unit (cooling and heating modes)




- \*Note 1. For about 3 minutes after power on, search for the indoor unit address, for the remote controller address, and for the group information will start. During this, "HO" / "PLEASE WAIT" blinks on the display of the remote controller. When the indoor unit to be controlled by the remote controller is missing, "HO" / "PLEASE WAIT" keeps blinking on the display of the remote controller even after 3 or more minutes after power on.
- \*Note 2. The system may go into the error mode on either the indoor unit or the heat source unit side. The heat source unit stops only when all of the connected indoor units are experiencing problems. The operation of even a single indoor unit will keep the heat source unit running. The error will be indicated on the LED display.
- \*Note 3. The heat source unit operates according to the operation mode commanded by the indoor unit. However, when the heat source unit is running a cooling operation, come of the operating indoor units will stop, or the operation of these indoor units will be prohibited even when the indoor unit mode is switched from fan mode to heating mode.

  This also applies when the heat source unit is running a heating operation.


## 2. Operations in each mode

## (1) Cooling operation




\*Note 1. The indoor fan operates at the set notch under cooling mode regardless of the ON/OFF state of the thermostat.

## (2) Heating operation



Normal operation
----- Unit in the stopped state
During test run mode

#### (3) Dry operation




\*Note 1.When the indoor unit inlet temperature exceeds 18°C [64°F], the heat source unit (compressor) and the indoor unit fan start the intermittent operation simultaneously. When the indoor unit inlet temperature becomes 18°C [64°F],or less, the fan always runs (at low speed). The heat source unit, the indoor unit, and the solenoid valve operate in the same way as they do in the cooling operation when the compressor is turned on.

\*Note 2.Thermostat is always kept on during test run mode, and indoor and heat source unit intermittent operation (ON) time is a little longer than that of normal operation.


#### 1. Mode determination flowchart <PQRY>

## (1) Indoor unit (cooling, heating, dry, fan mode)




- \*Note 1. Indoor unit LEV fully closed : Opening 41.
- \*Note 2. The system may go into the error mode on either the indoor unit side or the BC controller or heat source unit side. If some of the indoor units are experiencing a problem, only those indoor units that are experiencing the problem will stop. If the BC controller or the heat source unit is experiencing a problem, all the connected units will stop.
- \*Note 3. If multiple indoor units are connected to a port and there is a discrepancy in the operation mode between the indoor unit and the port, the operation will be prohibited. (Operation mode blinks on the remote controller, the Fan stops, indoor unit LEV becomes fully closed.)

#### (2) Heat source unit (cooling only, heating only, cooling main and heating main modes)



- \*Note 1. For about 3 minutes after power on, search for the indoor unit address, for the remote controller address, and for the group information will start. During this, "HO"/ "PLEASE WAIT" blinks on the display of the remote controller. When the indoor unit to be controlled by the remote controller is missing, "HO"/ "PLEASE WAIT" keeps blinking on the display of the remote controller even after 3 or more minutes after power on.
- \*Note 2. The system may go into the error mode on either the indoor unit or the heat source unit side. The heat source unit stops only when all of the connected indoor units are experiencing problems. The operation of even a single indoor unit will keep the heat source unit running. The error will be indicated on the LED display.
- \*Note 3. The units will follow the operation mode commands from the BC controller
- \*Note 4. When the operation mode commands from the BC controllers are mixed (both cooling and heating), the actual operation mode is determined by the heat source unit.


#### (3) BC controller (cooling only, heating only, cooling main and heating main modes)



Note 1. The system may go into the error mode on either the indoor unit side or the BC controller or heat source unit side. If some of the indoor units are experiencing a problem, only those indoor units that are experiencing the problem will stop. If the BC controller or the heat source unit is experiencing a problem, all the connected units will stop.


### 2. Operations in each mode

#### (1) Cooling operation




\*Note 1. The indoor fan operates at the set notch under cooling mode regardless of the ON/OFF state of the thermostat.

### (2) Heating operation



### (3) Dry operation



\*Note 1.When the indoor unit inlet temperature exceeds 18°C [64°F], the heat source unit (compressor) and the indoor unit fan start the intermittent operation simultaneously. When the indoor unit inlet temperature becomes 18°C [64°F],or less, the fan always runs (at low speed). The heat source unit, the indoor unit, and the solenoid valve operate in the same way as they do in the cooling operation when the compressor is turned on

\*Note 2.Thermostat is always kept on during test run mode, and indoor and heat source unit intermittent operation (ON) time is a little longer than that of normal operation.

### **VIII Test Run Mode**

[1]	Items to be checked before a Test Run	. 177
[2]	Test Run Method	. 178
[3]	Operating Characteristic and Refrigerant Amount	. 181
[4]	Adjusting the Refrigerant Amount	. 181
[5]	Refrigerant Amount Adjust Mode	. 189
[6]	The following symptoms are normal.	. 193
[7]	Standard Operation Data (Reference Data)	. 194

### [1] Items to be checked before a Test Run

- (1) Check for refrigerant leak and loose cables and connectors.
- (2) When opening or closing the front panel of the control box, do not let it come into contact with any of the internal components.

#### Note

- •Before inspecting the inside of the control box, turn off the power, keep the unit off for at least 10 minutes, and confirm that the capacitor voltage (inverter main circuit) has dropped to 20 VDC or less. (It takes about 10 minutes to discharge electricity after the power supply is turned off.)
- •Control box houses high temperature parts. Be well careful even after turning off the power source.
- (3) Measure the insulation resistance between the power supply terminal block and the ground with a 500V megger and make sure it reads at least 1 MΩ.

### Note

- •Do not operate the unit if the insulation resistance is below 1 M $\Omega$ .
- •Do not apply megger voltage to the terminal block for transmission line. Doing so will damage the controller board.
- •The insulation resistance between the power supply terminal block and the ground could go down to close to 1 MΩ immediately after installation or when the power is kept off for an extended period of time because of the accumulation of refrigerant in the compressor.
- •If insulation resistance reads below 1  $M\Omega$ , by turning on the main power and keeping it on for at least 12 hours, the refrigerant in the compressor will evaporate and the insulation resistance will go up.
- •Do not measure the insulation resistance of the terminal block for transmission line for the unit remote controller.
- (4) When the power is turned on, the compressor or heater is energized even while it is not operating.

#### Note

- •Before turning on the power, disconnect all power supply wires from the compressor terminal block, and measure the insulation resistance of the compressor.
- •Check the compressor for a ground fault. If the insulation resistance is below 1  $M\Omega$ , connect all power supply wires to the compressor and turn on the power to the heat source unit. (The liquid refrigerant in the compressor will evaporate by energizing the compressor or heater.)
- (5) Check that the valve on the gas pipe and liquid pipe are fully open.

#### Note

Securely tighten the cap.

(6) Check the phase sequence and the voltage of the power supply.

When the voltage is out of the ±10% range, or when the phase voltage difference is more than 2%, please discuss the countermeasure with the customer.

(7) [When a transmission booster is connected]

Turn on the transmission booster before turning on the heat source units.

#### Note

- •If the heat source units are turned on first, the connection information for the refrigerant circuit may not be properly recognized.
  •In case the heat source units are turned on before the transmission booster is turned on, perform a power reset on the heat source units after turning on the power booster.
- (8) Turn on the main power to the unit at least 12 hours before test run to power the crankcase heater.

#### Note

Insufficient powering time may result in compressor damage.


(9) When a power supply unit is connected to the transmission line for centralized control, perform a test run with the power supply unit being energized. Leave the power jumper connector on CN41 as it is (factory setting).

\*Includes the cases where power is supplied to the transmission line from a system controller with a power-supply function

### [2] Test Run Method

### 1. MA Remote Controller (PAR-30MAAU)

### (1) Remote controller button functions



#### (2) Operation procedures

#### Step 1: Turn on the main power at least 12 hours before starting operation.


The green power indicator and "Please Wait" will blink on the remote controller for up to five minutes. While they are blinking, remote controller will not respond to button pressing. Wait until "Please Wait" goes off the screen.

### Step 2: Set the remote controller to the "Test run" mode.

- 1 On the Service Menu screen, select "Test run" and press the 🔾 button.
- The test run menu will appear. Select "Test run" and press the button. Test run will begin, and the test run screen will appear.
- 3 It may take up to 15 minutes to detect a system error. (\*Keep all the systems simultaneously operating for a minimum of 15 minutes.)








#### Step 3: Check the supply air temperatures and the auto vane functions.

- 1 Press the F1 button to change the operation mode.
  Cooling: Check that the supply air is cold.
  Heating: Check that the supply air is warm.
- Press the button to bring up the screen to change the airflow direction, and check the auto vane with the F1 and F2 buttons. Press the button to return to the "Test run" screen.



### Step 4: Ending the test run


1 Press the (0) button to end the test run. (The screen will return to the Test run menu.)

### (3) Entering the maintenance information

# Step 1: Switching the remote controller screen to "Maintenance information" (Requires the maintenance password. This screen is not accessible while the controller is under centralized control.)

1 On the Service Menu screen, select "Input maintenance info." and press the 🕟 button.


2 Select "Model name input" and press the 🔾 button.



### Step 2: Selecting the heat source unit address and indoor unit address information to be resistered

1 Select the address to be registered, using the F1 and F2 buttons, and then press the 🕢 button.


•Address: 0-255



### Step 3: Registering the model name

1 Enter the model name. The character string can be up to 18 characters in length.

- Move the cursor left with the F1 button, and right with the F2 button.
- Select a character with the F3 and F4 buttons.
- Press the button when done entering characters. The screen will return to the one shown in Step 2.



Repeat Steps 2 and 3 until all the model names of the units at the selected addresses have been entered. To change the address, press the (5) button on the screen shown in Step 3 to return to the screen shown in Step 2, and then change the address. After changing the address, enter the model name.

Tips: the model name information of the unit at a given address can be copied and pasted to another unit at a different address.


• Press the F3 button in Step 2 to copy the model name information of the unit at the selected address.

• Press the F4 button in Step 2 to overwrite the model name information of the unit at the selected address.

### Step 4: Registering the serial number

1 Select "Serial No. input" in Step 1-2 above, and then press the button.

2 Register the serial number by following steps 2 and 3 above. The serial number can be up to 8 characters in length.





#### Step 5: Entering your dealer's phone number

Select "Dealer information input" on the Maintenance information screen, and press the button.

Press the button when "Dealer information" appears.






- 3 Enter your dealer's telephone number. Telephone number can be up to 13 characters.
  - Move the cursor left with the F1 button, and right with the F2 button.
  - Select a character with the F3 and F4 buttons.
  - Press the button when done entering characters.



### 2. MA Remote Controller (PAR-21MAAU)

The figure shows an MA remote controller (PAR-21MAAU).



Operation procedures							
Turn on the main power.	$\rightarrow$	"PLEASE WAIT" appears on the LCD for up to five minutes. Leave the power on for 12 hours. (Energize the belt heater.)					
Press the Test button twice.	$\rightarrow$	Operation mode display "TEST RUN" and OPERATION MODE are displayed alternately.					
Press the Operation Mode button. ☐ ♣♦♦	$\rightarrow$	Make sure that the air is blowing out.					
Switch to cooling (or heating) operation by pressing the	Opera	ation Mode button. ☐∯♦⊅Ф◊≫⊆					
$\rightarrow$ Make sure that cold (or warm) air blows out. On the							
Press the Fan Speed button.	$\rightarrow$	Make sure that the fan speed changes with each pressing of the button.					
Change the air flow direction by pressing the Vertical Air	ir Direc	ction button or the Louver button.					
ightarrow Make sure that the air flow direction changes with each pre-	essing c	of the button.					
Confirm the operation of all interlocked equipment, suc	h as ve	entilation equipment.					
Cancel the test run by pressing the ON/OFF button.	$\rightarrow$	Stop					
Note 1: Refer to the following pages if an error code app	ears o	n the remote controller or when the unit malfunctions.					
2: The OFF timer will automatically stop the test ru							
3: The remaining time for the test run will be displa	yed in	the time display during test run.					
<ol> <li>The temperature of the liquid pipe on the indoor controller during test run.</li> </ol>	unit w	ill be displayed in the room temperature display window on the remote					
		ne display when the Vane Control button is pressed. This is normal.					
6: If an external input is connected, perform a test		· ·					
<ol><li>Test run all systems for at least 15 minutes to dete</li></ol>	ect pos	sible system errors.					

### [3] Operating Characteristic and Refrigerant Amount

It is important to have a clear understanding of the characteristics of refrigerant and the operating characteristics of air conditioners before attempting to adjust the refrigerant amount in a given system.

#### 1. Operating characteristic and refrigerant amount

The following shows items of particular importance.

- 1) During cooling operation, the amount of refrigerant in the accumulator is the smallest when all indoor units are in operation.
- 2) During heating operation, the amount of refrigerant in the accumulator is the largest when all indoor units are in operation.
- 3) General tendency of discharge temperature
  - Discharge temperature tends to rise when the system is short on refrigerant.
  - •Changing the amount of refrigerant in the system while there is refrigerant in the accumulator has little effect on the discharge temperature.
  - •The higher the pressure, the more likely it is for the discharge temperature to rise.
  - •The lower the pressure, the more likely it is for the discharge temperature to rise.
- 4) When the amount of refrigerant in the system is adequate, the compressor shell temperature is 10 to 60°C [18 to 108°F] higher than the low pressure saturation temperature (Te).
  - -> If the temperature difference between the compressor shell temperature and low pressure saturation temperature (Te) is smaller than 5°C [9°F], an overcharging of refrigerant is suspected.

### [4] Adjusting the Refrigerant Amount

#### 1. Symptoms

Overcharging or undercharging of refrigerant can cause the following symptoms:

Before attempting to adjust the amount of refrigerant in the system, thoroughly check the operating conditions of the system. Then, adjust the refrigerant amount by running the unit in the refrigerant amount adjust mode.

The system comes to an abnormal stop, displaying 1500 (overcharged refrigerant) on the controller.	Overcharged refrigerant
The operating frequency does not reach the set frequency, and there is a problem with performance.	Insufficient refrigerant amount
The system comes to an abnormal stop, displaying 1102 (abnormal discharge temperature) on the controller.	

#### 2. Amount of refrigerant

### (1) To be checked during operation

Operate all indoor units in either cooling-only or heating-only mode, and check such items as discharge temperature, subcooling, low pressure, suction temperature, and shell bottom temperature to estimate the amount of refrigerant in the system.

Symptoms	Conclusion	
Discharge temperature is high. (Normal discharge temperature is below 95°C [203°F].)	Slightly under-	
Low pressure is unusually low.	charged refrigerant	
Suction superheat is large. (Normal suction superheat is less than 20°C [36°F].)		
Compressor shell bottom temperature is high. (The difference between the compressor shell bottom temperature and low pressure saturation temperature (Te) is greater than 60°C [108°F].)		
Discharge superheat is small. (Normal discharge superheat is greater than 10°C [18°F].)	Slightly overcharged	
Compressor shell bottom temperature is low. (The difference between the compressor shell bottom temperature and low pressure saturation temperature (Te) is less than 5°C [9°F].)	refrigerant	

### 3. Additional refrigerant charge <PQHY>

### (1) Factory charged-amount and maximum additional amount of refrigerant

The amount necessary for extended pipe (field piping) is not included and must be added on site. When the amount obtained by the calculation formula (2) exceeds the "Charged on site" values in the table below, restructure the system so that the additional refrigerant amount does not exceed those values.

### For PQHY-P-Z(S)LMU-A1/B

For PQHY-P-Z(S)LMU-A1/B								
Total index of the heat source units	P72 ZLMU	P96 ZLMU	P120 ZLMU	P144 ZLMU	P168 ZLMU	P192 ZLMU	P144 ZSLMU	P168 ZSLMU
Factory charged	5.0 kg	5.0 kg	5.0 kg	6.0 kg	6.0 kg	6.0 kg	10.0 kg	10.0 kg
Charged on site	22.0 kg	28.5 kg	29.5 kg	42.0 kg	51.5 kg	53.5 kg	42.0 kg	51.5 kg
Total for system	27.0 kg	33.5 kg	34.5 kg	48.0 kg	57.5 kg	59.5 kg	52.0 kg	61.5 kg
Factory charged	11 lbs 1 oz	11 lbs 1 oz	11 lbs 1 oz	13 lbs 4 oz	13 lbs 4 oz	13 lbs 4 oz	22 lbs 1 oz	22 lbs 1 oz
Charged on site	48 lbs 9 oz	62 lbs 14 oz	65 lbs 1 oz	92 lbs 10 oz	113 lbs 9 oz	118 lbs 0 oz	92 lbs 10 oz	113 lbs 9 oz
Total for system	59 lbs 9 oz	73 lbs 14 oz	76 lbs 1 oz	105 lbs 14 oz	126 lbs 13 oz	131 lbs 3 oz	114 lbs 11 oz	135 lbs 10 oz
Total index of the heat source units	P192 ZSLMU	P216 ZSLMU	P240 ZSLMU	P288 ZSLMU	P312 ZSLMU	P336 ZSLMU	P360 ZSLMU	
Factors of annual	40.01	40.01	40.01	40.01	40.01	40.01	40.01	

Total index of the heat source units	P192	P216	P240	P288	P312	P336	P360
	ZSLMU						
Factory charged	10.0 kg	10.0 kg	10.0 kg	12.0 kg	12.0 kg	12.0 kg	12.0 kg
Charged on site	53.5 kg	55.0 kg	56.0 kg	67.5 kg	67.5 kg	67.5 kg	70.0 kg
Total for system	63.5 kg	65.0 kg	66.0 kg	79.5 kg	79.5 kg	79.5 kg	82.0 kg
Factory charged	22 lbs	22 lbs	22 lbs	26 lbs	26 lbs	26 lbs	26 lbs
	1 oz	1 oz	1 oz	8 oz	8 oz	8 oz	8 oz
Charged on site	118 lbs	121 lbs	123 lbs	148 lbs	148 lbs	148 lbs	154 lbs
	0 oz	5 oz	8 oz	13 oz	13 oz	13 oz	6 oz
Total for system	140 lbs	143 lbs	145 lbs	175 lbs	175 lbs	175 lbs	180 lbs
	0 oz	5 oz	9 oz	5 oz	5 oz	5 oz	13 oz

#### (2) Calculation formula

- •Piping length from heat source unit to the farthest indoor unit ≤ 30.5 m [100 ft]: Use table [A].
- •Piping length from heat source unit to the farthest indoor unit > 30.5 m [100 ft]: Use table [B].

	Additional refrigerant charge		Liquid pipe size Total length of ø19.05 mm [3/4 in]				Liquid pipe size Total length of ø15.88 mm [5/8 in]			Liquid pipe size Total length of ø12.7 mm [1/2 in]
[A]	(kg)[oz]	=	[A]	(m) x 0.29 (kg/m) (ft) x 3.12 (oz/ft)	+	[A]	(m) x 0.2 (kg/m) (ft) x 2.16 (oz/ft)	+	[A]	(m) x 0.12 (kg/m) (ft) x 1.30 (oz/ft)
[B]	(kg)[oz]		[B]	(m) x 0.26 (kg/m) (ft) x 2.80 (oz/ft)		[B]	(m) x 0.18 (kg/m) (ft) x 1.94 (oz/ft)		[B]	(m) x 0.11 (kg/m) (ft) x 1.19 (oz/ft)
		Γ		Liquid pipe size	1		Liquid pipe size	1		
				Total length of ø9.52 mm [3/8 in]			Total length of ø6.35 mm [1/4 in]			
		+	[A]	Total length of	+	[A]	Total length of			

+	Total o		,	Amount (to be added for indoor units)
		-	27	2.0 kg [71 oz]
	28	-	54	2.5 kg [89 oz]
	55	-	126	3.0 kg [106 oz]
	127	-	144	3.5 kg [124 oz]
	145	-	180	4.5 kg [159 oz]
	181	-	234	5.0 kg [177 oz]
	235	-	273	6.0 kg [212 oz]
	274	-	307	8.0 kg [283 oz]
	308	-	342	9.0 kg [318 oz]
	343	-	411	10.0 kg [353 oz]
	412	-	480	12.0 kg [424 oz]
	481	-		14.0 kg [494 oz]

<sup>\*</sup>If the following (1) and (2) are met, add 0.3 kg [11 oz] of refrigerant per indoor unit.

Round up the calculation result to the nearest 0.1 kg. (Example: 18.04 kg to 18.1 kg)

Round up the calculation result in increments of 4 oz (0.1 kg) or round it up to the nearest 1 oz.


(Example: 178.21 oz to 179 oz)

<sup>(1)</sup> When only PEFY-P18NMAU-E\*\*, PEFY-P24NMAU-E\*\*, or PEFY-P30NMAU-E\*\* are connected

<sup>(2)</sup> When the total number of connected indoor units is 6 or less

<sup>\*</sup>When connecting PLFY-EP18NEMU\*\*-E\*\*, PLFY-EP24NEMU\*\*-E\*\*, or PLFY-EP36NEMU\*\*-E\*\*, add 0.4 kg [15 oz] of refrigerant per indoor unit.

### (3) Example: PQHY-P144ZLMU



### (4) Sample calculation

			Inc	door				
A: ø12.70 [1/2"]	40 m [13	31 ft]	1:	P36	a:	ø9.52 [3/8"]	10 m [32 ft]	
B: ø9.52 [3/8"]	10 m [32	2 ft]	2:	P30	b:	ø9.52 [3/8"]	5 m [16 ft]	Total capacity of indoor units: 117
C: ø9.52 [3/8"]	15 m [49	9 ft]	3:	P15	c:	ø6.35 [1/4"]	10 m [32 ft]	
D: ø9.52 [3/8"]	10 m [32	2 ft]	4:	P12	d:	ø6.35 [1/4"]	10 m [32 ft]	
			5:	P24	e:	ø9.52 [3/8"]	10 m [32 ft]	
Total length for each	pipe size:	ø12.70 [1/2"]				131 ft]		
		ø9.52 [3/8"]		B + 0	C + D	+ a + b + e = 10	) + 15 + 10 + 10 + 5	+ 10 = 60 m [193 ft]
		ø6.35 [1/4"]		c + d	= 10	+ 10 = 20 m [64	l ft]	
Therefore, additional	refrigerant	charge	=	40 × 0	0.11 +	60 × 0.054 + 2	0 × 0.021 + 3	
		(kg)	=	11.06		kg		
			÷	: 11.1		kg		
	or							
Therefore, additional	refrigerant	charge	=	= 131 ×	1.19	+ 193 × 0.59 +	64 × 0.23 + 106	
		(oz)	=	390.4	-8	oz		
			Ħ	390.5	i	OZ		

### **♠** CAUTION

Charge liquid refrigerant (as opposed to gaseous refrigerant) into the system.

•If gaseous refrigerant is charged into the system, the composition of the refrigerant in the cylinder will change and may result in performance loss.

### 4. Additional refrigerant charge <PQRY>

### (1) Factory charged-amount and maximum additional amount of refrigerant

The amount necessary for extended pipe (field piping) is not included and must be added on site. When the amount obtained by the calculation formula (2) exceeds the "Charged on site" values in the table below, restructure the system so that the additional refrigerant amount does not exceed those values.

### For PQRY-P-Z(S)LMU-A1/B

Total index of the heat source units	P72	P96	P120	P144	P168	P192	P144	P168
	ZLMU	ZLMU	ZLMU	ZLMU	ZLMU	ZLMU	ZSLMU	ZSLMU
Factory charged	5.0 kg	5.0 kg	5.0 kg	6.0 kg	6.0 kg	6.0 kg	10.0 kg	10.0 kg
Charged on site	28.0 kg	30.0 kg	31.0 kg	46.0 kg	47.0 kg	48.0 kg	49.0 kg	50.0 kg
Total for system	33.0 kg	35.0 kg	36.0 kg	52.0 kg	53.0 kg	54.0 kg	59.0 kg	60.0 kg
Factory charged	11 lbs	11 lbs	11 lbs	13 lbs	13 lbs	13 lbs	22 lbs	22 lbs
	1 oz	1 oz	1 oz	4 oz	4 oz	4 oz	1 oz	1 oz
Charged on site	61 lbs	66 lbs	68 lbs	101 lbs	103 lbs	105 lbs	108 lbs	110 lbs
	12 oz	3 oz	6 oz	7 oz	10 oz	14 oz	1 oz	4 oz
Total for system	72 lbs	77 lbs	79 lbs	114 lbs	116 lbs	119 lbs	130 lbs	132 lbs
	13 oz	3 oz	6 oz	11 oz	14 oz	1 oz	2 oz	5 oz

Total index of the heat source units	P192	P216	P240	P288	P312	P336
	ZSLMU	ZSLMU	ZSLMU	ZSLMU	ZSLMU	ZSLMU
Factory charged	10.0 kg	10.0 kg	10.0 kg	12.0 kg	12.0 kg	12.0 kg
Charged on site	51.0 kg	52.0 kg	54.0 kg	70.0 kg	70.0 kg	73.0 kg
Total for system	61.0 kg	62.0 kg	64.0 kg	82.0 kg	82.0 kg	85.0 kg
Factory charged	22 lbs	22 lbs	22 lbs	26 lbs	26 lbs	26 lbs
	1 oz	1 oz	1 oz	8 oz	8 oz	8 oz
Charged on site	112 lbs	114 lbs	119 lbs	154 lbs	154 lbs	160 lbs
	7 oz	11 oz	1 oz	6 oz	6 oz	15 oz
Total for system	134 lbs	136 lbs	141 lbs	180 lbs	180 lbs	187 lbs
	8 oz	11 oz	2 oz	13 oz	13 oz	7 oz

### (2) Calculation formula

- •Piping length from heat source unit to the farthest indoor unit ≤ 30.5 m [100 ft]: Use table [A].
- •Piping length from heat source unit to the farthest indoor unit > 30.5 m [100 ft]: Use table [B].

		High-pressure pipe size Total length of ø28.58 mm [1-1/8 in]		Hi	igh-pressure pipe size Total length of ø22.2 mm [7/8 in]		Hi	igh-pressure pipe size Total length of ø19.05 mm [3/4 in]
oz]	[A	(m) x 0.36 (kg/m) (ft) x 3.88 (oz/ft)	+	[A]	(m) x 0.23 (kg/m) (ft) x 2.48 (oz/ft)	+	[A]	(m) x 0.16 (kg/m) (ft) x 1.73 (oz/ft)
[oz]	[B	(m) x 0.33 (kg/m) (ft) x 3.55 (oz/ft)		[B]	(m) x 0.21 (kg/m) (ft) x 2.26 (oz/ft)		[B]	(m) x 0.14 (kg/m) (ft) x 1.51 (oz/ft)
+		High-pressure pipe size Total length of ø15.88 mm [5/8 in]			Liquid Piping Size Total length of ø19.05 mm [3/4 in]			Liquid Piping Size Total length of ø15.88 mm [5/8 in]
		+		(m) x 0.11 (kg/m) (ft) x 1.19 (oz/ft)	+	[A]	(m) x 0.29 (kg/m) (ft) x 3.13 (oz/ft)	+
	[B	(m) x 0.1 (kg/m) (ft) x 1.08 (oz/ft)		[B]	(m) x 0.26 (kg/m) (ft) x 2.81 (oz/ft)		[B]	(m) x 0.18 (kg/m) (ft) x 1.94 (oz/ft)
+		Liquid Piping Size Total length of ø12.7 mm [1/2 in]			Liquid Piping Size Total length of ø9.52 mm [3/8 in]			Liquid Piping Size Total length of ø6.35 mm [1/4 in]
		(m) x 0.12 (kg/m) (ft) x 1.30 (oz/ft)	+	[A]	(m) x 0.06 (kg/m) (ft) x 0.65 (oz/ft)	+	[A]	(m) x 0.024 (kg/m) (ft) x 0.26 (oz/ft)
	[B	(m) x 0.11 (kg/m) (ft) x 1.19 (oz/ft)		[B]	(m) x 0.054 (kg/m) (ft) x 0.59 (oz/ft)		[B]	(m) x 0.021 (kg/m) (ft) x 0.23 (oz/ft)
	[oz]	[oz] = [A] [oz] [B] + [A] + [A]		Total length of	Total length of	Total length of	Total length of	Total length of

	Main or Sub BC controller	Amount	
+	J-type	1.5 kg/unit [53 oz/unit]	
	JA-type	3.0 kg/unit [106 oz/unit]	
	KA-type	4.7 kg/unit [166 oz/unit]	
	KB-type	0.4 kg/unit [15 oz/unit]	

Total ca connected			Amount (to be added for indoor units)
	-	27	2.0 kg [71 oz]
28	-	54	2.5 kg [89 oz]
55	-	126	3.0 kg [106 oz]
127	-	144	3.5 kg [124 oz]
145	-	180	4.5 kg [159 oz]
181	-	234	5.0 kg [177 oz]
235	-	273	6.0 kg [212 oz]
274	-	307	8.0 kg [283 oz]
308	-	342	9.0 kg [318 oz]
343	-	411	10.0 kg [353 oz]
412	-	450	12.0 kg [424 oz]
451	-		14.0 kg [494 oz]

- •Piping length from heat source unit to the farthest indoor unit ≤ 30.5 m [100 ft]
- \*When connecting the CMB-P\*\*-NU-G1, CMB-P\*\*-NU-GA1, CMB-P\*\*-NU-HA1, CMB-P\*\*-NU-GB1, or CMB-P\*\*-NU-HB1 to a given system, add the amount of refrigerant as indicated in the table below.

BC controller	Amount	
G1/GA1-type	3.0 kg/unit [106 oz/unit]	
HA1-type	5.0 kg/unit [177 oz/unit]	
GB1/HB1-type	1.0 kg/unit [36 oz/unit]	

- •Piping length from heat source unit to the farthest indoor unit > 30.5 m [100 ft]
- \*When connecting the CMB-P\*\*-NU-G1, CMB-P\*\*-NU-GA1, CMB-P\*\*-NU-HA1, CMB-P\*\*-NU-GB1, or CMB-P\*\*-NU-HB1 to a given system, add the amount of refrigerant as indicated in the table below.


BC controller	Amount	
G1/GA1-type	0 kg/unit [0 oz/unit]	
HA1-type	2.0 kg/unit [71 oz/unit]	
GB1/HB1-type	1.0 kg/unit [36 oz/unit]	

- \*If the following (1) and (2) are met, add 0.55 kg [20 oz] of refrigerant per indoor unit.
- (1) When only PEFY-P18NMAU-E\*\*, PEFY-P24NMAU-E\*\*, or PEFY-P30NMAU-E\*\* are connected
- (2) When the total number of connected indoor units is 6 or less
- \*When connecting PLFY-EP18NEMU\*\*-E\*\*, PLFY-EP24NEMU\*\*-E\*\*, or PLFY-EP36NEMU\*\*-E\*\*, add 0.5 kg [18 oz] of refrigerant per indoor unit.

Round up the calculation result to the nearest 0.1 kg. (Example: 18.04 kg to 18.1 kg)

Round up the calculation result in increments of 4 oz (0.1 kg) or round it up to the nearest 1 oz. (Example: 78.21 oz to 79 oz)

### (3) Example: PQRY-P288ZSLMU



### (4) Sample calculation

		Indoor				
A: ø28.58 [1-1/8"]	40 m [131 ft]	1: P18	a:	ø6.35 [1/4"]	10 m [32 ft]	
B: ø9.52 [3/8"]	10 m [32 ft]	2: P96	b:	ø9.52 [3/8"]	10 m [32 ft]	Total capacity of indoor units: 258
C: ø12.70 [1/2"]	20 m [65 ft]	3: P06	c:	ø6.35 [1/4"]	5 m [16 ft]	Main BC controller: CMB-P108NU-JA1
D: ø9.52 [3/8"]	5 m [16 ft]	4: P06	d:	ø6.35 [1/4"]	5 m [16 ft]	Sub BC controller: CMB-P104NU-KB1 × 4
E: ø9.52 [3/8"]	5 m [16 ft]	5: P48	e:	ø9.52 [3/8"]	5 m [16 ft]	
F: ø9.52 [3/8"]	5 m [16 ft]	6: P36	f:	ø9.52 [3/8"]	5 m [16 ft]	
L: ø22.20 [7/8"]	3 m [9 ft]	7: P30	g:	ø9.52 [3/8"]	5 m [16 ft]	
M: ø22.20 [7/8"]	1 m [3 ft]	8: P18	h:	ø6.35 [1/4"]	10 m [32 ft]	
Total length for each	pipe size:	L + M C = 2 B + D	20 m [6 ) + E +	- 1 = 4 m [12 ft] 55 ft]	g = 50 m [160 ft]	
Therefore, additional	refrigerant charge	= 40 ×	).33 +	4 × 0.21 + 20 >	< 0.11 + 50 × 0.054	+ 30 × 0.021 + 3 + 0.4 × 4 + 6
	(kg)	= 30.17		kg		
		= 30.2		kg		
	or					
Therefore, additional	= 131 ×	= 131 × 3.55 + 12 × 2.26 + 65 × 1.19 + 160 × 0.59 + 96 × 0.23 + 106 + 15 × 4 + 212				
	(oz)	= 1064		OZ		

### [5] Refrigerant Amount Adjust Mode

#### 1. Procedures <PQHY>

Follow the procedures below to add or extract refrigerant as necessary depending on the operation mode.

When the function switch SW4 No.922 (SW6-10: ON) on the main board on the heat source unit (OC only) is turned to ON, the unit goes into the refrigerant amount adjust mode, and the following sequence is followed.

#### Note |

- 1) SW4-3 on the OS is invalid, and the unit will not go into the refrigerant amount adjust mode.
- 2) Refer to the relevant sections of the manual for how to set SW4 on the control board (page 142)

#### Operation

When the unit is in the refrigerant amount adjust mode, the LEV on the indoor unit does not open as fully as it normally does during cooling operation to secure subcooling.

#### Note

- 1) Adjust the refrigerant amount based on the values of TH4, TH3, TH6, and Tc, following the flowchart below. Check the TH4, TH3, TH6, and Tc values on the OC and OS by following the flowchart. The TH4, TH3, TH6, and Tc values can be displayed by setting the self-diagnosis switch SW4 (SW6-10: OFF) on the main board on the OC and OS.
- 2) There may be cases when the refrigerant amount may seem adequate for a short while after starting the unit in the refrigerant amount adjust mode but turn out to be inadequate later on (when the refrigerant system stabilizes).

#### When the amount of refrigerant is truly adequate.


TH3-TH6 on the heat source unit is 5°C [9°F] or above and SH on the indoor unit is between 5 and 15°C [9 and 27°F].

The refrigerant amount may seem adequate at the moment, but may turn out to be inadequate later on.

TH3-TH6 on the heat source unit is 5°C [9°F] or less and SH on the indoor unit is 5°C [9°F] or less.


Wait until the TH3-TH6 reaches 5°C [9°F] or above and the SH of the indoor unit is between 5 and 15°C [9 and 27°F] to determine that the refrigerant amount is adequate.

- 3) High pressure must be at least 2.0MPa[290psi] to enable a proper adjustment of refrigerant amount to be made.
- 4) Refrigerant amount adjust mode automatically ends 90 minutes after beginning. When this happens, by turning off the SW4 No.922 (SW6-10: ON) and turning them back on, the unit will go back into the refrigerant amount adjust mode.





The figure at left shows that the switches 1 through 5 are set to ON and 6 through 10 are set to OFF.



## **CAUTION**

Do not release the extracted refrigerant into the air.

### **∕!\** CAUTION

Charge liquid refrigerant (as opposed to gaseous refrigerant) into the system.

•If gaseous refrigerant is charged into the system, the composition of the refrigerant in the cylinder will change and may result in performance loss.

#### 2. Procedures <PQRY>

Follow the procedures below to add or extract refrigerant as necessary depending on the operation mode.

When the function switch SW4 No.922 (SW6-10: ON) on the main board on the heat source unit (OC only) is turned to ON, the unit goes into the refrigerant amount adjust mode, and the following sequence is followed.

#### Note

- (1) SW4-3 on the OS is invalid, and the unit will not go into the refrigerant amount adjust mode.
- (2) Refer to the relevant sections of the manual for how to set SW4 on the control board.(page 142)

### Operation

When the unit is in the refrigerant amount adjust mode, the LEV on the indoor unit does not open as fully as it normally does during cooling operation to secure subcooling.

#### Note


- 1) Adjust the refrigerant amount based on the TH4 value, following the flowchart below. Check the TH4, SC11, SC16, and Tc values on the OC, OS by following the flowchart. The TH4, SC11, and SC16 values can be displayed by setting the self-diagnosis switch SW4 (SW6-10: OFF) on the main board on the OC, OS.
- 2) There may be cases when the refrigerant amount may seem adequate for a short while after starting the unit in the refrigerant amount adjust mode but turn out to be inadequate later on (when the refrigerant system stabilizes).


#### When the amount of refrigerant is truly adequate.

Subcool (SC11 and SC16) of the BC controller is 5°C [9°F] or above and SH on the indoor unit is between 5 and 15°C [9 and 27°F].


The refrigerant amount may seem adequate at the moment, but may turn out to be inadequate later on. Subcool (SC11 and SC16) of the BC controller is 5°C [9°F] or less and SH on the indoor unit is 5°C [9°F] or less. Wait until the Subcool (SC11 and SC16) of the BC controller reaches 5°C [9°F] or above and the SH of the indoor unit is between 5 and 15°C [9 and 27°F] to determine that the refrigerant amount is adequate.

- •SC11: Subcool of liquid refrigerant at BC controller inlet; SC16: Subcool of liquid refrigerant at BC controller outlet
- 3) High pressure must be at least 2.0MPa [290psi] to enable a proper adjustment of refrigerant amount to be made.
- 4) Refrigerant amount adjust mode automatically ends 90 minutes after beginning. When this happens, by turning off the SW4 No.922 (SW6-10: ON) and turning them back on, the unit will go back into the refrigerant amount adjust mode.





The figure at left shows that the switches 1 through 5 are set to ON and 6 through 10 are set to OFF.



### **CAUTION**

Do not release the extracted refrigerant into the air.

## A

#### CAUTION

Charge liquid refrigerant (as opposed to gaseous refrigerant) into the system.

•If gaseous refrigerant is charged into the system, the composition of the refrigerant in the cylinder will change and may result in performance loss.

### [6] The following symptoms are normal.

Г		
Symptoms	Remote controller display	Cause
The indoor unit does not start after starting cooling (heating) operation.	"Cooling (heating)" icon blinks on the display.	The unit cannot perform a heating (cooling) operation when other indoor units are performing a cooling (heating) operation.
The auto vane adjusts its position by itself.	Normal display	After an hour of cooling operation with the auto vane in the vertical position, the vane may automatically move into the horizontal position. Louver blades will automatically move into the horizontal position while the unit is in the defrost mode, pre-heating stand-by mode, or when the thermostat triggers unit off.
The fan keeps running after the unit has stopped.	Unlit	When the auxiliary heater is turned on, the fan operates for one minute after stopping to dissipate heat.
The fan speed does not reach the set speed when operation switch is turned on.	STAND BY	The fan operates at extra low speed for 5 minutes after it is turned on or until the pipe temperature reaches 35°C[95°F], then it operates at low speed for 2 minutes, and finally it operates at the set speed. (Pre-heating stand-by)
When the main power is turned on, the display shown on the right appears on the indoor unit remote controller for 5 minutes.	"HO" or "PLEASE WAIT" icons blink on the display.	The system is starting up. Wait until the blinking display of "HO" or "PLEASE WAIT" go off.
The drain pump keeps running after the unit has stopped.	Unlit	The drain pump stays in operation for three minutes after the unit in the cooling mode is stopped.
The drain pump is running while the unit is stopped.	Unlit	When drain water is detected, the drain pump goes into operation even while the unit is stopped.
Indoor unit and BC controller make noise during cooling/ heating changeover.	Normal display	This noise is made when the refrigerant circuit is reversed and is normal.
Sound of the refrigerant flow is heard from the indoor unit immediately after starting operation.	Normal display	This is caused by the transient instability of the refrigerant flow and is normal.
Warm air sometimes comes out of the indoor units that are not in the heating mode.	Normal display	This is due to the fact that the LEVs on some of the indoor units are kept slightly open to prevent the refrigerant in the indoor units that are not operating in the heating mode from liquefying and accumulating in the compressor. It is part of a normal operation.

### [7] Standard Operation Data (Reference Data)

### 1. Single unit <PQHY>

### (1) Cooling operation

		Item		Heat source unit model			
		item		PQHY-P72ZLMU-A1/B	PQHY-P96ZLMU-A1/B		
	Indoor te	emperature	DB/WB	26.7°C/19.4°C [80°F/67°F]	26.7°C/19.4°C [80°F/67°F]		
	Heat sou	urce water temperature	°C [ °F]	29.4[85]	29.4[85]		
Operating conditions	Heat sou	urce water flow rate	m <sup>3</sup> /h [G/h] [gpm]	5.76 [1522] [25.4]	5.76 [1522] [25.4]		
		No. of connected units	Unit	2	2		
	Indoor unit	No. of units in operation	Offic	2	2		
		Model	-	36/36	48/48		
		Main pipe		5 [16-3/8]	5 [16-3/8]		
	Pipe length	Branch pipe	m [ft]	10 [32-3/4]	10 [32-3/4]		
		Total pipe length		25 [82]	25 [82]		
	Fan speed		-	Hi	Hi		
	Refrigerant charge		kg [lbs-oz]	11.8 [27]	13.0 [29]		
	Current		Α	7.0	9.3		
Heat source unit	Voltage		V	575	575		
	Compre	ssor frequency	Hz	66	90		
	Indoor u	nit		325/325	387/387		
I EV anoning	SC (LEV1)		Dulas	80	100		
LEV opening	LEV6		Pulse	41	41		
	LEV7			3000	3000		
Pressure switch	High pre	essure (after O/S)/ ssure (before accumulator)	MPa [psi]	2.20/0.81 [319/117]	2.27/0.81 [329/117]		
		Discharge (TH4)		65 [149]	65 [149]		
		Heat exchanger outlet		33 [91]	34 [93]		
	Heat	Accumulator inlet		8 [46]	8 [46]		
Sectional	source unit	Accumulator outlet	°C [°F]	8 [46]	8 [46]		
temperatures		Compressor inlet		19 [66]	19 [66]		
		Compressor shell bottom		47 [117]	40 [104]		
	Indoor	LEV inlet		19 [66]	19 [66]		
	unit	Heat exchanger outlet		6 [43]	6 [43]		

		Itam		Heat source unit model			
		Item		PQHY-P120ZLMU-A1/B	PQHY-P144ZLMU-A1/B		
	Indoor te	emperature	DB/WB	26.7°C/19.4°C [80°F/67°F]	26.7°C/19.4°C [80°F/67°F]		
	Heat sou	ırce water temperature	°C [ °F]	29.4[85]	29.4[85]		
Operating conditions	Heat sou	ırce water flow rate	m <sup>3</sup> /h [G/h] [gpm]	5.76 [1522] [25.4]	7.20 [1902] [31.7]		
		No. of connected units	Unit	3	4		
	Indoor unit	No. of units in operation	Offic	3	4		
		Model	-	36/36/48	36/36/36/36		
		Main pipe		5 [16-3/8]	5 [16-3/8]		
	Pipe length	Branch pipe	m [ft]	10 [32-3/4]	10 [32-3/4]		
		Total pipe length		35 [115]	45 [148]		
	Fan spe	ed	-	Hi	Hi		
	Refrigerant charge		kg [lbs-oz]	13.6 [30]	16.3 [36]		
	Current		Α	9.5	9.7		
Heat source unit	Voltage		V	575	575		
	Compres	ssor frequency	Hz	114	82		
	Indoor u	nit	Pulse	325/325/387	325/325/325/325		
LEV opening	SC (LEV	<b>71</b> )		100	160		
LL v opening	LEV6			41	41		
	LEV7			3000	3000		
Pressure switch	High pre Low pres	ssure (after O/S)/ ssure (before accumulator)	MPa [psi]	2.30/0.81 [334/117]	2.36/0.81 [342/117]		
		Discharge (TH4)		65 [149]	65 [149]		
		Heat exchanger outlet		35 [95]	36 [97]		
	Heat	Accumulator inlet		8 [46]	8 [46]		
Sectional	source unit	Accumulator outlet	°C [°F]	8 [46]	8 [46]		
temperatures		Compressor inlet	ا دا ا	19 [66]	19 [66]		
		Compressor shell bottom		42 [108]	42 [108]		
	Indoor	LEV inlet		19 [66]	19 [66]		
	unit	Heat exchanger outlet		6 [43]	6 [43]		

		Item	Heat source unit model				
		item		PQHY-P168ZLMU	-A1/B	PQHY-P192	ZLMU-A1/B
	Indoor te	emperature	DB/WB	26.7°C/19.4°C [80°F/67°F]		26.7°C/ [80°F/	
	Heat sou	ırce water temperature	°C [ °F]	29.4[85]		29.4	[85]
	Heat sou	ırce water flow rate	m <sup>3</sup> /h [G/h] [gpm]	7.20 [1902] [31.7]		7.: [19 [31	02]
		No. of connected units	Unit	4		4	1
Operating conditions	Indoor unit	No. of units in operation	Offic	4		4	1
		Model	-	36/36/48/48		48/48/	/48/48
		Main pipe		5 [16-3/	/8 ]	5	[16-3/8]
	Pipe length	Branch pipe	m [ft]	10 [32-3/	/4 ]	10	[32-3/4]
		Total pipe length		45 [148]		45	[148]
	Fan spe	ed	-	Hi		Hi	
	Refrigera	ant charge	kg [lbs-oz]	19.1 [43]		20.6	[46]
	Current		Α	13.4		16	5.7
Heat source unit	Voltage		V	575		57	75
	Compres	ssor frequency	Hz	97		11	12
	Indoor u	nit	- Pulse	325/325/387/38	37	387/387	/387/387
LEV opening	SC (LEV	<b>7</b> 1)		180		20	00
LEV opening	LEV6			41		4	1
	LEV7			3000		30	00
Pressure switch		ssure (after O/S)/ ssure (before accumulator)	MPa [psi]	2.48/0.81 [360/	117]	2.56/0.81	[371/117]
		Discharge (TH4)		65 [149]		65	[149]
		Heat exchanger outlet		38 [100]		39	[102]
	Heat source	Accumulator inlet		8 [46]		8	[46]
Sectional	unit	Accumulator outlet	°C [°F]	8 [46]		8	[46]
temperatures		Compressor inlet	∪ [ F]	19 [66]		19	[66]
		Compressor shell bottom		42 [108]		42	[108]
	Indoor	LEV inlet		19 [66]		19	[66]
	unit	Heat exchanger outlet		6 [43]		6	[43]

### (2) Heating operation

		Item		Heat s	source unit model
		item		PQHY-P72ZLMU-A1	/B PQHY-P96ZLMU-A1/E
	Indoor te	emperature	DB/WB	21.1°C/- [70°F/-]	21.1°C/- [70°F/-]
	Heat sou	urce water temperature	°C [ °F]	21.1[70]	21.1[70]
	Heat sou	urce water flow rate	m <sup>3</sup> /h [G/h] [gpm]	5.76 [1522] [25.4]	5.76 [1522] [25.4]
		No. of connected units	1.1	2	2
Operating conditions	Indoor unit	No. of units in operation	Unit	2	2
		Model	-	36/36	48/48
		Main pipe		5 [16-3/8]	5 [16-3/8]
	Pipe length	Branch pipe	m [ft]	10 [32-3/4]	10 [32-3/4]
		Total pipe length		25 [82]	25 [82]
	Fan spe	ed	-	Hi	Hi
	Refriger	ant charge	kg [lbs-oz]	11.8 [27]	13.0 [29]
	Current		Α	7.4	10.0
Heat source unit	Voltage		V	575	575
	Compre	ssor frequency	Hz	60	72
	Indoor u	nit		332/332	406/406
LEV opening	SC (LEV	SC (LEV1)		0	0
LEV opening	LEV6	LEV6		68	84
	LEV7			3000	3000
Pressure switch		ssure (after O/S)/ ssure (before accumulator)	MPa [psi]	2.64/0.80 [383/116	2.90/0.80 [421/116]
		Discharge (TH4)		73 [163]	80 [176]
		Heat exchanger outlet		5 [41]	5 [41]
	Heat source	Accumulator inlet		4 [39]	4 [39]
Sectional	source unit	Accumulator outlet	°C [°F]	4 [39]	4 [39]
temperatures		Compressor inlet		4 [39]	4 [39]
		Compressor shell bottom		40 [104]	40 [104]
	Indoor	LEV inlet		37 [99]	38 [100]
	unit Heat exchanger inlet			70 [158]	70 [158]

		и		Heat source unit model		
		Item		PQHY-P120ZLMU-A1/B	PQHY-P144ZLMU-A1/B	
	Indoor te	mperature	DB/WB	21.1°C/- [70°F/-]	21.1°C/- [70°F/-]	
	Heat sou	rce water temperature	°C [ °F]	21.1[70]	21.1[70]	
	Heat sou	irce water flow rate	m <sup>3</sup> /h [G/h] [gpm]	5.76 [1522] [25.4]	7.20 [1902] [31.7]	
		No. of connected units	Llmit	3	4	
Operating	Indoor unit	No. of units in operation	Unit	3	4	
conditions		Model	-	36/36/48	36/36/36	
		Main pipe		5 [16-3/8]	5 [16-3/8]	
	Pipe length	Branch pipe	m [ft]	10 [32-3/4]	10 [32-3/4]	
		Total pipe length		35 [115]	45 [148]	
	Fan spe	ed	-	Hi	Hi	
	Refrigerant charge		kg [lbs-oz]	13.6 [30]	16.3 [36]	
	Current		Α	11.3	11.6	
Heat source unit	Voltage		V	575	575	
	Compres	ssor frequency	Hz	90	75	
	Indoor u	nit		332/332/406	332/332/332/332	
LEV opening	SC (LEV1)		Pulse -	0	0	
LLV opening	LEV6			122	136	
	LEV7			3000	3000	
Pressure switch	High pre Low pres	ssure (after O/S)/ ssure (before accumulator)	MPa [psi]	2.68/0.80 [389/116]	2.54/0.80 [368/116]	
		Discharge (TH4)		81 [178]	77 [171]	
		Heat exchanger outlet		5 [41]	5 [41]	
	Heat source	Accumulator inlet		4 [39]	4 [39]	
Sectional	unit	Accumulator outlet	°C [°F]	4 [39]	4 [39]	
temperatures		Compressor inlet	○[ F]	4 [39]	4 [39]	
		Compressor shell bottom		40 [104]	40 [104]	
	Indoor	LEV inlet		39 [102]	36 [97]	
	unit	Heat exchanger inlet		70 [158]	70 [158]	

		II.		Heat source unit model		
		Item		PQHY-P168ZLMU-A1/B	PQHY-P192ZLMU-A1/B	
	Indoor te	mperature	DB/WB	21.1°C/- [70°F/-]	21.1°C/- [70°F/-]	
	Heat sou	rce water temperature	°C [ °F]	21.1[70]	21.1[70]	
	Heat sou	irce water flow rate	m <sup>3</sup> /h [G/h] [gpm]	7.20 [1902] [31.7]	7.20 [1902] [31.7]	
		No. of connected units	l lmit	4	4	
Operating	Indoor unit	No. of units in operation	Unit	4	4	
conditions		Model	-	36/36/48/48	48/48/48	
		Main pipe		5 [16-3/8]	5 [16-3/8]	
	Pipe length	Branch pipe	m [ft]	10 [32-3/4]	10 [32-3/4]	
		Total pipe length		45 [148]	45 [148]	
	Fan spe	ed	-	Hi	Hi	
	Refrigerant charge		kg [lbs-oz]	19.1 [43]	20.6 [46]	
	Current		Α	16.0	19.9	
Heat source unit	Voltage		V	575	575	
	Compres	ssor frequency	Hz	82	90	
	Indoor u	nit		332/332/406/406	406/406/406/406	
LEV opening	SC (LEV	SC (LEV1)		0	0	
LEV opening	LEV6	LEV6		152	168	
	LEV7			3000	3000	
Pressure switch	High pre Low pres	ssure (after O/S)/ ssure (before accumulator)	MPa [psi]	2.62/0.80 [380/116]	2.64/0.80 [383/116]	
		Discharge (TH4)		77 [171]	80 176	
		Heat exchanger outlet		5 [41]	5 [41]	
	Heat source	Accumulator inlet		4 [39]	4 [39]	
Sectional	unit	Accumulator outlet	°C [°F]	4 [39]	4 [39]	
temperatures		Compressor inlet	∪[ r]	4 [39]	4 [39]	
		Compressor shell bottom		40 [104]	40 [104]	
	Indoor	LEV inlet		37 [99]	37 [99]	
	unit	Heat exchanger inlet		70 [158]	70 [158]	

### 2. 2-unit combination <PQHY>

### (1) Cooling operation

				2-unit combination				
		Item			PQHY-P144Z	ZSLMU-A1/B		
				PQHY-P72	PQHY-P72ZLMU-A1/B PQHY-P72ZLMU-A			
	Indoor te	mperature	DB/WB		26.7°C/19.4°	C[80°F/67°F]		
	Heat sou	rce water temperature	°C [ °F]		29.4	[85]		
	Heat sou	rce water flow rate	m <sup>3</sup> /h G/h gpm	[15	76 [22] [5.4]	5.76 [1522] [25.4]		
		No. of connected units	Unit		4			
Operating	Indoor unit	No. of units in operation	Onic		4			
conditions		Model	-		36/36/	36/36		
		Main pipe			5	[16-3/8]		
	Pipe length	Branch pipe	m [ft]	10 [32-3/4]				
		Total pipe length		45 [148]				
	Fan speed		-		Hi			
	Refrigerant charge		kg [lbs-oz]	20.3 [45]				
	Current		Α	16.9				
Heat source unit	Voltage		V	575				
	Compres	ssor frequency	Hz	66		66		
	Indoor u	nit		325/325/325				
LEV opening	SC (LEV	1)	Pulse	80		80		
LEV opening	LEV6		ruise	41		41		
	LEV7			3000		3000		
Pressure switch	High pre Low pres	ssure (after O/S)/ ssure (before accumulator)	MPa [psi]	2.20/0.81	[319/117]	2.20/0.81 [319/117]		
		Discharge (TH4)		65	[149]	65 [149]		
		Heat exchanger outlet		33	[91]	33 [91]		
	Heat	Accumulator inlet		8	[46]	8 [46]		
Sectional	source unit	Accumulator outlet	°C [°F]	8	[46]	8 [46]		
temperatures		Compressor inlet	○[F]	19	[66]	19 [66]		
		Compressor shell bottom		47	[117]	47 [117]		
	Indoor	LEV inlet			19	[66]		
	unit	Heat exchanger outlet			6	[43]		

				2-unit combination				
		Item			PQHY-P1682	ZSLMU-A1/B		
				PQHY-P96	ZLMU-A1/B	PQHY-P72	ZLMU-A1/B	
	Indoor te	emperature	DB/WB		26.7°C/19.4°	C[80°F/67°F]		
	Heat sou	irce water temperature	°C [ °F]		29.4	[85]		
	Heat sou	ırce water flow rate	m <sup>3</sup> /h G/h gpm	[15	76 [22] [5.4]	[15	76 [22] [5.4]	
		No. of connected units	Unit		4			
Operating	Indoor unit	No. of units in operation	Offic		4			
conditions		Model	-		36/36/	48/48		
		Main pipe			5	[16-3/8]		
	Pipe length	Branch pipe	m [ft]	10 [32-3/4]				
		Total pipe length		45 [148]				
	Fan spe	ed	-	Hi				
	Refrigerant charge		kg [lbs-oz]	23.1 [51]				
	Current		Α	16.9				
Heat source unit	Voltage		V	575				
	Compressor frequency		Hz	78		78		
	Indoor u	nit			325/325/	387/387		
LEV opening	SC (LEV1)		Pulse	90		90		
LEV opening	LEV6			41		41		
	LEV7			3000		3000		
Pressure switch	High pre Low pres	ssure (after O/S)/ ssure (before accumulator)	MPa [psi]	2.23/0.81	[323/117]	2.23/0.81	[323/117]	
		Discharge (TH4)		65	[149]	65	[149]	
		Heat exchanger outlet		33	[91]	33	[91]	
	Heat	Accumulator inlet		8	[46]	8	[46]	
Sectional	source unit	Accumulator outlet	°C [°F]	8	[46]	8	[46]	
temperatures		Compressor inlet		19	[66]	19	[66]	
		Compressor shell bottom		40	[104]	47	[117]	
		LEV inlet	1	19 [66]				
	Indoor unit	LEV IIIIet			13	լսսյ		

				2-unit combination				
		Item			PQHY-P1922	ZSLMU-A1/B		
				PQHY-P96ZLMU-A1/B PQHY-P96ZLMU-A1			ZLMU-A1/B	
	Indoor te	mperature	DB/WB		26.7°C/19.4°0	C[80°F/67°F]		
	Heat sou	irce water temperature	°C [ °F]		29.4	[85]		
	Heat sou	ırce water flow rate	m <sup>3</sup> /h G/h gpm	[15	76 [22] [5.4]	[15	76 22] 5.4]	
		No. of connected units	Linit		4			
Operating	Indoor unit	No. of units in operation	Unit		4	ļ		
conditions		Model	-		48/48/	48/48		
		Main pipe			5	[16-3/8]		
	Pipe length	Branch pipe	m [ft]	10 [32-3/4]				
	longar	Total pipe length		45 [148]				
	Fan speed		-	Hi				
	Refrigerant charge		kg [lbs-oz]	24.6 [54]				
	Current		Α	20.7				
Heat source unit	Voltage		V	575				
<b>35</b>	Compressor frequency		Hz	90		90		
	Indoor u	nit		387/387/387				
15//	SC (LEV	(1)	Dulas	100		100		
LEV opening	LEV6		- Pulse -	41		41		
	LEV7			3000		3000		
Pressure switch	High pre	ssure (after O/S)/ ssure (before accumulator)	MPa [psi]	2.27/0.81	[329/117]	2.27/0.81	[329/117]	
		Discharge (TH4)		65	[149]	65	[149]	
		Heat exchanger outlet		34	[93]	34	[93]	
	Heat	Accumulator inlet		8	[46]	8	[46]	
Sectional	unit	Accumulator outlet	°C (°E1	8	[46]	8	[46]	
temperatures		Compressor inlet	°C [°F]	19	[66]	19	[66]	
		Compressor shell bottom		40	[104]	40	[104]	
	Indoor	LEV inlet			19	[66]		
	unit Heat exchanger outlet							

					2-unit con	nbination		
		Item			PQHY-P2162	ZSLMU-A1/B		
				PQHY-P120	ZLMU-A1/B	PQHY-P96	ZLMU-A1/B	
	Indoor te	emperature	DB/WB		26.7°C/19.4°	C[80°F/67°F]		
	Heat sou	irce water temperature	°C [ °F]		29.4	[85]		
	Heat sou	ırce water flow rate	m <sup>3</sup> /h G/h gpm	[15	76 [22] [5.4]	[15	76 22] 5.4]	
		No. of connected units	Unit		5	j		
Operating	Indoor unit	No. of units in operation	Offic		5	j		
conditions		Model	-		36/36/4	8/48/48		
		Main pipe			5	[16-3/8]		
	Pipe length	Branch pipe	m [ft]	10 [32-3/4]				
		Total pipe length		65 [213-1/4]				
	Fan speed		-	Hi				
	Refrigerant charge		kg [lbs-oz]	26.2 [58]				
	Current		Α	20.8				
Heat source unit	Voltage		V	575				
	Compressor frequency		Hz	98		9	8	
	Indoor u	nit			325/325/38	37/387/387		
LEV opening	SC (LEV1)		Pulse	159		159		
LEV opening	LEV6			41		41		
	LEV7			3000		3000		
Pressure switch		ssure (after O/S)/ ssure (before accumulator)	MPa [psi]	2.28/0.81	[331/117]	2.28/0.81	[331/117]	
		Discharge (TH4)		65	[149]	65	[149]	
		Heat exchanger outlet		35	[95]	35	[95]	
	Heat	Accumulator inlet		8	[46]	8	[46]	
Sectional	source unit	Accumulator outlet	°C [°F]	8	[46]	8	[46]	
temperatures		Compressor inlet	○[ F]	19	[66]	19	[66]	
		Compressor shell bottom		42	[108]	40	[104]	
	Indoor	LEV inlet			19	[66]		
	unit Heat exchanger outlet				6	[43]		

					2-unit con	nbination		
		Item			PQHY-P2402	ZSLMU-A1/B		
				PQHY-P120	ZLMU-A1/B	PQHY-P120	ZLMU-A1/B	
	Indoor te	emperature	DB/WB		26.7°C/19.4°	C[80°F/67°F]		
	Heat sou	irce water temperature	°C [ °F]		29.4	[85]		
	Heat sou	ırce water flow rate	m <sup>3</sup> /h G/h gpm	[15	76 [22] [5.4]	[15	76 22] 5.4]	
		No. of connected units	Unit		6	3		
Operating	Indoor unit	No. of units in operation	Unit		6	6		
conditions		Model	-		36/36/36/	36/48/48		
		Main pipe			5	[16-3/8]		
	Pipe length	Branch pipe	m [ft]	10 [32-3/4]				
		Total pipe length		65 [213-1/4]				
	Fan spe	ed	-	Hi				
	Refrigerant charge		kg [lbs-oz]	26.2 [58]				
	Current		Α	22.7				
Heat source unit	Voltage		V	575				
	Compressor frequency		Hz	105		10	)5	
	Indoor u	nit		325/325/325/387/387				
LEV opening	SC (LEV1)		Pulse	159		159		
LL v opening	LEV6			41		41		
	LEV7			3000		3000		
Pressure switch		ssure (after O/S)/ ssure (before accumulator)	MPa [psi]	2.30/0.81	[334/117]	2.30/0.81	[334/117]	
		Discharge (TH4)		65	[149]	65	[149]	
		Heat exchanger outlet		35	[95]	35	[95]	
	Heat	Accumulator inlet		8	[46]	8	[46]	
Sectional	source unit	Accumulator outlet	°C [°E]	8	[46]	8	[46]	
temperatures		Compressor inlet	°C [°F]	19	[66]	19	[66]	
		Compressor shell bottom		42	[108]	42	[108]	
	Indoor	LEV inlet			19	[66]		
	unit Heat exchanger outlet				6	[43]		

				2-unit combination				
		Item			PQHY-P2882	ZSLMU-A1/B		
				PQHY-P144	IZLMU-A1/B	PQHY-P144	ZLMU-A1/B	
	Indoor te	emperature	DB/WB		26.7°C/19.4°	C[80°F/67°F]		
	Heat sou	irce water temperature	°C [ °F]		29.4	[85]		
	Heat sou	ırce water flow rate	m <sup>3</sup> /h G/h gpm	[19	20  02]  1.7]	7. [19 [31		
		No. of connected units	l lmit		6	;		
Operating	Indoor unit	No. of units in operation	Unit		6	6		
conditions		Model	-		48/48/48/	48/48/48		
		Main pipe			5	[16-3/8]		
	Pipe length	Branch pipe	m [ft]	10 [32-3/4]				
	longar	Total pipe length		65 [213-1/4]				
	Fan spe	ed	-	Hi				
	Refrigerant charge		kg [lbs-oz]	22.5 [50]				
	Current		Α	22.7				
Heat source unit	Voltage		V	575				
4	Compressor frequency		Hz	84		84		
	Indoor u	nit		387/387/387/387/387				
L EV ananing	SC (LEV	<b>7</b> 1)	Dulas	234		234		
LEV opening	LEV6		Pulse	41		41		
	LEV7			3000		3000		
Pressure switch	High pre	ssure (after O/S)/ ssure (before accumulator)	MPa [psi]	2.36/0.81	[342/117]	2.36/0.81	[342/117]	
		Discharge (TH4)		65	[149]	65	[149]	
		Heat exchanger outlet		36	[93]	36	[93]	
	Heat	Accumulator inlet		8	[46]	8	[46]	
Sectional	source unit	Accumulator outlet	°C [°C]	8	[46]	8	[46]	
temperatures		Compressor inlet	°C [°F]	19	[66]	19	[66]	
		Compressor shell bottom		40	[104]	40	[104]	
	Indoor	LEV inlet			19	[66]		
	unit Heat exchanger outlet							

				2-unit combination				
		Item		PQHY-P312ZSLMU-A1/B				
				PQHY-P168	BZLMU-A1/B	PQHY-P144	ZLMU-A1/B	
	Indoor te	emperature	DB/WB		26.7°C/19.4°	C[80°F/67°F]		
	Heat sou	irce water temperature	°C [ °F]		29.4	[85]		
	Heat sou	ırce water flow rate	m <sup>3</sup> /h G/h gpm	[19	20  02]  1.7]	[19	20 02] .7]	
		No. of connected units	l lmit		6	;		
Operating	Indoor unit	No. of units in operation	Unit		6	6		
conditions		Model	-		54/54/54/	54/48/48		
		Main pipe			5	[16-3/8]		
	Pipe length	Branch pipe	m [ft]	10 [32-3/4]				
	longar	Total pipe length		65 [213-1/4]				
	Fan spe	ed	-	Hi				
	Refrigerant charge		kg [lbs-oz]	22.5 [50]				
	Current		Α	26.0				
Heat source unit	Voltage		V	575				
4	Compressor frequency		Hz	89		89		
	Indoor u	nit		395/395/395/387/387				
151/	SC (LEV1)		Dulaa	234		234		
LEV opening	LEV6		Pulse	41		41		
	LEV7			3000		3000		
Pressure switch		ssure (after O/S)/ ssure (before accumulator)	MPa [psi]	2.42/0.81	[351/117]	2.42/0.81	[351/117]	
		Discharge (TH4)		65	[149]	65	[149]	
		Heat exchanger outlet		37	[93]	37	[93]	
	Heat	Accumulator inlet		8	[46]	8	[46]	
Sectional	source unit	Accumulator outlet	°C (°E)	8	[46]	8	[46]	
temperatures		Compressor inlet	°C [°F]	19	[66]	19	[66]	
		Compressor shell bottom		40	[104]	40	[104]	
	Indoor	LEV inlet			19	[66]		
	unit Heat exchanger outlet				6	[43]		

				2-unit combination				
		Item			PQHY-P3362	ZSLMU-A1/B		
				PQHY-P168	BZLMU-A1/B	PQHY-P168	BZLMU-A1/B	
	Indoor te	emperature	DB/WB		26.7°C/19.4°	C[80°F/67°F]		
	Heat sou	irce water temperature	°C [ °F]		29.4	[85]		
	Heat sou	ırce water flow rate	m <sup>3</sup> /h G/h gpm	[19	20  02]  1.7]	[19	20 02] .7]	
		No. of connected units	Unit		7	,		
Operating	Indoor unit	No. of units in operation	Offic		7	,		
conditions		Model	-		48/48/48/4	8/48/48/48		
		Main pipe			5	[16-3/8]		
	Pipe length	Branch pipe	m [ft]	10 [32-3/4]				
		Total pipe length		65 [213-1/4]				
	Fan speed		-	Hi				
	Refrigerant charge		kg [lbs-oz]	23.5 [52]				
	Current		Α	29.9				
Heat source unit	Voltage		V	575				
	Compressor frequency		Hz	93		9	3	
	Indoor u	nit			387/387/387/38	37/387/387/387		
L EV ananing	SC (LEV	SC (LEV1)		234		234		
LEV opening	LEV6		Pulse	41		41		
	LEV7			3000		3000		
Pressure switch	High pre	ssure (after O/S)/ ssure (before accumulator)	MPa [psi]	2.48/0.81	[360/117]	2.48/0.81	[360/117]	
		Discharge (TH4)		65	[149]	65	[149]	
		Heat exchanger outlet		38	[95]	38	[95]	
	Heat	Accumulator inlet		8	[46]	8	[46]	
Sectional	source unit	Accumulator outlet	°C [°E]	8	[46]	8	[46]	
temperatures		Compressor inlet	°C [°F]	19	[66]	19	[66]	
		Compressor shell bottom		40	[104]	40	[104]	
	Indoor	LEV inlet			19	[66]		
	unit Heat exchanger outlet		1					

					2-unit con	nbination		
		Item			PQHY-P3602	ZSLMU-A1/B		
				PQHY-P192	ZLMU-A1/B	PQHY-P168	BZLMU-A1/B	
	Indoor te	emperature	DB/WB		26.7°C/19.4°	C[80°F/67°F]		
	Heat sou	irce water temperature	°C [ °F]	29.4[85]				
	Heat source water flow rate		m <sup>3</sup> /h G/h gpm	7.20 [1902] [31.7]		[19	20 02] .7]	
		No. of connected units	Unit		7	7		
Operating	Indoor unit	No. of units in operation	Offic		7	7		
conditions		Model	-		54/54/54/5	4/48/48/48		
		Main pipe			5	[16-3/8]		
	Pipe length	Branch pipe	m [ft]		10	[32-3/4]		
		Total pipe length		75 [246-1/16]				
	Fan spe	ed	-		Hi			
	Refrigerant charge		kg [lbs-oz]		23.8	[53]		
	Current	Current			32	.8		
Heat source unit	Voltage	Voltage			57	<b>'</b> 5		
	Compres	Compressor frequency		9	98		8	
	Indoor u	nit		395/395/395/395/387/387			,	
LEV opening	SC (LEV	<b>'</b> 1)	Pulse	150		150		
LEV opening	LEV6		ruise	41		41		
	LEV7			3000		30	00	
Pressure switch	High pre Low pres	ssure (after O/S)/ ssure (before accumulator)	MPa [psi]	2.52/0.81	[365/117]	2.52/0.81	[365/117]	
		Discharge (TH4)		65	[149]	65	[149]	
		Heat exchanger outlet		39	[95]	39	[95]	
	Heat	Accumulator inlet		8	[46]	8	[46]	
Sectional	source unit	Accumulator outlet	°C [°F]	8	[46]	8	[46]	
temperatures		Compressor inlet	○[ F]	19	[66]	19	[66]	
		Compressor shell bottom	<del> </del>	42	[108]	42	[108]	
	Indoor	LEV inlet			19	[66]		
	unit	Heat exchanger outlet			6	[43]		

## (2) Heating operation

					2-unit con	nbination		
		Item			PQHY-P144Z	ZSLMU-A1/B		
				PQHY-P72	ZLMU-A1/B	PQHY-P72ZLMU-A1/B		
	Indoor te	mperature	DB/WB		21.1°C/-	[70°F/-]		
	Heat sou	rce water temperature	°C [ °F]	21.1[70]				
	Heat source water flow rate		m <sup>3</sup> /h G/h gpm	5.76 [1522] [25.4]		5.76 [1522] [25.4]		
		No. of connected units	Unit		4			
Operating	Indoor unit	No. of units in operation	Offic		4			
conditions		Model	-		36/36/	36/36		
		Main pipe			5	[16-3/8]		
	Pipe length	Branch pipe	m [ft]		10	[32-3/4]		
		Total pipe length		45 [148]				
	Fan spee	ed	-		Н	łi		
	Refrigerant charge		kg [lbs-oz]		20.3	[45]		
	Current		Α		17	.7		
Heat source unit	Voltage		V		575			
	Compres	ssor frequency	Hz	60		60		
	Indoor u	nit		332/332/332		332/332		
LEV eneming	SC (LEV	1)	Pulse	0		0		
LEV opening	LEV6		Pulse	68		68		
	LEV7			3000		3000		
Pressure switch		ssure (after O/S)/ ssure (before accumulator)	MPa [psi]	2.64/0.80	[383/116]	2.64/0.80 [383/116]		
		Discharge (TH4)		77	[171]	77 [171]		
		Heat exchanger outlet		5	[41]	5 [41]		
	Heat	Accumulator inlet		4	[39]	4 [39]		
Sectional	source unit	Accumulator outlet	°C [°F]	4	[39]	4 [39]		
temperatures		Compressor inlet	∪ [ F]	4	[39]	4 [39]		
		Compressor shell bottom	_ n	40	[104]	40 [104]		
	Indoor	LEV inlet			37	[99]		
	unit	Heat exchanger inlet			70	[158]		

					2-unit con	nbination		
		Item			PQHY-P168Z	ZSLMU-A1/B		
				PQHY-P96	ZLMU-A1/B	PQHY-P72	ZLMU-A1/B	
	Indoor te	emperature	DB/WB		21.1°C/-	[70°F/-]		
	Heat sou	irce water temperature	°C [ °F]	21.1[70]				
	Heat sou	Heat source water flow rate		5.76 [1522] [25.4]		[15	76 [22] [5.4]	
		No. of connected units	Unit		4			
Operating	Indoor unit	No. of units in operation	Offic		4			
conditions		Model	-	36/36/48/48				
		Main pipe			5	[16-3/8]		
	Pipe length	Branch pipe	m [ft]	10 [32-3/4]				
	lg	Total pipe length		45 [148]				
	Fan spe	ed	-		Hi			
	Refrigera	Refrigerant charge			23.1	[51]		
	Current		Α		17	.7		
Heat source unit	Voltage	Voltage			57	<b>'</b> 5		
	Compressor frequency		Hz	66		6	6	
	Indoor u	nit		332/332/406/406				
L EV an anima	SC (LEV	<b>′</b> 1)	Pulse	0		0		
LEV opening	LEV6		Puise	84		68		
	LEV7			3000		3000		
Pressure switch	High pre	ssure (after O/S)/ ssure (before accumulator)	MPa [psi]	2.80/0.80	[406/116]	2.80/0.80	[406/116]	
		Discharge (TH4)		77	[171]	77	[171]	
		Heat exchanger outlet		5	[41]	5	[41]	
	Heat	Accumulator inlet		4	[39]	4	[39]	
Sectional	source unit	Accumulator outlet	°C (°E1	4	[39]	4	[39]	
temperatures		Compressor inlet	°C [°F]	4	[39]	4	[39]	
		Compressor shell bottom	 n	40	[104]	40	[104]	
	Indoor	LEV inlet			37	[99]		
	unit	Heat exchanger inlet				[158]		

					2-unit con	nbination		
		Item			PQHY-P1922	ZSLMU-A1/B		
				PQHY-P962	ZLMU-A1/B	PQHY-P96	ZLMU-A1/B	
	Indoor te	emperature	DB/WB		21.1°C/-	[70°F/-]		
	Heat sou	ırce water temperature	°C [ °F]	21.1[70]				
	Heat sou	Heat source water flow rate		5.76 [1522] [25.4]		[15	76 [22] [5.4]	
		No. of connected units	Unit		4			
Operating	Indoor unit	No. of units in operation	Offic		4			
conditions		Model	-	48/48/48				
		Main pipe			5	[16-3/8]		
	Pipe length	Branch pipe	m [ft]	10 [32-3/4]				
		Total pipe length		45 [148]				
	Fan spe	ed	-		Hi			
	Refrigera	Refrigerant charge			24.6	[54]		
	Current	Current			20	.4		
Heat source unit	Voltage	Voltage			57	75		
	Compres	Compressor frequency		72		7	2	
	Indoor u	Indoor unit			406/406/	406/406		
L EV an anima	SC (LEV	<b>71</b> )	Pulse	0		0		
LEV opening	LEV6		Puise	84		84		
	LEV7			3000		3000		
Pressure switch	High pre	ssure (after O/S)/ ssure (before accumulator)	MPa [psi]	2.90/0.80	[421/116]	2.90/0.80	[421/116]	
		Discharge (TH4)		80	[176]	80	[176]	
		Heat exchanger outlet		5	[41]	5	[41]	
	Heat	Accumulator inlet		4	[39]	4	[39]	
Sectional	source unit	Accumulator outlet	°C [°E]	4	[39]	4	[39]	
temperatures		Compressor inlet	°C [°F]	4	[39]	4	[39]	
		Compressor shell bottom	n l	40	[104]	40	[104]	
	Indoor	LEV inlet			37	[99]		
	unit	Heat exchanger inlet				[158]		

					2-unit con	nbination		
		Item			PQHY-P216Z	ZSLMU-A1/B		
				PQHY-P120	ZLMU-A1/B	PQHY-P96	ZLMU-A1/B	
	Indoor te	mperature	DB/WB		21.1°C/-	[70°F/-]		
	Heat sou	rce water temperature	°C [ °F]	21.1[70]				
	Heat source water flow rate		m <sup>3</sup> /h G/h gpm	5.76 [1522] [25.4]		[15	76 [22] [5.4]	
		No. of connected units	Unit		5	j		
Operating	Indoor unit	No. of units in operation	Offic		5	j		
conditions		Model	-		36/36/48	8/48/48		
		Main pipe			5	[16-3/8]		
	Pipe length	Branch pipe	m [ft]		10	[32-3/4]		
		Total pipe length		65 [213-1/4]				
	Fan spe	Fan speed			Н	li		
	Refrigerant charge		kg [lbs-oz]		26.2	[58]		
	Current		Α		22	.0		
Heat source unit	Voltage		V		57	'5		
	Compres	ssor frequency	Hz	81		8	1	
	Indoor u	nit		332/332/406/406/406				
LEV opening	SC (LEV	1)	Pulse	0		0		
LEV opening	LEV6	:V6		122		84		
	LEV7			3000		3000		
Pressure switch		ssure (after O/S)/ ssure (before accumulator)	MPa [psi]	2.75/0.80	[399/116]	2.75/0.80	[399/116]	
		Discharge (TH4)		81	[178]	81	[178]	
		Heat exchanger outlet		5	[41]	5	[41]	
	Heat	Accumulator inlet		4	[39]	4	[39]	
Sectional	source unit	Accumulator outlet	°C (°E)	4	[39]	4	[39]	
temperatures		Compressor inlet	°C [°F] -	4	[39]	4	[39]	
		Compressor shell bottom		40	[104]	40	[104]	
	Indoor	LEV inlet			35	[95]		
	unit	Heat exchanger inlet			70	[158]		

					2-unit cor	nbination		
		Item			PQHY-P2402	ZSLMU-A1/B		
				PQHY-P120	ZLMU-A1/B	PQHY-P120	ZLMU-A1/B	
	Indoor te	emperature	DB/WB		21.1°C/-	[70°F/-]		
	Heat sou	ırce water temperature	°C [ °F]	21.1[70]				
	Heat source water flow rate		m <sup>3</sup> /h G/h gpm	5.76 [1522] [25.4]			76 22] 5.4]	
		No. of connected units	Unit		6	3		
Operating	Indoor unit	No. of units in operation	Offic		6	3		
conditions		Model	-		36/36/36/	36/48/48		
		Main pipe			5	[16-3/8]		
	Pipe length	Branch pipe	m [ft]		10	[32-3/4]		
		Total pipe length		65 [213-1/4]				
	Fan spe	ed	-	Hi				
Refrigerar		ant charge	kg [lbs-oz]		26.2	[58]		
	Current		Α		23	.3		
Heat source unit	Voltage	Voltage			57	75		
	Compres	ssor frequency	Hz	90		9	0	
	Indoor u	nit		332/332/332/406/406				
LEV ananing	SC (LEV	<b>71</b> )	Pulse	0		0		
LEV opening	LEV6		Puise	122		122		
	LEV7			3000		3000		
Pressure switch	High pre	ssure (after O/S)/ ssure (before accumulator)	MPa [psi]	2.68/0.80	[389/116]	2.68/0.80	[389/116]	
		Discharge (TH4)		81	[178]	81	[178]	
		Heat exchanger outlet		5	[41]	5	[41]	
	Heat	Accumulator inlet		4	[39]	4	[39]	
Sectional	source unit	Accumulator outlet	°C [°E]	4	[39]	4	[39]	
temperatures		Compressor inlet	°C [°F]	4	[39]	4	[39]	
		Compressor shell bottom	n	40	[104]	40	[104]	
	Indoor	LEV inlet			35	[95]		
	unit	Heat exchanger inlet			70	[158]		
	•	•						

					2-unit cor	nbination		
		Item			PQHY-P288Z	ZSLMU-A1/B		
				PQHY-P144	IZLMU-A1/B	PQHY-P144	IZLMU-A1/B	
	Indoor te	emperature	DB/WB		21.1°C/-	[70°F/-]		
	Heat sou	irce water temperature	°C [ °F]		21.1[70]			
	Heat source water flow rate		m <sup>3</sup> /h G/h gpm	[19	7.20 [1902] [31.7]		20  02]  .7]	
		No. of connected units	Unit		6	3		
Operating	Indoor unit	No. of units in operation	Offic		6	3		
conditions		Model	-		48/48/48/	48/48/48		
		Main pipe			5	[16-3/8]		
	Pipe length	Branch pipe	m [ft]		10	[32-3/4]		
		Total pipe length		65 [213-1/4]				
	Fan spe	ed	-	Hi				
Refrigera		ant charge	kg [lbs-oz]		22.5	[50]		
	Current		Α		23.3			
Heat source unit	Voltage	/oltage			57	75		
	Compres	ssor frequency	Hz	6	67		7	
	Indoor u	nit		406/406/406/406/406				
LEV ananing	SC (LEV	<b>71</b> )	Pulse	0		0		
LEV opening	LEV6		Puise	126		126		
	LEV7			3000		3000		
Pressure switch		ssure (after O/S)/ ssure (before accumulator)	MPa [psi]	2.54/0.80	[368/116]	2.54/0.80	[368/116]	
		Discharge (TH4)		80	[176]	80	[176]	
		Heat exchanger outlet		5	[41]	5	[41]	
	Heat	Accumulator inlet		4	[39]	4	[39]	
Sectional	source unit	Accumulator outlet	00 100	4	[39]	4	[39]	
temperatures		Compressor inlet	- °C [°F] - - 1	4	[39]	4	[39]	
		Compressor shell bottom		40	[104]	40	[104]	
	Indoor	LEV inlet			36	[97]		
	unit	Heat exchanger inlet			70	[158]		
	1	1						

					2-unit con	nbination		
		Item			PQHY-P312Z	ZSLMU-A1/B		
				PQHY-P168	BZLMU-A1/B	PQHY-P144	IZLMU-A1/B	
	Indoor te	emperature	DB/WB		21.1°C/-	[70°F/-]		
	Heat sou	irce water temperature	°C [ °F]	21.1[70]				
	Heat sou	ırce water flow rate	m <sup>3</sup> /h G/h gpm	7.20 [1902] [31.7]		[19	20  02]  .7]	
		No. of connected units	Unit		6	3		
Operating	Indoor unit	No. of units in operation	Offic		6	3		
conditions		Model	-		54/54/54/	54/48/48		
		Main pipe			5	[16-3/8]		
	Pipe length	Branch pipe	m [ft]		10	[32-3/4]		
		Total pipe length		65 [213-1/4]				
	Fan spe	ed	-		Hi			
	Refrigerant charge		kg [lbs-oz]		22.5	[50]		
	Current	Current			26	.7		
Heat source unit	Voltage	Voltage			57	<b>'</b> 5		
	Compres	Compressor frequency		7	73		3	
	Indoor u	nit		414/414/414/406/406				
LEV opening	SC (LEV	<b>(1)</b>	Pulse	0		0		
LLV opening	LEV6		ruise	145		145		
	LEV7			3000		30	00	
Pressure switch	High pre Low pres	ssure (after O/S)/ ssure (before accumulator)	MPa [psi]	2.58/0.80	[374/116]	2.58/0.80	[374/116]	
		Discharge (TH4)		80	[176]	80	[176]	
		Heat exchanger outlet		5	[41]	5	[41]	
	Heat	Accumulator inlet		4	[39]	4	[39]	
Sectional	source unit	Accumulator outlet	°C (°E)	4	[39]	4	[39]	
temperatures		Compressor inlet		4	[39]	4	[39]	
		Compressor shell bottom		40	[104]	40	[104]	
	Indoor	LEV inlet			36	[97]		
	unit	Heat exchanger inlet			70	[158]		

					2-unit cor	nbination		
		Item			PQHY-P3362	ZSLMU-A1/B		
				PQHY-P168	BZLMU-A1/B	PQHY-P168	BZLMU-A1/B	
	Indoor te	emperature	DB/WB		21.1°C/-	[70°F/-]		
	Heat sou	irce water temperature	°C [ °F]	21.1[70]				
	Heat sou	ırce water flow rate	m <sup>3</sup> /h G/h gpm	7.20 [1902] [31.7]		[19	20 02] .7]	
		No. of connected units	Unit		7	,		
Operating	Indoor unit	No. of units in operation	Unit		7	,		
conditions		Model	-		48/48/48/4	8/48/48/48		
		Main pipe			5	[16-3/8]		
	Pipe length	Branch pipe	m [ft]		10	[32-3/4]		
	lgu.	Total pipe length		65 [213-1/4]				
	Fan spe	ed	-		Hi			
	Refrigera	Refrigerant charge			23.5	[52]		
	Current		Α		30	.6		
Heat source unit	Voltage	Voltage			57	75		
4	Compres	Compressor frequency		7	78		8	
	Indoor u	nit		406/406/406/406/406/406				
L EV ananing	SC (LEV	(1)	Dulaa	0		0		
LEV opening	LEV6		Pulse	164		164		
	LEV7			30	3000		00	
Pressure switch	High pre	ssure (after O/S)/ ssure (before accumulator)	MPa [psi]	2.62/0.80	[380/116]	2.62/0.80	[380/116]	
		Discharge (TH4)		81	[178]	81	[178]	
		Heat exchanger outlet		5	[41]	5	[41]	
	Heat	Accumulator inlet		4	[39]	4	[39]	
Sectional	source unit	Accumulator outlet	°C [°E]	4	[39]	4	[39]	
temperatures		Compressor inlet	°C [°F]	4	[39]	4	[39]	
		Compressor shell bottom		40	[104]	40	[104]	
	Indoor	LEV inlet			37	[99]		
	unit	Heat exchanger inlet			70	[158]		

					2-unit con	nbination		
		Item			PQHY-P3602	ZSLMU-A1/B		
				PQHY-P192	ZLMU-A1/B	PQHY-P168	BZLMU-A1/B	
	Indoor te	emperature	DB/WB		21.1°C/-	[70°F/-]		
	Heat sou	rce water temperature	°C [ °F]	21.1[70]				
	Heat source water flow rate		m <sup>3</sup> /h G/h gpm	7.20 [1902] [31.7]		7.20 [1902] [31.7]		
		No. of connected units	Unit		7	7		
Operating	Indoor unit	No. of units in operation	Offic		7	7		
conditions		Model	-		54/54/54/54	4/48/48/48		
		Main pipe			5	[16-3/8]		
	Pipe length	Branch pipe	m [ft]		10	[32-3/4]		
		Total pipe length		75 [246-1/16]				
	Fan spee	ed	-	Hi				
	Refrigerant charge		kg [lbs-oz]		23.8 [53]			
	Current		Α		33	.6		
Heat source unit	Voltage		V		57	'5		
	Compres	ssor frequency	Hz	84		8	4	
	Indoor u	nit		414/414/414/414/406/406/406		1		
LEV opening	SC (LEV	<b>(1)</b>	Pulse	0		0		
LEV opening	LEV6	EV6		183		183		
	LEV7			3000		30	00	
Pressure switch		ssure (after O/S)/ ssure (before accumulator)	MPa [psi]	2.63/0.80	[381/116]	2.63/0.80	[381/116]	
		Discharge (TH4)		81	[178]	81	[178]	
		Heat exchanger outlet		5	[41]	5	[41]	
	Heat	Accumulator inlet		4	[39]	4	[39]	
Sectional	source unit	Accumulator outlet	°C (°E)	4	[39]	4	[39]	
temperatures		Compressor inlet	- °C [°F] - n	4	[39]	4	[39]	
		Compressor shell bottom		40	[104]	40	[104]	
	Indoor	LEV inlet			37	[99]		
	unit	Heat exchanger inlet			70	[158]		

## 3. Single unit <PQRY>

## (1) Cooling only operation

		Item		Heat source	e unit model
		item		PQRY-P72ZLMU-A1/B	PQRY-P96ZLMU-A1/B
Model name or	f BC contr	oller		CMB-P104NU-J1/2	CMB-P104NU-J1/2
	Indoor te	mperature	DB/WB	26.7°C/19.4°C [80 °F/67 °F]	26.7°C/19.4°C [80 °F/67 °F]
	Heat sou	rce water temperature	°C [ °F]	29.4[85]	29.4[85]
	Heat sou	rce water flow rate	m <sup>3</sup> /h [G/h] [gpm]	5.76 [1522] [25.4]	5.76 [1522] [25.4]
		No. of connected units	Unit	2	2
Operating	Indoor unit	No. of units in operation	Offic	2	2
conditions		Model	_	36/36	48/48
	Pipe length	Main pipe		5 [16-3/8]	5 [16-3/8]
		Branch pipe	m [ft]	10 [32-3/4]	10 [32-3/4]
	J	Total pipe length		25 [82]	25 [82]
	Fan speed		_	Hi	Hi
	Refrigerant charge		kg [lbs-oz]	11.8 [27]	13.0 [29]
	Current		Α	7.0	9.3
Heat source unit	Voltage	Voltage		575	575
	Compres	ssor frequency	Hz	66	90
	Indoor u	nit		325/325	387/387
I <b>(</b> ) /i	BC controller (1/3/4)		Dulaa	3000/120/-	3000/120/-
LEV opening	LEV6		Pulse	41	41
	LEV7			3000	3000
Pressure		ssure (after O/S)/ ssure (before accumulator)	MPa	2.20/0.81 [319/117]	2.27/0.81 [329/117]
switch		oller on the liquid side ermediate part (PS3)	[psi]	2.10/2.10 [305/305]	2.17/2.17 [315/315]
		Discharge (TH4)		65 [149]	65 [149]
		Heat exchanger outlet		33 [91]	34 [93]
	Heat	Accumulator inlet		8 [46]	8 [46]
Sectional	source unit	Accumulator outlet	°C [ °F]	8 [46]	8 [46]
temperatures		Compressor inlet	O[F]	19 [66]	19 [66]
		Compressor shell bottom		47 [117]	40 [104]
	Indoor	LEV inlet		19 [66]	19 [66]
	unit	Heat exchanger outlet		6 [43]	6 [43]

		Item		Heat source	unit model	
		item		PQRY-P120ZLMU-A1/B	PQRY-P144ZLMU-A1/B	
Model name o	f BC contr	oller		CMB-P104NU-J1/2	CMB-P108NU-JA1/2	
	Indoor te	mperature	DB/WB	26.7°C/19.4°C [80 °F/67 °F]	26.7°C/19.4°C [80 °F/67 °F]	
	Heat sou	rce water temperature	°C [ °F]	29.4[85]	29.4[85]	
	Heat sou	rce water flow rate	m <sup>3</sup> /h [G/h] [gpm]	5.76 [1522] [25.4]	7.20 [1902] [31.7]	
		No. of connected units	Unit	3	4	
Operating	Indoor unit	No. of units in operation	Offic	3	4	
conditions		Model	_	36/36/48	36/36/36/36	
	Pipe length	Main pipe		5 [16-3/8]	5 [16-3/8]	
		Branch pipe	m [ft]	10 [32-3/4]	10 [32-3/4]	
		Total pipe length		35 [115]	45 [148]	
	Fan speed		_	Hi	Hi	
	Refrigerant charge		kg [lbs-oz]	13.6 [30]	16.3 [36]	
Heat source	Current		Α	9.5	9.7	
	Voltage	Voltage		575	575	
	Compres	ssor frequency	Hz	114	82	
	Indoor u	nit		325/325/387	325/325/325/325	
I EV anoning	BC contr	oller (1/3/4)	Pulse	3000/125/-	3000/140/41	
LEV opening	LEV6			41	41	
	LEV7			3000	3000	
Pressure		ssure (after O/S)/ ssure (before accumulator)	MPa	2.30/0.81 [334/117]	2.36/0.81 [342/117]	
switch		oller on the liquid side termediate part (PS3)	[psi]	2.20/2.20 [319/319]	2.26/2.26 [328/328]	
		Discharge (TH4)		65 [149]	65 [149]	
		Heat exchanger outlet		35 [95]	36 [97]	
	Heat	Accumulator inlet		8 [46]	8 [46]	
Sectional	source unit	Accumulator outlet	۰۰ ۲۰۶۱	8 [46]	8 [46]	
temperatures		Compressor inlet	°C [ °F]	19 [66]	19 [66]	
	_	Compressor shell bottom		42 [108]	42 [108]	
	Indoor	LEV inlet		19 [66]	19 [66]	
	unit	Heat exchanger outlet		6 [43]	6 [43]	
	ı		1			

ltem				Heat source	unit model
		item		PQRY-P168ZLMU-A1/B	PQRY-P192ZLMU-A1/B
Model name of BC controller				CMB-P108NU-JA1/2	CMB-P108NU-JA1/2
	Indoor te	emperature	DB/WB	26.7°C/19.4°C [80 °F/67 °F]	26.7°C/19.4°C [80 °F/67 °F]
	Heat sou	rce water temperature	°C [ °F]	29.4[85]	29.4[85]
	Heat sou	rce water flow rate	m <sup>3</sup> /h [G/h] [gpm]	7.20 [1902] [31.7]	7.20 [1902] [31.7]
		No. of connected units	Unit	4	4
Operating	Indoor unit	No. of units in operation	Onit	4	4
conditions		Model	_	36/36/48/48	48/48/48/48
		Main pipe		5 [16-3/8]	5 [16-3/8]
	Pipe length	Branch pipe	m [ft]	10 [32-3/4]	10 [32-3/4]
		Total pipe length		45 [148]	45 [148]
	Fan spee	ed	_	Hi	Hi
	Refrigerant charge		kg [lbs-oz]	19.1 [43]	20.6 [46]
	Current		Α	13.4	16.7
Heat source unit	Voltage		V	575	575
	Compressor frequency		Hz	97	112
	Indoor unit			325/325/387/387	387/387/387/387
LEV opening	BC controller (1/3/4)		Pulse	3000/140/41	3000/145/41
LEV opening	LEV6	LEV6		41	41
	LEV7		-	3000	3000
Pressure		ssure (after O/S)/ ssure (before accumulator)	MPa	2.48/0.81 [360/117]	2.56/0.81 [371/117]
switch	BC controller on the liquid side (PS1)/Intermediate part (PS3)		[psi]	2.38/2.38 [345/345]	2.46/2.46 [357/357]
		Discharge (TH4)		65 [149]	65 [149]
		Heat exchanger outlet	]	38 [100]	39 [102]
	Heat source	Accumulator inlet		8 [46]	8 [46]
Sectional	unit	Accumulator outlet	°C [ °F]	8 [46]	8 [46]
temperatures		Compressor inlet	[ [ ]	19 [66]	19 [66]
		Compressor shell bottom	]	42 [108]	42 [108]
	Indoor	LEV inlet		19 [66]	19 [66]
	unit	Heat exchanger outlet	]	6 [43]	6 [43]

## (2) Heating only operation

Item _				Heat source unit model		
		пеш	PQRY-P72ZLMU-A1/B	PQRY-P96ZLMU-A1/B		
Model name of BC controller			CMB-P104NU-J1/2	CMB-P104NU-J1/2		
	Indoor te	emperature	DB/WB	21.1°C/- [70 °F/-]	21.1°C/- [70 °F/-]	
	Heat sou	irce water temperature	°C [ °F]	21.1[70]	21.1[70]	
	Heat sou	ırce water flow rate	m <sup>3</sup> /h [G/h] [gpm]	5.76 [1522] [25.4]	5.76 [1522] [25.4]	
		No. of connected units	Unit	2	2	
Operating	Indoor unit	No. of units in operation	Offic	2	2	
conditions		Model	_	36/36	48/48	
		Main pipe		5 [16-3/8]	5 [16-3/8]	
	Pipe length	Branch pipe	m [ft]	10 [32-3/4]	10 [32-3/4]	
		Total pipe length		25 [82]	25 [82]	
	Fan spe	ed	_	Hi	Hi	
	Refrigerant charge		kg [lbs-oz]	11.8 [27]	13.0 [29]	
	Current		Α	7.4	10.0	
Heat source unit	Voltage		V	575	575	
	Compressor frequency		Hz	60	72	
	Indoor u	nit		332/332	406/406	
LEV opening	BC contr	BC controller (1/3/4)		85/270/-	85/295/-	
LLV opening	LEV6	LEV6		68	84	
	LEV7			41	41	
Pressure		ssure (after O/S)/ ssure (before accumulator)	MPa	2.64/0.80 [383/116]	2.90/0.80 [421/116]	
switch	BC controller on the liquid side (PS1)/Intermediate part (PS3)		[psi]	2.61/2.29 [379/332]	2.87/2.55 [416/370]	
		Discharge (TH4)		73 [163]	80 [176]	
		Heat exchanger outlet		5 [41]	5 [41]	
	Heat source	Accumulator inlet		4 [39]	4 [39]	
Sectional	unit	Accumulator outlet	°C [ °F]	4 [39]	4 [39]	
temperatures		Compressor inlet		4 [39]	4 [39]	
		Compressor shell bottom		40 [104]	40 [104]	
	Indoor	LEV inlet		37 [99]	38 [100]	
	unit Heat exchanger inlet			70 [158]	70 [158]	

		Item		Heat source	unit model
		item	PQRY-P120ZLMU-A1/B	PQRY-P144ZLMU-A1/B	
Model name of BC controller				CMB-P104NU-J1/2	CMB-P108NU-JA1/2
	Indoor te	emperature	DB/WB	21.1°C/- [70 °F/-]	21.1°C/- [70 °F/-]
	Heat sou	rce water temperature	°C [ °F]	21.1[70]	21.1[70]
	Heat sou	rce water flow rate	m <sup>3</sup> /h [G/h] [gpm]	5.76 [1522] [25.4]	7.20 [1902] [31.7]
		No. of connected units	Unit	3	4
Operating	Indoor unit	No. of units in operation	Oille	3	4
conditions		Model	_	36/36/48	36/36/36/36
		Main pipe		5 [16-3/8]	5 [16-3/8]
	Pipe length	Branch pipe	m [ft]	10 [32-3/4]	10 [32-3/4]
		Total pipe length		35 [115]	45 [148]
	Fan spe	ed	-	Hi	Hi
	Refrigerant charge		kg [lbs-oz]	13.6 [30]	16.3 [36]
	Current		Α	11.3	11.6
Heat source unit	Voltage		V	575	575
	Compressor frequency		Hz	90	75
	Indoor unit			332/332/406	332/332/332/332
LEV opening	BC controller (1/3/4)		- Pulse -	85/325/-	85/405/41
LEV opening	LEV6			122	136
	LEV7			41	41
Pressure		ssure (after O/S)/ ssure (before accumulator)	MPa	2.68/0.80 [389/116]	2.54/0.80 [368/116]
switch	BC controller on the liquid side (PS1)/Intermediate part (PS3)		[psi]	2.64/2.32 [383/336]	2.51/2.19 [364/318]
		Discharge (TH4)		81 [178]	77 [171]
		Heat exchanger outlet		5 [41]	5 [41]
	Heat	Accumulator inlet		4 [39]	4 [39]
Sectional	source unit	Accumulator outlet	۰۰ ۲۰۶۱	4 [39]	4 [39]
temperatures		Compressor inlet	°C [ °F]	4 [39]	4 [39]
		Compressor shell bottom		40 [104]	40 [104]
	Indoor	LEV inlet		39 [102]	36 [97]
	unit	Heat exchanger inlet		70 [158]	70 [158]
	<u> </u>				

Item				Heat source	unit model
		item		PQRY-P168ZLMU-A1/B	PQRY-P192ZLMU-A1/B
Model name of BC controller				CMB-P108NU-JA1/2	CMB-P108NU-JA1/2
	Indoor te	mperature	DB/WB	21.1°C/- [70 °F/-]	21.1°C/- [70 °F/-]
	Heat sou	irce water temperature	°C [ °F]	21.1[70]	21.1[70]
	Heat sou	rce water flow rate	m <sup>3</sup> /h [G/h] [gpm]	7.20 [1902] [31.7]	7.20 [1902] [31.7]
		No. of connected units	Unit	4	4
Operating	Indoor unit	No. of units in operation	Offic	4	4
conditions		Model	_	36/36/48/48	48/48/48/48
		Main pipe		5 [16-3/8]	5 [16-3/8]
	Pipe length	Branch pipe	m [ft]	10 [32-3/4]	10 [32-3/4]
		Total pipe length		45 [148]	45 [148]
	Fan spe	Fan speed		Hi	Hi
	Refrigerant charge		kg [lbs-oz]	19.1 [43]	20.6 [46]
	Current		Α	16.0	19.9
Heat source unit	Voltage		V	575	575
	Compressor frequency		Hz	82	90
	Indoor unit			332/332/406/406	406/406/406/406
I EV anoning	BC controller (1/3/4)		Pulse	85/405/41	85/450/41
LEV opening	LEV6	LEV6		152	168
	LEV7			41	41
Pressure		ssure (after O/S)/ ssure (before accumulator)	MPa	2.62/0.80 [380/116]	2.64/0.80 [383/116]
switch	BC controller on the liquid side (PS1)/Intermediate part (PS3)		[psi]	2.59/2.27 [376/329]	2.61/2.29 [379/332]
		Discharge (TH4)		77 [171]	80 [176]
		Heat exchanger outlet		5 [41]	5 [41]
	Heat source	Accumulator inlet		4 [39]	4 [39]
Sectional	unit	Accumulator outlet	°C [ °F]	4 [39]	4 [39]
temperatures		Compressor inlet		4 [39]	4 [39]
		Compressor shell bottom		40 [104]	40 [104]
	Indoor	LEV inlet		37 [99]	37 [99]
	unit	Heat exchanger inlet		70 [158]	70 [158]

#### 4. 2-unit combination <PQRY>

## (1) Cooling only operation

			2-unit combination		
		Item		PQRY-P1442	ZSLMU-A1/B
				PQRY-P72ZLMU-A1/B	PQRY-P72ZLMU-A1/B
Model name of BC controller			CMB-P108	BNU-JA1/2	
	Indoor te	mperature	DB/WB	26.7°C/19.4°C	[80 °F/67 °F]
	Heat sou	rce water temperature	°C [ °F]	29.4	[85]
	Heat sou	rce water flow rate	m <sup>3</sup> /h G/h gpm	5.76 [1522] [25.4]	5.76 [1522] [25.4]
		No. of connected units	Unit	4	ļ
Operating	Indoor unit	No. of units in operation	Offic	4	1
conditions		Model	-	36/36	/36/36
		Main pipe		5	[16-3/8]
	Pipe length	Branch pipe	m [ft]	10	[32-3/4]
		Total pipe length		45	[148]
	Fan spee	ed	-	H	li
	Refrigerant charge		kg [lbs-oz]	20.3 [45]	
	Current		Α	16	i.9
Heat source unit	Voltage		V	575	
	Compressor frequency		Hz	66	66
	Indoor unit			325/325/325/325	
L EV ananina	BC contr	oller (1/3/4)	Dulas	3000/140/41	
LEV opening	LEV6		Pulse	41	41
	LEV7			3000	3000
Pressure		ssure (after O/S)/ ssure (before accumulator)	MPa	2.20/0.81 [319/117]	2.20/0.81 [319/117]
switch	BC controller on the liquid side (PS1)/Intermediate part (PS3)		[psi]	2.10/2.10 [305/305]	
		Discharge (TH4)		65 [149]	65 [149]
		Heat exchanger outlet		33 [91]	33 [91]
	Heat	Accumulator inlet		8 [46]	8 [46]
Sectional	source unit	Accumulator outlet	°C [ °F]	8 [46]	8 [46]
temperatures		Compressor inlet	C[ F]	19 [66]	19 [66]
		Compressor shell bottom		47 [117]	47 [117]
	Indoor	LEV inlet		19	[66]
	unit	Heat exchanger outlet		6	[43]

				2-unit co	mbination
		Item		PQRY-P168	ZSLMU-A1/B
Madel name of DC controller				PQRY-P96ZLMU-A1/B PQRY-P72ZLMU-A1/B	
Model name of BC controller			CMB-P108	BNU-JA1/2	
	Indoor te	mperature	DB/WB	26.7°C/19.4°C	[80 °F/67 °F]
	Heat sou	rce water temperature	°C [ °F]	29.4	[85]
	Heat sou	rce water flow rate	m <sup>3</sup> /h G/h gpm	5.76 [1522] [25.4]	5.76 [1522] [25.4]
		No. of connected units	Unit	4	1
Operating	Indoor unit	No. of units in operation	Onit	4	4
conditions		Model	-	36/36	/48/48
		Main pipe		5	[16-3/8]
	Pipe length	Branch pipe	m [ft]	10	[32-3/4]
		Total pipe length		45 [148]	
	Fan spee	ed	-	Hi	
	Refrigerant charge		kg [lbs-oz]	23.1 [51]	
	Current		Α	16	5.9
Heat source unit	Voltage		V	575	
	Compressor frequency		Hz	78	78
	Indoor ur	nit		325/325	/387/387
LEV opening	BC controller (1/3/4)		Pulse	3000/140/41	
LEV opening	LEV6		Fuise	41	41
	LEV7			78  78  325/3  300  41  3000  2.23/0.81  [323/117]  2.  [3  65 [149]  33 [91]  8 [46]  8 [46]  19 [66]  40 [104]	3000
Pressure		ssure (after O/S)/ ssure (before accumulator)	MPa		2.23/0.81 [323/117]
switch		oller on the liquid side termediate part (PS3)	[psi]	2.13. [309.	/2.13 /309]
		Discharge (TH4)		65 [149]	65 [149]
		Heat exchanger outlet		33 [91]	33 [91]
	Heat source	Accumulator inlet		8 [46]	8 [46]
Sectional	unit	Accumulator outlet	°C [ °F]	8 [46]	8 [46]
temperatures		Compressor inlet	[ [ ]	19 [66]	19 [66]
		Compressor shell bottom		40 [104]	47 [117]
	Indoor	LEV inlet		19	[66]
	unit	Heat exchanger outlet	1	6	[43]

			2-unit co	mbination	
		Item		PQRY-P192	ZSLMU-A1/B
				PQRY-P96ZLMU-A1/B	PQRY-P96ZLMU-A1/B
Model name of BC controller			CMB-P108	BNU-JA1/2	
	Indoor te	mperature	DB/WB	26.7°C/19.4°C	[80 °F/67 °F]
	Heat sou	rce water temperature	°C [ °F]	29.4	[85]
	Heat sou	rce water flow rate	m <sup>3</sup> /h G/h gpm	5.76 [1522] [25.4]	5.76 [1522] [25.4]
		No. of connected units	Unit	4	4
Operating	Indoor unit	No. of units in operation	Offic	4	4
conditions		Model	-	48/48	/48/48
		Main pipe		5	[16-3/8]
	Pipe length	Branch pipe	m [ft]	10	[32-3/4]
	i i i i i i i i i i i i i i i i i i i	Total pipe length		45 [148]	
	Fan spee	ed	-	Hi	
	Refrigerant charge		kg [lbs-oz]	24.6 [54]	
	Current		Α	20	).7
Heat source unit	Voltage		V	575	
	Compressor frequency		Hz	90 90	
	Indoor u	Indoor unit		387/387/387	
LEV opening	BC contr	BC controller (1/3/4)		3000/145/41	
LEV opening	LEV6	LEV6		41	41
	LEV7			90 387/3 3000 41 3000 2.27/0.81 [329/117] 2. [3 65 [149] 34 [93] 8 [46]	3000
Pressure		ssure (after O/S)/ ssure (before accumulator)	MPa		2.27/0.81 [329/117]
switch	BC controller on the liquid side (PS1)/Intermediate part (PS3)		[psi]	2.17 [315.	/2.17 /315]
		Discharge (TH4)		65 [149]	65 [149]
		Heat exchanger outlet		34 [93]	34 [93]
	Heat source	Accumulator inlet		8 [46]	8 [46]
Sectional	unit	Accumulator outlet	°C [ °F]	8 [46]	8 [46]
temperatures		Compressor inlet	[ [ ]	19 [66]	19 [66]
		Compressor shell bottom		40 [104]	40 [104]
	Indoor	LEV inlet		19	[66]
	unit	Heat exchanger outlet		6	[43]

				2-unit cor	nbination	
		Item		PQRY-P2162	ZSLMU-A1/B	
				PQRY-P120ZLMU-A1/B PQRY-P96ZLMU-A1		
Model name of BC controller				CMB-P101	2NU-JA1/2	
	Indoor te	emperature	DB/WB	26.7°C/19.4°C	[80 °F/67 °F]	
	Heat sou	ırce water temperature	°C [ °F]	29.4	[85]	
	Heat sou	ırce water flow rate	m <sup>3</sup> /h G/h gpm	5.76 [1522] [25.4]	5.76 [1522] [25.4]	
		No. of connected units	Unit	5	j	
Operating	Indoor unit	No. of units in operation	Offic	5	j	
conditions		Model	_	36/36/4	8/48/48	
		Main pipe		5	[16-3/8]	
	Pipe length	Branch pipe	m [ft]	10	[32-3/4]	
		Total pipe length		65 [213-1/4]		
	Fan speed		_	Hi		
	Refrigerant charge		kg [lbs-oz]	26.2 [58]		
LI t	Current		Α	20	.8	
Heat source unit	Voltage		V	575		
	Compres	ssor frequency	Hz	98	98 98	
	Indoor u	nit		325/325/387/387		
LEV opening	BC contr	oller (1/3/4)	Pulse	3000/150/41		
LLV oponing	LEV6	LEV6		41	41	
	LEV7			3000	3000	
Pressure		ssure (after O/S)/ ssure (before accumulator)	MPa [psi]	2.28/0.81 [331/117]	2.28/0.81 [331/117]	
switch	BC contr (PS1)/Int	BC controller on the liquid side (PS1)/Intermediate part (PS3)		2.18/ [316/		
		Discharge (TH4)		65 [149]	65 [149]	
		Heat exchanger outlet		35 [95]	35 [95]	
	Heat source	Accumulator inlet		8 [46]	8 [46]	
Sectional	unit	Accumulator outlet	°C [ °F]	8 [46]	8 [46]	
temperatures		Compressor inlet	[ [ ]	19 [66]	19 [66]	
		Compressor shell bottom		42 [108]	40 [104]	
	Indoor	LEV inlet		19	[66]	
	unit Heat exchanger outlet			6	[43]	

			2-unit cor	mbination		
		Item		PQRY-P2402	ZSLMU-A1/B	
				PQRY-P120ZLMU-A1/B	PQRY-P120ZLMU-A1/B	
Model name of BC controller			CMB-P101	2NU-JA1/2		
	Indoor te	mperature	DB/WB	26.7°C/19.4°C	[80 °F/67 °F]	
	Heat sou	rce water temperature	°C [ °F]	29.4	[85]	
	Heat sou	rce water flow rate	m <sup>3</sup> /h G/h gpm	5.76 [1522] [25.4]	5.76 [1522] [25.4]	
		No. of connected units	Unit	(	3	
Operating	Indoor unit	No. of units in operation	Onit	(	3	
conditions		Model	_	36/36/36	/36/48/48	
		Main pipe		5	[16-3/8]	
	Pipe length	Branch pipe	m [ft]	10	[32-3/4]	
	g	Total pipe length		65 [213-1/4]		
	Fan spee	ed	-	Hi		
	Refrigerant charge		kg [lbs-oz]	26.2 [58]		
	Current		Α	22	2.7	
Heat source unit	Voltage		V	575		
	Compressor frequency		Hz	105	105	
	Indoor u	Indoor unit		325/325/325	/325/387/387	
LEV opening	BC contr	BC controller (1/3/4)		3000/	3000/155/41	
LEV opening	LEV6	LEV6		41	41	
	LEV7			26.  105  325/325/3.  300  41  3000  2.30/0.81  [334/117]  2  [3  65 [149]  35 [95]	3000	
Pressure		ssure (after O/S)/ ssure (before accumulator)	MPa		2.30/0.81 [334/117]	
switch		oller on the liquid side ermediate part (PS3)	[psi]	2.20 <sub>/</sub> [319 <sub>/</sub>	/2.20 /319]	
		Discharge (TH4)		65 [149]	65 [149]	
		Heat exchanger outlet		35 [95]	35 [95]	
	Heat source	Accumulator inlet		8 [46]	8 [46]	
Sectional	unit	Accumulator outlet	°C [ °F]	8 [46]	8 [46]	
temperatures		Compressor inlet	C[ F]	19 [66]	19 [66]	
		Compressor shell bottom		42 [108]	42 [108]	
	Indoor	LEV inlet		19	[66]	
	unit	Heat exchanger outlet		6	[43]	

			2-unit combination		
		Item		PQRY-P2882	ZSLMU-A1/B
Model name of BC controller				PQRY-P144ZLMU-A1/B PQRY-P144ZLMU-A1/B	
Model name of BC controller  Indoor temperature  DB/WE				CMB-P1016NU-JA1/2	
	Indoor te	emperature	DB/WB	26.7°C/19.4°C	[80 °F/67 °F]
	Heat sou	irce water temperature	°C [ °F]	29.4	[85]
	Heat sou	ırce water flow rate	m <sup>3</sup> /h G/h gpm	7.20 [1902] [31.7]	7.20 [1902] [31.7]
		No. of connected units	Unit	6	3
Operating	Indoor unit	No. of units in operation	Offic	6	3
conditions		Model	_	48/48/48/	/48/48/48
		Main pipe		5	[16-3/8]
	Pipe length	Branch pipe	m [ft]	10	[32-3/4]
		Total pipe length		65 [213-1/4]	
	Fan spe	ed	-	Hi	
	Refrigerant charge		kg [lbs-oz]	22.5 [50]	
	Current		Α	22	2.7
Heat source unit	Voltage	/oltage		575	
	Compres	ssor frequency	Hz	84	84
	Indoor u	nit		387/387/387/387/387	
LEV opening	BC contr	oller (1/3/4)	Pulse	3000/175/41	
LEV opening	LEV6		i uise	41	41
	LEV7			48/48/48 5 10 65 1 22.5 22 5 84 387/387/387 3000/ 41 3000 2.36/0.81 [342/117]	3000
Pressure		ssure (after O/S)/ ssure (before accumulator)	MPa		2.36/0.81 [342/117]
switch		oller on the liquid side termediate part (PS3)	[psi]	2.26/ [328/	
		Discharge (TH4)		65 [149]	65 [149]
		Heat exchanger outlet		36 [93]	36 [93]
	Heat source	Accumulator inlet		8 [46]	8 [46]
Sectional	unit	Accumulator outlet	°C [ °F]	8 [46]	8 [46]
temperatures		Compressor inlet	[ [ ]	19 [66]	19 [66]
		Compressor shell bottom		40 [104]	40 [104]
	Indoor	LEV inlet		19	[66]
	unit	Heat exchanger outlet		6	[43]

			2-unit cor	mbination	
		Item		PQRY-P312	ZSLMU-A1/B
Model name of BC controller				PQRY-P168ZLMU-A1/B PQRY-P144ZLMU-A1/B	
Model name of BC controller			CMB-P101	6NU-JA1/2	
	Indoor te	mperature	DB/WB	26.7°C/19.4°C	[80 °F/67 °F]
	Heat sou	rce water temperature	°C [ °F]	29.4	[85]
	Heat sou	rce water flow rate	m <sup>3</sup> /h G/h gpm	7.20 [1902] [31.7]	7.20 [1902] [31.7]
		No. of connected units	Unit	(	3
Operating	Indoor unit	No. of units in operation	Onit	(	3
conditions		Model	_	54/54/54	/54/48/48
		Main pipe		5	[16-3/8]
	Pipe length	Branch pipe	m [ft]	10	[32-3/4]
	g	Total pipe length		65 [213-1/4]	
	Fan spe	ed	-	Hi	
	Refrigerant charge		kg [lbs-oz]	22.5 [50]	
	Current		Α	26	3.0
Heat source unit	Voltage		V	575	
	Compressor frequency		Hz	89	89
	Indoor u	Indoor unit		395/395/395	/387/387/387
LEV opening	BC contr	BC controller (1/3/4)		3000/175/41	
LEV opening	LEV6		Pulse	41	41
	LEV7			54/54/  11 66 22 89 395/395/3 300 41 3000 2.42/0.81 [351/117] 2. [3 65 [149] 37 [93] 8 [46] 8 [46]	3000
Pressure		ssure (after O/S)/ ssure (before accumulator)	MPa		2.42/0.81 [351/117]
switch		BC controller on the liquid side (PS1)/Intermediate part (PS3)		2.32 [336	/2.32 /336]
		Discharge (TH4)		65 [149]	65 [149]
		Heat exchanger outlet		37 [93]	37 [93]
	Heat source	Accumulator inlet		8 [46]	8 [46]
Sectional	unit	Accumulator outlet	°C [ °F]	8 [46]	8 [46]
temperatures		Compressor inlet	C[ F]	19 [66]	19 [66]
		Compressor shell bottom		40 [104]	40 [104]
	Indoor	LEV inlet		19	[66]
	unit	Heat exchanger outlet		6	[43]

			2-unit combination		
		Item		PQRY-P336ZSLMU-A1/B	
Model name of BC controller			PQRY-P168ZLMU-A1/B PQRY-P168ZLMU-A1/B		
Model name of BC controller  Indoor temperature  DB/WB				CMB-P101	6NU-JA1/2
	Indoor te	emperature	DB/WB	26.7°C/19.4°C	[80 °F/67 °F]
	Heat sou	irce water temperature	°C [ °F]	29.4	[85]
	Heat sou	ırce water flow rate	m <sup>3</sup> /h G/h gpm	7.20 [1902] [31.7]	7.20 [1902] [31.7]
		No. of connected units	Unit	7	7
Operating	Indoor unit	No. of units in operation	Onn	7	7
conditions		Model	_	48/48/48/4	8/48/48/48
		Main pipe		5	[16-3/8]
	Pipe length	Branch pipe	m [ft]	10	[32-3/4]
		Total pipe length		65 [213-1/4]	
	Fan spee	ed	=	Hi	
	Refrigerant charge		kg [lbs-oz]	23.5 [52]	
	Current	Current		29	1.9
Heat source unit	Voltage	oltage		575	
	Compres	ssor frequency	Hz	93	93
	Indoor u	nit		387/387/387/387/387/387	
LEV opening	BC contr	oller (1/3/4)	Pulse	3000/1	175/41
LEV opening	LEV6		Fuise	41	41
	LEV7			93 387/387/387/ 3000 41 3000 2.48/0.81 [360/117] 2.3 [34 65 [149] 38 [95]	3000
Pressure	High pre	ssure (after O/S)/ ssure (before accumulator)	MPa		2.48/0.81 [360/117]
switch		oller on the liquid side termediate part (PS3)	[psi]	2.38/ [345 <i>/</i>	
		Discharge (TH4)		65 [149]	65 [149]
		Heat exchanger outlet		38 [95]	38 [95]
	Heat source	Accumulator inlet		8 [46]	8 [46]
Sectional	unit	Accumulator outlet	°C [ °F]	8 [46]	8 [46]
temperatures		Compressor inlet	ا در ۱	19 [66]	19 [66]
		Compressor shell bottom		40 [104]	40 [104]
	Indoor	LEV inlet		19	[66]
	unit	Heat exchanger outlet		6	[43]

#### (2) Heating only operation

		2-unit combination							
		Item		PQRY-P144ZSLMU-A1/B					
		item	PQRY-P72ZLMU-A1/B	PQRY-P72ZLMU-A1/B					
Model name of	BC contr	oller		CMB-P108NU-JA1/2					
Woder Hame of		mperature	DB/WB	21.1°C/-					
		irce water temperature	°C [ °F]	21.1					
	Tieat 300	nce water temperature	m <sup>3</sup> /h	5.76	5.76				
	Heat sou	rce water flow rate	G/h gpm	[1522] [25.4]	[1522] [25.4]				
		No. of connected units	Unit	4					
Operating	Indoor unit	No. of units in operation	Onit	4					
conditions		Model	_	36/36/	36/36				
		Main pipe		5	[16-3/8]				
	Pipe length	Branch pipe	m [ft]	10	[32-3/4]				
	J	Total pipe length		45 [148]					
	Fan spee	ed	_	Hi					
	Refrigerant charge		kg [lbs-oz]	20.3 [45]					
	Current		Α	17.7					
Heat source unit	Voltage		V	575					
	Compres	ssor frequency	Hz	60	60				
	Indoor ur	nit		332/332/332					
LEV opening	BC contr	oller (1/3/4)	Pulse	85/405/41					
LEV opening	LEV6			68	68				
	LEV7			41	41				
Pressure		ssure (after O/S)/ ssure (before accumulator)	MPa	2.64/0.80 [383/116]	2.64/0.80 [383/116]				
switch	BC controller on the liquid side (PS1)/Intermediate part (PS3)		[psi]	2.61/2.29 [379/332]					
		Discharge (TH4)		77 [171]	77 [171]				
		Heat exchanger outlet		5 [41]	5 [41]				
	Heat source	Accumulator inlet		4 [39]	4 [39]				
Sectional	unit	Accumulator outlet	°C [ °F]	4 [39]	4 [39]				
temperatures		Compressor inlet	ا در ۱	4 [39]	4 [39]				
		Compressor shell bottom		40 [104]	40 [104]				
	Indoor	LEV inlet		37	[99]				
	unit	Heat exchanger inlet		70 [158]					

				2-unit combination				
		Item		PQRY-P168ZSLMU-A1/B				
			PQRY-P96ZLMU-A1/B PQRY-P72ZLMU-A1/E					
Model name o	f BC contr	oller	CMB-P108NU-JA1/2					
	Indoor te	emperature	DB/WB	21.1°C/-	[70 °F/-]			
	Heat sou	irce water temperature	°C [ °F]	21.1	[70]			
	Heat sou	ırce water flow rate	m <sup>3</sup> /h G/h gpm	5.76 [1522] [25.4]	5.76 [1522] [25.4]			
		No. of connected units	Unit	4	ļ			
Operating	Indoor unit	No. of units in operation	Onit	4	ļ			
conditions		Model	_	36/36/	48/48			
		Main pipe		5	[16-3/8]			
	Pipe length	Branch pipe	m [ft]	10	[32-3/4]			
		Total pipe length		45 [148]				
	Fan spee	ed	_	Hi				
	Refrigerant charge		kg [lbs-oz]	23.1 [51]				
	Current		Α	17	7.7			
Heat source unit	Voltage		V	575				
	Compres	npressor frequency		66	66			
	Indoor u	nit		332/332/406/406				
LEV opening	BC contr	oller (1/3/4)	Pulse	85/405/41				
LEV opening	LEV6			84	68			
	LEV7			41	41			
Pressure	High pressure (after O/S)/ Low pressure (before accumulator)		MPa	2.80/0.80 [406/116]	2.80/0.80 [406/116]			
switch	BC controller on the liquid side (PS1)/Intermediate part (PS3)		[psi]	2.77/2.45 [402/355]				
		Discharge (TH4)		77 [171]	77 [171]			
		Heat exchanger outlet		5 [41]	5 [41]			
	Heat source	Accumulator inlet		4 [39]	4 [39]			
Sectional	unit	Accumulator outlet	°C [ °F]	4 [39]	4 [39]			
temperatures		Compressor inlet	ر ن ا	4 [39]	4 [39]			
		Compressor shell bottom		40 [104]	40 [104]			
	Indoor	LEV inlet		37	[99]			
	unit	Heat exchanger inlet		70	[158]			

				2-unit combination				
		Item		PQRY-P1922	ZSLMU-A1/B			
			PQRY-P96ZLMU-A1/B PQRY-P96ZLMU-A1/B					
Model name of	f BC contr	oller		CMB-P108	BNU-JA1/2			
	Indoor te	mperature	DB/WB	21.1°C/-	[70 °F/-]			
	Heat sou	rce water temperature	°C [ °F]	21.1	[70]			
	Heat sou	rce water flow rate	m <sup>3</sup> /h G/h gpm	5.76 [1522] [25.4]	5.76 [1522] [25.4]			
		No. of connected units	Unit	4	1			
Operating	IIndoor unit	No. of units in operation	Onit	4	1			
conditions		Model	-	48/48	/48/48			
		Main pipe		5	[16-3/8]			
	Pipe length	Branch pipe	m [ft]	10	[32-3/4]			
		Total pipe length		45 [148]				
	Fan spee	ed	-	Hi				
	Refrigerant charge		kg [lbs-oz]	24.6 [54]				
	Current		Α	20	).4			
Heat source unit	Voltage		V	575				
	Compressor frequency		Hz	72	72			
	Indoor u	nit		406/406	/406/406			
L TV ananing	BC contr	oller (1/3/4)	Pulse	85/450/41				
LEV opening	LEV6		ruise	84	84			
	LEV7			41	41			
Pressure	High pressure (after O/S)/ Low pressure (before accumulator)		MPa	2.90/0.80 [421/116]	2.90/0.80 [421/116]			
switch	BC controller on the liquid side (PS1)/Intermediate part (PS3)		[psi]	2.87/2.55 [416/370]				
		Discharge (TH4)		80 [176]	80 [176]			
		Heat exchanger outlet		5 [41]	5 [41]			
	Heat source	Accumulator inlet		4 [39]	4 [39]			
Sectional	unit	Accumulator outlet	°C [ °F]	4 [39]	4 [39]			
temperatures		Compressor inlet	[ [ ]	4 [39]	4 [39]			
		Compressor shell bottom		40 [104]	40 [104]			
	Indoor	LEV inlet		37	[99]			
	unit	Heat exchanger inlet	]	70	[158]			

				2-unit combination				
		Item		PQRY-P216ZSLMU-A1/B				
			PQRY-P120ZLMU-A1/B PQRY-P96ZLMU-A1/B					
Model name of BC controller				CMB-P1012NU-JA1/2				
	Indoor te	emperature	DB/WB	21.1°C/-	[70 °F/-]			
	Heat sou	irce water temperature	°C [ °F]	21.1	[70]			
	Heat sou	ırce water flow rate	m <sup>3</sup> /h G/h gpm	5.76 [1522] [25.4]	5.76 [1522] [25.4]			
		No. of connected units	Unit	5	5			
Operating	Indoor unit	No. of units in operation	Offic	Ę	5			
conditions		Model	_	36/36/4	8/48/48			
		Main pipe		5	[16-3/8]			
	Pipe length	Branch pipe	m [ft]	10 [32-3/4]				
		Total pipe length		65 [213-1/4]				
	Fan spe	ed	_	Hi				
	Refrigerant charge		kg [lbs-oz]	26.2 [58]				
	Current		Α	22	0			
Heat source unit	Voltage		٧	575				
	Compres	mpressor frequency		81	81			
	Indoor u	nit		332/332/406/406				
LEV opening	BC contr	oller (1/3/4)	Pulse	85/475/41				
LLV opolinig	LEV6			122	84			
	LEV7			41	41			
Pressure	High pressure (after O/S)/ Low pressure (before accumulator)		MPa	2.75/0.80 [399/116]	2.75/0.80 [399/116]			
switch	BC controller on the liquid side (PS1)/Intermediate part (PS3)		[psi]	2.72/2.40 [395/348]				
		Discharge (TH4)		81 [178]	81 [178]			
		Heat exchanger outlet		5 [41]	5 [41]			
	Heat source	Accumulator inlet		4 [39]	4 [39]			
Sectional	unit	Accumulator outlet	°C [ °F]	4 [39]	4 [39]			
temperatures		Compressor inlet	~ [ ' ' ]	4 [39]	4 [39]			
		Compressor shell bottom		40 [104]	40 [104]			
	Indoor	LEV inlet		35	[95]			
	unit	Heat exchanger inlet		70 [158]				

				2-unit combination				
		Item		PQRY-P2402	ZSLMU-A1/B			
				PQRY-P120ZLMU-A1/B PQRY-P120ZLMU-A1/				
Model name o	f BC contr	oller		CMB-P1012NU-JA1/2				
	Indoor te	mperature	DB/WB	21.1°C/-	[70 °F/-]			
	Heat sou	rce water temperature	°C [ °F]	21.1	[70]			
	Heat sou	rce water flow rate	m <sup>3</sup> /h G/h gpm	5.76 [1522] [25.4]	5.76 [1522] [25.4]			
		No. of connected units	Unit	(	3			
Operating	Indoor unit	No. of units in operation	Onit	(	3			
conditions		Model	_	36/36/36	/36/48/48			
		Main pipe		5	[16-3/8]			
	Pipe length	Branch pipe	m [ft]	10	[32-3/4]			
	g	Total pipe length		65 [213-1/4]				
	Fan spee	ed	_	Hi				
	Refrigerant charge		kg [lbs-oz]	26.2 [58]				
	Current		Α	23.3				
Heat source unit	Voltage		V	575				
	Compressor frequency		Hz	90	90			
	Indoor u	nit		332/332/332	/332/406/406			
LEV opening	BC contr	oller (1/3/4)	Pulse	85/500/41				
LEV opening	LEV6		Fuise	122	122			
	LEV7			41	41			
Pressure	High pressure (after O/S)/ Low pressure (before accumulator)		MPa	2.68/0.80 [389/116]	2.68/0.80 [389/116]			
switch	BC controller on the liquid side (PS1)/Intermediate part (PS3)		[psi]	2.64/2.32 [383/336]				
		Discharge (TH4)		81 [178]	81 [178]			
		Heat exchanger outlet		5 [41]	5 [41]			
	Heat source	Accumulator inlet		4 [39]	4 [39]			
Sectional	unit	Accumulator outlet	°C [ °F]	4 [39]	4 [39]			
temperatures		Compressor inlet	ا د ا	4 [39]	4 [39]			
		Compressor shell bottom		40 [104]	40 [104]			
	Indoor	LEV inlet		35	[95]			
	unit	Heat exchanger inlet		70	[158]			

				2-unit combination				
		Item		PQRY-P288ZSLMU-A1/B				
				PQRY-P144ZLMU-A1/B PQRY-P144ZLMU-A1/				
Model name o	f BC contr	oller		CMB-P101	6NU-JA1/2			
Indoor temperature				21.1°C/-	[70 °F/-]			
	Heat sou	ırce water temperature	°C [ °F]	21.1	[70]			
	Heat sou	ırce water flow rate	m <sup>3</sup> /h G/h gpm	7.20 [1902] [31.7]	7.20 [1902] [31.7]			
		No. of connected units	Unit	6	3			
Operating	Indoor unit	No. of units in operation	Offic	6	3			
conditions		Model	-	48/48/48/	/48/48/48			
		Main pipe		5	[16-3/8]			
	Pipe length	Branch pipe	m [ft]	10	[32-3/4]			
		Total pipe length		65 [213-1/4]				
	Fan spee	ed	-	Hi				
	Refrigerant charge		kg [lbs-oz]	22.5 [50]				
	Current		Α	23	3.3			
Heat source unit	Voltage		V	575				
	Compres	ssor frequency	Hz	67	67			
	Indoor u	nit		406/406/406/406/406				
LEV opening	BC contr	oller (1/3/4)	Pulse	85/530/41				
LEV opening	LEV6		i uise	126	126			
	LEV7			41	41			
Pressure		High pressure (after O/S)/ Low pressure (before accumulator)		2.54/0.80 [368/116]	2.54/0.80 [368/116]			
switch	BC controller on the liquid side (PS1)/Intermediate part (PS3)		[psi]	2.51/2.19 [364/318]				
		Discharge (TH4)		80 [176]	80 [176]			
		Heat exchanger outlet		5 [41]	5 [41]			
	Heat source	Accumulator inlet		4 [39]	4 [39]			
Sectional	unit	Accumulator outlet	°C [ °F]	4 [39]	4 [39]			
temperatures		Compressor inlet	[ [ ]	4 [39]	4 [39]			
		Compressor shell bottom		40 [104]	40 [104]			
	Indoor	LEV inlet		36	[97]			
	unit	Heat exchanger inlet		70	[158]			

				2-unit combination				
		Item	PQRY-P312ZSLMU-A1/B					
			PQRY-P168ZLMU-A1/B PQRY-P144ZLMU-A1					
Model name or	f BC contr	oller		CMB-P101	6NU-JA1/2			
	Indoor te	emperature	DB/WB	21.1°C/-	[70 °F/-]			
	Heat sou	irce water temperature	°C [ °F]	21.1	[70]			
	Heat sou	ırce water flow rate	m <sup>3</sup> /h G/h gpm	7.20 [1902] [31.7]	7.20 [1902] [31.7]			
		No. of connected units	Unit	6	3			
Operating	Indoor unit	No. of units in operation	Offic	6	3			
conditions		Model	-	54/54/54/	/54/48/48			
		Main pipe		5	[16-3/8]			
	Pipe length	Branch pipe	m [ft]	10	[32-3/4]			
		Total pipe length		65 [213-1/4]				
	Fan spee	ed	-	Hi				
	Refrigerant charge		kg [lbs-oz]	22.5 [50]				
	Current		Α	26.7				
Heat source unit	Voltage		V	575				
	Compres	ssor frequency	Hz	73	73			
	Indoor u	nit		414/414/414/406/406				
LEV opening	BC contr	oller (1/3/4)	Pulse	85/530/41				
LEV opening	LEV6			145	145			
	LEV7			41	41			
Pressure		High pressure (after O/S)/ Low pressure (before accumulator)		2.58/0.80 [374/116]	2.58/0.80 [374/116]			
switch	BC controller on the liquid side (PS1)/Intermediate part (PS3)		[psi]	2.55/2.23 [370/323]				
		Discharge (TH4)		80 [176]	80 [176]			
		Heat exchanger outlet		5 [41]	5 [41]			
	Heat source	Accumulator inlet		4 [39]	4 [39]			
Sectional	unit	Accumulator outlet	°C [ °F]	4 [39]	4 [39]			
temperatures		Compressor inlet	C[ F]	4 [39]	4 [39]			
		Compressor shell bottom		40 [104]	40 [104]			
	Indoor	LEV inlet		36	[97]			
	unit	Heat exchanger inlet		70	[158]			

				2-unit combination				
		Item		PQRY-P336ZSLMU-A1/B				
			PQRY-P168ZLMU-A1/B PQRY-P168ZLMU-A1/					
Model name o	f BC contr	oller		CMB-P101	6NU-JA1/2			
Indoor temperature				21.1°C/-	[70 °F/-]			
	Heat sou	irce water temperature	°C [ °F]	21.1	[70]			
	Heat sou	ırce water flow rate	m <sup>3</sup> /h G/h gpm	7.20 [1902] [31.7]	7.20 [1902] [31.7]			
		No. of connected units	Unit	7	7			
Operating	Indoor unit	No. of units in operation	Onn	7	7			
conditions		Model	_	48/48/48/4	8/48/48/48			
		Main pipe		5	[16-3/8]			
	Pipe length	Branch pipe	m [ft]	10	[32-3/4]			
		Total pipe length		65 [213-1/4]				
	Fan spee	ed	=	Hi				
	Refrigerant charge		kg [lbs-oz]	23.5 [52]				
	Current		Α	30	1.6			
Heat source unit	Voltage		V	575				
	Compres	ssor frequency	Hz	78	78			
	Indoor u	nit		406/406/406/406/406/406				
LEV opening	BC contr	oller (1/3/4)	Pulse	85/530/41				
LEV opening	LEV6			164	164			
	LEV7			41	41			
Pressure	High pre Low pres	High pressure (after O/S)/ Low pressure (before accumulator)		2.62/0.80 [380/116]	2.62/0.80 [380/116]			
switch	BC controller on the liquid side (PS1)/Intermediate part (PS3)		[psi]	2.59/2.27 [376/329]				
		Discharge (TH4)		81 [178]	81 [178]			
		Heat exchanger outlet		5 [41]	5 [41]			
	Heat source	Accumulator inlet		4 [39]	4 [39]			
Sectional	unit	Accumulator outlet	°C [ °F]	4 [39]	4 [39]			
temperatures		Compressor inlet	ا در ۱	4 [39]	4 [39]			
		Compressor shell bottom		40 [104]	40 [104]			
	Indoor	LEV inlet		37	[99]			
	unit	Heat exchanger inlet		70	[158]			

# IX Troubleshooting

[1]	Error Code Lists	243
[2]	Responding to Error Display on the Remote Controller	247
[3]	Checking Transmission Waveform and for Electrical Noise Interference	322
[4]	Troubleshooting Principal Parts	325
[5]	Refrigerant Leak	360
[6]	Compressor Replacement Instructions	364
[7]	Servicing the BC controller	373
[8]	Troubleshooting Using the Heat source Unit LED Error Display	376

## [1] Error Code Lists

					Sea	rched	l unit		
Error Code	Prelimi- nary error code	Error (prelim- inary) detail code	Error code definition	Heat source unit	Indoor unit	BC controller	LOSSNAY	Remote controller	Notes
0403	4300	01	Serial communication error/Panel communication error	0	0				
0404	-	-	Indoor unit EEPROM abnormality		0				
1102	1202	-	Discharge temperature fault	0					
1301	-	-	Low pressure fault	0					
1302	1402	-	High pressure fault	0					
1500	1600	-	Refrigerant overcharge	0					
-	1605	-	Preliminary suction pressure fault	0					
2000	2100	-	Pump interlock error	0					
2134	2234	-	Abnormal water temperature	0					
2135	2235	-	Water heat exchanger freeze up	0					
2500	-	-	Drain sensor submergence		0				
2502	-	-	Drain pump fault		0	0			
2503	-	-	Drain sensor (Thd) fault		0		0		
2600	-	-	Water leakage				0		
2601	-	-	Water supply cutoff				0		
2602	-	-	Function setting error				0		
4102	4152	-	Open phase	0					
4106	-	-	Transmission power supply fault	0					
4109	-	-	Fan operation status detection error		0				
4115	-	-	Power supply signal sync error	0					
4116	-	-	RPM error/Motor error		0		0		
4121	4171	-	Function setting error	0					
4124	-	-	Electric system not operate due to damper abnormality		0				
		[0]	Backup operation	0					
		[108]	Abnormal bus voltage drop (S/W detection)	0					
4220	4320	[109]	Abnormal bus voltage rise (S/W detection)	0					
		[111]	Logic error	0					
		[131]	Low bus voltage at startup	0					
4230	4330	-	Heatsink overheat protection	0					
4240	4340	-	Overload protection	0					

						Sea	ched	l unit		
Error Code	Prelimi- nary error code	Error (prelim- inary) detail code	Error code definition		Heat source unit	Indoor unit	BC controller	LOSSNAY	Remote controller	Notes
		[0]	Backup operation		0					
		[101]	IPM error		0					
4250	4350	[104]	Short-circuited IPM/G	round fault	0					
4200	4000	[105]	Overcurrent error due	to short-circuited motor	0					
		[106]	Instantaneous overcu	rrent	0					
		[107]	Overcurrent		0					
4260	-	-	Heatsink overheat pro	otection at startup	0					
5101	1202	_	Temperature sensor	Return air temperature (TH21)		0				
0101	1202		fault	OA processing unit inlet temperature (TH4)				0		
				Indoor unit pipe temperature (TH22)		0				
5102	1217	-	Temperature sensor fault	OA processing unit pipe temperature (TH2)				0		
				HIC bypass circuit outlet temperature (TH2)	0					
				Indoor unit gas-side pipe temperature (TH23)		0				
5103	1205	00	Temperature sensor fault	OA processing unit gasside pipe temperature (TH3)				0		
				Pipe temperature at heat exchanger outlet (TH3)	0					
				OA processing unit intake air temperature (TH1)				0		
5104	1202	-	Temperature sensor fault	Outside temperature (TH24)		0				Detectable only by the All- Fresh type in- door units
				Heat source unit discharge temperature (TH4)	0					
5105	1204	-	Temperature sensor fault	Accumulator inlet temperature (TH5)	0					
5106	1216	-	Temperature sensor fault	HIC circuit outlet temperature (TH6)	0					
5107	1221	-	Temperature sensor fault	Water inlet pipe (TH7)	0					
5108	1218	-	Temperature sensor fault	Water outlet pipe (TH8)	0					
5112	1215	-	Temperature sensor fault	Component cooler heat exchanger outlet (THINV)	0					
5115	1203	-	Temperature sensor fault	Shell bottom temperature (TH15)	0					

						Sear	ched	unit		
Error Code	Prelimi- nary error code	Error (prelim- inary) detail code	Error code definition		Heat source unit	Indoor unit	BC controller	LOSSNAY	Remote controller	Notes
5110	1214	[0]	Backup operation		0					
		01	Temperature sensor fault	Heatsink temperature (THHS)	0					
5111	-	-		Liquid inlet temperature (TH11)			0			
5112	-	-	Temperature sensor	Bypass outlet temperature (TH12)			0			
5115	-	-	(BC controller)	LEV3 outlet temperature (TH15)			0			
5116	-	-		LEV3 inlet temperature (TH16)			0			
5201	-	-	High-pressure sensor	fault (63HS1)	0					
5201	1402	-	High-pressure sensor (Heat source unit HPS	fault 6/BC controller PS1)	0		0			
5203	-	-	Intermediate pressure (BC controller PS3)	Intermediate pressure sensor fault (BC controller PS3)			0			
		[0]	Backup operation		0					
		[115]	ACCT sensor fault		0					
5301	4300	[117]	ACCT sensor circuit fa	ACCT sensor circuit fault						
		[119]	Open-circuited IPM/Lo	oose ACCT connector	0					
		[120]	Faulty ACCT wiring		0					
5701	-	-	Loose float switch connector			0				
6201	-	-	Remote controller boa error)	rd fault (nonvolatile memory					0	
6202	-	-	Remote controller boa	ard fault (clock IC error)					0	
6600	-	-	Address overlaps		0	0	0	0	0	
6601	-	-	Polarity setting error		0					
6602	-	-	Transmission process	or hardware error	0	0	0	0	0	
6603	ı	ı	Transmission line bus	busy error	0	0	0	0	0	
6606	-	-	Communication error mission processors	between device and trans-	0	0	0	0	0	
6607	-	-	No ACK error	No ACK error		0	0	0	0	
6608	-	-	No response error		0	0	0	0	0	
6831	-	-	MA controller signal reception error (No signal reception)			0			0	
6832	-	-	MA remote controller signal transmission error (Synchronization error)			0			0	
6833	-	-	MA remote controller signal transmission error (H/ W error)			0			0	
6834	-	-	MA controller signal reception error (Start bit detection error)			0			0	
6841	-	-	A control communication synchronism not recover			0				
6842	-	-	A control communicat hardware trouble	A control communication transmission/reception		0				

					Sear	ched	unit		
Error Code	Prelimi- nary error code	Error (prelim- inary) detail code	Error code definition	Heat source unit	Indoor unit	BC controller	LOSSNAY	Remote controller	Notes
6843	-	-	A control communication start bit detection error		0				
6846	-	-	Start-up time over		0				
7100	-	-	Total capacity error	0					
7101	-	-	Capacity code setting error	0	0		0		
7102	-	-	Wrong number of connected units	0		0			
7105	-	-	Address setting error	0					
7106	-	-	Attribute setting error				0		
7107	-	-	Port setting error			0			
7110	-	-	Connection information signal transmission/reception error	0					
7111	-	-	Remote controller sensor fault		0		0		
7113	-	-	Function setting error	0					
7117	-	-	Model setting error	0					
7130	-	-	Incompatible unit combination	0					

INV board	model	Overload protection Imax (Arms)	Current effective value error (Arms)	Current peak value error (Apeak)	Temperature protec- tion TOL (°C)
	PQHY-P72ZLMU-A1/B	16	23	38	100
	PQHY-P96ZLMU-A1/B	16	23	38	100
INV34Y	PQHY-P120ZLMU-A1/B	16	23	38	100
1144041	PQHY-P144ZLMU-A1/B	27	33	56	100
	PQHY-P168ZLMU-A1/B	27	33	56	100
	PQHY-P192ZLMU-A1/B	27	33	56	100

INV board	model	Overload protection Imax (Arms)	Current effective value error (Arms)	Current peak value error (Apeak)	Temperature protec- tion TOL (°C)
	PQRY-P72ZLMU-A1/B	16	23	38	95
	PQRY-P96ZLMU-A1/B	16	23	38	95
INV34Y	PQRY-P120ZLMU-A1/B	16	23	38	95
1147.041	PQRY-P144ZLMU-A1/B	27	33	56	95
	PQRY-P168ZLMU-A1/B	27	33	56	95
	PQRY-P192ZLMU-A1/B	27	33	56	95

# [2] Responding to Error Display on the Remote Controller

### 1. Error Code

0403

Serial communication error

### 2. Error definition and error detection method

Serial communication error between the control board and the INV board on the compressor.

Detail code 01: Between the control board and the INV board

### 3. Cause, check method and remedy

## (1) Faulty wiring

Check the following wiring connections.

1) Between Control board and INV board

Control board	INV board
CN2	CN2
CN4	CN4
CN61	

# (2) INV board failure and Control board failure

Replace the INV board when the power turns on automatically, even if the power source is reset.

### 1. Error code



Panel communication error

# 2. Error definition and detection method

This error is detected when indoor units cannot successfully receive the signals from the Auto filter cleaning unit for one minute.

### 3. Cause, check method and remedy

	Cause	Check method and remedy
(1)	Incorrect switch setting on the indoor unit circuit board	Check SW3-3 on the indoor unit circuit board Set SW3-3 to ON only when connecting an auto filter cleaning unit.
(2)	Power wire that connects the circuit board on the indoor unit and the circuit board on the cleaning unit is loose.	Check the LED1 (cleaning unit circuit board (microcomputer power)). Lit: Power is supplied properly. Unlit: Check for loose or disconnected power wire between the indoor unit circuit board (CNAC) and the cleaning unit circuit board (CN3A).
(3)	Communication wire that connects the circuit board on the indoor unit and the circuit board on the cleaning unit is loose.	Check the LED4 (cleaning unit circuit board (communication)). Blinking: Normal communication Unlit: Check for loose or disconnected communication wire between the indoor unit circuit board (CN3G) and the cleaning unit
(4)	Panel transceiver circuit fault (cleaning unit)	circuit board (CN3G). If the LED blinks at irregular intervals (normally blinks at 0.5-sec-
(5)	Panel transceiver circuit fault (indoor unit)	ond intervals), electrical interference is suspected. Check the items above, turn the power off, and turn the power
(6)	Electrical interference on the cleaning unit's communication cable	back on. If the error persists, replace either the cleaning unit circuit board or the indoor unit circuit board.

## Note



# A control communication reception error

# 2. Error definition and error detection method

Indoor controller board

Abnormal if data cannot be read normally from the nonvolatile memory of the indoor controller board.

Cause	Check method and remedy
Defective indoor controller board	Replace indoor controller board.



### Discharge temperature fault

### 2. Error definition and error detection method

- 1) If the discharge temperature of 120 °C [248°F] or more is detected during the operation (the first detection), the heat source unit stops once, turns to anti-restart mode for 3 minutes, and restarts after 3 minutes automatically.
- 2) If the discharge temperature of 120° C [248°F] or more is detected again (the second detection) within 30 minutes (PQRY: 5 minutes) after the second stop of the heat source unit described above, the mode will be changed to 3 minute restart mode, then the heat source unit will restart in 3 minutes.
- 3) If the discharge temperature of 120°C [248°F] or more is detected (the 31st (PQRY: third) detection) within 30 minutes (PQRY: 5 minutes) after the stop of the heat source unit described above, the heat source unit will make an error stop, and the error code "1102" will be displayed.
- 4) If the discharge temperature of 120°C [248°F] or more is detected more than 30 minutes (PQRY: 5 minutes) after the previous stop of the heat source unit, the detection is regarded as the first detection, and the operation described in step 1) above will start.
- 5) For 30 minutes (PQRY: 5 minutes) after the stop (e.g. the first stop or the second stop) of the heat source unit, preliminary errors will be displayed on the LED display.

	Cause	Check method and remedy
(1)	Gas leak, gas shortage	Refer to the page on refrigerant amount evaluation.
(2)	Overload operation	Check operating conditions and operation status of indoor/ heat source units.
(3) (4) (5) (6)	LEV failure on the indoor unit  BC controller LEV malfunction Cooling only: LEV3 Cooling main: LEV1,2,3 Heating only or heating main: LEV3  BC controller SVM1 and 2 malfunction → Cooling only  BC controller SVA malfunction → Cooling only or cooling main	Perform a heating operation and check the operation. Cooling: LEV on the indoor unit BC controller LEV1,2,3 Heat source unit LEV1,LEV7 BC controller SVM1,2 BC controller SVA,C Heating: LEV on the indoor unit Heat source unit LEV6,LEV7,SV4a-4d,7a,7b BC controller LEV3 BC controller SVB BC controller SV4a - 4d Refer to the page on troubleshooting LEV.
(7) (8) (9)	BC controller SVB malfunction  → Heating only or heating main  Solenoid valve SV malfunction 4a-4d,7a,7b :heating only, heating main  Heat source unit LEV1,LEV6,LEV7 actuation	
(40)	failure	
(10)	Port address setting error.	Confirm the port address of the indoor unit.
(11)	Closed ball valve	Confirm that the ball valve is fully open.
(12)	Insufficient heat source water flow, heat source water supply cutoff, dirty or clogged water heat exchanger→Heating	Check the water heat exchanger for clogging. Check the heat source water circulation pump.
(13)	Gas leak between low and high pressures (4-way valve failure, Compressor failure, Solenoid valve (SV1a) failure)	Perform a cooling or heating operation and check the operation.
(14)	Thermistor failure (TH4)	Check the thermistor resistor.
(15)	Input circuit failure on the controller board thermistor	Check the inlet air temperature on the LED monitor.

1301

# Low pressure fault

# 2. Error definition and error detection method

When starting the compressor from Stop Mode for the first time if low pressure reads  $0.098MPa\ [14psi]$  immediately before start-up, the operation immediately stops.

	Cause	Check method and remedy
(1)	Inner pressure drop due to a leakage.	Refer to the section on troubleshooting the low pressure
(2)	Low pressure sensor failure	sensor.
(3)	Short-circuited pressure sensor cable due to torn outer rubber	
(4)	A pin on the male connector is missing.	
(5)	Disconnected wire	
(6)	Failure of the low pressure input circuit on the controller board	



### High pressure fault 1 (Heat source unit)

### 2. Error definition and error detection method

- 1) If the pressure of 3.78MPa [548psi] or higher is detected by the pressure sensor during operation (the first detection), the heat source stops once, turns to antirestart mode for 3 minutes, and restarts after 3 minutes automatically.
- 2) If the pressure of 3.78MPa [548psi] or higher is detected by the pressure sensor again (the second detection) within 30 minutes after the first stop of the heat source unit, the heat source unit stops once, turns to anti-restart mode for 3 minutes, and restarts after 3 minutes automatically.
- 3) If the pressure of 3.87MPa [561psi] or higher is detected by the pressure sensor (the third (PQRY: 16th) detection) within 30 minutes of the second stop of the heat source unit, the heat source unit will make an error stop, and the error code "1302" will be displayed.
- 4) If the pressure of 3.78MPa [548psi] or higher is detected more than 30 minutes after the stop of the heat source unit, the detection is regarded as the first detection, and the operation described in step 1) above will start.
- 5) For 30 minutes after the stop of the heat source unit, preliminary errors will be displayed on the LED display.
- 6) The heat source unit makes an error stop immediately when not only the pressure sensor but also the pressure switch detects 4.15<sup>+0,-0.15</sup> MPa [601<sup>+0,-22</sup> psi]

	Cause	Check method and remedy
(1)	Indoor unit LEV actuation failure → Heating	Perform a heating operation and check the op-
(2)	BC controller LEV malfunction Heating only or heating main : Indoor LEV 3	eration. Cooling: LEV on the indoor unit Heat source unit LEV7
(3)	BC controller SVM1 and 2 malfunction →Cooling only	BC controller LEV1,2,3 BC controller SVM1,1b,2,2b BC controller SVA
(4)	BC controller SVA and SVC malfunction  →Cooling only or cooling main	Heating: LEV on the indoor unit Heat source unit LEV7
(5)	BC controller SVB malfunction →Heating only or heating main	BC controller LEV3 BC controller SVM2,2b BC controller SVB Refer to the page on troubleshooting for LEV
(6)	Heat source unit LEV7 actuation failure→Cooling	and solenoid valve.
(7)	Port address setting error.	Confirm the port address of the indoor unit.
(8)	Refrigerant service valve actuation failure	Confirm that the refrigerant service valve is fully open.
(9)	Short cycle on the indoor unit side	Check the indoor units for problems and correct
(10)	Clogged filter on the indoor unit	them, if any.
(11)	Reduced air flow due to dirty fan on the indoor unit fan	
(12)	Dirty heat exchanger of the indoor unit	
(13)	Insufficient heat source water flow	Check the water heat exchanger for clogging.
(14)	Heat source water supply cutoff	Check the heat source water circulation pump.
(15)	Dirty or clogged water heat exchanger Items (13) through (15) above reduce the condensing capability of the unit, resulting in high-pressure rise during heating operation.	
(16)	Solenoid valve (SV1a) malfunction The by-pass valve (SV1a) can not control rise in high pressure.	Refer to the section on troubleshooting the solenoid valve.
(17)	Thermistor failure (TH3, TH7)	Check the thermistor resistor.
(18)	Pressure sensor failure	Refer to the page on the troubleshooting of the high pressure sensor.
(19)	Failure of the thermistor input circuit and pressure sensor input circuit on the controller board	Check the sensor temperature/pressure on the LED monitor.
(20)	Thermistor mounting problem (TH3, TH7)	Check the sensor temperature/pressure on the LED monitor.
(21)	Disconnected male connector on the pressure switch (63H1) or disconnected wire	

# [ IX Troubleshooting ]

	Cause	Check method and remedy
(22)	Voltage drop caused by unstable power supply voltage	Check the input voltage at the power supply terminal TB1.
(23)	SW4(810) setting error	When using the water flow rate control valve, check the type of valve and setting the switch in the following.  *SW4(810) is OFF: 0 V (Fully open), 10 V (Fully closed)  *SW4(810) is ON: 0 V (Fully closed), 10 V (Fully open)
(24)	Broken the water flow rate control valve	Replace the water flow rate control valve



High pressure fault 2 (Heat source unit)

### 2. Error definition and error detection method

If the pressure of 0.098MPa [14psi] or lower is registered on the pressure sensor immediately before start-up, it will trigger an abnormal stop, and error code "1302" will be displayed.

### 3. Cause, check method and remedy

	Cause	Check method and remedy
(1)	Inner pressure drop due to a leakage.	Refer to the page on the troubleshooting of the high
(2)	Pressure sensor failure	pressure sensor.
(3)	Shorted-circuited pressure sensor cable due to torn outer rubber	
(4)	A pin on the male connector on the pressure sensor is missing or contact failure	
(5)	Disconnected pressure sensor cable	
(6)	Failure of the pressure sensor input circuit on the controller board	

### 1. Error Code



# Refrigerant overcharge

### 2. Error definition and error detection method

An error can be detected by the discharge temperature superheat.

- 1) If the formula "ToilSH (Shell bottom SH) ≤ 10°C [18°F]" is satisfied during operation (first detection), the heat source unit stops, goes into the 3-minute restart mode, and starts up in three minutes.
- 2) If the formula "ToilSH (Shell bottom SH) ≤ 10°C [18°F]" is satisfied again within 40 minutes of the first stoppage of the heat source unit (second detection), the unit comes to an abnormal stop, and the error code "1500" appears.
- 3) If the formula "ToilSH (Shell bottom SH) ≤ 10°C [18°F]" is satisfied 40 minutes or more after the first stoppage of the heat source unit, the same sequence as item 1) above (first detection) is followed.
- 4) For 40 minutes after the stop of the heat source unit, preliminary errors will be displayed on the LED display.

	Cause	Check method and remedy
(1)	Overcharged refrigerant	Refer to the page on refrigerant amount evaluation.
(2)	Thermistor input circuit failure on the control board	Check the temperature and pressure readings on the sensor that are displayed on the LED monitor.
(3)	Faulty mounting of thermistor (TH15)	Check the temperature and pressure readings on the thermistor that are displayed on the LED monitor.
(4)	Heat source unit LEV6 and LEV7 actuation failure  Heating	Refer to the section on troubleshooting the LEV.



## Pump interlock error

# 2. Error definition and error detection method

- 1) This error is detected by the pump interlock circuit (TB8 3-4).
- 2) If it is detected that the pump interlock circuit (TB8 3-4) is open (first detection) during operation or immediately before startup, the heat source unit stops and goes into the 3-minute restart delay mode.
- 3) If the pump interlock circuit (TB8 3-4) has remained open for continuous 10 minutes (second detection) since the first stoppage of the heat source unit, the unit will make an abnormal stop, and the error code "2000" appears on the LED.
- 4) For the 10 minutes from the time the heat source stopped is considered a preliminary error, and it is indicated on the LED. During pump interlock preliminary error, while the pump interlock circuit (TB8 3-4) is open, the compressor isn't operated.
- 5) This error is indicated on the LED only when Dip switch SW4 No.919(SW6-10: ON) on the control board of the heat source unit is set to OFF.

	Cause	Check method and remedy
(1)	Heat source water circulation pump fault	Operate the pump, and check for proper operation.
(2)	Broken wire	Check the field wiring for proper installation and conduction.
(3)	Loose connectors or contact failure	Check the control board connector CNOUT, CN63PW, CNAC2, CN510, and I/O board connector CNOUT2, CN-PW, CNAC4, TB9 for proper connection.
(4)	Interlock signal input circuit fault on the I/O board	Replace the I/O board.
(5)	Interlock signal input circuit fault on the control board	If the problem persists, replace the control board.
(6)	SW4(917) setting error	When using pump operation ON signal, set SW4(917) to ON.
(7)	SW4(901) and SW4(917) setting error	When using the water flow rate control valve, check the setting the switches in the following combinations. *Set SW4(901) to OFF and SW4(917) to OFF *Set SW4(901) to ON and SW4(917) to OFF
(8)	SW4(810) setting error	When using the water flow rate control valve, check the type of valve and setting the switch in the following. *SW4(810) is OFF: 0 V (Fully open), 10 V (Fully closed) *SW4(810) is ON: 0 V (Fully closed), 10 V (Fully open)
(9)	Broken the water flow rate control valve	Replace the water flow rate control valve
(10)	Broken the water flow switch	Replace the water flow switch



### Abnormal water temperature

### 2. Error definition and error detection method

- 1) If a water inlet pipe temperature (TH7) of 5°C[41°F] or below OR 50°C[122°F] or above OR a water outlet temperature (TH8) of 70°C[158°F] or above is detected (first detection) during operation, the heat source unit stops, goes into the 3-minute restart delay mode, and automatically restarts after three minutes.
- 2) If a water inlet pipe temperature (TH7) of 5°C[41°F] or below OR 50°C[122°F] or above OR a water outlet temperature (TH8) of 70°C[158°F] or above is detected again (second detection) within 30 minutes of the first stoppage of the heat source unit, the unit will make an abnormal stop, and the error code "2134" appears on the LED.
- 3) If a water inlet pipe temperature (TH7) of 5°C[41°F] or below OR 50°C[122°F] or above OR a water outlet temperature (TH8) of 70°C[158°F] or above is detected after 30 minutes of the first stoppage of the heat source unit, this is considered as the first detection, and the sequence as described in section 1) above is followed.
- 4) The period of 30 minutes after a stoppage of the heat source unit is considered a preliminary error, and a preliminary error code appears on the LED display.

	Cause	Check method and remedy
(1)	Heat source water circulation pump fault	Operate the pump, and check for proper operation.
(2)	Cooling tower or heater problem	Check the cooling tower and heater, and correct any prob- lems found.
(3)	Thermistor fault (TH7, TH8)	Check thermistor resistance.
(4)	Thermistor signal input circuit fault on the control board	Check the sensor reading on the LED.
(5)	Improper installation of thermistor (TH7, TH8)	Check the sensor reading on the LED.



### Water heat exchanger freeze up

### 2. Error definition and error detection method

- 1) If either of the following conditions is detected (first detection) during operation, the heat source unit stops, goes into the 3-minute restart delay mode, and automatically restarts after three minutes.
  - \*Water outlet pipe temperature (TH8) of 4°C[39°F] or below is detected.
  - \*All of the following conditions are continuously met for one minute during Heating-only or Heating-main operation: Compressor frequency < Minimum frequency + 20 AND Evaporation temperature (Te) < -2°C[28°F] AND Accumulator inlet pipe temperature (TH5) ≤ 3°C[37°F].
- 2) If the conditions above 1) are met again within 60 minutes of the first stoppage of the heat source unit (second detection), the unit will make an abnormal stop, and the error code "2135" will appear on the LED.
- 3) If the conditions above 1) are met again after 60 minutes of the first stoppage of the heat source unit, it is considered the first detection, and the sequence as described in section 1) above is followed.
- 4) For the 60 minutes from the time the heat source stopped is considered a preliminary error, and it is indicated on the LED.

	Cause	Check method and remedy
(1)	Heat source water circulation pump fault	Operate the pump, and check for proper operation.
(2)	Heater problem	Check the heater, and correct any problems found.
(3)	Poorly maintained field-installed water pipes	Identify and remove the cause of water flow reduction, such as a clogged strainer or cavitation.
(4)	Dirty or clogged water heat exchanger	Check the pressure difference between the unit's inlet and outlet.
(5)	Thermistor fault (TH5, TH8)	Check thermistor resistance.
(6)	Thermistor signal input circuit fault on the control board	Check the sensor reading on the LED.
(7)	Improper installation of thermistor (TH5, TH8)	Check the sensor reading on the LED.
(8)	SW4(810) setting error	When using the water flow rate control valve, check the type of valve and setting the switch in the following. *SW4(810) is OFF: 0 V (Fully open), 10 V (Fully closed) *SW4(810) is ON: 0 V (Fully closed), 10 V (Fully open)
(9)	Broken the water flow rate control valve	Replace the water flow rate control valve



Drain sensor submergence (Models with a drain sensor)

# 2. Error definition and error detection method

- 1) If an immersion of the drain sensor in the water is detected while the unit is in any mode other than the Cool/Dry mode and when the drain pump goes from OFF to ON, this condition is considered preliminary water leakage. While this error is being detected, humidifier output cannot be turned on.(Applicable to the units manufactured in or after October 1996)
- 2) If the immersion of the sensor in the water is detected four consecutive times at an hour interval, this is considered water leakage, and "2500" appears on the monitor.
- 3) Detection of water leakage is also performed while the unit is stopped.
- 4) Preliminary water leakage is cancelled when the following conditions are met:
  - \*One hour after the preliminary water leakage was detected, it is not detected that the drain pump goes from OFF to ON.
  - \*The operation mode is changed to Cool/Dry.
  - \*Liquid pipe temperature inlet temperature ≤ -10°C[-18°F]

	Cause		Check method and remedy
(1)	Drain water drainage problem  Clogged drain pump Clogged drain piping Backflow of drain water from other units		Check for proper drainage.
(2)	Adhesion of water drops to the drain sensor  Trickling of water along the lead wire Rippling of drain water caused by filter clogging	1) 2)	Check for proper lead wire installation. Check for clogged filter.
(3)	Failure of the relay circuit for the solenoid valve		Replace the relay.
(4)	Indoor unit control board failure  Drain sensor circuit failure		If the above item checks out OK, replace the indoor unit control board.



Drain sensor submergence (Models with a float switch)

### 2. Error definition and error detection method


- If an immersion of the float switch in the water is detected while the unit is in any mode other than the Cool/Dry mode and
  when the drain pump goes from OFF to ON, this condition is considered preliminary water leakage. While this error is being
  detected, humidifier output cannot be turned on.
- 2) If the drain pump turns on within one hour after preliminary water leakage is detected and the above-mentioned condition is detected two consecutive times, water leakage error water leakage is detected, and "2500" appears on the monitor.
- 3) Detection of water leakage is also performed while the unit is stopped.
- 4) Preliminary water leakage is cancelled when the following conditions are met:
  - \*One hour after the preliminary water leakage was detected, it is not detected that the drain pump goes from OFF to ON.
  - \*The operation mode is changed to Cool/Dry.
  - \*Liquid pipe temperature inlet temperature ≤ 10°C[-18°F]

# 3. Cause, check method and remedy

	Cause	Check method and remedy
(1)	Drain water drainage problem  •Clogged drain pump  •Clogged drain piping  •Backflow of drain water from other units	Check for proper drainage.
(2)	Stuck float switch Check for slime in the moving parts of the float switch.	Check for normal operation of the float switch.
(3)	Float switch failure	Check the resistance with the float switch turned on and turned off.

### <Reference>

Drain pump operation triggered by a submergence of the liquid level sensor (except during the Cooing/Dry mode)





Drain pump fault (Models with a drain sensor)

### 2. Error definition and error detection method

- 1) Make the drain sensor thermistor self-heat. If the temperature rise is small, it is interpreted that the sensor is immersed in water. This condition is considered to be a preliminary error, and the unit goes into the 3-minute restart delay mode.
- If another episode of the above condition is detected during the preliminary error, this is considered a drain pump error, and "2502" appears on the monitor.
- 3) This error is always detected while the drain pump is in operation.
- 4) The following criteria are met when the criteria for the forced stoppage of heat source unit (system stoppage) are met.
  - \*"Liquid pipe temperature inlet temperature ≤ 10 °C [ -18°F] " has been detected for 30 minutes.
  - \*The immersion of drain sensor is detected 10 consecutive times.
  - \*The conditions that are listed under items 1) through 3) above are always met before the criteria for the forced stoppage of the heat source unit.
- 5) The indoor unit that detected the conditions that are listed in item 4) above brings the heat source unit in the same refrigerant circuit to an error stop (compressor operation prohibited), and the heat source unit brings all the indoor units in the same refrigerant circuit that are in any mode other than Fan or Stop to an error stop. "2502" appears on the monitor of the units that came to an error stop.
- 6) Forced stoppage of the heat source unit
  - Detection timing: The error is detected whether the unit is in operation or stopped.
- 7) Ending criteria for the forced stoppage of heat source unit
  - Power reset the indoor unit that was identified as the error source and the heat source unit that is connected to the same refrigerant circuit.
  - Forced stoppage of the heat source unit cannot be cancelled by stopping the unit via the remote controller.
  - (Note) Items 1) 3) and 4) 7) are detected independently from each other.

#### Note

The address and attribute that appear on the remote controller are those of the indoor unit (or OA processing unit) that caused the error.

Cause			Check method and remedy
(1)	Drain pump failure		Check for proper functioning of the drain pump.
(2)	Drain water drainage problem  •Clogged drain pump •Clogged drain piping		Check for proper drainage.
(3)	Adhesion of water drops to the drain sensor	1)	Check for proper lead wire installation.
	<ul><li>Trickling of water along the lead wire</li><li>Rippling of drain water caused by filter clogging</li></ul>	2)	Check for clogged filter.
(4)	Indoor unit control board failure  •Drain pump drive circuit failure  •Drain heater output circuit failure		If the above item checks out OK, replace the indoor unit control board.
(5)	Items (1) through (4) above and an indoor unit electronic valve closure failure (leaky valve) occurred simultaneously.		Check the solenoid valves on the indoor unit for leaks.
(6)	Wrong dipswitch setting on the indoor unit controller board  *Dipswitch for the new indoor unit controller board was wrongly set to "unit model without drain pump" instead of "unit model with drain pump" when the board was replaced.		Check for proper dipswitch model setting on the indoor unit controller board.



Drain pump fault (Models with a float switch)

### 2. Error definition and error detection method

- 1) The immersion of sensor tip in water is detected by the ON/OFF signal from the float switch.
  - \*Submergence of the sensor
  - When it is detected that the float switch has been ON for 15 seconds, it is interpreted that the sensor tip is immersed in water.
  - \*Sensor in the air
  - When it is detected that the float switch has been OFF for 15 seconds, it is interpreted that the sensor tip is not immersed in water.
- 2) If it is detected that the float switch has been ON for 3 minutes after the immersion of the sensor tip was detected, this is considered a drain pump failure, and "2502" appears on the monitor.
  - \*The total time it takes for this error to be detected is 3 minutes and 15 seconds, including the time it takes for the first immersion of the sensor tip to be detected.
- 3) Detection of drain pump failure is performed while the unit is stopped.
- 4) The following criteria are met when the criteria for the forced stoppage of heat source unit (system stoppage) are met.
  - \*"Liquid pipe temperature inlet temperature ≤ 10°C [ -18°F] " has been detected for 30 minutes.
  - \*It is detected by the float switch that the sensor tip has been immersed in water for 15 minutes or more.
  - \*The conditions that are listed under items 1) through 3) above are always met before the criteria for the forced stoppage of the heat source unit.
- 5) The indoor unit that detected the conditions that are listed in item 4) above brings the heat source unit in the same refrigerant circuit to an error stop (compressor operation prohibited), and the heat source unit brings all the indoor units in the same refrigerant circuit that are in any mode other than Fan or Stop to an error stop.
- 6) Forced stoppage of the heat source unit
  - Detection timing: The error is detected whether the unit is in operation or stopped.
  - This error is detected whether the unit is in operation or stopped.
- Ending criteria for the forced stoppage of heat source unit
  - Power reset the indoor unit that was identified as the error source and the heat source unit that is connected to the same refrigerant circuit.
  - Forced stoppage of the heat source unit cannot be cancelled by stopping the unit via the remote controller.
  - (Note) Items 1) 3) and 4) 7) are detected independently from each other.

### Note

The address and attribute that appear on the remote controller are those of the indoor unit (or OA processing unit) that caused the error.

	Cause	Check method and remedy
(1)	Drain pump failure	Check for proper functioning of the drain pump mechanism
(2)	Drain water drainage problem  Clogged drain pump Clogged drain piping	Check for proper drainage.
(3)	Stuck float switch Check for slime in the moving parts of the float switch.	Check for normal operation of the float switch.
(4)	Float switch failure	Check the resistance with the float switch turned on and turned off.
(5)	Indoor unit control board failure  Drain pump drive circuit failure Float switch input circuit failure	Replace indoor unit control board.
(6)	Items (1) through (5) above and an indoor unit electronic valve closure failure (leaky valve) occurred simultaneously.	Check the solenoid valves on the indoor unit for leaks.
(7)	Wrong dipswitch setting on the indoor unit controller board  *Dipswitch for the new indoor unit controller board was wrongly set to "unit model without drain pump" instead of "unit model with drain pump" when the board was replaced.	Check for proper dipswitch model setting on the indoor unit controller board.



# Drain sensor (Thd) fault

### 2. Error definition and error detection method

- •If the open or short circuit of the thermistor has been detected for 30 seconds, this condition is considered to be a preliminary error, and the unit goes into the 3-minute restart delay mode.
- •If another episode of the above condition is detected during the preliminary error, this is considered a drain sensor error.(If the short or open circuit of the thermistor is no longer detected, normal operation will be restored in 3 minutes.)
- •This error is detected when one of the following conditions are met.
  - \*During Cool/Dry operation
  - \*Liquid pipe temperature minus inlet temperature is equal to or smaller than 10°C[ -18°F] (except during the defrost cycle)
  - \*When the liquid temperature thermistor or suction temperature thermistor or short or open circuited.
  - \*Drain pump is in operation.
  - \*One hour has elapsed since the drain sensor went off.

Short: 90 °C [194 °F] or above Open: - 20 °C [-4 °F] or below

	Cause		Check method and remedy
(1)	Faulty connector (CN31) insertion.	1)	Check for connector connection failure. Reinsert the connector, restart the operation, and check for proper operation.
(2)	Broken or semi-broken thermistor wire	2)	Check for a broken thermistor wire.
(3)	Thermistor failure	3)	Check the resistance of the thermistor. $0^{\circ}\text{C}[32\ ^\circ\text{F}]:6.0\text{k}\Omega\\ 10^{\circ}\text{C}[50\ ^\circ\text{F}]:3.9\text{k}\Omega\\ 20^{\circ}\text{C}[68^{\circ}\text{F}]:2.6\text{k}\Omega\\ 30^{\circ}\text{C}[86^{\circ}\text{F}]:1.8\text{k}\Omega\\ 40^{\circ}\text{C}[104\ ^\circ\text{F}]:1.3\text{k}\Omega$
(4)	Indoor unit control board (error detection circuit) failure	4)	Replace the indoor unit control board if the problem recurs when the unit is operated with the No1 and No2 pins on the drain sensor connector (CN31) being short-circuited. If the above item checks out OK, there are no problems with the drain sensor.  Turn off the power and turn it back on.



Water leakage

# 2. Cause, check method and remedy

Check that water does not leak from the pipes in such as the humidifier.

# 1. Error Code



Water supply cutoff

# 2. Cause, check method and remedy

Cause		Check method and remedy	
(1)	The water tank of the humidifier is empty.	Check the amount of supply water. Check for the solenoid valve and for the connection.	
(2)	The solenoid valve for humidification is OFF.	Check the connector.	
(3)	Disconnected float switch	Check the connecting part.	
(4)	Poor operation of float switch	Check for the float switch.	
(5)	Frozen water tank	Turn off the power source of the water tank to defrost, and turn it on again.	

# 1. Error Code

2602

**Function setting error** 

Cause		Check method and remedy	
	(1) The function selection switch on the LOSSNAY unit (SW5-5) is set to ON.	Set the function selection switch (SW5-5) on the LOSSNAY unit to OFF.	



Open phase

# 2. Error definition and error detection method

- •An open phase of the power supply (L1 phase, L2 phase) was detected at power on.
  •The L3 phase current is outside of the specified range.

### Note

The open phase of the power supply may not always be detected if a power voltage from another circuit is applied.

	Cause	Check method and remedy
(1)	Power supply problem  Open phase voltage of the power supply Power supply voltage drop	Check the input voltage to the power supply terminal block TB1.
(2)	Noise filter problem ◆Coil problem ◆Circuit board failure	<ul> <li>Check the coil connections.</li> <li>Check for coil burnout.</li> <li>Check that the voltage across TB11 and TB21 on the noise filter board is 517.5 V or above.</li> </ul>
(3)	Poor connector contact (faulty connector insertion)	Check the noise filter board connector (CN2) for proper connection.
(4)	Wiring failure	Confirm that the voltage at the control board connector CNAC is 190 V or above.  If the voltage is below 190 V, check the wiring between the noise filter CNTR, transformer box, and control board CNAC.  Check that the wiring between magnetic contactor (52C) terminal No. 5 and SC-L3 is put through CT3 on the inverter board.
(5)	Blown fuse	Check F01 on the control board, and F01 and F02 on the noise filter board for a blown fuse.  →If a blown fuse is found, check for a short-circuiting or earth fault of the actuator and Transformer T04.
(6)	CT3 failure	Replace the INV board if this problem is detected after the compressor has gone into operation.
(7)	Control board failure	Replace the control board if none of the above is causing the problem.



### <Transmission power supply fault error detail FF (Heat source unit)>

### 2. Error definition and error detection method

Transmission power output failure

# 3. Cause

- 1) Wiring failure
- 2) Transmission power supply cannot output voltage because overcurrent was detected.
- 3) Voltage cannot be output due to transmission power supply problem.
- 4) Transmission voltage detection circuit failure

### 4. Check method and remedy

Check the items in IX [4] -7- (2) Troubleshooting transmission power circuit of heat source unit on all heat source units in the same refrigerant circuit.

## <Transmission power supply fault other than error detail code FF (Heat source unit)>

### 2. Error definition and error detection method

Transmission power reception failure

#### 3. Cause

One of the heat source units stopped supplying power, but no other heat source units start supplying power.

### 4. Check method and remedy

Check the items in IX [4] -7- (2) Troubleshooting transmission power circuit of heat source unit on all heat source units in the same refrigerant circuit.

### 1. Error Code



Indoor unit fan operation error

# 2. Error definition and error detection method

During operation, it has been continuously detected for 100 seconds that the auxiliary relay (X13) for fan fault detection is not excited.

	Cause	Check method and remedy	
(1)	Auxiliary relay (X13) fault	Coil failure, disconnected coil	
(2)	Connector (CN28) is disconnected.	Check the connector for proper connection.	
(3)	Blown fuse	Check the fuse on the control circuit board.	
(4)	Motor error (thermistor error inside the motor)	Check the unit fan for proper operation in the test run mode.  If no problems are found with items (1) through (3) above and the fan does not operate, replace the motor.	



Indoor unit fan motor error

# 2. Error definition and error detection method

When the fan motor output from the indoor unit circuit board is ON and when the rotation speed input from the fan motor cannot be detected for 30 seconds or more

# 3. Cause, check method and remedy

	Cause	Check method and remedy		
(1)	Fan motor connector contact failure	Check the fan motor connector CNMF for proper connection.		
(2)	Contact failure of the relay connector for the fan motor	Check the relay connector for the fan motor for proper connection.		
(3)	Indoor unit circuit board failure	Remove the fan motor connector CNMF and check the voltage at the indoor unit circuit board.  Testing point 1. 280 VDC (Between CNMF1 (+) and CNMF4 (-))  2. 15 VDC (Between CNMF5 (+) and CNMF4 (-))  Replace the indoor unit circuit board if the voltage is abnormal.  If the 4114 error persists after the indoor unit circuit board is replaced, replace the fan motor as well.		
(4)	Fan motor fault	Replace the fan motor if the voltage is normal in step (3) above.  If the 4114 error persists after the fan motor is replaced, replace the indoor unit circuit board as well.		

# 1. Error Code



Power supply signal sync error

# 2. Error definition and error detection method

The frequency cannot be determined when the power is switched on.

	Cause	Check method and remedy
(1)	Power supply error	Check the voltage of the power supply terminal block (TB1).
(2)	Noise filter problem  •Coil problem  •Circuit board failure	Check the coil connections. Check for coil burnout. Check that the voltage across TB11 and TB21 on the noise filter board is 517.5 V or above.
(3)	Poor connector contact (faulty connector insertion)	Check the noise filter circuit board connector (CN2) for proper connection.
(4)	Faulty wiring	Check F01 on the control board and F01and F02 on the noise filter board for a blown fuse.
(5)	Wiring failure Between noise filter CNTR, transformer box, and con- trol board CNAC	Confirm that the voltage at the control board connector CNAC is 190 V or above.
(6)	Control board failure	If none of the items described above is applicable, and if the trouble reappears even after the power is switched on again, replace the control board.



# RPM error/Motor error

# 2. Error definition and error detection method

- \*LOSSNAY
  - \*The motor keep running even if the power is OFF.
  - \*The thermal overload relay is ON. (Only for the three-phase model)
- Indoor unit

If detected less than 180rpm or more than 2000rpm, the indoor unit will restart and keep running for 3 minutes. If detected again, the display will appear.

# 3. Cause, check method and remedy

	Cause	Check method and remedy
(1)	Board failure	Replace the board.
(2)	Motor malfunction	Check for the motor and the solenoid switch.
(3)	Solenoid switch malfunction	

# 1. Error Code



# **Function setting error**

# 2. Error source, cause, check method and remedy

Error source		Cause	Check method and remedy
Heat source unit	t source (1) Dip switch setting error on the control box		Check the SW6-1 setting on the control board.
unit	(2)	Connector connection error on the control board	Check that nothing is connected to the connector CNAF on the control board.
	(3)	Control board failure	Replace the control board if no problems are found with the two items above.

4124

Electric system not operate due to damper abnormality

### 2. Error definition and error detection method

When the damper is not located at the designated position.

### 3. Cause, check method and remedy

When the damper is not located at the designated position.

- 1) Check there is something that interferes the opening or closing movement of the damper.
- 2) If damper does not open or close, turn OFF the power supply and measure the resistance of the damper lock motors (ML1, ML2) and the damper motor (MV2).

The resistance value is normal each. →Replace the indoor electronic control P.C. board.

The resistance value is not normal each. →Replace the motor that indicates the abnormal value.

Part name	Check n	Figure		
Damper lock motor Right(ML1)	Measure the resistance I (Part temperature: 10°C			
Damper lock motor	Color of the lead wire	Normal		RED —
Left(ML2)	BRN-other one	235Ω~255Ω		ROTOR
Damper motor	Measure the resistance l (Part temperature: 10°C		ninals with a tester.	YLW BRN WOOD
(MV2)	Color of the lead wire	Normal		ORN GRN
	BRN-other one	282Ω~306Ω		

3) If damper opens or closes, measure the voltage between CN1X1 (+) and (-) and the voltage between CN1Y1 (+) and (-) during the damper open by pressing VANE CONTROL button.

There is not 0V DC between CN1X1 (+) and (-). →Replace the damper limit switch (open)


There is not 5V DC between CN1X1 (+) and (-). →Replace the damper limit switch (close)

4) If damper opens or closes and voltages in 3) are normal, measure the voltage between CN1X1 (+) and (-) and the voltage between CN1Y1 (+) and (-) during the damper close by pressing VANE CONTROL button.

There is not 5V DC between CN1X1 (+) and (-). →Replace the damper limit switch (open)

There is not 0V DC between CN1X1 (+) and (-). →Replace the damper limit switch (close)

There is 5V DC between CN1X1 (+) and (-) and 0V DC between CN1X1 (+) and (-). →Replace the indoor electronic control P.C. board.





Abnormal bus voltage drop (Detail code 108)

### 2. Error definition and error detection method

If Vdc 437V or less is detected during Inverter operation. (S/W detection)

### 3. Cause, check method and remedy

### (1) Power supply environment

Check whether the unit makes an instantaneous stop when the detection result is abnormal or a power failure occurs. Check whether the power voltage (Between L1 and L2, L2 and L3, and L1 and L3) is 518V or less across all phases.

#### (2) Voltage drop detected

#### 4220

- •Check the voltage between the FT-P and FT-N terminals on the INV board while the inverter is stopped and if it is 630 V or above, check the following items.
  - 1) Confirm on the LED monitor that the bus voltage is above 437V.

Replace the INV board if it is below 437 V.

- 2) Check the voltage at CN503 on the control board.  $\rightarrow$  Go to (3).
- 3) Check the noise filter coil connections and for coil burnout.
- 4) Check the wiring connections between the following sections

Between noise filter board and 52C. Between 52C and INV board.

Replace 52C if no problems are found.

- 5) Check the IGBT module resistance on the INV board (Refer to the Trouble shooting for IGBT module).
- •Check the voltage between the FT-P and FT-N terminals on the INV board while the inverter is stopped and if it is less than 630 V, check the following items.
  - 1) Check the coil connections and for coil burnout on the noise filter.
  - 2) Check the wiring between the noise filter board and INV board.
  - 3) Check the connection to SC-L1 and SC-L2 on the INV board.
  - 4) Check the in-rush current resistor value.
  - 5) Check the 52C resistance value.
  - 6) Check the DCL resistance value.

Replace the INV board if no problems are found.

### (3) Control board failure

Check that 230 VAC is applied to connector CN503 on the control board while the inverter is operating. If voltage is absent or the wrong voltage is applied, check the fuse F01. Replace the control board if no problems are found with the fuse.

#### Note



Abnormal bus voltage rise (Detail code 109)

### 2. Error definition and error detection method

If Vdc ≥ 1010V is detected during inverter operation.

### 3. Cause, check method and remedy

# (1) Different voltage connection

Check the power supply voltage on the power supply terminal block (TB1).

# (2) INV board failure

If the problem recurs, replace the INV board.

### Note

Refer to section -6- "Inverter" under part [4] Troubleshooting Principal Parts for error codes related to the inverter.

#### 1. Error Code



Logic error (Detail code 111)

#### 2. Error definition and error detection method

H/W error

If only the H/W error logic circuit operates, and no identifiable error is detected.

## 3. Cause, Check method and remedy

	Cause	Check method and remedy
(1)	External noise	
(2)	INV board failure	Refer to IX [4] -6- (2) [1].

### Note

Refer to section -6- "Inverter" under part [4] Troubleshooting Principal Parts for error codes related to the inverter.

## 1. Error Code



Low bus voltage at startup (Detail code 131)

### 2. Error definition and error detection method

When Vdc ≤437V is detected just before the inverter operation.

# 3. Cause, check method and remedy

### (1) Inverter main circuit failure

Same as detail code 108 of 4220 error

# Note



### Heatsink overheat protection

# 2. Error definition and error detection method

When the heat sink temperature (THHS) remains at or above TOH is detected.

Model	ТОН
PQHY	105°C [221°F]
PQRY	100°C [212°F]

### 3. Cause, check method and remedy

Cause			Check method and remedy
(1)	Air passage blockage		Check that the heat sink cooling air passage is not blocked
(2)	THHS failure	1)	Check for proper installation of the INV board IGBT. (Check for proper installation of the IGBT heatsink.)
		2)	Check the THHS sensor reading on the LED monitor.  →If an abnormal value appears, replace the INV board.

## Note

Refer to section -6- "Inverter" under part [4] Troubleshooting Principal Parts for error codes related to the inverter.

### 1. Error Code



## Overload protection

### 2. Error definition and error detection method

If the output current of "(lac) >lmax (Arms)" or "THHS > TOL" is continuously detected for 10 minutes during inverter operation. Refer to the relevant pages for the details of model names and the specified values.

# 3. Cause, check method and remedy

	Cause	Check method and remedy	
(1)	Air passage blockage	Check that the heat sink cooling air passage is not blocked	
(2)	Power supply environment	Power supply voltage is 518 V or above.	
(3)	Inverter failure	Refer to IX [4] -6	
(4)	Compressor failure	Check that the compressor has not overheated during operation.  → Check the refrigerant circuit (oil return section).  Refer to IX [4] -6- (2) [2].	

## Note

4250

IPM error (Detail code 101)

# 2. Error definition and error detection method

Overcurrent is detected by the overcurrent detection resistor (RSH) on the INV board.

### 3. Cause, check method and remedy

	Cause	Check method and remedy
(1)	Inverter output related	Refer to IX [4] -6- (2) [1]-[4].
		Check the IGBT module resistance value of the INV board, if no problems are found. (Refer to the Trouble shooting for IGBT module)
(2)	The model selection switches (SW5-3 - 5-8) on the Heat source unit are set incorrectly.	Check the setting for the model selection switch on the Heat source unit (Dipswitches SW5-3 - 5-8 on the Heat source unit control board).

### Note

Refer to section -6- "Inverter" under part [4] Troubleshooting Principal Parts for error codes related to the inverter.

### 1. Error Code



Instantaneous overcurrent (Detail code 106) Overcurrent (Detail code 107)

### 2. Error definition and error detection method

Refer to the relevant pages for the details of model names and the specified values.

# 3. Cause, check method and remedy

	Cause	Check method and remedy
(1)	Inverter output related	Refer to IX [4] -6- (2) [1]-[4].
		Check the IGBT module resistance value of the INV board if no problems are found. (Refer to "Troubleshooting" for IGBT module related problems)
(2)	The model selection switches (SW5-3 - 5-8) on the Heat source unit are set incorrectly.	Check the setting for the model selection switch on the Heat source unit (Dipswitches SW5-3 - 5-8 on the Heat source unit control board).

## Note



Short-circuited IPM/Ground fault (Detail code 104)

### 2. Error definition and error detection method

When IPM/IGBT short damage or grounding on the load side is detected just before starting the inverter.

### 3. Cause, check method and remedy

	Cause	Check method and remedy
(1)	Grounding fault compressor	Refer to IX [4] -6- (2) [2].
(2)	Inverter output related	Refer to IX [4] -6- (2) [1]-[4].

### Note

Refer to section -6- "Inverter" under part [4] Troubleshooting Principal Parts for error codes related to the inverter.

### 1. Error Code



Overcurrent error due to short-circuited motor (Detail code 105)

## 2. Error definition and error detection method

When a short is detected on the load side just before starting the inverter operation.

### 3. Cause, Check method and remedy

	Cause	Check method and remedy
(1)	Short - circuited compressor	Refer to IX [4] -6- (2) [2].
(2)	Output wiring	Check for a short circuit.

# Note

Refer to section -6- "Inverter" under part [4] Troubleshooting Principal Parts for error codes related to the inverter.

# 1. Error Code



Heatsink overheat protection at startup

### 2. Error definition and error detection method

The heatsink temperature (THHS) remains at or above TOH minutes or more at inverter startup.

Model	ТОН
PQHY	105°C [221°F]
PQRY	100°C [212°F]

### 3. Cause, check method and remedy

Same as 4230 error

# Note

5101

Return air temperature sensor (TH21) fault (Indoor unit) Return air temperature sensor (TH4) fault (OA processing unit)

5102

Pipe temperature sensor (TH22) fault (Indoor unit) Pipe temperature sensor (TH2) fault (OA processing unit)

5103

Gas-side pipe temperature sensor (TH23) fault (Indoor unit) Gas-side pipe temperature sensor (TH3) fault (OA processing unit)

5104

Intake air temperature sensor (TH1) fault (OA processing unit) Intake air temperature sensor (TH24) fault (All-fresh (100% outdoor air) type indoor unit)

### 2. Error definition and error detection method

•If a short or an open is detected during thermostat ON, the heat source unit turns to anti-restart mode for 3 minutes. When the error is not restored after 3 minutes (if restored, the heat source unit runs normally), the heat source unit makes an error stop.

Short: detectable at 90°C [194°F] or higher Open: detectable at -40°C [-40°F] or lower

- •Sensor error at gas-side cannot be detected under the following conditions.
  - \*During heating operation
  - \*During cooling operation for 3 minutes after the compressor turns on.

	Cause	Check method and remedy
(1)	Thermistor failure	Check the thermistor resistor.
(2)	Connector contact failure	0°C [32°F]: 15 kohm 10°C [50°F]: 9.7 kohm
(3)	Disconnected wire or partial disconnected thermistor wire	20°C [68°F] : 6.4 kohm 30°C [86°F] : 4.3 kohm 40°C [104°F] : 3.1 kohm
(4)	Unattached thermistor or contact failure	
(5)	Indoor board (detection circuit) failure	Check the connector contact.  When no fault is found, the indoor board is a failure.

5102

HIC bypass circuit outlet temperature sensor (TH2) fault (Heat source unit)

5103

Heat exchanger outlet temperature sensor (TH3) fault (Heat source unit)

5104

Discharge temperature sensor (TH4) fault (Heat source unit)

5105

Accumulator inlet temperature sensor (TH5) fault (Heat source unit)

5106

HIC circuit outlet temperature sensor (TH6) fault (Heat source unit)

5107

Water inlet pipe temperature sensor (TH7) fault (Heat source unit)

5108

Water outlet pipe temperature sensor (TH8) fault (Heat source unit)

5112

Component cooler heat exchanger outlet temperature sensor (THINV) fault (Heat source unit)

5115

Shell bottom temperature sensor (TH15) fault (Heat source unit)

## 2. Error definition and error detection method

- •When a short (high temperature intake) or an open (low temperature intake) of the thermistor is detected (the first detection). the heat source unit stops, turns to anti-restart mode for 3 minutes, and restarts when the detected temperature of the therm-
- •When a short or an open is detected again (the second detection) after the first restart of the heat source unit. the heat source unit stops, turns to anti-restart mode for 3 minutes, and restarts in 3 minutes when the detected temperature is within the normal range.
- •When a short or an open is detected again (the third detection) after the previous restart of the heat source unit, the heat source unit makes an error stop.
- •When a short or an open of the thermistor is detected just before the restart of the heat source unit, the heat source unit makes an error stop, and the error code "5102", "5103", 5104", "5105", "5106", "5107", "5108", "5112", or "5115" will appear.

  •During 3-minute antirestart mode, preliminary errors will be displayed on the LED display.
- •A short or an open described above is not detected for 10 minutes after the compressor start, during defrost mode, or for 3 minutes after defrost mode.

# 3. Cause, check method and remedy

	Cause	Check method and remedy
(1)	Thermistor failure	Check thermistor resistance.
(2)	Pinched lead wire	Check for pinched lead wire.
(3)	Torn wire coating	Check for wire coating.
(4)	A pin on the male connector is missing or contact failure	Check connector.
(5)	Disconnected wire	Check for wire.
(6)	Thermistor input circuit failure on the control board	Check the intake temperature of the sensor with the LED monitor.  When the temperature is far different from the actual temperature, replace the control board.

### <Reference>

	Short detection	Open detection
TH2	70 °C [158 °F] and above (0.4 k $\Omega$ )	-40 $^{\circ}$ C [ -40 $^{\circ}$ F ] and below (130 k $\Omega$ )
TH3	110 °C [230 °F ] and above (0.4 k Ω)	-40 $^{\circ}$ C [ -40 $^{\circ}$ F ] and below (130 k $\Omega$ )
TH4	240 °C [464 °F] and above (0.57 kΩ)	0 $^{\circ}$ C [ 32 $^{\circ}$ F ] and below (698 k $\Omega$ )
TH5	70 °C [158 °F ] and above (0.4 k Ω)	-40 $^{\circ}$ C [ -40 $^{\circ}$ F ] and below (130 k $\Omega$ )
TH6	70 °C [158 F] and above (1.14 k Ω)	-40 $^{\circ}$ C [ -40 $^{\circ}$ F ] and below (130 k $\Omega$ )
TH7	110 °C [230 °F] and above (0.4 k Ω)	-40 $^{\circ}$ C [ -40 $^{\circ}$ F ] and below (130 k $\Omega$ )
TH15	110 °C [230 °F] and above (0.4 k $\Omega$ and below)	-50 $^{\circ}$ C [ -58 $^{\circ}$ F ] and below (241 k $\Omega$ and above)

# 1. Error Code

5110

Heatsink temperature sensor (THHS) fault (Detail code 01)

# 2. Error definition and error detection method

When a short or an open of THHS is detected just before or during the inverter operation.

# 3. Cause, check method and remedy

Cause	Check method and remedy
(1) INV board failure	If the problem recurs when the unit is put into operation, replace the INV board.

# Note



High-pressure sensor fault (63HS1)

# 2. Error definition and error detection method

- •If the high pressure sensor detects 0.098MPa [14psi] or less during the operation, the heat source unit stops once, turns to anti-restart mode for 3 minutes, and restarts after 3 minutes when the detected high pressure sensor is 0.098MPa [14psi] or more.
- •If the high pressure sensor detects 0.098MPa [14psi] or less just before the restart, the heat source unit makes an error stop, and the error code "5201" will appear.
- •During 3-minute antirestart mode, preliminary errors will be displayed on the LED display.
- •A error is not detected for 3 minutes after the compressor start.

	Cause	Check method and remedy
(1)	High pressure sensor failure	Refer to the page on the troubleshooting of the high pressure sensor. (IX [4] -1-)
(2)	Pressure drop due to refrigerant leak	
(3)	Torn wire coating	
(4)	A pin on the male connector is missing or contact failure	
(5)	Disconnected wire	
(6)	High pressure sensor input circuit failure on the control board	



ACCT sensor fault (Detail code 115)

# 2. Error definition and error detection method

When the formula "output current < 2.0 Arms" remains satisfied for 10 seconds while the inverter is in operation.

### 3. Cause, check method and remedy

	Cause	Check method and remedy
(1)	Inverter open output phase	Check the output wiring connections.
(2)	Compressor failure	Refer to IX [4] -6- (2) [2].
(3)	INV board failure	Refer to IX [4] -6- (2) [1], [3], [4].

# Note

Refer to section -6-"Inverter" under part [4] Troubleshooting Principal Parts for error codes related to the inverter.

### 1. Error Code



ACCT sensor circuit fault (Detail code 117)

### 2. Error definition and error detection method

When an error value is detected with the ACCT detection circuit just before the inverter starts

# 3. Cause, check method and remedy

	Cause	Check method and remedy
(1)	INV board failure	Refer to IX [4] -6- (2) [1], [3], [4].
(2)	Compressor failure	Refer to IX [4] -6- (2) [2].

## Note



Open-circuited IPM/Loose ACCT connector (Detail code 119)

### 2. Error definition and error detection method

Presence of enough current cannot be detected during the self-diagnostic operation immediately before inverter startup.

### 3. Cause, check method and remedy

	Cause	Check method and remedy
(1)	Inverter output wiring problem	Check output wiring connections. Confirm that the U- and W-phase output cables are put through CT12 and CT22 on the INV board respectively.
(2)	Inverter failure	Refer to IX [4] -6- (2) [3], [4].
(3)	Compressor failure	Refer to IX [4] -6- (2) [2].

### Note

Refer to section -6- "Inverter" under part [4] Troubleshooting Principal Parts for error codes related to the inverter.

### 1. Error Code



Faulty ACCT wiring (Detail code 120)

### 2. Error definition and error detection method

Presence of target current cannot be detected during the self-diagnostic operation immediately before startup. (Detection of improperly mounted ACCT sensor)

# 3. Cause, check method and remedy

Cause		Check method and remedy
(1)	Inverter output wiring problem	Check output wiring connections. Confirm that the U- and W-phase output cables are put through CT12 and CT22 on the INV board respectively.
(2)	Inverter failure	Refer to IX [4] -6- (2) [3], [4].
(3)	Compressor failure	Refer to IX [4] -6- (2) [2].
(4)	INV board failure	Replace the INV board.

# Note

5701

Loose float switch connector

### 2. Error definition and error detection method

Detection of the disconnected float switch (open-phase condition) during operation

### 3. Cause, check method and remedy

# (1) CN4F disconnection or contact failure

Check for disconnection of the connector (CN4F) on the indoor unit control board.

### 1. Error Code



Remote controller board fault (nonvolatile memory error)

### 2. Error definition and error detection method

This error is detected when the data cannot be read out from the built-in nonvolatile memory on the remote controller.

### 3. Cause, check method and remedy

### (1) Remote controller failure

Replace the remote controller.

### 1. Error Code



Remote controller board fault (clock IC error)

### 2. Error definition and error detection method

This error is detected when the built-in clock on the remote controller is not properly functioning.

# 3. Cause, check method and remedy

# (1) Remote controller failure

Replace the remote controller.



# Address overlaps

# 2. Error definition and error detection method

An error in which signals from more than one indoor units with the same address are received

### Note

The address and attribute that appear on the remote controller indicate the controller that detected the error.

# 3. Cause, check method and remedy

Caus	se	Check method and remedy				
source units, indoor units, Loas M-NET remote controller <example> 6600 "01" appears on the re Unit #01 detected the error. Two or more units in the sys</example>		Find the unit that has the same address as that of the error source.  Once the unit is found, correct the address. Then, turn off the heat source units, indoor units, and LOSSNAY units, keep them all turned off for at least five minutes, and turn them back on.  When air conditioning units are operating normally despite the address overlap error.  Check the transmission wave shape and noise on the transmission line.  Refer to the following page(s). IX [3] Checking Transmission Waveform and for Electrical Noise Interference				

#### 1. Error Code



### Polarity setting error

### 2. Error definition and error detection method

The error detected when transmission processor cannot distinguish the polarities of the M-NET transmission line.

	Cause	Check method and remedy
(1)	No voltage is applied to the M-NET transmission line that AG-150A/GB-50ADA/GB-24A, PAC-YG50ECA, BAC-HD150 is connected to.	Check if power is supplied to the M-NET transmission line of the AG-150A/GB-50ADA/GB-24A, PAC-YG50ECA, BAC-HD150, and correct any problem found.
(2)	M-NET transmission line to which AG-150A/GB-50ADA/GB-24A, PAC-YG50ECA, BAC-HD150 is connected is short-circuited is short-circuited.	lound.



Transmission processor hardware error

#### 2. Error definition and error detection method


Although "0" was surely transmitted by the transmission processor, "1" is displayed on the transmission line.

#### Note

The address/attribute appeared on the display on the remote controller indicates the controller where an error occurred.

#### 3. Cause

- 1) When the wiring work of or the polarity of either the indoor or heat source transmission line is performed or is changed while the power is on, the transmitted data will collide, the wave shape will be changed, and an error will be detected.
- 2) Grounding fault of the transmission line
- 3) When grouping the indoor units that are connected to different heat source units, the male power supply connectors on the multiple heat source units are connected to the female power supply switch connector (CN40).
- 4) When the power supply unit for transmission lines is used in the system connected with MELANS, the male power supply connector is connected to the female power supply switch connector (CN40) on the heat source unit.
- 5) Controller failure of the source of the error
- 6) When the transmission data is changed due to the noise on the transmission line
- 7) Voltage is not applied on the transmission line for centralized control (in case of grouped indoor units connected to different heat source units or in case of the system connected with MELANS)





Transmission line bus busy error

### 2. Error definition and error detection method

- •Generated error when the command cannot be transmitted for 4-10 minutes in a row due to bus-busy
- •Generated error when the command cannot be transmitted to the transmission line for 4-10 minutes in a row due to noise

#### Note

The address/attribute appeared on the display on the remote controller indicates the controller where an error occurred.

### 3. Cause, check method and remedy

	Cause	Check method and remedy
(1)	The transmission processor cannot be transmitted as the short-wavelength voltage like noise exists consecutively on the transmission line.	No noise indicates that the error source controller is a failure. If noise exists, investigate the noise.  → No noise indicates that the error source controller is a failure.  → If noise exists, investigate the noise.
(2)	Error source controller failure	

#### 1. Error Code



Communication error between device and transmission processors

### 2. Error definition and error detection method

Communication error between the main microcomputer on the indoor unit board and the microcomputer for transmission

# Note

The address/attribute appeared on the display on the remote controller indicates the controller where an error occurred.

	Cause	Check method and remedy				
(1)	Data is not properly transmitted due to accidental erroneous operation of the controller of the error source.	Turn off the power source of the heat source and the in- door units.(When the power source is turned off separate- ly, the microcomputer will not be reset, and the error will				
(2)	Error source controller failure	not be corrected.)  → If the same error occurs, the error source controller is a failure.				



No ACK error

# 2. Error definition and error detection method

The error is detected when no acknowledgement (ACK signal) is received after the transmission. (eg. When the data is transmitted six times in a row with 30 seconds interval, the error is detected on the transmission side.)

### Note

The address/attribute appeared on the display on the remote controller indicates the controller which did not provide the response (ACK).

# 3. System configuration

# (1) System with one heat source unit

Error source address	Error dis- play	Detection method		Cause	Check method and remedy		
Heat source unit (OC)	ME re- mote con- troller (RC) MA re- mote con- troller (MA)	No ac- knowl- edgement (ACK) at IC trans- mission to OC	(1) (2) (3) (4)	Contact failure of transmission line of OC or IC  Decrease of transmission line voltage/signal by exceeding acceptable range of transmission wiring. Farthest:200 m [656ft] or less Remote controller wiring: 10m [32ft] or less  Erroneous sizing of transmission line (Not within the range below). Wire diameter: 1.25mm² [AWG16] or more  Heat source unit control board failure	Turn off the power source of the heat source unit, and turn it on again. If the error is accidental, it will run normally. If not, check the causes (1) - (4).		
BC controller (BC)	ME re- mote con- troller (RC) MA re- mote con- troller (MA)	No ac- knowl- edgement (ACK) at IC trans- mission to BC	(1) (2) (3) (4)	When BC controller address is changed or modified during operation.  Faulty or disconnected transmission wiring of BC controller  Disconnected connector of BC controller (CN02)  Faulty control board of BC controller	Turn off the heat source-indoor units for 5 or more minutes, and turn them on again. If the error is accidental, they will run normally. If not, check the causes (1) - (4).		
Indoor unit (IC)	ME re- mote con- troller (RC) MA re- mote con- troller (MA)	No ac- knowl- edgement (ACK) at RC trans- mission to IC	(1) (2) (3) (4) (5)	When IC unit address is changed or modified during operation.  Faulty or disconnected IC transmission wiring  Disconnected IC connector (CN2M)  Indoor unit controller failure  ME remote controller failure	Turn off the heat source- indoor units for 5 or more minutes, and turn them on again. If the error is accidental, they will run normally. If not, check the causes (1) - (5).		
LOSSNA Y (LC)	ME re- mote con- troller (RC) MA re- mote con- troller (MA)	No ac- knowl- edgement (ACK) at IC trans- mission to LC	<ul><li>(1)</li><li>(2)</li><li>(3)</li><li>(4)</li><li>(5)</li></ul>	The power source of LOSSNAY has been shut off.  When the address of LOSSNAY is changed in the middle of the operation  Faulty or disconnected transmission wiring of LOSSNAY  Disconnected connector (CN1) on LOSSNAY  Controller failure of LOSSNAY	Turn off the power source of LOSSNAY and turn it on again. If the error is accidental, it will run normally. If not, check the causes (1) - (5).		
ME re- mote control- ler (RC)	ME re- note mote con- control- troller No ac- knowl- edgement (2)		(2)	Faulty transmission wiring at IC unit side.  Faulty wiring of the transmission line for ME remote controller  When the address of ME remote controller is changed in the middle of the operation  ME remote controller failure	Turn off the power source of the heat source unit for 5 minutes or more, and turn it on again.  If the error is accidental, it will run normally.  If not, check the causes (1) - (4).		



No ACK error

# 2. Error definition and error detection method

The error is detected when no acknowledgement (ACK signal) is received after the transmission. (eg. When the data is transmitted six times in a row with 30 seconds interval, the error is detected on the transmission side.)

#### Note

The address/attribute appeared on the display on the remote controller indicates the controller which did not provide the response (ACK).

# 3. System configuration

# (2) Grouping of units in a system with multiple heat source units

Error source address	Error display	Detection method		Cause		Check method and remedy
Heat source unit (OC)	ME remote controller (RC) MA remote controller (MA)	No acknowl- edgement (ACK) at IC transmission to OC		Same cause as that for system with one heat source unit		Same remedy as that for system with one heat source unit
BC controller (BC)	ME remote controller (RC) MA remote controller (MA)	No acknowl- edgement (ACK) at IC transmission to BC		Same cause as that for system with one heat source unit		Same remedy as that for system with one heat source unit
Indoor unit (IC)	ME remote controller (RC) MA remote controller (MA)	No acknowl- edgement (ACK) at RC transmission to IC	(1)	Same causes as (1) - (5) for system with one heat source unit	1)	Turn off the power sources of the heat source and indoor units for 5 or more minutes, and turn them on again. If the error is accidental, the will run normally. If not, check the cause 2).
			(2)	Disconnection or short circuit of the transmission line for the heat source unit on the terminal block for centralized control line con- nection (TB7)	2)	Check the causes of (1) - (5). If the cause is found, correct it. If no cause is found, check 3).
			(3)	When multiple heat source units are connected and the power source of one of the heat source units has been shut off.	3)	Check the LED displays for troubleshooting on other remote controllers whether an error occurs.
			(4)	The male power supply connector of the heat source unit is not connected to the female power supply switch connector (CN40).		If an error is found,  → If an error is found, check the check code definition, and correct the error.
			(5)	The male power supply connectors on 2 or more heat source units are connected to the female power supply switch connector (CN40) for centralized control.		If no error is found,  → Indoor unit board failure
				If an error occurs, after the unit runs normally once, the following causes may be considered.  •Total capacity error (7100) •Capacity code error (7101) •Error in the number of connected units (7102) •Address setting error (7105)		



No ACK error

# 2. Error definition and error detection method

The error is detected when no acknowledgement (ACK signal) is received after the transmission. (eg. When the data is transmitted six times in a row with 30 seconds interval, the error is detected on the transmission side.)

#### Note

The address/attribute appeared on the display on the remote controller indicates the controller which did not provide the response (ACK).

# 3. System configuration

# (2) Grouping of units in a system with multiple heat source units

Error source address	Error display	Detection method		Cause		Check method and remedy
LOSSNA Y (LC)	ME remote controller (RC) MA remote controller (MA)	No acknowl- edgement (ACK) at IC transmission to LC	(1)	Factors (1) through (5) in the "Factors in system with one heat source unit" (When performing an interlocked operation of the LOSSNAY unit and the indoor units that are connected to different heat source units.)	1)	Turn off the power source of heat source unit for 5 or more minutes, and turn it on again. If the error is accidental, it will run normally. If not, check the cause 2).
			(2)	Disconnection or short circuit of the transmission line for the heat source unit on the terminal block for centralized control line connection (TB7)	2)	Check the causes of (1) - (5). If the cause is found, correct it. If no cause is found, check 3).
			(3)	When multiple heat source units are connected and the power source of one of the heat source units has been shut off.	3)	Same cause as that for indoor unit described in 3)
			(4)	The male power supply connector of the heat source unit is not connected to the female power supply switch connector (CN40).		
			(5)	The male power supply connectors on 2 or more heat source units are connected to the female power supply switch connector (CN40) for centralized control.		
				If an error occurs, after the unit runs normally once, the following causes may be considered.		
				<ul><li>Total capacity error (7100)</li><li>Capacity code error (7101)</li></ul>		
				<ul><li>Error in the number of connected units (7102)</li><li>Address setting error (7105)</li></ul>		



No ACK error

# 2. Error definition and error detection method

The error is detected when no acknowledgement (ACK signal) is received after the transmission. (eg. When the data is transmitted six times in a row with 30 seconds interval, the error is detected on the transmission side.)

#### Note

The address/attribute appeared on the display on the remote controller indicates the controller which did not provide the response (ACK).

# 3. System configuration

# (2) Grouping of units in a system with multiple heat source units

Error source address	Error display	Detection method		Cause		Check method and remedy
ME re- mote con- troller (RC)	ME remote controller (RC) MA remote controller (MA)	No acknowl- edgement (ACK) at IC transmission to RC	(1)	Same causes as (1) - (4) for system with one heat source unit	1)	Turn off the power source of heat source unit for 5 or more minutes, and turn it on again. If the error is accidental, it will run normally. If not, check the cause 2).
			(2)	Disconnection or short circuit of the transmission line for the heat source unit on the terminal block for centralized control line connection (TB7)	2)	Check the causes of (1) - (5). If the cause is found, correct it. If no cause is found, check 3).
			(3)	When multiple heat source units are connected and the power source of one of the heat source units has been shut off.	3)	Same cause as that for indoor unit described in 3)
			(4)	The male power supply connector of the heat source unit is not connected to the female power supply switch connector (CN40).		
			(5)	The male power supply connectors on 2 or more heat source units are connected to the female power supply switch connector (CN40) for centralized control.		
				If the problem recurs after normal operation is restored, the problem is caused by one of the following factors:  •Total capacity error (7100)  •Capacity code setting error (7101)  •Error in the number of		
				connected units (7102)  •Address setting error (7105)		



No ACK error

# 2. Error definition and error detection method

The error is detected when no acknowledgement (ACK signal) is received after the transmission. (eg. When the data is transmitted six times in a row with 30 seconds interval, the error is detected on the transmission side.)

### Note

The address/attribute appeared on the display on the remote controller indicates the controller which did not provide the response (ACK).

# 3. System configuration

Error source address	Error display	Detection method	Cause	Check method and remedy
Heat source unit (OC)	ME remote controller (RC) System control- ler (SC) MA remote controller (MA)	No acknowl- edgement (ACK) at IC transmis- sion to OC	Same cause as that for system with one heat source unit	Same remedy as that for system with one heat source unit
BC controller (BC)	ME remote controller (RC) system control- ler (SC) MA remote controller (MA)	No acknowl- edgement (ACK) at IC transmis- sion to BC	Same cause as that for system with one heat source unit	Same remedy as that for system with one heat source unit



No ACK error

# 2. Error definition and error detection method

The error is detected when no acknowledgement (ACK signal) is received after the transmission. (eg. When the data is transmitted six times in a row with 30 seconds interval, the error is detected on the transmission side.)

### Note

The address/attribute appeared on the display on the remote controller indicates the controller which did not provide the response (ACK).

# 3. System configuration

Error source address	Error display	Detection method		Cause	CI	heck method and remedy								
Indoor unit (IC)	ME remote controller (RC) MA remote controller (MA)	No acknowl- edgement (ACK) at RC transmis- sion to IC		Same as grouping of units in a system with multiple heat source units		Same remedy as that for grouping of units in a system with multiple heat source units								
	System control-	No acknowl-	1.	Error occurrence on some IC		Same remedy as that for								
	ler (SC)	edgement (ACK) at SC transmis-	(1)	Same cause as that for system with one heat source unit		system with one heat source unit								
		sion to IC	2.	Error occurrence on all IC in the system with one heat source unit	1)	Check the LED display for troubleshooting on the heat source unit.								
			(1)	Total capacity error (7100)		•If an error is found,								
			(2)	Capacity code error (7101)		check the check code definition, and correct the error. •If no error is found, check 2).								
			(3)	Error in the number of connected units (7102)										
			(4)	Address setting error (7105)		,								
			(5)	Disconnection or short circuit of the transmission line for the heat source unit on the terminal block for centralized control line connection (TB7)	2)	Check (5) - (7) on the left.								
			(6)	Turn off the power source of the heat source unit										
			(7)	Malfunction of electrical system for the heat source unit										
					İ					ļ	3.	Error occurrence on all IC		Check voltage of the
			(1)	Same causes as (1) - (7) described in 2.		transmission line for centralized control.								
			(2)	(2)	The male power supply connectors on 2 or more heat source units are connected to the female power supply switch connector (CN40) for the transmission line for centralized control.		•20V or more: Check (1) and (2) on the left. •Less than 20V: Check (3) on the left.							
			(3)	Disconnection or shutdown of the power source of the power supply unit for transmission line										
			(4)	System controller (MELANS) malfunction										



No ACK error

# 2. Error definition and error detection method

The error is detected when no acknowledgement (ACK signal) is received after the transmission. (eg. When the data is transmitted six times in a row with 30 seconds interval, the error is detected on the transmission side.)

#### Note

The address/attribute appeared on the display on the remote controller indicates the controller which did not provide the response (ACK).

# 3. System configuration

Error source address	Error display	Detection method		Cause	,	Check method and remedy		
ME re- mote con- troller (RC)	ME remote controller (RC) System con- troller (SC) MA remote controller (MA)	No acknowl- edgement (ACK) at IC transmission to RC		Same as grouping of units in a system with multiple heat source units		Same remedy as that for grouping of units in a system with multiple heat source units		
	System controller (SC)	No acknowl- edgement (ACK) at MELANS	1. (1)	Error occurrence on some IC  Same cause as that for system with one heat source unit		Same remedy as that for system with one heat source unit		
		transmission to RC	2.	Error occurrence on all IC in the system with one heat source unit	1)	Check the LED display for troubleshooting on the heat source unit.		
				(1)	An error is found by the heat source unit. Total capacity error (7100) Capacity code error (7101) Error in the number of connected units (7102) Address setting error (7105)		<ul> <li>If an error is found, check the check code definition, and correct the error.</li> <li>If no error is found, check the cause 2).</li> </ul>	
			(2)	Disconnection or short circuit of the transmission line for the heat source unit on the terminal block for centralized control line connection (TB7)	2)	Check (2) - (4) on the left.		
			(3)	Turn off the power source of the heat source unit				
						(4)	Malfunction of electrical system for the heat source unit	
			3.	Error occurrence on all IC		Check (1) - (4) on the left.		
			(1)	Same causes as (1) - (4) described in 2.				
			(2)	When the power supply unit for transmission lines is used and the male power supply connector is connected to the female power supply switch connector (CN40) for the transmission line for centralized control				
			(3)	Disconnection or shutdown of the power source of the power supply unit for transmission line				
			(4)	System controller (MELANS) mal- function				



No ACK error

# 2. Error definition and error detection method

The error is detected when no acknowledgement (ACK signal) is received after the transmission. (eg. When the data is transmitted six times in a row with 30 seconds interval, the error is detected on the transmission side.)

### Note

The address/attribute appeared on the display on the remote controller indicates the controller which did not provide the response (ACK).

# 3. System configuration

Error source address	Error display	Detection method		Cause	(	Check method and remedy	
System controller	ME remote controller	No acknowl- edgement	1.	Error display on some displays on ME remote controllers		Check (1) - (3) on the left.	
(SC)	(RC) MA remote controller	(ACK) at IC transmission to SC	(1)	Faulty wiring of the transmission line for ME remote controller			
	(MA)		(2)	Disconnection or contact failure of the transmission connector for ME remote controller			
			(3)	ME remote controller failure			
			2.	Error occurrence on all IC in the system with one heat source unit	1)	Check the LED display for troubleshooting on the heat source unit.	
			(1)	An error is found by the heat source unit. Total capacity error (7100) Capacity code error (7101) Error in the number of connected units (7102) Address setting error (7105)		If an error is found, check the check code definition, and correct the error.     If no error is found, check the cause 2)	
			(2)	Disconnection or short circuit of the transmission line for the heat source unit on the terminal block for centralized control line connection (TB7)	2)	Check (2) - (4) on the left.	
			(3)	Turn off the power source of the heat source unit			
			(4)	Malfunction of electrical system for the heat source unit			
			3.	Error display on all displays on ME remote controllers		Check (1) - (4) on the left	
				(1)	Same causes as (1) - (4) described in 2.		
			(2)	When the power supply unit for transmission lines is used and the male power supply connector is connected to the female power supply switch connector (CN40) for the transmission line for centralized control			
			(3)	Disconnection or shutdown of the power source of the power supply unit for transmission line			
			(4)	System controller (MELANS) mal- function			



No ACK error

# 2. Error definition and error detection method

The error is detected when no acknowledgement (ACK signal) is received after the transmission. (eg. When the data is transmitted six times in a row with 30 seconds interval, the error is detected on the transmission side.)

# Note

The address/attribute appeared on the display on the remote controller indicates the controller which did not provide the response (ACK).

# 3. System configuration

# (4) Errors that are not limited to a particular system

Error						
source ad- dress	Error dis- play	Detection method		Cause		Check method and remedy
Address which should not be existed	1	-	(1)	Although the address of ME remote controller has been changed after the group is set using ME remote controller, the indoor unit is keeping the memory of the previous address. The same symptom will appear for the registration with SC.		Delete unnecessary information of non-existing address which some indoor units have. Use either of the following two methods for deletion.
			(2)	Although the address of LOSSNAY has been changed after the interlock registration of LOSSNAY is made using ME remote controller, the indoor unit is keeping the memory of the previous address.	1)	Address deletion by ME remote controller Delete unnecessary address information using the manual setting function of ME remote controller. Refer to this service handbook "IV [2] Group Settings and Interlock Settings via the ME Remote Controller 1. (3) Address deletion.
					2)	Deletion of connection informa- tion of the heat source unit by the deleting switch
						Note that this switch deletes all the group information set via ME remote controller and all the interlock information of LOSSNAY and the indoor unit.  •Turn off the power source of the heat source unit, and wait for 5 minutes.  •Turn on the dip switch (SW5-2) on the heat source unit control board.  •Turn on the power source of the heat source unit, and wait for 5 minutes.  •Turn off the power source of the heat source unit, and wait for 5 minutes.  •Turn off the dip switch (SW5-2) on the heat source unit control board.  • Turn on the power source of the heat source unit control board.



No response error

#### 2. Error definition and error detection method

- •When no response command is returned although acknowledgement (ACK) is received after transmission, an error is detected.
- •When the data is transmitted 10 times in a row with 3 seconds interval, an error is detected on the transmission side.

#### Note

The address/attribute appeared on the display on the remote controller indicates the controller where an error occurred.

#### 3. Cause

- The transmission line work is performed while the power is on, the transmitted data will collide, and the wave shape will be changed.
- 2) The transmission is sent and received repeatedly due to noise.
- 3) Decrease of transmission line voltage/signal by exceeding acceptable range of transmission wiring.

Farthest:200m [656ft] or less

Remote controller wiring:12m [39ft] or less

4) The transmission line voltage/signal is decreased due to erroneous sizing of transmission line.

Wire diameter: 1.25mm<sup>2</sup>[AWG16] or more

### 4. Check method and remedy

- 1) When an error occurs during commissioning, turn off the power sources for the heat source unit, indoor unit, BC controller, and LOSSNAY for 5 or more minutes, and then turn them on again.
  - When they return to normal operation, the cause of the error is the transmission line work performed with the power on.
  - If an error occurs again, check the cause 2).
- 2) Check 3) and 4) above.
  - •If the cause is found, correct it.
  - If no cause is found, check 3).
- 3) Check transmission wave shape/ noise on trans-mission line by following "IX [3] Checking Transmission Waveform and for Electrical Noise Interference".

Noise is the most possible cause of the error "6608".



MA controller signal reception error (No signal reception)

#### 2. Error definition and error detection method

- •Communication between the MA remote controller and the indoor unit is not done properly.
- •No proper data has been received for 3 minutes.

#### 3. Cause

- 1) Contact failure of the remote controller lines of MA remote controller or the indoor unit.
- 2) All the remote controllers are set to SUB.
- 3) Failure to meet wiring regulations
  - ·Wire length
  - ·Wire size
  - Number of remote controllers
  - Number of indoor units
- 4) The remote controller is removed after the installation without turning the power source off.
- 5) Noise interference on the remote controller transmission lines
- 6) Faulty circuit that is on the indoor board and performs transmission/ reception of the signal from the remote controller
- 7) Problems with the circuit on the remote controller that sends or receives the signals from the remote controller

- 1) Check for disconnected or loose transmission lines for the indoor units or MA remote controllers.
- 2) Confirm that the power is supplied to the main power source and the remote controller line.
- 3) Confirm that MA remote controller's capacity limit is not exceeded.
- 4) Check the sub/main setting of the MA remote controllers. One of them must be set to MAIN.
- 5) Diagnose the remote controller (described in the remote controller installation manual).
  - [OK]: no problems with the remote controller (check the wiring regulations)
  - [NG]: Replace the MA remote controller.
  - [6832, 6833, ERC]: Due to noise interference <Go to 6)>
- 6) Check wave shape/noise on MA remote controller line by following "IX [3] Checking Transmission Waveform and for Electrical Noise Interference".
- 7) When no problems are found with items 1) through 6), replace the indoor unit board or the MA remote controller. The following status can be confirmed on LED1 and 2 on the indoor unit board.
  - If LED1 is lit, the main power source of the indoor unit is turned on.
  - •If LED2 is lit, the MA remote controller line is being powered.



### MA remote controller signal transmission error (Synchronization error)

#### 2. Error definition and error detection method

- •MA remote controller and the indoor unit is not done properly.
- •Failure to detect opening in the transmission path and unable to send signals
  - \*Indoor unit: 3 minutes
  - \*Remote controller: 6 seconds

#### 3. Cause

- 1) Contact failure of the remote controller lines of MA remote controller or the indoor unit
- 2) 2 or more remote controllers are set to MAIN
- 3) Overlapped indoor unit address
- 4) Noise interference on the remote controller lines
- 5) Failure to meet wiring regulations
  - •Wire length
  - ◆Wire size
  - Number of remote controllers
  - Number of indoor units
- 6) Problems with the circuit on the remote controller that sends or receives the signals from the remote controller

- 1) Check for disconnected or loose transmission lines for the indoor units or MA remote controllers.
- 2) Confirm that the power is supplied to the main power source and the remote controller line.
- 3) Confirm that MA remote controller's capacity limit is not exceeded.
- 4) Check the sub/main setting of the MA remote controllers. One of them must be set to MAIN.
- 5) Diagnose the remote controller (described in the remote controller installation manual).
  - [OK]: no problems with the remote controller (check the wiring regulations)
  - [NG]: Replace the MA remote controller.
  - [6832, 6833, ERC]: Due to noise interference <Go to 6)>
- 6) Check wave shape/noise on MA remote controller line by following "IX [3] Checking Transmission Waveform and for Electrical Noise Interference".
- 7) When no problems are found with items 1) through 6), replace the indoor unit board or the MA remote controller. The following status can be confirmed on LED1 and 2 on the indoor unit board.
  - •If LED1 is lit, the main power source of the indoor unit is turned on.
  - •If LED2 is lit, the MA remote controller line is being powered.



MA remote controller signal transmission error (Hardware error)

#### 2. Error definition and error detection method

- •Communication between the MA remote controller and the indoor unit is not done properly.
- •An error occurs when the transmitted data and the received data differ for 30 times in a row.

#### 3. Cause

- 1) Contact failure of the remote controller lines of MA remote controller or the indoor unit
- 2) 2 or more remote controllers are set to MAIN
- 3) Overlapped indoor unit address
- 4) Noise interference on the remote controller lines
- 5) Failure to meet wiring regulations
  - Wire length
  - Wire size
  - Number of remote controllers
  - Number of indoor units
- 6) Problems with the circuit on the remote controller that sends or receives the signals from the remote controller

- 1) Check for disconnected or loose transmission lines for the indoor units or MA remote controllers.
- 2) Confirm that the power is supplied to the main power source and the remote controller line.
- 3) Confirm that MA remote controller's capacity limit is not exceeded.
- 4) Check the sub/main setting of the MA remote controllers. One of them must be set to MAIN.
- 5) Diagnose the remote controller (described in the remote controller installation manual).
  - [OK]: no problems with the remote controller (check the wiring regulations)
  - [NG]: Replace the MA remote controller.
  - [6832, 6833, ERC]: Due to noise interference <Go to 6)>
- 6) Check wave shape/noise on MA remote controller line by following "IX [3] Checking Transmission Waveform and for Electrical Noise Interference".
- 7) When no problems are found with items 1) through 6), replace the indoor unit board or the MA remote controller. The following status can be confirmed on LED1 and 2 on the indoor unit board.
  - •If LED1 is lit, the main power source of the indoor unit is turned on.
  - •If LED2 is lit, the MA remote controller line is being powered.



### MA controller signal reception error (Start bit detection error)

#### 2. Error definition and error detection method

- \*Communication between the MA remote controller and the indoor unit is not done properly.
- •No proper data has been received for 2 minutes.

#### 3. Cause

- 1) Contact failure of the remote controller lines of MA remote controller or the indoor unit.
- 2) All the remote controllers are set to SUB.
- 3) Failure to meet wiring regulations
  - •Wire length
  - ·Wire size
  - Number of remote controllers
  - Number of indoor units
- 4) The remote controller is removed after the installation without turning the power source off.
- 5) Noise interference on the remote controller transmission lines
- 6) Faulty circuit that is on the indoor board and performs transmission/ reception of the signal from the remote controller
- 7) Problems with the circuit on the remote controller that sends or receives the signals from the remote controller

- 1) Check for disconnected or loose transmission lines for the indoor units or MA remote controllers.
- 2) Confirm that the power is supplied to the main power source and the remote controller line.
- 3) Confirm that MA remote controller's capacity limit is not exceeded.
- 4) Check the sub/main setting of the MA remote controllers. One of them must be set to MAIN.
- 5) Diagnose the remote controller (described in the remote controller installation manual).
  - [OK]: no problems with the remote controller (check the wiring regulations)
  - [NG]: Replace the MA remote controller.
  - [6832, 6833, ERC]: Due to noise interference <Go to 6)>
- 6) Check wave shape/noise on MA remote controller line by following "IX [3] Checking Transmission Waveform and for Electrical Noise Interference".
- 7) When no problems are found with items 1) through 6), replace the indoor unit board or the MA remote controller. The following status can be confirmed on LED1 and 2 on the indoor unit board.
  - If LED1 is lit, the main power source of the indoor unit is turned on
  - •If LED2 is lit, the MA remote controller line is being powered.



### A control communication synchronism not recover

# 2. Error definition and error detection method

Indoor/heat source unit communication error (Transmitting error) (Heat source unit)

- •Abnormal if "0" receiving is detected 30 times continuously though heat source controller circuit board has transmitted "1".
- •Abnormal if heat source controller circuit board could not find blank of transmission path for 3 minutes.

#### 3. Cause, check method and remedy

	Cause	Check method and remedy
(1)	Indoor/heat source unit connecting wire has contact failure.	Check disconnection or looseness of indoor/ heat source unit connecting wire.
(2)	Defective communication circuit of heat source controller circuit board.	Turn the power off, and on again to check. Replace heat source controller circuit board
(3)	Noise has entered power supply.	if abnormality is displayed again.
(4)	Noise has entered indoor/heat source unit connecting wire.	

### 1. Error Code



### A control communication transmission/reception hardware trouble

#### 2. Error definition and error detection method

Indoor/heat source unit communication error (Transmitting error)

Abnormal if "1" receiving is detected 30 times continuously though indoor controller board has transmitted "0".

	Cause	Check method and remedy
(1)	Defective transmitting receiving circuit of indoor controller board	Turn the power off, and on again to check. If abnormality generates again, replace indoor
(2)	Noise has entered into power supply.	controller board.
(3)	Noise has entered into heat source control wire.	



### A control communication start bit detection error

### 2. Error definition and error detection method

Indoor/heat source unit communication error (Signal receiving error)

- •Abnormal if indoor controller board could not receive any signal normally for 6 minutes after turning the power on.
- •Abnormal if indoor controller board could not receive any signal normally for 3 minutes.
- •Consider the unit as abnormal under the following condition. When 2 or more indoor units are connected to a heat source unit, indoor controller board could not receive a signal for 3 minutes from heat source controller circuit board, a signal which allows heat source controller circuit board to transmit signals.

# 3. Cause, check method and remedy

	Cause	Check method and remedy		
(1)	Contact failure, short circuit or miswiring (converse wiring) of indoor/heat source unit connecting wire	Check disconnecting or looseness of indoor /heat source unit connecting wire of all indoor units or Heat source units.		
(2)	Defective transmitting receiving circuit of heat source controller circuit board.	Turn the power off, and on again to check. If abnormality generates again, replace indoor controller board or heat source controller cir-		
(3)	Defective transmitting receiving circuit of indoor controller board.	cuit board.		
(4)	Noise has entered into indoor/heat source unit connecting wire.	Note: ther indoor controller board may have defect.		
(5)	Defective rush current resistor of heat source power circuit board	Check the rush current resistor on heat source power circuit board with tester. If open is detected, replace the power circuit board.		

#### 1. Error code definition

A control communication start bit detection error

### 2. Error definition and error detection method

Indoor/heat source unit communication error (Signal receiving error) (Heat source unit)

Abnormal if heat source controller circuit board could not receive anything normally for 3 minutes.

	Cause	Check method and remedy
(1)	Contact failure of indoor/heat source unit connecting wire	Check disconnection or looseness of indoor/ heat source unit connecting wire of indoor or heat source units.
(2)	Defective communication circuit of heat source controller circuit board	Turn the power off, and on again to check. Replace indoor controller board or heat
(3)	Defective communication circuit of indoor controller board	source controller circuit board if abnormality is displayed again.
(4)	Noise has entered into indoor/heat source unit connecting wire.	



Start-up time over

# 2. Error definition and error detection method

Start-up time over The unit cannot finish start-up process within 4 minutes after power on.

	Cause	Check method and remedy
(1)	Contact failure of indoor/heat source unit connecting wire	Check disconnection or looseness or polarity of indoor/heat source unit connecting wire of indoor and heat source units.
(2)	Diameter or length of indoor/heat source unit connecting wire is out of specified capacity.	Check diameter and length of indoor/heat source unit connecting wire. Total wiring length: 80 m (including wiring connecting each indoor unit and between indoor and heat source unit) Also check if the connection order of flat cable is S1, S2, S3.
(3)	2 or more heat source units have refrigerant address "0". (In case of group control)	Check if refrigerant addresses are overlapping in case of group control system.
(4)	Noise has entered into power supply or indoor/heat source unit connecting wire.	Check transmission path, and remove the cause.



# **Total capacity error**

# 2. Error definition and error detection method

The model total of indoor units in the system with one heat source unit exceeds limitations.

### 3. Error source, cause, check method and remedy,

After troubleshooting the error using the check methods and remedies shown below, turn the power back on.

Error source		Cau	se			Check method and remedy
Heat source unit	(1)	The model total of tem with one heat so following table.			1)	Check the model total (capacity code total) of units connected.
		<pqhy></pqhy>	<pqhy></pqhy>			Check the model name (capacity code) of the
		Model	Capacity Total	tal		connected indoor unit set by the switch (SW2 on
		P72 model	93			indoor unit board).
		P96 model	124			When the model name set by the switch is differ-
		P120 model	156			ent from that of the unit connected, turn off the
		P144 model	187			power source of the heat source and the indoor units, and change the setting of the model name
		P168 model	218			(capacity code).
		P192 model	249			(capaony coup).
		P216 model	280			
		P240 model	312			
		P288 model	374			
		P312 model	405			
		P336 model	436			
		P360 model	468			
		<pqry></pqry>	Canacity Tatal			
		Model	Capacity Total			
		P72 model P96 model	108			
		P120 model	180			
		P144 model	216			
		P168 model	252			
		P192 model	288			
		P216 model	324			
		P240 model	360			
		P288 model	432			
		P312 model	468			
		P336 model	504			
	(2)	The model selectic 6) on the heat sour rectly.				Check the setting for the model selection switch on the heat source unit (Dipswitches SW5-3 - 5-6 on the heat source unit control board).
			SW5			
		Model 3	4 5 6			
		72 model OFF	ON OFF OF	F		
		96 model ON				
		120 model OFF				
		144 model ON	+ + + + + + + + + + + + + + + + + + + +	_		
		168 model OFF	+ + + -	_		
		192 model ON		_		
	(3)	The heat source ur (OS) that is connectare not properly co	ted to the same:			Confirm that the TB3 on the OC and OS are properly connected.

7101

# Capacity code setting error

# 2. Error definition and error detection method

Connection of incompatible (wrong capacity code) indoor unit or heat source unit

Error source		Cause							Check method and remedy
Heat source unit Indoor unit	(1)	The model na the switch (S *The capacity confirmed by (SW4 (SW6- heat source to	W2) is of th the se 10:OF	· wror e indo elf-dia	ng. oor un ignosi	it can s func	be tion	1)	Check the model name (capacity code) of the indoor unit which has the error source address set by the switch (SW2 on indoor unit board). When the model name set by the switch is different from that of the unit connected, turn off the power source of the heat source and the indoor units, and change the setting of the capacity code.
Heat source unit	5-6) on the heat source unit are set incorrectly.			Check the setting for the model selection switch on the heat source unit (Dipswitches SW5-3 - 5-6 on the heat source unit control board).					
		Model	3	4	N5 5	6			
		72 model		ON	OFF	ЬŬ			
		96 model	ON	ON	OFF	-			
		120 model	OFF	OFF	ON	OFF			
		144 model	ON	ON	ON	OFF			
		168 model	OFF	OFF	OFF	ON			
		192 model	ON	OFF	OFF	ON			



# Wrong number of connected units

# 2. Error definition and error detection method

The number of connected indoor units is "0" or exceeds the allowable value.

Error source	C		Check method and remedy			
Heat source unit	source terminal bloc	nits connected to the heat ck (TB3) for indoor-heat source exceeds limitations described	1)	Check whether the number of units connected to the heat source terminal block (TB3) for indoor-heat source transmission lines does not exceed the limitation. (See (1) and (2) on the left.)  Check (2) - (3) on the left.		
	Number of units  Total number of indoor units	Restriction on the number of units <pqhy> 1 - 18 : P72 model 1 - 24 : P96 model 1 - 30 : P120 model 1 - 36 : P144 model 1 - 42 : P168 model 1 - 48 : P192 model 2 - 50 : P216 model 2 - 50 : P216 model 2 - 50 : P240 - P360 models <pqry> 1 - 18 : P72 model 1 - 24 : P96 model 1 - 30 : P120 model 1 - 36 : P144 model 1 - 42 : P168 model</pqry></pqhy>	3)	Check whether the transmission line for the terminal block for centralized control (TB7) is not connected to the terminal block for the indoor-heat source transmission line (TB3).  Check the setting for the model selection switch on the heat source unit (Dipswitches SW5-7 on the heat source unit control board).		
	Number of BC controllers  Number of Main BC controllers  Number of Sub BC controllers	1 - 48 : P192 model 2 - 50 : P216 - P336 models 1 (P72 - P120 models only) 0 or 1 0 - 11				
	Total number of LOSSNAY units (During auto address start-up only)  Total number of heat source units	0 or 1  1: P72 - P120 models 2: P144 - P240 models 3: P288 - P360 models				
	source unit or BC co.  (3) Short-circuited trans When (2) and (3) appear.  •M-NET remote co.	smission line oply, the following display will introller on the remote controller bewered.				
	source unit is set to  (5) Heat source unit ad  The heat source un  cuit do not have sec	n switch (SW5-7) on the heat OFF. (Normally set to ON) dress setting error its in the same refrigerant cir- quential address numbers.	Ļ			

7105

# Address setting error

# 2. Error definition and error detection method

Erroneous setting of OC unit address Erroneous setting of BC controller address

# 3. Cause, check method and remedy

Error source	Cause	Check method and remedy
Heat source unit BC controller	Erroneous setting of OC unit address The address of heat source unit is not being set to 51 - 100. The address of BC controller is not set to 51 - 100.	Check that the heat source unit and BC controller addresses are set to 00 or a number between 51 and 100.  If the heat source unit address is out of the valid range, reset the address with the power to the heat source unit turned off.  If the BC controller address is out of the valid range, reset the address with the power to both the heat source unit and BC controller turned off.

### 1. Error Code

7106

# Attribute setting error

### 2. Error definition and error detection method

Error source	Cause	Check method and remedy				
-	A remote controller for use with indoor units, such as the MA remote controller, is connected to the OA processing unit whose attribute is FU.	To operate the OA processing unit directly via a remote controller for use with indoor units, such as the MA remote controller, set the DIP SW 3-1 on the OA processing unit to ON.				
		Operation Method SW3-1				
		Interlocked operation with the indoor unit OFF				
		Direct operation via the MA remote controller ON				

7107

# Port setting error

# 2. Error definition and error detection method

The port with wrong number is connected to the indoor unit. The model total connected to the port is greater than the specification.

		Check method and remedy
(1)	Model total of indoor units per each port or per each port merge is greater than the specification.  Total port number   Model total   Single branching   54   2 branches merge   96	Before resetting the port number using the port number setting switch or the model using the model (capacity code) setting switch, turn off the power of the heat source unit, the BC controller and the indoor unit.
(2)	4 or more indoor units are connected to the same port.	
(3)	When two ports are used, the port with the smaller number is not connected to the indoor unit.	
(4)	For the address of the BC controller (Sub1 - 11), 50 is not added to the smallest indoor unit address, which is connected to the BC controller (Sub1 - 11).	
(5)	In the system to which multiple BC controllers are connected, the indoor unit address connected to the BC controller is not set as shown below.  (i) The indoor unit address which is connected to the BC controller (main)  (ii) The indoor unit address which is connected to the BC controller (Sub N)  (iii) The indoor unit address which is connected to the BC controller (Sub N + 1)  Address setting  (i)<(ii)<(iii) <td></td>	
	Is there a BC Oontroller (Sub)?  NO	For the address of the BC controller (Sub), is 50 added to the smallest indoor unit address, which is connected to the BC controller (Sub)?  YES
	Connected to the same port?  Port No. setting error?  Change the port No.  Is the model total of indoor  units connected to the same port  greater than the item (1)?  NO  YES  Adjust the piping connection to the port.	Is the address of the indoor unit, which is conceled to the the BC controller (Main),smaller than that of the indoor, which is connected to the BC controller (Sub1 - 11)?  Change the indoor unit address or change the BC controller address or
	When two ports are used, Is the port with the smallest number connected to the indoor unit?  NO  The wrong model (capacity code) is set.  Change the port No.  Change the port No.  Change the set indoor unit model (capacity code).	Is the formula "Address of the indoor unit connected to BC confoller (sub IV)" ridnoor unit address of the BC controller (sub IV) rivue?
	(2) (3) (4)	each port merge is greater than the specification.    Total port number   Model total   Single branching   54   2 branches merge   96

7110

# Connection information signal transmission/reception error

# 2. Error definition and error detection method

The given indoor unit is inoperable because it is not properly connected to the heat source unit in the same system.

### 3. Error source, cause, check method and remedy

Error source		Cause		Check method and remedy
Heat source unit	(1)	Power to the transmission booster is cut off.	1)	Confirm that the power to the transmission booster is not cut off by the booster being connected to the switch on the indoor unit. (The unit will not function properly unless the transmission booster is turned on.)
	(2)	Power resetting of the transmission booster and heat source unit.		→Reset the power to the heat source unit.
	(3)	Wiring failure between OC and OS	2)	Confirm that the TB3 on the OC and OS are properly connected.
	(4)	Broken wire between OC and OS.	3)	Check the model selection switch on the
	(5)	The model selection switch (SW5-7) on the heat source unit is set to OFF. (Normally set to ON)		heat source unit (Dipswitch SW5-7 on the control board.).

### 1. Error Code



# Remote controller sensor fault

### 2. Error definition and error detection method

This error occurs when the temperature data is not sent although the remote controller sensor is specified.

Error source	Cause	Check method and remedy
Indoor unit OA process- ing unit	The remote controller without the temperature sensor (the wireless remote controller or the ME compact remote controller (mounted type)) is used and the remote controller sensor for the indoor unit is specified. (SW1-1 is ON.)	Replace the remote controller with the one with built-in temperature sensor.

7113

Function setting error (improper connection of CNTYP)

Error source		Cause		Check method and remedy
Heat source	(1)	Wiring fault	(Det	ail code 15)
unit	(2)	Loose connectors, short-circuit, contact failure	1)	Check the connector CNTYP5 on the control board for proper connection.
			(Det	tail code 14)
	(3)	Incompatible control board and INV board (replacement with a wrong circuit board)	1)	Check the connector CNTYP4 on the control board for proper connection.
			2)	Check the connector CNTYP5 on the control board for proper connection.
	(4)	DIP SW setting error on the control board	3)	Check the settings of SW5-3 through SW5-6 on the control board.
			(Det	tail code 12)
			1)	Check the connector CNTYP2 on the control board for proper connection.
			2)	Check the connector CNTYP5 on the control board for proper connection.
			3)	Check the connector CNTYP4 on the control board for proper connection.
			4)	Check the settings of SW5-3 through SW5-6 on the control board.
			(Det	tail code 0, 1)
			1)	Check the wiring between the control board and INV board. (Refer to the section on Error code 0403.)
			2)	Check the settings of SW5-3 through SW5-6 on the control board.
			3)	Check the connector CNTYP5 on the control board for proper connection.
			4)	Check the connector CNTYP4 on the control board for proper connection.
			(Det	tail code Miscellaneous)
				*If a set-model-name identification error occurs, check the detail code on the unit on which the error occurred. The detail code that appears on other units will be dif- ferent from the ones shown above.

7117

Model setting error

Error source		Cause		Check method and remedy
Heat source unit	(1)	(1) Wiring fault (Detail code 15)		tail code 15)
	(2)	Loose connectors, short-circuit, contact failure	1)	Check the connector CNTYP5 on the control board for proper connection.
			(Detail code 14)	
			1)	Check the connector CNTYP4 on the control board for proper connection.
			(Detail code 12)	
			1)	Check the connector CNTYP2 on the control board for proper connection.
			2)	Check the connector CNTYP5 on the control board for proper connection.
			(Detail code 0, 1)	
			1)	Check the wiring between the control board and INV board. (Refer to the section on Error code 0403.)
			2)	Check the settings of SW5-3 through SW5-6 on the control board.
			3)	Check the connector CNTYP5 on the control board for proper connection.
			4)	Check the connector CNTYP4 on the control board for proper connection.
			(De	tail code Miscellaneous)
				*If a set-model-name identification error occurs, check the detail code on the unit on which the error occurred. The detail code that appears on other units will be dif- ferent from the ones shown above.



# Incompatible unit combination

# 2. Error definition and error detection method

The check code will appear when the indoor units with different refrigerant systems are connected.

Error source	Cause	Check method and remedy
Heat source unit	(1) The connected indoor unit or BC cont exclusively for use with R22 or R4070 compatible indoor unit or BC controlle nected. The M-NET connection adapter is cor to the indoor unit system in a system in the Slim Model (A control) of units are nected to the M-NET.	door unit and the BC controller. Check whether the connecting adapter for M-NET is not connected to the indoor unit. (Connect the connecting adapter for M-NET to the heat source unit.)
	(2) Combination of heat source units Incorrect combination of heat source u and OS. Only the combinations listed System configuration" are allowed. In tion, the connected heat source units mix old and new model names.	Check whether the combination of the heat source units is as per "II [1] System configu-

# -1- Troubleshooting according to the remote controller malfunction or the external input error In the case of MA remote controller

#### 1. Phenomena

Even if the operation button on the remote controller is pressed, the display remains unlit and the unit does not start running.(Power indicator ① does not appear on the screen.)

### (1) Cause

- 1) The power is not supplied to the indoor unit.
  - •The main power of the indoor unit is not on.
  - •The connector on the indoor unit board has come off.
  - \*The fuse on the indoor unit board has melted.
  - Transformer failure and disconnected wire of the indoor unit.
- 2) Incorrect wiring for the MA remote controller
  - \*Disconnected wire for the MA remote controller or disconnected line to the terminal block.
  - Short-circuited MA remote controller wiring
  - •Incorrect wiring of the MA remote controller cables
  - •Incorrect connection of the MA remote wiring to the terminal block for transmission line (TB5) on the indoor unit
  - •Wiring mixup between the MA remote controller cable and 220 240 VAC power supply cable
  - •Reversed connection of the wire for the MA remote controller and the M-NET transmission line on the indoor unit
- 3) The number of the MA remote controllers that are connected to an indoor unit exceeds the allowable range (2 units).
- 4) The length or the diameter of the wire for the MA remote controller are out of specification.
- 5) Short circuit of the wire for the remote display output of the heat source unit or reversed polarity connection of the relay.
- 6) The indoor unit board failure
- 7) MA remote controller failure

- 1) Measure voltages of the MA remote controller terminal (among 1 to 3).
  - •If the voltage is between DC 9 and 12V, the remote controller is a failure.
  - •If no voltage is applied, check the causes 1) and 3) and if the cause is found, correct it. If no cause is found, refer to 2).
- 2) Remove the wire for the remote controller from the terminal block (TB13) on the MA remote controller for the indoor unit, and check voltage among 1 to 3.
  - •If the voltage is between DC 9 and 12 V, check the causes 2) and 4) and if the cause is found, correct it.
  - \*If no voltage is applied, check the cause 1) and if the cause is found, correct it.
  - If no cause is found, check the wire for the remote display output (relay polarity).
  - If no further cause is found, replace the indoor unit board.

#### In the case of MA remote controller

### 2. Phenomena


When the remote controller operation SW is turned on, the operation status briefly appears on the display, then it goes off, and the display lights out immediately, and the unit stops.

#### (1) Cause

- 1) The power for the M-NET transmission line is not supplied from the heat source unit.
- 2) Short circuit of the transmission line.
- 3) Incorrect wiring of the M-NET transmission line on the heat source unit.
  - Disconnected wire for the MA remote controller or disconnected line to the terminal block.
  - •The indoor transmission line is connected incorrectly to the transmission terminal block for centralized controller (TB7).
  - •The male power supply connectors on the multiple heat source units are connected to the female power supply switch connector (CN40).
  - In the system to which the power supply unit for transmission lines is connected, the male power supply connector is connected to the female power supply switch connector (CN40) on the heat source unit.
- 4) Disconnected M-NET transmission line on the indoor unit side.
- 5) Disconnected wire between the terminal block for M-NET line (TB5) of the indoor unit and the indoor unit board (CN2M) or disconnected connector.

# (2) Check method and remedy

1) When 2) and 3) above apply, check code 7102 will be displayed on the self-diagnosis LED on the heat source unit.



Refer to IX [4] -7- (2) "Troubleshooting transmission power circuit of heat source unit" for how to check item 1 in the flow chart above.

#### In the case of MA remote controller

#### 3. Phenomena


"HO" or "PLEASE WAIT" display on the remote controller does not disappear, and no operation is performed even if the button is pressed. ("HO" or "PLEASE WAIT" display will normally turn off 5 minutes later after the power on.)

### (1) Cause

- 1) The power for the M-NET transmission line is not supplied from the heat source unit.
- 2) Short-circuited transmission line
- 3) Incorrect wiring of the M-NET transmission line on the heat source unit.
  - Disconnected wire for the MA remote controller or disconnected line to the terminal block.
  - •The indoor transmission line is connected incorrectly to the transmission terminal block for centralized controller (TB7).
  - •The male power supply connectors on the multiple heat source units are connected to the female power supply switch connector (CN40).
  - In the system to which the power supply unit for transmission lines is connected, the male power supply connector is connected to the female power supply switch connector (CN40) on the heat source unit
- 4) Disconnected M-NET transmission line on the indoor unit.
- 5) Disconnected wire between the terminal block for M-NET line (TB5) of the indoor unit and the indoor unit board (CN2M) or disconnected connector.
- 6) Incorrect wiring for the MA remote controller
  - ·Short-circuited wire for the MA remote controller
  - \*Disconnected wire for the MA remote controller (No.2) and disconnected line to the terminal block.
  - •Reversed daisy-chain connection between groups
  - •Incorrect wiring for the MA remote controller to the terminal block for transmission line connection (TB5) on the indoor unit •The M-NET transmission line is connected incorrectly to the terminal block (TB13) for the MA remote controller.
- 7) The sub/main setting of the MA remote controller is set to sub.
- 8) 2 or more main MA remote controllers are connected.
- 9) Indoor unit board failure (MA remote controller communication circuit)
- 10) Remote controller failure
- 11) Heat source unit failure (Refer to IX [8] Troubleshooting Using the Heat source Unit LED Error Display.)

#### (2) Check method and remedy


1) When 2) and 3) above apply, check code 7102 will be displayed on the self-diagnosis LED on the heat source unit.



Refer to IX [4] -7- (2) "Troubleshooting transmission power circuit of heat source unit" for how to check item 1 in the flow chart above.

Flow chart

Even if the operation button on the remote controller is pressed, the indoor and the heat source units do not start running.



### In case of ME remote controller

# 1. Phenomena

Even if the operation button on the remote controller is pressed, the display remains unlit and the unit does not start running. (Power indicator • does not appear on the screen.)

### (1) Cause

- 1) The power for the M-NET transmission line is not supplied from the indoor unit.
- 2) Short circuit of the transmission line.
- 3) Incorrect wiring of the M-NET transmission line on the heat source unit.
  - •Disconnected wire for the MA remote controller or disconnected line to the terminal block.
  - •The indoor transmission line is connected incorrectly to the transmission terminal block for centralized controller (TB7).
- 4) Disconnected transmission line on the remote controller.
- 5) Remote controller failure
- 6) Heat source unit failure (Refer to IX [8] Troubleshooting Using the Heat source Unit LED Error Display.)

- 1) Check voltage of the transmission terminal block for of the ME remote controller.
  - •If voltage between is 17V and 30V→ ME remote controller failure
- When voltage is 17V or less→ Refer to IX [4] -7- (2) "Troubleshooting transmission power circuit of heat source unit".
   When 2) and 3) above apply, check code 7102 will be displayed on the self-diagnosis LED on the heat source unit.

### In case of ME remote controller

#### 2. Phenomena

When the remote controller operation SW is turned on, a temporary operation display is indicated, and the display lights out immediately.


### (1) Cause

#### 1) The power is not supplied to the indoor unit.

- •The main power of the indoor unit (AC208/230V) is not on.
- •The connector on the indoor unit board has come off.
- •The fuse on the indoor unit board has melted.
- •Transformer failure and disconnected wire of the indoor unit
- The indoor unit board failure

### 2) The heat source control board failure

As the indoor unit does not interact with the heat source unit, the heat source unit model cannot be recognized.



#### In case of ME remote controller

#### 3. Phenomena

"HO" display on the remote controller does not disappear, and no operation is performed even if the button is pressed.

#### (1) Cause

### Without using MELANS

- 1) Heat source unit address is set to "00"
- 2) A wrong address is set.
  - •The address of the indoor unit that is connected to the remote controller is incorrect. (It should equal the ME remote controller address plus 100.)
  - A wrong address is set to the ME remote controller. (100 must be added to the address of the indoor unit.)
- 3) Faulty wiring of the terminal block for transmission line (TB5) of the indoor unit in the same group with the remote controller.
- 4) The centralized control switch (SW5-1) on the heat source unit is set to ON.
- 5) Disconnection or faulty wiring of indoor unit transmission line.
- 6) Disconnection between the terminal block for M-NET line connection (TB5) of the indoor unit and the male connector (CN2M)
- 7) The male power supply connectors on 2 or more heat source units are connected to the female power supply switch connector (CN40) for the transmission line for centralized control.
- 8) Heat source unit control board failure
- 9) Indoor unit control board failure
- 10) Remote controller failure


#### Interlocking control with MELANS

- 1) No group registration is made using MELANS. (The indoor unit and the ME remote controller are not grouped.)
- 2) Disconnected transmission line for centralized control (TB7) of the heat source unit
- 3) The male power supply connector is connected to CN40 on more than one heat source unit, or the connected to CN40 on the heat source unit in the system to which a power supply unit for transmission line is connected.

#### **Using MELANS**

1) When MELANS is used, "HO" display on the remote controller will disappear when the indoor unit and the local remote controller (ME remote controller) are grouped.

If "HO" does not disappear after the registration, check the causes (2) 1) - 3).



<sup>\*1.</sup> When the heat source unit address is set to 1 - 50, the address will be forcibly set to 100.

# In case of ME remote controller

# 4. Phenomena

"88" appears on the remote controller when the address is registered or confirmed.

# (1) Cause, check method and remedy

Cause			Check method and remedy
An error occurs when the address is registered or confirmed. (common)			
1.	A wrong address is set to the unit to be coupled.	(1)	Confirm the address of unit to be coupled.
2.	The transmission line of the unit to be coupled is disconnected or is not connected.	(2)	Check the connection of transmission line.
3.	Circuit board failure of the unit to be coupled	(3)	Check voltage of the terminal block for transmission line of the unit to be coupled.
		1)	Normal if voltage is between DC17 and 30V.
4.	Improper transmission line work	2)	Check (4) in case other than 1).
	erates at interlocking registration between SNAY and the indoor unit		
5.	The power of LOSSNAY is OFF.	(4)	Check for the main power of LOSSNAY.
syste	erates at confirmation of controllers used in the em in which the indoor units connected to different source units are grouped		
6.	The power of the heat source unit to be confirmed has been cut off.	(5)	Check the power supply of the heat source unit which is coupled with the unit to be confirmed.
7.	The power of the heat source unit to be confirmed has been cut off.	(6)	Check that the transmission line for centralized control (TB7) of the heat source unit is not disconnected.
8.	When the indoor units connected to different heat source units are grouped without MELANS, the male power supply connector is not connected to the female power supply switch connector (CN40) for the transmission line for centralized control.	(7)	Check voltage of the transmission line for centralized control.
9.	The male power supply connectors on 2 or more heat source units are connected to the female power supply switch connector (CN40) for the transmission line for centralized control.	1)	Normal when voltage is between 10V and 30V
10.	In the system to which MELANS is connected, the male power supply connector is connected to the female power supply switch connector (CN40) for the transmission line for centralized control.	2)	Check 8 - 11 described on the left in case other than 1).
11.	Short circuit of the transmission line for centralized control		

# Both for MA remote controller and ME remote controller

# 1. Phenomena

Although cooling operation starts with the normal remote controller display, the capacity is not enough

# (1) Cause, check method and remedy

Cause		Check method and remedy
Compressor frequency does not rise sufficiently.     Faulty detection of pressure sensor.     Protection works and compressor frequency does not rise due to high discharge temperature     Protection works and compressor frequency does not rise due to high pressure     Pressure drops excessively.     The high temperature of the heatsink on the INV board triggers the protection mechanism that keeps the compressor frequency from rising.	(1) Note:	Check pressure difference between the detected pressure by the pressure sensor and the actual pressure with self-diagnosis LED.  → If the accurate pressure is not detected, check the pressure sensor. (Refer to the page on Trouble-shooting of Pressure Sensor).  Lower inlet pressure by the low pressure sensor than the actual pressure causes insufficient capacity.  SW4 setting (SW6-10:OFF)
		Low pressure sensor  SW4 ON 1 2 3 4 5 6 7 8 9 10  1 2 3 4 5 6 7 8 9 10
	(2)	Check temperature difference between the evaporating temperature (Te) and the target evaporating temperature (Tem) with self-diagnosis LED.
	Note:	Higher Te than Tem causes insufficient capacity. SW4 setting (SW6-10:OFF)
		Evaporating temperature Te  SW4 ON  1 2 3 4 5 6 7 8 9 10  Target evaporating temperature Tem  SW4 ON  1 2 3 4 5 6 7 8 9 10
	Note:	Protection works and compressor frequency does not rise even at higher Te than Tem due to high discharge temperature and high pressure.  At high discharge temperature: Refer to 1102. At high pressure: Refer to 1302.
	(3)	Fan problem, fan connection fault Check to see if the fan is rotating while the heat-source unit is in operation. If the fan is rotating -> Check the items listed under 4230. If the fan is not rotating -> Check the fan wires for proper connection. If the fan wires are properly connected, check that the voltage at the connector CN502 on the control board is 188 V or above (with the heat-source unit in operation). If this value is normal, there is a problem with the fan.



	Cause	Check method and remedy
2.	Indoor unit LEV malfunction  Insufficient refrigerant flows due to LEV malfunction (not enough opening) or protection works and compressor frequency does not rise due to pressure drop.  Refrigerant leak from LEV on the stopping unit causes refrigerant shortage on the running unit.	Refer to the page of LEV troubleshooting ([4] -4- ).
3.	Long piping length The cooling capacity varies greatly depending on the pressure loss. (When the pressure loss is large, the cooling capacity drops.)	Check the piping length to determine if it is contributing to performance loss. Piping pressure loss can be estimated from the temperature difference between the indoor unit heat exchanger outlet temperature and the satura-
4.	Piping size is not proper (thin)	tion temperature (Te) of 63LS. →Correct the piping.
5.	Insufficient refrigerant amount Protection works and compressor frequency does not rise due to high discharge temperature.	Refer to 1-1. (Compressor frequency does not rise sufficiently.) Refer to the page on refrigerant amount adjustment.
6.	Clogging by foreign object	Check the temperature difference between in front of and behind the place where the foreign object is clogging the pipe (upstream side and downstream side). When the temperature drops significantly, the foreign object may clog the pipe.  → Remove the foreign object inside the pipe.
7.	The indoor unit inlet temperature is excessively low. (Less than 15°C [59°F] WB)	Check the inlet air temperature and for short cycling. Change the environment where the indoor unit is used.
8.	Compressor failure The amount of circulating refrigerant decreases due to refrigerant leak in the compressor.	Check the discharge temperature to determine if the refrigerant leaks, as it rises if there is a leak.
9.	LEV3 malfunction Sufficient liquid refrigerant is not be supplied to the indoor unit as sufficient sub cool cannot be secured due to LEV3 malfunction.	Refer to the page of LEV troubleshooting ( [4] -4- ). It most likely happens when there is little difference or no difference between TH12 and TH15.
10.	TH12, TH15 and 63HS1 sensor failure or faulty wiring LEV3 is not controlled normally.	Check the thermistor. Check wiring.

# 2. Phenomena

Although heating operation starts with the normal remote controller display, the capacity is not enough.

# (1) Cause, check method and remedy

	Cause		Check method and remedy
1.	Compressor frequency does not rise sufficiently.  •Faulty detection of pressure sensor.  •Protection works and compressor frequency does not rise due to high discharge temperature.  •Protection works and compressor frequency does not rise due to high pressure.  •The high temperature of the heatsink on the INV board triggers the protection mechanism that keeps the compressor frequency from rising.	(1) Note:	Check pressure difference between the detected pressure by the pressure sensor and the actual pressure with self-diagnosis LED.  → If the accurate pressure is not detected, check the pressure sensor.(Refer to the page on Trouble-shooting of Pressure Sensor)  Higher inlet pressure by the high pressure sensor than the actual pressure causes insufficient capacity.  SW4 setting (SW6-10: OFF)
			High pressure sensor SW4 ON
			Low pressure sensor SW4 ON 1 2 3 4 5 6 7 8 9 10
		(2)	Check the difference between the condensing temperature (Tc) and the target condensing temperature (Tcm) with self-diagnosis LED.
		Note:	Higher Tc than Tcm causes insufficient capacity. SW4 setting (SW6-10: OFF)
			Condensing temperature Tc  SW4  ON  1 2 3 4 5 6 7 8 9 10  Target condensing temperature Tcm SW4 ON  ON  1 2 3 4 5 6 7 8 9 10
		Note:	Protection works and compressor frequency does not rise even at lower Tc than Tcm due to high discharge temperature and high pressure. At high discharge temperature: Refer to 1102. At high pressure: Refer to 1302.
		(3)	Fan problem, fan connection fault Check to see if the fan is rotating while the heat-source unit is in operation. If the fan is rotating -> Check the items listed under 4230. If the fan is not rotating -> Check the fan wires for proper connection. If the fan wires are properly connected, check that the voltage at the connector CN502 on the control board is 188 V or above (with the heat-source unit in operation). If this value is normal, there is a problem with the fan.



	Causa	Charle mathed and remade
	Cause	Check method and remedy
2.	Indoor unit LEV malfunction Insufficient refrigerant flows due to LEV malfunction (not enough opening).	Refer to the page of LEV troubleshooting ( [4] -4- ).
3.	Temperature reading error on the indoor unit piping temperature sensor If the temperature reading on the sensor is higher than the actual temperature, it makes the subcool seem smaller than it is, and the LEV opening decreases too much.	Check the thermistor.
4.	Insulation failure of the refrigerant piping	
5.	Long piping length Excessively long piping on the high pressure side causes pressure loss leading to increase in the high pressure.	Confirm that the characteristic of capacity drop due to piping length.  → Change the pipe
6.	Piping size is not proper (thin)	
7.	Clogging by foreign object	Check the temperature difference between the upstream and the downstream of the pipe section that is blocked. Since blockage in the extended section is difficult to locate, operate the unit in the cooling cycle, and follow the same procedures that are used to locate the blockage of pipe during cooling operation.  →Remove the blockage in the pipe.
8.	The indoor unit inlet temperature is excessively high.(exceeding 28°C [82°F])	Check the inlet air temperature and for short cycling. Change the environment where the indoor unit is used.
9.	Insufficient refrigerant amount Protection works and compressor frequency does not rise due to low discharge temperature Refrigerant recovery operation is likely to start.	Refer to 2 - 1. (Compressor frequency does not rise sufficiently.) Refer to the page on refrigerant amount adjustment.
10.	Compressor failure (same as in case of cooling)	Check the discharge temperature.
11.	LEV3 actuation failure A drop in the low pressure that is caused either by a blockage of liquid pipe or by a pressure loss and the resultant slowing of refrigerant flow causes a tendency for the discharge temperature to rise.	Refer to the page on troubleshooting the LEV ([4] - 4-).

# 3. Phenomena

Heat source unit stops at times during operation.

# (1) Cause, check method and remedy

	Cause		Check method and remedy
	The first stop is not considered as an error, as the unit turns to anti-restart mode for 3 minutes as a preliminary error.	(1)	Check the mode operated in the past by displaying preliminary error history on LED display with SW4.
	Error mode		
1	Abnormal high pressure	(2)	Reoperate the unit to find the mode that stops the
2	Abnormal discharge air temperature		unit by displaying preliminary error history on LED display with SW4.
3	Heatsink thermistor failure		
4	Thermistor failure		→ Refer to the reference page for each error mode.
5	Pressure sensor failure		*Display the indoor piping temperature table with SW4 to check whether the freeze proof operation
6	Over-current break		runs properly, and check the temperature.
7	Refrigerant overcharge		
Note1:	Frost prevention tripping only under cooling mode may be considered in addition to the above. (Freeze protection is detected by one or all indoor units.)		
Note2:	Even the second stop is not considered as an error when some specified errors occur. (eg. The third stop is considered as an error when the thermistor error occurs.)		

# [3] Checking Transmission Waveform and for Electrical Noise Interference


#### 1. M-NET transmission

Control is performed by exchanging signals between the heat source unit and the indoor unit (ME remote controller) through M-NET transmission. Noise interference on the transmission line will interrupt the normal transmission, leading to erroneous operation.

# (1) Symptoms caused by noise interference on the transmission line

Cause	Erroneous operation	Error code	Error code definition
	Signal is transformed and will be misjudged as the signal of another address.	6600	Address overlap
	Transmission wave pattern is transformed due to the noise creating a new signal	6602	Transmission processor hardware error
Noise interference on the transmission line	Transmission wave pattern is transformed due to the noise, and will not be received normally leading to no acknowledgement (ACK).	6607	No ACK error
	Transmission cannot be performed due to the fine noise.	6603	Transmission line bus busy error
	Transmission is successful; however, the acknowledgement (ACK) or the response cannot be received normally due to the noise.	6607 6608	No ACK error No response error

## (2) Wave shape check



# Wave shape check

Check the wave pattern of the transmission line with an oscilloscope. The following conditions must be met.

- 1) Small wave pattern (noise) must not exist on the transmission signal. (Minute noise (approximately 1V) can be generated by DC-DC converter or the inverter operation; however, such noise is not a problem when the shield of the transmission line is grounded.)
- 2) The sectional voltage level of transmission signal should be as follows.

Logic	Voltage level of the transmission line	
0	V <sub>HL</sub> = 2.5V or higher	
1	V <sub>BN</sub> = 1.3V or below	

# (3) Check method and remedy

# 1) Measures against noise

Check the followings when noise exists on the wave or the errors described in (1) occur.

		Error code definition	Remedy
Check that the wiring work is performed according to wiring	1.	The transmission line and the power line are not wired too closely.	Isolate the transmission line from the power line (5cm [1-31/32"] or more). Do not insert them in the same conduit.
specifications.	2.	The transmission line is not bundled with that for another systems.	The transmission line must be isolated from another transmission line. When they are bundled, erroneous operation may be caused.
	3.	The specified wire is used for the transmission line.	Use the specified transmission line. Type: Shielded wire CVVS/CPEVS/MVVS (For ME remote controller) Diameter: 1.25mm <sup>2</sup> [AWG16] or more (Remote controller wire: 0.3 - 1.25mm <sup>2</sup> [AWG22-16])
	4.	When the transmission line is daisy-chained on the indoor unit terminals, are the shields daisy-chained on the terminals, too?	The transmission is two-wire daisy-chained. The shielded wire must be also daisy-chained.  When the shielded cable is not daisy-chained, the noise cannot be reduced enough.
Check that the grounding work is performed according to grounding specifications.	5.	Is the shield of the indoor- heat source transmission cable grounded to the earth terminal on the heat source unit?	Connect the shield of the indoor-heat source transmission cable to the earth terminal (力) on the heat source unit. If no grounding is provided, the noise on the transmission line cannot escape leading to change of the transmission signal.
	6.	Check the treatment method of the shield of the transmission line (for centralized control).	The transmission cable for centralized control is less subject to noise interference if it is grounded to the heat source unit whose power jumper cable was moved from CN41 to CN40 or to the power supply unit.  The environment against noise varies depending on the distance of the transmission lines, the number of the connected units, the type of the controllers to be connected, or the environment of the installation site. Therefore, the transmission line work for centralized control must be performed as follows.
			(1) When no grounding is provided: Ground the shield of the transmission cable by connecting to the heat source unit whose power jumper connector was moved from CN41 to CN40 or to the power supply unit.
			(2) When an error occurs even though one point grounding is provided: Ground the shield on all heat source units.

2) Check the followings when the error "6607" occurs, or "HO" appears on the display on the remote controller.

	Error code definition	Remedy
7.	The farthest distance of transmission line is 200m [656ft] or longer.	Check that the farthest distance from the heat source unit to the indoor unit and to the remote controller is within 200m [656ft].
8.	The types of transmission lines are different.	Use the specified transmission line. Type: Shielded wire CVVS/CPEVS/MVVS (For ME remote controller) Diameter: 1.25mm <sup>2</sup> [AWG16] or more (Remote controller wire: 0.3-1.25mm <sup>2</sup> [AWG22-16])
9.	Heat source unit circuit board failure	Replace the heat source unit control board or the power supply board for the transmission line.
10.	Indoor unit circuit board failure or remote controller failure	Replace the indoor unit circuit board or the remote controller.
11.	The MA remote controller is connected to the M-NET transmission line.	Connect the MA remote controller to the terminal block for MA remote controller (TB15).


# 2. MA remote controller transmission


The communication between the MA remote controller and the indoor unit is performed with current tone burst.

# (1) Symptoms caused by noise interference on the transmission line

If noise is generated on the transmission line, and the communication between the MA remote controller and the indoor unit is interrupted for 3 minutes in a row, MA transmission error (6831) will occur.

## (2) Confirmation of transmission specifications and wave pattern





# [4] Troubleshooting Principal Parts

# -1- High-Pressure Sensor (63HS1, PS1, PS3)

#### Compare the pressure that is detected by the high pressure sensor, and the high-pressure gauge pressure to check for failure.

By configuring the digital display setting switch (SW4 (when SW6-10 is set to OFF)) as shown in the figure below, the pressure as measured by the high-pressure sensor appears on the LED1 on the control board.





The figure at left shows that the switches 1 through 5 are set to ON and 6 through 10 are set to OFF.

#### (1) While the sensor is stopped, compare the gauge pressure and the pressure displayed on self-diagnosis LED1.

- 1) When the gauge pressure is between 0 and 0.098MPa [14psi], internal pressure is caused due to gas leak.
- 2) When the pressure displayed on self-diagnosis LED1 is between 0 and 0.098MPa [14psi], the connector may be defective or be disconnected. Check the connector and go to (4).
- 3) When the pressure displayed on self-diagnosis LED1 exceeds 4.15MPa [601psi], go to (3).
- 4) If other than 1), 2) or 3), compare the pressures while the sensor is running. Go to (2).

# (2) Compare the gauge pressure and the pressure displayed on self-diagnosis LED1 while the sensor is running. (Compare them by MPa [psi] unit.)

- 1) When the difference between both pressures is within 0.098MPa [14psi], both the high pressure sensor and the control board are normal.
- 2) When the difference between both pressures exceeds 0.098MPa [14psi], the high pressure sensor has a problem. (performance deterioration)
- 3) When the pressure displayed on self-diagnosis LED1 does not change, the high pressure sensor has a problem.
- (3) Remove the high pressure sensor from the control board to check the pressure on the self-diagnosis LED1.
- 1) When the pressure displayed on self-diagnosis LED1 is between 0 and 0.098MPa [14psi], the high pressure sensor has a problem.
- 2) When the pressure displayed on self-diagnosis LED1 is approximately 4.15MPa [601psi], the control board has a problem.
- (4) Remove the high pressure sensor from the control board, and short-circuit between the No.2 and 3 connectors (63HS1, PS1, PS3) to check the pressure with self-diagnosis LED1.
- 1) When the pressure displayed on the self-diagnosis LED1 exceeds 4.15MPa [601psi], the high pressure sensor has a problem.
- 2) If other than 1), the control board has a problem.


#### 2. Pressure sensor configuration


The high pressure sensor consists of the circuit shown in the figure below. If DC 5V is applied between the red and the black wires, voltage corresponding to the pressure between the white and the black wires will be output, and the value of this voltage will be converted by the microcomputer. The output voltage is 0.071V per 0.098MPa [14psi].

# Note

The pressure sensor on the body side is designed to connect to the connector. The connector pin number on the body side is different from that on the control board side.

	Body side	Control board side
Vcc Pin 1		Pin 3
Vout Pin 2		Pin 2
GND	Pin 3	Pin 1





## -2- Low-Pressure Sensor (63LS)

#### Compare the pressure that is detected by the low pressure sensor, and the low pressure gauge pressure to check for failure.

By configuring the digital display setting switch (SW4 (when SW6-10 is set to OFF)) as shown in the figure below, the pressure as measured by the low-pressure sensor appears on the LED1 on the control board.





The figure at left shows that the switches 1 through 5 are set to ON and 6 through 10 are set to OFF.

# (1) While the sensor is stopped, compare the gauge pressure and the pressure displayed on self-diagnosis LED1.

- 1) When the gauge pressure is between 0 and 0.098MPa [14psi], internal pressure is caused due to gas leak.
- 2) When the pressure displayed on self-diagnosis LED1 is between 0 and 0.098MPa [14psi], the connector may be defective or be disconnected. Check the connector and go to (4).
- 3) When the pressure displayed on self-diagnosis LED1 exceeds 1.7MPa [247psi], go to (3).
- 4) If other than 1), 2) or 3), compare the pressures while the sensor is running. Go to (2).

# (2) Compare the gauge pressure and the pressure displayed on self-diagnosis LED1 while the sensor is running.(Compare them by MPa [psi] unit.)

- 1) When the difference between both pressures is within 0.03MPa [4psi], both the low pressure sensor and the control board are normal.
- 2) When the difference between both pressures exceeds 0.03MPa [4psi], the low pressure sensor has a problem. (performance deterioration)
- 3) When the pressure displayed on the self-diagnosis LED1 does not change, the low pressure sensor has a problem.

#### (3) Remove the low pressure sensor from the control board to check the pressure with the self-diagnosis LED1 display.

- 1) When the pressure displayed on the self-diagnosis LED1 is between 0 and 0.098MPa [14psi], the low pressure sensor has a problem.
- 2) When the pressure displayed on self-diagnosis LED1 is approximately 1.7MPa [247psi], the control board has a problem.
  - •When the heat source temperature is 30°C [86°F] or less, the control board has a problem.
  - •When the heat source temperature exceeds 30°C [86°F], go to (5).

# (4) Remove the low pressure sensor from the control board, and short-circuit between the No.2 and 3 connectors (63LS:CN202) to check the pressure with the self-diagnosis LED1.

- 1) When the pressure displayed on the self-diagnosis LED1 exceeds 1.7MPa [247psi], the low pressure sensor has a problem.
- 2) If other than 1), the control board has a problem.
- (5) Remove the high pressure sensor (63HS1) from the control board, and insert it into the connector for the low pressure sensor (63LS) to check the pressure with the self-diagnosis LED1.
- 1) When the pressure displayed on the self-diagnosis LED1 exceeds 1.7MPa [247psi], the control board has a problem.
- 2) If other than 1), the control board has a problem.


#### 2. Low-pressure sensor configuration


The low pressure sensor consists of the circuit shown in the figure below. If DC5V is applied between the red and the black wires, voltage corresponding to the pressure between the white and the black wires will be output, and the value of this voltage will be converted by the microcomputer. The output voltage is 0.173V per 0.098MPa [14psi].

## Note

The pressure sensor on the body side is designed to connect to the connector. The connector pin number on the body side is different from that on the control board side.

	Body side	Control board side
Vcc	Pin 1	Pin 3
Vout	Pin 2	Pin 2
GND	Pin 3	Pin 1





#### -3- Solenoid Valve

Check whether the output signal from the control board and the operation of the solenoid valve match.

Setting the self-diagnosis switch (SW4) as shown in the figure below causes the ON signal of each relay to be output to the LED's. Each LED shows whether the relays for the following parts are ON or OFF. LEDs light up when relays are on.

#### Note

The circuits on some parts are closed when the relays are ON. Refer to the following instructions.

SW4 (SW6-10:OFF	SW4 (SW6-10:OFF)		Display						
0114 (0110 10:011	,	LD1	LD2	LD3	LD4	LD5	LD6	LD7	LD8
	Upper	21S4a		CH11		SV1a			
SW4 ON									
1 2 3 4 5 6 7 8 9 10	Lower			21S4b					
	Upper	SV4a	SV4b				SV4d	SV9	
SW4 ON									
1 2 3 4 5 6 7 8 9 10	Lower	SV7a	SV7b		SV7c				



The figure at left shows that the switches 1 through 5 are set to ON and 6 through 10 are set to OFF.

### (1) In case of 21S4a (4-way switching valve)

About this 4-way valve

When not powered:

Conducts electricity between the oil separator outlet and heat exchanger AND the gas ball valve (BV1) and the accumulator to complete the circuit for the cooling cycle.

When powered:

The electricity runs between the oil separator and the gas ball valve, and between the heat exchanger and the accumulator. This circulation is for heating.

Check the LED display and the intake and the discharge temperature for the 4-way valve to check whether the valve has no faults and the electricity runs between where and where.Do not touch the pipe when checking the temperature, as the pipe on the oil separator side will be hot.

## Note

Do not give an impact from outside, as the outer hull will be deformed leading to the malfunction of the inner valve.

## (2) In case of SV1a (Bypass valve)


This solenoid valve opens when powered (Relay ON).


- 1) At compressor start-up, the SV1a turns on for 4 minutes, and the operation can be checked by the self-diagnosis LED display and the closing sound.
- 2) To check whether the valve is open or closed, check the change of the SV1a downstream piping temperature while the valve is being powered. Even when the valve is closed, high-temperature refrigerant flows inside the capillary next to the valve. (Therefore, temperature of the downstream piping will not be low with the valve closed.)


#### (3) SV4a - 4d, SV7a, 7b(Controls heat exchanger capacity)

- 1) At least one of the solenoid valves among SV4a through 4d,SV7a, and SV7b turns on. Check for proper operation on the LED and by listening for the operation sound of the solenoid valve.
- 2) SV4a, 4b, 4c, 4d, 7a, and 7b control the flow of high-temperature (high-pressure) refrigerant during Cooling-only and Cooling-main operation. These valves will be closed during the Heating-only and Heating-main operation and will not allow the refrigerant to flow.Refer to the refrigerant circuit diagram. Solenoid valves turns on and off according to such factors as the capacity of the indoor units in operation and water inlet temperature. Check the LED. Remove the SV coil, open the lid, and check the plunger. The type of pin face wrench that is listed in the service parts list is required to perform this task.

<sup>•</sup>When a valve malfunctions, check if the wrong solenoid valve coil is not attached the lead wire of the coil is not disconnected, the connector on the board is not inserted wrongly, or the wire for the connector is not disconnected.







# (4) In the case of SV9 (Bypass valve) (PQRY only)

This solenoid valve opens when energized (when the relay is on)

This valve turns on when the value of 63HS1 is greater than 3.5 MPa [507psi] during Heating-only or Heating-main operation at the minimum frequency. The valve position can be determined by measuring and monitoring the changes in the pipe temperature on the downstream of SV9 while the unit is energized. When the valve is open, high-temperature gas refrigerant passes through the pipe. Do not attempt to check the pipe temperature by touching the pipe.

# -4- LEV


# **LEV** operation

The LEV on the indoor unit and LEV1, LEVINV, LEV6, and LEV7 on the heat source unit are driven by the pulse signal from the circuit board on the indoor and heat-source units and are controlled by a stepping motor


# (1) Indoor LEV and heat source LEV (LEV6,LEV7), and BC controller LEV (LEV1, LEV3, LEV4)

The valve opening changes according to the number of pulses.

1) Control boards (indoor unit and BC controller) and LEV (indoor unit LEV and BC controller LEV)



2) Control boards (indoor unit and Heat source unit) and LEV (indoor unit LEV and Heat source unit LEV)



## 3) Pulse signal output and valve operation


Output (phase) number	Output state						
number	1	2	3	4			
<i>∮</i> 1	ON	OFF	OFF	ON			
φ <b>2</b>	ON	ON	OFF	OFF			
φ3	OFF	ON	ON	OFF			
φ <b>4</b>	OFF	OFF	ON	ON			

Output pulses change in the following orders when the

Valve is closed; 
$$1 \rightarrow 2 \rightarrow 3 \rightarrow 4 \rightarrow 1$$
  
Valve is open;  $4 \rightarrow 3 \rightarrow 2 \rightarrow 1 \rightarrow 4$ 

- \*1. When the LEV opening angle does not change, all the output phases will be off.
- \*2. When the output is open phase or remains ON, the motor cannot run smoothly, and rattles and vibrates

#### 4) LEV valve closing and opening operation



\*Upon power on, the indoor unit circuit board sends a 2200 pulse closing signal to the indoor unit LEV and a 3200 pulse closing signal to the heat source unit LEV to determine the valve position and always brings the valve to the position as indicated by "(A)" in the diagram.

After the valve position has been adjusted to the position as indicated by (A) in the diagram, the indoor unit circuit board sends a 41-pulse signal to bring the LEV opening to the position as indicated by (B) in the diagram.

When the valve operates smoothly, no sound from LEV or no vibration occurs, however, when the pulses change from E to A in the chart or the valve is locked, a big sound occurs.


\*Whether a sound is generated or not can be determined by holding a screwdriver against it, then placing your ear against the handle.

\*1 The LEV opening may become greater depending on the operation status.

# (2) Heat source LEV (LEV1,LEVINV)

The valve opening changes according to the number of pulses.

Connections between the heat source control board and LEV




## 2) Pulse signal output and valve operation

Output	Output state								
(phase) number	1	2	3	4	5	6	7	8	
ø <b>1</b>	ON	OFF	OFF	OFF	OFF	OFF	ON	ON	
ø2	ON	ON	ON	OFF	OFF	OFF	OFF	OFF	
ø3	OFF	OFF	ON	ON	ON	OFF	OFF	OFF	
ø <b>4</b>	OFF	OFF	OFF	OFF	ON	ON	ON	OFF	

Output pulses change in the following orders when the Valve is open;  $1 \rightarrow 2 \rightarrow 3 \rightarrow 4 \rightarrow 5 \rightarrow 6 \rightarrow 7 \rightarrow 8 \rightarrow 1$ Valve is closed;  $8 \rightarrow 7 \rightarrow 6 \rightarrow 5 \rightarrow 4 \rightarrow 3 \rightarrow 2 \rightarrow 1 \rightarrow 8$ 

- \*1. When the LEV opening angle does not change, all the output phases will be off.
- \*2. When the output is open phase or remains ON, the motor cannot run smoothly, and rattles and vibrates.

# 3) LEV valve closing and opening operation



\*When the power is turned on, the valve closing signal of 520 pulses will be output from the indoor board to LEV to fix the valve position.

When the valve operates smoothly, there is no sound from the LEV and no vibration occurs, but when the valve is locked, noise is generated.

\*Whether a sound is generated or not can be determined by

\*If liquid refrigerant flows inside the LEV, the sound may become smaller.

# (3) Judgment methods and possible failure mode

#### Note


The specifications of the heat source unit (heat source LEV), indoor unit (indoor LEV),and BC controller (BC controller LEV) differ. Therefore, remedies for each failure may vary. Check the remedy specified for the appropriate LEV as indicated in the right column.

Malfunction mode	Judgment method	Remedy	Target LEV
Microcomputer driver circuit fail- ure	Disconnect the control board connector and connect the check LED as shown in the figure below.	When the drive circuit has a problem, replace the control board.	Indoor Heat source
LEV mechanism is locked	faulty.  If the LEV is locked, the drive motor runs idle, and makes a small clicking sound.  When the valve makes a closing and opening sound, the valve has a problem.	Replace the LEV.	Indoor Heat source BC controller
Disconnected or short-circuited LEV motor coil	Measure resistance between the coils (red - white, red -orange, brown - yellow, brown - blue) using a tester. They are normal if resistance is 150ohm ± 10%.	Replace the LEV coils.	Indoor BC controller
	Measure the resistance between coils (red-white, red- orange, red-yellow, red-blue) with a tester. When the resistance is in the range of 100ohm ± 10%, the LEV is normal.	Replace the LEV coils.	Heat source (LEV6,LEV7) BC controller
	Measure resistance between the coils (red - white, red -orange, brown - yellow, brown - blue) using a tester. They are normal if resistance is 46ohm $\pm$ 3%.	Replace the LEV coils.	Heat source (LEV1,LEVINV)
Incomple sealing (leak from the valve)	When checking the refrigerant leak from the indoor LEV, run the target indoor unit in the fan mode, and the other indoor units in the cooling mode. Then, check the liquid temperature (TH22) with the self-diagnosis LED. When the unit is running in the fan mode, the LEV is fully closed, and the temperature detected by the thermistor is not low. If there is a leak, however, the temperature will be low. If the temperature is extremely low compared with the inlet temperature displayed on the remote controller, the LEV is not properly sealed, however, if there is a little leak, it is not necessary to replace the LEV when there are no effects to other parts.	If there is a large amount of leakage, re- place the LEV.	Indoor BC controller
Faulty wire con- nections in the connector or faulty contact	Check for loose pins on the connector and check the colors of the lead wires visually     Disconnect the control board's connector and conduct a continuity check using a tester.	Check the continuity at the points where an error occurs.	Indoor Heat source BC controller

## (4) Heat source unit LEV (LEV1,LEVINV) coil removal procedure


## 1) LEV component

As shown in the figure, the heat source LEV is made in such a way that the coils and the body can be separated.



# 2) Removing the coils


Fasten the body tightly at the bottom (Part A in the figure) so that the body will not move, then pull out the coils toward the top.If the coils are pulled out without the body gripped, undue force will be applied and the pipe will be bent.



# 3) Installing the coils

Fix the body tightly at the bottom (Part A in the figure) so that the body will not move, then insert the coils from the top, and insert the coil stopper securely in the pipe on the body. Hold the body when pulling out the coils to prevent so that the pipe will not be bent.


If the coils are pushed without the body gripped, undue force will be applied and the pipe will be bent. Hold the body when pulling out the coils to prevent so that the pipe will not be bent.



# (5) Heat source unit LEV (LEV6,LEV7) coil removal procedure

## 1) Components


The heat source unit LEV consists of a coil and a valve body that can be separated from each other.



## 2) Removing the coil

Securely hold the LEV at the bottom (as indicated by A in the figure), and turn the coil. After checking that the stopper is removed, pull up and out the coil.


When removing the coil, hold the LEV body securely to prevent undue force from being placed on the pipe and bending the pipe.




# 3) Installing the coil

Securely hold the bottom of the LEV (Part A in the figure), insert the coil from above, and turn the coil until the coil stopper is properly installed on the LEV body.

When removing the coil, hold the LEV body securely to prevent undue force from being placed on the pipe and bending the pipe.




# (6) Indoor unit LEV, BC controller LEV coil removal procedure



# Notes on the procedure

- 1) Do not put undue pressure on the motor.
- 2) Do not use motors if dropped.
- 3) Do not remove the cap until immediately before the procedure.
- 4) Do not wipe off any molybdenum.
- 5) Do not remove the packing.
- 6) Do not apply any other than specified liquid such as screw lock agent, grease and etc.



#### Replacement procedure

- 1) Stop the air conditioner. After checking that the air conditioner is stopped, turn off the power of the heat source unit.
- Prepare two spanners. Hold the valve body with one spanner and loosen the locknut with another one.
   Turning the locknut counter-clockwise from motor side view can loosen it.
   Two spanners must be used.
  - Do not hold the motor with one hand and loosen the locknut with only one spanner.
- 3) Turning the locknut several times. The locknut will come off and then the motor can be removed.
- 4) Prepare a motor replacement. Use only factory settings, which the head part of the driver does not come out. Use of other than factory settings may result in malfunction and failure of valve flow rate control.
- 5) Keep dust, contaminants, and water out of the space between the motor and the valve body during replacement. (The space is the mechanical section of the valve.) Do not damage the junction with tools.
  - After removing the motor, blow N<sub>2</sub> gas or etc. into bellows in order to blow off water from inside.
- 6) Remove the cap of the motor replacement. Joint the axis of the motor and the one of the valve body with the locknut to stick precisely. Apply screw lock agent to whole part of the screw. Do not introduce screw lock agent into the motor. Use new motors if problems are found on the motor during the replacement.
- 7) After rotating the locknut 2~3 times by hands, hold the valve body with the spanner, and tighten the locknut with the specified torque with a torque wrench. Apply the tightening torque of 15N·m (150kgf·cm) (administration value 15 ± 1 N·m (150 ± 10kgf·cm)).
  - Note that undue tightening may cause breaking a flare nut.
- 8) When tightening the locknut, hold the motor with hands so that undue rotary torque and load can not be applied.
- 9) The differences of relative position after assembling the motor and the valve body do not affect the valve control and the switching function.
  - Do not relocate the motor and the valve body after tightening the locknut. Even the relative position is different from before and after assembling.

Difference in rotational direction is acceptable.




The motor may not be fixed with clamp because of the changing of the motor configuration. However, the fixing is not necessary due to the pipe fixing.

- 10) Connect the connector. Do not pull hard on the lead wire. Make sure that the connector is securely inserted into the specified position, and check that the connector does not come off easily.
- 11) Turn on the indoor unit, and operate the air conditioner. Check that no problems are found.

# -5- Troubleshooting Principal Parts of BC Controller

#### 1. Pressure sensor

Troubleshooting flow chart for pressure sensor



#### Note

1) BC controller: Phenomena when the pressure sensor is connected wrongly (reverse connection of P1 and P3) to the board.

	Symptoms								
Cooling-only Cooling-main Heating only Heating main									
Normal	Non-cooling	SC16 small	Indoor heating SC small Heating indoor Thermo ON Especially noise is large.	SC11 large SC16 small △PHM large	Non-cooling Indoor heating SC small Heating indoor Thermo ON Especially noise is large.	SC11 large SC16 small △PHM large			

## Note

2) Check the self-diagnosis switch (Heat source control board SW4 (SW6-10. OFF)).

Measurement data	Symbol	SW4 setting value	SW6 setting value	Measurement data	Symbol	SW4 setting value	SW6 setting value
Heat source high pressure	63HS1	ON	ON 1 2 3 4 5 6 7 8 9 10	Sub BC controller pressure (intermediate part) (Sub 5)	PS3	ON	ON
Heat source low pressure	63LS	ON	ON	Sub BC controller pressure (intermediate part) (Sub 6)	PS3	ON	ON
BC controller pressure (liquid side)	PS1	ON	ON 1 2 3 4 5 6 7 8 9 10	Sub BC controller pressure (intermediate part) (Sub 7)	PS3	ON	ON
BC controller pressure (intermediate part)	PS3	ON	ON 1 2 3 4 5 6 7 8 9 10	Sub BC controller pressure (intermediate part) (Sub 8)	PS3	ON	ON 1 2 3 4 5 6 7 8 9 10
Sub BC controller pressure (intermediate part) (Sub 1)	PS3	ON	ON	Sub BC controller pressure (intermediate part) (Sub 9)	PS3	ON	ON 1 2 3 4 5 6 7 8 9 10
Sub BC controller pressure (intermediate part) (Sub 2)	PS3	ON	ON 1 2 3 4 5 6 7 8 9 10	Sub BC controller pressure (intermediate part) (Sub 10)	PS3	ON	ON
Sub BC controller pressure (intermediate part) (Sub 3)	PS3	ON	ON 1 2 3 4 5 6 7 8 9 10	Sub BC controller pressure (intermediate part) (Sub 11)	PS3	ON	ON
Sub BC controller pressure (intermediate part) (Sub 4)	PS3	ON	ON 1 2 3 4 5 6 7 8 9 10				

ON									
					П	$\Box$			
-	1-1	-	-1	-	_	1_1	1_1	_	_
ш	Ш		Ш	Ш			呾		
1	2	3	4	5	6	7	8	9	10
_									


The figure at left shows that the switches 1 through 5 are set to ON and 6 through 10 are set to OFF.

# Note

- 3) Check whether CNP1 (liquid side) connector on the BC controller control board and the connector CNP2 (intermediate part) are not disconnected or not loose.
- 4) Check the pressure value on the self-diagnosis switch (same as note 2) with the connector of the applied pressure sensor is disconnected from the board.

## 2. Temperature sensor

# Troubleshooting instructions for thermistor



## Note

- 1) For the connectors on the board, TH11 and TH12 are connected to CN10, and TH15 and TH16 are connected to CN11. Disconnect the connector in trouble, and check the sensor of each number.
- 2)
- •Pull out the sensor connector from the I/O board, Do not pull the sensor by holding the lead wire.
- •Measure the resistance with such as a tester.
- •Compare the measured value with that shown in the table below. When the result is  $\pm 10\%$ , it is normal.
- 3) Check the self-diagnosis switch (Heat source control board SW4 (SW6-10. OFF)).

	Measurement data	Symbol	SW4 setting value	SW6 setting value
	Liquid inlet temperature	TH11	ON	ON
J, JA, KA	Bypass outlet temperature	TH12	ON 1 2 3 4 5 6 7 8 9 10	ON 1 2 3 4 5 6 7 8 9 10
(Standard / main)	Bypass inlet temperature	TH15	ON 1 2 3 4 5 6 7 8 9 10	ON 1 2 3 4 5 6 7 8 9 10
	Bypass inlet temperature	TH16	ON	ON 1 2 3 4 5 6 7 8 9 10
	Bypass outlet temperature	TH12	ON 1 2 3 4 5 6 7 8 9 10	ON 1 2 3 4 5 6 7 8 9 10
KB (Sub 1)	Bypass inlet temperature	TH15	ON 1 2 3 4 5 6 7 8 9 10	ON 1 2 3 4 5 6 7 8 9 10
	Bypass inlet temperature	TH16	ON	ON 1 2 3 4 5 6 7 8 9 10
	Bypass outlet temperature	TH12	ON 1 2 3 4 5 6 7 8 9 10	ON 1 2 3 4 5 6 7 8 9 10
KB (Sub 2)	Bypass inlet temperature	TH15	ON 1 2 3 4 5 6 7 8 9 10	ON 1 2 3 4 5 6 7 8 9 10
	Bypass inlet temperature	TH16	ON 1 2 3 4 5 6 7 8 9 10	ON 1 2 3 4 5 6 7 8 9 10
	Bypass outlet temperature	TH12	ON 1 2 3 4 5 6 7 8 9 10	ON 1 2 3 4 5 6 7 8 9 10
KB (Sub 3)	Bypass inlet temperature	TH15	ON 1 2 3 4 5 6 7 8 9 10	ON 1 2 3 4 5 6 7 8 9 10
	Bypass inlet temperature	TH16	ON	ON 1 2 3 4 5 6 7 8 9 10



	Measurement data	Symbol	SW4 setting value	SW6 setting value
	Bypass outlet temperature	TH12	ON	ON
KB (Sub 5)	Bypass inlet temperature	TH15	ON 1 2 3 4 5 6 7 8 9 10	ON
	Bypass inlet temperature	TH16	ON 1 2 3 4 5 6 7 8 9 10	ON 1 2 3 4 5 6 7 8 9 10
	Bypass outlet temperature	TH12	ON	ON 1 2 3 4 5 6 7 8 9 10
KB (Sub 6)	Bypass inlet temperature	TH15	ON	ON
	Bypass inlet temperature	TH16	ON	ON
	Bypass outlet temperature	TH12	ON	ON
KB (Sub 7)	Bypass inlet temperature	TH15	ON	ON
	Bypass inlet temperature	TH16	ON	ON
	Bypass outlet temperature	TH12	ON	ON
KB (Sub 8)	Bypass inlet temperature	TH15	ON 1 2 3 4 5 6 7 8 9 10	ON
	Bypass inlet temperature	TH16	ON	ON
	Bypass outlet temperature	TH12	ON	ON 1 2 3 4 5 6 7 8 9 10
KB (Sub 9)	Bypass inlet temperature	TH15	ON	ON
	Bypass inlet temperature	TH16	ON	ON




	Measurement data	Symbol	SW4 setting value	SW6 setting value
	Bypass outlet temperature	TH12	ON	ON 1 2 3 4 5 6 7 8 9 10
KB (Sub 10)	Bypass inlet temperature	TH15	ON	ON 1 2 3 4 5 6 7 8 9 10
	Bypass inlet temperature	TH16	ON 1 2 3 4 5 6 7 8 9 10	ON 1 2 3 4 5 6 7 8 9 10
	Bypass outlet temperature	TH12	ON 1 2 3 4 5 6 7 8 9 10	ON 1 2 3 4 5 6 7 8 9 10
KB (Sub 11)	Bypass inlet temperature	TH15	ON 1 2 3 4 5 6 7 8 9 10	ON 1 2 3 4 5 6 7 8 9 10
	Bypass inlet temperature	TH16	ON 1 2 3 4 5 6 7 8 9 10	ON 1 2 3 4 5 6 7 8 9 10

ON								
1	2 :	3 4	5	6	7	8	9	10

## 3. Troubleshooting flow chart for LEV Solenoid valve

#### (1) LEV



## Note

1) BC controller: Phenomena when LEV is connected wrongly (reverse connection of LEV1 and LEV3) to the board.

	Phenomena								
Cooling-only	Cooling-main	Heating only	Heating main						
Non-cooling SH12 small, SC11 small SH16 small, branch pipe SC small BC controller sound	Non-cooling and non-heating SH12 small, SC11 small SH16 large, but branch pipe SC small BC controller sound △PHM large	Indoor heating SC small △ PHM large	Non-cooling Indoor heating SC small △ PHM large						

- 2) Check method of fully open state or fully closed state of LEV
  - •Check LEV opening (pulse) on the self-diagnosis LED (Heat source control board SW4 (SW6-10:OFF)). Full open: 2000 pulses
  - Fully closed: 110 pulses (In the case of heating-only mode, however, the pulse may become 110 or more.)
  - •When LEV is fully open, measure the temperature at the upstream and downstream pipes of LEV, and make sure that there is no temperature difference.
  - •When LEV is fully closed, check that there is no refrigerant flowing sound.
- 3) Refer to the chart below to judge LEV opening controlled by the values of the differential pressure and of the superheat. (BC controller LEV basic operation characteristic)


	Part	Malfunction mode	Operation mode	Content	Standards of judgment on unit stable operation	
	LEV1	Inclined to close	Heating only	Difference between high pressure (P1) and intermediate pressure (P3) is large.	0.3 to 0.4MPa	
		Inclined to open	Heating-main Cooling-main	Difference between high pressure (P1) and intermediate pressure (P3) is small.	[44 to 58psi]	
	LEV3	Inclined to close	Cooling-only Cooling-main	SH12 is large.	SH12 < 20°C [36°F]	
J, JA, KA type			Heating only Heating-main	Difference between high pressure (P1) and intermediate pressure (P3) is small.	0.3 to 0.4MPa [44 to 58psi]	
		Inclined to open	Cooling-only Cooling-main	SC16 and SH12 are small.	SC16 > 3°C [5.4°F] SH12 > 3°C [5.4°F]	
			Heating only Heating-main	Difference between high pressure (P1) and intermediate pressure (P3) is large.	0.3 to 0.4MPa [44 to 58psi]	
	LEV4 (JA and KA types only)	Inclined to close	Heating-only Heating-main	Difference between high pressure (P1) and intermediate pressure (P3) is small.	0.3 to 0.4MPa [44 to 58 psi]	
		Inclined to open	Cooling-only Cooling-main Heating-only Heating-main	SC16 is small.	SC16 > 3°C [5.4°F]	
				Difference between high pressure (P1) and intermediate pressure (P3) is large.	0.3 to 0.4MPa [44 to 58 psi]	
KB type	LEV3	Inclined to close	Cooling-only Cooling-main	SH12 is large.	SH12 < 20°C [36°F]	
		Inclined to open	Cooling-only Cooling-main	SH12 is small.	SH12 > 3°C [5.4°F]	

# Self-diagnosis LED


	Measurement data	Symbol	SW4 setting value	SW6 setting value
	LEV1 opening	-	ON	ON 1 2 3 4 5 6 7 8 9 10
	LEV3 opening	-	ON 1 2 3 4 5 6 7 8 9 10	ON 1 2 3 4 5 6 7 8 9 10
J, JA, KA	LEV4 opening (JA and KA only)	-	ON 1 2 3 4 5 6 7 8 9 10	ON 1 2 3 4 5 6 7 8 9 10
(Standard / main)	BC controller bypass outlet superheat	SH12	ON	ON 1 2 3 4 5 6 7 8 9 10
	BC controller intermediate part subcool	SC16	ON	ON 1 2 3 4 5 6 7 8 9 10
	BC controller liquid-side subcool	SC11	ON	ON
KB (Sub 1)	LEV3 opening	-	ON 1 2 3 4 5 6 7 8 9 10	ON 1 2 3 4 5 6 7 8 9 10
KB (Sub 2)	LEV3 opening	-	ON 1 2 3 4 5 6 7 8 9 10	ON 1 2 3 4 5 6 7 8 9 10
KB (Sub 3)	LEV3 opening	-	ON 1 2 3 4 5 6 7 8 9 10	ON 1 2 3 4 5 6 7 8 9 10
KB (Sub 4)	LEV3 opening	-	ON 1 2 3 4 5 6 7 8 9 10	ON 1 2 3 4 5 6 7 8 9 10
KB (Sub 5)	LEV3 opening	-	ON 1 2 3 4 5 6 7 8 9 10	ON 1 2 3 4 5 6 7 8 9 10
KB (Sub 6)	LEV3 opening	-	ON	ON 1 2 3 4 5 6 7 8 9 10
KB (Sub 7)	LEV3 opening	-	ON 1 2 3 4 5 6 7 8 9 10	ON 1 2 3 4 5 6 7 8 9 10
KB (Sub 8)	LEV3 opening	-	ON 1 2 3 4 5 6 7 8 9 10	ON 1 2 3 4 5 6 7 8 9 10
KB (Sub 9)	LEV3 opening	-	ON	ON 1 2 3 4 5 6 7 8 9 10
KB (Sub 10)	LEV3 opening	-	ON 1 2 3 4 5 6 7 8 9 10	ON 1 2 3 4 5 6 7 8 9 10
KB (Sub 11)	LEV3 opening	-	ON	ON 1 2 3 4 5 6 7 8 9 10



# Troubleshooting flow chart for solenoid valve body



# (2) Solenoid valve (SVA, SVB, SVC)



Check whether the BC board output signal corresponds with the solenoid valve operation correspond.

## Note

# 1) SVA, SVB, SVC

SVA, SVB, and SVC turn on or off according to the indoor unit operation mode.

		Mode				
		Cooling	Heating	Stopped	Defrost	Fan
	SVA	ON	OFF	OFF	OFF	OFF
Port	SVB	OFF	ON	OFF	OFF	OFF
	SVC	ON	OFF	OFF	OFF	ON

# SVM1, SVM1b


SVM1 and SVM1b turn on or off according to the indoor unit operation mode.

Operation mode	Cooling only	Cooling main	Heating only	Heating main	Defrost	Stopped
SVM1, SVM1b	ON	Pressure dif- ferential con- trol OFF or ON	OFF	OFF	ON	OFF


# <u>Note</u>

# 2) SVA, SVB, SVC

Measure the temperature at the upstream and downstream pipes ①and ②of SVA. Measure the temperature at the upstream and downstream ①pipes and ③of SVB.



# 4. BC controller transformer



	Normal	Abnormal
CNTR(1)-(3)	about 58 ohm.	Open-phase or shorting
CN03(1)-(3)	about 1.6 ohm.	Open-phase of shorting

<sup>\*</sup> Before measuring the resistance, pull out the connector.

#### -6- Inverter

- •Replace only the compressor if only the compressor is found to be defective. (Overcurrent will flow through the inverter if the compressor is damaged, however, the power supply is automatically cut when overcurrent is detected, protecting the inverter from damage. Make sure that the model selection switches on the Heat source unit (Dip switches SW5-3 through 5-8 on the heat source unit control board) are set correctly. For switch settings, refer to the following page(s). [2] Responding to Error Display on the Remote Controller)
- •Replace the defective components if the inverter is found to be defective.
- •If both the compressor and the inverter are found to be defective, replace the defective component(s) of both devices.

#### (1) Inverter-related problems: Troubleshooting and remedies

- 1) The INV board has a large-capacity electrolytic capacitor, in which residual voltage remains even after the main power is turned off, posing a risk of electric shock. Turn off the unit, leave it turned off for at least 10 minutes, and check that the voltage across FT-P and FT-N terminals on the INV board or the terminals at both ends of the electrolytic capacitor is 20V or below before checking inside the control box.
  - (It takes about 10 minutes to discharge electricity after the power supply is turn off.)
- 2) Control boxes house high-voltage and high-temperature electrical parts. Use caution not to come in contact with them.
- 3) The IPM on the inverter becomes damaged if there are loose screws are connectors. If a problem occurs after replacing some of the parts, mixed up wiring is often the cause of the problem. Check for proper connection of the wiring, screws, connectors, and Faston terminals.
- 4) To avoid damage to the circuit board, do not connect or disconnect the inverter-related connectors with the main power turned on.
- 5) Faston terminals have a locking function. Make sure the terminals are securely locked in place after insertion.

Press the tab on the terminals to remove them.



- 6) When the IPM or IGBT is replaced, apply a thin layer of heat radiation grease that is supplied evenly to these parts. Wipe off any grease that may get on the wiring terminal to avoid terminal contact failure.
- 7) Faulty wiring to the compressor damages the compressor. Connect the wiring in the correct phase sequence.
- 8) When the power is turned on, the compressor or heater is energized even while the compressor is not operating. Before turning on the power, disconnect all power supply wires from the compressor terminal block, and measure the insulation resistance of the compressor. Check the compressor for a ground fault. If the insulation resistance is below 1 MΩ, connect all power supply wires to the compressor and turn on the power to the heat source unit. The liquid refrigerant in the compressor will evaporate by energizing the compressor or heater.
- 9) Read Chapter I [13] Precautions for servicing, and tighten screws to the appropriate torque. Loose screws and poor contact can result in overheating and fire.

	Error display/failure condition	Measure/inspection item
[1]	Inverter related errors 4250, 4220, 4230, 4240,4260, 5301, 0403	Check the details of the inverter error in the error log in X LED Monitor Display on the Heat source Unit Board.  Take appropriate measures to the error code and the error details in accordance with IX. [2] Responding to Error Display on the Remote Controller.
[2]	Main power breaker trip Measure the secondary voltage of the main power breaker before	<1> Check the breaker capacity.
	checking because the main power breaker may have been broken.	<2> Check whether the electrical system is short-circuited or ground-faulted.
		<3> If items cause is not <1>or <2> are not the causes of the problem, see (3)-[1].
[3]	Main power earth leakage breaker trip Measure the secondary voltage of the main power earth leakage breaker before checking because the main power earth leakage	<1> Check the earth leakage breaker capacity and the sensitivity current.
	breaker may have been broken.	<2> Meg failure for electrical system other than the inverter
		<3> If the cause is not <1>or <2>, see (3)-[1].
[4]	Only the compressor does not operate.	Check the inverter frequency on the LED monitor and proceed to (2) - [4] if the compressor is in operation.
[5]	The compressor vibrates violently at all times or makes an abnormal sound.	See (2)-[4].
[6]	Compressor rotation speed does not reach the specified speed.	<1> Check for problems with compressor current and heatsink temperature.
		<2> Check for imbalance in power supply voltage. *Approximate target: 3% or less.
[7]	Noise is picked up by the peripheral device	<1> Check that power supply wiring of the peripheral device does not run close to the power supply wiring of the heat source unit.
		<2> Check if the inverter output wiring is not running parallel to the power supply wiring and the transmission lines.
		<3> Check that the shielded wire is used as the transmission line when it is required, and check that the grounding work is performed prop- erly on the shielded wire.
		<4> Meg failure for electrical system other than the inverter
		<5> Attach a ferrite core to the inverter output wiring. (Contact the factory for details of the service part settings.)
		<6> Provide separate power supply to the air conditioner and other electric appliances.
		<7> If the error occurred suddenly, a ground fault of the inverter output can be considered. See (2)-[4].
		*Contact the factory for cases other than those listed above.
[8]	Sudden malfunction (as a result of external noise.)	<1> Check that the grounding work is performed properly.
		<2>Check that the shielded wire is used as the transmission line when it is required, and check that the grounding work is performed prop- erly on the shielded wire.
		<3>Check that neither the transmission line nor the external connection wiring does not run close to another power supply system or does not run through the same conduit pipe.
		* Contact the factory for cases other than those listed above.

## (2) Inverter output related troubles

	It	ems to be checked		Phenomena	Remedy
[1] Check the INV board er- ror detection	(1)	Remove power supply.	1)	Overcurrent error Error code: 4250 Detail code: No. 101, 104, 105, 106, and 107	Replace the INV board.
circuit.	(2)	Disconnect the invert- er output wire from the terminals of the INV board (SC-U, SC-V, SC-W).	2)	Logic error Error code: 4220 Detail code: No. 111	Replace the INV board.
	(3)	Apply power supply.	3)	ACCT sensor circuit failure Error code: 5301 Detail code: No.117	Replace the INV board.
	(4) Put the heat source unit into operation.		4)	IPM open Error code: 5301 Detail code: No.119	Normal
[2] Check for compressor ground fault	Disconnect the compressor wiring, and check the compressor Meg, and coil resistance.		1)	Compressor Meg failure Error if below 1 MΩ.	Check that there is no liquid re- frigerant in the compressor. If there is none, replace the com- pressor.
or coil error.			2)	Compressor coil resistance failure <p72, models="" p120="" p96,=""> Coil resistance value of 0.71 ohm <p144, models="" p168,="" p192=""> Coil resistance value of 0.30 ohm</p144,></p72,>	Replace the compressor.
[3] Check wheth-	(1)	Remove power supply.	1)	Inverter-related problems are detected.	Connect the short-circuit connector to CN6, and go to section [1].
er the inverter is damaged. (No load)	(2)	Disconnect the invert- er output wire from the terminals of the INV board (SC-U, SC-V, SC-W).	2)	Inverter voltage is not output at the terminals (SC-U, SC-V, and SC-W)	Replace the INV board.
	(3)	Disconnect the short- circuit connector from CN6 on the INV board.	3)	There is an voltage imbalance between the wires. Greater than 5% imbalance or 5V	Replace the INV board.
	<ul> <li>(4) Apply power supply.</li> <li>(5) Put the heat source unit into operation.         Check the inverter output voltage after     </li> </ul>		4)	There is no voltage imbalance between the wires.	Normal *Reconnect the short-circuit connector to CN6 after checking the voltage.
		the inverter output frequency has stabilized.			

	Items to be checked		Phenomena	Re	emedy
[4] Check whether the inverter is damaged. (During compressor operation)	Put the heat source unit into operation. Check the inverter output voltage after the inverter output frequency has stabilized.	1)	Overcurrent-related problems occur immediately after compressor startup. Error code: 4250 Detail code: 101, 106, 107	a. b. c.	Check items [1] through [3] for problems.  Check that high and low pressures are balanced.  Check for compressor flooding and refrigerant flood back.  ->If the problem persists after restarting the unit several times, see item "d"  Check that there is a pressure difference between high and low pressures after compressor startup.  ->Check the high pressure with LED monitor for changes.  Replace the compressor if there is no pressure difference. (the compressor may be locked.)
		2)	There is a voltage imbalance between the wires. Greater than 5% imbalance or 5V	Re	eplace the INV board.

### (3) Trouble treatment when the main power breaker is tripped

	Items to be checked	Phenomena	Remedy
[1]	Check the breaker capacity.	Use of a non-specified break- er	Replace it with a specified breaker.
[2]	Perform Meg check between the terminals on the power terminal block TB1.	Zero to several ohm, or Meg failure	Check each part and wiring. *Refer to (5) "Simple checking procedures for individual components of main inverter
[3]		Main power breaker trip	circuit".  *IGBT module
	check again.	2) No remote control display	Rush current protection resistor     Magnetic contactor     DC reactor
[4]	Turn on the heat source unit and check that it operates normally.	Operates normally without tripping the main breaker.	a) The wiring may have been short-circuited. Search for the wire that short-circuited
		2) Main power breaker trip	ed, and repair it. b) If item a) above is not the cause of the problem, refer to (2)-[1]-[4].

### (4) Trouble treatment when the main power earth leakage breaker is tripped

	Items to be checked	Phenomena	Remedy
[1]	Check the earth leakage breaker capacity and the sensitivity current.	Use of a non-specified earth leakage breaker	Replace with a regulation earth leakage breaker.
[2]	Check the resistance at the power supply terminal block with a megger.	Failure resistance value	Check each part and wiring.  *Refer to (5) "Simple checking procedures for individual components of main inverter circuit".  •IGBT module  •Rush current protection resistor  •Magnetic contactor  •DC reactor
[3]	Disconnect the compressor wirings and check the resistance of the compressor with a megger.	Failure compressor if the insulating resistance value is not in specified range. Failure when the insulating resistance value is below 1 $\rm M\Omega$ .	Check that there is no liquid refrigerant in the compressor. If there is none, replace the compressor.

### Note

The insulation resistance could go down to close to 1 M $\Omega$  after installation or when the power is kept off for an extended period of time because of the accumulation of refrigerant in the compressor. If the insulation resistance is below 1 M $\Omega$ , please use the following procedure to take care of this.

- •Connect all power supply wires to the compressor and turn on the power to the heat source unit.
- •By turning on the main power and keeping it on for at least 12 hours, the refrigerant in the compressor will evaporate and the insulation resistance will go up.
- •Turn off the main power and leave it for at least 10 minutes.
- •Disconnect the power supply wires from the compressor, measure the compressor's insulation resistance, and confirm that the resistance has recovered to 1  $M\Omega$  or greater.

### Earth leakage current measurement method

•For easy on-site measurement of the earth leakage current, enable the filter with a measurement instrument that has filter functions as below, clamp all the power supply wires, and measure.

Recommended measurement instrument: CLAMP ON LEAK HITESTER 3283 made by HIOKI E.E. CORPORATION

•When measuring one device alone, measure near the device's power supply terminal block.

### (5) Simple checking procedure for individual components of main inverter circuit

### Note

Before inspecting the inside of the control box, turn off the power, keep the unit off for at least 10 minutes, and confirm that the voltage between FT-P and FT-N on INV Board has dropped to DC20V or less.

Part name	Judgment method						
IGBT module	See "Troubleshooting for IGBT Module ". (IX [4] - 6 - (6) )						
Rush current protection resistor R1, R5	Measure the resistance between terminals R1 and R5: 22 ohm ± 10%						
Magnetic Contactor 52C	This electromagnetic relay is rated at 230 VAC and is driven by a coil.  Check the resistance between terminals  Upper  Installation direction  Check point Checking criteria(W)  Coil Between Terminals A1 and A2 Not to be short-circuited Between Terminals 5 and 6 oo oo						
DC reactor DCL	Measure the resistance between terminals: 10hm or lower (almost 0 ohm) Measure the resistance between terminals and the chassis:∞						

### (6) Troubleshooting for IGBT Module

Measure the resistances between each pair of terminals on the IGBT with a tester, and use the results for troubleshooting. The terminals on the INV board are used for the measurement.

### 1) Notes on measurement

- •Check the polarity before measuring. (On the tester, black normally indicates plus.)
- •Check that the resistance is not open ( $\infty$  ohm) or not shorted (to 0 ohm).
- •The values are for reference, and the margin of errors is allowed.
- •The result that is more than double or half of the result that is measured at the same measurement point is not allowed.
- •Disconnect all the wiring connected the INV board, and make the measurement.

### 2) Tester restriction

- Use the tester whose internal electrical power source is 1.5V or greater
- •Use the dry-battery-powered tester.

#### Note

(The accurate diode-specific resistance cannot be measured with the button-battery-powered card tester, as the applied voltage is low.)


•Use a low-range tester if possible. A more accurate resistance can be measured.

# Judgment value (reference)

Black						
		SC-P10	FT-N	SC-L1	SC-L2	SC-L3
	SC-P10	-	-	5 - 200 ohm	5 - 200 ohm	5 - 200 ohm
	FT-N	-	-	∞	∞	∞
Red	SC-L1	∞	5 - 200 ohm	-	-	-
	SC-L2	∞	5 - 200 ohm	-	-	-
	SC-L3	∞	5 - 200 ohm	-	-	-


		Black							
		SC-P2	FT-N	SC-U	SC-V	SC-W			
	SC-P2	-	-	5 - 200 ohm	5 - 200 ohm	5 - 200 ohm			
	FT-N	-	-	∞	∞	∞			
Red	SC-U	∞	5 - 200 ohm	-	-	-			
	SC-V	∞	5 - 200 ohm	-	-	-			
	SC-W	∞	5 - 200 ohm	-	-	-			

## INV board external diagram



### -7- Control Circuit


## (1) Control power source function block



<sup>\*</sup> MA remote controllers and M-NET remote controllers cannot be used together.

(Both the M-NET and MA remote controller can be connected to a system with a system controller.)

### (2) Troubleshooting transmission power circuit of heat source unit



## [5] Refrigerant Leak

#### Note

Refer to the relevant sections of the manual for how to set SW4 on the control board.

- Leak spot: In the case of extension pipe for indoor unit (Cooling season)<PQHY>
- 1) Mount a pressure gauge on the service check joint (CJ2) on the low-pressure side.
- Stop all the indoor units, and close the liquid service valve (BV2) inside the heat source unit while the compressor is being stopped.
- 3) Stop all the indoor units; turn on SW4 No.912 (SW6-10:ON) on the heat source unit control board while the compressor is being stopped.(Pump down mode will start, and all the indoor units will run in cooling test run mode.)
- 4) In the pump down mode (SW4 No.912 (SW6-10:ON)), all the indoor units will automatically stop when the low pressure (63LS) reaches 0.383MPa [55psi] or less or 15 minutes have passed after the pump mode started. Stop all the indoor units and compressors when the pressure indicated by the pressure gauge, which is on the check joint (CJ2) for low-pressure service, reaches 0.383MPa [55psi] or 20 minutes pass after the pump down operation is started.
- 5) Close the gas service valve (BV1) inside the heat source unit.
- 6) Collect the refrigerant that remains in the extended pipe for the indoor unit. Do not discharge refrigerant into the atmosphere when it is collected.
- 7) Repair the leak.
- 8) After repairing the leak, vacuum\*1 the extension pipe and the indoor unit.
- 9) To adjust refrigerant amount, open the service valves (BV1 and BV2) inside the heat source unit and turn off SW4 No.912 (SW6-10:ON).
- 2. Leak spot: In the case of heat source unit (Cooling season)<PQHY>
- (1) Run all the indoor units in the cooling test run mode.
- 1) Set SW4 No. 769 (SW6-10: ON) on the control board of the heat-source unit to ON to operate all indoor units in the test-run mode.
- 2) Change the setting of the remote controller for all the indoor units to the cooling mode.
- 3) Check that all the indoor units are performing a cooling operation.
- (2) Check the values of Tc and TH6.

(To display the values on the LED screen, use the self-diagnosis switch (SW4 (SW6-10:OFF)) on the heat source unit control board.)

- 1) When Tc-TH6 is 10°C [18°F] or more: See the next item (3).
- 2) When Tc-TH6 is less than 10°C [18°F]: After the compressor stops, collect the refrigerant inside the system, repair the leak, perform evacuation, and recharge new refrigerant. (Leak spot: 4. In the case of heat source unit, handle in the same way as heating season.)



The figure at left shows that the switches 1 through 5 are set to ON and 6 through 10 are set to OFF.

<sup>\*1.</sup> Refer to Chapter I [8] Vacuum Drying (Evacuation) for detailed procedure.

#### (3) Stop all the indoor units, and stop the compressor.

- 1) Set SW4 No. 769 (SW6-10: ON) on the control board of the heat-source unit from ON to OFF to stop all indoor units and the compressors.
- 2) Check that all the indoor units are being stopped.
- (4) Close the service valves (BV1 and BV2).
- (5) To prevent the liquid seal, extract small amount of refrigerant from the check joint of the liquid service valve (BV2), as the liquid seal may cause a malfunction of the unit.
- (6) Collect the refrigerant that remains inside the heat source unit. Do not discharge refrigerant into air into the atmosphere when it is collected.
- (7) Repair the leak.
- (8) After repairing the leak, replace the dryer with the new one, and perform evacuation \*1 inside the heat source unit.
- (9) To adjust refrigerant amount, open the service valves (BV1 and BV2) inside the heat source unit.

#### Note

When the power to the heat source-indoor unit must be turned off to repair the leak after closing the service valves specified in the item 4, turn the power off in approximately one hour after the heat source-indoor units stop.

When 30 minutes have passed after the item (4) above, the indoor unit lev turns from fully closed to slightly open to prevent the refrigerant

LEV2 on the heat-source unit will open after the unit has been stopped for 15 minutes to allow the recovery of the refrigerant from and the evacuation of the heat-source unit. If the power is turned off within 5 minutes of the stoppage of the unit, LEV2 may close, trapping highpressure refrigerant in the heat-source unit and creating a dangerous situation.

- Therefore, if the power source is turned off within 30 minutes, the lev remains fully closed and the refrigerant remains sealed. When only the power for the indoor unit is turned off, the indoor unit LEV turns from faintly open to fully closed.
- 3) In the cooling cycle, the liquid refrigerant circuit between 21S4a and LEV2 will form a closed circuit. To recover the refrigerant or evacuate the system, "LEV1" and "SV5b, c" will be open by setting SW4 No.988 (SW6-10:ON) in the stop mode. Set SW4 No.988 (SW6-10:ON) to OFF upon completion of all work.
- 4) When performing the maintenance work, such as vacuum drying, pumping down, or refrigerant recovery, on the heat-source unit, operate the water circuit pump and circulate the water to prevent the water side of the heat exchanger from freezing.

### Leak spot: In the case of extension pipe for indoor unit (Heating season)<PQHY>

- (1) Run all the indoor units in heating test run mode.
- 1) Set SW4 No. 769 (SW6-10: ON) on the control board of the heat-source unit to ON to operate all indoor units in the test-run
- Change the setting of the remote controller for all the indoor units to the heating mode.
- 3) Check that all the indoor units are performing a heating operation.

#### (2) Stop all the indoor units, and stop the compressor.

- 1) Set SW4 No. 769 (SW6-10: ON) on the control board of the heat-source unit from ON to OFF to stop all indoor units and the compressors.
- 2) Check that all the indoor units are stopped.
- (3) Close the service valves (BV1 and BV2).
- (4) Collect the refrigerant that remains inside the indoor unit. Do not discharge refrigerant into air into the atmosphere when it is collected.
- (5) Repair the leak.
- (6) After repairing the leak, perform evacuation\*1 of the extension pipe for the indoor unit, and open the service valves (BV1 and BV2) to adjust refrigerant.

### 4. Leak spot: In the case of heat source unit (Heating season)<PQHY>

- 1) Collect the refrigerant in the entire system (heat source unit, extended pipe and indoor unit). Do not discharge refrigerant into the atmosphere when it is collected.
- Repair the leak.
- 3) After repairing the leak, replace the dryer with the new one, and perform evacuation of the entire system, and calculate the standard amount of refrigerant to be added (for heat source unit, extended pipe and indoor unit), and charge the refrigerant. Refer to "VIII [4] 3. "

#### Note

If the indoor or heat source units need to be turned off for repairing leaks during Step 1) above, turn off the power approximately 1 hour after

the units came to a stop.

LEV2 on the heat-source unit will open after the unit has been stopped for 15 minutes to allow the recovery of the refrigerant from and the evacuation of the heat-source unit.

If the power is turned off within 15 minutes of the stoppage of the unit, LEV2 may close, trapping high-pressure refrigerant in the heat-source unit and creating a dangerous situation.

<sup>\*1.</sup> Refer to Chapter I [8] Vacuum Drying (Evacuation) for detailed procedure.

### 5. Leak spot: In the case of extension pipe for indoor unit (Cooling season)<PQRY>

- 1) Mount a pressure gauge on the service check joint (CJ2) on the low-pressure side.
- Stop all the indoor units, and close the high-pressure side refrigerant service valve (BV2) on the heat source unit while the compressor is being stopped.
- 3) Stop all the indoor units; turn on SW4 No.912 (SW6-10:ON) on the heat source unit control board while the compressor is being stopped.(Pump down mode will start, and all the indoor units will run in cooling test run mode.)
- 4) In the pump down mode (SW4 No.912 (SW6-10:ON) is ON), all the indoor units will automatically stop when the low pressure (63LS) reaches 0.383MPa [55psi] or less or 15 minutes have passed after the pump mode started. Stop all the indoor units and compressors when the pressure indicated by the pressure gauge, which is on the check joint (CJ2) for low-pressure service, reaches 0.383MPa [55psi] or 20 minutes pass after the pump down operation is started.
- 5) Close the service ball valve (BV1) on the low-pressure pipe on the heat source unit.
- 6) Collect the refrigerant that remains in the extended pipe for the indoor unit. Do not discharge refrigerant into the atmosphere when it is collected.
- 7) Repair the leak.
- 8) After repairing the leak, vacuum\*1 the extension pipe and the indoor unit.
- 9) To adjust refrigerant amount, open the ball valves (BV1 and BV2) inside the heat source unit and turn off SW4 No.912 (SW6-10:ON).

### 6. Leak spot: In the case of heat source unit (Cooling season)<PQRY>

- (1) Run all the indoor units in the cooling test run mode.
- Set SW4 No. 769 (SW6-10: ON) on the control board of the heat-source unit to ON to operate all indoor units in the test-run mode.
- 2) Change the setting of the remote controller for all the indoor units to the cooling mode.
- 3) Check that all the indoor units are performing a cooling operation.

#### (2) Check the SC16 value.

(This valve can be displayed on the LED by setting the self-diagnosis switch (SW4(SW6-10:OFF)) on the heat source unit control board.)

- 1) When SC16 is 10°C [18°F] or above: Go to the next item (3).
- 2) When the SC16 value is below 10°C [18°F]: After the compressor has stopped, extract the refrigerant in the system, repair the leak, evacuate the air from the system \*1, and charge the system with refrigerant. (If the leak is in the heat source unit, follow the same procedure as listed under "heating season.")

SC16 self-diagnosis switch





The figure at left shows that the switches 1 through 5 are set to ON and 6 through 10 are set to OFF.

### (3) Stop all the indoor units, and stop the compressor.

- 1) Set SW4 No. 769 (SW6-10: ON) on the control board of the heat-source unit from ON to OFF to stop all indoor units and the compressors.
- 2) Check that all the indoor units are being stopped.
- (4) Close the ball valves (BV1 and BV2).
- (5) Collect the refrigerant that remains inside the heat source unit.Do not discharge refrigerant into air into the atmosphere when it is collected.
- (6) Repair the leak.
- (7) After repairing the leak, replace the dryer with the new one, and perform evacuation \*1 inside the heat source unit.
- (8) To adjust refrigerant amount, open the ball valves (BV1 and BV2) inside the heat source unit.
- (9) When performing the maintenance work, such as vacuum drying, pumping down, or refrigerant recovery, on the heat-source unit, operate the water circuit pump and circulate the water to prevent the water side of the heat exchanger from freezing.

## 7. Leak spot: In the case of extension pipe for indoor unit (Heating season)<PQRY>

- (1) Run all the indoor units in heating test run mode.
- 1) Set SW4 No. 769 (SW6-10: ON) on the control board of the heat-source unit to ON to operate all indoor units in the test-run mode
- 2) Change the setting of the remote controller for all the indoor units to the heating mode.
- 3) Check that all the indoor units are performing a heating operation.

### (2) Stop all the indoor units, and stop the compressor.

- 1) Set SW4 No. 769 (SW6-10: ON) on the control board of the heat-source unit from ON to OFF to stop all indoor units and the compressors.
- 2) Check that all the indoor units are stopped.
- (3) Close the ball valves (BV1 and BV2).
- (4) Collect the refrigerant that remains inside the indoor unit. Do not discharge refrigerant into air into the atmosphere when it is collected.
- (5) Repair the leak.
- (6) After repairing the leak, perform evacuation of the extension pipe\*1 for the indoor unit, and open the ball valves (BV1 and BV2) to adjust refrigerant.

### 8. Leak spot: In the case of heat source unit (Heating season)<PQRY>

- 1) Collect the refrigerant in the entire system (heat source unit, extended pipe and indoor unit). Do not discharge refrigerant into the atmosphere when it is collected.
- 2) Repair the leak.
- 3) Repair the leak, and evacuate the air from the entire system \*1. Then, calculate the proper amount of refrigerant to be added (heat source unit + extension pipe + indoor unit), and charge the system with that amount. Refer to Chapter VIII [4] 4. for the proper amount of refrigerant charge.

### Note


When performing the maintenance work, such as vacuum drying, pumping down, or refrigerant recovery, on the heat-source unit, operate the water circuit pump and circulate the water to prevent the water side of the heat exchanger from freezing.

<sup>\*1.</sup> Refer to Chapter I [8] Vacuum Drying (Evacuation) for detailed procedure.


## [6] Compressor Replacement Instructions

## 1. Compressor Replacement Instructions


Follow the procedures below to remove the compressor components and replace the compressor. Reassemble them in the reverse order after replacing the compressor.




1. Remove the service panel (front panels).



2. Remove the control box.




Remove the electrical wiring from the frame, unscrew the screws holding the check joint fixing plate, and remove the frame.




- 4. Remove the acoustic insulation from the compressor.
- 5. Remove the thermistor (TH15) and the Heater (CH11) wiring (if it is installed) from the compressor.




Remove or protect the wiring around the compressor and the thermal insulation on the accumulator, unbraze the pipe from the compressor, and replace the compressor. Follow the procedures below to remove the compressor components and replace the compressor. Reassemble them in the reverse order after replacing the compressor.




1. Remove the front service panels (top and bottom).



2. Remove the control box.



- 3. Remove the acoustic insulation material from the compressor. 5. First, move the nearby wiring and the pipe covers out
- 4. Remove the thermistor (TH15) and the Heater (CH11) wiring (if it is installed) from the compressor.



First, move the nearby wiring and the pipe covers out of the way or protect them from the brazing flame; then debraze the pipe, and replace the compressor.

#### 1. Explained below are procedures for replacing water-cooled heat exchanger assembly parts.

#### 1. Applicable models

- PQHY-P72, 96, 120ZLMU-A1/B
- PQRY-P72, 96, 120ZLMU-A1/B

#### 2. Parts to be serviced

The procedures apply to the service parts listed in the table below.

No.	Parts to be replaced	Required materials	Qty.
1	Water-cooled heat exchanger assembly	Water-cooled heat exchanger service parts kit	1

#### 3. Procedures

- \* Precautions for starting replacement
- · Check that the main power supply is OFF.
- · Check that no refrigerant is in the heat source unit.

Remove each part according to the 1)-8) procedures on the next page before replacing service parts.


Mount the removed parts back in place in a reversed procedures of 1)-8) on the next page after replacing service parts.

### (1) Water-cooled heat exchanger assembly replacement procedures


- Removal procedures
  - ① After removing the right panel (R), hang the beam of the Component cooler heat exchanger from the four-way valve piping to keep the Component cooler heat exchanger from falling downward, using a wire (see the right figure below).
  - ② Remove the duct and the solenoid valve block support, pipe support, pipe fixing plate.
  - 3 Hang the solenoid valve block and pipe from the four-way valve to keep the solenoid valve block and pipe from falling downward, using a wire (see the right figure below).
  - 4 Unbraze the pipe, remove the pipe assembly (see the left figure below), and remove the water heat exchanger fixing screws.
  - ⑤ Pull out the water heat exchanger.

### Installation procedures


- (6) Install the replacement water heat exchanger.
- Reinstall the water heat exchanger fixing screws, solenoid valve block support, pipe support, pipe fixing plate and duct as they were.
- \* Precautions for replacing water-cooled heat exchanger assembly
- Be sure to perform no-oxidation brazing when brazing.
- After brazing, check the condition around the brazing. After confirming no leakage, evacuate the air inside. (\*1)
- · Perform brazing with care of the flame direction so that it does not burn cables and plates etc. in the unit.
- \*1: Refer to Chapter I [8] Vacuum Drying (Evacuation) for detailed procedure.



- ① After removing the right panel (R), hang the beam of the Component cooler heat exchanger from the four-way valve piping to keep the Component cooler heat exchanger from falling downward, using a wire (see the right figure below).
- 2 Remove the duct and the solenoid valve block support, pipe support, pipe fixing plate.
- ③ Hang the solenoid valve block and pipe from the four-way valve to keep the solenoid valve block and pipe from falling downward, using a wire (see the right figure below).



- ① Unbraze the pipe, remove the pipe assembly (see the left figure below), and remove the water heat exchanger fixing screws.
- (5) Pull out the water heat exchanger.



Reinstall the water heat exchanger fixing screws, solenoid valve block support, pipe support, pipe fixing plate and duct as they were.

- 1. Explained below are procedures for replacing water-cooled heat exchanger assembly parts.
- 2. Applicable models
  - PQHY-P144, P168, P192ZLMU-A1/B
- 3. Service parts list




### 4. Procedures


\*Precautions for starting replacement

- Check that the main power supply is OFF.
- Check that no refrigerant is in the heat source unit.


Remove each part according to the 1)-5) procedures before replacing service parts.


Mount the removed parts back in place in a reversed procedures of 1)-5) after replacing service parts.






②Disconnect the wiring from the circuit board








### 2) To remove the Frame M













3) To remove the Water Heat Exchanger and Front Panel

①Remove the screw (total 2 places) and pipe cover, and then remove the Front Panel according to the 1-4 procedures on the figure below.


the 1-4 procedures on the









After removing Front Panel.




4) To move the Water Heat Exchanger and the Partition Plate



②To move the Partition Plate to the left.






5) To remove the water heat exchanger


①Remove the screw (total 2 places), and debraze the pipe (total 2 places).

②To move the Water Heat Exchanger to the left.

③Pull out in front Water Heat Exchanger.







### Precautions for brazing

- Be sure to perform no-oxidation brazing when brazing.
- After brazing, check the condition around the brazing. After confirming no leakage, evacuate the air inside.
- Perform brazing with care of the flame direction so that it does not burn cables and plates etc. in the unit.


- 1. Explained below are procedures for replacing water-cooled heat exchanger assembly parts.
- 2. Applicable models
  - PQRY-P144, P168, P192ZLMU-A1/B
- 3. Service parts list





### 4. Procedures

- \*Precautions for starting replacement
- Check that the main power supply is OFF.
- Check that no refrigerant is in the heat source unit.


Remove each part according to the 1)-5) procedures before replacing service parts. Mount the removed parts back in place in a reversed procedures of 1)-5) after replacing service parts.









②Disconnect the wiring from the circuit board as shown in the figure.






#### 2) To remove the Frame M


①Remove the screw. (total 4 places)





3) To remove the Water Heat Exchanger and Front Panel

①Remove the screw (total 2 places), pipe cover and cable tie (total 2 places), and then remove the Front Panel according to the 1-4 procedures on the figure below.










After removing Front Panel.

After removing Frame M.




4) To move the Water Heat Exchanger and the Partition Plate



②To move the Partition Plate to the left.






5) To remove the water heat exchanger


①Remove the screw (total 2 places), and debraze the pipe (total 3 places).







③Pull out in front Water Heat Exchanger.



# \* Precautions for brazing

- Be sure to perform no-oxidation brazing when brazing.
- After brazing, check the condition around the brazing. After confirming no leakage, evacuate the air inside.
- Perform brazing with care of the flame direction so that it does not burn cables and plates etc. in the unit.


## [7] Servicing the BC controller

### 1. Service panel

\*Special care must be taken when replacing heavy parts.

### Work procedure Explanatory figure <KB type, J type, and 4-, 6-, 8-branch types> 1) Remove the control box by unscrewing the four fixing screws. (Figure 1) Unscrew the four service panel fixing screws. (Figure 2) Control Box 3) Remove the top panel by unscrewing the nine fixing screws. (Figure 2) Ceiling panel (Figure 1) <For J-type, 12- and 16-branch types, JA-type, and KA-type> 1) Remove the service panel (1) by unscrewing the two fixing screws. (Figure 3) Remove the control box by unscrewing the four fixing Service panel screws. (Figure 3) 3) Remove the top panel by unscrewing the 10 fixing (Figure 2) screws. (Figure 4) 4) Remove the service panel (2) by unscrewing the two fixing screws. (Figure 4) Control Box (Figure 3) Service panel (1) Ceiling panel Service panel (2) (Figure 4)

#### 2. Control box



### 3. Removing the drain pan

#### Work procedure


- Remove the fixing screw on the long side of the bottom panel.
  - (Four places encircled by circles in Figure 1)
- 2) To prevent the bottom panel from falling, of the four screws indicated with triangles in Figure 1, only loosen (but not remove) the two screws that are diagonally located or on the opposite ends of the long side of the panel (either (1) and (3), (2) and (4), (1) and (4), or (2) and (3)). Remove the two remaining screws.
- 3) As shown in the enlarged view of Figure 1, the fastening screw hole on the short side looks like two circles in different shape joined together (double-snowman shape). Slide the bottom panel in the direction of the arrow, and remove it in the downward direction. (Figure 2)
- 4) When removing the drain pan, hold the protruded area of the panel or the socket and pull it straight down, using caution not to let it come into contact with the sheet metal. (Figure 3) If the drain pan comes into contact with the sheet metal, the drain pan may be scraped, leading to water leakage.

#### Installing the bottom panel

- Of the four screws indicated with triangles in Figure 1, partially tighten the two screws that are diagonally located ed (either (1) and (3), or (2) and (4)).
- 2) Thread the screw into the double-snowman shaped hole, move the panel in the opposite direction as when it was removed in step 3) above, set the screw into the smaller circle, and tighten the screw to hold the panel in place.
- 3) Tighten the remaining screws.

### Note

Do not stay directly underneath the unit when working with the bottom plate. Remove the drain piping to remove the drain pan. Check that no water has accumulated in the drain pan.



## 4. Thermistor (liquid pipe/gas pipe temperature detection)

\*Special care must be taken when replacing heavy parts.

### Work procedure Explanatory figure (1) Remove the service panel. 1) See the right figure and the section [III [4] BC Controller Components] for information on TH11, TH12, TH15, and TH<sub>16</sub> (2) Remove the lead wire of the piping sensor from the control board. 1) TH11,TH12 (CN10) 2) TH15,TH16 (CN11) (3) Pull out the temperature sensor from the tempera-TH12 ture sensor housing, and replace the temperature sensor with the new one. **TH11** (4) Connect the lead wire of the temperature sensor se-TH15 curely on the control board. CMB-P1016NU-KA1/2

### 5. Pressure sensor

### Work procedure Explanatory figure (1) Remove the service panel. 1) See the right figure and the section [III [4] BC Controller Components] for information on pressure sensors PS1 and PS3. (2) Remove the pressure sensor connector in trouble from the control board, and insulate the connector. 1) Liquid-side pressure sensor (CNP1) 2) Intermediate-part pressure sensor (CNP3) PS1 (3) Attach a new pressure sensor to the place which is shown in the figure, and insert the connector to the control board. CMB-P1016NU-KA1/2 Note When gas leaks from the pressure sensor, repair the leak, and follow the instructions above if required.

### 6. LEV

Work procedure	Explanatory figure
(1) Remove the service panel. (2) Replace the LEV in trouble.  Note  Secure enough service space in the ceiling for welding operation, and conduct the work carefully. If required, dismount the unit from the ceiling, and conduct the work.	LEV4 LEV1 LEV3 CMB-P1016NU-KA1/2

### 7. Solenoid valve

\*Special care must be taken when replacing heavy parts.

Work procedure	Explanatory figure
<ol> <li>(1) Remove the service panel.</li> <li>(2) Remove the connector of the solenoid valve in trouble.</li> <li>(3) Remove the solenoid valve coil.</li> <li>1) The coils on the solenoid valves SVA, SVB, SVC, SVM1, and SVM1b can be serviced through the inspection door. SVC is accessible for replacement by removing the drain pan.</li> </ol>	Solenoid valve  CMB-P1016NU-KA1/2

## [8] Troubleshooting Using the Heat source Unit LED Error Display

If the LED error display appear as follows while all the SW4 switches and SW6-10 are set to OFF, check the items under the applicable item numbers below.

### 1. Error code appears on the LED display.

Refer to IX [2] Responding to Error Display on the Remote Controller.

#### 2. LED is blank.

Take the following troubleshooting steps.


- (1) If the voltage between pins 1 and 3 of CNDC on the control board is outside the range between 220 VDC and 380 VDC, refer to IX [4] -7- (2) Troubleshooting transmission power circuit of heat source unit.
- (2) If the LED error display becomes lit when the power is turned on with all the connectors on the control board except CNDC disconnected, there is a problem with the wiring to those connectors or with the connectors themselves.
- (3) If nothing appears on the display under item (2) above AND the voltage between pins 1 and 3 of CNDC is within the range between 220 VDC and 380 VDC, control board failure is suspected.
- 3. Only the software version appears on the LED display.
- (1) Only the software version appears while the transmission cables to TB3 and TB7 are disconnected.
- 1) Wiring failure between the control board and the transmission line power supply board.(CN62, CNPS, CNIT, CNS2, CN102)
- 2) If item 1) checks out OK, the transmission line power supply board failure is suspected.
- 3) If items 1) and 2) check out OK, control board failure is suspected.
- (2) If the LED display appears as noted in "X [1] 2. LED display at Initial setting" while the transmission cables to TB3 and TB7 are disconnected, failure with the transmission cable or the connected equipment is suspected.

ΧL	.ED	<b>Monitor</b>	<b>Display</b>	on the	Heat	source	Unit	Board	ı
----	-----	----------------	----------------	--------	------	--------	------	-------	---

## [1] How to Read the LED on the Service Monitor

### 1. How to read the LED

By setting the DIP SW 4-1 through 4-10 (SW6-10: OFF) (Switch number 10 is represented by 0), the operating condition of the unit can be monitored on the service monitor. (Refer to the table on the following pages for DIP SW settings.) The service monitor uses 4-digit 7-segment LED to display numerical values and other types of information.





• In the example above, 1 through 9 are set to ON, and 10 is set to OFF.

Pressure and temperature are examples of numerical values, and operating conditions and the on-off status of solenoid valve are examples of flag display.

#### 1) Display of numerical values

Example: When the pressure data sensor reads 18.8kg/cm<sup>2</sup> (Item No. 58)


- •The unit of pressure is in kg/cm<sup>2</sup>
- Use the following conversion formula to convert the displayed value into a value in SI unit.

Value in SI unit (MPa) = Displayed value (kg/cm<sup>2</sup>) x 0.098




### 2) Flag display

Example: When 21S4a, 21S4b, SV1a are ON. (Item No. 3)



Example: 3-minutes restart mode (Item No. 14)



### 2. LED display at initial setting

From power on until the completion of initial settings, the following information will be displayed on the monitor screen. (Displays No. 1 through No. 4 in order repeatedly.)

No	Item	Display	Remarks
1	Software version		[0103] : Version 1.03
2	Refrigerant type		[ 410] : R410A
3	Model and capacity		[H-20]: Cooling/Heating 20 HP For the first few minutes after power on, the capacity of each heat source unit is displayed. Thereafter, the combined capacity is displayed.
4	Communication address		[ 51] : Address 51

After the initial settings have been completed, the information on these items can be checked by making the switch setting that corresponds to No. 517 in the LED display table.

#### Note

Only item No. 1 "Software Version" appears on the display if there is a wiring failure between the control board and the transmission line power supply board or if the circuit board has failed.

### +How to convert HP capacity to Model name /Ton

HP capacity is the capacity of heat source unit that is shown on LED display at initial setting. Please refer to the following table to convert from HP capacity to Model name/Ton.

HP	Model	Ton
8	P72	6.0
10	P96	8.0
12	P120	10.0
16	P144	12.0
18	P168	14.0
20	P192	16.0
22	P216	18.0

HP	Model	Ton
24	P240	20.0
30	P288	24.0
32	P312	26.0
34	P336	28.0
36	P360	30.0

#### 3. Time data storage function

The heat source unit has a simple clock function that enables the unit to calculate the current time with an internal timer by receiving the time set by the system controller, such as AG-150A.

If an error (including a preliminary error) occurs, the error history data and the error detection time are stored into the service memory. The error detection time stored in the service memory and the current time can be seen on the service LED.

#### Note

- 1) Use the time displayed on the service LED as a reference.
- 2) The date and the time are set to "00" by default. If a system controller that sets the time, such as AG-150A is not connected, the elapsed time and days since the first power on will be displayed.
  - If the time set on a system controller is received, the count will start from the set date and the time.
- 3) The time is not updated while the power of the heat source unit is turned off. When the power is turned off and then on again, the count will resume from the time before the power was turned off. Thus, the time that differs the actual time will be displayed. (This also applies when a power failure occurs.)

The system controller, such as AG-150A, adjusts the time once a day. When the system controller is connected, the time will be automatically updated to the correct current time after the time set by the system controller is received. (The data stored into the memory before the set time is received will not be updated.)

## (1) Reading the time data:

1) Time display


Example: 12 past 9



\* Disappears if the time data is deviated due to a power failure, or if a system controller that sets the time is not connected.


### 2) Date display

•When the main controller that can set the time is connected Example: May 10, 2003



\* Appears between the year and the month, and nothing appears when the date is displayed.

•When the main controller that can set the time is not connected Example: 52 days after power was turned



LED monitor display

Currer	Current data													
o O	SW4 1-10 [0: OFF, 1: ON] (SW6-10: OFF)	Ite	ltem				Disp	Display				Unit (A, B) *1	t *1	Remarks
	1234567890			LD1	LD2	FD3	LD4	FD5	PDP	LD7	PD8	00	SO	
C	0000000	Relay output display 1 Lighting	ıt display 1	Comp in op- eration				72C		၁၀	CPU in oper- ation	∢	4	
•		Check (error) display 1 OC/OS error	r) display 1 r			0000 to 999	99 (Address an	0000 to 9999 (Address and error codes highlighted)	ighlighted)			В	В	
-	1000000000	Check (error) display 2 OC/OS error	r) display 2			0000 to 990	99 (Address an	0000 to 9999 (Address and error codes highlighted)	ighlighted)			∢	∢	Display of the latest pre- liminary error If no preliminary errors are detected, "" ap- pears on the display.
2	0100000000	Check (error) display 3 (Including IC and BC)	r) display 3 3 and BC)			0000 to 99(	99 (Address an	0000 to 9999 (Address and error codes highlighted)	ighlighted)			В		If no errors are detected, "" appears on the display.
ď	44,0000000	Relay out-	Тор	21S4a		CH11		SV1a				<	<	
n	000000000000000000000000000000000000000	putuispiay 2	Bottom			21S4b						ζ	ζ.	
4	001000000	Relay out- putdisplay 3	Тор	SV4a	SV4b				SV4d	6/\S	Power supply for indoor transmission line	∢	٧	
			Bottom	SV7a	SV7b		SV7c							
7	111000000	Special control		Retry opera- tion	Emergency					Communication error between the OC and OS	Communication error 3-minute restart delay mode	В	В	
თ	1001000000	Communication de- mand capacity	tion de-				0000 tc	0000 to 9999				В	В	If not demanded controlled, "" [%] appears on the display.
10	0101000000	Contact point demand capacity	nt demand				0000 tc	0000 to 9999				В		If not demanded controlled, "" [%] appears on the display.
<del></del>	1101000000	External signal (Open input contact point)	nal contact	Contact point de- mand	Low-noise mode (Capacity priority )		Cooling- heating changeover (Cooling)	Cooling- heating changeover (Heating)				∢	4	
**	** A. The condition of either OC or OS is displayed individually. B. The condition of the entire refrience to displayed	in SO Jo Jo Je	e dienlayed ir	Adividually B. Th	at to notition of the	optire refrice	rant evetem ie	havelasib						

\*1 A: The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerant system is displayed.

Current data

No.	SW4 1-10 [0: OFF, 1: ON] (SW6-10: OFF)	ltem	٤				Display	olay				Unit (A, B) *1	it )*1	Remarks
	1234567890	ı		LD1	LD2	FD3	LD4	FD5	PD7	LD7	FD8	00	SO	
12	0011000000	External signal (Open input contact point)	nal contact							Pump interlock (Contact: open)	Low-noise mode (Quiet priori- ty)	∢	4	
4	0111000000	Heat source unit operation status	unit opera-	BC opera- tion signal		3-minutes restart mode	Compressor in operation	Preliminary error	Error	3-minutes restart after instanta- neous power failure	Preliminary low pres- sure error	V V	٧	
15	1111000000	OC/OS identification	tification				SO/20	SO,				∢	⋖	
4	00000	unit	Тор	Unit No. 1	Unit No. 2	Unit No. 3	Unit No. 4	Unit No. 5	Unit No. 6	Unit No. 7	Unit No. 8	В		The lamp that corre-
2		cneck	Bottom	Unit No. 9	Unit No. 10	Unit No. 11	Unit No. 12	Unit No. 13	Unit No. 14	Unit No. 15	Unit No. 16			sponds to the unit that came to an abnormal stop
7	40000	ı	Тор	Unit No. 17	Unit No. 18	Unit No. 19	Unit No. 20	Unit No. 21	Unit No. 22	Unit No. 23	Unit No. 24			lights.
=	0000		Bottom	Unit No. 25	Unit No. 26	Unit No. 27	Unit No. 28	Unit No. 29	Unit No. 30	Unit No. 31	Unit No. 32			the error is reset.
ά	000000		Тор	Unit No. 33	Unit No. 34	Unit No. 35	Unit No. 36	Unit No. 37	Unit No. 38	Unit No. 39	Unit No. 40			Each unit that comes to an abnormal unit will be
<u> </u>			Bottom	Unit No. 41	Unit No. 42	Unit No.43	Unit No. 44	Unit No. 45	Unit No. 46	Unit No47	Unit No. 48			given a sequential num-
0	110010000		Top	Unit No. 49	Unit No. 50									starting with 1.
2			Bottom											
00	000000		Тор	Unit No. 1	Unit No. 2	Unit No. 3	Unit No. 4	Unit No. 5	Unit No. 6	Unit No. 7	Unit No. 8	В		Lit during cooling
0		Operation	Bottom	Unit No. 9	Unit No. 10	Unit No. 11	Unit No. 12	Unit No. 13	Unit No. 14	Unit No. 15	Unit No. 16			Lit during neating Unlit while the unit is
5	40400000		Тор	Unit No. 17	Unit No. 18	Unit No. 19	Unit No. 20	Unit No. 21	Unit No. 22	Unit No. 23	Unit No. 24			stopped or in the fan
-			Bottom	Unit No. 25	Unit No. 26	Unit No. 27	Unit No. 28	Unit No. 29	Unit No. 30	Unit No. 31	Unit No. 32			
22	011010000	ı	Тор	Unit No. 33	Unit No. 34	Unit No. 35	Unit No. 36	Unit No. 37	Unit No. 38	Unit No. 39	Unit No. 40			
1			Bottom	Unit No. 41	Unit No. 42	Unit No.43	Unit No. 44	Unit No. 45	Unit No. 46	Unit No47	Unit No. 48			
23	111010000		Тор	Unit No. 49	Unit No. 50									
9			Bottom											
1 A: T	1 A: The condition of either OC or OS is displayed individually. B: The condition of	er OC or OS is	s displayed in	ndividually. B: Ti	he condition of t	the entire refrigerant system is displayed.	erant system is	displayed.						

A: The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerant system is displaye

Current data

urrent data	. nala													
No.	SW4 1-10 [0: OFF, 1: ON] (SW6-10: OFF)		ltem				Display	olay				Unit (A, B) *1	it :) *1	Remarks
	1234567890			LD1	LD2	FD3	LD4	FD5	PDP	LD7	PD8	20	SO	
20	0000110000	Indoorunit	Тор	Unit No. 1	Unit No. 2	Unit No. 3	Unit No. 4	Unit No. 5	Unit No. 6	Unit No. 7	Unit No. 8	В		Lit when thermostat is on
<b>5</b>	00000	thermo- stat	Bottom	Unit No. 9	Unit No. 10	Unit No. 11	Unit No. 12	Unit No. 13	Unit No. 14	Unit No. 15	Unit No. 16			Unlit when thermostat is off
25	1001100000		Тор	Unit No. 17	Unit No. 18	Unit No. 19	Unit No. 20	Unit No. 21	Unit No. 22	Unit No. 23	Unit No. 24			
67	000001		Bottom	Unit No. 25	Unit No. 26	Unit No. 27	Unit No. 28	Unit No. 29	Unit No. 30	Unit No. 31	Unit No. 32			
96	0404400000		Тор	Unit No. 33	Unit No. 34	Unit No. 35	Unit No. 36	Unit No. 37	Unit No. 38	Unit No. 39	Unit No. 40			
07	00000		Bottom	Unit No. 41	Unit No. 42	Unit No.43	Unit No. 44	Unit No. 45	Unit No. 46	Unit No47	Unit No. 48			
7.0	1101100000		Тор	Unit No. 49	Unit No. 50									
Ž			Bottom											
37	1010010000	BC operation mode	on mode	Cooling-only ON	Cooling-only OFF	Heating-only ON	Heating-only OFF	Mixed-mode ON	Mixed-mode OFF	Fan	Stop	В		
39	1110010000	Heat source tion mode	Heat source unit Opera- tion mode	Permissible stop	Standby	Cooling	Cooling- main	Heating	Heating- main			⋖	۷	
42	0101010000	Heat source mode	Heat source unit control mode	Stop	Thermo OFF	Abnormal stop	Scheduled	Initial start up	Defrost	Oil balance	Low fre- quency oil recovery	∢	∢	
43	1101010000			Warm-up mode	Refrigerant recovery							∢	⋖	
45	1011010000	TH4					-99.9 to 999.9	6.666.0				∢	4	The unit is [°C]
46	0111010000	TH3					-99.9 tc	-99.9 to 999.9				∢	A	
47	1111010000	TH7					-99.9 to 999.9	6.666.0				∢	4	
48	0000110000	1Н6					-99.9 to 999.9	6.666.0				4	∢	
49	1000110000	TH2					-99.9 to	-99.9 to 999.9				∢	4	
20	0100110000	TH5					-99.9 to	-99.9 to 999.9				٧	4	
51	1100110000	TH8					-99.9 to 999.9	6.666.0				∢	4	
53	1010110000	THINV					-99.9 tc	-99.9 to 999.9				∢	4	Unit in [°C]
26	0001110000	THHS1					-99.9 tc	-99.9 to 999.9				∢	4	The unit is [°C]
58	0101110000	High-pressure sensor data	ure sensor				-99.9 tc	-99.9 to 999.9				4	Α	The unit is [kgf/cm²]
59	1101110000	Low-pressure sensor data	ire sensor				-99.9 to 999.9	989.9				∢	∢	
1 A · Th	1 A: The condition of either OC or OS is displayed individually. B: The condition of	er OC or OS	e dienlaved in	Aividually B. Th		the entire refricerant system is displayed	rant evetem is	displayed			•	•		

\*1 A: The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerant system is displayed.

Current data

5													
No.	SW4 1-10 [0: OFF, 1: ON] (SW6-10: OFF)	Item				Display	olay				Unit (A, B) *1	iit 3) *1	Remarks
	1234567890		LD1	TD2	FD3	LD4	FD5	PDP	LD7	FD8	20	SO	
78	0111001000	ΣQj				0000 to 9999	6666				В	В	
62	1111001000	Σ Qjc				0000 to 9999	6666				В	В	
80	0000101000	∑ Qjh				0000 to 9999	6666				В	В	
81	1000101000	Target Tc				-99.9 to 999.9	6.666.9				В		The unit is [°C]
82	0100101000	Target Te				-99.9 to 999.9	6.999.9				В		
83	1100101000	Tc				-99.9 to	-99.9 to 999.9				A	A	
84	0010101000	Te				-99.9 to 999.9	6.666.				۷	∢	
98	0110101000	Total frequencies (OC+OS)				0000 to 9999	6666				В		Control data [ Hz ]
87	1110101000	Total frequency of each unit				0000 to 9999	6666				∢	∢	
88	0001101000	COMP frequency				0000 to 9999	6666				Α	∢	
91	1101101000	Comp operating frequency				0000 to 9999	6666				4	∢	Unit in [rsp] The inverter output current (voltage) frequency will equal the integer multiples of the operating frequency of the compressor.
92	0011101000	Number of times error occurred during IH crankcase heating by compressor motor				0000 to 9999	6666				∢	∢	Number of times INV error occurred during IH crankcase heating by compressor motor
93	10111101000	All AK (OC+OS)				0000 to 9999	6666				В		
94	0111101000	AK				0000 to 9999	6666				Α	∢	
66	1100011000	LEV6				0000 to 9999	6666				∢	∢	Heat source unit LEV opening (Fully open: 3000)
100	0010011000	LEV7				0000 to 9999	6666				∢	∢	Heat source unit LEV opening (Fully open: 3000)
102	0110011000	LEVINV				0 to 480	480				∢	∢	Heat source unit LEV opening (Fully open: 480)
1 A: T	ne condition of eith	1 A. The condition of either OC or OS is displayed individually. B. The condition of	dividually. B: The	he condition of	the entire refrige	the entire refrigerant system is displayed	displayed						

\*1 A: The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerant system is displayed.

Current data

5	סמון פוור ממנמ												
o N	SW4 1-10 [0: OFF, 1: ON] (SW6-10: OFF)	ltem				Disp	Display				Unit (A, B) *1	iit 5) *1	Remarks
	1234567890		LD1	LD2	FD3	LD4	FD5	PD9	LD7	FD8	00	SO	
103	1110011000	LEV1				0 to	0 to 480				٨	Α	Heat source unit LEV opening (Fully open: 480)
108	0011011000	COMP operating current (DC)				00.0 tc	00.0 to 999.9				٧	∢	Peak value[A]
<u>+</u>	1111011000	COMP bus voltage				00.0 tc	00.0 to 999.9				∢	∢	The unit is [V]
116	0010111000	Number of times the unit went into the mode to remedy wet vapor suction				t 0000 tr	0000 to 9999				В		
117	1010111000	COMP Operation time Upper 4 digits				4 0000 t	0000 to 9999				٧	⋖	The unit is [h]
118	0110111000	COMP Operation time Lower 4 digits				0000 k	0000 to 9999				∢	∢	
121	1001111000	Backup mode	Abnormal pressure rise	High-pres- sure drop	Low-pres- sure drop	Abnormal Td rise		Control box temperature rise			∢	∢	Stays lit for 90 seconds after the completion of backup control
123	1101111000	COMP number of start- stop events Upper 4 digits				t 0000	0000 to 9999				٨	∢	Count-up at start-up The unit is [Time]
124	0011111000	COMP number of start- stop events Lower 4 digits				n 0000	0000 to 9999				٨	∢	
129	1000000100	Integrated operation time of compressor (for rotation purpose)				<b>ካ</b> 0000	0000 to 9999				В		The unit is [ h ]
*1 A: Ti	ne condition of eith	*1 A: The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerant system is displayed.	ndividually. B: T	he condition of	the entire refric	rerant system is	displayed.						

1 A: The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerant system is displayed

Current data

Current data	t data													
No.	SW4 1-10 [0: OFF, 1: ON] (SW6-10: OFF)	4	ltem				Display	ılay				Unit (A, B) *1	it ) *1	Remarks
	1234567890			LD1	LD2	LD3	LD4	FD5	PD9	LD7	PD8	00	SO	
130	0010000100	Relay out-	Тор	SVM1	SVM2	SVM1b	SVM2b					α		
76	001000100	putdisplay BC(Main)	Bottom									۵	ı	
133	1010000100		Тор	SVA1	SVB1	SVC1	SVA2	SVB2	SVC2			α		
3	0010000101		Bottom	SVA3	SVB3	SVC3	SVA4	SVB4	SVC4			۵	ı	
707	0110000100		Тор	SVA5	SVB5	SVC5	SVA6	SVB6	SVC6			٥		
<u></u>	0010000110		Bottom	SVA7	SVB7	SVC7	SVA8	SVB8	SVC8			۵		
707	4400000		Тор	SVA9	SVB9	SVC9	SVA10	SVB10	SVC10			٥		
<u> </u>	0010000111		Bottom	SVA11	SVB11	SVC11	SVA12	SVB12	SVC12			۵	ı	
200	0000		Тор	SVA13	SVB13	SVC13	SVA14	SVB14	SVC14			٥		
05	0010001000		Bottom	SVA15	SVB15	SVC15	SVA16	SVB16	SVC16			۵		
20	000	Relay out-	Тор	SVA1	SVB1	SVC1	SVA2	SVB2	SVC2			c		
8	000000000000000000000000000000000000000	putdisplay BC(Sub1)	Bottom	SVA3	SVB3	SVC3	SVA4	SVB4	SVC4			۵	1	
200	440400400		Тор	SVA5	SVB5	SVC5	SVA6	SVB6	SVC6			٥		
<u></u>	001000101		Bottom	SVA7	SVB7	SVC7	SVA8	SVB8	SVC8			۵	1	
7	0011000100		Тор	SVA9	SVB9	SVC9	SVA10	SVB10	SVC10			٥		
5	0010001100		Bottom	SVA11	SVB11	SVC11	SVA12	SVB12	SVC12			۵	ı	
7	4044000400		Тор	SVA13	SVB13	SVC13	SVA14	SVB14	SVC14			٥		
<u>+</u>	0010001101		Bottom	SVA15	SVB15	SVC15	SVA16	SVB16	SVC16			۵	ı	
140	444000400	Relay out-	Тор	SVA1	SVB1	SVC1	SVA2	SVB2	SVC2			٥		
3	00000	putdisplay BC(Sub2)	Bottom	SVA3	SVB3	SVC3	SVA4	SVB4	SVC4			۵	ı	
77	0000100100		Тор	SVA5	SVB5	SVC5	SVA6	SVB6	SVC6			٥		
<u> </u>	00000		Bottom	SVA7	SVB7	SVC7	SVA8	SVB8	SVC8			۵	ı	
175	40004000		Тор	SVA9	SVB9	SVC9	SVA10	SVB10	SVC10			۵		
3	00000		Bottom	SVA11	SVB11	SVC11	SVA12	SVB12	SVC12			۵	ı	
176	0100100100		Тор	SVA13	SVB13	SVC13	SVA14	SVB14	SVC14			α		
2			Bottom	SVA15	SVB15	SVC15	SVA16	SVB16	SVC16			מ		
*1 A: Th	*1 A: The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerant system is displayed.	₃r OC or OS	is displayed in	ndividually. B: Th	ne condition of t	he entire refrige	rant system is d	lisplayed.						

A: The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerant system is displayed.

Current data

												•	
O	SW4 1-10 [0: OFF, 1: ON] (SW6-10: OFF)	Item				Dis	Display				Unit (A, B) *1	it ***	Remarks
	1234567890		LD1	LD2	LD3	LD4	FD2	PDP	LD7	8GT	00	SO	
149	1010100100	BC(Main or standard) TH11				1 6.66-	.99.9 to 999.9				В		
150	0110100100	BC(Main)TH12				-99.9 te	-99.9 to 999.9				В		
151	1110100100	BC(Main)TH15				-99.9 t	.99.9 to 999.9				В		
152	0001100100	BC(Main)TH16				-99.9 te	99.9 to 999.9				В		
153	1001100100	BC(Main)63HS1				-99.9 t	.99.9 to 999.9				В		
154	0101100100	BC(Main)63HS3				-99.9 t	.99.9 to 999.9				В		
155	1101100100	BC(Main)SC11				-99.9 t	-99.9 to 999.9				В		
156	0011100100	BC(Main)SH12				-99.9 t	.99.9 to 999.9				В		
157	1011100100	BC(Main)SH13				-99.9 t	99.9 to 999.9				В		
158	0111100100	BC(Main)SC16				-99.9 te	.99.9 to 999.9				В		
159	1111100100	BC(Main)LEV1				0000 t	0000 to 2000				В		LEV1 opening (Fully open:2000)
160	0000010100	BC(Main)LEV3				0000 t	0000 to 2000				В		LEV3 opening (Fully open:2000)
161	1000010100	BC(Sub1)TH22				-99.9 te	.99.9 to 999.9				В		
162	0100010100	BC(Sub1)TH25				-99.9 te	.99.9 to 999.9				В		
163	1100010100	BC(Sub1)LEV3				0000 t	0000 to 2000				В		LEV3a opening (Fully open:2000)
164	0010010100	BC(Sub2)TH22				-99.9 te	.99.9 to 999.9				В		
165	1010010100	BC(Sub2)TH25				-99.9 te	-99.9 to 999.9				В		
166	0110010100	BC(Sub2)LEV3				0000 t	0000 to 2000				В		LEV3a opening (Fully open:2000)
167	1110010100	BC(Main)LEV2				0000 t	0000 to 2000				В		LEV2 opening (Fully open:2000)
1 A: Th	e condition of eith	*1 A. The condition of either OC or OS is displayed individually. B. The condition of the entire refrigerant system is displayed	ndividually. E	t. The condition o	f the entire refring	erant system is	displayed						

\*1 A: The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerant system is displayed.

Current data

5													
o N	SW4 1-10 [0: OFF, 1: ON] (SW6-10: OFF)	ltem				Q	Display				Unit (A, B) *1	3) *1	Remarks
•	1234567890		LD1	LD2	FD3	LD4	FD5	PDP	LD7	PD8	00	SO	
178	0100110100	Error history 1				0000	0000 to 9999				В	В	Address and error codes
179	1100110100	Error details of inverter				Error details of i	Error details of inverter (0001-0120)	20)			∢	∢	nignlignted If no errors are detected,
180	0010110100	Error history 2				0000	0000 to 9999				В	В	" " appears on the dis-
181	1010110100	Error details of inverter				Error details of i	Error details of inverter (0001-0120)	20)			∢	4	Preliminary error informa-
182	0110110100	Error history 3				0000	0000 to 9999				В	В	tion of the OS does not appear on the OC.
183	1110110100	Error details of inverter				Error details of i	Error details of inverter (0001-0120)	20)			٧	∢	Neither preliminary error
184	0001110100	Error history 4				0000	0000 to 9999				В	В	error information of the IC
185	1001110100	Error details of inverter				Error details of i	Error details of inverter (0001-0120)	20)			∢	4	appears on the OS.
186	0101110100	Error history 5				)000	0000 to 9999				В	В	
187	1101110100	Error details of inverter				Error details of i	Error details of inverter (0001-0120)	20)			∢	4	
188	0011110100	Error history 6				0000	0000 to 9999				В	В	
189	1011110100	Error details of inverter				Error details of i	Error details of inverter (0001-0120)	20)			∢	⋖	
190	0111110100	Error history 7				)000	0000 to 9999				В	В	
191	1111110100	Error details of inverter				Error details of i	Error details of inverter (0001-0120)	20)			∢	⋖	
192	0000001100	Error history 8				0000	0000 to 9999				В	В	
193	1000001100	Error details of inverter				Error details of i	Error details of inverter (0001-0120)	20)			∢	⋖	
194	0100001100	Error history 9				)000	0000 to 9999				В	В	
195	1100001100	Error details of inverter				Error details of i	Error details of inverter (0001-0120)	20)			∢	∢	
196	0010001100	Error history 10				0000	0000 to 9999				В	В	
197	1010001100	Error details of inverter			-	Error details of i	Error details of inverter (0001-0120)	20)			A	∢	
198	0110001100	Error history of inverter (At the time of last data backup before error)				)000	0000 to 9999				В	В	
199	1110001100	Error details of inverter			_	Error details of i	Error details of inverter (0001-0120)	20)			٧	∢	
A: Th	e condition of either	A: The condition of either OC or OS is displayed individually. B: The condition of the entire refriderant system is displayed	dividually B.	The condition	of the entire refr	inerant system	is displayed.						

\*1 A: The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerant system is displayed.

**Error history** 

	(S) (S) (S)												
No.	SW4 1-10 [0: OFF, 1: ON] (SW6-10: OFF)	ltem				Display	olay				Unit (A, B) *1	it ;) *1	Remarks
	1234567890		LD1	LD2	FD3	LD4	FD5	PD7	LD7	FD8	00	SO	
201	1001001100	Heat source unit operation status	BC opera- tion signal	Warm-up mode	3-minutes restart mode	Compressor in operation	Preliminary error	Error	3-minutes restart after instanta-neous power failure	Preliminary low pres- sure error	∢	∢	
202	0101001100	OC/OS identification				SO/OO	SO.				∢	∢	
203	1101001100	BC operation mode	Cooling-only ON	Cooling-only OFF	Heating-only ON	Heating-only OFF	Mixed-mode ON	Mixed-mode OFF	Fan	Stop	∢	∢	
205	1011001100	Heat source unit Operation mode	Permissible stop	Standby	Cooling	Cooling- main	Heating	Heating- main			∢	∢	
208	0000101100	Heat source unit control mode	Stop	Thermo OFF	Abnormal stop	Scheduled	Initial start up		Oil balance	Low fre- quency oil recovery	∢	∢	
209	1000101100		Warm-up mode	Refrigerant recovery							٧	Α	
211	1100101100	Relay output display 1 Lighting	Comp in op- eration				72C		00	Always lit	∢	Α	
212	0010101100	Relay out- putdisplay 2 Bottom Lighting	21S4a		CH11		SV1a				∢	∢	
213	1010101100	Relay out- Top putdisplay 3 Lighting	SV4a	SV4b				SV4d	6/\S	Lit while power to the indoor units is being sup- plied	4	4	
		Bottom	SV7a	SV7b		SV7c							
,	10 9 10.0 · · · · · · · · · · · · · · · · · ·			9 - 1100			1						

\*1 A: The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerant system is displayed.

**Error history** 

	•												
N O	SW4 1-10 [0: OFF, 1: ON] (SW6-10: OFF)	ltem				Disk	Display				Unit (A, B) *1	oit 3) *1	Remarks
	1234567890		LD1	LD2	FD3	LD4	FD5	9Q7	LD7	PD8	၁၀	SO	
216	0001101100	TH4				-99.9 tc	-99.9 to 999.9				∢	⋖	The unit is [°C]
217	1001101100	TH3				-99.9 tc	-99.9 to 999.9				∢	4	
218	0101101100	TH7				-99.9 tc	-99.9 to 999.9				∢	⋖	
219	1101101100	TH6				-99.9 tc	-99.9 to 999.9				∢	∢	
220	0011101100	TH2				-99.9 tc	-99.9 to 999.9				∢	4	
221	1011101100	TH5				-99.9 tc	-99.9 to 999.9				∢	4	
222	0111101100	TH8				-99.9 tc	-99.9 to 999.9				∢	4	
224	0000011100	THINV				-99.9 tc	-99.9 to 999.9				∢	٧	Unit in [°C]
227	1100011100	THHS1				-99.9 tc	.99.9 to 999.9				∢	4	The unit is [°C]
229	1010011100	High-pressure sensor data				-99.9 tc	.99.9 to 999.9				∢	∢	The unit is [kgf/cm²]
230	0110011100	Low-pressure sensor data				-99.9 tc	.99.9 to 999.9				∢	∢	
249	1001111100	ΣQj				0000 tc	0000 to 9999				В	В	
250	0101111100	∑ Qjc				0000 tc	0000 to 9999				В	В	
251	1101111100	∑ Qjh				0000 tc	0000 to 9999				В	В	
252	0011111100	Target Tc				-99.9 tc	-99.9 to 999.9				В		The unit is [°C]
253	1011111100	Target Te				-99.9 tc	.99.9 to 999.9				В		
254	011111100	Tc				-99.9 tc	-99.9 to 999.9				∢	∢	The unit is [°C]
255	111111100	Те				-99.9 tc	-99.9 to 999.9				٧	4	
257	1000000010	Total frequencies (OC+OS)				0000 tr	0000 to 9999				В		Control data [ Hz ]
258	0100000010	Total frequency of each unit				0000 tc	0000 to 9999				٧	∢	
259	1100000010	COMP frequency				0000 tc	0000 to 9999				Α	А	
797	0110000010	Comp operating frequency				0000 tc	0000 to 9999				٧	٧	Unit in [rps]
264	00001000010	All AK (OC+OS)				0000 tc	0000 to 9999				В		
597	1001000010	AK				0000 tc	0000 to 9999				4	۷	
*1 A·T	The condition of eith	*1 A: The condition of either OC or OS is displayed individually. B: The condition of the	ndividually B.	The condition of	the entire refric	he entire refrigerant system is displayed	dienlaved						

**Error history** 

	•												
o.	SW4 1-10 [0: OFF, 1: ON] (SW6-10: OFF)	ltem				Σ	Display				Unit (A, B) *1	it *1	Remarks
_	1234567890		LD1	LD2	FD3	LD4	FD5	PDP	LD7	FD8	20	SO	
270	0111000010	TEV6				0000	0000 to 9999				∢	Ą	Heat source unit LEV opening (Fully open: 3000)
271	1111000010	LEV7				0000	0000 to 9999				∢	Ą	Heat source unit LEV opening (Fully open: 3000)
273	1000100010	LEVINV				0 tc	0 to 480				∢	∢	Heat source unit LEV opening (Fully open: 480)
274	0100100010	LEV1				0 tc	0 to 480				A	А	Heat source unit LEV opening (Fully open: 480)
279	1110100010	COMP operating current (DC)				00.0 t	00.0 to 999.9				∢	Ą	Peak value [A]
282	01001100010	COMP bus voltage				00.01	00.0 to 999.9				∢	∢	The unit is [V]
288	0000010010	COMP Operation time Upper 4 digits				0000	0000 to 9999				A	A	The unit is [ h ]
289	1000010010	COMP Operation time Lower 4 digits				0000	0000 to 9999				A	А	
294	0110010010	COMP number of start- stop events Upper 4 digits				0000	0000 to 9999				4	A	Count-up at start-up The unit is [Time]
295	1110010010	COMP number of start- stop events Lower 4 digits				0000	0000 to 9999				٨	А	
300	0011010010	Integrated operation time of compressor (for rotation purpose)				0000	0000 to 9999				В		The unit is [ h ]

\*1 A: The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerant system is displayed.

**Current data** 

No.	SW4 1-10 [0: OFF, 1: ON] (SW6-10: OFF)	ltem				Display	olay				Unit (A, B)*1	1)t 3)*1	Remarks
	1234567890		LD1	TD2	FD3	LD4	FD5	PDP	LD7	PD8	00	SO	
301	1011010010	Power supply unit				OC/OS <-> Address	> Address				В		
302	0111010010	Start-up unit				OC/OS <-> Address	> Address				В		
320	0000001010	BC(Main)TH11				-99.9 tc	-99.9 to 999.9				В		
321	1000001010	BC(Main)TH12				-99.9 tc	-99.9 to 999.9				В		
322	0100001010	BC(Main)TH15				-99.9 tc	-99.9 to 999.9				В		
323	1100001010	BC(Main)TH16				-99.9 tc	-99.9 to 999.9				В		
324	0010001010	BC(Main)63HS1				-99.9 tc	.99.9 to 999.9				В		
325	1010001010	BC(Main)63HS3				-99.9 tc	-99.9 to 999.9				В		
330	0101001010	BC(Main)LEV1				0000 tc	0000 to 2000				В		
331	1101001010	BC(Main)LEV3				0000 tc	0000 to 2000				В		
332	0011001010	BC(Sub1)TH22				-99.9 tc	-99.9 to 999.9				В		
333	101100110	BC(Sub1)TH25				-99.9 tc	-99.9 to 999.9				В		
334	0111001010	BC(Sub1)LEV3				0000 to 2000	2000				В		
335	1111001010	BC(Sub2)TH22				-99.9 tc	-99.9 to 999.9				В		
336	0000101010	BC(Sub2)TH25				-99.9 tc	-99.9 to 999.9				В		
337	1000101010	BC(Sub2)LEV3				0000 tc	0000 to 2000				В		
338	0100101010	BC(Main)LEV2				0000 to 2000	2000				В		
						٠				1			

\*1 A: The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerant system is displayed.

Data on indoor unit system

No.	SW4 1-10 [0: OFF, 1: ON] (SW6-10: OFF)	ltem				Display	lay				Unit (A, B) *1	it ) *1	Remarks
	1234567890	T	LD1	LD2	FD3	LD4	LD5	9Q7	LD7	PD8	20	SO	
351	1111101010	IC1 Address/capacity code		0000 t	0000 to 9999			0000 to 9999	6666		В		Displayed alternately ev-
352	0000011010	IC2 Address/capacity code		0000 t	0000 to 9999			0000 tc	0000 to 9999				ery 5 seconds
353	1000011010	IC3 Address/capacity code		0000 t	0000 to 9999			0000 to 9999	6666				
354	0100011010	IC4 Address/capacity code		0000 t	0000 to 9999			0000 to 9999	6666				
355	1100011010	IC5 Address/capacity code		0000 t	0000 to 9999			0000 to 9999	6666				
356	0010011010	IC6 Address/capacity code		1 0000	0000 to 9999			0000 tc	0000 to 9999				
357	1010011010	IC7 Address/capacity code		1 0000	0000 to 9999			0000 tc	0000 to 9999				
358	0110011010	IC8 Address/capacity code		1 0000	0000 to 9999			0000 to 9999	6666				
329	1110011010	IC9 Address/capacity code		0000 t	0000 to 9999			0000 to 9999	6666				
360	0001011010	IC10 Address/capacity code		0000 t	0000 to 9999			0000 to 9999	6666				
361	1001011010	IC11 Address/capacity code		0000 t	0000 to 9999			0000 to 9999	6666				
362	01011010	IC12 Address/capacity code		0000 t	0000 to 9999			0000 to 9999	6666				
363	1101011010	IC13 Address/capacity code		0000 t	0000 to 9999			0000 to 9999	6666				
364	0011011010	IC14 Address/capacity code		0000 t	0000 to 9999			0000 to 9999	6666				
365	1011011010	IC15 Address/capacity code		0000 t	0000 to 9999			0000 to 9999	6666				
366	0111011010	IC16 Address/capacity code		0000 t	0000 to 9999			0000 to 9999	6666				
367	1111011010	IC17 Address/capacity code		0000 t	0000 to 9999			0000 to 9999	6666				
368	0000111010	IC18 Address/capacity code		0000 t	0000 to 9999			0000 tc	0000 to 9999				
369	1000111010	IC19 Address/capacity code		0000 t	0000 to 9999			0000 to 9999	6666				
370	0100111010	IC20 Address/capacity code		0000 t	0000 to 9999			0000 to 9999	6666				
371	1100111010	IC21 Address/capacity code		0000 t	0000 to 9999			0000 to 9999	6666				
372	0010111010	IC22 Address/capacity code		0000 t	0000 to 9999			0000 to 9999	6666				
373	1010111010	IC23 Address/capacity code		0000 t	0000 to 9999			0000 to 9999	6666				
374	0110111010	IC24 Address/capacity code		0000 t	0000 to 9999			0000 to 9999	6666				
375	1110111010	IC25 Address/capacity code		0000 t	0000 to 9999			0000 to 9999	6666				
376	0001111010	IC26 Address/capacity code		0000 t	0000 to 9999			0000 tc	0000 to 9999				
377	1001111010	IC27 Address/capacity code		0000 t	0000 to 9999			0000 to 9999	6666				
*1 A: 1	The condition of eith	*1 A: The condition of either OC or OS is displayed individually. B: The condition of the entire refriderant system is displayed.	Ily. B: The co	ndition of the er	itire refrigerant	system is disp	ayed.						

A: The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerant system is displaye

Data on indoor unit system

מומכ	Data on macol anni system												
Š	SW4 1-10 [0: OFF, 1: ON] (SW6-10: OFF)	ltem				Display	olay				Unit (A, B) *1	*	Remarks
	1234567890		LD1	LD2	FD3	LD4	FD5	PTP9	LD7	LD8	00	SO	
378	0101111010	IC28 Address/capacity code		1 0000	0000 to 9999			0000 to 9999	6666		В		Displayed alternately ev-
379	1101111010	IC29 Address/capacity code		0000	00 to 9999			0000 to 9999	6666				ery 5 seconds
380	0011111010	IC30 Address/capacity code		10000	0000 to 9999			0000 to 9999	6666				
381	1011111010	IC31 Address/capacity code		10000	0000 to 9999			0000 to 9999	6666				
382	0111111010	IC32 Address/capacity code		10000	0000 to 9999			0000 to 9999	6666				
383	1111111010	IC33 Address/capacity code		10000	0000 to 9999			0000 to 9999	6666				
384	0000000110	IC34 Address/capacity code		10000	0000 to 9999			0000 to 9999	6666				
385	1000000110	IC35 Address/capacity code		0000	00 to 9999			0000 to 9999	6666				
386	0100000110	IC36 Address/capacity code		10000	0000 to 9999			0000 to 9999	6666				
387	1100000110	IC37 Address/capacity code		10000	0000 to 9999			0000 to 9999	6666				
388	0010000110	IC38 Address/capacity code		0000	0000 to 9999			0000 to 9999	6666				
389	1010000110	IC39 Address/capacity code		0000	0000 to 9999			0000 to 9999	6666				
390	0110000110	IC40 Address/capacity code		10000	0000 to 9999			0000 to 9999	6666				
391	1110000110	IC41 Address/capacity code		10000	0000 to 9999			0000 to 9999	6666				
392	0001000110	IC42 Address/capacity code		10000	0000 to 9999			0000 to 9999	6666				
393	1001000110	IC43 Address/capacity code		10000	0000 to 9999			0000 to 9999	6666				
394	0101000110	IC44 Address/capacity code		10000	0000 to 9999			0000 to 9999	6666				
395	1101000110	IC45 Address/capacity code		1 0000	0000 to 9999			0000 to 9999	6666				
396	0011000110	IC46 Address/capacity code		1 0000	0000 to 9999			0000 to 9999	6666				
397	1011000110	IC47 Address/capacity code		10000	0000 to 9999			0000 to 9999	6666				
398	0111000110	IC48 Address/capacity code		0000	00 to 9999			0000 to 9999	6666				
399	1111000110	IC49 Address/capacity code		10000	0000 to 9999			0000 to 9999	6666				
400	0000100110	IC50 Address/capacity code		0000	00 to 9999			0000 to 9999	6666				
408	0001100110	IC1 Suction temperature				-99.9 tc	-99.9 to 999.9				В		The unit is [°C]
409	1001100110	IC2 Suction temperature				-99.9 tc	-99.9 to 999.9						
410	0101100110	IC3 Suction temperature				-99.9 tc	-99.9 to 999.9						
411	1101100110	IC4 Suction temperature				-99.9 tc	-99.9 to 999.9						
'1 A: T	The condition of eith	1 A: The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerant system is displayed	Ilv B. The con	dition of the e	ntire refrigeran	svstem is disc	laved.						

1 A: The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerant system is displayed

Data on indoor unit system

Data o	Data on indoor unit system	stem												
No.	SW4 1-10 [0: OFF, 1: ON] (SW6-10: OFF)	ltem					Dis	Display				Unit (A, B) *1	3) *1	Remarks
	1234567890		LD1	LD2	2	FD3	LD4	FD5	9Q7	LD7	RD1	၁၀	SO	
412	0011100110	IC5 Suction temperature					-99.9 te	-99.9 to 999.9				В		The unit is [°C]
413	1011100110	IC6 Suction temperature					-99.9 te	-99.9 to 999.9						
414	0111100110	IC7 Suction temperature					-99.9 te	-99.9 to 999.9						
415	1111100110	IC8 Suction temperature					-99.9 te	-99.9 to 999.9						
416	0000010110	IC9 Suction temperature					-99.9 te	-99.9 to 999.9						
417	1000010110	IC10 Suction temperature					-99.9 to	-99.9 to 999.9						
418	0100010110	IC11 Suction temperature					-99.9 te	-99.9 to 999.9						
419	1100010110	IC12 Suction temperature					-99.9 te	-99.9 to 999.9						
420	0010010110	IC13 Suction temperature					-99.9 te	-99.9 to 999.9						
421	1010010110	IC14 Suction temperature					-99.9 te	-99.9 to 999.9						
422	0110010110	IC15 Suction temperature					-99.9 te	-99.9 to 999.9						
423	1110010110	IC16 Suction temperature					-99.9 te	-99.9 to 999.9						
424	0001010110	IC17 Suction temperature					-99.9 te	-99.9 to 999.9						
425	1001010110	IC18 Suction temperature					-99.9 te	-99.9 to 999.9						
426	010101010	IC19 Suction temperature					-99.9 te	-99.9 to 999.9						
427	1101010110	IC20 Suction temperature					-99.9 te	-99.9 to 999.9						
428	0011010110	IC21 Suction temperature					-99.9 te	-99.9 to 999.9						
429	1011010110	IC22 Suction temperature					-99.9 te	-99.9 to 999.9						
430	0111010110	IC23 Suction temperature					-99.9 te	-99.9 to 999.9						
431	1111010110	IC24 Suction temperature					-99.9 te	-99.9 to 999.9						
432	0000110110	IC25 Suction temperature					-99.9 te	-99.9 to 999.9						
433	1000110110	IC26 Suction temperature					-99.9 te	-99.9 to 999.9						
434	0100110110	IC27 Suction temperature					-99.9 te	-99.9 to 999.9						
435	1100110110	IC28 Suction temperature					-99.9 te	-99.9 to 999.9						
436	0010110110	IC29 Suction temperature					-99.9 te	-99.9 to 999.9						
437	1010110110	IC30 Suction temperature					-99.9 te	-99.9 to 999.9						
438	0110110110	IC31 Suction temperature					-99.9 te	-99.9 to 999.9						
*1 A: T	he condition of eith	*1 A: The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerant system is displayed	ly. B: The co	ondition of	the entire	refrigerant s	svstem is disg	olaved.						

1 A: The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerant system is disp

Data on indoor unit system

Data o	Data on indoor unit system	stem												
o N	SW4 1-10 [0: OFF, 1: ON] (SW6-10: OFF)	ltem					Disp	Display				Unit (A, B) *1	3) *1	Remarks
	1234567890		LD1	LD2	5	FD3	LD4	FD5	9G7	LD7	RD1	20	SO	
439	1110110110	IC32 Suction temperature		-			-99.9 tc	-99.9 to 999.9				В		The unit is [°C]
440	0001110110	IC33 Suction temperature					-99.9 tc	-99.9 to 999.9						
441	1001110110	IC34 Suction temperature					-99.9 tc	-99.9 to 999.9						
442	0101110110	IC35 Suction temperature					-99.9 tc	-99.9 to 999.9						
443	1101110110	IC36 Suction temperature					-99.9 tc	-99.9 to 999.9						
444	0011110110	IC37 Suction temperature					-99.9 tc	-99.9 to 999.9						
445	1011110110	IC38 Suction temperature					-99.9 tc	-99.9 to 999.9						
446	01111110110	IC39 Suction temperature					-99.9 tc	-99.9 to 999.9						
447	1111110110	IC40 Suction temperature					-99.9 tc	-99.9 to 999.9						
448	0000001110	IC41 Suction temperature					-99.9 tc	-99.9 to 999.9						
449	1000001110	IC42 Suction temperature					-99.9 tc	-99.9 to 999.9						
450	0100001110	IC43 Suction temperature					-99.9 tc	-99.9 to 999.9						
451	1100001110	IC44 Suction temperature					-99.9 tc	-99.9 to 999.9						
452	0010001110	IC45 Suction temperature					-99.9 tc	-99.9 to 999.9						
453	1010001110	IC46 Suction temperature					-99.9 tc	-99.9 to 999.9						
454	0110001110	IC47 Suction temperature					-99.9 tc	-99.9 to 999.9						
455	1110001110	IC48 Suction temperature					-99.9 tc	-99.9 to 999.9						
456	0001001110	IC49 Suction temperature					-99.9 tc	-99.9 to 999.9						
457	1001001110	IC50 Suction temperature					-99.9 tc	-99.9 to 999.9						
458	0101001110	IC1 Liquid pipe temperature					-99.9 tc	-99.9 to 999.9						
459	1101001110	IC2 Liquid pipe temperature					-99.9 tc	-99.9 to 999.9						
460	0011001110	IC3 Liquid pipe temperature					-99.9 tc	-99.9 to 999.9						
461	1011001110	IC4 Liquid pipe temperature					-99.9 tc	-99.9 to 999.9						
462	0111001110	IC5 Liquid pipe temperature					-99.9 tc	-99.9 to 999.9						
463	1111001110	IC6 Liquid pipe temperature					-99.9 tc	-99.9 to 999.9						
464	0000101110	IC7 Liquid pipe temperature					-99.9 tc	-99.9 to 999.9						
465	1000101110	IC8 Liquid pipe temperature					-99.9 tc	-99.9 to 999.9						
*1 A: T	he condition of eith	*1 A: The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerant system is displayed	lly. B: The co	ondition of	the entire	refrigerant s	system is disp	olaved.						

\*1 A: The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerant system is disp

Data on indoor unit system

Data o	Data on Indoor unit system	stem											
No.	SW4 1-10 [0: OFF, 1: ON] (SW6-10: OFF)	ltem				Display	olay				Unit (A, B) *1	) *1	Remarks
	1234567890		LD1	LD2	FD3	LD4	FD5	PTP9	LD7	FD8	20	SO	
466	0100101110	IC9 Liquid pipe temperature				-99.9 tc	-99.9 to 999.9				В		The unit is [°C]
467	1100101110	IC10 Liquid pipe temperature				-99.9 to	-99.9 to 999.9						
468	0010101110	IC11 Liquid pipe temperature				-99.9 to 999.9	6.666.0						
469	1010101110	IC12 Liquid pipe temperature				-99.9 tc	-99.9 to 999.9						
470	0110101110	IC13 Liquid pipe temperature				-99.9 to	-99.9 to 999.9						
471	1110101110	IC14 Liquid pipe temperature				-99.9 tc	-99.9 to 999.9						
472	0001101110	IC15 Liquid pipe temperature				-99.9 to	-99.9 to 999.9						
473	1001101110	IC16 Liquid pipe temperature				-99.9 to 999.9	6.666.0						
474	0101101110	IC17 Liquid pipe temperature				-99.9 to	-99.9 to 999.9						
475	1101101110	IC18 Liquid pipe temperature				-99.9 tc	-99.9 to 999.9						
476	0011101110	IC19 Liquid pipe temperature				-99.9 tc	-99.9 to 999.9						
477	1011101110	IC20 Liquid pipe temperature				-99.9 to	-99.9 to 999.9						
478	0111101110	IC21 Liquid pipe temperature				-99.9 to 999.9	6.666.0						
479	1111101110	IC22 Liquid pipe temperature				-99.9 to	-99.9 to 999.9						
480	0000011110	IC23 Liquid pipe temperature				-99.9 to	-99.9 to 999.9						
481	1000011110	IC24 Liquid pipe temperature				-99.9 tc	-99.9 to 999.9						
482	0100011110	IC25 Liquid pipe temperature				-99.9 to 999.9	6.666.0						
483	1100011110	IC26 Liquid pipe temperature				-99.9 to	-99.9 to 999.9						
484	0010011110	IC27 Liquid pipe temperature				-99.9 to 999.9	6.666.0						
485	1010011110	IC28 Liquid pipe temperature				-99.9 tc	-99.9 to 999.9						
486	0111001110	IC29 Liquid pipe temperature				-99.9 to	-99.9 to 999.9						
487	1110011110	IC30 Liquid pipe temperature				-99.9 to	-99.9 to 999.9						
488	0001011110	IC31 Liquid pipe temperature				-99.9 to	-99.9 to 999.9						
489	1001011110	IC32 Liquid pipe temperature				-99.9 tc	-99.9 to 999.9						
490	0101011110	IC33 Liquid pipe temperature				-99.9 to	-99.9 to 999.9						
491	1101011110	IC34 Liquid pipe temperature				-99.9 to	-99.9 to 999.9						
492	0011011110	IC35 Liquid pipe temperature				-99.9 to 999.9	6.666						
*1 A: T	The condition of eith	*1 A: The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerant system is displayed	lly. B: The cor	ndition of the er	ntire refrigerant	system is disp	layed.						

Data on indoor unit system

No.	SW4 1-10 [0: OFF, 1: ON] (SW6-10: OFF)	ltem				Disl	Display				Unit (A, B) *1	iit 5) *1	Remarks
	1234567890		LD1	LD2	FD3	LD4	FD5	907	LD7	8G7	၁၀	SO	
493	1011011110	IC36 Liquid pipe temperature				-99.9 te	-99.9 to 999.9				В		The unit is [°C]
494	0111011110	IC37 Liquid pipe temperature				-99.9 te	-99.9 to 999.9						
495	1111011110	IC38 Liquid pipe temperature				-99.9 tc	-99.9 to 999.9						
496	0000111110	IC39 Liquid pipe temperature				-99.9 tr	-99.9 to 999.9						
497	1000111110	IC40 Liquid pipe temperature				-99.9 te	-99.9 to 999.9						
498	0100111110	IC41 Liquid pipe temperature				-99.9 tc	-99.9 to 999.9						
499	1100111110	IC42 Liquid pipe temperature				-99.9 tc	-99.9 to 999.9						
200	0010111110	IC43 Liquid pipe temperature				-99.9 tc	-99.9 to 999.9						
501	1010111110	IC44 Liquid pipe temperature				-99.9 te	-99.9 to 999.9						
502	011111110	IC45 Liquid pipe temperature				-99.9 te	-99.9 to 999.9						
503	1110111110	IC46 Liquid pipe temperature				-99.9 tr	-99.9 to 999.9						
504	0001111110	IC47 Liquid pipe temperature				-99.9 tc	-99.9 to 999.9						
202	1001111110	IC48 Liquid pipe temperature				-99.9 te	-99.9 to 999.9						
206	0101111110	IC49 Liquid pipe temperature				-99.9 te	-99.9 to 999.9						
202	1101111110	IC50 Liquid pipe temperature				-99.9 tr	-99.9 to 999.9						
۲۰۷	410 30 401110400 04.	4 A. The condition of either OF or OF is discharged individually. B. The condition of the continuous series and an along the continuous series and an along the continuous series and along the continuous series are along the continuous series and along the continuous series are along the continuous series and along the continuous series are along the continuous series and along the continuous series are along the continuous series and along the continuous series are along the continuous series and along the continuous series are along the continuous series and along the continuous series are along th	The opposite	o of the	acropingor crit-	toile ei meter	60						

\*1 A: The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerant system is displayed.

Setting data

Remarks									
Unit A, B)*1	SO	∢					٧	В	
Unit (A, B) <sup>*1</sup>	၁၀	∢	В	В	В	В	∢		
	FD8								
	LD7						n address		
	907	nit model	ed units	ed units	ed units	ed units	<ul><li>Communicatio</li></ul>		
Display	FD5	Alternate display of self address and unit model	Count-up display of number of connected units	Count-up display of number of connected units	Count-up display of number of connected units	Count-up display of number of connected units	S/W version -> Refrigerant type -> Model and capacity -> Communication address	OC address display	
Dis	LD4	e display of self	ıp display of nur	nt type -> Mode	OC addre				
	FD3	Alternat	Count-u	Count-u	Count-u	Count-u	on -> Refrigerar		
	TD2						S/W version		
	LD1								1
ltem		Self-address	IC/FU address	RC address	BC/BS/TU address	OS address	Version/Capacity	OC address	
SW4 1-10 [0: OFF, 1: ON] (SW6-10: OFF)	1234567890	0000000001	1000000001	0100000001	1100000001	001000001	101000001	0110000001 OC address	
No.	<u>I</u>	512	513	514	515	516	517	518	

Data on indoor unit system

Dala	Data on muool umt system	Stelli											
N O	SW4 1-10 [0: OFF, 1: ON] (SW6-10: OFF)	ltem				Pist	Display				Unit (A, B) *1	Remarks	
	1234567890		LD1	LD2	FD3	LD4	FD5	PDP	LD7	FD8	00 0s		
523	1101000001	IC1 Gas pipe temperature				-99.9 tc	-99.9 to 999.9				В	The unit is [°C]	
524	0011000001	IC2 Gas pipe temperature				-99.9 tc	-99.9 to 999.9						
525	1011000001	IC3 Gas pipe temperature				-99.9 tc	-99.9 to 999.9						
526	0111000001	IC4 Gas pipe temperature				-99.9 tc	-99.9 to 999.9						
527	1111000001	IC5 Gas pipe temperature				-99.9 tc	-99.9 to 999.9						
528	0000100001	IC6 Gas pipe temperature				-99.9 tc	-99.9 to 999.9						
529	1000100001	IC7 Gas pipe temperature				-99.9 tc	-99.9 to 999.9						
230	0100100001	IC8 Gas pipe temperature				-99.9 tc	-99.9 to 999.9						
531	1100100001	IC9 Gas pipe temperature				-99.9 tc	-99.9 to 999.9						
532	0010100001	IC10 Gas pipe temperature				-99.9 tc	-99.9 to 999.9						
533	1010100001	IC11 Gas pipe temperature				-99.9 tc	-99.9 to 999.9						
534	0110100001	IC12 Gas pipe temperature				-99.9 tc	-99.9 to 999.9						
535	111010001	IC13 Gas pipe temperature				-99.9 tc	-99.9 to 999.9						
536	0001100001	IC14 Gas pipe temperature				-99.9 tc	-99.9 to 999.9						
237	1001100001	IC15 Gas pipe temperature				-99.9 tc	-99.9 to 999.9						
538	0101100001	IC16 Gas pipe temperature				-99.9 tc	-99.9 to 999.9						
539	1101100001	IC17 Gas pipe temperature				-99.9 tc	-99.9 to 999.9						
540	0011100001	IC18 Gas pipe temperature				-99.9 tc	-99.9 to 999.9						
541	1011100001	IC19 Gas pipe temperature				-99.9 tc	-99.9 to 999.9						
542	0111100001	IC20 Gas pipe temperature				-99.9 tc	-99.9 to 999.9						
543	1111100001	IC21 Gas pipe temperature				-99.9 tc	-99.9 to 999.9						
544	0000010001	IC22 Gas pipe temperature				-99.9 tc	-99.9 to 999.9						
545	1000010001	IC23 Gas pipe temperature				-99.9 tc	-99.9 to 999.9						
546	0100010001	IC24 Gas pipe temperature				-99.9 tc	-99.9 to 999.9						
547	1100010001	IC25 Gas pipe temperature				-99.9 tc	-99.9 to 999.9						
548	0010010001	IC26 Gas pipe temperature				-99.9 tc	-99.9 to 999.9						
549	1010010001	IC27 Gas pipe temperature				-99.9 tc	-99.9 to 999.9						
*1 A: T	The condition of eith	*1 A: The condition of either OC or OS is displayed individually. B: The condition of the entire refriderant system is displayed	ually. B: The co	andition of the e	ntire refrigerant	system is displa	aved.					-	

Data on indoor unit system

במום	f =	3) 3(6)												
No.	SW4 1-10 [0: OFF, 1: ON] (SW6-10: OFF)	ltem				Die	Display				Unit (A, B) *1	-	Remarks	
	1234567890	ı	LD1	LD2	FD3	LD4	FD5	9Q7	LD7	FD8	00	SO		
250	0110010001	IC28 Gas pipe temperature				6.66-	-99.9 to 999.9				В	'	The unit is [°C]	1
551	1110010001	IC29 Gas pipe temperature				6.66-	-99.9 to 999.9							
552	0001010001	IC30 Gas pipe temperature				6.66-	-99.9 to 999.9							
553	1001010001	IC31 Gas pipe temperature				6.99.9	-99.9 to 999.9							
554	0101010001	IC32 Gas pipe temperature				6.66-	-99.9 to 999.9							
555	1101010001	IC33 Gas pipe temperature				6.99.9	.99.9 to 999.9							
256	0011010001	IC34 Gas pipe temperature				6.66-	-99.9 to 999.9							
222	1011010001	IC35 Gas pipe temperature				6.66-	-99.9 to 999.9							
258	0111010001	IC36 Gas pipe temperature				6.66-	.99.9 to 999.9							
259	1111010001	IC37 Gas pipe temperature				6.66-	-99.9 to 999.9							
260	0000110001	IC38 Gas pipe temperature				6.66-	-99.9 to 999.9							
561	1000110001	IC39 Gas pipe temperature				6.66-	-99.9 to 999.9							
292	0100110001	IC40 Gas pipe temperature				6.66-	-99.9 to 999.9							
563	1100110001	IC41 Gas pipe temperature				6.66-	.99.9 to 999.9							
564	0010110001	IC42 Gas pipe temperature				6.66-	-99.9 to 999.9							
292	1010110001	IC43 Gas pipe temperature				6.66-	-99.9 to 999.9							
266	0110110001	IC44 Gas pipe temperature				6.66-	.99.9 to 999.9							
292	11101110001	IC45 Gas pipe temperature				6.66-	-99.9 to 999.9							
268	0001110001	IC46 Gas pipe temperature				6.66-	-99.9 to 999.9							
699	1001110001	IC47 Gas pipe temperature				6.66-	-99.9 to 999.9							
220	0101110001	IC48 Gas pipe temperature				6.66-	-99.9 to 999.9							
571	11011110001	IC49 Gas pipe temperature				6.66-	-99.9 to 999.9							
572	0011110001	IC50 Gas pipe temperature				6.66-	-99.9 to 999.9							
*1 A: T	he condition of eith	*1 A: The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerant system is displayed	ually. B: The	condition of the	entire refrigeran	t system is disc	olaved.							_

1 A: The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerant system is displayed.

Data on indoor unit system

	•											
No.	SW4 1-10 [0: OFF, 1: ON] (SW6-10: OFF)	ltem				Display	olay				Unit (A, B)*1	Remarks
	1234567890		LD1	LD2	FD3	LD4	FD5	PDP TDE	LD7	FD8	so	
573	1011110001	IC1SH				-99.9 to 999.9	6.666				В	The unit is [ °C ]
574	0111110001	IC2SH				-99.9 to 999.9	6.666					
575	1111110001	IC3SH				-99.9 to 999.9	6.666.					
929	0000001001	IC4SH				-99.9 to 999.9	6.666.9					
577	1000001001	IC5SH				-99.9 to 999.9	6.666					
578	0100001001	IC6SH				-99.9 to 999.9	6.666.9					
629	1100001001	IC7SH				-99.9 to 999.9	6.666.9					
580	0010001001	IC8SH				-99.9 to 999.9	6.666.0					
581	1010001001	IC9SH				-99.9 to 999.9	6.666.9					
582	0110001001	IC10SH				-99.9 to 999.9	6.666.9					
583	1110001001	IC11SH				-99.9 to 999.9	6.666.9					
584	0001001001	IC12SH				-99.9 to 999.9	6.666.9					
585	1001001001	IC13SH				-99.9 to 999.9	6.666.					
586	0101001001	IC14SH				-99.9 to 999.9	6.666					
287	1101001001	IC15SH				-99.9 to 999.9	6.666					
588	0011001001	IC16SH				-99.9 to 999.9	6.666					
589	1011001001	IC17SH				-99.9 to 999.9	6.666.0					
290	0111001001	IC18SH				-99.9 to 999.9	6.666					
591	1111001001	IC19SH				-99.9 to 999.9	6.666					
592	0000101001	IC20SH				-99.9 to 999.9	6.666					
593	1000101001	IC21SH				-99.9 to 999.9	6.666.					
594	0100101001	IC22SH				-99.9 to 999.9	6.666.9					
595	1100101001	IC23SH				-99.9 to 999.9	6.666					
596	0010101001	IC24SH				-99.9 to 999.9	6.666.					
265	101010101	IC25SH				-99.9 to 999.9	6.666.					
598	0110101001	IC26SH				-99.9 to 999.9	6.666					
599	1110101001	IC27SH				-99.9 to 999.9	6.666					
1 A: T	he condition of eith	1 A: The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerant system is displayed.	ndividually. B: 1	he condition of	the entire refrig	erant system is	displayed.					

Data on indoor unit system

Data c	Data on Indoor unit system	stem												
No.	SW4 1-10 [0: OFF, 1: ON] (SW6-10: OFF)	ltem				Display	olay				Unit (A, B)*1	iit 3)*1	Remarks	
	1234567890		LD1	TD2	FD3	LD4	FD5	PDP	LD7	FD8	20	SO		
009	0001101001	IC28SH				-99.9 to 999.9	999.9				В		The unit is [ °C ]	
601	1001101001	IC29SH				-99.9 tc	-99.9 to 999.9							
602	0101101001	IC30SH				-99.9 tc	-99.9 to 999.9							
603	1101101001	IC31SH				-99.9 tc	-99.9 to 999.9							
604	0011101001	IC32SH				-99.9 to 999.9	989.9							
909	1011101001	IC33SH				-99.9 tc	-99.9 to 999.9							
909	0111101001	IC34SH				-99.9 tc	-99.9 to 999.9							
209	1111101001	IC35SH				-99.9 tc	-99.9 to 999.9							
809	0000011001	IC36SH				-99.9 tc	-99.9 to 999.9							
609	1000011001	IC37SH				-99.9 tc	-99.9 to 999.9							
610	0100011001	IC38SH				-99.9 tc	-99.9 to 999.9							
611	1100011001	IC39SH				-99.9 to 999.9	999.9							
612	0010011001	IC40SH				-99.9 tc	-99.9 to 999.9							
613	1010011001	IC41SH				-99.9 tc	-99.9 to 999.9							
614	0110011001	IC42SH				-99.9 tc	-99.9 to 999.9							
615	1110011001	IC43SH				-99.9 to 999.9	999.9							
616	0001011001	IC44SH				-99.9 tc	-99.9 to 999.9							
617	1001011001	IC45SH				-99.9 tc	-99.9 to 999.9							
618	0101011001	IC46SH				-99.9 tc	-99.9 to 999.9							
619	1101011001	IC47SH				-99.9 tc	-99.9 to 999.9							
620	0011011001	IC48SH				-99.9 tc	-99.9 to 999.9							
621	1011011001	IC49SH				-99.9 tc	-99.9 to 999.9							
622	0111011001	IC50SH				-99.9 to 999.9	999.9							
*1 A·1	The condition of eith	*1 A. The condition of either OC or OS is displayed individually B. The condition of the entire refrinerant system is displayed	individually B.	The condition of	f the entire refrice	erant system is	displayed							

\*1 A: The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerant system is displayed.

Data on indoor unit system

														_
O	SW4 1-10 [0: OFF, 1: ON] (SW6-10: OFF)	Item				Display	olay				Unit (A, B)*1	-	Remarks	
	1234567890		LD1	LD2	LD3	LD4	FD5	9G7	LD7	PD8	00	SO		
623	1111011001	IC1SC				-99.9 to 999.9	6.666.0				В		The unit is [ °C ]	
624	0000111001	IC2SC				-99.9 to 999.9	6.666							
625	1000111001	IC3SC				-99.9 to 999.9	6.666.0							
626	0100111001	IC4SC				-99.9 to 999.9	6.666.0							
627	1100111001	IC5SC				-99.9 to 999.9	6.666.0							
628	0010111001	Cesc				-99.9 to 999.9	6.666.0							
629	1010111001	IC7SC				-99.9 to 999.9	6.666.0							
630	0110111001	IC8SC				-99.9 to 999.9	6.666.0							
631	11101111001	C9SC				-99.9 to 999.9	6.666.0							
632	0001111001	IC10SC				-99.9 to 999.9	6.666.0							
633	1001111001	IC11SC				-99.9 to 999.9	6.666.0							
634	0101111001	IC12SC				-99.9 to 999.9	6.666.0							
635	11011111001	IC13SC				-99.9 to 999.9	6.666.0							
636	0011111001	IC14SC				-99.9 to 999.9	6.666.0							
637	1011111001	IC15SC				-99.9 to 999.9	6.666.0							
638	0111111001	IC16SC				-99.9 to 999.9	6.666							
639	1111111001	IC17SC				-99.9 to 999.9	6.999.9							
640	0000000101	IC18SC				-99.9 to 999.9	6.666.0							
641	1000000101	IC19SC				-99.9 to 999.9	6.666.0							
642	0100000101	IC20SC				-99.9 to 999.9	6.666							
643	1100000101	IC21SC				-99.9 to 999.9	6.666.0							
644	0010000101	IC22SC				-99.9 to 999.9	6.666.0							
645	1010000101	IC23SC				-99.9 to 999.9	6.666.0							
646	0110000101	IC24SC				-99.9 to 999.9	6.666.0							
647	1110000101	IC25SC				-99.9 to 999.9	6.666.0							
648	0001000101	IC26SC				-99.9 to 999.9	6.666.0							
649	1001000101	IC27SC				-99.9 to 999.9	6.666.0							
A:	ne condition of eith€	I A: The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerant system is displayed.	ndividually. B: T	he condition of	the entire refrige	erant system is	displayed.							_

Data on indoor unit system

Data o	Data on Indoor unit system	Stern												
No.	SW4 1-10 [0: OFF, 1: ON] (SW6-10: OFF)	ltem				Dis	Display				Unit (A, B)*1	it ;)*1	Remarks	
	1234567890		LD1	LD2	FD3	LD4	FD5	PDP	LD7	FD8	00	SO		
029	0101000101	IC28SC				6.66-	-99.9 to 999.9				В		The unit is [ °C ]	
651	1101000101	IC29SC				6.66-	-99.9 to 999.9							
652	0011000101	IC30SC				6.66-	.99.9 to 999.9							
653	1011000101	IC31SC				-66.6	-99.9 to 999.9							
654	0111000101	IC32SC				6.66-	-99.9 to 999.9							
655	1111000101	IC33SC				6.66-	.99.9 to 999.9							
929	0000100101	IC34SC				6.66-	-99.9 to 999.9							
299	1000100101	IC35SC				6.66-	-99.9 to 999.9							
658	0100100101	C36SC				6.66-	-99.9 to 999.9							
629	1100100101	IC37SC				6.66-	.99.9 to 999.9							
099	0010100101	IC38SC				6.66-	.99.9 to 999.9							
661	101010101	IC39SC				6.66-	-99.9 to 999.9							
662	0110100101	IC40SC				6.66-	-99.9 to 999.9							
663	1110100101	IC41SC				6.66-	.99.9 to 999.9							
664	0001100101	IC42SC				6.66-	.99.9 to 999.9							
999	1001100101	IC43SC				6.66-	-99.9 to 999.9							
999	0101100101	IC44SC				6.66-	-99.9 to 999.9							
299	1101100101	IC45SC				6.66-	.99.9 to 999.9							
899	0011100101	IC46SC				6.66-	.99.9 to 999.9							
699	1011100101	IC47SC				6.66-	-99.9 to 999.9							
029	0111100101	IC48SC				6.66-	-99.9 to 999.9							
671	1111100101	IC49SC				6.66-	99.9 to 999.9							
672	0000010101	IC50SC				6.66-	-99.9 to 999.9							
*1 A . T	the condition of eith	*1 A. The condition of either OC or OS is disculaved individually. B. The condition of the entire refringerant system is disculaved	ndividually B	. The condition	of the entire refri	oi motovo tacrop	havelnoih.							

\*1 A: The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerant system is displayed.

Setting data

ann Suma	3 4415											•	
O	SW4 1-10 [0: OFF, 1: ON] (SW6-10: OFF)	ltem				Dis	Display				Unit (A, B) <sup>* 1</sup>	t ,*1	Remarks
	1234567890		LD1	LD2	LD3	LD4	TD5	PDP	LD7	LD8	00	OS	
929	0010010101	INV board S/W version				0.00 tc	0.00 to 99.99				A	Α	
889	0000110101	Current time				00:00 t	00:00 to 23:59				4	٧	Hour: minute
689	1000110101	Current time -2				00.00 to 99	00.00 to 99.12/1 to 31						Year and month, and date alternate display
069	0100110101	Time of error detection 1				00:00 t	00:00 to 23:59					•	Hour: minute
691	1100110101	Time of error detection 1-2				00.00 to 99	00.00 to 99.12/1 to 31						Year and month, and date alternate display
692	0010110101	Time of error detection 2				00:00 t	00:00 to 23:59						Hour: minute
693	1010110101	Time of error detection 2-2				00.00 to 99	00.00 to 99.12/1 to 31						Year and month, and date alternate display
694	0110110101	Time of error detection 3				00:00 t	00:00 to 23:59						Hour: minute
695	1110110101	Time of error detection 3-2				00.00 to 99	00.00 to 99.12/1 to 31						Year and month, and date alternate display
969	0001110101	Time of error detection 4				00:00 t	00:00 to 23:59						Hour: minute
269	1001110101	Time of error detection 4-2				00.00 to 99	00.00 to 99.12/1 to 31						Year and month, and date alternate display
869	0101110101	Time of error detection 5				00:00 t	00:00 to 23:59					•	Hour: minute
669	1101110101	Time of error detection 5-2				00.00 to 99	00.00 to 99.12/1 to 31						Year and month, and date alternate display
700	0011110101	Time of error detection 6				00:00 t	00:00 to 23:59						Hour: minute
701	101111101	Time of error detection 6-2				00.00 to 99	00.00 to 99.12/1 to 31						Year and month, and date alternate display
ŀ			i (		;		-						

Setting data

			ъріау О					IIIL E			
Remarks		Hour: minute	Year and month, and date alternate display	Hour: minute	Year and month, and date alternate display	Hour: minute	Year and month, and date alternate display	Hour: minute	Year and month, and date alternate display	Hour: minute	Year and month, and date alternate display
Unit A, B) <sup>*1</sup>	SO	4				l		ı			
Unit (A, B)*1	၁၀	∢	ī	1	ī	I	ī	ı	ī	T	ī
	PD8										
	LD7										
	9G7										
olay	FD5	23:59	.12/1 to 31	23:59	.12/1 to 31	23:59	.12/1 to 31	23:59	.12/1 to 31	23:59	.12/1 to 31
Display	LD4	00:00 to 23:59	00.00 to 99.12/1 to 31	00:00 to 23:59	00.00 to 99.12/1 to 31	00:00 to 23:59	00.00 to 99.12/1 to 31	00:00 to 23:59	00.00 to 99.12/1 to 31	00:00 to 23:59	00.00 to 99.12/1 to 31
	FD3										
	LD2										
	LD1										
ltem		Time of error detection 7	Time of error detection 7-2	Time of error detection 8	Time of error detection 8-2	Time of error detection 9	Time of error detection 9-2	Time of error detection 10	Time of error detection 10-2	Time of last data backup be- fore error	Time of last data backup before error -2
SW4 1-10 [0: OFF, 1: ON] (SW6-10: OFF)	1234567890	0111110101	1111110101	0000001101	1000001101	0100001101	1100001101	0010001101	1010001101	0110001101	1110001101
o O		702	703	704	705	902	707	708	402	710	711

Data on indoor unit system

	1												
ŏ	SW4 1-10 [0: OFF, 1: ON] (SW6-10: OFF)	ltem				Display	olay				Unit (A, B) <sup>*1</sup>	##*C	Remarks
	1234567890		LD1	LD2	FD3	LD4	LD5	PDP	LD7	FD8	00	SO	
714	0101001101	IC1 LEV opening				0000 to 9999	6666		•		В		Fully open: 2000
715	1101001101	IC2 LEV opening				0000 to 9999	6666						
716	0011001101	IC3 LEV opening				0000 to 9999	6666						
717	1011001101	IC4 LEV opening				0000 to 9999	6666						
718	0111001101	IC5 LEV opening				0000 to 9999	, 9999						
719	1111001101	IC6 LEV opening				0000 to 9999	6666 (						
720	0000101101	IC7 LEV opening				0000 to 9999	6666 (						
721	1000101101	IC8 LEV opening				0000 to 9999	6666 (						
722	0100101101	IC9 LEV opening				0000 to 9999	, 9999						
723	1100101101	IC10 LEV opening				0000 to 9999	6666 (						
724	0010101101	IC11 LEV opening				0000 to 9999	6666 (						
725	1010101101	IC12 LEV opening				0000 to 9999	6666						
726	0110101101	IC13 LEV opening				0000 to 9999	6666						
727	1110101101	IC14 LEV opening				0000 to 9999	6666						
728	0001101101	IC15 LEV opening				0000 to 9999	6666						
729	1001101101	IC16 LEV opening				0000 to 9999	6666						
730	0101101101	IC17 LEV opening				0000 to 9999	6666						
731	1101101101	IC18 LEV opening				0000 to 9999	6666						
732	0011101101	IC19 LEV opening				0000 to 9999	6666						
733	1011101101	IC20 LEV opening				0000 to 9999	6666						
734	0111101101	IC21 LEV opening				0000 to 9999	6666						
735	1111101101	IC22 LEV opening				0000 to 9999	6666 (						
736	0000011101	IC23 LEV opening				0000 to 9999	6666						
737	1000011101	IC24 LEV opening				0000 to 9999	6666						
738	0100011101	IC25 LEV opening				0000 to 9999	6666 (						
739	1100011101	IC26 LEV opening				0000 to 9999	6666						
740	0010011101	IC27 LEV opening				0000 to 9999	6666 (						
*1 A: T	The condition of eitl	*1 A: The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerant system is displayed.	individually. B:	The condition o	f the entire refrig	gerant system is	displayed.						

Data on indoor unit system

	,	H											
S.	SW4 1-10 [0: OFF, 1: ON] (SW6-10: OFF)	ltem				Display	olay				Unit (A, B) <sup>*</sup> 1	it 	Remarks
	1234567890		LD1	TD5	FD3	LD4	FD5	PDP	LD7	FD8	20	SO	
741	1010011101	IC28 LEV opening				0000 to 9999	o 9999				В		Fully open: 2000
742	0110011101	IC29 LEV opening				0000 to 9999	o 9999						
743	1110011101	IC30 LEV opening				0000 to 9999	o 9999						
744	0001011101	IC31 LEV opening				0000 to 9999	9888						
745	1001011101	IC32 LEV opening				0000 to 9999	o 9999						
746	0101011101	IC33 LEV opening				0000 to 9999	o 9999						
747	1101011101	IC34 LEV opening				0000 to 9999	o 9999						
748	0011011101	IC35 LEV opening				0000 to 9999	o 9999						
749	1011011101	IC36 LEV opening				0000 to 9999	o 6666						
750	0111011101	IC37 LEV opening				0000 to 9999	o 9999						
751	1111011101	IC38 LEV opening				0000 to 9999	6666 c						
752	0000111101	IC39 LEV opening				0000 to 9999	6666 c						
753	1000111101	IC40 LEV opening				0000 to 9999	6666 c						
754	0100111101	IC41 LEV opening				0000 to 9999	6666 0						
755	1100111101	IC42 LEV opening				0000 to 9999	o 9999						
756	0010111101	IC43 LEV opening				0000 to 9999	o 6666						
757	101111101	IC44 LEV opening				0000 to 9999	o 9999						
758	0110111101	IC45 LEV opening				0000 to 9999	6666 c						
759	1110111101	IC46 LEV opening				0000 to 9999	o 6666						
260	0001111101	IC47 LEV opening				0000 to 9999	o 9999						
761	1001111101	IC48 LEV opening				0000 to 9999	o 9999						
762	0101111101	IC49 LEV opening				0000 to 9999	o 6666						
763	1101111101	IC50 LEV opening				0000 to 9999	6666 c						
*1 A: T	he condition of eitl	*1 A: The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerant system is displayed.	individually. B: T	he condition of	the entire refrig	erant system is	displayed.						

Data on indoor unit system

No.	SW4 1-10 [0: OFF, 1: ON] (SW6-10: OFF)	ltem				Display	olay				Unit (A, B) <sup>* 1</sup>	)*1	Remarks
	1234567890		LD1	LD2	FD3	LD4	FD5	9G7	LD7	PD8	၁၀	SO	
764	0011111101	0011111101 IC1 Operation mode									В		When WR2 is used, the
765	1011111101	1011111101 IC2 Operation mode											rour LDs on the left (LDT-4) display operation
992	0111111101	011111111 IC3Operation mode		: 0000	0000 : Stop 0001 : Ventilation 0002 : Cooling 0003 : Heating 0004 : Dry	Intilation 0002	: Cooling 0003	: Heating 000	4 : Dry				mode, and the four LDs
191	1111111101	111111101 IC4 Operation mode											display port address.
292	0000000011	0000000011 IC5 Operation mode											(Displayed alternately every five seconds)
*1 A·7	The condition of eith	*1 A. The condition of either OC or OS is displayed individually B. The condition of the entire refrinerant system is displayed	L. A. Vilendividua	The condition of	the entire refrict	erant eyetem is	heyelusib						

1 A: The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerant system is displayed

Data on indoor unit system

	ć												
Š.	SW4 1-10 [0: OFF, 1: ON] (SW6-10: OFF)	ltem				Disk	Display				Unit (A, B) <sup>*</sup> 1	** -	Remarks
	1234567890		LD1	LD2	FD3	LD4	FD5	PDP TDE	LD7	FD8	00	SO	
692	100000011	IC6 Operation mode									В		When WR2 is used, the
770	0100000011	IC7 Operation mode											rour LDs on the lett (LD1-4) display opera-
771	1100000011	IC8 Operation mode											tion mode, and the four
772	001000011	IC9 Operation mode											LDS on the right (LD5- LD8) display port ad-
773	1010000011	IC10 Operation mode											dress.
774	0110000011	IC11 Operation mode											(Displayed alternately every five seconds)
775	1110000011	IC12 Operation mode											
922	0001000011	IC13 Operation mode											
777	100100011	IC14 Operation mode											
778	0101000011	IC15 Operation mode											
622	110100011	IC16 Operation mode											
780	0011000011	IC17 Operation mode											
781	1011000011	IC18 Operation mode											
782	0111000011	IC19 Operation mode		. 0000	Stop 0001 · Ve	2000 noitelitue	Stan 0001 - Ventilation 0002 - Caalina 0003 - Heatina 0004 - Day	· Heating 0004	, , ,				
783	1111000011	IC20 Operation mode						600	<u>.</u>				
784	0000100011	IC21 Operation mode											
785	1000100011	IC22 Operation mode											
786	0100100011	IC23 Operation mode											
787	110010011	IC24 Operation mode											
788	0010100011	IC25 Operation mode											
789	1010100011	IC26 Operation mode											
190	0110100011	IC27 Operation mode											
791	1110100111	IC28 Operation mode											
792	0001100011	IC29 Operation mode											
793	1001100011	IC30 Operation mode											
794	0101100011	IC31 Operation mode											
262	1101100011	IC32 Operation mode											
962	0011100011	IC33 Operation mode											
*	The population of eith	*4 A. The condition of either OC is disaloued individually D. The condition of	T-Alividually B. T	The condition of	the entire refricerate extension of the	oi motovo tacro	Povolacio						

\*1 A: The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerant system is displayed.

Data on indoor unit system

No.	SW4 1-10 [0: OFF, 1: ON] (SW6-10: OFF)	ltem				Display	olay				Unit (A, B) <sup>* 1</sup>	, t	Remarks
	1234567890		LD1	LD2	FD3	LD4	FD5	PDP TD9	LD7	FD8	00	SO	
797	1011100011	IC34 Operation mode						•			В		When WR2 is used, the
798	0111100011	IC35 Operation mode											four LDs on the left (LD1-4) display opera-
799	1111100011	IC36 Operation mode											tion mode, and the four
800	0000010011	IC37 Operation mode											LDs on the right (LD5- LD8) display port ad-
801	1000010011	IC38 Operation mode											dress.
802	0100010011	IC39 Operation mode											(Displayed alternately every five seconds)
803	1100010011	IC40 Operation mode											
804	0010010011	IC41 Operation mode											
802	1010010011	IC42 Operation mode		: 0000	Stop 0001 : Ve	0000 : Stop 0001 : Ventilation 0002 : Cooling 0003 : Heating 0004 : Dry	: Cooling 0003	: Heating 0004	: Dry				
908	0110010011	IC43 Operation mode											
807	11100100111	IC44 Operation mode											
808	0001010011	IC45 Operation mode											
808	1001010011	IC46 Operation mode											
810	0101010011	IC47 Operation mode											
811	110101011	IC48 Operation mode											
812	0011010011	IC49 Operation mode											
813	101101011	IC50 Operation mode											
*1 A·T	he condition of eith	*1 A. The condition of either OC or OS is displayed individually B. The condition of the entire refrinerant system is displayed	individually B. T	he condition of	the entire refrio	erant evetem is	heyeldsib						

Data on indoor unit system

o N	SW4 1-10 [0: OFF, 1: ON] (SW6-10: OFF)	ltem				Dis	Display				Unit (A, B) 1	#*(	Remarks
	1234567890		LD1	LD2	FD3	LD4	FD5	9Q7	LD7	PD8	00	SO	
814	0111010011	IC1 filter				0000 t	0000 to 9999				В		Hours since last mainte-
815	1111010111	IC2 filter				0000 t	0000 to 9999						nance [ n ]
816	0000110011	IC3 filter				0000 t	0000 to 9999						
817	1000110011	IC4 filter				0000 t	0000 to 9999						
818	0100110011	IC5 filter				0000 t	0000 to 9999						
819	1100110011	IC6 filter				0000 t	0000 to 9999						
820	0010110011	IC7 filter				0000 t	0000 to 9999						
821	1010110011	IC8 filter				0000 t	0000 to 9999						
822	0110110011	IC9 filter				0000 t	0000 to 9999						
823	1110110011	IC10 filter				0000 t	0000 to 9999						
824	0001110011	IC11 filter				0000 t	0000 to 9999						
*1 A·T	The condition of eith	*1 A. The condition of either OC or OS is disculaved individually. B. The condition of the entire refringerent evetem is disculaved	T.B. Alendiviba	to acitibaco ed	the entire refric	ai metave tuerek	povolacjo,						

Data on indoor unit system

Jalao	zata oli ilidool dilit systelli												
O	SW4 1-10 [0: OFF, 1: ON] (SW6-10: OFF)	ltem				Display	olay				Unit (A, B) <sup>* 1</sup>	-	Remarks
	1234567890		LD1	TD2	LD3	LD4	FD5	9G7	LD7	FD8	00	SO	
825	1001110011	IC12 filter				0000 to 9999	6666 с				В		Hours since last mainte-
826	0101110011	IC13 filter				0000 to 9999	o 9999						nance [ n ]
827	1101110011	IC14 filter				0000 to 9999	o 9999						
828	0011110011	IC15 filter				0000 to 9999	o 9999						
829	1011110011	IC16 filter				0000 to 9999	o 6666 c						
830	0111110011	IC17 filter				0000 to 9999	6666 с						
831	1111110011	IC18 filter				0000 tc	0000 to 9999						
832	0000001011	IC19 filter				0000 tc	0000 to 9999						
833	100000111	IC20 filter				0000 tc	0000 to 9999						
834	0100001011	IC21 filter				0000 to 9999	o 9999						
835	110000111	IC22 filter				0000 to 9999	6666 c						
836	0010001011	IC23 filter				0000 to 9999	6666 с						
837	1010001011	IC24 filter				0000 tc	0000 to 9999						
838	0110001011	IC25 filter				0000 to 9999	6666 c						
839	111000111	IC26 filter				0000 to 9999	6666 c						
840	0001001011	IC27 filter				0000 tc	0000 to 9999						
841	1001001011	IC28 filter				0000 to 9999	6666 c						
842	0101001011	IC29 filter				0000 to 9999	6666 c						
843	1101001011	IC30 filter				0000 to 9999	6666 c						
844	0011001011	IC31 filter				0000 to 9999	6666 c						
845	1011001111	IC32 filter				0000 tc	0000 to 9999						
846	0111001001	IC33 filter				0000 to 9999	6666 c						
847	1111001011	IC34 filter				0000 to 9999	o 9999						
848	0000101011	IC35 filter				0000 to 9999	o 9999						
849	1000101011	IC36 filter				0000 to 9999	6666 c						
850	0100101011	IC37 filter				0000 tc	0000 to 9999						
851	1100101011	IC38 filter				0000 to 9999	6666 c						
852	0010101011	IC39 filter				0000 to 9999	6666 c						
1 A: T	he condition of eith	1 A: The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerant system is displayed.	ndividually. B: T	The condition of	f the entire refrig	erant system is	displayed.						

\*1 A: The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerant system is displayed.

Data on indoor unit system

Remarks		Hours since last mainte-	nance [ n ]									
ait 3)* 1	SO											
Unit (A, B) <sup>*1</sup>	၁၀	В										
	FD8											
	LD7											
	9Q7											
olay	FD5	6666	6666	6666	6666	6666	6666	6666	6666	6666	6666	6666
Display	LD4	0000 to 9999	0000 to 9999	0000 to 9999	0000 to 9999	0000 to 9999	0000 to 9999	0000 to 9999	0000 to 9999	0000 to 9999	0000 to 9999	0000 to 9999
	FD3											
	LD2											
	LD1											
ltem		IC40 filter	IC41 filter	IC42 filter	IC43 filter	IC44 filter	IC45 filter	IC46 filter	IC47 filter	IC48 filter	IC49 filter	IC50 filter
SW4 1-10 [0: OFF, 1: ON] (SW6-10: OFF)	1234567890	1010101011	0110101011	1110101011	0001101011	100110111	0101101011	110110111	0011101011	1011110111	0111101011	1111101011
O		853	854	855	856	857	828	859	860	861	862	863

Other types of data

No.	SW4 1-10 [0: OFF, 1: ON] (SW6-10: OFF)	ltem				Display	olay				Unit (A, B)*1	iit 3)*1	Remarks	1
	1234567890		LD1	LD2	FD3	LD4	FD5	9Q7	LD7	8Q7	20	SO		
871	1110011011	U-phase current effective value 1				-99.9 to	-99.9 to 999.9				∢	4	The unit is [ A ]	
872	0001011011	W-phase current effective value 1				-99.9 to 999.9	939.9				٧	Α		
873	1001011011	Power factor phase angle 1				-99.9 to 999.9	9.666 0				Α	А	The unit is [ deg ]	
088	0000111011	Control board Reset counter				0 to 254	254				Α	Α	The unit is [ time ]	
881	1000111011	INV board Reset counter				0 to 254	254				Α	Α		

\*1 A: The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerant system is displayed.

HWE1515C - 416 -

## Service Handbook

Model

PQHY-P72, P96, P120, P144, P168, P192ZLMU-A1/B PQHY-P144, P168, P192, P216, P240, P288, P312, P336, P360ZSLMU-A1/B

PQRY-P72, P96, P120, P144, P168, P192ZLMU-A1/B PQRY-P144, P168, P192, P216, P240, P288, P312, P336ZSLMU-A1/B

## MITSUBISHI ELECTRIC CORPORATION

www.MitsubishiElectric.com