

2023 R410A

Service Handbook

Model

PURY-P72, P96, P120, P144ZKMU-B PURY-P168, P192, P216, P240, P264, P288ZSKMU-B

Safety Precautions

•Please read the following safety precautions carefully before installing the unit to ensure safety.

<u>∧</u> WARNING

Indicates a risk of death or serious injury.



Indicates a risk of serious injury or structural damage.

- •Make sure that this manual is passed on to the end user to retain for future reference.
- •Retain this manual for future reference. When the unit is reinstalled or repaired, have this manual available to those who provide these services. Make sure that this manual is passed on to any future users.

All electric work must be performed by qualified personnel. Air tightness test must be performed by qualified personnel.

General Precautions

MARNING

Do not use refrigerant other than the type indicated in the manuals provided with the unit and on the nameplate. Doing so may cause the unit or pipes to burst, or result in explosion or fire during use, during repair, or at the time of disposal of the unit. It may also be in violation of applicable laws. MIT-SUBISHI ELECTRIC CORPORATION cannot be held responsible for malfunctions or accidents resulting from the use of the wrong type of refrigerant.

Do not install the unit in a place where large amounts of oil, steam, organic solvents, or corrosive gases, such as sulfuric gas, are present or where acidic/alkaline solutions or sprays containing sulfur are used frequently. These substances can compromise the performance of the unit or cause certain components of the unit to corrode, which can result in refrigerant leakage, water leakage, injury, electric shock, malfunctions, smoke, or fire.

Do not try to defeat the safety features of the unit or make unauthorized setting changes. Forcing the unit to operate the unit by defeating the safety features of the devices such as the pressure switch or the temperature switch, making unauthorized changes to the switch settings, or using accessories other than the ones recommended by Mitsubishi Electric may result in smoke, fire, or explosion.

Before installing, inspecting, or repairing the unit, check that it is safe around the unit and prevent any children from approaching. There is a risk of an injury if a tool or other object falls.

Do not modify. There is a risk of refrigerant leaking, water leaking, injury, electric shock, and fire.

When replacing a fuse, use a fuse of the specified capacity and do not use steel wire or copper wire instead. There is a risk of rupture, fire, and explosion.

To reduce the risk of shorting, current leakage, electric shock, malfunctions, smoke, or fire, do not splash water on electric parts.

To reduce the risk of electric shock, malfunctions, smoke or fire, do not operate the switches/buttons or touch other electrical parts with wet hands.

To reduce the risk of pipe burst and explosion, do not allow gas refrigerant and refrigerant oil to be trapped in the refrigerant circuit.

Before performing cleaning, maintenance, or inspection, stop operation and turn off the main power. There is a risk of an injury and electric shock. There is a risk of an injury from a fan or other rotating part.

i

To reduce the risk of burns or frost bites, do not touch the refrigerant pipes or refrigerant circuit components with bare hands during and immediately after operation.

To reduce the risk of injury from falling tools, keep children away while installing, inspecting, or repairing the unit.

Keep the space well ventilated. Refrigerant can displace air and cause oxygen starvation. If leaked refrigerant comes in contact with a heat source, toxic gas may be generated.

When there is an abnormality (burning smell, etc.), stop operation and turn off the power switch. Contact your dealer or customer support. There is a risk of electric shock, failure, and fire if operation is continued while there is an abnormality.

Attach the unit cover. There is a risk of electric shock, smoke generation, and fire if dust and water enters inside.

To reduce the risk of electric shock, smoke, and fire due to infiltration of dust and water, properly install all required terminal block covers and insulation sheets.

To reduce the risk of electric shock, smoke, and fire due to infiltration of dust and water, properly install all required covers and panels on the terminal box and control box.

To reduce the risk of injury from units falling or falling over, periodically check the installation base for damage.

Consult an authorized agency for the proper disposal of the unit. Refrigerant oil and refrigerant that may be left in the unit pose a risk of fire, explosion, or environmental pollution.

ACAUTION

Do not place combustible materials or use inflammable spray near the unit. There is a risk of ignition, fire, and explosion.

To reduce the risk of being caught in rotating parts, electric shock, and burns, do not operate the unit without all required panels and guards being installed.

To reduce the risk of injury, do not sit, stand, or place objects on the unit.

The unit described in this manual is not intended for use with food, animals, plants, precision instruments, or art work.

To reduce the risk of water leakage and malfunctions, do not turn off the power immediately after stopping operation. Leave the unit turned on for at least 5 minutes before turning off the power.

Do not install the unit over things that are vulnerable to water damage from condensation dripping.

To reduce the risk of injury, electric shock, and malfunctions, do not touch or allow cables to come in contact with the edges of components.

To reduce the risk of injury, do not touch the heat exchanger fins or sharp edges of components with bare hands.

Always wear protective gears when touching electrical components on the unit. Several minutes after the power is switched off, residual voltage may still cause electric shock.

When touching electrical parts, wear protective gear. There is a risk of a burn if you touch a high-temperature part. There is a risk of an electric shock if you touch a high-voltage part.

To reduce the risk of injury, do not insert fingers or foreign objects into air inlet/outlet grills. If the unit is left on a damaged base, it may fall and cause injury.

When performing work, wear protective gear. There is a risk of an injury.

Do not release refrigerant into the atmosphere. Collect and reuse the refrigerant, or have it properly disposed of by an authorized agency. Refrigerant poses environmental hazards if released into the air.

Transportation and Installation

↑ WARNING

Lift the unit by placing the slings at designated locations. Support the outdoor unit securely at four points to keep it from slipping and sliding. If the unit is not properly supported, it may fall and cause personal injury.

ACAUTION

To reduce the risk of injury, do not carry the product by the PP bands that are used on some packages.

To reduce the risk of injury, products weighing 20 kg or more should be carried by two or more people.

Installation

MARNING

Do not install the unit where there is a risk of leaking flammable gas.

If flammable gas accumulates around the unit, it may ignite and cause a fire or explosion.

To reduce the risk of injury from coming in contact with units, install units where they are not accessible to people other than maintenance personnel.

Do not modify. Installation work must be performed by the dealer or a qualified personnel in accordance with the instructions in the installation manual. There is a risk of water leaking, injury, electric shock, and fire.

Dispose of the packing material. There is a risk of an injury.

Destroy the packing material. There is a risk of a suffocation accident.

All drainage work should be performed by the dealer or qualified personnel according to the instructions detailed in the Installation Manual. Improper drainage work may cause water leakage and resultant damage to the furnishings.

Remove packing materials from the unit before operating the unit. Note that some accessories may be taped to the unit. Properly install all accessories that are required. Failing to remove the packing materials or failing to install required accessories may result in refrigerant leakage, oxygen deprivation, smoke, or fire. Consult your dealer and take appropriate measures to safeguard against refrigerant leakage and resultant oxygen starvation. An installation of a refrigerant gas detector is recommended.

Any additional parts must be installed by the dealer or qualified personnel. Only use the parts specified by Mitsubishi Electric. Installation by unauthorized personnel or use of unauthorized parts or accessories may result in water leakage, electric shock, or fire.

Take appropriate safety measures against wind gusts and earthquakes to prevent the unit from toppling over and causing injury.

To reduce the risk of injury from units falling or falling over, install the unit on a surface that is strong enough to support its weight.

To reduce the risk of injury from units falling or falling over, periodically check the installation base for damage.

ACAUTION

Do not install the unit over things that are vulnerable to water damage. Provide an adequate collective drainage system for the drain water from unit as necessary.

Do not install the unit over things that are vulnerable to water damage. When the indoor humidity exceeds 80% or if the drain water outlet becomes clogged, condensation may drip from the indoor unit onto the ceiling or floor.

To reduce the risk of damage to the unit and resultant electric leak and electric shock, keep small animals, snow, and rain water from entering the unit by closing the gap in the pipe and wire access holes.

To reduce the risk of rain water or drain water from entering the room and damaging the interior, drainage work must be performed by your dealer or qualified personnel according to the instructions detailed in the Installation Manual.

To reduce the risk of drain water overflow, install the unit horizontally, using a level.

Piping Work

∴WARNING

To reduce the risk of injury, including frost bites, that may result from being blasted with refrigerant, use caution when operating the refrigerant service valve. If refrigerant leaks out and comes in contact with an open flame, toxic gases may be generated.

To reduce the risk of refrigerant catching fire and causing burns, remove the refrigerant gas and the residual refrigerant oil in the pipes before heating them.

To reduce the risk of pipe damage, refrigerant leakage, and oxygen deprivation, use pipes that meet the pipe thickness specifications, which vary by the type of refrigerant used, pipe diameter, and pipe material.

To reduce the risk of pipe burst or explosion, evacuate the refrigerant circuit using a vacuum pump, and do not purge the system with refrigerant.

To reduce the risk of explosion and deterioration of refrigerant oil caused by chloride, do not use oxygen, flammable gas, or refrigerant that contains chloride as a pressurizing gas.

To prevent explosion, do not heat the unit with refrigerant gas in the refrigerant circuit.

⚠CAUTION

To reduce the risk of pipe bursting and explosion due to abnormal pressure rise, do not allow any substances other than R410A (such as air) to enter the refrigerant circuit.

To reduce the risk of refrigerant leakage and resultant oxygen deprivation, use the flare nut with holes that is supplied with the refrigerant service valve.

To reduce the risk of refrigerant leakage and resultant oxygen deprivation, use the flare nut that is supplied with the unit or its equivalent that meets applicable standards.

To reduce the risk of damage to the unit, and resultant refrigerant leakage and oxygen deprivation, tighten flare nuts to a specified torque.

To reduce the risk of oxygen deprivation and gas poisoning, check for gas leakage and keep fire sources away.

Insulate pipe connections after completing the air tightness test. Performing an air tightness test with the pipe being insulated may lead to failure to detect refrigerant leakage and cause oxygen deprivation.

To reduce the risk of pipe damage and resultant refrigerant leakage and oxygen deprivation, keep the field-installed pipes out of contact with the edges of components.

To reduce the risk of water leakage and resultant damage to the furnishings, drain piping work must be performed by your dealer or qualified personnel according to the instructions detailed in the Installation Manual.

To keep the ceiling and floor from getting wet due to condensation, properly insulate the pipes.

Wiring Work

*↑***WARNING**

To reduce the risk of wire breakage, overheating, smoke, and fire, keep undue force from being applied to the wires.

To reduce the risk of wire breakage, overheating, smoke, or fire, properly secure the cables in place and provide adequate slack in the cables so as not to stress the terminals.

Do not use a mixture of solid wires and stranded wires or wires of different sizes for the power terminal block. If used, there is a risk of smoke generation, ignition, and fire due to a bad contact.

Tighten the screws of wiring terminals to the specified torque. There is a risk of smoke generation, ignition, and fire due to screw looseness or a bad contact.

To reduce the risk of injury or electric shock, switch off the main power before performing electrical work.

All electric work must be performed by a qualified electrician according to the local regulations, standards, and the instructions detailed in the Installation Manual. Capacity shortage to the power supply circuit or improper installation may result in malfunction, electric shock, smoke, or fire.

To reduce the risk of electric shock, smoke, or fire, install an earth leakage breaker on the power supply to each unit.

⚠CAUTION

To reduce the risk of current leakage, wire breakage, smoke, or fire, keep the wiring out of contact with the refrigerant pipes and other parts, especially sharp edges.

To reduce the risk of electric shock, smoke, or fire, install an inverter circuit breaker on the power supply to each unit. (Applicable to inverter units only)

Use properly rated breakers and fuses (earth leakage breaker, local switch <switch + fuse>, no-fuse breaker). The use of a breaker with a breaking capacity greater than the specified capacity may cause electric shock, malfunctions, smoke, or fire.

Use properly rated breakers and fuses (inverter circuit breaker, local switch <switch + fuse>, no-fuse breaker). The use of a breaker with a breaking capacity greater than the specified capacity may cause electric shock, malfunctions, smoke, or fire. (Applicable to inverter units only)

To reduce the risk of current leakage, overheating, smoke, or fire, use properly rated cables with adequate current carrying capacity.

Grounding (earth) work must be performed by a qualified electrician. Do not connect the ground wire to a gas pipe, water pipe, lightning rod, or telephone ground wire. There is a risk of electric shock, incorrect operation due to noise, smoke generation, ignition, fire, and explosion.

Relocation and Repairs

↑ WARNING

To reduce the risk of refrigerant leakage, water leakage, injury, electric shock, and fire, units should only be moved or repaired by your dealer or qualified personnel.

To reduce the risk of wire shorting, electric leak, electric shock, smoke, or fire, do not perform maintenance work in the rain.

To reduce the risk of injury, electric shock, and fire, properly reinstall all removed components after completing repair work.

ACAUTION

Do not touch a board with a hand or tool or allow dust to adhere to it. There is a risk of a short-circuit, electric shock, failure, and fire. To reduce the risk of refrigerant and water leakage, check the pipe supports and insulation for damage during inspection or repair, and replace or repair the ones that are found to be deteriorated.

Additional Precautions

To avoid damage to the unit, use appropriate tools to install, inspect, or repair the unit.

Turn on the power at least 12 hours before starting operation. Do not turn off the power during a unit operation period. There is a risk of a failure.

Recover all refrigerant in the units, and dispose of it properly according to any applicable laws and regulations.

To reduce the risk of deterioration of refrigerant oil and compressor malfunctions caused by a refrigerant that contains chloride, such as R22, only use R410A.

Provide a maintenance access to allow for the inspection of pipes above the ceiling or the buried pipes.

When installing the unit in a location with an electrical noise source, take measures against noise. There is a risk of the unit failing or operating incorrectly due to the influence of equipment such as an inverter device, home power generator, high frequency medical equipment, or radio communication equipment.

When installing the unit in a location where electrical noise generated by the unit will be a problem, take measures against noise. There is a risk of interference with medical treatment. There is a risk of video broadcasts being distorted or affected by noise.

To reduce the risk of damage to the unit, leave the valves on the unit closed until refrigerant charging is completed.

Place a wet towel on the refrigerant service valve before brazing the pipes to keep its temperature from rising above 120°C and damaging the surrounding equipment.

Direct the blazing torch flame away from the adjacent cables and sheet metal to keep them from being overheated and damaged.

Prepare tools for exclusive use with R410A. Do not use the following tools if they have been used with the conventional refrigerant (R22): gauge manifold, charging hose, refrigerant leak detector, check valve, refrigerant charge spout, vacuum gauge, and refrigerant recovery equipment. R410A does not contain chloride, so leak detectors for use with older types of refrigerants will not detect an R410A leak. Infiltration of the residual refrigerant, refrigerant oil, or water on these tools may cause the refrigerant oil in the new system to deteriorate or damage the compressor.

To reduce the risk of the vacuum pump oil backflowing into the refrigerant cycle and causing the refrigerant oil to deteriorate, use a vacuum pump with a check valve.

Use dedicated R410A tools. Tools specifically for R410A are required. Contact your nearest dealer or customer support.

Keep dust, dirt, and water off charging hose and flare tool. Infiltration of dust, dirt, or water into the refrigerant circuit may cause the refrigerant oil to deteriorate or damage the compressor.

Use refrigerant piping and couplings that meet the applicable standards. For refrigerant pipes, use pipes made of phosphorus deoxidized copper. Keep the inner and outer surfaces of pipes and couplings clean and free of such contaminants as sulfur, oxides, dust, dirt, shaving particles, oil, and moisture. Failure to follow these directions may result in the deterioration of refrigerant oil or compressor damage.

Store pipes indoors and keep both ends sealed until immediately before the brazing or flare connection work. Store joints in plastic bags. There is a risk of deterioration of the refrigerant oil or a compressor failure if dust, dirt, or moisture enters the refrigerant circuit.

Apply ester oil, ether oil, or a small amount of alkyl benzene to flares and flanges. The use and accidental infiltration of mineral oil into the system may cause the refrigerant oil to deteriorate or damage the compressor.

To reduce the risk of oxidized film from entering the refrigerant pipe and causing the refrigerant oil to deteriorate or damaging the compressor, braze pipes under nitrogen purge.

Do not use the existing refrigerant piping. A large amount of chloride that is contained in the residual refrigerant and refrigerant oil in the existing piping may cause the refrigerant oil in the new unit to deteriorate or damage the compressor.

Charge refrigerant in the liquid state. If refrigerant is charged in the gas phase, the composition of the refrigerant in the cylinder will change, compromising the unit's performance.

Do not use a charging cylinder. The use of a charging cylinder will change the composition of the refrigerant, compromising the unit's performance.

Charge the system with an appropriate amount of refrigerant in the liquid phase. Refer to the relevant sections in the manuals to calculate the appropriate amount of refrigerant to be charged. Refrigerant overcharge or undercharge may result in performance drop or abnormal stop of operation.

To reduce the risk of power capacity shortage, always use a dedicated power supply circuit.

To reduce the risk of both the breaker on the product side and the upstream breaker from tripping and causing problems, split the power supply system or provide protection coordination between the earth leakage breaker and no-fuse breaker.

Have a backup system, if failure of the unit has a potential for causing significant problems or damages.

| Chapter | 1 | Check Before Servicing | |
|---------|------------|--|-------|
| | 1-1 | Preparation for Piping Work | 3 |
| | 1-2 | Handling and Characteristics of Piping Materials, Refrigerant, and Refrigerant Oil | 5 |
| | 1-3 | Working with Refrigerant Piping | |
| | 1-4 | Precautions for Wiring | |
| | 1-5 | Cautionary notes on installation environment and maintenance | |
| | 1-6 | Inspection and maintenance | 17 |
| Chapter | 2 | Restrictions | |
| | 2-1 | System Configurations | |
| | 2-2 | Types and Maximum Allowable Length of Cables | |
| | 2-3 | Switch Settings | |
| | 2-4 2-5 | M-NET Address Settings Demand Control Overview | |
| | 2-5 2-6 | System Connection Example | |
| | 2-0 2-7 | Example System with an MA Remote Controller | |
| | 2-8 | Example System with an ME Remote Controller | |
| | 2-9 | Example System with an MA and an ME Remote Controller | |
| | 2-10 | Restrictions on Refrigerant Pipes | |
| Chapter | 3 | Major Components, Their Functions and Refrigerant Circ | cuits |
| | 3-1 | External Appearance and Refrigerant Circuit Components of Outdoor Unit | |
| | 3-2 | Outdoor Unit Refrigerant Circuit Diagrams | |
| | 3-3 | Functions of the Major Components of Outdoor Unit | |
| | 3-4 | Functions of the Major Components of Indoor Unit | |
| | 3-5 | External Appearance and Refrigerant Circuit Components of BC Controller | |
| | 3-6 3-7 | BC Controller Refrigerant Circuit Diagrams Functions of the Major Components of BC Controller | |
| | 3-7 | runctions of the Major Components of BC Controller | |
| Chapter | 4 | Electrical Components and Wiring Diagrams | |
| | 4-1 | Outdoor Unit Circuit Board Arrangement | 97 |
| | 4-2 | Outdoor Unit Circuit Board Components | |
| | 4-3 | Outdoor Unit Electrical Wiring Diagrams | |
| | 4-4 | Transmission Booster Electrical Wiring Diagrams | |
| | 4-5 | BC Controller Circuit Board Arrangement | |
| | 4-6 | BC Controller Circuit Board Components | |
| | 4-7 | BC Controller Electrical Wiring Diagrams | 112 |
| Chapter | 5 | Control | |
| | 5-1 | Dipswitch Functions and Factory Settings | |
| | 5-2 | Outdoor Unit Control | 130 |
| | 5-3 | BC Controller Control | |
| | 5-4 | Operation Flowcharts | 146 |
| Chapter | 6 | Test Run | |
| | 6-1 | Read before Test Run | 155 |
| | 6-2 | Operation Characteristics and Refrigerant Charge | 156 |
| | 6-3 | Evaluating and Adjusting Refrigerant Charge | 156 |
| | 6-4 | The Following Symptoms Are Normal | 162 |
| Chapter | 7 | Troubleshooting Using Error Codes | |
| | 7-1 | Error Code and Preliminary Error Code Lists | |
| | 7-2 | Error Code Definitions and Solutions: Codes [0 - 999] | |
| | 7-3 | Error Code Definitions and Solutions: Codes [1000 - 1999] | |
| | 7-4 | Error Code Definitions and Solutions: Codes [2000 - 2999] | |
| | 7-5 7-6 | Error Code Definitions and Solutions: Codes [3000 - 3999] Error Code Definitions and Solutions: Codes [4000 - 4999] | |
| | 7-6 7-7 | Error Code Definitions and Solutions: Codes [4000 - 4999] Error Code Definitions and Solutions: Codes [5000 - 5999] | |
| | 1-1 | LITOI OOGE DEIIIILIOIIS AIIG SOIGLIOIIS. OOGES [3000 - 3333] | IJJ |

HWE23040 GB

CONTENTS

| | 7-8 7-9 | Error Code Definitions and Solutions: Codes [6000 - 6999] Error Code Definitions and Solutions: Codes [7000 - 7999] | |
|---------|------------|--|-----|
| Chapter | 8 | Troubleshooting Based on Observed Symptoms | |
| | 8-1 | MA Remote Controller Problems | 243 |
| | 8-2 | ME remote Controller Problems | 247 |
| | 8-3 | Refrigerant Control Problems | 251 |
| | 8-4 | Checking Transmission Waveform and for Electrical Noise Interference | 256 |
| | 8-5 | Pressure Sensor Circuit Configuration and Troubleshooting Pressure Sensor Problems | 259 |
| | 8-6 | Troubleshooting Solenoid Valve Problems | 261 |
| | 8-7 | Troubleshooting Outdoor Unit Fan Problems | 265 |
| | 8-8 | Troubleshooting LEV Problems | 266 |
| | 8-9 | Troubleshooting Problems with Major Components on BC Controller | 270 |
| | 8-10 | Troubleshooting Inverter Problems | 284 |
| | 8-11 | Control Circuit | 294 |
| | 8-12 | Measures for Refrigerant Leakage | 297 |
| | 8-13 | Compressor Replacement Instructions | 299 |
| | 8-14 | Solenoid Valve Block and Check Valve Replacement Instructions | 301 |
| | 8-15 | BC Controller Maintenance Instructions | 309 |
| | 8-16 | Troubleshooting Problems Using the LED Status Indicators on the Outdoor Unit | 312 |
| Chapter | 9 | LED Status Indicators on the Outdoor Unit Circuit Board | |
| | 9-1 | LED Status Indicators | 315 |
| | 9-2 | LED Status Indicators Table | 318 |

HWE23040 GB

Chapter 1 Check Before Servicing

| 1-1 | Preparation for Piping Work | 3 |
|-------|--|----|
| 1-1-1 | Read before Servicing | 3 |
| 1-1-2 | Tool Preparation | 4 |
| 1-2 | Handling and Characteristics of Piping Materials, Refrigerant, and Refrigerant Oil | 5 |
| 1-2-1 | Piping Materials | 5 |
| 1-2-2 | Storage of Piping Materials | 6 |
| 1-2-3 | Pipe Processing | 6 |
| 1-2-4 | Differences in Refrigerant Properties | 7 |
| 1-2-5 | Refrigerant Oil | 8 |
| 1-3 | Working with Refrigerant Piping | g |
| 1-3-1 | Pipe Brazing | 9 |
| 1-3-2 | Air Tightness Test | 10 |
| 1-3-3 | Vacuum Drying | 11 |
| 1-3-4 | Refrigerant Charging | 13 |
| 1-4 | Precautions for Wiring | 14 |
| 1-5 | Cautionary notes on installation environment and maintenance | 16 |
| 1-6 | Inspection and maintenance | 17 |
| 1-6-1 | Guideline for preventive maintenance | 17 |
| 1-6-2 | Recommended parts inspection interval | 18 |

1-1 Preparation for Piping Work

1-1-1 Read before Servicing

 Check the type of refrigerant used in the system to be serviced. Refrigerant Type

Multi air conditioner for building application CITY MULTI R2 ZKMU series:R410A

- 2. Check the symptoms exhibited by the unit to be serviced.
 - Refer to this service handbook for symptoms relating to the refrigerant cycle.
- 3. Thoroughly read the safety precautions at the beginning of this manual.
- 4. Preparing necessary tools: Prepare a set of tools to be used exclusively with each type of refrigerant. For information about the correct use of tools, refer to the following page(s). [1-1-2 Tool Preparation](page 4)
- 5. Verification of the connecting pipes: Verify the type of refrigerant used for the unit to be moved or replaced.
 - •Use refrigerant pipes made of phosphorus deoxidized copper. Keep the inner and outer surfaces of the pipes clean and free of such contaminants as sulfur, oxides, dust, dirt, shaving particles, oil, and water.
 - •These types of contaminants inside the refrigerant pipes may cause the refrigerant oil to deteriorate.
- 6. If there is a leak of gaseous refrigerant and the remaining refrigerant is exposed to an open flame, a poisonous gas hydrofluoric acid may form. Keep workplace well ventilated.



CAUTION

- Install new pipes immediately after removing old ones to keep moisture out of the refrigerant circuit.
- •The use of refrigerant that contains chloride, such as R22, will cause the refrigerating machine oil to deteriorate.
- 7. Specifications and system requirements may differ for products manufactured at different times. Refer to the relevant chapters for specification details. Production periods can be found from the serial number as follows.



1-1-2 Tool Preparation

Prepare the following tools and materials necessary for installing and servicing the unit.

Tools for use with R410A (Adaptability of tools that are for use with R22 or R407C)

1. To be used exclusively with R410A (not to be used if used with R22 or R407C)

| Tools/Materials | Use | Notes |
|---|---------------------------------------|---|
| Gauge Manifold | Evacuation and refrigerant charging | Higher than 5.09MPa[738psi] on the high-pressure side |
| Charging Hose | Evacuation and refrigerant charging | The hose diameter is larger than the conventional model. |
| Refrigerant Recovery Cylinder | Refrigerant recovery | |
| Refrigerant Cylinder | Refrigerant charging | The refrigerant type is indicated. The cylinder is pink. |
| Charging Port on the Refrigerant Cylinder | Refrigerant charging | The charge port diameter is larger than that of the current port. |
| Flare Nut | Connection of the unit with the pipes | Use Type-2 Flare nuts. |

2. Tools and materials that may be used with R410A with some restrictions

| Tools/Materials | Use | Notes |
|--------------------------------|----------------------|---|
| Gas Leak Detector | Gas leak detection | The ones for use with HFC refrigerant may be used. |
| Vacuum Pump | Vacuum drying | May be used if a check valve adapter is attached. |
| Flare Tool | Flare processing | Flare processing dimensions for the piping in the system using the new refrigerant differ from those of R22. Refer to the following page(s). [1-2-1 Piping Materials](page 5) |
| Refrigerant Recovery Equipment | Refrigerant recovery | May be used if compatible with R410A. |

3. Tools and materials that are used with R22 or R407C that may also be used with R410A

| Tools/Materials | Use | Notes |
|--------------------------------|-----------------------|--|
| Vacuum Pump with a Check Valve | Vacuum drying | |
| Bender | Bending pipes | |
| Torque Wrench | Tightening flare nuts | Only the flare processing dimensions for pipes that have a diameter of ø12.7 (1/2") and ø15.88 (5/8") have been changed. |
| Pipe Cutter | Cutting pipes | |
| Welder and Nitrogen Cylinder | Welding pipes | |
| Refrigerant Charging Meter | Refrigerant charging | |
| Vacuum Gauge | Vacuum level check | |

4. Tools and materials that must not be used with R410A

| Tools/Materials | Use | Notes |
|-------------------------------------|----------------------------------|-------------------|
| Charging Cylinder | Refrigerant charging | Prohibited to use |
| Tools containing abrasive materials | Pipe cutting, cut edge treatment | Prohibited to use |

1-2 Handling and Characteristics of Piping Materials, Refrigerant, and Refrigerant Oil

1-2-1 Piping Materials

Do not use the existing piping!

1. Copper pipe materials

| Annealed | Soft copper pipes (annealed copper pipes). They can easily be bent with hands. |
|----------|---|
| Drawn | Hard copper pipes (straight pipes). They are stronger than the Annealed at the same radial thickness. |

- •The distinction between Annealed and Drawn is made based on the strength of the pipes themselves.
- ·Annealed can easily be bent with hands.
- •Drawn are considerably stronger than Annealed at the same thickness.

2. Types of copper pipes

| Maximum working pressure | Refrigerant type |
|--------------------------|------------------|
| 3.45 MPa [500psi] | R22, R407C etc. |
| 4.30 MPa [624psi] | R410A etc. |

3. Piping materials/Radial thickness

Select piping materials that meet the requirements set forth in ASTM B280.

4. Thickness and refrigerant type indicated on the piping materials

Ask the pipe manufacturer for the symbols indicated on the piping material for refrigerant R410A.

5. Flare processing

Select piping materials that meet the requirements set forth in ASTM.

6. Flare nut

Select piping materials that meet the requirements set forth in ASTM.

1-2-2 Storage of Piping Materials


1. Storage location






Store the pipes to be used indoors. (Warehouse at site or owner's warehouse) If they are left outdoors, dust, dirt, or moisture may infiltrate and contaminate the pipe.

2. Sealing the pipe ends





Both ends of the pipes should be sealed until just before brazing. Keep elbow pipes and T-joints in plastic bags.

The new refrigerator oil is 10 times as hygroscopic as the conventional refrigerating machine oil (such as Suniso) and, if not handled with care, could easily introduce moisture into the system. Keep moisture out of the pipes, for it will cause the oil to deteriorate and cause a compressor failure.

1-2-3 Pipe Processing

Use a small amount of ester oil, ether oil, or alkylbenzene to coat flares and flanges.

Prevent the particles that are generated during pipe cutting or cut edge treatment from entering the pipes. If abrasive materials contained in sandpaper or cutting tools, hard foreign matter in concrete, gravel, etc. enter the refrigerant circuit, they may cause the compressor, valves, or other refrigerant circuit components to fail.

Note

- ◆Use a minimum amount of oil.
- •Use only ester oil, ether oil, and alkylbenzene.
- •To deburr pipes, use a reamer or other deburring tools, not sandpaper.
- •To cut pipes, use a pipe cutter, not a grinder or other tools that use abrasive materials.
- •When cutting or deburring pipes, do not allow cutting chips or other foreign matters to enter the pipes.
- •If cutting chips or other foreign matters enter pipes, wipe them off the inside of the pipes.

1-2-4 Differences in Refrigerant Properties

1. Chemical property

As with R22, R410A is low in toxicity and chemically stable nonflammable refrigerant.

However, because the specific gravity of vapor refrigerant is greater than that of air, leaked refrigerant in a closed room will accumulate at the bottom of the room and may cause hypoxia.

If exposed to an open flame, refrigerant will generate poisonous gases. Do not perform installation or service work in a confined area.

| | HFC Re | frigerant | HCFC Refrigerant |
|---|--|--|---|
| | R410A | R407C | R22 |
| | R32/R125 | R32/R125/R134a | R22 |
| Composition (wt%) | (50/50) | (23/25/52) | (100) |
| Type of Refrigerant | Pseudo-azeotropic Refrigerant | Non-azeotropic Refrigerant | Single Refrigerant |
| Chloride | Not included | Not included | Included |
| Safety Class | A1/A1 | A1/A1 | A1 |
| Molecular Weight | 72.6 | 86.2 | 86.5 |
| Boiling Point (°C/°F) | -51.4/-60.5 | -43.6/-46.4 | -40.8/-41.4 |
| Steam Pressure (25°C,MPa/77°F,psi) (gauge) | 1.557/226 | 0.9177/133 | 0.94/136 |
| Saturated Steam Density (25°C,kg/m³/77°F,psi) | 64.0 | 42.5 | 44.4 |
| Flammability | Nonflammable | Nonflammable | Nonflammable |
| Ozone Depletion Coefficient (ODP)*1 | 0 | 0 | 0.055 |
| Global Warming Coefficient (GWP)*2 | 2088 | 1774 | 1810 |
| Refrigerant Charging Method | Refrigerant charging in the liquid state | Refrigerant charging in the liquid state | Refrigerant charging in the gaseous state |
| Replenishment of Refrigerant after a Refrigerant Leak | Available | Available | Available |

^{*1} When CFC11 is used as a reference

2. Refrigerant composition

R410A is a pseudo-azeotropic HFC blend and can almost be handled the same way as a single refrigerant, such as R22. To be safe, however, draw out the refrigerant from the cylinder in the liquid phase. If the refrigerant in the gaseous phase is drawn out, the composition of the remaining refrigerant will change and become unsuitable for use.

If the refrigerant leaks out, it may be replenished. The entire refrigerant does not need to be replaced.

3. Pressure characteristics

The pressure in the system using R410A is 1.6 times as great as that in the system using R22.

| | | Pressure (gauge) | |
|---------------------|----------|------------------|----------|
| Temperature (°C/°F) | R410A | R407C | R22 |
| | MPa/psi | MPa/psi | MPa/psi |
| -20/-4 | 0.30/44 | 0.18/26 | 0.14/20 |
| 0/32 | 0.70/102 | 0.47/68 | 0.40/58 |
| 20/68 | 1.34/194 | 0.94/136 | 0.81/117 |
| 40/104 | 2.31/335 | 1.44/209 | 1.44/209 |
| 60/140 | 3.73/541 | 2.44/354 | 2.33/338 |
| 65/149 | 4.17/605 | 2.75/399 | 2.60/377 |

^{*2} When CO₂ is used as a reference

1-2-5 Refrigerant Oil

1. Refrigerating machine oil in the HFC refrigerant system

HFC type refrigerants use a refrigerating machine oil different from that used in the R22 system. Note that the ester oil used in the system has properties that are different from commercially available ester oil.

| Refrigerant | Refrigerating machine oil |
|-------------|---------------------------|
| R22 | Mineral oil |
| R407C | Ester oil |
| R410A | Ester oil |

2. Effects of contaminants*1

Refrigerating machine oil used in the HFC system must be handled with special care to keep contaminants out. The table below shows the effect of contaminants in the refrigerating machine oil on the refrigeration cycle.

3. The effects of contaminants in the refrigerating machine oil on the refrigeration cycle.

| Cause | | Symptoms | | Effects on the refrigerant cycle | |
|---|------------------|--|---|--|--|
| Water infiltration | | | Frozen expansion valve and capillary tubes | Clogged expansion valve and capillary tubes Poor cooling performance Compressor overheat Motor insulation failure Burnt motor Coppering of the orbiting scroll Lock Burn-in on the orbiting scroll | |
| | | Hydrolysis | Sludge formation and adhesion Acid generation Oxidization Oil degradation | | |
| Air infiltration | | Oxidization | - On adgradation | | |
| Dust, dirt Infiltration of contaminants | | Adhesion to expansion valve and capillary tubes | | Clogged expansion valve, capillary tubes, and drier Poor cooling performance Compressor overheat | |
| | | Infiltration of contaminants into the compressor | | Burn-in on the orbiting scroll | |
| | Mineral oil etc. | Sludge formati | on and adhesion | Clogged expansion valve and capillary tubes Poor cooling performance Compressor overheat | |
| | | Oil degradation | | Burn-in on the orbiting scroll | |

^{*1.} Contaminants is defined as moisture, air, processing oil, dust/dirt, wrong types of refrigerant, and refrigerating machine oil.


1-3 Working with Refrigerant Piping

1-3-1 Pipe Brazing


No changes have been made in the brazing procedures. Perform brazing with special care to keep foreign objects (such as oxide scale, water, and dust) out of the refrigerant system.

Example: Inside the brazed connection

Use of no inert gas during brazing



Use of inert gas during brazing



1. Items to be strictly observed

- •Do not conduct refrigerant piping work outdoors if raining.
- •Use inert gas during brazing.
- •Use a brazing material (BCuP-3) that requires no flux when brazing between copper pipes or between a copper pipe and copper coupling.
- •If installed refrigerant pipes are not immediately connected to the equipment, then braze and seal both ends.

2. Reasons


- •The new refrigerating machine oil is 10 times as hygroscopic as the conventional oil and is more likely to cause unit failure if water infiltrates into the system.
- •Flux generally contains chloride. Residual flux in the refrigerant circuit will cause sludge to form.

3. Notes

Do not use commercially available antioxidants because they may cause the pipes to corrode or refrigerating machine oil to deteriorate.

1-3-2 Air Tightness Test

No changes have been made in the detection method. Note that a refrigerant leak detector for R22 will not detect an R410A leak.



1. Items to be strictly observed

- •Pressurize the equipment with nitrogen up to the design pressure (4.15MPa[601psi]), and then judge the equipment's air tightness, taking temperature variations into account.
- •Refrigerant R410A must be charged in its liquid state (vs. gaseous state).

2. Reasons

- Oxygen, if used for an air tightness test, poses a risk of explosion. (Only use nitrogen to check air tightness.)
- •Refrigerant R410A must be charged in its liquid state. If gaseous refrigerant in the cylinder is drawn out first, the composition of the remaining refrigerant in the cylinder will change and become unsuitable for use.

3. Notes

Procure a leak detector that is specifically designed to detect an HFC leak. A leak detector for R22 will not detect an HFC(R410A) leak.

1-3-3 Vacuum Drying







(Photo2) 14010

Recommended vacuum gauge: ROBINAIR 14010 Thermistor Vacuum Gauge

1. Vacuum pump with a reverse-flow check valve (Photo1)

To prevent the vacuum pump oil from flowing into the refrigerant circuit during power OFF or power failure, use a vacuum pump with a reverse-flow check valve.

A reverse-flow check valve may also be added to the vacuum pump currently in use.

2. Standard of vacuum degree (Photo 2)

Use a vacuum pump that attains 0.5Torr(65Pa) or lower degree of vacuum after 5 minutes of operation, and connect it directly to the vacuum gauge. Use a pump well-maintained with an appropriate lubricant. A poorly maintained vacuum pump may not be able to attain the desired degree of vacuum.

3. Required precision of vacuum gauge

Use a vacuum gauge that registers a vacuum degree of 5Torr(650Pa) and measures at intervals of 1Torr(130Pa). (A recommended vacuum gauge is shown in Photo2.)

Do not use a commonly used gauge manifold because it cannot register a vacuum degree of 5Torr(650Pa).

4. Evacuation time

•After the degree of vacuum has reached 5Torr(650Pa), evacuate for an additional 1 hour. (A thorough vacuum drying removes moisture in the pipes.) When the outside temperature drops below 1°C (or when the saturation pressure drops below 656 Pa), continue vacuum drying for another 1 hour after the vacuum degree has reached the saturated vapor pressure of the water (ice) at the outside temperature. When performing vacuum drying at a low outside temperature, use a vacuum gauge appropriate for the temperature range.

Degree of vacuum (reference)

| Outdoor temp. | -20°C (-4°F) | -15°C (5°F) | -10°C (14°F) | -5°C (23°F) | 0°C (32°F) |
|------------------|--------------------|--------------------|--------------------|--------------------|--------------------|
| Degree of vacuum | 0.77 Torr (103 Pa) | 1.24 Torr (165 Pa) | 1.95 Torr (260 Pa) | 3.01 Torr (402 Pa) | 4.58 Torr (611 Pa) |

^{*} Degrees of vacuum shown above are obtained based on the saturated vapor pressure of ice.

- •Verify that the vacuum degree has not risen by more than 1Torr(130Pa) 1hour after evacuation. A rise by less than 1Torr(130Pa) is acceptable.
- •If the vacuum is lost by more than 1Torr(130Pa), conduct evacuation, following the instructions in section 6. Special vacuum drying.

5. Procedures for stopping vacuum pump

To prevent the reverse flow of vacuum pump oil, open the relief valve on the vacuum pump side, or draw in air by loosening the charge hose, and then stop the operation.

The same procedures should be followed when stopping a vacuum pump with a reverse-flow check valve.

^{*} In a system using water heat exchangers, circulate water to prevent the water in the heat exchangers from freezing during vacuum drying.

6. Special vacuum drying

- •When 5Torr(650Pa) or lower degree of vacuum cannot be attained after 3 hours of evacuation, it is likely that water has penetrated the system or that there is a leak.
- •If water infiltrates the system, break the vacuum with nitrogen. Pressurize the system with nitrogen gas to 0.5kgf/cm²G(0.05MPa) and evacuate again. Repeat this cycle of pressurizing and evacuation either until the degree of vacuum below 5Torr(650Pa) is attained or until the pressure stops rising.
- •Only use nitrogen gas for vacuum breaking. (The use of oxygen may result in an explosion.)

7. Triple Evacuation

The method below can also be used to evacuate the system.

- •Evacuate the system to 4,000 microns from both service valves. System manifold gauges must not be used to measure vacuum. A micron gauge must be used at all times. Break the vacuum with Nitrogen (N2) into the discharge service valve to 0 PSIG.
- •Evacuate the system to 1,500 microns from the suction service valve. Break the vacuum with Nitrogen (N2) into the discharge service valve to 0 PSIG.
- •Evacuate the system to 500 microns. System must hold the vacuum at 500 microns for a minimum of 1 hour.
- Conduct a rise test for a minimum of 30 minutes

8. Notes

*To evacuate air from the entire system

Applying a vacuum through the check joints at the refrigerant service valve on the high and low pressure sides (BV1 and 2) is not enough to attain the desired vacuum pressure.

Be sure to apply a vacuum through the check joints at the refrigerant service valve on the high and low pressure sides (BV1 and 2) and also through the check joints on the high and low pressure sides (CJ1 and 2).

•To evacuate air only from the outdoor units


Apply a vacuum through the check joints on the high and low pressure sides (CJ1, and 2).

•To evacuate air from the indoor units and extension pipes

Apply a vacuum through the check joints at the refrigerant service valve on the high and low pressure sides (BV1 and 2).


1-3-4 Refrigerant Charging

Cylinder with a siphon




Cylinder color R410A is pink.

Cylinder without a siphon



Refrigerant charging in the liquid state





1. Reasons

R410A is a pseudo-azeotropic HFC blend (boiling point R32=-52°C[-62°F], R125=-49°C[-52°F]) and can almost be handled the same way as a single refrigerant, such as R22. To be safe, however, draw out the refrigerant from the cylinder in the liquid phase. If the refrigerant in the gaseous phase is drawn out, the composition of the remaining refrigerant will change and become unsuitable for use.

2. Notes

When using a cylinder with a siphon, refrigerant is charged in the liquid state without the need for turning it upside down. Check the type of the cylinder on the label before use.

If the refrigerant leaks out, it may be replenished. The entire refrigerant does not need to be replaced. (Charge refrigerant in the liquid state.)

Refer to the following page(s).[8-12 Measures for Refrigerant Leakage](page 297)

1-4 Precautions for Wiring

- •Control boxes house high-voltage and high-temperature electrical parts.
- •They may still remain energized or hot after the power is turned off.
- •Before inspecting the inside of the control box, turn off the power, keep the unit off for at least 10 minutes, and confirm that the voltage between FT-P and FT-N on INV Board has dropped to DC20V or less.

(It will take approximately 10 minutes until the voltage is discharged after power off.)

•Before beginning service work, disconnect the fan board connector (CNINV) or the connectors (CN01 and CN11) on the INV board. To plug or unplug connectors, check that the outdoor unit fan is not rotating and that the voltage of capacitor in the main circuit is 20 VDC or below. The capacitor may collect a charge and cause an electric shock when the outdoor unit fan rotates in windy conditions. Refer to the wiring nameplate for details.

If the outdoor unit fan is rotated by external forces such as strong winds, the main circuit capacitor can be charged and cause an electric shock.

Refer to the wiring nameplate for details.

When the service work is finished, reconnect the connector (CNINV) on the fan board and the connectors (CN01 and CN11) on the INV board.

- •When the power is on, the heater is energized even while the compressor is stopped.
- The liquid refrigerant in the compressor will evaporate by energizing the heater.
- •Before connecting wiring to TB7, check that the voltage has dropped below 20 VDC.
- •When a system controller is connected to the centralized control transmission cable to which power is supplied from the outdoor unit (power jumper on the outdoor unit is connected to CN40), be aware that power can be supplied to the centralized control transmission and the system controller may detect an error and send an error notice if the outdoor unit fan is rotated by external forces, such as strong winds, even when power to the outdoor unit is turned off.
- •When replacing the internal electrical components of the control box, tighten the screws to the recommended tightening torque as specified below.

Recommended tightening torque for the internal electrical components of the control box

| Screw | Recommended tightening torque (N·m) |
|-------|-------------------------------------|
| M3 | 0.69 |
| M4 | 1.47 |
| M5 | 2.55 |
| M6 | 2.75 |
| M8 | 6.20 |

- *1 When replacing INV board or fan board, apply heatsink silicone evenly to the mounting surface of the semiconductor module on the back of the circuit board. Next, tighten the screws holding the semiconductor module to one-third of the specified torque, and then tighten the screws to the specified torque.
- *2 Deviating from the recommended tightening torque may cause damage to the unit or its parts.

Take the following steps to ensure that the screws are properly tightened.

1) Ensure that the spring washers are parallel to the terminal block.

Even if the tightening torque is observed, if the washers are not parallel to the terminal block, then the semiconductor module is not installed properly.




- 2) Check the wires are securely fastened to the screw terminals.
 - •Screw the screws straight down so as not to damage the screw threads.

Hold the two round terminals back to back to ensure that the screw will screw down straight.

•After tightening the screw, mark a line through the screw head, washer, and terminals with a permanent marker.

Example



Poor contact caused by loose screws may result in overheating and fire. Continued use of the damaged circuit board may cause overheating and fire.

1-5 Cautionary notes on installation environment and maintenance

Salt-resistant unit is resistant to salt corrosion, but not salt-proof. Please note the following when installing and maintaining outdoor units in marine atmosphere.

- 1) Install the salt-resistant unit out of direct exposure to sea breeze, and minimize the exposure to salt water mist.
- 2) Avoid installing a sun shade over the outdoor unit, so that rain will wash away salt deposits off the unit.
- Install the unit horizontally to ensure proper water drainage from the base of the unit. Accumulation of water in the base of the outdoor unit will significantly accelerate corrosion.
- 4) Periodically wash salt deposits off the unit, especially when the unit is installed in a coastal area.
- 5) Repair all noticeable scratches after installation and during maintenance.
- 6) Periodically check the unit, and apply anti-rust agent and replace corroded parts as necessary.

1-6 Inspection and maintenance

1-6-1 Guideline for preventive maintenance

The following maintenance intervals indicate the estimated intervals of parts replacement and repair to be required as a result of periodic inspections. They do not necessarily mean that replacement is required at the maintenance intervals.

The maintenance intervals do not indicate the warranty period.

| Unit | Parts | Inspection interval | Maintenance interval | Daily inspection | Maintenance inspection | Remarks |
|------|----------------------------|---------------------|-------------------------|------------------|------------------------|---------|
| | Compressor | | | | 0 | |
| | Fan motor | Ī | 0 | | 0 | |
| 0.11 | Electronic expansion valve | † | 20,000 hours | | 0 | |
| unit | Outdoor valve | 1 year | | | 0 | |
| | Heat exchanger | | 5 years | | 0 | |
| | Sensor | 1 | 20,000 hours | | 0 | |
| | Electric board | 1 | 25,000 hours | | 0 | |

1-6-2 Recommended parts inspection interval

| Unit | Parts | Inspection interval | Inspection items | Criteria | Measures |
|---------------------------------|---|---------------------|---|--|---|
| | Compressor | | *Auditory check of operating sounds *Measurement of insulation resistance *Visual check for loose terminals | No abnormal sounds Insulation resistance must be 1 MΩ or above. No loose terminals | Replace the compressor if an insulation problem is found when the refrigerant is not stagnating. Retighten loose terminals. |
| | Fan motor (for air-cooled outdoor unit) | | Auditory check of operating sounds Measurement of insulation resistance | No abnormal sounds Insulation resistance must be 1 MΩ or above. | Replace the fan motor if an insulation problem is found. |
| | Electronic expansion valve | | Operation check using operation data | Temperature must change in proportion to the valve position. (Check the temperature variation with the centralized controller.) | Replace the valve if the operation data show an operation failure due to valve problems. |
| Outdoor unit (air-cooled) | Valve | 1 year | Operation check using operation data | Temperature must change according to the valve position.(Check the temperature variation when the operation mode is switched between cooling and heating.) | Replace the valve if the operation data show an operation failure due to valve problems. |
| | Heat exchanger | | Check for clogging, contamination, and damage | Clogging, contamination, and damage | Perform cleaning. |
| | Sensor | | *Check for breakage and deterioration of the cables, and for disconnection of the connectors. *Measurement of insulation resistance | No breakage or deterioration of the cables or disconnected connectors. | Replace the sensor if the cable is broken, short-circuited, or se- verely deteriorated, or an insulation problem is found. |
| | Electric board | | •Check the appearance | •No sedimentary remains | Clean with a brush if deposits are attached |
| | Smoothing capacitor *1 | | Check the appearance of electrolytic capacitors | No liquid leakage, de- formation, or sleeve (outer film) shrinkage | Replace the electrolytic capacitor if there is leakage, deformation, or shrinkage of the sleeve (outer film). |

[•]The inspection intervals depend on the usage and environment.

The inspection intervals do not indicate the warranty period.

- •The maintenance and inspection items may differ depending on maintenance providers. Please check with your maintenance provider when concluding a maintenance contract.
- •Repairs outside the warranty period will be charged, even if periodic inspections have been performed at the recommended intervals.
- *1 If the performance of the electrolytic capacitor deteriorates due to long-term use, the internal temperature of the capacitor may rise and the safety valve may operate.

The operation of the safety valve may cause the electrolyte inside to leak and make other electrical components unusable. (The operation of the safety valve may cause the electrolyte to spurt out as liquid or gas.)

As a preventive maintenance, if the integrated operation time of the compressor exceeds 25,000 hours, or if 10 years have passed since the start of use, it is recommended to replace the electrolytic capacitor (or, depending on the model, the board with the capacitor mounted).

Even if the integrated operation time is less than 25,000 hours, the electrolytic capacitor may deteriorate quickly due to environmental influences (power supply imbalance, temperature, or humidity), resulting in shrinkage of the exterior film, exposure of the aluminum case, and liquid leakage. If any of the conditions shown in Photos 2 and 4 are found, please replace the capacitor promptly.

- * For the location of the smoothing capacitor, refer to the following page(s). [4 Electrical Components and Wiring Diagrams](page 97)
- * The integrated operation time of compressor can be monitored on service LED on the control board. For details on how to read the LED, refer to the following page(s). [9 LED Status Indicators on the Outdoor Unit Circuit Board](page 315)




Photo 3. Normal

Photo 4. Deteriorated

Chapter 2 Restrictions

| 2-1 | System Configurations | 23 |
|--------|--|----|
| 2-2 | Types and Maximum Allowable Length of Cables | 24 |
| 2-3 | Switch Settings | 26 |
| 2-4 | M-NET Address Settings | 27 |
| 2-4-1 | Address Settings List | 27 |
| 2-4-2 | Outdoor Unit Power Jumper Connector Connection | 29 |
| 2-4-3 | Outdoor Unit Centralized Controller Switch Setting | 29 |
| 2-4-4 | Room Temperature Detection Position Selection | 29 |
| 2-4-5 | Start/Stop Control of Indoor Units | 30 |
| 2-4-6 | Miscellaneous Settings | 30 |
| 2-4-7 | Various Control Methods Using the Signal Input/Output Connector on Outdoor Unit | 31 |
| 2-5 | Demand Control Overview | 33 |
| 2-6 | System Connection Example | 35 |
| 2-7 | Example System with an MA Remote Controller | 36 |
| 2-7-1 | Single Refrigerant System (Automatic Indoor/Outdoor Address Startup) | 36 |
| 2-7-2 | Single Refrigerant System with Two or More LOSSNAY Units | 38 |
| 2-7-3 | Grouped Operation of Units in Separate Refrigerant Circuits | 40 |
| 2-7-4 | System with a Connection of System Controller to Centralized Control Transmission Line | 42 |
| 2-7-5 | System with a Connection of System Controller to Indoor-Outdoor Transmission Line | 44 |
| 2-7-6 | System with Multiple BC Controllers | 46 |
| 2-8 | Example System with an ME Remote Controller | 49 |
| 2-8-1 | System with a Connection of System Controller to Centralized Control Transmission Line | 49 |
| 2-9 | Example System with an MA and an ME Remote Controller | 51 |
| 2-9-1 | System with a Connection of System Controller to Centralized Control Transmission Line | 51 |
| 2-10 | Restrictions on Refrigerant Pipes | 54 |
| 2-10-1 | Restrictions on Refrigerant Pipe Length and Pipe Size | |
| 2-10-2 | BC Controller Connection Method | 61 |
| 2-10-3 | Outdoor Twinning Kit | 68 |

2-1 System Configurations

1. Table of compatible indoor units

The table below summarizes the types of indoor units that are compatible with different types of outdoor units.

| Outdoor units | Composing units | | Maximum total ca- pacity of connect- able indoor units | Maximum num- ber of connectable indoor units | Types of connectable indoor units |
|---------------|-----------------|---------|--|--|-----------------------------------|
| 72ZKMU | - | - | 36 - 108 | 18 | P04 - P96 models |
| 96ZKMU | - | - | 48 - 144 | 24 | R410A series indoor units |
| 120ZKMU | - | - | 60 - 180 | 30 | |
| 144ZKMU | - | - | 72 - 216 | 36 | |
| 168ZSKMU | 96ZKMU | 72ZKMU | 84 - 252 | 42 | |
| 192ZSKMU | 96ZKMU | 96ZKMU | 96 - 288 | 48 | |
| 216ZSKMU | 120ZKMU | 96ZKMU | 108 - 324 | 50 | |
| 240ZSKMU | 120ZKMU | 120ZKMU | 120 - 360 | 50 | |
| 264ZSKMU | 144ZKMU | 120ZKMU | 132 - 396 | 50 | |
| 288ZSKMU | 144ZKMU | 144ZKMU | 144 - 432 | 50 | |

Note

- 1) "Maximum total capacity of connectable indoor units" refers to the sum of the numeric values in the indoor unit model names.
- 2) If the total capacity of the indoor units that are connected to a given outdoor unit exceeds the capacity of the outdoor unit, the indoor units will not be able to perform at the rated capacity when they are operated simultaneously. Select a combination of units so that the total capacity of the connected indoor units is at or below the capacity of the outdoor unit whenever possible.
- 3) PURY-P-ZKMU-A and PURY-P-ZKMU-B outdoor units cannot be used in combination.


2-2 Types and Maximum Allowable Length of Cables


1. Wiring work

(1) Notes

- 1) Have all electrical work performed by an authorized electrician according to the local regulations and instructions in this manual.
- 2) Install external transmission cables at least 5cm [1-31/32"] away from the power supply cable to avoid noise interference. (Do not put the control cable and power supply cable in the same conduit tube.)
- 3) Provide grounding for the outdoor unit as required.
- 4) Run the cable from the electric box of the indoor or outdoor unit in such way that the box is accessible for servicing.
- Do not connect power supply wiring to the terminal block for transmission line. Doing so will damage the electronic components on the terminal block.
- 6) Use 2-core shielded cables as transmission cables.

Use a separate 2-core control cable for each refrigerant system. Do not use a single multiple-core cable to connect indoor units that belong to different refrigerant systems. The use of a multiple-core cable may result in signal transmission errors and malfunctions.





TB3: Terminal block for indoor-outdoor transmission line TB7: Terminal block for centralized control

- 7) When extending the transmission cable, be sure to extend the shield wire.
- 8) Before inspecting the inside of the control box, turn off the power, keep the unit off for at least 10 minutes, and confirm that the voltage between FT-P and FT-N on INV Board has dropped to DC20V or less. (It takes about 10 minutes to discharge electricity after the power supply is turned off.)
- 9) The control box (inside and rear) contains high-temperature parts. Be careful even after shutting down the power.
- Before beginning service work, disconnect the fan board connector (CNINV) or the connectors (CN01 and CN11) on the INV board.

Before disconnecting and connecting a connector, check that the outdoor fan is not rotating and that the voltage of the main circuit capacitor has decreased to 20 V DC or less. If the outdoor fan rotates due to a strong wind, there is a risk of an electric shock because the main circuit capacitor will be charged. Refer to the wiring nameplate for details.

When the service work is finished, reconnect the connector (CNINV) on the fan board and the connectors (CN01 and CN11) on the INV board.

- 11) When connecting wires to TB7, check that the voltage is 20 V DC or less.
- 12) When the power is on, the heater is energized even when the compressor is stopped. Before turning on the power, disconnect the power wires from the terminal block of the compressor and measure the insulation resistance of the compressor. Check that the compressor does not have a ground fault. If the insulation resistance is 1 MΩ or less, connect the power wires of the compressor and turn on the power of the outdoor unit. (The liquid refrigerant in the compressor will evaporate by energizing the heater.)
- 13) When connecting a system controller to the TB7 side of the outdoor unit, we recommend connecting a power supply unit for transmission to the TB7 side.
 - If a system controller is connected to the TB3 side, up to three units can be connected.
 - A system controller can be connected to the TB7 side if the power supply switch connector is disconnected from CN41 and then connected to CN40, but power will be supplied to the TB7 side even when the power of the outdoor unit is off so the system controller may log an error and generate a warning.
- 14) When tightening the screws, take care that the screws are not loose or overtightened. A contact fault resulting from screw looseness may cause the generation of heat and fire. Refer to the following page(s). [1-4 Precautions for Wiring](page 14)

(2) Control wiring

Different types of control wiring are used for different systems. Before performing wiring work, refer to the following page(s). [2-7 Example System with an MA Remote Controller](page 36)

[2-8 Example System with an ME Remote Controller](page 49)

[2-9 Example System with an MA and an ME Remote Controller](page 51)

Types and maximum allowable length of cables

Control lines are categorized into 2 types: transmission line and remote controller line.

Use the appropriate type of cables and observe the maximum allowable length specified for a given system. If a given system has a long transmission line or if a noise source is located near the unit, place the unit away from the noise source to reduce noise interference.

1) M-NET transmission line

| Туре | 2-core shielded cable CVVS, CPEVS, or MVVS |
|---------|--|
| Size | 1.25 mm ² [AWG 16], or ø1.2 mm or above |
| Length | Max. 200 m [656 ft] |
| Remarks | The maximum allowable length of transmission cables via outdoor units (both centralized control transmission cables and indoor-outdoor transmission cables) is 500 m [1640 ft]*1. The maximum allowable length of transmission cables from the power supply unit to each outdoor unit or to the system controller is 200 m [656 ft]. |

^{*} Do not use a single multiple-core cable to connect indoor units that belong to different refrigerant systems. The use of a multiple-core cable may result in signal transmission errors and malfunctions.

2) Remote controller wiring

| | MA remote controller | ME remote controller | |
|--------|--|---|--|
| Туре | 2-core cable VCTF, VCTFK, CVV, VVR, VVF, or VCT | 2-core shielded cable CVVS, CPEVS, or MVVS | |
| Size | 0.3 to 1.25 mm ² [AWG 22 to 16] *1 *4 | 0.3 to 1.25 mm ² [AWG 22 to 16] *1 *5 | |
| Length | Max. 200 m [656 ft] *2 *3 | The section of the cable that exceeds 10 m [32 ft] must be included in the maximum indoor-outdoor transmission line distance. | |

^{*1} The use of cables that are smaller than 0.75 mm² [AWG 18] is recommended for easy handling.

^{*} Ensure shield continuity when extending the transmission cable.

^{*1} When extending the length of the transmission cables to 1000 m [3280 ft], consult your dealer.

^{*2} Max. 70 m [229 ft] for PAR-CT01MA series

^{*3} Max. 150 m [492 ft] for PAR-FS01MA series

^{*4} To wire PAR-CT01MA series, PAR-FS01MA series, PAR-4"x"MA series, PAR-3"x"MA series ("x" represents 0 or later), or Simple MA remote controller, use a cable with a size of 0.3 mm² [AWG 22].

^{*5} When connected to the terminal block on the Simple remote controller, use a cable with a size of 0.75 to 1.25 mm² [AWG18 to 16].

2-3 Switch Settings

1. Switch setting

The necessary switch settings depend on system configuration. Before performing wiring work, refer to the following page(s).

[2-7 Example System with an MA Remote Controller](page 36)

[2-8 Example System with an ME Remote Controller](page 49)

[2-9 Example System with an MA and an ME Remote Controller](page 51)

If the switch settings are changed while the unit is being powered, those changes will not take effect, and the unit will not function properly.

| Units on which to set the switches | | Symbol | Units to which the power must be shut off |
|------------------------------------|--|----------|---|
| CITY MULTI indoor unit | Main/sub unit | IC | Outdoor units *3 and Indoor units |
| LOSSNAY, OA processing unit *1 | | LC | Outdoor units *3 and LOSSNAY |
| ME remote controller | remote controller Main/sub remote controller | | Outdoor units *3 |
| MA remote controller | Main/sub remote controller | MA | Indoor units |
| CITY MULTI outdoor unit*2 | | OC,OS | Outdoor units *3 |
| BC controller Main Sub1 - 11 | | ВС | Outdoor units *3 and BC controller |
| | | BS1 - 11 | Outdoor units *3 *4 and BC controller |

^{*1.} Applicable when LOSSNAY units are connected to the indoor-outdoor transmission line.

^{*2.} The outdoor units in the same refrigerant circuit are automatically designated as OC and OS in the order of capacity from large to small (if two or more units have the same capacity, in the order of address from small to large).

^{*3.} Turn off the power to all the outdoor units in the same refrigerant circuit.

^{*4.} When setting the switch SW4 of the control board, set it with the outdoor unit power on. Refer to the following page(s). [5-1-1 Outdoor Unit Switch Functions and Factory Settings](page 123)

2-4 M-NET Address Settings

2-4-1 Address Settings List

1. M-NET Address settings

(1) Address settings table

The need for address settings and the range of address setting depend on the configuration of the system.

| Uni | t or controller | Sym- bol | Ad- dress setting range | ess titing | |
|------------------------------|-------------------------|--|--|--|------|
| CITYMULTI indoor unit | Main/sub unit | IC | 0, 01 to 50*1*4 *6*7 | Assign the smallest address to the main indoor unit in the group, and assign sequential address numbers to the rest of the indoor units in the same group. | 00 |
| M-NET adapter | | | | In an R2 system with a sub BC controller, make the settings for the indoor units in the following order. | |
| M-NET con- trol interface | | | | (i) Indoor unit to be connected to the main BC controller (ii) Indoor unit to be connected to sub BC controller 1 (iii) Indoor unit to be connected to sub BC controller 2 | |
| Free Plan adapter | | | | Make the settings for the indoor units in the way that the formula "(i) < (ii) < (iii)" is true. | |
| LOSSNAY, C | DA processing unit | processing unit LC 0, 01 to 50*1*4 Assign an arbitrary but unique address to each of these units after assigning an address to all indoor units. | | 00 | |
| ME remote controller | Main remote controller | RC | 101 to Add 100 to the smallest address of all the indoor units in the same group. | | 101 |
| | Sub remote controller | RC | 151 to 200 ^{*3} Add 150 to the smallest address of all the indoor units the same group. | | |
| MA remote co | ontroller | MA | No address settings required. (The main/sub setting must be made if 2 remote controllers are connected to the system.) | | Main |
| CITY MULTI | CITY MULTI outdoor unit | | 0, 51 to 100*1*2 *6 | Assign an address that equals the lowest address of the indoor units in the same refrigerant circuit plus 50. Assign sequential addresses to the outdoor units in the same refrigerant circuit. The outdoor units in the same refrigerant circuit are automatically designated as OC and OS. | 00 |
| Auxiliary outdoor unit | BC controller (main) | ВС | • Assign an address that equals the address of the outdoor unit in the same refrigerant system plus 1. •If a given address overlaps any of the addresses that are assigned to the outdoor units or to the sub BC controller, use a different, unused address within the setting range. | | 00 |
| | BC controller (sub) | BS1 BS2 BS3 BS11 | 51 to 100 *2 | Assign an address to both the sub BC controller that equals the lowest address of the indoor units that are connected to each of them plus 50. If a sub BC controller is connected, the automatic startup function is not available. | |

^{*1.} If a given address overlaps any of the addresses that are assigned to other units, use a different, unused address within the setting range.

^{*2.} To set the outdoor unit address or the auxiliary outdoor unit address to " 100," set the rotary switches to "50."

^{*3.} To set the ME remote controller address to "200," set the rotary switches to "00."

^{*4.} Some models of indoor units have two or three control boards.

Assign an address to the No.1, No. 2, and No. 3 control boards so that the No. 2 control board address equals the No. 1 control board address plus 1, and that the No. 3 control board address equals the No. 1 control board address plus 2.

^{*5.} The outdoor units in the same refrigerant circuit are automatically designated as OC, and OS. They are designated as OC, and OS in the descending order of capacity (ascending order of address if the capacities are the same).

the descending order of capacity (ascending order of address if the capacities are the same).

*6. No address settings are required for units in a system with a single outdoor unit (with some exceptions).

Address setting is required if a sub BC controller is connected.

Address setting is required if a sub BC controller is connected.

*7. If a given address overlaps any of the addresses that are assigned to other units, use a different, unused address within the setting range.

| Unit or controller | | Sym- bol | Address setting range | Setting method | Factory address setting |
|--------------------|---|-------------|-----------------------------|--|-------------------------------|
| System controller | Group remote controller | GR SC | 201 to 250 | Assign an address that equals the sum of the smallest group number of the group to be controlled and 200. | 201 |
| | System remote controller | SR SC | - | Assign an arbitrary but unique address within the range listed on the left to each unit. | |
| | ON/OFF remote controller | AN SC | | Assign an address that equals the sum of the smallest group number of the group to be controlled and 200. | |
| | Schedule timer (compatible with M-NET) | ST SC | | Assign an arbitrary but unique address within the range listed on the left to each unit. | 202 |
| | Central controller AE-200 AG-150A GB-50ADA G(B)-50A | TR SC | 000 201 to 250 | Assign an arbitrary but unique address within the range listed on the left to each unit. The address must be set to "000" to control the K-control unit. | 000 |
| | Expansion controller PAC-YG50ECA | TR | 000 201 to 250 | Assign an arbitrary but unique address within the range listed on the left to each unit. The address must be set to "000" to control the K-control unit. | 000 |
| | BM adapter BAC-HD150 | SC | 000 201 to 250 | Assign an arbitrary but unique address within the range listed on the left to each unit. The address must be set to "000" to control the K-control unit. | 000 |
| | LM adapter | SC | 201 to 250 | Assign an arbitrary but unique address within the range listed on the left to each unit. | 247 |

2-4-2 Outdoor Unit Power Jumper Connector Connection

There are limitations on the total number of units that are connectable to each refrigerant system. Refer to the DATABOOK for details.

| System configuration | Connection to the system controller | Power supply unit for transmission lines | Group operation of units in a system with multiple outdoor units | Power supply switch connector connection |
|------------------------------|--|--|--|--|
| System with one outdoor unit | - | _ | _ | Leave CN41 as it is (Factory setting) |
| System with multi- | Not connected | _ | Not grouped | |
| ple outdoor units | | | Grouped | Disconnect the male connector from the fe- |
| | With connection to the indoor unit system | Not required | Grouped/not grouped | male power supply switch connector (CN41) and connect it to the female power supply switch connector (CN40) on only one of the outdoor units.*2 |
| | With connection to the central- ized control sys- tem | Not required*1 (Powered from the outdoor unit) | Grouped/not grouped | *Connect the S (shielded) terminal on the terminal block (TB7) on the outdoor unit whose CN41 was replaced with CN40 to the ground terminal (///) on the electric box. |
| | | Required *1 | Grouped/not grouped | Leave CN41 as it is (Factory setting) |

^{*1} The need for a power supply unit for transmission lines depends on the system configuration.

2-4-3 Outdoor Unit Centralized Controller Switch Setting

| System configuration | Centralized control switch (SW5-1) settings *1 | | |
|---|--|--|--|
| Connection to the system controller Not connected | Leave it to OFF. (Factory setting) | | |
| Connection to the system controller Connected *2 | ON | | |

^{*1} Set SW5-1 on all outdoor units in the same refrigerant circuit to the same setting.

2-4-4 Room Temperature Detection Position Selection

To stop the fan during heating Thermo-OFF (SW1-7 and 1-8 on the indoor units to be set to ON), use the built-in thermistor on the remote controller or an optional thermistor.

- To use the built-in sensor on the remote controller, set the SW1-1 to ON. (Factory setting: SW1-1 set to "OFF".)
 - •Some models of remote controllers are not equipped with a built-in temperature sensor. Use the built-in temperature sensor on the indoor unit instead.
 - •When using the built-in sensor on the remote controller, install the remote controller where room temperature can be detected. (Note) Factory setting for SW1-1 on the indoor unit of the All-Fresh Models is ON.
- 2) When an optional temperature sensor is used, set SW1-1 to OFF, and set SW3-8 to ON.
 - •When using an optional temperature sensor, install it where room temperature can be detected.

^{*2} The replacement of the power jumper connector from CN41 to CN40 must be performed on only one outdoor unit in the system.

^{*2} When only the LM adapter is connected, leave SW5-1 to OFF (as it is).

2-4-5 Start/Stop Control of Indoor Units

Each indoor unit (or group of indoor units) can be controlled individually by setting SW 1-9 and 1-10.

| Function | Operation of the indoor unit when the operation is resumed after the unit was stopped | | Setting (SW1)*4 *5 | |
|---|---|-----|--------------------|--|
| Function | | | 10 | |
| Power ON/OFF by the plug*1,*2,*3 | Indoor unit will go into operation regardless of its operation status before power off (power failure). (In approx. 5 minutes) | OFF | ON | |
| Automatic restoration after power failure | Indoor unit will go into operation if it was in operation when the power was turned off (or cut off due to power failure). (In approx. 5 minutes) | ON | OFF | |
| | Indoor unit will remain stopped regardless of its operation status before power off (power failure). | OFF | OFF | |

^{*1.} Do not cut off power to the outdoor unit. Cutting off the power supply to the outdoor unit will cut off the power supply to the belt heater and may cause the compressor to malfunction when the unit is put back into operation.

2-4-6 Miscellaneous Settings

Cooling-only setting for the indoor unit: Cooling only model (Factory setting: SW3-1 "OFF.") When using indoor unit as a cooling-only unit, set SW3-1 to ON.

^{*2.} Not applicable to units with a built-in drain pump or humidifier.

^{*3.} Models with a built-in drain pump cannot be turned on/off by the plug individually. All the units in the same refrigerant circuits will be turned on or off by the plug.

^{*4.} Requires that the dipswitch settings for all the units in the group be made.

^{*5.} When using the free contact on the indoor units, set SW1-9 and SW1-10 to ON. With these settings made, the power start-stop function becomes disabled. To use the auto recovery function after power failure while these settings are made, set SW1-5 to ON.

2-4-7 Various Control Methods Using the Signal Input/Output Connector on Outdoor Unit

(1) Various connection options

| Туре | Usage | Function | Terminal to be used *1 | Option |
|-------------|--|---------------------------------------|------------------------------|---------------------------------------|
| Input | Prohibiting cooling/heating operation (thermo OFF) by an external input to the outdoor unit. | DEMAND (level) | CN3D*2 | Adapter for external input (PAC-SC36- |
| | Performs a low level noise operation of the outdoor unit by an external input to the outdoor unit. * It can be used as the silent operation device for each refrigerant system. | Low-noise mode (level) *3*4 | | NA-E) |
| | Forces the outdoor unit to perform a fan operation by receiving signals from the snow sensor.*5*7 | Snow sensor signal input (level) | CN3S | |
| | Cooling/heating operation can be changed by an external input to the outdoor unit. | Auto-changeover | CN3N | |
| Out- put | How to extract signals from the outdoor unit *It can be used as an operation status display device. *It can be used for an interlock operation with external devices. | Operation status of the compressor *5 | CN51 | Adapter for external out- |
| | it can be used for an interiock operation with external devices. | Error status*6*8 | | put (PAC-SC37- SA-E) |

^{*1} For details, refer to section (2) Example of wiring connection.

When SW6-7 is set to ON: The low-noise mode always remains effective.

When SW6-7 is set to OFF: The low noise mode is cancelled when certain outside temperature or pressure criteria are met, and the unit goes into normal operation (capacity priority mode).

| Low-noise mod is effective. | | Capacity priority mode becomes effective. | | |
|---|--|--|---|--|
| Cooling Heating | | Cooling Heating | | |
| TH7<30°C[86°F] and 63HS1<32kg/cm ² | TH7>3°C[37°F] and 63LS>4.6kg/cm ² | TH7>35°C[95°F] or 63HS1>35kg/cm ² | TH7<0°C[32°F] or 63LS<3.9kg/cm ² | |

^{*5} If multiple outdoor units are connected to the same refrigerant circuit, signal input/output settings need to be made for each outdoor unit.

^{*2} For details, refer to section (2) Example of wiring connection and other relevant sections in the manual. [2-5 Demand Control Overview](page 33)

^{*3} Low-noise mode is valid when Dip SW6-8 on the outdoor unit is set to OFF. When DIP SW6-8 is set to ON, 4 levels of on-DEMAND are possible, using different configurations of low-noise mode input and DEMAND input settings. When 2 or more outdoor units exist in one refrigerant circuit system, 8 levels of on-DEMAND are possible.

^{*4.} By setting Dip SW6-7, the Low-noise mode can be switched between the Capacity priority mode and the Low-noise priority mode.

^{*6} Take out signals from the outdoor unit that is designated as OC if multiple outdoor units in the same system.


^{*7} If the formula TH7>5 holds true, the fan will not go into operation when the contact receives signal input.


^{*8} When using a base heater, change the setting using SW4. When using a base heater, error output will not be available.


(2) Example of wiring connection


♠ CAUTION

- 1) Wiring should be covered by insulation tube with supplementary insulation.
- 2) Use relays or switches with IEC or equivalent standard.
- 3) The electric strength between accessible parts and control circuit should have 2750V or more.









Demand Control Overview 2-5

(1) General outline of control

Demand control is performed by using the external signal input to the 1-2 and 1-3 pins of CN3D on the outdoor units (OC and OS). Between 2 and 8 steps of demand control is possible by setting Dip SW6-8 on the outdoor units (OC and OS).

| No | Demand control switch | Dip SW6-8 | | Input to CN3D*2 | |
|-----|---------------------------------------|-----------|-----|-----------------|--|
| INO | | ОС | OS | input to CNOD | |
| 1 | 2 steps (0-100%) | OFF | OFF | ОС | |
| 2 | 4 steps (0-50-75-100%) | ON | OFF | ОС | |
| 3 | 4 steps (0-00-70-10070) | OFF | ON | OS | |
| 4 | 8 steps (0-25-38-50-63-75-88-100%) | ON | ON | OC and OS | |

^{*1} Available demand functions

P72-P144ZKMU models (single-outdoor-unit system): 2 and 4 steps shown in the rows 1 and 2 in the table above only. P168-P288ZSKMU models (two-outdoor-unit system OC+OS): 2-8 steps shown in the rows 1, 2, 3, and 4 in the table above

*2 Signal is input to CN3D on the outdoor unit whose SW6-8 is set to ON. When SW6-8 is set to OFF on all outdoor units, the signal is input to the CN3D on the OC. Outdoor units whose SW6-8 is set to ON are selectable in a single refrigerant system.

*3 If wrong sequence of steps are taken, the units may go into the Thermo-OFF (compressor stop) mode.

Ex) When switching from 100% to 50%

(Incorrect) 100% \to 0% \to 50% The units may go into the Thermo-OFF mode. (Correct) 100% \to 75% \to 50%

*4 The percentage of the demand listed in the table above is an approximate value based on the compressor volume and does

not necessarily correspond with the actual capacity.

*5 Notes on using demand control in combination with the low-noise mode

To enable the low-noise mode, it is necessary to short-circuit 1-2 pin of CN3D on the outdoor unit whose SW6-8 is set to OFF.

When SW6-8 is set to ON on all outdoor units, the following operations cannot be performed.

- •Performing 4-step demand in combination with the low-noise operation in a single-outdoor-unit system.
- •Performing 8-step demand in combination with the low-noise operation in a two-outdoor-unit system.

1) Contact input and control content

2-step demand control

The same control as the Thermo-OFF is performed by closing 1-3 pin of CN3D.

| CN3D | |
|-------|------|
| 1-3 | |
| Open | 100% |
| Close | 0% |

4-step demand control (When SW6-8 is set to ON on an outdoor unit)

Demand capacity is shown below.

| CN3D | 1-2P | | | | |
|-------|------------|-----|--|--|--|
| 1-3P | Open Close | | | | |
| Open | 100% | 75% | | | |
| Close | 0% | 50% | | | |

8-step demand control (When SW6-8 is set to ON on two outdoor units)

Demand capacity is shown below.

| 8-step demand | | | No.2 CN3D | | | | | |
|---------------|-------|-------|-----------|-------|------|-------|--|--|
| | | 1-2P | | Open | | Close | | |
| No.1 CN3D | 1-2P | 1-3P | Open | Close | Open | Close | | |
| | Open | Open | 100% | 50% | 88% | 75% | | |
| | | Close | 50% | 0% | 38% | 25% | | |
| | Close | Open | 88% | 38% | 75% | 63% | | |
| | | Close | 75% | 25% | 63% | 50% | | |

^{*1.} The outdoor units whose SW6-8 is set to ON are designated as No. 1 and No. 2 in the order of address from small to large. Ex) When outdoor units whose SW6-8 is set to ON are designated as OC and OS, OC = No. 1 and OS = No. 2.

2-6 System Connection Example

Examples of typical system connection are shown below. Refer to the Installation Manual that came with each device or controller for details.

(1) An example of a system to which an MA remote controller is connected

| | System configuration | Connection to the system controller | Address start up for in- door and outdoor units | Notes |
|---|---|--|--|--------------------------------------|
| 1 | System with one out- door unit | NO | Automatic address setup | |
| 2 | System with one out- door unit | NO | Manual address setup | Connection of multiple LOSSNAY units |
| 3 | Grouping of units in a system with multiple outdoor units | NO | Manual address setup | |
| 4 | System with one out- door unit | With connection to transmission line for centralized control | Manual address setup | |
| 5 | System with one out- door unit | With connection to indoor-outdoor transmission line | Manual address setup | |
| 6 | System with one out- door unit | With connection to transmission line for centralized control | Manual address setup | Connection of multiple LOSSNAY units |

(2) An example of a system to which an ME remote controller is connected

| | System configuration | Connection to the system controller | Address start up for indoor and outdoor units | Notes |
|---|-----------------------------------|--|---|-------|
| 1 | System with one out- door unit | With connection to transmission line for centralized control | Manual address setup | |

(3) An example of a system to which both MA remote controller and ME remote controller are connected


| | System configuration | Connection to the system controller | Address start up for in- door and outdoor units | Notes |
|---|-----------------------------------|--|--|-------|
| 1 | System with one out- door unit | With connection to transmission line for centralized control | Manual address setup | |

^{*}MA remote controller and ME remote controller cannot both be connected to the same group.

Example System with an MA Remote Controller

2-7-1 Single Refrigerant System (Automatic Indoor/Outdoor Address Startup)

(1) Sample control wiring



(2) Cautions

- ME remote controller and MA remote controller cannot both be connected to the same group of indoor units.
- No more than 2 MA remote controllers can be connected to a group of indoor units
 - When the PAR-CT01MA series, PAR-FS01MA series, PAR-4"x"MA series, or PAR-3"x"MA series ("x" represents 0 or later) is connected to a group, no other MA remote controllers can be connected to the same group
- When the number of the connected indoor units is as shown in the table below, one or more transmission boosters (sold separately)

To connect two transmission boosters, connect them in parallel. (Observe the maximum number of connectable indoor units that are listed in the specifications for each outdoor unit.)

| | Number of transmission booster (sold separately) re- quired | | |
|--|---|---------------|--|
| | 1 unit | 2 units | |
| When the P72 and P96 models are not included in the connected indoor units | 27 - 50 units | - | |
| When the P72 and P96 models are included in the connected indoor units | 21 - 39 units | 40 - 50 units | |

•The table above shows the number of transmission boosters that is required by the system with three BC controllers. For each BC controller that is subtracted from the above-mentioned system, two additional indoor units can be connected.

- Automatic address setup is not available if start-stop input (CN32, CN51, CN41) is used for a group operation of indoor units or when multiple indoor units with different functions are grouped in the same group. Refer to the following page(s). [2-7-2 Single Refrigerant System with Two or More LOSSNAY Units](page 38)
- For information about connecting two or more LOSSNAY units to a system, refer to the following page(s). [2-7-2 Single Refrigerant System with Two or More LOSSNAY Units](page 38)

(3) Maximum allowable length

1) Indoor/outdoor transmission line

Maximum distance (1.25mm² [AWG16] or larger) L1 +L2+L3+L4+L5≤200m[656ft] L1 +L2+L3+L11+L12+L13≤200m[656ft]

- *If the power-supply distance exceeds the distance limit of 200 meters, a transmission booster (PAC-SF46EPA-G) is required.
- Transmission line for centralized control

No connection is required.

MA remote controller wiring

Maximum overall line length (0.3 to 1.25mm² [AWG22 to 16]) m1≤200m [656ft] m2+m3≤200m [656ft], m2+m3≤200m [656ft], m4+m5≤200m [656ft], *2 *1 Max. 70 m [229 ft] for PAR-CT01MA series *2 Max. 150 m [492 ft] for PAR-FS01MA series

"When connecting PAR-CT01MA, PAR-FS01MA, PAR-4"x"MA, PAR-3"x"MA ("x" represents 0 or later), use sheathed cables with a minimum thickness of 0.3 mm

1) Indoor/outdoor transmission line

Daisy-chain terminals M1 and M2 of the terminal block for indoor-outdoor transmission line (TB3) on the outdoor units (OC and OS), of the terminal block for indoor-outdoor transmission line (TB02) on the main BC controller (BC), and of the terminal block for indoor-outdoor transmission line (TB5) on each indoor unit (IC). (Non-polarized two-wire)

Only use shielded cables.

Note

The outdoor units in the same refrigerant circuit are automatically designated as OC and OS in the order of capacity from large to small (if two or more units have the same capacity, in the order of address from small to large).

Shielded cable connection

Daisy-chain the ground terminal (//) on the outdoor units (OC and OS), the S terminal of the terminal block (TB02) on the BC controller (BC), and the S terminal of the terminal block (TB5) on the indoor unit (IC) with the shield of the shielded cable.

2) Transmission line for centralized control

No connection is required.

3) MA remote controller wiring

Connect terminals 1 and 2 on the terminal block for MA remote controller line (TB15) on the indoor unit (IC) to the terminal block on the MA remote controller (MA). (Non-polarized two-wire)

When 2 remote controllers are connected to the system

When 2 remote controllers are connected to the system, connect terminals 1 and 2 of the terminal block (TB15) on the indoor unit (IC) to the terminal block on the two MA

remote controllers.

Set one of the MA remote controllers as a sub controller.
 (Refer to the Instruction Manual for the MA remote controller for the setting method.)

Group operation of indoor units

To perform a group operation of indoor units (IC), daisychain terminals 1 and 2 on the terminal block (TB15) on all indoor units (IC) in the same group, and then connect terminals 1 and 2 on the terminal block (TB15) on the indoor unit on one end to the terminal block on the MA remotecontroller. (Non-polarized two-wire)

•When performing a group operation of indoor units that have different functions, "Automatic indoor/outdoor address setup" is not available.

4) LOSSNAY connection

Connect terminals M1 and M2 on the terminal block(TB5) on the indoor unit (IC) to the appropriate terminals on the terminal block (TB5) on LOSSNAY (LC). (Non-polarized two-wire)

- Interlock operation setting with all the indoor units in the same system will automatically be made. (It is required that the LOSSNAY unit be turned on before the outdoorunit.)
- •For information about certain types of systems (1. Systems in which the LOSSNAY unit is interlocked with only part of the indoor units, 2. Systems in which the LOSSNAY unit is operated independently from the indoor units, 3. Systems in which more than 16 indoor units are interlocked with the LOSSNAY unit, and 4. Systems to which two ore more LOSSNAY units are connected), refer to the following page(s). [2-7-2 Single Refrigerant System with Two or More LOSSNAY Units](page 38)
- 5) Switch setting

Address setting is required as follows.

(5) Address setting method

| Proce- dures | Unit or controller | | | Address set- ting range | Setting method | Notes | Factory setting |
|-----------------|------------------------------|--------------------------------|----------------|-------------------------------|---|--|-----------------|
| 1 | Indoor unit | Main unit | IC No settings | | - | Port number setting is required | 00 |
| | | Sub unit | IC | - required. | | For information about how to perform a group operation of indoor units that feature different functions, refer to the following page(s). [2-7-2 Single Refrigerant System with Two or More LOSSNAY Units](page 38) | |
| 2 | LOSSNAY | | LC | No settings required. | - | | 00 |
| 3 | MA remote con- troller | Main remote con- troller | MA | No settings required. | - | | Main |
| | | Sub remote con- troller | MA | Sub remote con- troller | Settings to be made with the Sub/Main switch | | |
| 4 | Outdoor unit | | oc os | No settings required. | - | | 00 |
| 5 | Auxiliary outdoor unit | BC controller | ВС | No settings required. | - | | 00 |


Note

The outdoor units in the same refrigerant circuit are automatically designated as OC and OS.

They are designated as OC and OS in the descending order of capacity (ascending order of address if the capacities are the same).

2-7-2 Single Refrigerant System with Two or More LOSSNAY Units

(1) Sample control wiring



OC, OS, and BS addresses (lowest indoor unit address in the group plus +50) have higher priority than the BS address

(2) Cautions

- ME remote controller and MA remote controller cannot both be connected to the same group of indoor units.

 No more than 2 MA remote controllers can be connected to a group
- of indoor units.
 - When the PAR-CT01MA series, PAR-FS01MA series, PAR-4"x"MA series, or PAR-3"x"MA series ("x" represents 0 or later) is connected to a group, no other MA remote controllers can be connected to the
- When the number of the connected indoor units is as shown in the table below, one or more transmission boosters (sold separately)
 - To connect two transmission boosters, connect them in parallel. (Observe the maximum number of connectable indoor units that are listed in the specifications for each outdoor unit.)

| | Number of transmission booster (sold separately) required | | |
|--|---|---------------|--|
| | 1 unit | 2 units | |
| When the P72 and P96 models are not included in the connected indoor units | 27 - 50 units | - | |
| When the P72 and P96 models are included in the connected indoor units | 21 - 39 units | 40 - 50 units | |

- •The table above shows the number of transmission boosters that is required by the system with three BC controllers. For each BC controller that is subtracted from the abovementioned system, two additional indoor units can be con-
- •Refer to the DATABOOK for further information about how many booster units are required for a given system.

(3) Maximum allowable length

- Indoor/outdoor transmission line Same as 2-7-1
- Transmission line for centralized control
- No connection is required. MA remote controller wiring
 - Same as 2-7-1

1) Indoor/outdoor transmission line

Daisy-chain terminals M1 and M2 of the terminal block for indoor-outdoor transmission line (TB3) on the outdoor units (OC and OS), of the terminal block for indoor-outdoor transmission line (TB02) on the main and sub BC controllers (BC and BS), and of the terminal block for indoor-outdoor transmission line (TB5) on each indoor unit (IC). (Non-polarized two-wire)

Only use shielded cables.

Note

The outdoor units in the same refrigerant circuit are automatically designated as OC and OS in the order of capacity from large to small (if two or more units have the same capacity, in the order of address from small to large).

Shielded cable connection

Daisy-chain the ground terminal (\not ____) on the outdoor units (OC and OS), the S terminal of the terminal block (TB02) on BC and BS, and the S terminal of the terminal block (TB5) on the indoor unit (IC) with the shield of the shielded cable.

 Transmission line for centralized control No connection is required.

3) MA remote controller wiring

Same as 2-7-1

When 2 remote controllers are connected to the system

Same as 2-7-1

Group operation of indoor units

Same as 2-7-1

4) LOSSNAY connection

Connect terminals M1 and M2 on the terminal block (TB5) on the indoor unit (IC) to the appropriate terminals on the terminal block (TB5) on LOSSNAY (LC). (Non-polarized two-wire)

- Interlock setting between the indoor units and LOSSNAY units must be entered on the remote controller. For information about how to interlock the operation of indoor and LOSSNAY units, refer to the installation manual for MA Remote Controller.
- Switch setting

Address setting is required as follows.

(5) Address setting method

| Proce- dures | Unit or controller | | Address setting range | Setting method | Notes | Fac- tory set- ting | |
|-----------------|------------------------------|-----------------------------|-----------------------------|---------------------------------|--|---|------|
| 1 | Indoor unit | Main unit | IC | 01 to 50 | Assign the smallest address to the main unit in the group. In a system with a sub BC controller, make the settings for the indoor units in the following order. (i) Indoor unit to be connected to the main BC controller (ii) Indoor unit to be connected to sub BC controller 1 (iii) Indoor unit to be connected to sub BC controller 2 Make the settings for the indoor units in the way that the formula "(i) < (ii) < (iii)" | Port number setting is required To perform a group operation of indoor units that feature different functions, designate the indoor unit in the group with the greatest number of functions as the main unit. | 00 |
| | | Sub unit | | | Assign sequential numbers starting with the address of the main unit in the same group +1. (Main unit address +1, main unit address +2, main unit address +3, etc.) | | |
| 2 | LOSSNAY | ′ | LC | 01 to 50 | Assign an arbitrary but unique address to each of these units after assigning an address to all indoor units. | None of these addresses may overlap any of the indoor unit addresses. | 00 |
| 3 | MA remote controller | Main remote controller | MA | No set- tings re- quired. | - | | Main |
| | | Sub remote controller | MA | Sub remote controller | Settings to be made with the Sub/ Main switch | | |
| 4 | Outdoor u | nit | OC OS | 51 to 100 | Assign sequential address to the outdoor units in the same refrigerant circuit. The outdoor units are automatically designated as OC and OS.(Note) | To set the address to 100, set the rotary switches to 50. If the addresses that is assigned to the main BC controller overlaps any of the | 00 |
| 5 | Auxiliary outdoor unit | BCcontrol- ler (Sub) | BS | 51 to 100 | Assign an address that equals the sum of the smallest address of the indoor units that are connected to the sub BC controller and 50. | troiler overlaps any or the addresses that are assigned to the outdoor units or to the sub BC controller, use a dif- ferent, unused address with- in the setting range. | |
| | | BC control- ler (Main) | ВС | | OC (or OS if it exists) +1 | *The use of a sub BC control- ler requires the connection of a main BC controller. | |


Note

The outdoor units in the same refrigerant circuit are automatically designated as OC and OS.

They are designated as OC and OS in the descending order of capacity (ascending order of address if the capacities are the same).

2-7-3 Grouped Operation of Units in Separate Refrigerant Circuits

(1) Sample control wiring



(2) Cautions

- ME remote controller and MA remote controller cannot both be connected to the same group of indoor units.
- No more than 2 MA remote controllers can be connected to a group of indoor units.
 - When the PAR-CT01MA series, PAR-FS01MA series, PAR-4"x"MA series, or PAR-3"x"MA series ("x" represents 0 or later) is connected to a group, no other MA remote controllers can be connected to the same group.
- 3) Do not connect the terminal blocks (TB5) on the indoor units that are connected to different outdoor units with each other.
- 4) Replacement of male power jumper connector (CN41) must be performed only on one of the outdoor units.
- Provide grounding to S terminal on the terminal block for transmission line for centralized control (TB7) on only one of the outdoor units.
- 6) When the number of the connected indoor units is as shown in the table below, one or more transmission boosters (sold separately) are required.
 - To connect two transmission boosters, connect them in parallel. (Observe the maximum number of connectable indoor units that are listed in the specifications for each outdoor unit.)

| | Number of transmission boost- er (sold separately) required | | |
|--|--|---------------|--|
| | 1 unit | 2 units | |
| When the P72 and P96 models are not included in the connected indoor units | 27 - 50 units | - | |
| When the P72 and P96 models are included in the connected indoor units | 21 - 39 units | 40 - 50 units | |

- •The left table shows the number of transmission boosters that is required by the system with three BC controllers. For each BC controller that is subtracted from the above-mentioned system, two additional indoor units can be connected.
- •Refer to the DATABOOK for further information about how many booster units are required for a given system.

(3) Maximum allowable length

- Indoor/outdoor transmission line
 Maximum distance (1.25mm² [AWG16] or larger)
 L11+L12≤200m [656ft]
 L21+L22≤200m [656ft]
- Transmission line for centralized control L31+L21≤200m [656ft]
- 3) MA remote controller wiring
- Same as 2-7-1
 4) Maximum line distance via outdoor unit (1.25mm² [AWG16] or larger)
 L12(L11)+L31+L22(L21)≤500m [1640ft]*1
 - *1 When the wiring length exceeds 500 m [1640 ft], consult the sales office.

1) Indoor/outdoor transmission line

Same as 2-7-2

Shielded cable connection

Same as 2-7-2

2) Transmission line for centralized control

Daisy-chain terminals M1 and M2 on the terminal block for transmission line for centralized control (TB7) on the outdoor units (OC) in different refrigerant circuits and on the OC and OS (Note a) in the same refrigerant circuit. If a power supply unit is not connected to the transmission line for centralized control, replace the power jumper connector on the control board from CN41 to CN40 on only one of the outdoor units.

Note |

- a) The outdoor units in the same refrigerant circuit are automatically designated as OC and OS in the order of capacity from large to small (if two or more units have the same capacity, in the order of address from small to large).
 b) If TB7's on the outdoor units in the same refrigerant circuit
- b) If TB7's on the outdoor units in the same réfrigerant circuit are not daisy-chained, connect the transmission line for the central control system to TB7 of the OC. (Note a).To maintain the central control even during an OC failure or a power failure, connect TB7 on OC and OS together. (If there is a

problem with the outdoor unit whose power jumper was moved from CN41 to CN40, central control is not possible, even if TB7's are daisy-chained.)

even if TB7's are daisy-chained.)
c) When connecting TB7, only commence after checking that the voltage is below 20 VDC.

Only use shielded cables.

Shielded cable connection

Daisy-chain the S terminal on the terminal block (TB7) on the outdoor units (OC, OS) with the shield wire of the shielded cable. Short-circuit the earth terminal (\not _) and the S terminal or the terminal block (TB7) on the outdoor unit whose power jumper connector is mated with CN40.

3) MA remote controller wiring

Same as 2-7-1

When 2 remote controllers are connected to the system Same as 2-7-1

Group operation of indoor units

Same as 2-7-1

4) LOSSNAY connection

Same as 2-7-2

5) Switch setting

Address setting is required as follows.

(5) Address setting method

| Proce- dures | Unit or controller | | Address setting range | Setting method | Notes | Fac- tory set- ting | |
|-----------------|------------------------------|-----------------------------|-----------------------------|---------------------------------|--|---|------|
| 1 | Indoor unit | Main unit | IC | 01 to 50 | Assign the smallest address to the main unit in the group. In a system with a sub BC controller, make the settings for the indoor units in the following order. (i) Indoor unit to be connected to the main BC controller (ii) Indoor unit to be connected to sub BC controller 1 (iii) Indoor unit to be connected to sub BC controller 2 Make the settings for the indoor units in the way that the formula "(i) < (ii) < (iii)" | Port number setting is required To perform a group operation of indoor units that feature different functions, designate the indoor unit in the group with the greatest number of functions as the main unit. | 00 |
| | | Sub unit | | | Assign sequential numbers starting with the address of the main unit in the same group +1. (Main unit address +1, main unit address +2, main unit address +3, etc.) | | |
| 2 | LOSSNAY | , | LC | 01 to 50 | Assign an arbitrary but unique address to each of these units after assigning an address to all indoor units. | None of these addresses may overlap any of the indoor unit addresses. | 00 |
| 3 | MA remote controller | Main remote controller | MA | No set- tings re- quired. | - | | Main |
| | | Sub remote controller | MA | Sub remote controller | Settings to be made with the Sub/ Main switch | | |
| 4 | Outdoor u | nit | OC OS | 51 to 100 | Assign sequential address to the outdoor units in the same refrigerant circuit. The outdoor units are automatically designated as OC and OS.(Note) | To set the address to 100, set the rotary switches to 50. If the addresses that is assigned to the main BC controller overlaps any of the | 00 |
| 5 | Auxiliary outdoor unit | BCcontrol- ler (Sub) | BS | 51 to 100 | Assign an address that equals the sum of the smallest address of the indoor units that are connected to the sub BC controller and 50. | addresses that are assigned to the outdoor units or to the sub BC controller, use a dif- ferent, unused address with- in the setting range. | |
| | | BC control- ler (Main) | ВС | | OC (or OS if it exists) +1 | •The use of a sub BC control- ler requires the connection of a main BC controller. | |

Note


The outdoor units in the same refrigerant circuit are automatically designated as OC and OS.

They are designated as OC and OS in the descending order of capacity (ascending order of address if the capacities are the same).

2-7-4 System with a Connection of System Controller to Centralized Control Transmission Line

(1) Sample control wiring

An example of a system in which a system controller is connected to the transmission cable for the centralized control system and the power is supplied from the outdoor unit



(2) Cautions

- ME remote controller and MA remote controller cannot both be connected to the same group of indoor units.
- No more than 2 MA remote controllers can be connected to a group of indoor units.
 - When the PAR-CT01MA series, PAR-FS01MA series, PAR-4"x"MA series, or PAR-3"x"MA series ("x" represents 0 or later) is connected to a group, no other MA remote controllers can be connected to the same group.
- Do not connect the terminal blocks (TB5) on the indoor units that are connected to different outdoor units with each other.
- Replacement of male power jumper connector (CN41) must be performed only on one of the outdoor units.
- 6) When the number of the connected indoor units is as shown in the table below, one or more transmission boosters (sold separately) are required.
 - To connect two transmission boosters, connect them in parallel. (Observe the maximum number of connectable indoor units that are listed in the specifications for each outdoor unit.)

| | Number of transmission booster (sold separately) required | | |
|--|---|---------------|--|
| | 1 unit | 2 units | |
| When the P72 and P96 models are not included in the connected indoor units | 27 - 50 units | - | |
| When the P72 and P96 models are included in the connected indoor units | 21 - 39 units | 40 - 50 units | |

- •The left table shows the number of transmission boosters that is required by the system with three BC controllers. For each BC controller that is subtracted from the above-mentioned system, two additional indoor units can be connected.
- Refer to the DATABOOK for further information about how many booster units are required for a given system.
- When a power supply unit is connected to the transmission line for centralized control, leave the power jumper connector on CN41 as it is (factory setting).

(3) Maximum allowable length

- 1) Indoor/outdoor transmission line
 - Same as 2-7-3
- Transmission line for centralized control L31+L32(L21) ≤200m [656ft]
- 3) MA remote controller wiring Same as 2-7-1
- Maximum line distance via outdoor unit (1.25mm² [AWG16] or larger)

L32+L31+L12(L11) ≤500m [1640ft]^{*1} L32+L22(L21) ≤500m [1640ft]^{*1} L12(L11)+L31+L22(L21) ≤500m[1640ft]^{*1}

*1 When the wiring length exceeds 500 m [1640 ft], consult the sales office.

1) Indoor/outdoor transmission line

Same as 2-7-2

Only use shielded cables.

Shielded cable connection

Same as 2-7-2

2) Transmission line for centralized control

Daisy-chain terminals A and B on the system controller, terminals M1 and M2 on the terminal block for transmission line for centralized control (TB7) on the outdoor units (OC) in different refrigerant circuits and on the outdoor units (OC and OS) in the same refrigerant circuit. (Note b) If a power supply unit is not connected to the transmission

line for centralized control, replace the power jumper connector on the control board from CN41 to CN40 on only one of the outdoor units

If a system controller is connected, set the central control switch (SW5-1) on the control board of all outdoor units to "ON."

Note

- a) The outdoor units in the same refrigerant circuit are automatically designated as OC and OS in the order of capacity from large to small (if two or more units have the same capacity, in the order of address from small to large)
- b) If TB7's on the outdoor units in the same refrigerant circuit are not daisy-chained, connect the transmission line for the central control system to TB7 of the OC. (Note a). To maintain the central control even during an OC failure or a power failure, connect TB7 on OC and OS together. (If there is a problem with the outdoor unit whose power jumper was

moved from CN41 to CN40, central control is not possible, even if TB7's are daisy-chained.)

- When connecting TB7, only commence after checking that the voltage is below 20 VDC.
 - Only use shielded cables

Shielded cable connection

Daisy-chain the S terminal of the terminal block (TB7) on the system controller, OC, and OS with the shield of the shield ed cable. Short-circuit the earth terminal (,,) and the S terminal on the terminal block (TB7) on the outdoor unit whose power jumper connector is mated with CN40.

MA remote controller wiring

Same as 2-7-1

When 2 remote controllers are connected to the system Same as 2-7-1

Group operation of indoor units

Same as 2-7-1

LOSSNAY connection

Connect terminals M1 and M2 on the terminal block (TB5) on the indoor unit (IC) to the appropriate terminals on the terminal block for indoor-outdoor transmission line (TB5) on LOSSNAY (LC). (Non-polarized two-wire)

- Indoor units must be interlocked with the LOSSNAY unit using the system controller. (Refer to the operation manual for the system controller for the setting method.) Interlock setting from the remote controller is required if the ON/OFF remote controller alone or the LM adapter alone is connected.
- Switch setting

Address setting is required as follows.

(5) Address setting method


| Proce- dures | Unit or controller | | | Ad- dress setting range | Setting method | Notes | Fac- tory set- ting |
|-----------------|------------------------------|--------------------------------|----------|----------------------------------|--|---|------------------------------|
| 1 | Indoor unit | Main unit | IC | 01 to 50 | Assign the smallest address to the main unit in the group. In a system with a sub BC controller, make the settings for the indoor units in the following order. Indoor unit to be connected to the main BC controller. Indoor unit to be connected to sub BC controller. Indoor unit to be connected to sub BC controller. Indoor unit to be connected to sub BC controller. Make the settings for the indoor units in the way that the formula "(i) < (ii) < (iii)" is true. | Port number setting is required To perform a group operation of indoor units that feature different functions, designate the indoor unit in the group with the greatest number of functions as the main unit. | 00 |
| | | Sub unit | | | Assign sequential numbers starting with the address of the main unit in the same group +1. (Main unit address +1, main unit address +2, main unit address +3, etc.) | | |
| 2 | LOSSNAY | , | LC | 01 to 50 | Assign an arbitrary but unique address to each of these units after assigning an address to all indoor units. | None of these addresses may over- lap any of the indoor unit addresses. | 00 |
| 3 | MA remote controller | Main remote con- troller | MA | No set- tings re- quired. | - | Make the same indoor unit group settings with the system controller as the ones that were made with the MA remote controller. | Main |
| | | Sub remote con- troller | MA | Sub remote controller | Settings to be made with the Sub/ Main switch | | |
| 4 | Outdoor u | nit (Note) | OC OS | 51 to 100 | Assign sequential address to the outdoor units in the same refrigerant circuit. The outdoor units are automatically designated as OC and OS.(Note) | To set the address to 100, set the rotary switches to 50. If the addresses that is assigned to the main BC controller overlaps any of the addresses that are as- | 00 |
| 5 | Auxiliary outdoor unit | BCcontrol- ler (Sub) | BS | 51 to 100 | Assign an address that equals the sum of the smallest address of the indoor units that are connected to the sub BC controller and 50. | signed to the outdoor units or to the sub BC controller, use a differ- ent, unused address within the setting range. | |
| | | BC control- ler (Main) | ВС | | OC (or OS if it exists) +1 | The use of a sub BC controller requires the connection of a main BC controller. | |

Note

The outdoor units in the same refrigerant circuit are automatically designated as OC and OS.
They are designated as OC and OS in the descending order of capacity (ascending order of address if the capacities are the same).

2-7-5 System with a Connection of System Controller to Indoor-Outdoor **Transmission Line**

(1) Sample control wiring



(2) Cautions

- ME remote controller and MA remote controller cannot both be connected to the same group of indoor units.
- No more than 2 MA remote controllers can be connected to a group of indoor units.
 - When the PAR-CT01MA series, PAR-FS01MA series, PAR-4"x"MA series, or PAR-3"x"MA series ("x" represents 0 or later) is connected to a group, no other MA remote controllers can be connected to the same group.
- Do not connect the terminal blocks (TB5) on the indoor units that are connected to different outdoor units with each other.
- Replacement of male power jumper connector (CN41) must be performed only on one of the outdoor units.
- Provide grounding to S terminal on the terminal block for transmission line for centralized control (TB7) on only one of the outdoor
- A maximum of three system controllers can be connected to the indoor-outdoor transmission line. (AE-200, AG-150A, GB-50ADA, or G(B)-50A are not connectable.)
- When the total number of indoor units exceeds 20 (12 if one or more indoor units of the 72 model or above is connected), it may not be possible to connect a system controller to the indoor-outdoor trans-
- When the number of the connected indoor units is as shown in the table below, one or more transmission boosters (sold separately) are required.
 - To connect two transmission boosters, connect them in parallel. (Observe the maximum number of connectable indoor units that are listed in the specifications for each outdoor unit.)

| | Number of transmission booster (sold separately) required | | |
|--|---|---------------|--|
| | 1 unit | 2 units | |
| When the P72 and P96 models are not included in the connected indoor units | 27 - 50 units | - | |
| When the P72 and P96 models are included in the connected indoor units | 21 - 39 units | 40 - 50 units | |

- •The table above shows the number of transmission boosters that is required by the system with three BC controllers. For each BC controller that is subtracted from the above-mentioned system, two additional indoor units can be connected
- Refer to the DATABOOK for further information about how many booster units are required for a given system.

(3) Maximum allowable length

Indoor/outdoor transmission line

Maximum distance (1.25mm² [AWG16] or larger) L11+L12≤200m [656ft] L21+L22≤200m [656ft] L25≤200m [656ft]

- Transmission line for centralized control
- L31+L21≤200m [656ft] MA remote controller wiring

Same as 2-7-1

- Maximum line distance via outdoor unit (1.25mm² [AWG16] or larger) L25+L31+L12(L11)≤500m [1640ft]*1 L12(L11)+L31+L22(L21)≤500m [1640ft]*1
 - *1 When the wiring length exceeds 500 m [1640 ft], consult the sales

1) Indoor/outdoor transmission line

Daisy-chain terminals M1 and M2 of the terminal block for indooroutdoor transmission line (TB3) on the outdoor units (OC and OS) (Note a), of the terminal block for indoor-outdoor transmission line (TB02) on the main and sub BC controllers (BC and BS), of the terminal block for indoor-outdoor transmission line (TB5) on each indoor unit (IC), and the S terminal of the system controller.(Non-polarized two-wire)

Only use shielded cables.

Note

a) The outdoor units in the same refrigerant circuit are automatically designated as OC and OS in the order of capacity from large to small (if two or more units have the same capacity, in the order of address from small to large).

Shielded cable connection

Daisy-chain the ground terminal (//) on the outdoor units (OC and OS), the S terminal of the terminal block (TB02) on the BC and BS, and the S terminal of the terminal block (TB5) on the indoor unit (IC) with the shield of the shielded cable.

Transmission line for centralized control

Daisy-chain terminals M1 and M2 on the terminal block for transmission line for centralized control (TB7) on the outdoor units (OC) in different refrigerant circuits and on the OC and OS in the same re-

If a power supply unit is not connected to the transmission line for centralized control, replace the power jumper connector on the control board from CN41 to CN40 on only one of the outdoor units. Set the central control switch (SW5-1) on the control board of all outdoor units to "ON". door units to "ON.

Note

b) If TB7's on the outdoor units in the same refrigerant circuit are not

daisy-chained, connect the transmission line for the central control system to TB7 of the OC. (Note a).To maintain the central control even during an OC failure or a power failure, connect TB7 on OC and OS together. (If there is a problem with the outdoor unit whose power jumper was moved from CN41 to CN40, central control is not possible, even if TB7's are daisy-chained.)

c) When connecting TB7, only commence after checking that the voltage is below 20 VDC.

Only use shielded cables

Shielded cable connection

Daisy-chain the S terminal on the terminal block (TB7) on the outdoor units (OC, OS) with the shield wire of the shielded cable. Short-circuit the earth terminal ($\frac{1}{1}$) and the S terminal on the terminal block (TB7) on the outdoor unit whose power jumper connector is mated`with´CN40.

MA remote controller wiring

Same as 2-7-1

When 2 remote controllers are connected to the system

Group operation of indoor units

Same as 2-7-1

4) LOSSNAY connection

Connect terminals M1 and M2 on the terminal block (TB5) on the indoor units (IC) to the appropriate terminals on the terminal block for indoor-outdoor transmission line (TB5) on LOSSNAY (LC). (Non-polarized two-wire)

•Indoor units must be interlocked with the LOSSNAY unit using the system controller. (Refer to the operation manual for the system controller for the setting method.) Interlock setting from the remote controller is required if the ON/OFF remote controller alone is connected.

Switch setting

Address setting is required as follows.

(5) Address setting method


| Proce- dures | Unit | or controller | | Address setting range | Setting method | Notes | Facto- ry set- ting |
|-----------------|------------------------------|--------------------------------|----------|---------------------------------|--|---|---------------------------|
| 1 | Indoor unit | Main unit | IC | 01 to 50 | Assign the smallest address to the main unit in the group. In a system with a sub BC controller, make the settings for the indoor units in the following order. (i) Indoor unit to be connected to the main BC controller (ii) Indoor unit to be connected to sub BC controller 1 (iii) Indoor unit to be connected to sub BC controller 2 Make the settings for the indoor units in the way that the formula "(i) < (ii) < (iii)" is true. Assign sequential numbers starting with the | Port number setting is required To perform a group operation of indoor units that feature different functions, designate the indoor unit in the group with the greatest number of functions as the main unit. | 00 |
| | | Sub unit | | | Assign sequential numbers starting with the address of the main unit in the same group +1. (Main unit address +1, main unit address +2, main unit address +3, etc.) | | |
| 2 | LOSSNAY | , | LC | 01 to 50 | Assign an arbitrary but unique address to each of these units after assigning an address to all indoor units. | None of these addresses may overlap any of the indoor unit addresses. | 00 |
| 3 | MA remote controller | Main remote con- troller | MA | No set- tings re- quired. | - | Make the same indoor unit group settings with the system controller as the ones that were made with the MA remote | Main |
| | | Sub remote con- troller | MA | Sub remote controller | Settings to be made with the Sub/ Main switch | controller. | |
| 4 | Outdoor u | nit | OC OS | 51 to 100 | Assign sequential address to the outdoor units in the same refrigerant circuit. The outdoor units are automatically designated as OC and OS.(Note) | To set the address to 100, set the rotary switches to 50. If the addresses that is assigned to the main BC controller overlaps any of the | 00 |
| 5 | Auxiliary outdoor unit | BCcontrol- ler (Sub) | BS | 51 to 100 | Assign an address that equals the sum of the smallest address of the indoor units that are connected to the sub BC controller and 50. | addresses that are assigned to the outdoor units or to the sub BC controller, use a dif- ferent, unused address with- | |
| | | BC control- ler (Main) | BC | | OC (or OS if it exists) +1 | in the setting range. •The use of a sub BC controller requires the connection of a main BC controller. | |

Note

The outdoor units in the same refrigerant circuit are automatically designated as OC and OS.
They are designated as OC and OS in the descending order of capacity (ascending order of address if the capacities are the same).

2-7-6 System with Multiple BC Controllers

(1) Sample control wiring



(2) Cautions

- ME remote controller and MA remote controller cannot both be connected to the same group of indoor units.
- No more than 2 MA remote controllers can be connected to a group of indoor units.
 - When the PAR-CT01MA series, PAR-FS01MA series, PAR-4"x"MA series, or PAR-3"x"MA series ("x" represents 0 or later) is connected to a group, no other MA remote controllers can be connected to the same group.
- Do not connect the terminal blocks (TB5) on the indoor units that are connected to different outdoor units with each other.
- Replacement of male power jumper connector (CN41) must be performed only on one of the outdoor units.
- 5) Short-circuit the S (shield) terminal of the terminal block for the central control unit (TB7) and the ground terminal (1/17) on the outdoor unit whose power jumper was moved from CN41 to CN40.
- 6) When the number of the connected indoor units is as shown in the table below, one or more transmission boosters (sold separately) are required.

To connect two transmission boosters, connect them in parallel. (Observe the maximum number of connectable indoor units that are listed in the specifications for each outdoor unit.)

| | Number of transmission booster (sold separately) required | | |
|--|---|---------------|--|
| | 1 unit | 2 units | |
| When the P72 and P96 models are not included in the connected indoor units | 27 - 50 units | - | |
| When the P72 and P96 models are included in the connected indoor units | 21 - 39 units | 40 - 50 units | |

•The table above shows the number of transmission boosters that is required by the system with three BC controllers. For each BC controller that is subtracted from the abovementioned system, two additional indoor units can be connected.

- •Refer to the DATABOOK for further information about how many booster units are required for a given system.
- When a power supply unit is connected to the transmission line for centralized control, leave the power jumper connector on CN41 as it is (factory setting).

(3) Maximum allowable length

- Indoor/outdoor transmission line
 Maximum distance (1.25mm² [AWG16] or larger)
 L11+L12≤200m [656ft]
 L21+L22≤200m [656ft]
- Transmission line for centralized control L31+L32(L21) ≤200m [656ft]
- 3) MA remote controller wiring Maximum overall line length

(0.3 to 1.25mm² [AWG22 to 16]) m1≤200m [656ft] m2+m3≤200m [656ft]

 Maximum line distance via outdoor unit (1.25mm² [AWG16] or larger)

 $L32+L31+L12(L11) \le 500m [1640ft]^{*1}$ $L32+L22(L21) \le 500m [1640ft]^{*1}$ $L12(L11)+L31+L22(L21) \le 500m [1640ft]^{*1}$

*1 When the wiring length exceeds 500 m [1640 ft], consult the sales office.

1) Indoor/outdoor transmission line

Daisy-chain terminals M1 and M2 of the terminal block for indoor-outdoor transmission line (TB3) on the outdoor units (OC and OS) (Note a), of the terminal block for indoor-outdoor transmission line (TB02) on the main and sub BC controllers (BC and BS), and of the terminal block for indoor-outdoor transmission line (TB5) on each indoor unit (IC). (Non-polarized two-wire)

Only use shielded cables.

Note

a) The outdoor units in the same refrigerant circuit are automatically designated as OC and OS in the order of capacity from large to small (if two or more units have the same capacity, in the order of address from small to large).

Shielded cable connection

Daisy-chain the ground terminal (///) on the outdoor units (OC and OS), the S terminal of the terminal block (TB02) on the BC and BS, and the S terminal of the terminal block (TB5) on the indoor unit (IC) with the shield of the shielded cable.

2) Transmission line for centralized control

Daisy-chain terminals A and B of the system controller, M1 and M2 terminals of TB7 (terminal block for centralized control system connection) on the outdoor units (OC) in different refrigerant systems, and M1 and M2 terminals of TB7 (terminal block for centralized control system connection) on the outdoor units (OC and OS) in the same refrigerant circuit. (Note b)

If a power supply unit is not connected to the transmission line for centralized control, replace the power jumper connector on the control board from CN41 to CN40 on only one of the outdoor units.

When connecting a system controller, set the centralized control switch (SW5-1) on the control board of all indoor units to "ON."

Note

b) If TB7's on the outdoor units in the same refrigerant cir-

cuit are not daisy-chained, connect the transmission line for the central control system to TB7 of the OC. (Note a). To maintain the central control even during an OC failure or a power failure, connect TB7 on OC and OS together. (If there is a problem with the outdoor unit whose power jumper was moved from CN41 to CN40, central control is not possible, even if TB7's are daisy-chained.)

c) When connecting TB7, only commence after checking that the voltage is below 20 VDC.

Only use shielded cables.

Shielded cable connection

Daisy-chain the S terminal of the terminal block (TB7) on the system controller, OC, and OS with the shield of the shielded cable. Short-circuit the earth terminal (,-) and the S terminal on the terminal block (TB7) on the outdoor unit whose power jumper connector is mated with CN40.

3) MA remote controller wiring

Same as 2-7-1

When 2 remote controllers are connected to the system

Same as 2-7-1

Group operation of indoor units

Same as 2-7-1

4) LOSSNAY connection

Connect terminals M1 and M2 on the terminal block (TB5) on the indoor unit (IC) to the appropriate terminals on the terminal block for indoor-outdoor transmission line (TB5) on LOSSNAY (LC). (Non-polarized two-wire)

- •Indoor units must be interlocked with the LOSSNAY unit using the system controller. (Refer to the operation manual for the system controller for the setting method.) Interlock setting from the remote controller is required if the ON/OFF remote controller alone or the LM adapter alone is connected.
- Switch setting

Address setting is required as follows.

(5) Address setting method

| Pro- ce- dur es | Unit or controller | | | Address setting range | Setting method | Notes | Fac- tory set- ting |
|--------------------------|---------------------------------|---------------------------------|----------|---------------------------------|---|--|------------------------------|
| 1 | Indoor unit | Main unit | IC | 01 to 50 | Assign the smallest address to the main unit in the group. In a system with a sub BC controller, make the settings for the indoor units in the following order. Indoor unit to be connected to the main BC controller Indoor unit to be connected to sub BC controller 1 Indoor unit to be connected to sub BC controller 2 Make the settings for the indoor units in the way that the formula "(i) < (ii) < (iii)" is true. Assign sequential numbers starting with the address of the main unit in the same group +1. (Main unit address +1, main unit address +2, main unit address +3, etc.) | Port number setting is required To perform a group operation of indoor units that feature different functions, designate the indoor unit in the group with the greatest number of functions as the main unit. | 00 |
| 2 | LOSSNA | Υ | LC | 01 to 50 | Assign an arbitrary but unique address to each of these units after assigning an address to all indoor units. | None of these addresses may overlap any of the indoor unit addresses. | 00 |
| 3 | MA remote control- ler | Main re- mote controller | MA | No set- tings re- quired. | - | Make the same indoor unit group settings with the system controller as the ones that were made with the MA remote controller. | Main |
| | | Sub re- mote con- troller | MA | Sub re- mote controller | Settings to be made with the Sub/Main switch | | |
| 4 | 4 Outdoor unit | | OC OS | 51 to 100 | The sum of the smallest address of the indoor units in the same system and 50. Assign sequential address to the outdoor units in the same refrigerant circuit. The outdoor units are automatically designated as OC and OS. | •To set the address to 100, set the rotary switches to 50. | 00 |
| 5 | Auxilia- ry out- door | BC controller (Sub) | BS | 51 to 100 | Assign an address that equals the sum of the smallest address of the indoor units that are connected to the sub BC controller and 50. | To set the address to 100, set the rotary switches to 50. If the addresses that is assigned to the main PC controller. | 00 |
| | unit BC controller (Main) | | ВС | 51 to 100 | OC (or OS if it exists) +1 | to the main BC controller over- laps any of the addresses that are assigned to the outdoor units or to the sub BC control- ler, use a different, unused ad- dress within the setting range. *The use of a sub BC controller requires the connection of a main BC controller. | |

Note


The outdoor units in the same refrigerant circuit are automatically designated as OC and OS.

They are designated as OC and OS in the descending order of capacity (ascending order of address if the capacities are the same).

2-8 Example System with an ME Remote Controller

2-8-1 System with a Connection of System Controller to Centralized Control Transmission Line

(1) Sample control wiring



(2) Cautions

- ME remote controller and MA remote controller cannot both be connected to the same group of indoor units.
- No more than 2 ME remote controllers can be connected to a group of indoor units.
- Do not connect the terminal blocks (TB5) on the indoor units that are connected to different outdoor units with each other.
- 4) Replace the power jumper connector of the control board from CN41 to CN40 on only one of the outdoor units.
- Provide an electrical path to ground for the S terminal on the terminal block for centralized control on only one of the outdoor units.
- 6) When the number of the connected indoor units is as shown in the table below, one or more transmission boosters (sold separately) are required.

To connect two transmission boosters, connect them in parallel. (Observe the maximum number of connectable indoor units that are listed in the specifications for each outdoor unit.)

| | Number of transmission booster (sold separately) required | | | |
|--|---|------------------|------------------|--|
| | 1 unit | 2 units | 3 units | |
| When the P72 and P96 models are not included in the connected indoor units | 15 - 34 units | 35 - 50 units | - | |
| When the P72 and P96 models are included in the connected indoor units | 11 - 26 units | 27 - 42 units | 43 - 50 units | |

•The left table shows the number of transmission boosters

- that is required by the system with three BC controllers. For each BC controller that is subtracted from the above-mentioned system, two additional indoor units can be connected.
- •Refer to the DATABOOK for further information about how many booster units are required for a given system.
- When a power supply unit is connected to the transmission line for centralized control, leave the power jumper connector on CN41 as it is (factory setting).

(3) Maximum allowable length

- 1) Indoor/outdoor transmission line
 - Same as 2-7-3

Same as 2-7-4

- Transmission line for centralized control Same as 2-7-4
- 3) ME remote controller wiring

Maximum overall line length (0.3 to 1.25mm² [AWG22 to 16]) m1≤10m [32ft] m2+m3≤10m [32ft]

If the standard-supplied cable must be extended, use a cable with a diameter of 1.25mm² [AWG16]. The section of the cable that exceeds 10m [32ft] must be included in the maximum indoor-outdoor transmission line distance described in (1).

When connected to the terminal block on the Simple remote controller, use cables that meet the following cable size specifications: 0.75 - 1.25 mm² [AWG18-16].

4) Maximum line distance via outdoor unit (1.25 mm² [AWG16] or large)

1) Indoor/outdoor transmission line

Same as 2-7-2

Shielded cable connection

Same as 2-7-2

2) Transmission line for centralized control

Same as 2-7-4

Shielded cable connection

Same as 2-7-4

3) ME remote controller wiring

ME remote controller is connectable anywhere on the indoor-outdoor transmission line.

When 2 remote controllers are connected to the system

Refer to the section on Switch Setting.

Performing a group operation (including the group operation of units in different refrigerant circuits).

Refer to the section on Switch Setting.

4) LOSSNAY connection

Same as 2-7-4

5) Switch setting

Address setting is required as follows.

(5) Address setting method

| Proce- dures | Unit or controller | | | Ad- dress setting range | Setting method | Notes | Fac- tory set- ting |
|-----------------|------------------------------|--|----------|----------------------------------|---|--|------------------------------|
| 1 | Indoor unit | 50 in the g In a syst the sett lowing of (i) Indoor contro (ii) Indoor contro (iii) Indoor contro Make th | | | Assign the smallest address to the main unit in the group. In a system with a sub BC controller, make the settings for the indoor units in the following order. (i) Indoor unit to be connected to the main BC controller (ii) Indoor unit to be connected to sub BC controller 1 (iii) Indoor unit to be connected to sub BC controller 2 Make the settings for the indoor units in the way that the formula "(i) < (ii) < (iii)" is true. | Port number setting is required To perform a group operation of indoor units that have different functions, set the indoor unit in the group with the greatest number of functions as the main unit. | 00 |
| | | Sub unit | | | Assign sequential numbers starting with the address of the main unit in the same group +1. (Main unit address +1, main unit address +2, main unit address +3, etc.) | | |
| 2 | LOSSNAY | , | LC | 01 to 50 | Assign an arbitrary but unique address to each of these units after assigning an address to all indoor units. | None of these addresses may overlap any of the indoor unit addresses. | 00 |
| 3 | ME remote controller | Main remote con- troller | RC | 101 to 150 | Add 100 to the main unit address in the group | It is not necessary to set the 100s digit. To set the address to 200, set the rotary switches to 00. | 101 |
| | | Sub remote con- troller | RC | 151 to 200 | Add 150 to the main unit address in the group | set the rotary switches to ou. | |
| 4 | Outdoor u | nit | OC OS | 51 to 100 | Assign sequential address to the outdoor units in the same refrigerant circuit. The outdoor units are automatically designated as OC and OS.(Note) | To set the address to 100, set the rotary switches to 50. If the addresses that is assigned to the main BC controller overlaps any of the | 00 |
| 5 | Auxiliary outdoor unit | BCcontrol- ler (Sub) | BS | 51 to 100 | Assign an address that equals the sum of the smallest address of the indoor units that are connected to the sub BC controller and 50. | addresses that are assigned to the outdoor units or to the sub BC controller, use a dif- ferent, unused address with- | |
| | | BC control- ler (Main) | BC | | OC (or OS if it exists) +1 | in the setting range. •The use of a sub BC controller requires the connection of a main BC controller. | |

Note


The outdoor units in the same refrigerant circuit are automatically designated as OC and OS.

They are designated as OC and OS in the descending order of capacity (ascending order of address if the capacities are the same).

2-9 Example System with an MA and an ME Remote Controller

2-9-1 System with a Connection of System Controller to Centralized Control Transmission Line

(1) Sample control wiring



(2) Cautions

- 1) Be sure to connect a system controller.
- ME remote controller and MA remote controller cannot both be connected to the same group of indoor units.
- Assign to the indoor units connected to the MA remote controller addresses that are smaller than those of the indoor units that are connected to the ME remote controller.
- No more than 2 ME remote controllers can be connected to a group of indoor units.
- No more than 2 MA remote controllers can be connected to a group of indoor units.
 - When the PAR-CT01MA series, PAR-FS01MA series, PAR-4"x"MA series, or PAR-3"x"MA series ("x" represents 0 or later) is connected to a group, no other MA remote controllers can be connected to the same group.
- Do not connect the terminal blocks (TB5) on the indoor units that are connected to different outdoor units with each other.
- Replace the power jumper connector of the control board from CN41 to CN40 on only one of the outdoor units.
- Provide an electrical path to ground for the S terminal on the terminal block for centralized control on only one of the outdoor units.
- When the number of the connected indoor units is as shown in the table below, one or more transmission boosters (sold separately) are required.
 - To connect two transmission boosters, connect them in parallel. (Observe the maximum number of connectable indoor units that are

listed in the specifications for each outdoor unit.)

| | Number of transmission booster (sold separately) required | | | |
|--|---|------------------|------------------|--|
| | 1 unit | 2 units | 3 units | |
| When the P72 and P96 models are not included in the connected indoor units | 15 - 34 units | 35 - 50 units | - | |
| When the P72and P96 models are included in the connected indoor units | 11 - 26 units | 27 - 42 units | 43 - 50 units | |

- •The left table shows the number of transmission boosters that is required by the system with three BC controllers. For each BC controller that is subtracted from the above-mentioned system, two additional indoor units can be connected.
- •Refer to the DATABOOK for further information about how many booster units are required for a given system.
- When a power supply unit is connected to the transmission line for centralized control, leave the power jumper connector on CN41 as it is (factory setting).

(3) Maximum allowable length

1) Indoor/outdoor transmission line

Same as 2-7-3

2) Transmission line for centralized control Same as 2-7-4

3) MA remote controller wiring

Same as 2-7-1

4) ME remote controller wiring

Same as 2-8

5) Maximum line distance via outdoor unit (1.25 mm² [AWG16] or larger)

Same as 2-7-4

(4) Wiring method

 Indoor/outdoor transmission line Same as 2-7-2

Shielded cable connection

Same as 2-7-2

2) Transmission line for centralized control

Same as 2-7-4

Shielded cable connection

Same as 2-7-4

3) MA remote controller wiring

When 2 remote controllers are connected to the system

Group operation of indoor units

Same as 2-7-1

4) ME remote controller wiring

When 2 remote controllers are connected to the system

Group operation of indoor units

Same as 2-8

5) LOSSNAY connection

Same as 2-7-4

6) Switch setting

Address setting is required as follows.

(5) Address setting method

| Pro- ce- dure s | U | nit or coi | ntroller | | Ad- dress set- ting range | Setting method | Notes | Facto- ry set- ting |
|--------------------------|---|---------------------------|-------------------------------------|--------------|--|--|---|---------------------------|
| 1 | Operation with the MA remote controller | In- door unit | Main unit | IC | 01 to 50 | Assign the smallest address to the main unit in the group. In a system with a sub BC controller, make the settings for the indoor units in the following order. Indoor unit to be connected to the main BC controller Indoor unit to be connected to sub BC controller 1 Indoor unit to be connected to sub BC controller 2 Make the settings for the indoor units in the way that the formula "(i) < (ii) < (iii)" is true. | Assign an address smaller than that of the indoor unit that is connected to the ME remote controller. Enter the same indoor unit group settings on the system controller as the ones that were entered on the MA remote controller. To perform a group operation of indoor units that have different functions, designate the indoor unit in the group with the greatest number of functions as the main unit. Port number setting is required. | 00 |
| | | | Sub unit | IC | 01 to 50 | Assign sequential numbers start- ing with the address of the main unit in the same group +1. (Main unit address +1, main unit address +2, main unit address +3, etc.) | | |
| | | MA re- mote | Main re- mote control- ler | MA | No set- tings re- quired. | - | | Main |
| | | troller | Sub remote control- ler | MA | Sub remote control- ler | Settings to be made according to the remote controller function selection | | |
| 2 | Operation with the ME remote controller | In- door | Main unit | IC | 01 to 50 | Assign the smallest address to the main unit in the group. | Assign an address higher than those of the indoor units that are connected to the MA remote controller. | 00 |
| | | unit | Sub unit | IC | 01 to 50 | Assign sequential numbers starting with the address of the main unit in the same group +1. (Main unit address +1, main unit address +2, main unit address +3, etc.) | Make the initial settings for the indoor unit group settings via the system controller. To perform a group operation of indoor units that have different functions, designate the indoor unit in the group with the greatest number of functions as the main unit. Port number setting is required. Addresses that are assigned to the indoor units that are connected to the sub BC controller should be higher than the addresses that are assigned to the indoor units that are connected to the main BC controller. | |
| | | ME re- mote con- | Main re- mote control- ler | RC | 101 to 150 | Add 100 to the main unit address in the group. | It is not necessary to set the 100s digit. To set the address to 200, set it to 00. | 101 |
| | | troller | Sub remote control- ler | RC | 151 to 200 | Add 150 to the main unit address in the group. | | |
| 3 | LOSSNAY | | LC | 01 to 50 | Assign an arbitrary but unique address to each of these units after assigning an address to all indoor units. | None of these addresses may over- lap any of the indoor unit addresses. | 00 | |
| 4 | Outdoor unit | | OC OS | 51 to 100 | Assign sequential address to the outdoor units in the same refrigerant circuit. The outdoor units are automatically designated as OC and OS.(Note) | To set the address to 100, set it to 50. If the addresses that is assigned to the main BC controller overlaps any of the addresses that are assigned to the outdoor units or to the sub BC controller, use a different, unused address within the setting range. | 00 | |
| 5 | Auxiliary outdoor unit | BCcontro | oller (Sub) | BS | 51 to 100 | Assign an address that equals the sum of the smallest address of the indoor units that are connected to the sub BC controller and 50. | *The use of a sub BC controller requires the connection of a main BC controller. | |
| | | BC conti (Main) | roller | ВС | | OC (or OS if it exists) +1 | | |

Note

The outdoor units in the same refrigerant circuit are automatically designated as OC and OS.

They are designated as OC and OS in the descending order of capacity (ascending order of address if the capacities are the same).

Restrictions on Refrigerant Pipes 2-10

2-10-1 Restrictions on Refrigerant Pipe Length and Pipe Size

(1) System that requires 16 BC controller ports or fewer <System with only the main BC controller or standard BC controller>

Note1. No Header usable on PURY system.

Note2. Indoor unit sized P72-P96 should be connected to BC controller via Y shape joint CMY-R160-J1.

Note3. Indoor unit sized P72-P96 does NOT share BC controller ports with other Indoor units;

Note4. As bents cause pressure loss on transportation of refrigerant, fewer bents design is better;

Piping length needs to consider the actual length and equivalent length which bents are counted.

Equivalent piping length (m)=Actual piping length+"M" x Number of bent.

Note5. Set DIP-SW 4-6 to ON of BC controller, in case of connected Indoor unit sized P72-P96 with 2 ports.

Note6. Do not connect multiple indoor units to the same port when operating each of them in different mode (cooling, heating, stop, and thermo-off), in case of connecting multiple indoor units to the same port units to one remote controller and switching SW1-1 ON in the all connected indoor units (switch to thermostat built in the remote controller) are recommended.


built in the remote controller) are recommended.

Note7. Indoor capacity is described as its model size. For example, PEFY-P24NMAU-**, its capacity is P24.

Note8. Total down-stream Indoor capacity is the summary of the model size of Indoors down-stream. For example, PEFY-P24NMAU-**, 15tal Indoor capacity = P24 + P06 = P30.

Note9. To connect the BC controller to the main pipe, use the reducer (CMY-R301S-G, CMY-R302S-G1, or CMY-R304S-G1).

Note10. Install the pipes correctly referring to the section 2-10-2.



OU Pipe (High pressure) Pipe (Low pressure) CMY-R160-J1 (joint) Н H' troller (Main BC) (joint_A) CMY-Y102SS-G2 CMY-Y102LS-G2 **-** D Pipe (Liquid) Pipe (Gas) ΙÜ ΙU Max. 3 sets for 2 port. P54 < Total capacity < = P96 IU (each) max < = P54 Max. 3 sets for 1 port. Total capacity < = P54, CMY-R160-J1 (joint) Fig. B Piping scheme OU: Outdoor unit, IU: Indoor unit

| Piping length limitation *8 | (m [ft.]) |
|-----------------------------|-----------|


| Item | Piping in the figure | Max. length | Max. equivalent length |
|--|---------------------------|---------------------|------------------------|
| Total piping length (Total length of high pressure and liquid pipes) | A+B+C+D+E+a+b+c+d+e+f+g+i | *1 | - |
| Farthest IU from OU | A+D+E+i | 165 [541'] | 190 [623'] |
| Distance between OU and BC | A | 110 [360'] *1 | 110 [360'] *1 |
| Farthest IU from BC controller | D+E+i | 60 [197'] *2*3 | 60 [197'] *2*3 |
| Height between OU and IU (OU above IU) | Н | 50 [164'] *6 | - |
| Height between OU and IU (OU under IU) | H' | 40 [131'] *7 | - |
| Height between IU and BC | h1 | 15 [49'] (10 [32']) | *4 - |
| Height between IU and IU | h2 | 30 [98'] (20 [65']) | *5 - |

Bent equivalent length Outdoor Model M (m/bent [ft./bent]) P72ZKMU 0.35 [1.15] P96ZKMU 0.42 [1.38] P120ZKMU 0.50 [1.64] P144ZKMU 0.50 [1.64]

- OU: Outdoor Unit; IU: Indoor Unit; BC: BC controlle
- 1. Refer to the section titled "Total piping length restrictions"
- *2. Details refer to Fig. 1.

 *3. When the P72 or P96 model of indoor units are connected to the system, the maximum distance from the BC controller to the farthest indoor unit (indicated as "D + E + i" in the figure is 40 meters.)
- *4. Distance of Indoor sized P72, P96 from BC must be less than 10 m, if any *5. Distance of Indoor sized P72, P96 from IU must be less than 20 m, if any.
- *6. 113m is available depending on the model and installation conditions. For more detailed information, contact your local distributor.
- *7. 60 m is available depending on the model and installation conditions. For more detailed information, contact your local distributor.
 *8. Total length of high-pressure pipes and liquid pipes

Fig. 1 Piping length and height between IU and BC controller



| Piping "A"size selec | (mm [in.]) | |
|----------------------|---------------------|--------------------|
| Outdoor Model | Pipe(High pressure) | Pipe(Low pressure) |
| P72ZKMU | ø15.88 [5/8"] | ø19.05 [3/4"] |
| P96ZKMU | ø19.05 [3/4"] | ø22.20 [7/8"] |
| P120ZKMU | ø19.05 [3/4"] | ø28.58 [1-1/8"] |
| P144ZKMU | ø22.20 [7/8"] | ø28.58 [1-1/8"] |

| Piping "B", "C", "D", "E" size selecito | (mm [in.]) | |
|---|--------------|---------------|
| Total down-stream Indoor capacity | Pipe(Liquid) | Pipe(Gas) |
| P54 or less | ø9.52 [3/8"] | ø15.88 [5/8"] |
| P55-P72 | ø9.52 [3/8"] | ø19.05 [3/4"] |
| P73-P96 | ø9.52 [3/8"] | ø22.20 [7/8"] |
| | | |

| Piping "a", "b", "c", "d", "e", | "f", "g", "i" size selection | rule (mm [in.]) |
|---------------------------------|------------------------------|-----------------|
| Indoor Unit size | Pipe(Liquid) | Pipe(Gas) |
| P04-P18 | ø6.35 [1/4"] | ø12.70 [1/2"] |
| P24-P54 | ø9.52 [3/8"] | ø15.88 [5/8"] |
| P72 | ø9.52 [3/8"] | ø19.05 [3/4"] |
| P96 | ø9.52 [3/8"] | ø22.20 [7/8"] |

| Selection criteria for joints_A | | |
|-----------------------------------|---------------|--|
| Total down-stream Indoor capacity | Joint | |
| -P72 | CMY-Y102SS-G2 | |
| P73-P96 | CMY-Y102LS-G2 | |

Joint CMY-R160-J1 Liquid side

Joint CMY-R160-J1 Gas side

S)ø5/8"(Brazing)

226 (T)ø19.05ID

(2) System that requires more than 16 BC controller ports or with multiple BC controllers < Outdoor unit P144 model or below.>

Fig. A

Note1. No Header usable on PURY system.


Note2. Indoor unit sized P72-P96 should be connected to BC controller via Y shape joint CMY-R160-J1.

Note3. Indoor unit sized P72-P96 does NOT share BC controller ports with other Indoor units;

Note4. As bents cause pressure loss on transportation of refrigerant, fewer bents design is better Piping length needs to consider the actual length and equivalent length which bents are counted Equivalent piping length (m)=Actual piping length+"M" x Number of bent.

Note5. Set DIP-SW 4-6 to ON of BC controller, in case of connected Indoor unit sized P72-P96 with 2 ports

Note6. Do not connect multiple indoor units to the same port when operating each of them in different mode (cooling, heating, stop, and thermo-off). In case of connecting multiple indoor units to the same port, connecting all indoor units to one remote controller and switching SW1-1 ON in the all connected indoor units (switch to thermostat built in the remote controller) are recommended.



Note8. Indoor capacity is described as its model size. For example, PEFY-P24NMAU-**, its capacity is P24.

Note9. Total down-stream Indoor capacity is the summary of the model size of Indoors down-stream. For example, PEFY-P24NMAU-** + PEFY-P06NMAU-** : Total Indoor capacity = P24 + P06 = P30.

Note10. To connect the BC controller to the main pipe, use the reducer (CMY-R301S-G, CMY-R302S-G1, or CMY-R304S-G1).

Note11. To connect the sub BC controller to the main BC controller, use the reducer (CMY-R303S-G1, CMY-R305S-G1, or CMY-R306S-G).

Note12. Install the pipes correctly referring to the section 2-10-2.

Note13. Up to 11 sub BC controllers can be connected.




Fig. B Piping scheme OU: Outdoor unit. IU: Indoor unit

| Piping length limitation *10 | | | (m [ft.]) |
|--|---|-----------------------|------------------------|
| Item | Piping in the figure | Max. length N | Max. equivalent length |
| Total piping length (Total length of high pressure and liquid pipes) | A+B+C+D+E+F+G+J+K+a+b+c+d+e+f+g+i+j+k+m+n | *1 | - |
| Farthest IU from OU | A+F+G+J+K+n | 165 [541'] | 190 [623'] |
| Distance between OU and BC | A | 110 [360'] *1 | 110 [360'] *1 |
| Farthest IU from BC controller | D+E+i | 60 [197'] *2*3 | 60 [197'] *2*3 |
| Farthest IU from BC controller via Sub BC controller | F+G+J+K+n | 90 [295'] *9 | 90 [295'] *9 |
| Height between OU and IU (OU above IU) | Н | 50 [164'] *7 | - |
| Height between OU and IU (OU under IU) | H' | 40 [131'] *8 | = |
| Height between IU and BC | h1 | 15 [49'] (10 [32']) * | 4 - |
| Height between IU and IU | h2 | 30 [98'] (20 [65']) * | 5 - |
| Height between BC(Main or Sub) and BC(Sub) | h3 | 15 [49'] (10 [32']) | *6 - |

OU: Outdoor Unit; IU: Indoor Unit; BC: BC controller

- *1. Refer to the section titled "Total piping length restrictions".
- *2. Details refer to Fig. 2.
- *3. When the P72 or P96 model of indoor units are connected to the system, the maximum distance from the BC controller to the farthest indoor unit (indicated as "D + E + i" in the figure is 40 meters.)
- *4. Distance of Indoor sized P72, P96 from BC must be less than 10 m, if any.
- *5. Distance of Indoor sized P72, P96 from IU must be less than 20 m, if any.
- *6. When using 2 or more Sub BC controllers, max. height "h3" should be considered.
- *7. 113m is available depending on the model and installation conditions. For more detailed information, contact your local distributor.
- *8. 60 m is available depending on the model and installation conditions. For more detailed information, contact your local distributor.
- *9. When the piping length or the vertical separation exceeds the limit specified in Fig. 2, connect a sub BC to the system. The restriction for a system with a sub BC connection is shown in Fig. 3. When a given system configuration falls within the shaded area in Fig. 3, increase the size of the high-pressure pipe and the liquid pipe between the main BC and sub BC by one size. When using P12, P15, P18, P36, or P48 model of indoor units, increase the size of the liquid branch pipe between the sub BC and indoor unit by one size. When using indoor models P54 or larger, the restrictions shown in Fig. 2 cannot be exceeded
- *10. Total length of high-pressure pipes and liquid pipes

| Bent equivalent length | |
|------------------------|----------------------|
| Outdoor Model | M(m/bent [ft./bent]) |
| P72ZKMU | 0.35 [1.15'] |
| P96ZKMU | 0.42 [1.38'] |
| P120ZKMU | 0.50 [1.64'] |
| P144ZKMU | 0.50 [1.64'] |

Piping length and height between IU and BC controller




Fig. 2





Fig. 3



*9. When the piping length or the vertical separation exceeds the limit specified in Fig. 2, connect a sub BC to the system.

The restriction for a system with a sub BC connection is shown in Fig. 3.

When a given system configuration falls within the shaded area in Fig. 3, increase the size of the high-pressure pipe and the liquid pipe between the main BC and sub BC by one size. The maximum liquid branch pipe diameter is ø19.05. If a given system already has a ø19.05-pipe between the main BC and sub BC, there is no need to increase the pipe size.

When using P12, P15, P18, P36, or P48 model of indoor units, increase the size of the liquid

branch pipe between the sub BC and indoor unit by one size.

When using indoor models P54 or larger, the restrictions shown in Fig. 2 cannot be exceeded.

Piping "A"size selection rule

| Piping "A"size selection rule | | (mm [in.]) |
|-------------------------------|---------------------|--------------------|
| Outdoor Model | Pipe(High pressure) | Pipe(Low pressure) |
| P72ZKMU | ø15.88 [5/8"] | ø19.05 [3/4"] |
| P96ZKMU | ø19.05 [3/4"] | ø22.20 [7/8"] |
| P120ZKMU | ø19.05 [3/4"] | ø28.58 [1-1/8"] |
| P144ZKMU | ø22.20 [7/8"] | ø28.58 [1-1/8"] |

Selection criteria for joints_A

| Total down-stream Indoor capacity | Joint |
|-----------------------------------|---------------|
| -P72 | CMY-Y102SS-G2 |
| P73-P96 | CMY-Y102LS-G2 |

Piping "B", "C", "D", "E" size seleciton rule

| Piping "B", "C", "D", "E" size sel | (mm [in.]) | |
|------------------------------------|--------------|---------------|
| Total down-stream Indoor capacity | Pipe(Liquid) | Pipe(Gas) |
| P54 or less | ø9.52 [3/8"] | ø15.88 [5/8"] |
| P55-P72 | ø9.52 [3/8"] | ø19.05 [3/4"] |
| P73-P96 | ø9.52 [3/8"] | ø22.20 [7/8"] |

Selection criteria for joints_B

| Total down-stream Indoor capacity | Joint |
|-----------------------------------|-------------|
| -P126 | CMY-R201S-G |
| P127-P216 | CMY-R202S-G |

Piping "a", "b", "c", "d", "e", "f", "g", "i", "j", "k", "m", "n" size selection rule (mm [in.])

| Indoor Unit size | Pipe(Liquid) | Pipe(Gas) |
|------------------|--------------|---------------|
| P04-P18 | ø6.35 [1/4"] | ø12.70 [1/2"] |
| P24-P54 | ø9.52 [3/8"] | ø15.88 [5/8"] |
| P72 | ø9.52 [3/8"] | ø19.05 [3/4"] |
| P96 | ø9.52 [3/8"] | ø22.20 [7/8"] |

| Piping "F", "G", "J", "K" size selection rule | | | (mm [in.]) |
|---|---------------|-----------------|-----------------|
| Total down-stream Indoor capacity | Pipe(Liquid) | Pipe(HP Gas) | Pipe(LP Gas) |
| P72 or less | ø9.52 [3/8"] | ø15.88 [5/8"] | ø19.05 [3/4"] |
| P73 to P108 | ø9.52 [3/8"] | ø19.05 [3/4"] | ø22.20 [7/8"] |
| P109 to P126 | ø12.70 [1/2"] | ø19.05 [3/4"] | ø28.58 [1-1/8"] |
| P127 to P144 | ø12.70 [1/2"] | ø22.20 [7/8"] | ø28.58 [1-1/8"] |
| P145 to P216 | ø15.88 [5/8"] | ø22.20 [7/8"] | ø28.58 [1-1/8"] |
| P217 to P234 | ø15.88 [5/8"] | ø28.58 [1-1/8"] | ø28.58 [1-1/8"] |
| P235 to P288 | ø19.05 [3/4"] | ø28.58 [1-1/8"] | ø34.93 [1-3/8"] |
| P289 or above | ø19.05 [3/4"] | ø28.58 [1-1/8"] | ø41.28 [1-5/8"] |
| UD II'd and ID I a seed of | | | |

HP: High pressure, LP: Low pressure

(3) System that requires more than 16 BC controller ports or with multiple BC controllers <Outdoor unit P168 model or above.>

Note1. No Header usable on PURY system.


Note2. Indoor unit sized P72-P96 should be connected to BC controller via Y shape joint CMY-R160-J1.

Note3. Indoor unit sized P72-P96 does NOT share BC controller ports with other Indoor units

Note4. As bents cause pressure loss on transportation of refrigerant, fewer bents design is better;
Piping length needs to consider the actual length and equivalent length which bents are counted.
Equivalent piping length (m)=Actual piping length+"M" x Number of bent.

Note5. Set DIP-SW 4-6 to ON of BC controller, in case of connected Indoor unit sized P72-P96 with 2 ports.

Note6. Do not connect multiple indoor units to the same port when operating each of them in different mode (cooling, heating, stop, and thermo-off). In case of connecting multiple indoor units to the same port, connecting all indoor units to one remote controller and switching SW1-1 ON in the all connected indoor units (switch to thermostat built in the remote controller) are recommended.



Joint CMY-R160-J1 Liquid side

Fig. A

Note7. The maximum total capacity of indoor units that can be connected to each sub BC controller CMB-P•NU-KB1/2 is P126.

Note8. Indoor capactiy is described as its model size. For example, PEFY-P24NMAU-**, its capacity is P24. Note9. Total down-stream Indoor capacity is the summary of the model size of Indoors down-stream. For example PEFY-P24NMAU-** + PEFY-P06NMAU-**: Total Indoor capacity = P24 + P06 = P30.

Note10. To connect the BC controller to the main pipe, use the reducer (CMY-R301S-G, CMY-R302S-G1, or CMY-R304S-G1).

Note11. To connect the sub BC controller to the main BC controller, use the reducer (CMY-R303S-G1, CMY-R305S-G1, or CMY-R306S-G)

Note12. Install the pipes correctly referring to the section 2-10-2 and 2-10-3. Note13. Up to 11 sub BC controllers can be connected.




Fig. B Piping scheme

OU: Outdoor unit, IU: Indoor unit

Piping length limitation *10

(m [ft.])

| Item | Piping in the figure | Max. length | Max. equivalent length |
|--|---|-----------------------|------------------------|
| Total piping length (Total length of high pressure and liquid pipes) | L+M+A+B+C+D+E+F+G+J+K+a+b+c+d+e+f+g+i+j+k+m+n | *1 | - |
| Farthest IU from OU | L(M)+A+F+G+J+K+n | 165 [541'] | 190 [623'] |
| Distance between OU and BC | L(M)+A | 110 [360'] *1 | 110 [360'] *1 |
| Farthest IU from BC controller | D+E+i | 60 [197'] *2 *3 | 60 [197'] *2*3 |
| Farthest IU from BC controller via Sub BC controller | F+G+J+K+n | 90 [295'] *9 | 90 [295'] *9 |
| Height between OU and IU (OU above IU) | Н | 50 [164'] *7 | - |
| Height between OU and IU (OU under IU) | H' | 40 [131'] *8 | - |
| Height between IU and BC | h1 | 15 [49'] (10 [32']) * | 4 - |
| Height between IU and IU | h2 | 30 [98'] (20 [65']) * | 5 - |
| Height between BC(Main or Sub) and BC(Sub) | h3 | 15 [49'] (10 [32']) * | 6 - |
| Distance between Main unit and Sub unit | L+M or M | 5 [16'] | - |
| Height between Main unit and Sub unit | h4 | 0.1 [0.3'] | - |

OU: Outdoor Unit; IU: Indoor Unit; BC: BC controller

- 1. Refer to the section titled "Total piping length restrictions".
- The it of the section rule in the piping respires includes:
 The section rule in the section rule in the piping respires includes:
 The section rule in the BC controller to the farthest indoor unit (indicated as "D + E + i" in the figure is 40 meters.)
- *4. Distance of Indoor sized P72, P96 from BC must be less than 10 m, if any.
 *5. Distance of Indoor sized P72, P96 from IU must be less than 20 m, if any.
- *6. When using 2 or more Sub BC controllers, max. height "h3" should be considered.
- *7. 113m is available depending on the model and installation conditions. For more detailed information, contact your local distributor.
- *8. 60 m is available depending on the model and installation conditions. For more detailed information, contact your local distributor
- *9. When the piping length or the vertical separation exceeds the limit specified in Fig. 2, connect a sub BC to the system.

The restriction for a system with a sub BC connection is shown in Fig. 3. When a given system configuration falls within the shaded area in Fig. 3, increase the size of the high-pressure pipe and the liquid pipe between the main BC and sub BC by one size

When using P12, P15, P18, P36, or P48 model of indoor units, increase the size of the liquid branch pipe between the sub BC and indoor unit by one size.

When using indoor models P54 or larger, the restrictions shown in Fig. 2 cannot be exceeded.

*10. Total length of high-pressure pipes and liquid pipes

Bent equivalent length

| Dent equivalent length | | |
|------------------------|---------------|----------------------|
| | Outdoor Model | M(m/bent [ft./bent]] |
| | P168ZSKMU | 0.50 [1.64'] |
| | P192ZSKMU | 0.50 [1.64'] |
| | P216ZSKMU | 0.50 [1.64'] |
| | P240ZSKMU | 0.50 [1.64'] |
| | P264ZSKMU | 0.70 [2.29'] |
| | P288ZSKMU | 0.70 [2.29'] |

Piping length and height between IU and BC controller




Fig. 2





Fig. 3



*9. When the piping length or the vertical separation exceeds the limit specified in Fig. 2, connect a sub BC to the system.

The restriction for a system with a sub BC connection is shown in Fig. 3. When a given system configuration falls within the shaded area in Fig. 3, increase the size of the high-pressure pipe and the liquid pipe between the main BC and sub BC by one size. The maximum liquid branch pipe diameter is ø19.05. If a given system already has a ø19.05-pipe between the main BC and sub BC, there is no need to increase the pipe size. When using P12, P15, P18, P36, or P48 model of indoor units, increase the size of the liquid branch pipe between the sub BC and indoor unit by one size.

When using indoor models P54 or larger, the restrictions shown in Fig. 2 cannot be exceeded.

Piping "A", "P"size selection rule

| Piping "A", "P"size selection rule | |
|------------------------------------|---|
| Pipe(High pressure) | Pipe(Low pressure) |
| ø22.20 [7/8"] | ø28.58 [1-1/8"] |
| ø22.20 [7/8"] | ø28.58 [1-1/8"] |
| | ø28.58 [1-1/8"] |
| ø28.58 [1-1/8"] | ø34.93 [1-3/8"] |
| ø28.58 [1-1/8"] | ø34.93 [1-3/8"] |
| ø28.58 [1-1/8"] | ø34.93 [1-3/8"] |
| | Pipe(High pressure) ### ### ### ### ### #### ########### |

Piping "L", "M", "N" size selection rule (mm [in.])

| Outdoor Model | Pipe(High pressure) | Pipe(Low pressure) |
|---------------|---------------------|--------------------|
| P72ZKMU | ø15.88 [5/8"] | ø19.05 [3/4"] |
| P96ZKMU | ø19.05 [3/4"] | ø22.20 [7/8"] |
| P120ZKMU | ø19.05 [3/4"] | ø28.58 [1-1/8"] |
| P144ZKMU | ø22.20 [7/8"] | ø28.58 [1-1/8"] |

Piping "B", "C", "D", "E" size seleciton rule

| <u> </u> | | (L |
|-----------------------------------|--------------|---------------|
| Total down-stream Indoor capacity | Pipe(Liquid) | Pipe(Gas) |
| P54 or less | ø9.52 [3/8"] | ø15.88 [5/8"] |
| P55-P72 | ø9.52 [3/8"] | ø19.05 [3/4"] |
| P73-P96 | ø9.52 [3/8"] | ø22.20 [7/8"] |

(mm [in.]) Selection criteria for joints_A

| Total down-stream Indoor capacity | | Joint |
|-----------------------------------|---------|---------------|
| | -P72 | CMY-Y102SS-G2 |
| | P73-P96 | CMY-Y102LS-G2 |
| | | |

Piping "a", "b", "c", "d", "e", "f", "g", "i", "j", "k", "m", "n" size selection rule (mm [in.])

| - · · · · · · · · · · · · · · · · · · · | ·, , , ·, , , · · , · · · , · · · | to concern the final |
|---|---|----------------------|
| Indoor Unit size | Pipe(Liquid) | Pipe(Gas) |
| P04-P18 | ø6.35 [1/4"] | ø12.70 [1/2"] |
| P24-P54 | ø9.52 [3/8"] | ø15.88 [5/8"] |
| P72 | ø9.52 [3/8"] | ø19.05 [3/4"] |
| P96 | ø9.52 [3/8"] | ø22.20 [7/8"] |

Selection criteria for joints_B

| Total down-stream Indoor capacity | Joint |
|-----------------------------------|-------------|
| -P126 | CMY-R201S-G |
| P127-P216 | CMY-R202S-G |
| P217-P234 | CMY-R203S-G |
| P235-P360 | CMY-R204S-G |
| P361- | CMY-R205S-G |


Piping "F", "G", "J", "K" size selection rule


| Tiping 1 , C , C , K Size selection rule | | | (111111 [1111.]) |
|--|---------------|-----------------|------------------|
| Total down-stream Indoor capacity | Pipe(Liquid) | Pipe(HP Gas) | Pipe(LP Gas) |
| P72 or less | ø9.52 [3/8"] | ø15.88 [5/8"] | ø19.05 [3/4"] |
| P73 to P108 | ø9.52 [3/8"] | ø19.05 [3/4"] | ø22.20 [7/8"] |
| P109 to P126 | ø12.70 [1/2"] | ø19.05 [3/4"] | ø28.58 [1-1/8"] |
| P127 to P144 | ø12.70 [1/2"] | ø22.20 [7/8"] | ø28.58 [1-1/8"] |
| P145 to P216 | ø15.88 [5/8"] | ø22.20 [7/8"] | ø28.58 [1-1/8"] |
| P217 to P234 | ø15.88 [5/8"] | ø28.58 [1-1/8"] | ø28.58 [1-1/8"] |
| P235 to P288 | ø19.05 [3/4"] | ø28.58 [1-1/8"] | ø34.93 [1-3/8"] |
| P289 or above | ø19.05 [3/4"] | ø28.58 [1-1/8"] | ø41.28 [1-5/8"] |
| | | | |


HP: High pressure, LP: Low pressure


2 Restrictions


Total piping length restrictions (m)













Total piping length restrictions(ft.)


[PURY-P72, 96ZKMU-B]




[PURY-P216, 240ZSKMU-B]




[PURY-P120, 144, 168Z(S)KMU-B]



[PURY-P264, 288ZSKMU-B]




[PURY-P192ZSKMU-B]



2-10-2 BC Controller Connection Method

(1) Size of the pipe that fits the standard BC controller ports

P72 - P120 models



Note 1 Do not connect multiple indoor units to the same port when operating each of them in different mode (cooling, heating, stop, and thermo-off).

The indoor units connected to the same port must be set to operate in the same mode. Set them in the same group to make them run/stop in the same mode all together. For other options, enable the thermo setting on the remote controller, or set the common thermostat (optional) to run/stop the units in the same mode based on a representative temperature.


The ports of the BC controller accommodates the pipes on P24 - P54 models of indoor units. To connect other types of indoor units, follow the procedure below.

Unit: mm [inch]

| Operation | | Pipe sections | | |
|-------------------|-----------------------------------|--|--------------------------------------|--|
| | | High-pressure side (gas) | Low-pressure side (gas) | |
| Outdoor unit side | PURY-P72ZKMU | ø15.88 [5/8"] (Brazed connection) | ø19.05 [3/4"] (Brazed connection) | |
| | PURY-P96ZKMU | RY-P96ZKMU ø19.05 [3/4"] | ø22.2 [7/8"] (Brazed connection) | |
| | PURY-P120ZKMU (Brazed connection) | ø28.58 [1-1/8"] (Brazed connection) | | |
| Indoor unit side | | ø9.52 [3/8"] (Brazed connection) | ø15.88 [5/8"] (Brazed connection) | |

^{*} BC controllers can only be connected to P72 - P120 models of outdoor units.

Note



Be sure to have pipe expansion of indoor unit connecting port by cutting the piping at the cutting point which depends on the indoor unit capacity.

®Cutting point: ø9.52 (Liquid side) or ø15.88 (Gas side)

(Indoor unit model : bigger than P18)

©Cutting point: ø6.35 (Liquid side) or ø12.7 (Gas side)

(Indoor unit model : P18 or smaller)

©Cut the piping at the cutting point

©Have pipe expansion of indoor unit connecting port

©Field pipe


Note:

Remove burr after cutting the piping to prevent entering the piping.

Check that there is no crack at the pipe expansion part.

Note

2) To connect P72 - P96 models of indoor units (or when the total capacity of indoor units exceeds P55), use a junction pipe kit and merge the two nozzles.



Note


- 3) To connect multiple indoor units to a port (or to a junction pipe)
 - •Maximum total capacity of connected indoor units: P54 or below (in a system with a junction pipe: P96 or below)
 - •Maximum number of connectable indoor units: 3 units
 - •Branch joint: Use CMY-Y102SS-G2, CMY-Y102LS-G2 (optional accessory).
 - •(1) Size of the pipe that fits the standard BC controller ports (A, B): Select the proper size pipes based on the total capacity of the downstream indoor units, using the table below as a reference.

Unit: mm [inch]

| Total capacity of indoor units | Liquid pipe | Gas pipe |
|--------------------------------|--------------|---------------|
| P54 or below | ø9.52 [3/8"] | ø15.88 [5/8"] |
| P55 - P72 | ø9.52 [3/8"] | ø19.05 [3/4"] |
| P73 - P96 | ø9.52 [3/8"] | ø22.2 [7/8"] |

(2) Size of the pipe that fits the main BC controller ports


P72 - P288 models



*Note 1 Do not connect multiple indoor units to the same port when operating each of them in different mode (cooling, heating, stop, and thermo-off).

The indoor units connected to the same port must be set to operate in the same mode. Set them in the same group to make them run/stop in the same mode all together. For other options, enable the thermo setting on the remote controller, or set the common thermostat (optional) to run/stop the units in the same mode based on a representative temperature.


• Restriction on installing the branch joint between Main BC and Sub BC on the high-pressure piping, low-pressure piping, and liquid piping.



- Regarding the branch joint between Main BC and Sub BC on the high-pressure/low-pressure/liquid piping, A and B must be installed horizontally, and C must be installed upward higher than the horizontal plane of A and B.

The ports of the BC controller accommodates the pipes on P24-P54 models of indoor units. To connect other types of indoor units, follow the procedure below.





Be sure to have pipe expansion of indoor unit connecting port by cutting the piping at the cutting point which depends on the indoor unit capacity.

®Cutting point: ø9.52 (Liquid side) or ø15.88 (Gas side)

(Indoor unit model : bigger than P18)

©Cutting point : ø6.35 (Liquid side) or ø12.7 (Gas side)

(Indoor unit model : P18 or smaller) ©Cut the piping at the cutting point

©Have pipe expansion of indoor unit connecting port

©Field pipe


Note:

Remove burr after cutting the piping to prevent entering the piping.

Check that there is no crack at the pipe expansion part.

Note

2) To connect P72 - P96 models of indoor units (or when the total capacity of indoor units exceeds P55), use a junction pipe kit and merge the two nozzles.



Note

- 3) To connect multiple indoor units to a port (or to a junction pipe)
 - •Maximum total capacity of connected indoor units: P54 or below (in a system with a junction pipe: P96 or below)
 - •Maximum number of connectable indoor units: 3 units
 - •Branch joint: Use CMY-Y102SS-G2, CMY-Y102LS-G2 (optional accessory).
 - •(2) Size of the pipe that fits the main BC controller ports (A, B): Select the proper size pipes based on the total capacity of the downstream indoor units, using the table below as a reference.


Unit: mm [inch]

| Total capacity of indoor units | Liquid pipe | Gas pipe |
|--------------------------------|--------------|---------------|
| P54 or below | ø9.52 [3/8"] | ø15.88 [5/8"] |
| P55 - P72 | ø9.52 [3/8"] | ø19.05 [3/4"] |
| P73 - P96 | ø9.52 [3/8"] | ø22.2 [7/8"] |

Unit : mm [inch]

| Operation | Pipe sections | | |
|-------------------|--------------------------------------|--|--|
| Outdoor unit side | High pressure side (Liquid) | Low-pressure side (Gas) | |
| PURY-P72ZKMU | ø15.88 [5/8"] (Brazed connection) | ø19.05 [3/4"] (Brazed connection) | |
| PURY-P96ZKMU | ø19.05 [3/4"] (Brazed connection) | ø22.2 [7/8"] (Brazed connection) | |
| PURY-P120ZKMU | (Brazed connection) | | |
| PURY-P144ZKMU | | - | |
| PURY-P168ZSKMU | ø22.2 [7/8"] (Brazed connection) | ø28.58 [1-1/8"] (Brazed connection) | |
| PURY-P192ZSKMU | , | , | |
| PURY-P216ZSKMU | | | |
| PURY-P240ZSKMU | ø28.58 [1-1/8"] | | |
| PURY-P264ZSKMU | (Brazed connection) | ø34.93 [1-3/8"] (Brazed connection) | |
| PURY-P288ZSKMU | | | |
| Indoor unit side | ø9.52 [3/8"] (Brazed connection) | ø15.88 [5/8"] (Brazed connection) | |

(3) Size of the pipe that fits the sub BC controller ports




Note 1 Do not connect multiple indoor units to the same port when operating each of them in different mode (cooling, heating, stop, and thermo-off).

The indoor units connected to the same port must be set to operate in the same mode. Set them in the same group to make them run/stop in the same mode all together. For other options, enable the thermo setting on the remote controller, or set the common thermostat (optional) to run/stop the units in the same mode based on a representative temperature.


The ports of the BC controller accommodates the pipes on P24-P54 models of indoor units. To connect other types of indoor units, follow the procedure below.





Note

To connect P72 - P96 models of indoor units (or when the total capacity of indoor units exceeds P55), use a junction pipe kit and merge the two nozzles.



Note

- 3) To connect multiple indoor units to a port (or to a junction pipe)
 - •Maximum total capacity of connected indoor units: P54 or below (in a system with a junction pipe: P96 or below)
 - •Maximum number of connectable indoor units: 3 units
 - *Branch joint: Use CMY-Y102SS-G2, CMY-Y102LS-G2 (optional accessory).
 - •(3) Size of the pipe that fits the sub BC controller ports (A, B): Select the proper size pipes based on the total capacity of the downstream indoor units, using the table below as a reference.

Unit: mm [inch]


| Total capacity of indoor units | Liquid pipe | Gas pipe |
|--------------------------------|--------------|---------------|
| P54 or below | ø9.52 [3/8"] | ø15.88 [5/8"] |
| P55 - P72 | ø9.52 [3/8"] | ø19.05 [3/4"] |
| P73 - P96 | ø9.52 [3/8"] | ø22.2 [7/8"] |


Unit: mm [inch]

| Ор | eration | Pipe sections | | | |
|-------------------------|--|--|--|--------------------------------------|--|
| | Total capacity of indoor units connected to downstream BC controller | High-pressure side (gas) | Low-pressure side (gas) | Liquid pipe side | |
| Main BC controller side | - P72 | ø15.88 [5/8"] (Brazed connection) | ø19.05 [3/4"] (Brazed connection) | ø9.52 [3/8"] | |
| | P73 - P108 | ø19.05 [3/4"] | ø22.2 [7/8"] (Brazed connection) | (Brazed connection) | |
| | P109 - P126 | (Brazed connection) | | ø12.7 [1/2"] | |
| | P127 - P144 | ø22.2 [7/8"] | ø28.58 [1-1/8"] | (Brazed connection) | |
| | P145 - P216 | (Brazed connection) | (Brazed connection) | ø15.88 [5/8"] | |
| | P217 - P234 | | | (Brazed connection) | |
| | P235 - P288 | ø28.58 [1-1/8"] (Brazed connection) | ø34.93 [1-3/8"] (Brazed connection) | ø19.05 [3/4"] (Brazed connection) | |
| | P289 - | | ø41.28 [1-5/8"] (Brazed connection) | (Brazed connection) | |

2-10-3 Outdoor Twinning Kit


The following optional Outdoor Twinning Kit is needed to use to combine multiple refrigerant pipes. Refer to section "Piping Design" of the DATA BOOK for the details of selecting a proper twinning kit.





Note 1. Refer to the figure below for the installation position of the twinning pipe.

The Twinning pipe must be installed horizontally using a level vessel to avoid unit damage.



- 2. Use the attached pipe to braze the port-opening of the twinning pipe.
- 3. Pipe diameter is indicated by inside diameter.
- 4. Only use the twinning pipe by Mitsubishi (optional parts).


Chapter 3 Major Components, Their Functions and Refrigerant Circuits

| 3-1 | External Appearance and Refrigerant Circuit Components of Outdoor Unit | 71 |
|-------|---|----|
| 3-1-1 | External Appearance of Outdoor Unit | 71 |
| 3-1-2 | Outdoor Unit Refrigerant Circuits | 74 |
| 3-2 | Outdoor Unit Refrigerant Circuit Diagrams | 77 |
| 3-3 | Functions of the Major Components of Outdoor Unit | 82 |
| 3-4 | Functions of the Major Components of Indoor Unit | 85 |
| 3-5 | External Appearance and Refrigerant Circuit Components of BC Controller | 86 |
| 3-6 | BC Controller Refrigerant Circuit Diagrams | 89 |
| 3-7 | Functions of the Major Components of BC Controller | 91 |


3-1 External Appearance and Refrigerant Circuit Components of Outdoor Unit

3-1-1 External Appearance of Outdoor Unit


(1) PURY-P72ZKMU



(2) PURY-P96ZKMU




(3) PURY-P120, P144ZKMU




3-1-2 Outdoor Unit Refrigerant Circuits


(1) PURY-P72ZKMU



(2) PURY-P96ZKMU




(3) PURY-P120, P144ZKMU




3-2 Outdoor Unit Refrigerant Circuit Diagrams


(1) PURY-P72, P96 ZKMU models




(2) PURY-P120, P144 ZKMU models




(3) PURY-P168, P192 ZSKMU models



(4) PURY-P216 ZSKMU model



(5) PURY-P240, P264, P288 ZSKMU models



3-3 Functions of the Major Components of Outdoor Unit

| Part name | Symbols (functions) | Notes | Usage | Specifications | Check method |
|-------------------------------------|---------------------|-------|---|--|------------------|
| Com- pressor | MC1 (Comp) | | Adjusts the amount of circulating refrigerant by adjusting the operating frequency based on the operating pressure data | 72, 96models Low-pressure shell scroll compressor Wirewound resistance 20°C[68°F]: 0.72Ω 120, 144 models Low-pressure shell scroll compressor Wirewound resistance 20°C[68°F]: 0.431Ω | |
| High pressure sensor | 63HS1 | | Detects high pressure Regulates frequency and provides high-pressure protection | Connector Pressure [MPa] 1.23 0.4.15 MPa [601psi] 1.23 0.071V/0.098 MPa [14psi] 1.38 x Vout [V]-0.69 1 | |
| Low pressure sensor | 63LS | | Detects low pressure Provides low-pressure protection | Con- 1 | |
| Pres- sure switch | 63H1 | | Detects high pressure Provides high-pressure protection | 4.15MPa[601psi] OFF set- ting | |
| Power supply trans- former | Trans former | | Decreases the power supply voltage (575V) supplied to the circuit board | Primary rated voltage: 575V, 50/60Hz Secondary rated voltage: 232V (No-load voltage) | |
| Thermis- tor | TH4 (Discharge) | | Detects discharge air temperature Provides high-pressure protection | Degrees Celsius R ₁₂₀ = 7.465k Ω R _{25/120} = 4057 R _t = 7.465exp{4057($\frac{1}{273+t}$ - $\frac{1}{393}$)} | Resistance check |
| | | | 0°C[32°F]:698kΩ 10°C[50°F]:413kΩ 20°C[68°F]:250kΩ 30°C[86°F]:160kΩ 40°C[104°F]:104kΩ 50°C[122°F]:70kΩ 60°C[140°F]:48kΩ 70°C[158°F]:34kΩ 80°C[176°F]:24kΩ 90°C[194°F]:17.5kΩ 100°C[212°F]:13.0kΩ 110°C[230°F]:9.8kΩ | 213⊤€ 393 | |

| Part name | Symbols (functions) | Notes | Usage | Specifications | Check method |
|-------------------|--|---|---|---|--|
| Thermis- tor | TH3 (Pipe temperature) | | Controls defrosting during heating operation | Degrees Celsius R ₀ = $15k\Omega$ R _{0/80} = 3460 | Resistance check |
| | TH7 (Outdoor tem- perature) | | Detects outdoor air temperature Controls fan operation | Rt = 15exp[3460 $(\frac{1}{273+t} - \frac{1}{273})]$ 0°C[32°F]:15k Ω | |
| | TH5 | | Fan operated on the 63LS and TH5 values. | 10°C[50°F] :9.7kΩ 20°C[68°F] :6.4kΩ | |
| | TH6 | | Controls defrosting during heating operation | 25°C[77°F] :5.3kΩ 30°C[86°F] :4.3kΩ 40°C[104°F] :3.1kΩ | |
| | TH15 Compressor shell bottom temperature | | Used to detect refrigerant over- charge | | |
| | THHS Inverter heat sink tem- perature | | Controls inverter cooling fan based on THHS temperature | Degrees Celsius $R_{50} = 17k\Omega$ $R_{25/120} = 4016$ $R_{t} = 17 \exp\{4016 \left(\frac{1}{273 + t} - \frac{1}{323}\right)\}$ | |
| | THBOX Control box internal tem- perature de- tection | | | 0°C[32°F] :161kΩ 10°C[50°F] :97kΩ 20°C[68°F] :60kΩ 25°C[77°F] :48kΩ 30°C[86°F] :39kΩ 40°C[104°F] :25kΩ | |
| Solenoid valve | SV1a Discharge- suction bypass | | High/low pressure bypass at start-up and stopping, and capacity control during low-load operation High-pressure-rise prevention | AC208 - 230V Open while being powered/ closed while not being pow- ered | Continuity check with a tester |
| | SV4a - SV4d Heat exchanger capacity con- trol | | Controls outdoor unit heat exchanger capacity | | |
| | SV5b Heat exchanger capacity con- trol | | Prevents high-pressure-rise Controls defrost cycle | AC208 - 230V Closed while being powered/ open while not being pow- ered | |
| | SV9 | | High-pressure-rise prevention | AC208 - 230V Open while being powered/ closed while not being pow- ered | |
| LEV | LEV5a,b | LEV5b is only on the P120, P144 models. | Evaporating temperature control | DC12V Opening of stepping motor driving valve 0-3000 pulses | Continuity check with a tester. Continuity between white and orange. Continuity between yellow, brown, and blue. White Orange MOOrange MILE White Sown Blue |
| 4-way valve | 21S4a 21S4b | P120 and P144 only | Changeover between heating and cooling | AC208-230V Dead: cooling cycle Live: heating cycle | Continuity check with a tester |

[3-3 Functions of the Major Components of Outdoor Unit]

| Part name | Symbols (functions) | Notes | Usage | Specifications | Check method |
|--------------------------|------------------------|---|---|---|--------------------------------|
| Fan mo- tor | FAN motor 1,2 | FAN motor 2 is only on the P120, P144 models. | Regulates the heat exchanger capacity by adjusting the operating frequency and operating the propeller fan based on the operating pressure. | AC380-460V, 920W | |
| Crank- case heater | CH11 | | Heat the compressor shell to make liquid refrigerant in the compressor evaporate. | P72, P96 AC230V, 35W P120,P144 AC240V, 45W | Continuity check with a tester |


3 Major Components, Their Functions and Refrigerant Circuits

3-4 Functions of the Major Components of Indoor Unit


| Part Name | Symbol (functions) | Notes | Usage | Specification | Check method |
|--------------------------------|--|-------|--|---|--|
| Linear expan- sion valve | LEV | | Adjusts superheat at the indoor heat exchanger outlet during cooling Adjusts subcool at the heat exchanger outlet of the indoor unit during cooling | DC12V Opening of stepping motor driving valve 0-(1800) puls- es | Continuity check with a tester. Continuity between white, red, and orange. Continuity between yellow, brown, and blue. White Market Ma |
| Thermis- tor | TH1 (Suction air temperature) | | Indoor unit control (Thermo) | R ₀ =15kΩ R ₀ / ₈ 0=3460 | Resistance check |
| | TH2 (Pipe tem- perature) | | Indoor unit control (Frost prevention, Hot adjust) LEV control during heating operation (subcool detection). | Rt = 15exp{3460(\frac{1}{273+t} - \frac{1}{273})} 0°C [32°F]:15kohm 10°C [50°F]:9.7kohm 20°C [68°F]:6.4kohm 25°C [77°F]:5.3kohm 30°C [86°F]:4.3kohm 40°C [104°F]:3.1kohm | |
| | TH3 (Gas pipe temperature) | | LEV control during cooling operation (superheat detection) | | |
| | TH4 Outdoor air temperature) | | Indoor unit control (Thermo) | | |
| | Temperature sensor (In- door air tem- perature) | | Indoor unit control (Thermo) | | |

3-5 External Appearance and Refrigerant Circuit Components of BC Controller


- 1. CMB-P O NU-J1/2, JA1/2, KA1/2
- (1) Front




(2) Rear view <J1/2 type>



(3) Rear view <JA1/2 type>




(4) Rear view <KA1/2 type>




2. CMB-P \cap NU-KB1/2

(1) Front




(2) Rear view




3-6 BC Controller Refrigerant Circuit Diagrams


(1) CMB-P104, 106, 108, 1012, P1016NU-J1/2




(2) CMB-P108, 1012, P1016NU-JA1/2 (main)



(3) CMB-P1016NU-KA1/2 (main)



(4) CMB-P104, 108NU-KB1/2 (sub)



3 Major Components, Their Functions and Refrigerant Circuits

3-7 Functions of the Major Components of BC Controller

(1) J type

| Part name | Symbols (functions) | Part code | Usage | Specifications | Check method |
|-----------------|---|--------------|--|--|-------------------------|
| Pressure sensor | PS1 (High pressure side) | | Detects high pressure LEV control | PS1 | |
| | PS3 (Intermediate pressure) | | Detects intermediate pressure LEV control | Con- nector Pressure [MPa] =1.38 x Vout [V]-0.69 Pressure [psi] =(1.38 x Vout [V] - 0.69) x 145 1 GND (Black) Vout (White) Voc (DC5V) (Red) | |
| Thermistor | TH11 (Liquid inlet tempera- ture) | | LEV control (Liquid level control) | $R_0 = 15k\Omega$ $R_{0/80} = 3460$ $R_1 = 15 \exp\{3460 \left(\frac{1}{273 + t} - \frac{1}{273}\right)\}$ | |
| | TH12 (Bypass outlet tem- perature) | | LEV control (Superheat) | 0°C[32°F] : 15 kΩ 10°C[50°F] :9.7 kΩ 20°C[68°F] :6.4 kΩ 25°C[77°F] :5.3 kΩ 30°C[86°F] :4.3 kΩ 40°C[104°F] :3.1 kΩ | |
| | TH15 (Bypass in- let tempera- ture) | | LEV control (Superheat) | | |
| | TH16 (Liquid re- frigerant tempera- ture) | | LEV control (Subcool) | | |
| Solenoid valve | SVA | | Provides refrigerant to indoor unit in cooling operation | AC208-230V Open while being powered/ | Continuity check with a |
| | SVB | | Provides refrigerant to indoor unit in heating operation | closed while not being powered | tester |
| | SVC | | Provides refrigerant to indoor unit in cooling operation | | |
| LEV | LEV1 | | Liquid level control | DC12V | Same as |
| | LEV3 | | Pressure differential control | Opening of a valve driven by a stepping motor 41-3000 pulses | indoor LEV |

(2) JA type

| Part name | Symbols (functions) | Part code | Usage | Specifications | Check method |
|--------------------|---|--------------|--|---|-------------------------|
| Pressure sensor | PS1 (High pressure side) | | Detects high pressure LEV control | PS1 Pressure O-4.15 MPa [601psi] Vout 0.5-3.5V 1.2.3 0.071V/0.098 MPa [14psi] Pressure [MPa] O-4.15 MPa [14psi] O-4.15 | |
| | PS3 (Intermediate pressure) | | Detects intermediate pressure LEV control | Connector | |
| Thermistor | TH11 (Liquid inlet tempera- ture) | | LEV control (Liquid level control) | R ₀ = 15kΩ R _{0/80} = 3460 R _t = 15 exp{3460 $(\frac{1}{273 + t} - \frac{1}{273})$ } | |
| | TH12 (Bypass outlet tem- perature) | | LEV control (Superheat) | 0°C[32°F] : 15 kΩ 10°C[50°F] :9.7 kΩ 20°C[68°F] :6.4 kΩ 25°C[77°F] :5.3 kΩ | |
| | TH15 (Bypass in- let tempera- ture) | | LEV control (Superheat) | 30°C[86°F] :4.3 kΩ 40°C[104°F] :3.1 kΩ | |
| | TH16 (Liquid re- frigerant tempera- ture) | | LEV control (Subcool) | | |
| Solenoid valve | SVM1 | | Opens during cooling and de- frost modes | AC208-230V Open while being powered/ | Continuity check with a |
| | SVM1b | | Opens during cooling and de- frost modes | closed while not being pow- ered | tester |
| | SVA | | Provides refrigerant to indoor unit in cooling operation | | |
| | SVB | | Provides refrigerant to indoor unit in heating operation | | |
| | SVC | | Provides refrigerant to indoor unit in cooling operation | | |
| LEV | LEV1 | | Liquid level control | DC12V | Same as |
| | LEV3 | | Pressure differential control | Opening of a valve driven by a stepping motor | indoor LEV |
| | LEV4 | | 3) Subcool control | 41 - 3000 pulses | |

(3) KA type

| | ı | 1 | | T | ı |
|--------------------|---|--------------|--|---|--------------------------------|
| Part name | Symbols (functions) | Part code | Usage | Specifications | Check method |
| Pressure sensor | PS1 (High pressure side) | | Detects high pressure LEV control | PS1 | |
| | PS3 (Intermediate pressure) | | Detects intermediate pressure LEV control | | |
| Thermistor | TH11 (Liquid inlet tempera- ture) | | LEV control (Liquid level control) | $R_0 = 15k\Omega$ $R_{0/80} = 3460$ $R_1 = 15 exp[3460 (\frac{1}{273 + t} - \frac{1}{273})]$ $0^{\circ}C[32^{\circ}F] : 15 k\Omega$ $10^{\circ}C[50^{\circ}F] : 9.7 k\Omega$ $20^{\circ}C[68^{\circ}F] : 6.4 k\Omega$ $25^{\circ}C[77^{\circ}F] : 5.3 k\Omega$ $30^{\circ}C[86^{\circ}F] : 4.3 k\Omega$ $40^{\circ}C[104^{\circ}F] : 3.1 k\Omega$ | |
| | TH12 (Bypass outlet tem- perature) | | LEV control (Superheat) | | |
| | TH15 (Bypass in- let tempera- ture) | | LEV control (Superheat) | | |
| | TH16 (Liquid re- frigerant tempera- ture) | | LEV control (Subcool) | | |
| Solenoid valve | SVM1 | | Opens during cooling and de- frost modes | AC208-230V Open while being powered/ closed while not being pow- ered | Continuity check with a tester |
| | SVM1b | | Opens during cooling and de- frost modes | | |
| | SVA | | Provides refrigerant to indoor unit in cooling operation | | |
| | SVB | | Provides refrigerant to indoor unit in heating operation | | |
| | SVC | | Provides refrigerant to indoor unit in cooling operation | | |
| LEV | LEV1 | | Liquid level control Pressure differential control Subcool control | DC12V Opening of a valve driven by a stepping motor 41 - 3000 pulses | Same as indoor LEV |
| | LEV3 | | | | |
| | LEV4 | | | | |

(4) KB type

| Part name | Symbols (functions) | Part code | Usage | Specifications | Check method |
|--------------------|---|--------------|--|--|--------------------------------------|
| Pressure sensor | PS3 (Intermediate pressure) | | Detects intermediate pressure LEV control | Pressure [0-4.15 MPa [601psi] Vout 0.5-3.5V 0.071V/0.098 MPa [14psi] Pressure [MPa] = 1.38 x Vout [V]-0.69 Pressure [psi] = (1.38 x Vout [V]-0.69) x 145 | |
| Thermistor | TH12 (Bypass outlet tem- perature) | | LEV control (Superheat) | R ₀ = 15kΩ R _{0/80} = 3460 R _t = 15exp{3460 $(\frac{1}{273+t} - \frac{1}{273})$ } | |
| | TH15 (Bypass in- let tempera- ture) | | LEV control (Superheat) | 0°C[32°F] : 15 kΩ 10°C[50°F] :9.7 kΩ 20°C[68°F] :6.4 kΩ 25°C[77°F] :5.3 kΩ | |
| | TH16 (Liquid re- frigerant tempera- ture) | | LEV control (Subcool) | 30°C[86°F] :4.3 kΩ 40°C[104°F] :3.1 kΩ | |
| Solenoid valve | SVA | | Provides refrigerant to indoor unit in cooling operation | AC208-230V Open while being powered/ | Continuity check with a tester |
| | SVB | | Provides refrigerant to indoor unit in heating operation | closed while not being pow- ered | |
| | SVC | | Provides refrigerant to indoor unit in cooling operation | | |
| LEV | LEV3 | | Pressure differential control | DC12V Opening of a valve driven by a stepping motor 0-2000 pulses | Same as indoor LEV |

Chapter 4 Electrical Components and Wiring Diagrams

| 4-1 | Outdoor Unit Circuit Board Arrangement | 97 |
|-------|---|-----|
| 4-1-1 | Outdoor Unit Control Box (Main box) | |
| 4-1-2 | Transformer Box | 98 |
| 4-1-3 | Outdoor Unit Control Box (Sub box) | 99 |
| 4-2 | Outdoor Unit Circuit Board Components | 101 |
| 4-2-1 | Control Board | 101 |
| 4-2-2 | M-NET Board (Transmission Power Supply Board) | 102 |
| 4-2-3 | INV Board | 103 |
| 4-2-4 | Fan Board | 104 |
| 4-2-5 | Noise Filter | 105 |
| 4-3 | Outdoor Unit Electrical Wiring Diagrams | 106 |
| 4-4 | Transmission Booster Electrical Wiring Diagrams | 108 |
| 4-5 | BC Controller Circuit Board Arrangement | 109 |
| 4-5-1 | BC Controller Control Box | 109 |
| 4-6 | BC Controller Circuit Board Components | 110 |
| 4-6-1 | BC Board | |
| 4-6-2 | Four-Relay Board | 111 |
| 4-6-3 | Ten-Relay Board | 111 |
| 4-7 | BC Controller Electrical Wiring Diagrams | 112 |

4-1 Outdoor Unit Circuit Board Arrangement


4-1-1 Outdoor Unit Control Box (Main box)

<HIGH VOLTAGE WARNING>



- · Control box houses high-voltage parts.
- When opening or closing the front panel of the control box, do not let it come into contact with any of the internal components.
- Before inspecting the inside of the control box, turn off the power, keep the unit off for at least 10 minutes, and confirm that the voltage between FT-P and FT-N on INV Board has dropped to DC20V or less. (It takes about 10 minutes to discharge electricity after the power supply is turned off.)

1. PURY-P72, P96, P120, P144ZKMU




Note

- Exercise caution not to damage the bottom and the front panel of the control box. Damage to these parts affect the waterproof and dust proof properties of the control box and may result in damage to its internal components.
- Faston terminals have a locking function. Make sure the cable heads are securely locked in place. Press the tab on the terminals to remove them.
- Control box houses high temperature parts. Be well careful even after turning off the power source.
- 4) Before beginning service work, disconnect the fan board connector (CNINV) or the connectors (CN01 and CN11) on the INV board. To plug or unplug connectors, check that the outdoor unit fan is not rotating and that the voltage of capacitor in the main circuit is 20 VDC or below. The capacitor may collect a charge and cause an electric shock when the outdoor unit fan rotates in windy conditions. Refer to the wiring nameplate for details.
- 5) To connect wiring to TB7, check that the voltage is 20 VDC or below.
- 6) When the service work is finished, reconnect the connector (CNINV) on the fan board and the connectors (CN01 and CN11) on the INV board
- 7) Before inspecting the inside of the control box, turn off the power, keep the unit off for at least 10 minutes, and confirm that the voltage between FT-P and FT-N on INV Board has dropped to DC20V or less. (It takes about 10 minutes to discharge electricity after the power supply is turned off.)
- 8) When the power is turned on, the heater is energized even while the compressor is not operating. Before turning on the power, disconnect all power supply wires from the compressor terminal block, and measure the insulation resistance of the compressor. Check the compressor for a ground fault. If the insulation resistance is 1.0 MΩ or below, connect all power supply wires to the compressor and turn on the power to the outdoor unit. The liquid refrigerant in the compressor will evaporate by energizing the heater.


4-1-2 Transformer Box

1. PURY-P120, P144ZKMU



4-1-3 Outdoor Unit Control Box (Sub box)


1. PURY-P72, P196ZKMU



Note

- 1) Handle the sub box with care. If the front or the bottom panel becomes damaged, water or dust may enter the sub box, damaging its internal parts.
- 2) Before beginning service work, disconnect the fan board connector (CNINV) or the connectors (CN01 and CN11) on the INV board. To plug or unplug connectors, check that the outdoor unit fan is not rotating and that the voltage of capacitor in the main circuit is 20 VDC or below. The capacitor may collect a charge and cause an electric shock when the outdoor unit fan rotates in windy conditions.
- 3) When the service work is finished, reconnect the connector (CNINV) on the fan board and the connectors (CN01 and CN11) on the INV board.
- 4) Faston terminals have a locking function. Make sure the cable heads are securely locked in place. Press the tab on the terminals to remove them.
- 5) Before inspecting the inside of the control box, turn off the power, keep the unit off for at least 10 minutes, and confirm that the voltage between FT-P and FT-N on INV Board has dropped to DC20V or less. (It takes about 10 minutes to discharge electricity after the power supply is turned off.)
- 6) Control box houses high temperature parts. Be well careful even after turning off the power source.

2. PURY-P120, P144ZKMU




Note

- 1) Handle the sub box with care. If the front or the bottom panel becomes damaged, water or dust may enter the sub box, damaging its internal parts.
- 2) Before beginning service work, disconnect the fan board connector (CNINV) or the connectors (CN01 and CN11) on the INV board. To plug or unplug connectors, check that the outdoor unit fan is not rotating and that the voltage of capacitor in the main circuit is 20 VDC or below. The capacitor may collect a charge and cause an electric shock when the outdoor unit fan rotates in windy conditions.
- 3) When the service work is finished, reconnect the connector (CNINV) on the fan board and the connectors (CN01 and CN11) on the INV board.
- 4) Faston terminals have a locking function. Make sure the cable heads are securely locked in place. Press the tab on the terminals to remove them.
- 5) Before inspecting the inside of the control box, turn off the power, keep the unit off for at least 10 minutes, and confirm that the voltage between FT-P and FT-N on INV Board has dropped to DC20V or less. (It takes about 10 minutes to discharge electricity after the power supply is turned off.)
- 6) Control box houses high temperature parts. Be well careful even after turning off the power source.


4-2 Outdoor Unit Circuit Board Components

4-2-1 Control Board




*For information about the display of SW4 function settings, refer to the following page(s). [5-1-1 Outdoor Unit Switch Functions and Factory Settings](page 123)

4-2-2 M-NET Board (Transmission Power Supply Board)



4-2-3 INV Board




Note |

- 1) Before inspecting the inside of the control box, turn off the power, keep the unit off for at least 10 minutes, and confirm that the voltage between FT-P and FT-N on INV Board has dropped to DC20V or less.

 (It takes about 10 minutes to discharge electricity after the power supply is turned off.)
- 2) Faston terminals have a locking function. Make sure the cable heads are securely locked in place. Press the tab on the terminals to remove them.
- 3) Control box houses high temperature parts. Be well careful even after turning off the power source.
- 4) Before beginning service work, disconnect the fan board connector (CNINV) or the connectors (CN01 and CN11) on the INV board. To plug or unplug connectors, check that the outdoor unit fan is not rotating and that the voltage of capacitor in the main circuit is 20 VDC or below. The capacitor may collect a charge and cause an electric shock when the outdoor unit fan rotates in windy conditions. Refer to the wiring nameplate for details.
- 5) To connect wiring to TB7, check that the voltage is 20 VDC or below.
- 6) When the service work is finished, reconnect the connector (CNINV) on the fan board and the connectors (CN01 and CN11) on the INV board.
- 7) When the power is turned on, the heater is energized even while the compressor is not operating. Before turning on the power, disconnect all power supply wires from the compressor terminal block, and measure the insulation resistance of the compressor. Check the compressor for a ground fault. If the insulation resistance is 1.0 MΩ or below, connect all power supply wires to the compressor and turn on the power to the outdoor unit. The liquid refrigerant in the compressor will evaporate by energizing the heater.

4-2-4 Fan Board

(1) PURY-P72, P96, P120, P144ZKMU




Note

- 1) Before inspecting the inside of the control box, turn off the power, keep the unit off for at least 10 minutes, and confirm that the voltage between FT-P and FT-N on INV Board has dropped to DC20V or less. (It takes about 10 minutes to discharge electricity after the power supply is turned off.)
- 2) Control box houses high temperature parts. Be well careful even after turning off the power source.
- 3) Before beginning service work, disconnect the fan board connector (CNINV) or the connectors (CN01 and CN11) on the INV board. To plug or unplug connectors, check that the outdoor unit fan is not rotating and that the voltage of capacitor in the main circuit is 20 VDC or below. The capacitor may collect a charge and cause an electric shock when the outdoor unit fan rotates in windy conditions. Refer to the wiring nameplate for details.
- 4) To connect wiring to TB7, check that the voltage is 20 VDC or below.
- 5) When the service work is finished, reconnect the connector (CNINV) on the fan board and the connectors (CN01 and CN11) on the INV board.


4-2-5 Noise Filter

(1) PURY-P72, P96, P120, P144ZKMU




4-3 Outdoor Unit Electrical Wiring Diagrams


(1) PURY-P72, P96ZKMU



(2) PURY-P120, P144ZKMU




4-4 Transmission Booster Electrical Wiring Diagrams



4-5 BC Controller Circuit Board Arrangement


4-5-1 BC Controller Control Box


1. CMB-P1016V-J1/2, JA1/2, KA1/2




4-6 BC Controller Circuit Board Components

4-6-1 BC Board






4-6-2 Four-Relay Board




4-6-3 Ten-Relay Board



4-7 BC Controller Electrical Wiring Diagrams

(1) CMB-P104NU-J1/2 model




Note 1. TB02 is transmission terminal block.

Never connect power line to it.


2. The initial set values of switch on CONT. B are as follows.

SW1:0


SW2:0




(2) CMB-P106NU-J1/2 model



(3) CMB-P108NU-J1/2 model




(4) CMB-P1012, P1016NU-J1/2 models



Note 1. TB02 is transmission terminal block.

Never connect power line to it.
The initial set values of switch on CONT. B are as follows.
SW1:0
SW2:0

(5) CMB-P108NU-JA1/2 model



Note 1. TB02 is transmission terminal block.


Never connect power line to it.

2. The initial set values of switch on CONT. B are as follows.

SW1:0

SW2:0

(6) CMB-P1012, P1016NU-JA1/2 models




Note 1. TB02 is transmission terminal block.

Never connect power line to it.

2. The initial set values of switch on CONT. B are as follows.

(7) CMB-P1016NU-KA1/2 model




Never connect power line to it.

The initial set values of switch on CONT. B are as follows. ۲,


SW2:0

SW1:0

(8) CMB-P104NU-KB1/2 model



(9) CMB-P108NU-KB1/2 model



Chapter 5 Control

| 5-1 | Dipswitch Functions and Factory Settings | 123 |
|--------|---|-----|
| 5-1-1 | Outdoor Unit Switch Functions and Factory Settings | 123 |
| 5-1-2 | Indoor Unit Switch Functions and Factory Settings | 126 |
| 5-1-3 | Remote Controller Switch Functions and Factory Settings | 127 |
| 5-1-4 | BC Controller Switch Settings | 129 |
| 5-2 | Outdoor Unit Control | 130 |
| 5-2-1 | Overview | 130 |
| 5-2-2 | Rotation Control | 130 |
| 5-2-3 | Initial Control | 130 |
| 5-2-4 | Startup Control | 130 |
| 5-2-5 | Refrigerant Bypass Control | 131 |
| 5-2-6 | Frequency Control | 132 |
| 5-2-7 | Defrost Operation Control | 133 |
| 5-2-8 | Refrigerant Recovery Control | 135 |
| 5-2-9 | Outdoor Unit Fan Control | 136 |
| 5-2-10 | Evaporation Temperature Control (Expansion Valves <lev5a, b="">)</lev5a,> | 137 |
| 5-2-11 | Control at Initial Startup | 137 |
| 5-2-12 | Emergency Operation Mode | 139 |
| 5-2-13 | Unit Control Scheme | 141 |
| 5-2-14 | Refrigerant Circuits and Refrigerant Cycle Diagrams | 142 |
| 5-2-15 | Operation Mode | 143 |
| 5-2-16 | Demand Control | 144 |
| 5-3 | BC Controller Control | 145 |
| 5-4 | Operation Flowcharts | 146 |
| 5-4-1 | Operation Sequence Flowchart | 146 |
| 5-4-2 | Actions Performed in Different Modes | 149 |

5-1 Dipswitch Functions and Factory Settings

5-1-1 Outdoor Unit Switch Functions and Factory Settings

(1) Control board

| Switch | | Function | Function according | ng to switch setting | Switch setting timing | Units that require | | | |
|--------|--------|---|--|---|------------------------|----------------------------|--|--|--|
| Sw | /ILCIT | FullClion | OFF | ON | Switch setting timing | switch setting (Note 2) | | | |
| SWU | 1-2 | Unit address set- ting | Set to 00 or 51-100 | with the dial switch | Before power on | С | | | |
| | 1 | Centralized control switch | Without connection to the centralized controller | With connection to the centralized controller | Before power on | В | | | |
| | 2 | Deletion of connection information | Normal control | Deletion | Before power on | А | | | |
| SW5 | 3 | - | | | | - | | | |
| | 4 | - | | | | - | | | |
| | 5 | - | | Preset before shipment | | | | | |
| | 6 | - | | - | | | | | |
| | 7 | - | | - | | | | | |
| | 4 | Model setting (out- door unit/high static pressure setting) | Normal static pressure | High static pres- sure | Before power on | С | | | |
| | 5 | Model setting (out- door unit/high static pressure setting) | High (60 Pa) | High (30 Pa) | Before power on | С | | | |
| | 6 | - | | Preset before shipme | ent | - | | | |
| SW6 | 7 | Performance-prior- ity/low-noise mode setting | Performance-pri- ority mode (Note 3) | Quiet-priority mode | Anytime after power on | A | | | |
| | 8 | Low-noise mode/ step demand switching | Low-noise mode (Note 4) | Step demand mode | Before power on | С | | | |
| | 10 | Self-diagnosis/ function setting No. display setting | Self-diagnosis monitor display | Function setting No. display | Anytime after power on | С | | | |

Note

- 1) Unless otherwise specified, leave the switch to OFF where indicated by "-" or where the cells are blank, which may be set to OFF for a reason.
- 2) A: Only the switch on OC needs to be set for the setting to be effective.
 - B: The switches on both the OC and OS need to be set to the same seeing for the setting to be effective.
 - C: The switches on both the OC and OS need to be set.
- 3) When set to the performance-priority mode, the low-noise mode will be terminated, and the units will operate in the normal mode.
 - Cooling: Ambient temperature or the high pressure is high.
 - Heating: Ambient temperature or the low pressure is low. [2-4-7 Various Control Methods Using the Signal Input/Output Connector on Outdoor Unit](page 31)
- 4) Operation noise is reduced by controlling the compressor frequencies and the rotation speed of the outdoor unit fans. Requires CN3D to be set.[2-4-7 Various Control Methods Using the Signal Input/Output Connector on Outdoor Unit](page 31)
- 5) Settings in the shaded areas are factory settings.

(2) Additional dipswitch settings at time of shipment

| | Switch | | | | Function according | ng to switch setting | | Units that require |
|------------------------------|--------------------------------------|------------|--|---|---|---|--|--------------------|
| Switch | | Function | | OFF (LED3 Unlit) | ON (LED3 Lit) | Switch setting timing | switch setting (Note 2) | |
| SW4 SW6-10: OFF | W6-10: 1-10 Sell-diagnosis/operation | | Refer to the following p Indicators on the Outo Board](page 315) | page(s). [9 LED Status door Unit Circuit | Anytime after power on | С | | |
| | No.769 | 1000000011 | Test run mode: ON/0 | OFF | Stops all ICs | Sends a test-run sig- nal to all IC | Anytime after power on | А |
| | No.832 | 0000001011 | Cumulative compres operation time deletion | sor on | Retained | Cleared | Anytime after power on (OFF→ON) | С |
| | No.896 | 0000000111 | Clearance of error history | oc os | Retained (IC/OC) Retained (OS) | Deleted (IC/OC) Deleted (OS) | Anytime after power on (OFF→ON) | С |
| | No.897 | 1000000111 | High sensible heat o | | Normal control | High sensible heat operation mode | After being energized and while the compressor is stopped | A |
| | No.912 | 0000100111 | Pump down function | | Normal control | Pump down opera- | After being energized and while the compressor is stopped | А |
| | No.913 | 1000100111 | Forced defrost (Note | Forced defrost (Note 3) | | Forced defrost starts | 10 minutes after the completion of de- frost operation (OFF→ON) or 10 minutes after compressor start-up (OFF→ON) | D |
| | No.915 | 1100100111 | Defrost start temperature (Note 3) | | P72, P96: -10°C [14°F] P120, P144: -8°C [18°F] | -5°C [23°F] | Anytime after power on | В |
| SW4 1-10 | No.916 | 0010100111 | Defrost end temperature (Note 3) | | 7°C [45°F] | 12°C [54°F] | Anytime after power on | В |
| [0:OFF, 1:ON] (Note 1) | No.918 | 0110100111 | Changes the defrost timer setting (Note 3) | | 50 minutes | 90 minutes | Anytime after power on (OFF→ON) | В |
| SW6-10:ON | No.921 | 1001100111 | Temperature unit dis | play | °C | °F | Anytime after power on | С |
| | No.922 | 0101100111 | Refrigerant amount a ment | Refrigerant amount adjust- ment | | Refrigerant amount adjust mode | Anytime after power on (except during initial startup/becomes ineffective 60 minutes after compressor started up. | А |
| | No.932 | 0010010111 | Heating backup | | Disabled | Enabled | Anytime after power on | Α |
| | No.933 | 1010010111 | Snow sensor setting | | Effective only when TH7 ≤ 5 is true or the snow sensor contact input is on. | Effective when TH7 ≤ 5 is true | Anytime after power on | С |
| | No.934 | 0110010111 | Snow sensor setting | Snow sensor setting | | Refrigerant recovery/Evacuation (two-way valve/LEV1 open) | Anytime after power on | С |
| | No.935 | 1110010111 | High heating power (outside temperature) | at low | Ineffective | Effective | Anytime after power on | А |
| | No.972 | 0011001111 | Automatic cooling/he mode (IC with the sm address) | eating nallest | Normal control | Automatic cooling/ heating mode | After being energized and while the compressor is stopped | А |
| | No.982 | 0110101111 | Target evaporation to perature setting | em- | Depends on the setting 964 (Note 4) | g combination with No. | Anytime after power on | А |

Note

To change the settings, set SW6-10 to ON, set SW4, and press and hold SWP01 for 2 seconds or longer (OFF→ON).

LED3 will light up when the switch setting is ON, and lights off when OFF.

Use the LED3 display to confirm that the settings are properly made.

The settings will need to be set again when the control board is replaced. Write down the settings on the electrical wiring drawing label.

- 2) A: OC: Only the switch on OC needs to be set for the setting to be effective.
 - B: OC: The switches on both the OC and OS need to be set to the same seeing for the setting to be effective.
 - C: OC: The switches on both the OC and OS need to be set.
 - D: OC: The switch on either the OC or OS needs to be set.
- 3) For details, refer to the following page(s).[5-2-7 Defrost Operation Control](page 133)
- 4) Target evaporating temperature will change as shown in the table below each time SW4(982) is turned ON and OFF.

| SW4(982) | \bigcirc OFF \rightarrow ON \rightarrow OFF \rightarrow ON \rightarrow OFF \rightarrow ON |
|--------------------------------|---|
| Target evaporating temperature | $ \begin{array}{cccccccccccccccccccccccccccccccccccc$ |

- 5) Unless otherwise specified, leave the switch to OFF where indicated by "-" or where the cells are blank, which may be set to OFF for a reason.
- The settings that are configured with SW4 (SW6-10: ON) will automatically be stored on the indoor units that support the new function*. The stored settings will automatically be restored when the outdoor unit control board is replaced.

If none of the connected indoor units supports the new function, no configuration information will be saved. If this is the case, manually record the settings configuration on the control box panel.

- *The new function is supported on most units that are manufactured in April of 2012 and later. Depending on the model, this function may be added on later date. Ask your dealer for further details.

 7) Settings in the shaded areas are factory settings.

(3) INV board

Functions are switched with the following connector.

| Connector | Function | Function according to connector tor | | Setting timing | |
|--------------------------------------|--|-------------------------------------|--|------------------------|--|
| | | Enabled | Disabled | | |
| CN6 short- circuit con- nector | Enabling/disabling the following error detection functions; ACCT sensor failure (5301 Detail No. 115) ACCT sensor circuit failure (5301 Detail No.117) IPM open/ACCT erroneous wiring (5301 Detail No. 119) Detection of ACCT erroneous wiring (5301 Detail No. 120) | Error detection enabled | Error detection disable (No load operation is possible.) | Anytime after power on | |

Note

- •CN6 short-circuit connector is mated with the mating connector.
- •Leave the short-circuit connector on the mating connector during normal operation to enable error detection and protect the equipment from damage.

(4) Fan board

| Sw | vitch | Function | | rding to switch ting | Switch setting timing |
|-----|---|--|---------------------------------|--------------------------------|------------------------|
| | | | OFF | ON | |
| SW1 | SW1 1 Enabling/Disabling no-load operation No-load operation will continue for approximately 30 seconds, and then the unit will come to an abnormal stop. Refer to the section on "Inverter" for details. [8-10-8 Checking the Fan Inverter for Damage at No Load](page 289) | | No-load oper- ation disabled | No-load oper- ation enabled | Anytime after power on |
| | 2 | - | - | - | - |
| | 3 | - | - | - | - |
| | 4 | - | - | - | - |
| | 5 Address setting (P120 and P144: Bottom fan board inside the sub box) | | 0 | 5 | Before power on |
| | 6 | Address setting (P120 and P144: Top fan board inside the sub box) | 0 | 6 | Before power on |

Note

- •Only the addresses are preset before shipment (All other switches are set to OFF.) Unless otherwise specified, leave the switch to OFF where indicated by "-," which may be set to OFF for a reason.
- •PURY-P72 and P96ZKMU models: Set SW1-5 on the fan control board on the sub box side to ON. Set the address to 5. PURY-P120 and P144ZKMU models: Bottom fan control board in the sub box: Set SW1-5 to ON, and set the address to 5. Top fan control board in the sub box: Set SW1-6 to ON, and set the address to 6.
- •Leave SW1-1 to OFF during normal operation. Setting this switch to ON will disable the error detection function and may result in equipment damage.

5-1-2 **Indoor Unit Switch Functions and Factory Settings**

(1) Dipswitches

1) SW1,3

| Swi | tch | Function | Function accordin | g to switch setting | Switch setting timing | Notes | |
|-----|-----|---|--------------------------------|--|---------------------------|--|--|
| | | | OFF ON | | | Notes | |
| | 1 | Room temperature detection position | Indoor unit inlet | Built-in sensor on the remote controller | | Set to ON (built-in sensor on the remote controller) on All Fresh (PEFY-VMH-F) model units | |
| | 2 | Clogged filter detection | Not available | Available | | | |
| | 3 | Filter check reminder time setting | 100h | 2500h | | | |
| | 4 | Outside air intake | Disabled | Enabled | | Always set to OFF on PKFY-AM model units | |
| | 5 | Remote display option | Fan output | Thermo-ON signal | | | |
| SW1 | 6 | Humidifier control | During heating operation | Always on while in the heating mode | | | |
| | 7 | Fan speed setting for Heating Thermo-OFF | Very Low | Low | | | |
| | 7 | Forced heating operation at OA temp of 5°C or below | Not available | Available | | Applicable to All Fresh model units (PEFY-VMH-F) only | |
| | • | Fan speed setting for Heating Thermo-OFF | According to the SW1-7 setting | Preset speed | | | |
| | 8 | - | - | - | While the unit is stopped | Applicable to All Fresh model units (PEFY-VMH-F) only | |
| | 9 | Self-recovery after power failure | Disabled | Enabled | (Remote controller OFF) | | |
| | 10 | Power source start-stop | Disabled | Enabled | | | |
| | 1 | Unit model selection | Heat pump | Cooling only | | | |
| | 2 | Louver | Not available | Available | | | |
| | 3 | Vane | Not available | Available | | | |
| | 4 | Vane swing function | Not available | Available | | Always set to OFF on PKFY-VAM model units | |
| SW3 | 5 | - | - | - | | | |
| | 6 | Vane angle limit setting for cooling operation | Downblow B,C | Horizontal | | Always set to Downblow B or C on PKFY-VAM model units | |
| | | Initial vane position | Enabled | Disabled | | PLFY-VLMD model only | |
| | 7 | Automatic LEV value conversion function | Not available Available | | | | |
| | 8 | Heating 4°C [7.2°F] up | Enabled | Disabled | | Set to ON on floor-standing (PFFY) type units | |
| | 9 | SHm setting | 2°C [3.6°F] | 5°C [9°F] | | The setting depends on the model and type. | |
| | 10 | SCm setting | 10°C [18°F] | 15°C [27°F] | | The setting depends on the model and type. | |

Note 1. Settings in the shaded areas are factory settings. (Refer to the table below for the factory setting of the switches whose factory settings are not indicated by the shaded cells.) Note 2. If both SW1-7 and SW1-8 are set to ON, the fan remains stopped during heating Thermo-OFF.

Note 3. By setting SW3-1, SW1-7, and SW1-8 to a certain configuration, the fan can be set to remain stopped during cooling Thermo-OFF. See the table below for details.

| S | Switch setting | | Fan speed durii | ng Thermo-OFF | |
|-------|----------------|-------|-----------------|---------------|------------------------|
| SW3-1 | SW1-7 | SW1-8 | Heating | Cooling | Cooling-only/heat pump |
| | OFF | OFF | Very Low | | |
| OFF | ON | OFF | Low | Preset speed | Heat pump |
| | OFF | ON | Preset speed | | |
| | ON | ON | Stop | | |
| | OFF | 055 | - | Preset speed | Olil- |
| ON | ON | OFF | - | i reset speed | Cooling-only |
| | OFF | ON | - | Stop | |
| | ON | ON | Stop | Stop | Heat pump |

Note 4. The settings that are configured from the remote controller will automatically be stored on the outdoor unit. The stored settings will automatically be restored when the indoor unit control board is replaced.

The switch setting may vary depending on the indoor unit's type. Refer to relevant Service Handbook for details.

(2) Address switch

Actual indoor unit address setting varies in different systems. Refer to the installation manual for the outdoor unit for details on how to make the address setting.

Each address is set with a combination of the settings for the 10's digit and 1's digit.


When setting the address to "3", set the 1's digit to 3, and the 10's digit to 0. When setting the address to "25", set the 1's digit to 5, and the 10's digit to 2.

To prevent incorrect temperature detection due to a build-up of warm air around the indoor unit, use the built-in temperature sensor on the remote controller (SW1-1) instead of the one on the indoor unit inlet thermistor.

5-1-3 Remote Controller Switch Functions and Factory Settings

(1) MA simple remote controller (PAC-YT53CRAU)

There are switches on the back of the top case. Remote controller Main/Sub and other function settings are performed using these switches. Ordinarily, only change the Main/Sub setting of SW1. (The factory settings are ON for SW1, 2, and 3 and OFF for SW4.)






The figure at left shows that the switches 1 through 5 are set to ON and 6 through 10 are set to OFF.

| SW No. | SW contents Main | ON | OFF | Comment | Switch setting timing |
|--------|---------------------------------------|---------|------------|---|-----------------------|
| 1 | Remote controller Main/Sub setting | Main | Sub | Set one of the two remote controllers at one group to "ON". | Before power on |
| 2 | Temperature display units setting | Celsius | Fahrenheit | When the temperature is displayed in [Fahrenheit], set to "OFF". | Before power on |
| 3 | Cooling/heating display in AUTO mode | Yes | No | When you do not want to display "Cooling" and "Heating" in the AUTO mode, set to "OFF". | Before power on |
| 4 | Indoor temperature display | Yes | No | When you want to display the indoor temperature, set to "ON". | Before power on |

Note

The MA remote controllers (PAR-CT01MA series, PAR-FS01MA series, PAR-4"x"MA series, or PAR-3"x"MA series ("x" represents 0 or later)) do not have the switches listed above. Refer to the installation manual for the function setting.

(2) ME remote controller (PAR-U01MEDU)



| | Address range | Address setting method |
|------------------------|---------------|--|
| Main remote controller | 101 to 150 | Address that equals the lowest address of the group plus 100 |
| Sub remote controller | 151 to 200 | Address that equals the lowest address of the group plus 150 |

| Rotary switch setting | Address |
|-----------------------|---|
| 01 to 99 | 101-199 with the 100's digit automatically set to 1 |
| 00 | 200 |

^{*} The factory setting for the rotary switches is 01.

Group information for indoor units and AHC units will be deleted, but the rest of the information will be retained.

Note

To set the address, turn the rotary switch with a precision slotted screwdriver [(-), 2.0 mm (1/16 in) (W)] to a torque of less than 19.6 N to avoid the damage to the rotary switches.

^{**} M-NET address can be changed with or without the power being applied to the controller.

The screen will jump to the [Start-up] screen.

5-1-4 BC Controller Switch Settings

| Su | vitch | Function | Function accordin | g to switch setting | Switch setting timing |
|-----|--------|---------------|--------------------------|---------------------|----------------------------------|
| 34 | VILCII | Function | OFF | ON | — Switch setting timing |
| | 1 | Model setting | R410A | - | Always leave this switch to OFF. |
| SW4 | 2 - 5 | - | - | - | - |
| 344 | 6 | No. of ports | 1 | 2 | Before being energized |
| | 7, 8 | - | - | - | - |
| | 1 - 6 | - | - | - | - |
| SW5 | 7 | Model setting | Refer to the table below | ٧. | Before being energized |
| | 8 | Model setting | Refer to the table below | ٧. | Before being energized |

Model setting

| | | SW5-8 | | |
|--------|-----|--------------|---------|--|
| | | OFF | ON | |
| SW5-7 | OFF | J type | | |
| 3443-7 | ON | JA (KA) type | KB type | |

5-2 Outdoor Unit Control

5-2-1 Overview

- •The outdoor units are designated as OC and OS in the order of capacity from large to small (if two or more units have the same capacity, in the order of address from small to large).
- •The setting of outdoor unit can be verified by using the self-diagnosis switch (SW4).

| SW4 (SW6-10:OFF) | Display | |
|------------------|--|--|
| ON | The unit is designated as the OC: "OC" appears on the display. The unit is designated as OS: "OS" appears on the display. | |



The figure at left shows that the switches 1 through 5 are set to ON and 6 through 10 are set to OFF.

- •The OC determines the operation mode and the control mode, and it also communicates with the indoor units.
- •The OS exercises autonomous distributed control (over defrost, error detection, and actuator control etc.) according to the operation/control mode signals that are sent from the OC.

5-2-2 Rotation Control

- •At the initial startup, outdoor units start up in the order of "OC and OS." When the cumulative operation time of the OC reaches two hours, the OS will start up before the OC at the next start up.
- •Startup sequence rotation is performed while all the indoor units are stopped. (Even after two hours of operation, startup sequence rotation is not performed while the compressor is in operation.)
- In a system with multiple outdoor units (OC and OS), when the integrated operation time of the unit in operation (either OC or OS) reaches one hour during a cooling operation at low outside temperature, that unit will stop and the other unit will go into operation.
- •For information about rotation control at initial startup, refer to the following page(s). [5-2-11 Control at Initial Startup](page 137)
- Performing startup sequence rotation does not change the basic operation of OC and OS. Only startup sequence is changed.
- •Startup sequence of the outdoor units can be checked with the self-diagnosis switch (SW4) on the OC.

| SW4 (SW6-10:OFF) | Display | |
|------------------|---|--|
| ON | •OC →OS: "OC" and the "OC" address appear alternately on the display. •OS →OC: "OS" and the "OS" address appear alternately on the display. | |



The figure at left shows that the switches 1 through 5 are set to ON and 6 through 10 are set to OFF.

5-2-3 Initial Control

- •When the power is turned on, the initial processing of the microcomputer is given top priority.
- •During the initial processing, control processing of the operation signal is suspended. (The control processing is resumed after the initial processing is completed. Initial processing involves data processing in the microcomputer and initial setting of each of the LEV opening. This process will take up to 5 minutes.)
- •During the initial processing, the LED monitor on the outdoor unit's control board displays S/W version → refrigerant type → Model and capacity → and communication address in turn every second.

5-2-4 Startup Control

- •The upper limit of frequency during the first 3 minutes of the operation is 50 Hz.
- •When the power is turned on, normal operation will start after the initial start-up mode (to be described later) has been completed (with a restriction on the frequency).
- •If the liquid refrigerant level in the accumulator before start is at the middle level or higher, the maximum compressor frequency for the first 6 minutes is 60 Hz.

5-2-5 Refrigerant Bypass Control

Bypass solenoid valves, which bypass the high- and low- pressure sides, perform the following functions.

(1) Bypass solenoid valve (SV1a) (ON = Open)

| Operation | SV1a | | |
|--|---|---|--|
| Operation | ON | OFF | |
| When starting-up the compressor of each outdoor unit | ON for 4 minutes. | | |
| After the restoration of thermo or 3 minutes after restart | ON for 4 minutes. | | |
| During cooling or heating operation with the compressor stopped | Always ON. Exception: OFF when 63HS1-63LS is 0.2MPa[29psi] or less | | |
| After the operation has stopped | ON for 3 minutes. Exception: OFF when 63HS1-63LS is 0.2MPa[29psi] or less | | |
| During defrost operation | ON | | |
| While the compressor is operating at the minimum frequency and when the low pressure (63LS) drops (3 or more minutes after compressor startup) | When low pressure (63LS) drops below 0.23MPa[33psi]. | When low pressure (63LS) exceeds 0.38MPa[55psi]. | |
| When high pressure (63HS1) rises | When 63HS1 exceeds 3.62MPa[525psi] | When 63HS1 is or below 3.43MPa[497psi] and 30 seconds have passed | |

(2) Bypass solenoid valve (SV9) (ON = Open)

| Operation | SV9 | | |
|---|--|---|--|
| Operation | ON | OFF | |
| When high pressure (63HS1) rises during the heating operation | When 63HS1 exceeds 3.50MPa [507psi] | When SV5b is ON and the pressure is 2.70MPa[391psi]or below | |
| Others | Always OFF | | |

(3) Bypass solenoid valve (SV5b) (ON = Closed)

| Operation | SV5b | | |
|--|--|---|--|
| Operation | ON (Closed) | OFF (Open) | |
| When high pressure (63HS1) rises during the heating operation | When the pressure is 2.70MPa [391psi] or below | When SV9 is ON and the pressure is 3.50MPa [507psi] or more | |
| At startup | ON (Closed) | | |
| During defrost cycle | OFF (Open) | | |
| When returning to normal operation after completion of the defrost cycle | OFF (Open) for 3 minutes and goes ON (Closed) | | |
| Others | Always ON (Closed) | | |

[•]On the module system, SV5b may open to balance the liquid refrigerant level depending on the TdSH values of both outdoor units. SV5b opens when TdSH is smaller, and closes when TdSH is larger. SV5b opens for maximum 3 minutes and then closes.

SV5b: ON (energized) = closed

[◆]TdSH = TH4 - Tc

5-2-6 Frequency Control

- •Depending on the capacity required, the frequency of the compressor is controlled to keep constant evaporation temperature (0°C [32°F] = 0.71 MPa [103 psi]) during cooling operation, and condensing temperature (49°C [120°F] = 2.88 MPa [418 psi]) during heating operation.
- •The table below summarizes the operating frequency ranges of the inverter compressor during normal operation.
- •The OS in the multiple-outdoor-unit system operates at the actual compressor frequency value that is calculated by the OS based on the preliminary compressor frequency value that the OC determines.

| Model | Frequency/cooling | | Frequency/heating | |
|------------|-------------------|------|-------------------|------|
| Wiodei | Max | Min | Max | Min |
| P72 model | 43Hz | 10Hz | 75Hz | 27Hz |
| P96 model | 62Hz | 10Hz | 79Hz | 27Hz |
| P120 model | 75Hz | 16Hz | 102Hz | 29Hz |
| P144 model | 87Hz | 16Hz | 107Hz | 29Hz |

Note

The maximum frequency during heating operation depends on the outside air temperature and the dipswitch settings.

(1) Pressure limit

The upper limit of high pressure (63HS1) is preset, and when it exceeds the upper limit, the frequency is decreased every 15 seconds.

The actuation pressure is when the high-pressure reading on 63HS1 is 3.58MPa[519psi].

(2) Discharge temperature limit

Discharge temperature (TH4) of the compressor in operation is monitored, and when it exceeds the upper limit, the frequency is decreased every minute.

Operating temperature is 115°C [239°F].

(3) Periodic frequency control

Frequency control other than the ones performed at start-up, upon status change, and for protection is called periodic frequency control (convergent control) and is performed in the following manner.

Periodic control cycle

Periodic control is performed after the following time has passed

- •30 seconds after either compressor start-up or the completion of defrost operation
- •30 seconds after frequency control based on discharge temperature or pressure limit

The amount of frequency change

The amount of frequency change is controlled to approximate the target value based on the evaporation temperature (Te) and condensing temperature (Tc).

5-2-7 Defrost Operation Control

(1) Starting the defrost operation

•The defrost cycle will start when all of the three conditions (outside temperature, cumulative compressor operation time, and pipe temperature) under <Condition 1>, <Condition 2>, or <Condition 3> are met.

| | Condition 1 | Condition 2 | Condition 3 |
|--------------------------------------|--|---|--|
| Outside temperature (TH7) | -5°C [23°F] or above | -5°C [23°F |] or below |
| Cumulative compressor operation time | 50 minutes or more 90 minutes or more if the defrost prohibit timer is set to 90. | | 250 minutes or more |
| Pipe temperature (TH6) | The pipe temperature has stayed below the temperatures in the table below (Note1) for three minutes. | The pipe temperature has stayed below the value obtained from the formula "Outside temperature (TH7) - 5°C [23°F]" for three minutes, or the 63LS reading has stayed below the value obtained from the formula "1.5 + 0.02 x (20+TH7)" for three minutes. | The pipe temperature has stayed below the temperatures in the table below (Note1) for three minutes. |

Note

1) Pipe temperature (TH6)

| | P72 | P96 | P120 | P144 |
|---------------|-------|-------|------|------|
| SW4 (915) OFF | -10°C | -10°C | -8°C | -8°C |
| SW4 (915) ON | -5°C | -5°C | -5°C | -5°C |

- •The defrost cycle will not start if other outdoor units are in the defrost cycle or until a minimum of 10 minutes have passed since the completion of the last defrost cycle.
- •If 10 minutes have passed since compressor startup or since the completion of a defrost cycle, a forced defrost cycle can be started by setting DIP SW4 (913) to ON.
- •Even if the defrost-prohibit timer is set to 90 minutes (or 150 minutes for "Condition 3" to be met), the actual defrost-prohibit time for the next defrost cycle is 50 minutes if the last defrost cycle took 12 minutes.
- •All units in the heating mode will simultaneously go into the defrost cycle in a system with multiple units.
- *Depending on the type of the connected indoor unit, etc., the next defrosting prohibition time may be 40 minutes.

(2) Defrost operation

| Outdoor unit | Compressor frequency | Model | Compressor frequency | | |
|---------------|------------------------------|--|---|--|--|
| | | P72 model | 79Hz | | |
| | | P96 model | 79Hz | | |
| | | P120, P144 models | 107Hz | | |
| | Outdoor unit fan | Stop | pped | | |
| | SV1a | ON (| open) | | |
| | SV5b | OFF (| (open) | | |
| | 21S4a, 21S4b | OFF | | | |
| | SV9 | OFF (closed) | | | |
| BC controller | LEV1 | J type: 3000, JA type | J type: 3000, JA type: 3000, KA type: 3000 | | |
| | LEV3 | J type: 3000, JA type: 3000, KA type: 3000, KB type: 60 (full closed) | | | |
| | LEV4 (JA and KA types only) | JA type: 3000, | KA type: 3000 | | |
| | SVM1 (JA and KA types only) | ON | | | |
| | SVM1b (JA and KA types only) | ON | | | |
| | SVB | OFF | | | |
| | SVA | | ndoor units in cooling Thermo-ON orts: OFF | | |

- •On the module system, both outdoor units start in the defrost mode regardless of the operation mode before the defrost operation.
- •The compressor frequency is fixed at 60Hz for 3 minutes.
- •The compressor frequency is fixed at 60Hz when the compressor bottom SH (TH15 Te) ≤ 10°C [18°F].
- •The compressor frequency is fixed at 60Hz when the compressor bottom SH (TH15 Te) ≤ 10°C [18°F]. And the defrost mode may continue even after 12 minutes.

(3) Stopping the defrost operation

- •The defrost cycle ends when 12 minutes have passed since the beginning of the cycle, or when the pipe temperatures (TH3 and TH6) have been continuously detected for 4 minutes (when SW4 (916) is set to OFF) or 2 minutes (when SW4 (916) is set to ON) that exceeds the values in the table below.
- •The defrost cycle will not end for two minutes once started unless one of the following conditions is met : Pipe temperature reaches 25°C [77°F] and SW4 (916) is set to OFF OR α =25+TH7°C [77°F+TH7] and SW4 (916) is set to ON. *1 (5°C [41°F] $\leq \alpha \leq$ 25°C [77°F]).
- •In the multiple-outdoor-unit system, defrosting is stopped on all units at the same time.
- *1 The compressor frequency is fixed at 60Hz when the compressor bottom SH (TH15 Te) ≤ 10°C [18°F]. And the defrost mode may continue even after 12 minutes.

| Model | TH3 and TH6 | | | |
|-----------|---------------|--------------|--|--|
| IVIOGEI | SW4 (916) OFF | SW4 (916) ON | | |
| 72 model | 7°C [45°F] | 12°C [54°F] | | |
| 96 model | 7°C [45°F] | 12°C [54°F] | | |
| 120 model | 7°C [45°F] | 12°C [54°F] | | |
| 144 model | 7°C [45°F] | 12°C [54°F] | | |

5 Control

(4) Problems during defrost operation

- •If a problem is detected during defrost operation, the operation will be stopped, and the defrost prohibition time based on the integrated compressor operation time will be set to 20 minutes.
- •The unit will stop after the defrost operation when the total time of "compressor bottom SH (TH15 Te) ≤ 10°C [18°F]" reaches 3 minutes.

(5) Change in the number of operating indoor units during defrost operation

- •Even when there is a change in the number of operating indoor units during defrost operation, the operation will continue, and an adjustment will be made after the completion of the defrost operation.
- Defrost operation will be continued, even if the indoor units stop or under the Thermo-OFF conditions until it has run its course.

5-2-8 Refrigerant Recovery Control

Refrigerant recovery is performed for each BC port during heating operation to prevent the refrigerant from accumulating inside the units that are stopped (in the fan mode), in the cooling mode, or in the heating Thermo-OFF mode. It is also performed during cooling operation to prevent an excessive amount of refrigerant from accumulating in the outdoor heat exchanger.

Starting criteria for the refrigerant recovery cycle (during Cooling-only, Cooling-main, Heating-only, or Heating-main mode)

The refrigerant recovery mode starts when all of the following conditions are met:

 When 5 minutes have passed in the Heating-only or Heating-main mode or 30 seconds have passed in the Cooling-only or Cooling-main mode since the completion of the previous refrigerant recovery cycle AND the when following conditions are met.

TH4 > 105°C [221°F]

2) When the port is not in the 4-minute restart delay mode

Starting criteria for the refrigerant recovery cycle (during Cooling-only, Cooling-main, Heating-only, or Heating-main mode)

- When the port is in the cooling Thermo-OFF, fan, or stop mode SVC at the port turns on for 30 seconds.
- The opening of LEV1 and LEV3 is increased.

5-2-9 Outdoor Unit Fan Control

(1) Control method

- •Depending on the capacity required, the rotation speed of the outdoor unit fan is controlled by the inverter to keep a constant condensing temperature of (outside temperature +10°C [18°F]) during cooling operation and a constant evaporation temperature of (0°C [32°F] =0.71 <Pa [103psi]) during heating operation.
- •The OS in the multiple-outdoor-unit system operates at the actual outdoor unit fan control value that is calculated by the OS based on the preliminary outdoor unit fan control value that the OC determines.

(2) Control

- •Outdoor unit fan stops while the compressor is stopped (except in the presence of input from snow sensor).
- •The fan operates at full speed for 5 seconds after start-up.(Only when TH7<0°C [32°F])
- •The outdoor unit fan stops during defrost operation.

(3) Outdoor unit heat exchanger capacity control patterns

| Model | Operation | Operation | | Soleno | id valve | | LE | LEV | |
|-----------------------|------------------------------|-----------|------|--------|----------|------|-------|-------|--|
| Wodel | mode | patterns | SV4a | SV4b | SV4c | SV4d | LEV5a | LEV5b | |
| P72, P96 models | Cooling-only | 1 | OFF | ON | - | ON | 220 | - | |
| | Cooling-main | 2 | OFF | ON | - | OFF | 220 | - | |
| | | 3 | ON | ON | - | OFF | 41 | - | |
| | Heating-only | 1 | ON | ON | - | OFF | 41 | - | |
| | Heating-main | 1 | ON | ON | - | ON | 41 | - | |
| | | 2 | ON | ON | - | OFF | 41 | - | |
| | Defrost | 1 | ON | ON | - | OFF | 41 | - | |
| P120,P144 mod- els | Cooling-only Cooling-main | 1 | OFF | ON | OFF | ON | 200 | 200 | |
| eis | | 2 | OFF | ON | OFF | OFF | 200 | 200 | |
| | | 3 | ON | ON | OFF | OFF | 41 | 200 | |
| | | 4 | ON | ON | OFF | OFF | 41 | 200 | |
| | | 5 | ON | ON | ON | OFF | 41 | 41 | |
| | Heating-only | 1 | ON | ON | ON | OFF | 41 | 41 | |
| | Heating-main | 1 | ON | ON | ON | ON | 41 | 41 | |
| | | 2 | ON | ON | ON | OFF | 41 | 41 | |
| | Defrost | 1 | ON | ON | ON | OFF | 41 | 41 | |

(4) Control of the outdoor unit fan during refrigerant balance control operation

•To correct the deviation of refrigerant among the combination of units, the fan rotation speeds are controlled in accordance with the difference of TdSH between the OC and OS. The outdoor unit fan speed for each unit is increased or decreased during liquid equalization control, and the unit with the lower TdSH is operated with a fan rotation speed that is faster than that of the unit with the higher TdSH.

The maximum fan rotation speed of the unit during liquid refrigerant equalization control is approximately 20 percent greater than that of the unit not operated in the liquid refrigerant equalization control mode.

◆TdSH=TH4-Tc

5-2-10 Evaporation Temperature Control (Expansion Valves <LEV5a, b>)

(1) LEV5 control will begin when all of the following conditions are met.

- •Units are operated in the Heating-Main mode.
- •15 minutes have passed after the compressor started up.
- •TH7<5°C [41°F]
- •63LS<0.69MPa [99psi]
- •TH15<4°C [39°F]


(2) LEV5 control will end when one or more of the following conditions are met.

- •Units are operated in the mode other than Heating-Main or Heating-Only.
- •TH7>10°C [50°F]
- +63LS>0.98MPa [142psi]
- •The LEV is controlled every 30 seconds to maintain constant the bypass inlet temperature (TH15 = 4~5°C [39~41°F]) of the BC controller during heating main mode or heating mode. When LEV5 is being controlled, SV4a, b, c, and d will all be turned off
- •The LEV operates at 300 pulse while the compressor is stopped. The LEV opens to a specified position in response to changes in heat exchanger capacity control patterns during cooling only or cooling main mode.


5-2-11 Control at Initial Startup

- •When started up for the first time before 12 hours have elapsed after power on, the unit goes into the initial startup mode.
- •At the completion of the initial operation mode on the OC and OS, they will go into the normal control mode.

(1) P72, P96, P120, P144ZKMU models



(2) P168, P192, P216, P240, P264, P288ZSKMU models



*1 ∑Qj:Total capacity (models) code

For information about capacity codes, refer to the relevant Service Handbook of the indoor unit for details.

5-2-12 Emergency Operation Mode

1. Problems with the outdoor unit

- •The P168 through P288 ZSKMU models of unit have a mode that allows the outdoor unit to perform an emergency operation when the other outdoor unit in the system malfunctions.
- •This mode can be started by performing an error reset via the remote controller.

(1) Starting the emergency operation

- 1) When an error occurs, the error source and the error code will be displayed on the display on the remote controller.
- 2) The error is reset using the remote controller.
- 3) If an error code appears that permits an emergency operation in step 1) above, (See the table below.), the retry operation starts
- 4) If the same error is detected during the retry operation (step 3 above), an emergency operation can be started by resetting the error via the remote controller.

Error codes that permit an emergency operation (Applicable to both OC and OS)

| Trouble source | | Error codes that permit an emergency operation | Error code description | | |
|-------------------------|------|--|---|--|--|
| | | 0403 | Serial communication error | | |
| | | 4220,4225,4226 | Bus voltage drop | | |
| | | 4230,4235 | Heatsink overheat protection | | |
| Compressor Fan motor | | 4240,4245 | Overload protection | | |
| Inverter | | 4250,4255,4256 | Overcurrent relay trip | | |
| | | 5110 | Heatsink temperature sensor failure (THHS) | | |
| | | 5301 | Current sensor/circuit failure | | |
| | | 5305,5306 | Position error | | |
| Thermistor | TH2 | 5102 | Subcool heat exchanger bypass outlet temperature sensor failure | | |
| | TH3 | 5103 | Pipe temperature sensor failure | | |
| | TH4 | 5104 | Discharge temperature sensor failure | | |
| | TH5 | 5105 | Accumulator inlet temperature sensor failure | | |
| | TH6 | 5106 | Subcool heat exchanger liquid outlet sensor failure | | |
| | TH7 | 5107 | Outside air temperature sensor failure | | |
| | TH15 | 5115 | Compressor shell bottom temperature sensor failure | | |
| Power | | 4102 | Open phase | | |
| | | 4115 | Power supply sync signal abnormality | | |

Emergency operation pattern (2 outdoor units)

| | | OC failure pattern | OS failure pattern | |
|---|---------|--------------------|--------------------|--|
| ОС | | Trouble | Normal | |
| os | | Normal | Trouble | |
| Emergency | Cooling | Permitted | Permitted | |
| operation | Heating | Permitted Permitte | | |
| Maximum total capacity of indoor units (Note 1) | | 60 | 0% | |

Note

1) If an attempt is made to put into operation a group of indoor units whose total capacity exceeds the maximum allowable capacity, some of the indoor units will go into the same condition as Thermo-OFF.

(2) Ending the emergency operation

1) End conditions

When one of the following conditions is met, emergency operation stops, and the unit makes an error stop.

- •When the integrated operation time of compressor in cooling mode has reached four hours.
- •When the integrated operation time of compressor in heating mode has reached two hours.
- •When an error is detected that does not permit the unit to perform an emergency operation.
- 2) Control at or after the completion of emergency operation
 - •At or after the completion of emergency operation, the compressor stops, and the error code reappears on the remote controller.
 - •If another error reset is performed at the completion of an emergency mode, the unit repeats the procedures in section (1) above.
 - •To stop the emergency mode and perform a current-carrying operation after correcting the error, perform a power reset.

2. Communication circuit failure or when some of the outdoor units are turned off

This is a temporary operation mode in which the outdoor unit that is not in trouble operates when communication circuit failure occurs or when some of the outdoor units are turned off.

(1) Starting the emergency operation (When the OC is in trouble)

- 1) When an error occurs, the error source and the error code appear on the display on the remote controller.
- 2) Reset the error via the remote controller to start an emergency operation.

Precautions before servicing the unit

- •When the OC is in trouble, the OS temporarily takes over the OC's function and performs an emergency operation. When this happens, the indoor unit connection information are changed.
- •In a system that has a billing function, a message indicating that the billing system information has an error may appear on the TG-2000A. Even if this message appears, do not change (or set) the refrigerant system information on the TG-2000A. After the completion of an emergency operation, the correct connection information will be restored.

(2) Starting the emergency operation (When the OS is in trouble)

1) A communication error occurs. -> An emergency operation starts in approximately six minutes.

Error codes that permit an emergency operation (Applicable to both OC and OS)

| Trouble source | Error codes that permit an emergency operation | Error code description |
|------------------------------------|---|--------------------------|
| Circuit board failure or the power | 6607 | No acknowledgement error |
| to the outdoor units is off | 6608 | No response error |

Emergency operation pattern (2 outdoor units)

| | | OC failure pattern | OS failure pattern | |
|---------------------------------|---------|-------------------------------------|--------------------|--|
| ОС | | Trouble | Normal | |
| os | | Normal | Trouble | |
| Emergency operation | Cooling | Permitted | Permitted | |
| | Heating | Permitted Permitte | | |
| Maximum tota of indoor units | | Capacity the total cap operable out | pacity of the | |

Note |


1) If an attempt is made to put into operation a group of indoor units whose total capacity exceeds the maximum allowable capacity, some of the indoor units will go into the same condition as Thermo-OFF.

(3) Ending the emergency operation

When communication is restored, the emergency mode is cancelled, and the units go into the normal operation mode.


5-2-13 Unit Control Scheme

The control system configuration for the PURY models is shown in the chart below.



Autonomous distributed control system : A system that consists of three independent sub control systems, instead of a single centralized control system, that work together to maintain the overall control of the entire system.

5-2-14 Refrigerant Circuits and Refrigerant Cycle Diagrams



5-2-15 Operation Mode

(1) Indoor unit operation mode

The operation mode can be selected from the following 6 modes using the remote controller.

| 1 | Cooling mode |
|---|--------------------------------|
| 2 | Heating mode |
| 3 | Dry mode |
| 4 | Automatic cooling/heating mode |
| 5 | Fan mode |
| 6 | Stopping mode |

(2) Outdoor unit operation mode


| 1 | Cooling only mode | All indoor units in operation are in cooling mode. |
|---|-------------------|--|
| 2 | Heating only mode | All indoor units in operation are in heating mode. |
| 3 | Cooling main mode | Coexistence of units in cooling and heating modes. |
| 4 | Heating main mode | Coexistence of units in cooling and heating modes. |
| 5 | Stopping mode | All indoor units are in fan mode or stopping mode. |

Note


When units in cooing and heating coexist, the operation mode (cooling main mode or heating main mode) will be determined, based on the refrigerant pressure in the R2 refrigerant circuit and speed variation data.

(3) Operation pattern for automatic cooling/heating mode

When the automatic cooling/heating mode is selected from remote controller functions, the indoor temperature will be detected in pattern as shown in the figure below, and the operation mode (cooling or heating) will automatically be selected.



(4) Relationship between the operation mode and the load capacity (kW) (within a system)



5-2-16 Demand Control

Cooling/heating operation can be prohibited (Thermo-OFF) by an external input to the indoor units.

Note

When DIP SW6-8 is set to ON, the 4-step DEMAND control is enabled. Eight-step demand control is possible in the system with two outdoor units.

For details, refer to the following page(s). [2-4-7 Various Control Methods Using the Signal Input/Output Connector on Outdoor Unit](page 31)

5-3 BC Controller Control

1. Control of SVA, SVB, and SVC

SVA, SVB, and SVC turn on or off depending on the operation mode of the branch.

| | | Mode | | | | |
|------|-----|---------|---------|---------|---------|--|
| | | Cooling | Heating | Stopped | Defrost | |
| Port | SVA | ON | OFF | OFF | OFF | |
| | SVB | OFF | ON | OFF | OFF | |
| | SVC | ON | OFF | OFF | OFF | |

2. Control of SVM1 and SVM1b

SVM turns on or off depending on the operation mode.

| Operation mode | Cooling only | Cooling main | Heating only | Heating main | Defrost | Stopped |
|----------------|--------------|---|--------------|--------------|---------|---------|
| SVM1,1b | ON | Pressure dif- ferential con- trol*1 | OFF | OFF | ON | OFF |

^{*1.} Pressure differential control: The detected differential pressure (PS1 and PS3) is controlle every minute so as to be within a certain range.

3. Control of LEV

LEV opening (sj) is controlled as follows depending on the operation mode.

| | Operation mode | Cooling only | Cooling main | Heating only | Heating main | Defrost | Stopped |
|-------------------|-----------------------------------|---------------------|---|---|---|---------|---------|
| | LEV1 | 3000 | Liquid level | 85 ^{*3} | 85 ^{*3} | 3000 | 900 |
| J, JA, KA type | LEV3 Superneat ferential | | Pressure dif- ferential con- trol*2 | Pressure dif- ferential con- trol*2 | 3000 | 41 | |
| | LEV4 (JA and KA types only) | 41 | 41 | Pressure differential control ^{*2} | Pressure differential control ^{*2} | 3000 | 41 |
| KB type | LEV3 | Superheat control*4 | Superheat control*4 | 60 | 60 | 60 | 60 |

^{*1.} Liquid level control: The liquid level detected by the liquid inlet temperature (TH11 sensor) is controlled so as to be within a certain range.

^{*2.} Pressure differential control: The detected differential pressure (PS1 and PS3) is controlle every minute so as to be within a certain range.


^{*3.} Can be 85 or more due to pressure rise on the liquid side (PS1).

^{*4.} Superheat control: The amound of superheat that is calculated on the bypass inlet and outlet temperature (TH12, TH15) is controlled every minute so as to be within a certain range.

5-4 Operation Flowcharts

5-4-1 Operation Sequence Flowchart

(1) Indoor unit (cooling, heating, dry, fan mode)




^{*}Note 1. Indoor unit LEV fully closed: Opening 41.

^{*}Note 2. The system may go into the error mode on either the indoor unit side or the BC controller or outdoor unit side.

If some of the indoor units are experiencing a problem, only those indoor units that are experiencing the problem will stop. If the BC controller or the outdoor unit is experiencing a problem, all the connected units will stop.


^{*}Note 3. If multiple indoor units are connected to a port and there is a discrepancy in the operation mode between the indoor unit and the port, the operation will be prohibited. (Operation mode blinks on the remote controller, the Fan stops, indoor unit LEV becomes fully closed.)

(2) Outdoor unit (cooling only, heating only, cooling main and heating main modes)



- *Note 1. For about 3 minutes after power on, search for the indoor unit address, for the remote controller address, and for the group information will start. During this, "HO"/ "PLEASE WAIT" blinks on the display of the remote controller. When the indoor unit to be controlled by the remote controller is missing, "HO"/ "PLEASE WAIT" keeps blinking on the display of the remote controller even after 3 or more minutes after power on.
- *Note 2. The system may go into the error mode on either the indoor unit or the outdoor unit side. The outdoor stops only when all of the connected indoor units are experiencing problems. The operation of even a single indoor unit will keep the outdoor unit running. The error will be indicated on the LED display.
- *Note 3. The units will follow the operation mode commands from the BC controller
- *Note 4. When the operation mode commands from the BC controllers are mixed (both cooling and heating), the actual operation mode is determined by the outdoor unit.


(3) BC controller (cooling only, heating only, cooling main and heating main modes)



Note 1. The system may go into the error mode on either the indoor unit side or the BC controller or outdoor unit side. If some of the indoor units are experiencing a problem, only those indoor units that are experiencing the problem will stop. If the BC controller or the outdoor unit is experiencing a problem, all the connected units will stop.


5-4-2 Actions Performed in Different Modes

(1) Cooling operation



*Note 1. The indoor fan operates at the set notch under cooling mode regardless of the ON/OFF state of the thermostat.


(2) Heating operation



Note

- 1) When the outdoor unit goes into the defrost mode, defrost command is sent to the BC controller and indoor units. Upon reception of the command, the indoor units will go into the defrost mode. When defrosting is completed and upon receiving the signal that indicates the completion of defrosting, indoor units will resume the heating operation.
- Defrost end condition: 10 minutes have passed since defrost operation started.
 Outdoor unit pipe temperature: Refer to the following page(s).[5-2-7 Defrost Operation Control](page 133)

(3) Dry operation



*Note 1.When the indoor unit inlet temperature exceeds 18°C [64°F], the outdoor unit (compressor) and the indoor unit fan start the intermittent operation simultaneously. When the indoor unit inlet temperature becomes 18°C [64°F],or less, the fan always runs (at low speed). The outdoor unit, the indoor unit, and the solenoid valve operate in the same way as they do in the cooling operation when the compressor is turned on.

*Note 2.Thermostat is always kept on during test run mode, and indoor and outdoor unit intermittent operation (ON) time is a little longer than that of normal operation.

Chapter 6 Test Run

| 6-1 | Read before Test Run | 155 |
|-------|--|-----|
| 6-2 | Operation Characteristics and Refrigerant Charge | 156 |
| 6-3 | Evaluating and Adjusting Refrigerant Charge | 156 |
| 6-3-1 | Refrigerant Overcharge and undercharge | 156 |
| 6-3-2 | Checking the Refrigerant Charge during Operation | 156 |
| 6-3-3 | The Amount of Refrigerant to Be Added | 157 |
| 6-3-4 | Refrigerant Charge Adjustment Mode | 160 |
| 6-4 | The Following Symptoms Are Normal | 162 |

6 Test Run

6-1 Read before Test Run

- (1) Check for refrigerant leak and loose cables and connectors.
- (2) When opening or closing the front panel of the control box, do not let it come into contact with any of the internal components.

Note

- *Before inspecting the inside of the control box, turn off the power, keep the unit off for at least 10 minutes, and confirm that the voltage between FT-P and FT-N on INV Board has dropped to DC20V or less. (It takes about 10 minutes to discharge electricity after the power supply is turned off.)
- •Control box houses high temperature parts. Be well careful even after turning off the power source.
- *Before beginning service work, disconnect the fan board connector (CNINV) or the connectors (CN01 and CN11) on the INV board. (To plug or unplug connectors, check that the outdoor unit fan is not rotating and that the voltage of capacitor in the main circuit is 20 VDC or below. The capacitor may collect a charge and cause an electric shock when the outdoor unit fan rotates in windy conditions. Refer to the wiring nameplate for details.)
- •To connect wiring to TB7, check that the voltage is 20 VDC or below.
- •When the service work is finished, reconnect the connector (CNINV) on the fan board and the connectors (CN01 and CN11) on the INV board.
- (3) Measure the insulation resistance between the power supply terminal block and the ground with a 500V megger and make sure it reads at least 1.0Mohm.

Note

- •Do not operate the unit if the insulation resistance is below 1.0Mohm.
- *Do not apply megger voltage to the terminal block for transmission line. Doing so will damage the controller board.
- •The insulation resistance between the power supply terminal block and the ground could go down to close to 1Mohm immediately after installation or when the power is kept off for an extended period of time because of the accumulation of refrigerant in the compressor.
- •If insulation resistance reads at least 1 M Ω , by turning on the main power and keeping it on for at least 12 hours, the refrigerant in the compressor will evaporate and the insulation resistance will go up.
- •Do not measure the insulation resistance of the terminal block for transmission line for the unit remote controller.
- (4) When the power is turned on, the heater is energized even while the compressor is not operating.

Note

- •Before turning on the power, disconnect all power supply wires from the compressor terminal block, and measure the insulation resistance of the compressor.
- •Check the compressor for a ground fault. If the insulation resistance is 1.0 M Ω or below, connect all power supply wires to the compressor and turn on the power to the outdoor unit. (The liquid refrigerant in the compressor will evaporate by energizing the heater.)
- (5) Make sure the valves on both the high-pressure and low-pressure sides are fully open.

Note

Securely tighten the cap.

(6) Check the phase sequence and the voltage of the power supply.

When the voltage is out of the ±10% range, or when the phase voltage difference is more than 2%, please discuss the counter-measure with the customer.

(7) [When a transmission booster is connected]

Turn on the transmission booster before turning on the outdoor units.

<u>Note</u>

- •If the outdoor units are turned on first, the connection information for the refrigerant circuit may not be properly recognized.
- •In case the outdoor units are turned on before the transmission booster is turned on, perform a power reset on the outdoor units after turning on the power booster.
- (8) Turn on the main power at least 12 hours before test run.

Note

Insufficient powering time may result in compressor damage.

(9) When a power supply unit is connected to the transmission line for centralized control(*), perform a test run with the power supply unit being energized. Leave the power jumper connector on CN41 as it is (factory setting).

*Includes the cases where power is supplied to the transmission line from a system controller with a power-supply function

6-2 Operation Characteristics and Refrigerant Charge

It is important to have a clear understanding of the characteristics of refrigerant and the operating characteristics of air conditioners before attempting to adjust the refrigerant amount in a given system.

The following shows items of particular importance.

- 1) During cooling operation, the amount of refrigerant in the accumulator is the smallest when all indoor units are in operation.
- 2) During heating operation, the amount of refrigerant in the accumulator is the largest when all indoor units are in operation.
- 3) General tendency of discharge temperature
 - •Discharge temperature tends to rise when the system is short on refrigerant.
 - •Changing the amount of refrigerant in the system while there is refrigerant in the accumulator has little effect on the discharge temperature.
 - •The higher the pressure, the more likely it is for the discharge temperature to rise.
 - •The lower the pressure, the more likely it is for the discharge temperature to rise.
- 4) When the amount of refrigerant in the system is adequate, the compressor shell temperature is 10 to 60°C [18 to 108°F] higher than the low pressure saturation temperature (Te).
 - → If the temperature difference between the compressor shell temperature and low pressure saturation temperature (Te) is smaller than 5°C [9°F], an overcharging of refrigerant is suspected.

6-3 Evaluating and Adjusting Refrigerant Charge

6-3-1 Refrigerant Overcharge and undercharge

Overcharging or undercharging of refrigerant can cause the following symptoms:

Before attempting to adjust the amount of refrigerant in the system, thoroughly check the operating conditions of the system. Then, adjust the refrigerant amount by running the unit in the refrigerant amount adjust mode.

| The system comes to an abnormal stop, displaying 1500 (overcharged refrigerant) on the controller. | Overcharged refrigerant |
|---|---------------------------------|
| The operating frequency does not reach the set frequency, and there is a problem with performance. | Insufficient refrigerant amount |
| The system comes to an abnormal stop, displaying 1102 (abnormal discharge temperature) on the controller. | |

6-3-2 Checking the Refrigerant Charge during Operation

Operate all indoor units in either cooling-only or heating-only mode, and check such items as discharge temperature, subcooling, low pressure, suction temperature, and shell bottom temperature to estimate the amount of refrigerant in the system.

| Symptoms | Conclusion |
|--|----------------------|
| Discharge temperature is high. (Normal discharge temperature is below 95°C [203°F].) | Slightly under- |
| Low pressure is unusually low. | charged refrigerant |
| Suction superheat is large. (Normal suction superheat is less than 20°C [36°F].) | |
| Compressor shell bottom temperature is high. (The difference between the compressor shell bottom temperature and low pressure saturation temperature (Te) is greater than 60°C [108°F].) | |
| Discharge superheat is small. (Normal discharge superheat is greater than 10°C [18°F].) | Slightly overcharged |
| Compressor shell bottom temperature is low. (The difference between the compressor shell bottom temperature and low pressure saturation temperature (Te) is less than 5°C [9°F].) | refrigerant |

6-3-3 The Amount of Refrigerant to Be Added

The amount of refrigerant that is shown in the table below is factory-charged to the outdoor units. The amount necessary for extended pipe (field piping) is not included and must be added on site.

| Outdoor unit model | P72 | P96 | P120 | P144 |
|--|-------|-------|------|------|
| Amount of pre-charged refrigerant in the outdoor unit (kg) | 9.5 | 10.3 | 11.8 | 11.8 |
| Amount of pre-charged refrigerant in the outdoor unit [lbs-oz] | 20-16 | 22-12 | 26-1 | 26-1 |

(1) Calculation formula

The amount of refrigerant to be added depends on the size and the length of field piping. (unit in m[ft])

•When the piping length to the farthest indoor unit is shorter than 30.5 meters (100 feet)

Amount of added refrigerant (kg) =
$$(0.36 \times L_1) + (0.23 \times L_2) + (0.16 \times L_3) + (0.11 \times L_4) + (0.2 \times L_5) + (0.12 \times L_6) + (0.06 \times L_7) + (0.024 \times L_8) + \alpha_1 + \alpha_2 + \beta$$

Amount of added refrigerant (oz) = $(3.88 \times L_1') + (2.48 \times L_2') + (1.73 \times L_3') + (1.19 \times L_4') + (2.16 \times L_5') + (1.30 \times L_6') + (0.65 \times L_7') + (0.26 \times L_8') + \alpha_1' + \alpha_2' + \beta'$

•When the piping length to the farthest indoor unit is 30.5 meters (100 feet) or longer

Amount of added refrigerant (kg) =
$$(0.33 \times L_1) + (0.21 \times L_2) + (0.14 \times L_3) + (0.11 \times L_4) + (0.18 \times L_5) + (0.11 \times L_6) + (0.054 \times L_7) + (0.021 \times L_8) + \alpha_1 + \alpha_2 + \beta$$

Amount of added refrigerant (oz) = $(3.54 \times L_1') + (2.26 \times L_2') + (1.51 \times L_3') + (1.08 \times L_4') + (1.94 \times L_5') + (1.19 \times L_6') + (0.59 \times L_7') + (0.23 \times L_8') + \alpha_1' + \alpha_2' + \beta'$

 $\begin{array}{l} L_1: \text{Length of } \emptyset 28.58[1\text{-}1/8"] \text{ high pressure pipe } (m) \\ L_2: \text{Length of } \emptyset 22.2[7/8"] \text{ high pressure pipe } (m) \\ L_3: \text{Length of } \emptyset 19.05[3/4"] \text{ high pressure pipe } (m) \\ L_4: \text{Length of } \emptyset 15.88[5/8"] \text{ high pressure pipe } (m) \\ L_5: \text{Length of } \emptyset 15.88[5/8"] \text{ liquid pipe } (m) \\ L_6: \text{Length of } \emptyset 12.7[1/2"] \text{ liquid pipe } (m) \\ L_7: \text{Length of } \emptyset 9.52[3/8"] \text{ liquid pipe } (m) \\ L_8: \text{Length of } \emptyset 6.35[1/4"] \text{ liquid pipe } (m) \\ \alpha_1, \alpha_2, \ \alpha_1', \alpha_2': \text{ Refer to the table below.} \end{array}$

L₁': Length of $\emptyset 28.58[1-1/8"]$ high pressure pipe [ft] L₂': Length of $\emptyset 22.2[7/8"]$ high pressure pipe [ft] L₃': Length of $\emptyset 19.05[3/4"]$ high pressure pipe [ft] L₄': Length of $\emptyset 15.88[5/8"]$ high pressure pipe [ft] L₅': Length of $\emptyset 15.88[5/8"]$ liquid pipe [ft] L₆': Length of $\emptyset 12.7[1/2"]$ liquid pipe [ft] L₇': Length of $\emptyset 9.52[3/8"]$ liquid pipe [ft] L₈': Length of $\emptyset 6.35[1/4"]$ liquid pipe [ft]

 β , β ': Refer to the table below.

| Main or sub BC controller | Amount for the BC controllers | | |
|------------------------------|-------------------------------|-----------------------|--|
| | α ₁ (kg) | α ₁ ' (oz) | |
| J-type | 1.5 | 53 | |
| JA-type | 3.0 | 106 | |
| KA-type | 4.7 | 166 | |
| KB-type | 0.4 | 15 | |

| Total capacity of connected indoor | | Amount for the Indoor unit | | | |
|------------------------------------|------|----------------------------|----------------------|-----|-----------------------|
| un | nits | | units $\alpha_2(kg)$ | | α ₂ ' (oz) |
| | - 27 | | 2.0 | 71 | |
| 28 | - | 54 | 2.5 | 89 | |
| 55 | - | 126 | 3.0 | 106 | |
| 127 | - | 144 | 3.5 | 124 | |
| 145 | - | 180 | 4.5 | 159 | |
| 181 | - | 234 | 5.0 | 177 | |
| 235 | - | 273 | 6.0 | 212 | |
| 274 | - | 307 | 8.0 | 283 | |
| 308 | - | 342 | 9.0 | 318 | |
| 343 | - | 411 | 10.0 | 353 | |
| 412 | - | 450 | 12.0 | 424 | |
| 451 | - | | 14.0 | 494 | |

| Outdoor unit total index | | Charged amount for Out- door Unit(s) | | |
|--------------------------|------------|---|---------|--|
| | | β (kg) | β' (oz) | |
| | P72 model | 0.0 | 0 | |
| single | P96 model | 0.0 | 0 | |
| Sirigio | P120 model | 5.5 | 195 | |
| | P144 model | 5.5 | 195 | |
| | P168 model | 0.0 | 0 | |
| | P192 model | 0.0 | 0 | |
| Combination | P216 model | 5.5 | 195 | |
| Combination | P240 model | 11.0 | 390 | |
| | P264 model | 11.0 | 390 | |
| | P288 model | 11.0 | 390 | |

Round up the calculation result in increments of 4oz (0.1kg) or round it up to the nearest 1oz. (Example: 78.21oz to 79oz)

1) Maximum refrigerant charge

There is a limit to the amount of refrigerant that can be charged into a unit. Regardless of the amount yielded by the formula above, observe the maximum refrigerant charge in the table below.

| Total index of the outdoor units | P72 | P96 | P120 | P144 | P168 | P192 | P216 |
|--|------|------|-------|-------|------|------|--------|
| Maximum refrigerant charge *1 (kg) | 15.6 | 25.9 | 32.1 | 32.1 | 29.2 | 42.3 | 63.0 |
| Maximum refrigerant charge *1 [lbs-oz] | 34-7 | 57-2 | 70-13 | 70-13 | 64-6 | 93-5 | 138-15 |

| Total index of the outdoor units | P240 | P264 | P288 |
|--|-------|-------|-------|
| Maximum refrigerant charge *1 (kg) | 66.4 | 66.4 | 66.4 |
| Maximum refrigerant charge *1 [lbs-oz] | 146-7 | 146-7 | 146-7 |

^{*1} Maximum refrigerant charge: the amount of refrigerant to be added on site.


^{*}When connecting PLFY-EP08NEMU-E, add 0.3 kg (10.6 oz) of refrigerant per indoor unit.
*When connecting PLFY-EP06NEMU**-E**, PLFY-EP18NEMU**-E**, PLFY-EP24NEMU**-E**, or PLFY-EP36NEMU**-E**, add 0.67 kg (24 oz) of refrigerant per indoor unit.

^{*}When connecting PEFY-P06NMAU-E**, PEFY-P18NMAU-E**, PEFY-P24NMAU-E**, PEFY-P30NMAU-E**, or PEFY-P36NMAU-E**, add 0.55 kg (20 oz) of refrigerant per indoor unit.

Round up the calculation result to the nearest 0.1kg. (Example: 18.04kg to 18.1kg)

6 Test Run

(2) Example



(3) Sample calculation

```
Units "m" and "kg"
Indoor 1: 18
                                                           The total length of each liquid line as follows:
                 A: ø28.58 40 m a: ø6.35
                                                 10 m
                                                           ø28.58: A = 40 m
                  B: ø9.52
                              10 m b: ø9.52
         2.96
                                                 10 m
                  C: ø12.7
         3: 06
                              20 m c: ø6.35
                                                           ø19.05: G + H = 4 m
                                                  5 m
         4: 06
                 D: ø9.52
                               5 m d: ø6.35
                                                  5 m
                                                           ø12.70: C = 20 m
                                                           Ø9.52: B + D + E + F + b + e + f + g = 50 m
Ø6.35: a + c + d + h = 30 m
         5: 48
                  E: ø9.52
                               5 m e: ø9.52
                                                  5 m
         6: 36
                  F: ø9.52
                               5 m f: ø9.52
                                                  5 m
         7: 30
8: 18
                               3 m g: ø9.52
1 m h: ø6.35
                  G: ø19.05
                                                  5 m
                                                           <Calculation example>
                 H: ø19.05
                                                 10 m
                                                           Additional refrigerant charge
Outdoor P240
                                                            = 40 × 0.33 + 4 × 0.14 + 20 × 0.11 + 50 × 0.054
+ 30 × 0.021 + 3 + 0.4 × 4 + 6 + 11
Main BC controller CMB-P108NU-JA2
Sub BC controller
                     CMB-P104NU-KB2 × 4
                                                            = 40.9 (40.89) kg
Units "ft" and "oz"
                 A: ø1-1/8 131 ft a: ø1/4
B: ø3/8 32 ft b: ø3/8
Indoor
        1: 18
2: 96
                                                32 ft
                                                           The total length of each liquid line as follows:
                                                 32 ft
                                                           ø1-1/8: A = 131 ft
         3:06
                  C: ø1/2
                               65 ft c: ø1/4
                                                 16 ft
                                                           ø3/4: G + H = 12 ft
         4: 06
                  D: ø3/8
                               16 ft d: ø1/4
                                                 16 ft
                                                           ø1/2: C = 65 ft
         5: 48
                 E: ø3/8
                               16 ft
                                     e: ø3/8
                                                 16 ft
                                                           \emptyset3/8: B + D + E + F + b + e + f + g = 160 ft
         6: 36
7: 30
                 F: ø3/8
                               16 ft f: ø3/8
                                                 16 ft
                                                           \emptyset1/4: a + c + d + h = 96 ft
                                9 ft g: ø3/8
3 ft h: ø1/4
                  G: ø3/4
                                                 16 ft
                                                           <Calculation example>
         8: 18
                  H: ø3/4
                                                           Additional refrigerant charge
Outdoor P240
                                                            = 131 \times 3.54 + 12 \times 1.51 + 65 \times 1.19 + 160 \times 0.59
Main BC controller CMB-P108NU-JA2
                                                             + 96 × 0.23 + 106 + 15 × 4 + 212 + 390
Sub BC controller CMB-P104NU-KB2 × 4
                                                            = 1443.7 (1443.69) oz
```

6-3-4 Refrigerant Charge Adjustment Mode

Follow the procedures below to add or extract refrigerant as necessary depending on the operation mode.

When the function switch (SW4 (922)) on the main board on the outdoor unit (OC only) is turned to ON, the unit goes into the refrigerant amount adjust mode, and the following sequence is followed.

Note

The unit will not go into the refrigerant amount adjust mode when the switch on the OS is set to ON.

Operation

When the unit is in the refrigerant amount adjust mode, the LEV on the indoor unit does not open as fully as it normally does during cooling operation to secure subcooling.

Note


- Adjust the refrigerant amount based on the values of TH4, SC11, SC16, and Tc, following the flowchart below. The TH4, SC11, SC16, and Tc values can be displayed by using the self-diagnosis switch (SW4 (SW6-10: OFF)) on the control board of the OC or OS.
- There may be cases when the refrigerant amount may seem adequate for a short while after starting the unit in the refrigerant amount adjust mode but turn out to be inadequate later on (when the refrigerant system stabilizes).

When the amount of refrigerant is truly adequate.

Subcool (SC11 and SC16) of the BC controller is 5°C [9°F] or above and SH on the indoor unit is between 5 and 15°C [9 and 27°F].

The refrigerant amount may seem adequate at the moment, but may turn out to be inadequate later on. Subcool (SC11 and SC16) of the BC controller is 5°C [9°F] or less and SH on the indoor unit is 5°C [9°F] or less. Wait until the Subcool (SC11 and SC16) of the BC controller reaches 5°C [9°F] or above and the SH of the indoor unit is between 5 and 15°C [9 and 27°F] to determine that the refrigerant amount is adequate.


- •SC11: Subcool of liquid refrigerant at BC controller inlet; SC16: Subcool of liquid refrigerant at BC controller outlet
- 3) High pressure must be at least 2.0MPa [290psi] to enable a proper adjustment of refrigerant amount to be made.
- 4) Refrigerant amount adjust mode automatically ends 90 minutes after beginning. When this happens, by turning off the SW4 (922) and turning them back on, the unit will go back into the refrigerant amount adjust mode.



•For how to read the SW settings, refer to the following page(s). [9-1-1 How to Read the LED](page 315)



The figure at left shows that the switches 1 through 5 are set to ON and 6 through 10 are set to OFF.





Do not release the extracted refrigerant into the air.

⚠ CAUTION

Charge liquid refrigerant (as opposed to gaseous refrigerant) into the system.

•If gaseous refrigerant is charged into the system, the composition of the refrigerant in the cylinder will change and may result in performance loss.

6-4 The Following Symptoms Are Normal

| Events | Display on remote controller | Cause | | | | |
|---|----------------------------------|---|--|--|--|--|
| The auto vane automatically switches air flow direction. | Normal display | vertical air flow ation has beer mediately afte | e may switch over to horizontal air flow operation from voperation in cooling mode if the vertical air flow operarion running for one hour. At defrost in heating mode or imreating start-up/shutdown, the auto vane switches to horizontal air flow for a short time. | | | |
| The fan speed automatically changes during heating operation. | Normal display | off, and autom | The fan operates at Very Low speed when the thermostat is turned off, and automatically changes over to the preset speed according to the timer setting or refrigerant temperature when the thermostat is turned on. | | | |
| The fan stops during heating operation. | "Defrost" | The fan remains stopped during the defrost cycle. | | | | |
| The fan keeps running after the unit has stopped. | No display | | nas stopped during heating operation, the fan operates to exhaust heat. | | | |
| At the beginning of heating operation, the fan cannot be manually set. | "Stand By" | eration starts (95°F), then th | tes at Very Low speed for five minutes after heating op- or until the refrigerant temperature reaches 35°C he fan operates at Low speed for two minutes, and final- rates at the preset speed. | | | |
| When the main power is turned on, the display as shown right appears on the remote controller for about five minutes. | "HO" or "PLEASE WAIT" blinks. | The system is starting up. Wait until "HO" or "PLEASE WAIT" stops blinking and goes off then try again. | | | | |
| The drain pump keeps running after the unit has stopped. | No display | The drain pump remains in operation for three minutes after the unin cooling mode has stopped. The drain pump goes into operation when drain water is detected, even when the unit is stopped. | | | | |
| The indoor unit emits noise when switching from heating to cooling | Normal display | R2 system | This is a normal sound of the refrigerant circuit operating properly. | | | |
| and vice versa. | | Hybrid City Multi system | Some air may be left in the water circuit. Referring to the Service Handbook provided with the HBC controller, take the appropriate measures. | | | |
| Immediately after startup, the indoor unit emits the sound of liquid flowing. | Normal display | | of the heating medium produces a sound. This is temes not imply a problem. | | | |
| In a short while after the outdoor unit stops, the unit makes a clicking sound. | No display | tion, the press | stops and before the unit performs pressure equaliza- ure difference temporarily becomes small and the lay vibrate and make a sound. This is temporary and y a problem. | | | |
| Drain water comes out of the out-door unit from the bottom part of the heat exchanger. | No display | This ensures preezes and real low ambien | proper drainage of drain water in case the drain water emains in the outdoor unit during the heating operation t temperature. | | | |

Chapter 7 Troubleshooting Using Error Codes

| 7-1 7-1-1 | Error Code and Preliminary Error Code Lists | |
|---------------------|---|-----|
| 7-2 | Error Code Definitions and Solutions: Codes [0 - 999] | 170 |
| 7-2-1 | Error Code [0403] | 170 |
| 7-2-2 | Error Code [0404] | 172 |
| 7-3 | Error Code Definitions and Solutions: Codes [1000 - 1999] | 173 |
| 7-3-1 | Error Code [1102] | 173 |
| 7-3-2 | Error Code [1301] | 174 |
| 7-3-3 | Error Code [1302] (during operation) | 175 |
| 7-3-4 | Error Code [1302] (at startup) | |
| 7-3-5 | Error Code [1500] | 177 |
| 7-4 | Error Code Definitions and Solutions: Codes [2000 - 2999] | |
| 7-4-1 | Error Code [2500] (Models with a drain sensor) | 178 |
| 7-4-2 | Error Code [2500] (Models with a float switch) | 179 |
| 7-4-3 | Error Code [2502] (Models with a drain sensor) | |
| 7-4-4 | Error Code [2502] (Models with a float switch) | |
| 7-4-5 | Error Code [2503] | |
| 7-4-6 | Error Code [2600] | 183 |
| 7-4-7 | Error Code [2601] | 183 |
| 7-5 | Error Code Definitions and Solutions: Codes [3000 - 3999] | 184 |
| 7-5-1 | Error Code [3121] | 184 |
| 7-6 | Error Code Definitions and Solutions: Codes [4000 - 4999] | |
| 7-6-1 | Error Code [4102] | 185 |
| 7-6-2 | Error Code [4106] | 186 |
| 7-6-3 | Error Code [4109] | 186 |
| 7-6-4 | Error Code [4114] | |
| 7-6-5 | Error Code [4115] | |
| 7-6-6 | Error Code [4116] | |
| 7-6-7 | Error Code [4121] | |
| 7-6-8 | Error Code [4124] | |
| 7-6-9 | Error Codes [4220, 4225, 4226] Detail Code 108 | |
| 7-6-10 | Error Codes [4220, 4225, 4226] Detail Code 109 | 191 |
| 7-6-11 | Error Codes [4220, 4225, 4226] Detail Code 111 | |
| | Error Codes [4220, 4225, 4226] Detail Code 131 | |
| | Error Code [4230] | |
| | Error Code [4240] | |
| 7-6-15 | Error Codes [4250, 4255, 4256] Detail Code 101 | 195 |
| | Error Codes [4250, 4255, 4256] Detail Code 104 | |
| 7-6-17 | Error Codes [4250, 4255, 4256] Detail Code 105 | 197 |
| 7-6-18 | Error Code [4250] Detail Codes 106 and 107 | 198 |
| 7-6-19 | Error Code [4260] | 198 |
| 7-7 | Error Code Definitions and Solutions: Codes [5000 - 5999] | |
| 7-7-1 | Error Codes [5101, 5102, 5103, 5104] | |
| 7-7-2 | Error Codes [5103, 5104, 5105, 5106, 5107] | |
| 7-7-3 | Error Code [5115] | |
| 7-7-4 | Error Code [5110] | |
| 7-7-5 | Error Codes [5111, 5112, 5115, 5116] | 203 |

| 7-7-6 | Error Code [5201] | 204 |
|---|--|---|
| 7-7-7 | Error Codes [5201, 5203] | 204 |
| 7-7-8 | Error Code [5301] Detail Code 115 | 205 |
| 7-7-9 | Error Code [5301] Detail Code 117 | 205 |
| 7-7-10 | Error Code [5301] Detail Code 119 | 206 |
| 7-7-11 | Error Code [5301] Detail Code 120 | 206 |
| 7-7-12 | Error Codes [5305, 5306] Detail Code 132 | 207 |
| 7-7-13 | Error Codes [5305, 5306] Detail Code 133 | 207 |
| 7-7-14 | Error Codes [5305, 5306] Detail Code 134 | 208 |
| 7-7-15 | Error Code [5401] | 208 |
| 7-7-16 | Error Code [5701] | 209 |
| 7-8 | Error Code Definitions and Solutions: Codes [6000 - 6999] | 210 |
| 7-8-1 | Error Code [6201] | 210 |
| 7-8-2 | Error Code [6202] | 210 |
| 7-8-3 | Error Code [6600] | 211 |
| 7-8-4 | Error Code [6601] | 211 |
| 7-8-5 | Error Code [6602] | 212 |
| 7-8-6 | Error Code [6603] | 213 |
| 7-8-7 | Error Code [6606] | 213 |
| 7-8-8 | Error Code [6607] Error Source Address = Outdoor Unit (OC) | 214 |
| 7-8-9 | Error Code [6607] Error Source Address = BC Controller (BC) | 215 |
| 7-8-10 | Error Code [6607] Error Source Address = Indoor Unit (IC) | 216 |
| 7-8-11 | Error Code [6607] Error Source Address = LOSSNAY (LC) | 217 |
| 7-8-12 | Error Code [6607] Error Source Address = ME Remote Controller | 218 |
| 7-8-13 | Error Code [6607] Error Source Address = System Controller | 219 |
| 7-8-14 | Error Code [6607] All Error Source Addresses | 220 |
| 7-8-15 | Error Code [6607] No Error Source Address | 221 |
| 7-8-16 | Error Code [6608] | 222 |
| 7-8-17 | Error Code [6831] | 223 |
| 7-8-18 | Error Code [6832] | 224 |
| 7-8-19 | Error Code [6833] | 225 |
| 7-8-20 | Life Code [cooc] | |
| | Error Code [6834] | |
| 7-8-21 | | 226 |
| | Error Code [6834] | 226 227 |
| 7-8-22 | Error Code [6834] | 226 227 227 |
| 7-8-22 7-8-23 | Error Code [6834] Error Code [6840] Error Code [6841] | 226 227 227 228 |
| 7-8-22 7-8-23 7-8-24 | Error Code [6834] Error Code [6840] Error Code [6841] Error Code [6842] | 226 227 227 228 229 |
| 7-8-22 7-8-23 7-8-24 | Error Code [6834] Error Code [6840] Error Code [6841] Error Code [6842] Error Code [6843] | 226 227 227 228 229 230 |
| 7-8-22 7-8-23 7-8-24 7-8-25 | Error Code [6834] Error Code [6840] Error Code [6841] Error Code [6842] Error Code [6843] Error Code [6846] | 226 227 227 228 229 230 |
| 7-8-22 7-8-23 7-8-24 7-8-25 7-9 | Error Code [6834] Error Code [6840] Error Code [6841] Error Code [6842] Error Code [6843] Error Code [6846] Error Code Definitions and Solutions: Codes [7000 - 7999] | 226 227 227 228 229 230 231 231 |
| 7-8-22 7-8-23 7-8-24 7-8-25 7-9 | Error Code [6834] Error Code [6840] Error Code [6841] Error Code [6842] Error Code [6843] Error Code [6846] Error Code Definitions and Solutions: Codes [7000 - 7999] Error Code [7100] | 226 227 227 228 229 230 231 231 |
| 7-8-22 7-8-23 7-8-24 7-8-25 7-9 7-9-1 7-9-2 | Error Code [6834] Error Code [6840] Error Code [6841] Error Code [6842] Error Code [6843] Error Code [6846] Error Code Definitions and Solutions: Codes [7000 - 7999] Error Code [7100] Error Code [7101] | 226 227 228 229 230 231 231 232 233 |
| 7-8-22 7-8-23 7-8-24 7-8-25 7-9 7-9-1 7-9-2 7-9-3 | Error Code [6834] Error Code [6840] Error Code [6841] Error Code [6842] Error Code [6843] Error Code [6846] Error Code Definitions and Solutions: Codes [7000 - 7999] Error Code [7100] Error Code [7101] Error Code [7102] | 226 227 228 229 230 231 231 232 233 234 |
| 7-8-22 7-8-23 7-8-24 7-8-25 7-9 7-9-1 7-9-2 7-9-3 7-9-4 | Error Code [6834] Error Code [6840] Error Code [6841] Error Code [6842] Error Code [6843] Error Code [6846] Error Code Definitions and Solutions: Codes [7000 - 7999] Error Code [7100] Error Code [7101] Error Code [7102] Error Code [7105] | 226 227 228 229 230 231 231 232 233 234 |
| 7-8-22 7-8-23 7-8-24 7-8-25 7-9 7-9-1 7-9-2 7-9-3 7-9-4 7-9-5 | Error Code [6834] Error Code [6840] Error Code [6841] Error Code [6842] Error Code [6843] Error Code [6846] Error Code Definitions and Solutions: Codes [7000 - 7999] Error Code [7100] Error Code [7101] Error Code [7102] Error Code [7105] Error Code [7106] | 226 227 227 228 229 230 231 231 232 233 234 234 235 |
| 7-8-22 7-8-23 7-8-24 7-8-25 7-9 7-9-1 7-9-2 7-9-3 7-9-4 7-9-5 7-9-6 | Error Code [6834] Error Code [6840] Error Code [6841] Error Code [6842] Error Code [6843] Error Code [6846] Error Code Definitions and Solutions: Codes [7000 - 7999] Error Code [7100] Error Code [7101] Error Code [7102] Error Code [7105] Error Code [7106] Error Code [7107] | 226 227 228 229 230 231 232 233 234 234 235 236 |
| 7-8-22 7-8-23 7-8-24 7-8-25 7-9 7-9-1 7-9-2 7-9-3 7-9-4 7-9-5 7-9-6 7-9-7 | Error Code [6840] Error Code [6841] Error Code [6842] Error Code [6843] Error Code [6846] Error Code [6846] Error Code [7100] Error Code [7101] Error Code [7105] Error Code [7106] Error Code [7107] Error Code [7107] Error Code [7107] Error Code [7107] | 226 227 228 229 230 231 231 232 233 234 234 235 236 |
| 7-8-22 7-8-23 7-8-24 7-8-25 7-9 7-9-1 7-9-2 7-9-3 7-9-4 7-9-5 7-9-6 7-9-7 7-9-8 7-9-9 | Error Code [6834] Error Code [6840] Error Code [6841] Error Code [6842] Error Code [6843] Error Code [6846] Error Code Definitions and Solutions: Codes [7000 - 7999] Error Code [7100] Error Code [7101] Error Code [7105] Error Code [7106] Error Code [7107] Error Code [7110] Error Code [7110] Error Code [7107] Error Code [7111] | 226 227 228 229 230 231 231 232 233 234 235 236 236 237 |

7 Troubleshooting Using Error Codes

7-1 Error Code and Preliminary Error Code Lists

| | | | | | Sea | rchec | l unit | | |
|---------------|-----------------------------------|-------------------------|---|--------------|-------------|---------------|---------|-------------------|------------|
| Error Code | Prelimi- nary error code | ary (prelim- inary) | (prelim- inary) Error code definition detail | Outdoor unit | Indoor unit | BC controller | LOSSNAY | Remote controller | Notes |
| 0403 | 4300 4305 4306 | 1 5 6 (Note 1) | Serial communication error/Panel communication error | | 0 | | | | (page 170) |
| 0404 | - | - | Indoor unit EEPROM abnormality | | 0 | | | | (page 172) |
| 1102 | 1202 | - | Discharge temperature fault | 0 | | | | | (page 173) |
| 1301 | - | - | Low pressure fault | 0 | | | | | (page 174) |
| 1302 | 1402 | - | High pressure fault | 0 | | | | | (page 175) |
| 1500 | 1600 | - | Refrigerant overcharge | 0 | | | | | (page 177) |
| - | 1605 | - | Preliminary suction pressure fault | 0 | | | | | |
| 2500 | - | - | Drain sensor submergence | | 0 | | | | (page 178) |
| 2502 | - | - | Drain pump fault | | 0 | 0 | | | (page 180) |
| 2503 | - | - | Drain sensor (Thd) fault | | 0 | | 0 | | (page 182) |
| 2600 | - | - | Water leakage | | | | 0 | | (page 183) |
| 2601 | - | - | Water supply cutoff | | | | 0 | | (page 183) |
| 3121 | - | - | Out-of-range outside air temperature | 0 | | | | | (page 184) |
| 4102 | 4152 | - | Open phase | 0 | | | | | (page 185) |
| 4106 | - | - | Transmission power supply fault | 0 | | | | | (page 186) |
| 4109 | - | - | Fan operation status detection error | | 0 | | | | (page 186) |
| 4114 | - | - | Indoor unit fan motor error | | 0 | | | | (page 187) |
| 4115 | - | - | Power supply signal sync error | 0 | | | | | (page 187) |
| 4116 | - | - | RPM error/Motor error | | 0 | | 0 | | (page 188) |
| 4121 | 4171 | - | Function setting error | 0 | | | | | (page 188) |
| 4124 | - | - | Electric system not operate due to damper abnormality | | 0 | | | | (page 189) |
| | | [0] | Backup operation | 0 | | | | | |
| 4220 | 4320 | [108] | Abnormal bus voltage drop | 0 | | | | | (page 190) |
| 4225 4226 | 4325 4326 | [109] | Abnormal bus voltage rise | 0 | | | | | (page 191) |
| (Note 1) | (Note 1) | [111] | Logic error | 0 | | | | | (page 192) |
| | | [131] | Low bus voltage at startup | 0 | | | | | (page 193) |
| 4230 | 4330 | - | Heatsink overheat protection | 0 | | | | | (page 193) |
| 4240 | 4340 | - | Overload protection | 0 | | | | | (page 194) |

| | | | | | | Sea | rched | unit | | | | | | | |
|------------------|-----------------------------------|---|---|---|--|--|---------------|--|-------------------|--|------------|------------|--|------------|--|
| Error Code | Prelimi- nary error code | Error (prelim- inary) detail code | Error code definition | | Outdoor unit | Indoor unit | BC controller | LOSSNAY | Remote controller | Notes | | | | | |
| | | [0] | Backup operation | | 0 | | | | | | | | | | |
| 4050 | 4050 | [101] | IPM error | | 0 | | | | | (page 195) | | | | | |
| 4250 4255 | 4350 4355 | [104] | Short-circuited IPM/Ground fault | | 0 | | | | | (page 196) | | | | | |
| 4256 (Note 1) | 4356 (Note 1) | [105] | Overcurrent error due | to short-circuited motor | 0 | | | | | (page 197) | | | | | |
| , | , | [106] | Instantaneous overcu | rrent (S/W detection) | 0 | | | | | (page 198) | | | | | |
| | | [107] | Overcurrent (effective | value)(S/W detection) | 0 | | | | | (page 198) | | | | | |
| 4260 | - | - | Heatsink overheat pro | otection at startup | 0 | | | | | (page 198) | | | | | |
| 5101 | 1202 | _ | Temperature sensor | Return air temperature (TH21) | | 0 | | | | (page 199) | | | | | |
| 0101 | 1202 | | fault | OA processing unit inlet temperature (TH4) | | | | 0 | | (page 199) | | | | | |
| 5102 | 1017 | 1017 | 1217 - | Temperature sensor | Indoor unit pipe tempera- ture (TH22) | | 0 | | | | (page 199) | | | | |
| 3102 | 1217 | | | - | - | | | | fault | OA processing unit pipe temperature (TH2) | | | | 0 | |
| | | | | | | Indoor unit gas-side pipe temperature (TH23) | | 0 | | | | (page 199) | | | |
| 5103 | 1205 | 00 | Temperature sensor fault | OA processing unit gasside pipe temperature (TH3) | 0 | | (page 199) | | | | | | | | |
| | | | | Pipe temperature at heat exchanger outlet (TH3) | 0 | | | | | (page 200) | | | | | |
| | | | | OA processing unit intake air temperature (TH1) | | | | 0 | | (page 199) | | | | | |
| 5104 | 1202 | - | Temperature sensor fault | Outside temperature (TH24) | | 0 | | | | (page 199) Detectable only by the All- Fresh type in- door units | | | | | |
| | | | | | | | | Outdoor unit discharge temperature (TH4) | 0 | | | | | (page 200) | |
| 5105 | 1204 | - | Temperature sensor fault | Accumulator inlet temperature (TH5) | 0 | | | | | (page 200) | | | | | |
| 5106 | 1216 | - | Temperature sensor fault | Heat exchanger inlet temperature (TH6) | 0 | | | | | (page 200) | | | | | |
| 5107 | 1221 | - | Temperature sensor fault | Outside temperature (TH7) | 0 | | | | | (page 200) | | | | | |
| 5115 | 1203 | - | Temperature sensor fault (Outdoor unit) | Compressor shell bottom temperature | 0 | | | | | (page 201) | | | | | |
| | 40 | [0] | Backup operation | | 0 | | | | | | | | | | |
| 5110 | 1214 | 01 | Temperature sensor fault | Heatsink temperature (THHS) | 0 | | | | | (page 202) | | | | | |

| | | | | | Searched unit | | | | | |
|---------------|-----------------------------------|---|--|--|---------------|---------------|---------|-------------------|-------|------------|
| Error Code | Prelimi- nary error code | Error (prelim- inary) detail code | Error c | Outdoor unit | Indoor unit | BC controller | LOSSNAY | Remote controller | Notes | |
| 5111 | - | - | | Liquid inlet temperature (TH11) | | | 0 | | | (page 203) |
| 5112 | - | - | Temperature sensor | Bypass outlet temperature (TH12) | | | 0 | | | (page 203) |
| 5115 | - | - | (BC controller) | LEV3 outlet temperature (TH15) | | | 0 | | | (page 203) |
| 5116 | - | - | | LEV3 inlet temperature (TH16) | | | 0 | | | (page 203) |
| 5201 | - | - | High-pressure sensor | fault (63HS1) | 0 | | | | | (page 204) |
| 5201 | 1402 | - | High-pressure sensor (Outdoor unit 63HS1/l | | 0 | | 0 | | | (page 204) |
| 5203 | - | - | Intermediate pressure (BC controller PS3) | Intermediate pressure sensor fault (BC controller PS3) | | | 0 | | | (page 204) |
| | | [0] | Backup operation | | 0 | | | | | |
| | | [115] | ACCT sensor fault | | 0 | | | | | (page 205) |
| 5301 | 1 4300 [117] | [117] | ACCT sensor circuit fault | | 0 | | | | | (page 205) |
| | | [119] | Open-circuited IPM/Loose ACCT connector | | 0 | | | | | (page 206) |
| | | | Faulty ACCT wiring | | 0 | | | | | (page 206) |
| | [0] | | Backup operation | | 0 | | | | | |
| 5305 | 4305 | [132] | Position detection error at startup | | 0 | | | | | (page 207) |
| 5306 | 4306 | [133] | Position detection erro | or during operation | 0 | | | | | (page 207) |
| | | [134] | RPM error before startup | | 0 | | | | | (page 208) |
| 5401 | - | - | Humidity sensor fault | | | 0 | | | | (page 208) |
| 5701 | - | - | Loose float switch connector | | | 0 | | | | (page 209) |
| 6201 | - | - | Remote controller board fault (nonvolatile memory error) | | | | | | 0 | (page 210) |
| 6202 | - | - | Remote controller boa | ard fault (clock IC error) | | | | | 0 | (page 210) |
| 6600 | - | - | Address overlaps | | 0 | 0 | 0 | 0 | 0 | (page 211) |
| 6601 | - | - | Polarity setting error | | | | | | 0 | (page 211) |
| 6602 | - | - | Transmission process | or hardware error | 0 | 0 | 0 | 0 | 0 | (page 212) |
| 6603 | - | - | Transmission line bus busy error | | 0 | 0 | 0 | 0 | 0 | (page 213) |
| 6606 | - | - | Communication error between device and transmission processors | | 0 | 0 | 0 | 0 | 0 | (page 213) |
| 6607 | - | - | No ACK error | | 0 | 0 | 0 | 0 | 0 | (page 214) |
| 6608 | - | - | No response error | | 0 | 0 | 0 | 0 | 0 | (page 222) |
| 6831 | - | - | MA controller signal reception error (No signal reception) | | | 0 | | | 0 | (page 223) |
| 6832 | - | - | MA remote controller signal transmission error (Synchronization error) | | | 0 | | | 0 | (page 224) |
| 6833 | - | - | MA remote controller signal transmission error (H/ W error) | | | 0 | | | 0 | (page 225) |
| 6834 | - | - | MA controller signal retection error) | eception error (Start bit de- | | 0 | | | 0 | (page 226) |

| | | | | | Sea | ched | unit | | |
|---------------|-----------------------------------|---|---|---|-------------|---------------|---------|-------------------|------------|
| Error Code | Prelimi- nary error code | Error (prelim- inary) detail code | Error code definition | | Indoor unit | BC controller | LOSSNAY | Remote controller | Notes |
| 6840 | - | - | A control communication reception error | | 0 | | | | (page 227) |
| 6841 | - | - | A control communication synchronism not recover | | 0 | | | | (page 227) |
| 6842 | - | - | A control communication transmission/reception hardware trouble | | 0 | | | | (page 228) |
| 6843 | - | - | A control communication start bit detection error | | 0 | | | | (page 229) |
| 6846 | - | - | Start-up time over | | 0 | | | | (page 230) |
| 7100 | - | - | Total capacity error | 0 | | | | | (page 231) |
| 7101 | - | - | Capacity code setting error | 0 | 0 | | 0 | | (page 232) |
| 7102 | - | - | Wrong number of connected units | 0 | | 0 | | | (page 233) |
| 7105 | - | - | Address setting error | 0 | | | | | (page 234) |
| 7106 | - | - | Attribute setting error | | | | 0 | | (page 234) |
| 7107 | - | - | Port setting error | | | 0 | | | (page 235) |
| 7110 | - | - | Connection information signal transmission/reception error | 0 | | | | | (page 236) |
| 7111 | - | - | Remote controller sensor fault | | 0 | | 0 | | (page 236) |
| 7113 | - | - | Function setting error (improper connection of CN-TYP) | 0 | | | | | (page 237) |
| 7117 | - | - | Model setting error | 0 | | | | | (page 238) |
| 7130 | - | - | Incompatible unit combination | 0 | | | | | (page 239) |

Note

1) The last digit in the check error codes in the 4000's and 5000's and two-digit detail codes indicate if the codes apply to inverter on fan inverter.

Example

Code 4225 (detail code 108): Bus voltage drop in the fan inverter system

Code 4230 : Heatsink overheat protection in the inverter system

| The last digit | Inverter system | | | | | |
|----------------|----------------------------|--|--|--|--|--|
| 0 or 1 | Compressor inverter system | | | | | |
| 5 or 6 | Fan inverter system | | | | | |

7-1-1 Inverter Protection Level Table

| INV board | Outdoor units | Overload protection Imax (Arms) | Current effective value error (Arms) | Current peak value error (Apeak) | Temperature protection TOL (°C) |
|--------------|---------------|------------------------------------|--------------------------------------|----------------------------------|---------------------------------|
| | PURY-P72ZKMU | 16 | 23 | 38 | 95 |
| INV34Y | PURY-P96ZKMU | 16 | 23 | 38 | 95 |
| | PURY-P120ZKMU | 22 | 26 | 44 | 95 |
| | PURY-P144ZKMU | 22 | 26 | 44 | 95 |

7-2 Error Code Definitions and Solutions: Codes [0 - 999]

7-2-1 Error Code [0403]

1. Error code definition

Serial communication error

2. Error definition and error detection method

Serial communication error between the control board and the INV board on the compressor, and between the control board and the Fan board

Detail code 1: Between the control board and the INV board

Detail code 5, 6: Between the control board and the Fan board

3. Cause, check method and remedy

(1) Faulty wiring

Check the following wiring connections.

1) Between Control board and Fan board

| Control board | Fan board | relay connector |
|---------------|-----------|-----------------|
| CN61 | CN82 | CNSUB2 |
| CN2A, CN4A | CN80 | - |

2) Between Control board and INV board

| Control board | INV board |
|---------------|-----------|
| CN2,CN61 | CN2 |
| CN4 | CN4 |

P120, P140 models only

3) Between Control board and Fan board 2 (Top)

| Control board | Fan board 2 |
|---------------|-------------|
| CN332 | CN81 |

4) Between Fan board 1 (bottom) and Fan board 2 (top)

| Fan board 1 | Fan board 2 |
|-------------|-------------|
| CN83 | CN80 |

(2) INV board failure, Fan board failure and Control board failure

Replace the INV board or the Fan board or control board when the power turns on automatically, even if the power source is reset.

1. Error code definition

Panel communication error (Indoor unit)

2. Error definition and detection method

This error is detected when indoor units cannot successfully receive the signals from the Auto filter cleaning unit for one minute.

3. Cause, check method and remedy

| | Cause | Check method and remedy |
|-----|--|---|
| (1) | Incorrect switch setting on the indoor unit circuit board | Check SW3-3 on the indoor unit circuit board Set SW3-3 to ON only when connecting an auto filter cleaning unit. |
| (2) | Power wire that connects the circuit board on the indoor unit and the circuit board on the cleaning unit is loose. | Check the LED1 (cleaning unit circuit board (microcomputer power)). Lit: Power is supplied properly. Unlit: Check for loose or disconnected power wire between the indoor unit circuit board (CNAC) and the cleaning unit circuit board (CN3A). |
| (3) | Communication wire that connects the circuit board on the indoor unit and the circuit board on the cleaning unit is loose. | Check the LED4 (cleaning unit circuit board (communication)). Blinking: Normal communication Unlit: Check for loose or disconnected communication wire between the indoor unit circuit board (CN3G) and the cleaning unit |
| (4) | Panel transceiver circuit fault (cleaning unit) | circuit board (CN3G). If the LED blinks at irregular intervals (normally blinks at 0.5-sec- |
| (5) | Panel transceiver circuit fault (indoor unit) | ond intervals), electrical interference is suspected. Check the items above, turn the power off, and turn the power |
| (6) | Electrical interference on the cleaning unit's communication cable | back on. If the error persists, replace either the cleaning unit circuit board or the indoor unit circuit board. |

Note

7-2-2 Error Code [0404]

1. Error code definition

A control communication reception error

2. Error definition and error detection method

Indoor controller board

Abnormal if data cannot be read normally from the nonvolatile memory of the indoor controller board.

| Cause | Check method and remedy |
|-----------------------------------|----------------------------------|
| Defective indoor controller board | Replace indoor controller board. |

7-3 Error Code Definitions and Solutions: Codes [1000 - 1999]

7-3-1 Error Code [1102]

Error code definition Discharge temperature fault

2. Error definition and error detection method

- 1) If the discharge temperature of 120 °C [248°F] or more is detected during the operation (the first detection), the outdoor unit stops once, turns to anti-restart mode for 3 minutes, and restarts after 3 minutes automatically.
- 2) If the discharge temperature of 120° C [248°F] or more is detected again (the second detection) within 30 minutes after the second stop of the outdoor unit described above, the mode will be changed to 3 minute restart mode, then the outdoor unit will restart in 3 minutes.
- 3) If the discharge temperature of 120°C [248°F] or more is detected (the third detection) within 30 minutes after the stop of the outdoor unit described above (regardless of the first or the second stop), the outdoor unit will make an error stop, and the error code "1102" will be displayed.
- 4) If the discharge temperature of 120°C [248°F] or more is detected more than 30 minutes after the previous stop of the outdoor unit, the detection is regarded as the first detection, and the operation described in step 1 above will start.
- 5) For 30 minutes after the stop (the first stop or the second stop) of the outdoor unit, preliminary errors will be displayed on the LED display.

| | Cause | Check method and remedy |
|--|--|--|
| (1) | Gas leak, gas shortage | Refer to the following page(s).[6-3 Evaluating and Adjusting Refrigerant Charge](page 156) |
| (2) | Overload operation | Check operating conditions and operation status of indoor/ outdoor units. |
| (3) (4) (5) (6) (7) (8) | LEV failure on the indoor unit BC controller LEV malfunction Cooling only: LEV3 Cooling main: LEV1,2,3 Heating only or heating main: LEV3 Defrost: LEV3 BC controller SVM1 and 2 malfunction → Cooling only or defrost BC controller SVA malfunction → Cooling only or cooling main BC controller SVB malfunction → Heating only or heating main Solenoid valve SV malfunction (4a,4b,4d (P72, P96 models),4a-4d (P120, P144 mod- | Perform a heating operation and check the operation. Cooling: LEV on the indoor unit LEV1,2,3 SVM1,2 SVA,C Heating: LEV on the indoor unit LEV3 SVB SVB SV4a - 4d Refer to the following page(s). [8-8 Troubleshooting LEV Problems](page 266) |
| (0) | els)) :heating only, heating main | |
| (9) | Port address setting error. | Confirm the port address of the indoor unit. |
| (10) | Closed ball valve | Confirm that the ball valve is fully open. |
| (11) | Outdoor fan (including fan parts) failure, motor failure, or fan controller malfunction Rise in discharge temp. by low pressure drawing for (3) - (11). | Check the fan on the outdoor unit. Refer to the following page(s). [8-7 Troubleshooting Outdoor Unit Fan Problems](page 265) |
| (12) | Gas leak between low and high pressures (4-way valve failure, Compressor failure, Solenoid valve (SV1a) failure) | Perform a cooling or heating operation and check the operation. |
| (13) | Thermistor failure (TH4) | Refer to the following page(s). [7-7-2 Error Codes [5103, 5104, 5105, 5106, 5107]](page 200) |
| (14) | Input circuit failure on the controller board thermistor | Check the inlet air temperature on the LED monitor. |

7-3-2 <u>Error</u> Code [1301]

1. Error code definition Low pressure fault

2. Error definition and error detection method

When starting the compressor from Stop Mode for the first time if low pressure reads 0.098MPa [14psi] immediately before start-up, the operation immediately stops.

| | Cause | Check method and remedy |
|-----|---|---|
| (1) | Inner pressure drop due to a leakage. | Refer to the following page(s). [8-5-3 Comparing the Low- |
| (2) | Low pressure sensor failure | Pressure Sensor Measurement and Gauge Pressure](page 260) |
| (3) | Short-circuited pressure sensor cable due to torn outer rubber | |
| (4) | A pin on the male connector is missing. | |
| (5) | Disconnected wire | |
| (6) | Failure of the low pressure input circuit on the controller board | |

7-3-3 Error Code [1302] (during operation)

1. Error code definition

High pressure fault 1 (Outdoor unit)

2. Error definition and error detection method

- 1) If the pressure of 3.78MPa [548psi] or higher is detected by the pressure sensor during operation (the first detection), the outdoor stops once, turns to antirestart mode for 3 minutes, and restarts after 3 minutes automatically.
- 2) If the pressure of 3.78MPa [548psi] or higher is detected by the pressure sensor again (the second detection) within 30 minutes after the first stop of the outdoor unit, the outdoor unit stops once, turns to anti-restart mode for 3 minutes, and restarts after 3 minutes automatically.
- 3) If the pressure of 3.87MPa [561psi] or higher is detected by the pressure sensor (the third detection) within 30 minutes of the second stop of the outdoor unit, the outdoor unit will make an error stop, and the error code "1302" will be displayed.
- 4) If the pressure of 3.78MPa [548psi] or higher is detected more than 30 minutes after the stop of the outdoor unit, the detection is regarded as the first detection, and the operation described in step 1 above will start.
- 5) For 30 minutes after the stop of the outdoor unit, preliminary errors will be displayed on the LED display.
- 6) The outdoor unit makes an error stop immediately when not only the pressure sensor but also the pressure switch detects 4.15^{+0,-0.15} MPa [601^{+0,-22} psi]
- 7) Open phase due to unstable power supply voltage may cause the pressure switch to malfunction or cause the units to come to an abnormal stop.

| | Cause | Check method and remedy |
|------|---|---|
| (1) | Indoor unit LEV actuation failure | Perform a heating operation and check the operation. |
| (2) | BC controller LEV malfunction Heating only or heating main : Indoor LEV 3 Defrost : LEV3 | Cooling: LEV on the indoor unit LEV1,2,3 SVM1,1b,2,2b |
| (3) | BC controller SVM1 and 2 malfunction →Cooling only or defrost | SVA Heating: LEV on the indoor unit LEV3 |
| (4) | BC controller SVA and SVC malfunction →Cooling only or cooling main | SVM2,2b SVB,SV4a - 4d Refer to the following page(s). [8-8 Troubleshoot- |
| (5) | BC controller SVB malfunction →Heating only or heating main Solenoid valve SV malfunction(4a, 4b, 4d (P72, P96 models) ,4a-4d(P120, P144 models)) →Cooling only or cooling main | ing LEV Problems](page 266) |
| (6) | Port address setting error. | Confirm the port address of the indoor unit. |
| (7) | Refrigerant service valve actuation failure | Confirm that the refrigerant service valve is fully open. |
| (8) | Short cycle on the indoor unit side | Check the indoor units for problems and correct |
| (9) | Clogged filter on the indoor unit | them, if any. |
| (10) | Reduced air flow due to dirty fan on the indoor unit fan | |
| (11) | Dirty heat exchanger of the indoor unit | |
| (12) | Indoor fan (including fan parts) failure or motor failure Items (7) through (12) above reduce the condensing capability of the unit, resulting in high-pressure rise during heating operation. | |
| (13) | Short cycle on the outdoor unit | Check the outdoor units for problems and correct |
| (14) | Dirty heat exchanger of the outdoor unit | them, if any. |
| (15) | Outdoor fan (including fan parts) failure, motor failure, or fan controller malfunction ltems (13) through (15) above reduce the condensing capability of the unit, resulting in high-pressure rise during cooling operation. | Check the fan on the outdoor unit. Refer to the following page(s). [8-7 Troubleshooting Outdoor Unit Fan Problems](page 265) |
| (16) | Solenoid valve (SV1a) malfunction The by-pass valve (SV1a) can not control rise in high pressure. | Refer to the following page(s). [8-6 Troubleshooting Solenoid Valve Problems](page 261) |
| (17) | Thermistor failure (TH3, TH7) | Refer to the following page(s). [7-7-2 Error Codes [5103, 5104, 5105, 5106, 5107]](page 200) |

| | Cause | Check method and remedy |
|--------------|--|---|
| (18) | Pressure sensor failure | Refer to the following page(s). [8-5-1 Comparing the High-Pressure Sensor Measurement and Gauge Pressure](page 259) |
| (19) | Failure of the thermistor input circuit and pressure sensor input circuit on the controller board | Check the sensor temperature/pressure on the LED monitor. |
| (20) (21) | Thermistor mounting problem (TH3, TH7) Disconnected male connector on the pressure switch (63H1) or disconnected wire | Check the sensor temperature/pressure on the LED monitor. |
| (22) | Voltage drop caused by unstable power supply voltage | Check the input voltage at the power supply ter- |
| (22) | voltage drop caused by unstable power supply voltage | minal block (TB1). |

7-3-4 Error Code [1302] (at startup)

1. Error code definition High pressure fault 2 (Outdoor unit)

2. Error definition and error detection method

If the pressure of 0.098MPa [14psi] or lower is registered on the pressure sensor immediately before start-up, it will trigger an abnormal stop, and error code "1302" will be displayed.

| | Cause | Check method and remedy |
|-----|--|---|
| (1) | Inner pressure drop due to a leakage. | Refer to the following page(s). [8-5-1 Comparing the |
| (2) | Pressure sensor failure | High-Pressure Sensor Measurement and Gauge Pressure](page 259) |
| (3) | Shorted-circuited pressure sensor cable due to torn outer rubber | |
| (4) | A pin on the male connector on the pressure sensor is missing or contact failure | |
| (5) | Disconnected pressure sensor cable | |
| (6) | Failure of the pressure sensor input circuit on the controller board | |

7-3-5 Error Code [1500]

1. Error code definition Refrigerant overcharge

2. Error definition and error detection method

An error can be detected by the discharge temperature superheat.

- 1) If the formula "TdSH ≤10°C [18°F]" is satisfied during operation (first detection), the outdoor unit stops, goes into the 3-minute restart mode, and starts up in three minutes.
- 2) If the formula "TdSH ≤10°C [18°F]" is satisfied again within 30 minutes of the first stoppage of the outdoor unit (second detection), the unit comes to an abnormal stop, and the error code "1500" appears.
- 3) If the formula "TdSH ≤10°C [18°F]" is satisfied 30 minutes or more after the first stoppage of the outdoor unit, the same sequence as Item "1 above (first detection) is followed.
- 4) For 30 minutes after the stop of the outdoor unit, preliminary errors will be displayed on the LED display.

An error can be detected based on the compressor bottom SH (TH15 - Te)

- 5) If the formula "compressor bottom SH (TH15 Te) ≤ 10°C [18°F]" is satisfied during operation (first detection), the outdoor unit stops, goes into the 3-minute restart mode, and starts up in three minutes.
- 6) If the formula "compressor bottom SH (TH15 Te) ≤ 10°C [18°F]" is satisfied again within 40 minutes of the first stoppage of the outdoor unit (second detection), the unit comes to an abnormal stop, and the error code "1500" appears.
- 7) If the formula "compressor bottom SH (TH15 Te) ≤ 10°C [18°F]" is satisfied 40 minutes or more after the first stoppage of the outdoor unit, the same sequence as Item 5) above (first detection) is followed.
- 8) For 40 minutes after the stop of the outdoor unit, preliminary errors will be displayed on the LED display.
- 9) If the formula "compressor bottom SH (TH15 Te) ≤ 10°C [18°F]" is satisfied during the defrost operation and if the formula "compressor bottom SH (TH15 Te) ≤ 10°C [18°F]" is also satisfied after the defrost operation, the same sequence as Item 5) above (first detection) is followed.

| | Cause | Check method and remedy |
|-----|---|--|
| (1) | Overcharged refrigerant | Refer to the following page(s). [6-3 Evaluating and Adjusting Refrigerant Charge](page 156) |
| (2) | Thermistor input circuit failure on the control board | Check the temperature and pressure readings on the sensor that are displayed on the LED monitor. |
| (3) | Faulty mounting of thermistor (TH4) | Check the temperature reading on the thermistor that are displayed on the LED monitor. |
| (4) | Faulty mounting of thermistor (TH15) | Check the temperature reading on the thermistor that is displayed on the LED monitor. |

7-4 Error Code Definitions and Solutions: Codes [2000 - 2999]

7-4-1 Error Code [2500] (Models with a drain sensor)

1. Error code definition Drain sensor submergence

2. Error definition and error detection method

- 1) If an immersion of the drain sensor in the water is detected while the unit is in any mode other than the Cool/Dry mode and when the drain pump goes from OFF to ON, this condition is considered preliminary water leakage. While this error is being detected, humidifier output cannot be turned on.
- 2) If the immersion of the sensor in the water is detected four consecutive times at an hour interval, this is considered water leakage, and "2500" appears on the monitor.
- 3) Detection of water leakage is also performed while the unit is stopped.
- 4) Preliminary water leakage is cancelled when the following conditions are met:
 - •One hour after the preliminary water leakage was detected, it is not detected that the drain pump goes from OFF to ON.
 - •The operation mode is changed to Cool/Dry.
 - •The liquid pipe temperature minus the inlet temperature is -10°C [-18°F] or less.

| | Cause | | Check method and remedy |
|-----|---|----------|---|
| (1) | Drain water drainage problem Clogged drain pump Clogged drain piping Backflow of drain water from other units | | Check for proper drainage. |
| (2) | Adhesion of water drops to the drain sensor Trickling of water along the lead wire Rippling of drain water caused by filter clogging | 1) 2) | Check for proper lead wire installation. Check for clogged filter. |
| (3) | Failure of the relay circuit for the solenoid valve | | Replace the relay. |
| (4) | Indoor unit control board failure Drain sensor circuit failure | | If the above item checks out OK, replace the indoor unit control board. |

7-4-2 Error Code [2500] (Models with a float switch)

1. Error code definition Drain sensor submergence

2. Error definition and error detection method


- 1) If an immersion of the float switch in the water is detected while the unit is in any mode other than the Cool/Dry mode and when the drain pump goes from OFF to ON, this condition is considered preliminary water leakage. While this error is being detected, humidifier output cannot be turned on.
- 2) If the drain pump turns on within one hour after preliminary water leakage is detected and the above-mentioned condition is detected two consecutive times, water leakage error water leakage is detected, and "2500" appears on the monitor.
- 3) Detection of water leakage is also performed while the unit is stopped.
- 4) Preliminary water leakage is cancelled when the following conditions are met:
 - •One hour after the preliminary water leakage was detected, it is not detected that the drain pump goes from OFF to ON.
 - •The operation mode is changed to Cool/Dry.
 - •The liquid pipe temperature minus the inlet temperature is 10°C [-18°F] or less.

3. Cause, check method and remedy

| | Cause | Check method and remedy |
|-----|--|--|
| (1) | Drain water drainage problem Clogged drain pump Clogged drain piping Backflow of drain water from other units | Check for proper drainage. |
| (2) | Stuck float switch Check for slime in the moving parts of the float switch. | Check for normal operation of the float switch. |
| (3) | Float switch failure | Check the resistance with the float switch turned on and turned off. |

<Reference>

Drain pump operation triggered by a submergence of the liquid level sensor (except during the Cooing/Dry mode)



7-4-3 Error Code [2502] (Models with a drain sensor)

1. Error code definition Drain pump fault

2. Error definition and error detection method

- 1) Make the drain sensor thermistor self-heat. If the temperature rise is small, it is interpreted that the sensor is immersed in water. This condition is considered to be a preliminary error, and the unit goes into the 3-minute restart delay mode.
- 2) If another episode of the above condition is detected during the preliminary error, this is considered a drain pump error, and "2502" appears on the monitor.
- 3) This error is always detected while the drain pump is in operation.
- 4) The following criteria are met when the criteria for the forced stoppage of outdoor unit (system stoppage) are met.
 - *"Liquid pipe temperature inlet temperature ≤-10°C [-18 °F] " has been detected for 30 minutes.
 - *The immersion of drain sensor is detected 10 consecutive times.
 - *The conditions that are listed under items 1) through 3) above are always met before the criteria for the forced stoppage of the outdoor unit.
- 5) The indoor unit that detected the conditions that are listed in item 4) above brings the outdoor unit in the same refrigerant circuit to an error stop (compressor operation prohibited), and the outdoor unit brings all the indoor units in the same refrigerant circuit that are in any mode other than Fan or Stop to an error stop. "2502" appears on the monitor of the units that came to an error stop.
- 6) Forced stoppage of the outdoor unit
 - Detection timing: The error is detected whether the unit is in operation or stopped.
- 7) Ending criteria for the forced stoppage of outdoor unit
 - Power reset the indoor unit that was identified as the error source and the outdoor unit that is connected to the same refrigerant circuit.

Forced stoppage of the outdoor unit cannot be cancelled by stopping the unit via the remote controller.

(Note) Items 1) - 3) and 4) - 7) are detected independently from each other.

Note

The address and attribute that appear on the remote controller are those of the indoor unit (or OA processing unit) that caused the error.

| | Cause | | Check method and remedy |
|-----|--|----------|---|
| (1) | Drain pump failure | | Check for proper functioning of the drain pump. |
| (2) | Drain water drainage problem •Clogged drain pump •Clogged drain piping | | Check for proper drainage. |
| (3) | Adhesion of water drops to the drain sensor •Trickling of water along the lead wire •Rippling of drain water caused by filter clogging | 1) 2) | Check for proper lead wire installation. Check for clogged filter. |
| (4) | Indoor unit control board failure *Drain pump drive circuit failure *Drain heater output circuit failure | | If the above item checks out OK, replace the indoor unit control board. |
| (5) | Items (1) through (4) above and an indoor unit electronic valve closure failure (leaky valve) occurred simultaneously. | | Check the solenoid valves on the indoor unit for leaks. |

7-4-4 Error Code [2502] (Models with a float switch)

Error code definition Drain pump fault

2. Error definition and error detection method

- 1) The immersion of sensor tip in water is detected by the ON/OFF signal from the float switch.
 - *Submergence of the sensor
 - When it is detected that the float switch has been ON for 15 seconds, it is interpreted that the sensor tip is immersed in water.
 - *Sensor in the air
 - When it is detected that the float switch has been OFF for 15 seconds, it is interpreted that the sensor tip is not immersed in water.
- 2) If it is detected that the float switch has been ON for 3 minutes after the immersion of the sensor tip was detected, this is considered a drain pump failure, and "2502" appears on the monitor.
 - *The total time it takes for this error to be detected is 3 minutes and 15 seconds, including the time it takes for the first immersion of the sensor tip to be detected.
- 3) Detection of drain pump failure is performed while the unit is stopped.
- 4) The following criteria are met when the criteria for the forced stoppage of outdoor unit (system stoppage) are met.
 - *"Liquid pipe temperature inlet temperature ≤- 10°C [-18°F] " has been detected for 30 minutes.
 - *It is detected by the float switch that the sensor tip has been immersed in water for 15 minutes or more.
 - *The conditions that are listed under items 1) through 3) above are always met before the criteria for the forced stoppage of the outdoor unit.
- 5) The indoor unit that detected the conditions that are listed in item 4) above brings the outdoor unit in the same refrigerant circuit to an error stop (compressor operation prohibited), and the outdoor unit brings all the indoor units in the same refrigerant circuit that are in any mode other than Fan or Stop to an error stop.
- 6) Forced stoppage of the outdoor unit
 - Detection timing: The error is detected whether the unit is in operation or stopped.
 - This error is detected whether the unit is in operation or stopped.
- 7) Ending criteria for the forced stoppage of outdoor unit
 - Power reset the indoor unit that was identified as the error source and the outdoor unit that is connected to the same refrigerant circuit.
 - Forced stoppage of the outdoor unit cannot be cancelled by stopping the unit via the remote controller.
 - (Note) Items 1) 3) and 4) 7) are detected independently from each other.

Note

The address and attribute that appear on the remote controller are those of the indoor unit (or OA processing unit) that caused the error.

| | Cause | Check method and remedy |
|-----|--|--|
| (1) | Drain pump failure | Check for proper functioning of the drain pump mechanism |
| (2) | Drain water drainage problem Clogged drain pump Clogged drain piping | Check for proper drainage. |
| (3) | Stuck float switch Check for slime in the moving parts of the float switch. | Check for normal operation of the float switch. |
| (4) | Float switch failure | Check the resistance with the float switch turned on and turned off. |
| (5) | Indoor unit control board failure •Drain pump drive circuit failure •Float switch input circuit failure | Replace indoor unit control board. |
| (6) | Items (1) through (5) above and an indoor unit electronic valve closure failure (leaky valve) occurred simultaneously. | Check the solenoid valves on the indoor unit for leaks. |

7-4-5 Error Code [2503]

1. Error code definition Drain sensor (Thd) fault

2. Error definition and error detection method

- •If the open or short circuit of the thermistor has been detected for 30 seconds, this condition is considered to be a preliminary error, and the unit goes into the 3-minute restart delay mode.
- •If another episode of the above condition is detected during the preliminary error, this is considered a drain sensor error.(If the short or open circuit of the thermistor is no longer detected, normal operation will be restored in 3 minutes.)
- •This error is detected when one of the following conditions are met.
 - *During Cool/Dry operation
 - *Liquid pipe temperature minus inlet temperature is equal to or smaller than 10°C [-18°F] (except during the defrost cycle)
 - *When the liquid temperature thermistor or suction temperature thermistor or short or open circuited.
 - *Drain pump is in operation.
 - *One hour has elapsed since the drain sensor went off.

Short: 90°C [194 °F] or above Open: - 20°C [-4 °F] or below

| | Cause | | Check method and remedy |
|-----|---|----|---|
| (1) | Faulty connector (CN31) insertion. | 1) | Check for connector connection failure. Reinsert the connector, restart the operation, and check for proper operation. |
| (2) | Broken or semi-broken thermistor wire | 2) | Check for a broken thermistor wire. |
| (3) | Thermistor failure | 3) | Check the resistance of the thermistor. $0^{\circ}\text{C}[32\ ^{\circ}\text{F}]:6.0\ k\Omega$ $10^{\circ}\text{C}[50\ ^{\circ}\text{F}]:3.9\ k\Omega$ $20^{\circ}\text{C}[68^{\circ}\text{F}]:2.6\ k\Omega$ $30^{\circ}\text{C}[86^{\circ}\text{F}]:1.8\ k\Omega$ $40^{\circ}\text{C}[104\ ^{\circ}\text{F}]:1.3\ k\Omega$ |
| (4) | Indoor unit control board (error detection circuit) failure | 4) | Replace the indoor unit control board if the problem recurs when the unit is operated with the No1 and No2 pins on the drain sensor connector (CN31) being short-circuited. If the above item checks out OK, there are no problems with the drain sensor. Turn off the power and turn it back on. |

7 Troubleshooting Using Error Codes

7-4-6 Error Code [2600]

1. Error code definition Water leakage

2. Cause, check method and remedy

Check that water does not leak from the pipes in such as the humidifier.

7-4-7 Error Code [2601]

1. Error code definition Water supply cutoff

| | Cause | Check method and remedy |
|-----|---|--|
| (1) | The water tank of the humidifier is empty. | Check the amount of supply water. Check for the solenoid valve and for the connection. |
| (2) | The solenoid valve for humidification is OFF. | Check the connector. |
| (3) | Disconnected float switch | Check the connecting part. |
| (4) | Poor operation of float switch | Check for the float switch. |
| (5) | Frozen water tank | Turn off the power source of the water tank to defrost, and turn it on again. |

7-5 Error Code Definitions and Solutions: Codes [3000 - 3999]

7-5-1 Error Code [3121]

1. Error code definition

Out-of-range outside air temperature

2. Error definition and error detection method

- •When the thermistor temperature of -28°C[-18°F] or below has continuously been detected for 3 minutes during heating operation (during compressor operation), the unit makes an error stop and "3121" appears on the display. (Use the OC thermistor temperature to determine when two outdoor units are in operation.)
- •The compressor restarts when the thermistor temperature is -26°C[-15°F] or above (both OC and OS) during error stop. (The error display needs to be canceled by setting the remote controller.)
- •Outdoor temperature error is canceled if the units stop during error stop. (The error display needs to be canceled by setting the remote controller.)

3. Cause, check method and remedy

Check the following factors if an error is detected, without drop in the outdoor temperature.

| | Cause | Check method and remedy |
|-----|---|---|
| (1) | Thermistor failure | Check thermistor resistance. |
| (2) | Pinched lead wire | Check for pinched lead wire. |
| (3) | Torn wire coating | Check for wire coating. |
| (4) | A pin on the male connector is missing or contact failure | Check connector. |
| (5) | Disconnected wire | Check for wire. |
| (6) | Thermistor input circuit failure on the control board | Check the intake temperature of the sensor with the LED monitor. When the temperature is far different from the actual temperature, replace the control board. |

<Reference>

 $\begin{tabular}{ll} Short detection & Open detection \\ TH7 & 110 \ ^{\circ}C \ [230 \ ^{\circ}F \] \ and \ above \ (0.4 \ k \ \Omega) & -40 \ ^{\circ}C \ [-40 \ ^{\circ}F \] \ and \ below \ (130 \ k \ \Omega) \\ \end{tabular}$

7-6 Error Code Definitions and Solutions: Codes [4000 - 4999]

7-6-1 Error Code [4102]

1. Error code definition Open phase

2. Error definition and error detection method

- •An open phase of the power supply (L1 phase, L2 phase) was detected at power on.
- •The L3 phase current is outside of the specified range.

Note

The open phase of the power supply may not always be detected if a power voltage from another circuit is applied.

| | Cause | Check method and remedy |
|-----|--|--|
| (1) | Power supply problem Open phase voltage of the power supply Power supply voltage drop | Check the input voltage to the power supply terminal block TB1. |
| (2) | Noise filter problem Coil problem Circuit board failure | Check the coil connections. Check for coil burnout. Check that the voltage across TB11 and TB21 on the noise filter board is 517.5V or above. |
| (3) | Wiring failure | Confirm that the voltage at the control board connector CNAC is 190 V or above. If the voltage is below 190, check the wiring between noise filter CN6, noise filter CNTR, transformer box or sub box, and control board CNAC. Confirm that the wiring between noise filter TB31 and INV board SC-L3 is put through CT3. |
| (4) | Blown fuse | Check F01 on the control board, noise filter for a blown fuse F01 and F02. →If a blown fuse is found, check for a short-circuiting or earth fault of the actuator. |
| (5) | CT3 failure | Replace the inverter if this problem is detected after the compressor has gone into operation. |
| (6) | Control board failure | Replace the control board if none of the above is causing the problem. |

7-6-2 Error Code [4106]

1. Error code definition

<Transmission power supply fault Error detail code FF (Outdoor unit)>

2. Error definition and error detection method

Transmission power output failure

3. Cause

- 1) Wiring failure
- 2) Transmission power supply cannot output voltage because overcurrent was detected.
- 3) Voltage cannot be output due to transmission power supply problem.
- 4) Transmission voltage detection circuit failure

4. Check method and remedy

Check the transmission power supply circuit on all outdoor units in a given refrigerant circuit for problems. [8-11-2 Troubleshooting Problems with Outdoor Unit Transmission Power Supply Circuit](page 296)

1. Error code definition

<Transmission power supply fault other than error detail code FF (Outdoor unit)>

2. Error definition and error detection method

Transmission power reception failure

3.Cause

One of the outdoor units stopped supplying power, but no other outdoor units start supplying power.

4.Check method and remedy

Check the transmission power supply circuit on all outdoor units in a given refrigerant circuit for problems. [8-11-2 Troubleshooting Problems with Outdoor Unit Transmission Power Supply Circuit](page 296)

7-6-3 Error Code [4109]

1. Error code definition

Indoor unit fan operation error

2. Error definition and error detection method

1) During operation, it has been continuously detected for 100 seconds that the auxiliary relay (X13) for fan fault detection is not excited.

| | Cause | Check method and remedy |
|-----|---|---|
| (1) | Auxiliary relay (X13) fault | Coil failure, disconnected coil |
| (2) | Connector (CN28) is disconnected. | Check the connector for proper connection. |
| (3) | Blown fuse | Check the fuse on the control circuit board. |
| (4) | Motor error (thermistor error inside the motor) | Check the unit fan for proper operation in the test run mode. If no problems are found with items 1 through 3 above and the fan does not operate, replace the motor. |

7-6-4 Error Code [4114]

Error code definition Indoor unit fan motor error

2. Error definition and error detection method

When the fan motor output from the indoor unit circuit board is ON and when the rotation speed input from the fan motor cannot be detected for 30 seconds or more

3. Cause, check method and remedy

| Cause | | Check method and remedy | |
|-------|--|---|--|
| (1) | Fan motor connector contact failure | Check the fan motor connector CNMF for proper connection. | |
| (2) | Contact failure of the relay connector for the fan motor | Check the relay connector for the fan motor for proper connection. | |
| (3) | Indoor unit circuit board failure | Remove the fan motor connector CNMF and check the voltage at the indoor unit circuit board. Testing point 1. 280 VDC (Between CNMF1 (+) and CNMF4 (-)) 2. 15 VDC (Between CNMF5 (+) and CNMF4 (-)) Replace the indoor unit circuit board if the voltage is abnormal. If the 4114 error persists after the indoor unit circuit board is replaced, replace the fan motor as well. | |
| (4) | Fan motor fault | Replace the fan motor if the voltage is normal in step (3) above. If the 4114 error persists after the fan motor is replaced, replace the indoor unit circuit board as well. | |

7-6-5 Error Code [4115]

1. Error code definition Power supply signal sync error

2. Error definition and error detection method

The frequency cannot be determined when the power is switched on.

| | Cause | Check method and remedy |
|-----|--|--|
| (1) | Power supply error | Check the voltage of the power supply terminal block (TB1). |
| (2) | Noise filter problem •Coil problem •Circuit board failure | Check the coil connections. Check for coil burnout. Check that the voltage across TB11 and TB21 on the noise filter board is 517.5V or above. |
| (3) | Blown fuse | Check F01 on the control board, F01, and F02 for a noise filter. |
| (4) | Wiring failure Between noise filter CN6, noise filter CNTR, transformer box or sub box, and control board CNAC | Confirm that the voltage at the control board connector CNAC is 190 V or above. |
| (5) | Control board failure | If none of the items described above is applicable, and if the trouble reappears even after the power is switched on again, replace the control board. |

7-6-6 Error Code [4116]

1. Error code definition RPM error/Motor error

2. Error definition and error detection method

- *LOSSNAY
 - *The motor keep running even if the power is OFF.
 - *The thermal overload relay is ON. (Only for the three-phase model)
- Indoor unit

If detected less than 180rpm or more than 2000rpm, the indoor unit will restart and keep running for 3 minutes. If detected again, the display will appear.

3. Cause, check method and remedy

| | Cause | Check method and remedy |
|-----|-----------------------------|--|
| (1) | Board failure | Replace the board. |
| (2) | Motor malfunction | Check for the motor and the solenoid switch. |
| (3) | Solenoid switch malfunction | |

7-6-7 Error Code [4121]

1. Error code definition Function setting error

2. Error source, cause, check method and remedy

| Error source | Cause | Check method and remedy |
|--------------|---|--|
| Outdoor unit | (1) Dip switch setting error on the control board | Check the SW6-1 setting on the control board |
| | (2) Connector connection error on the control board | Check that nothing is connected to the connector CNAF on the control board. |
| | (3) Control board failure | Replace the control board if no problems are found with the two items above. |

7-6-8 Error Code [4124]

1. Error code definition

Electric system not operate due to damper abnormality

2. Error definition and error detection method

When the damper is not located at the designated position.

3. Cause, check method and remedy

When the damper is not located at the designated position.

- 1) Check there is something that interferes the opening or closing movement of the damper.
- 2) If damper does not open or close, turn OFF the power supply and measure the resistance of the damper lock motors (ML1, ML2) and the damper motor (MV2).

The resistance value is normal each. →Replace the indoor electronic control P.C. board.

The resistance value is not normal each. →Replace the motor that indicates the abnormal value.

| Part name | Check n | Figure | | |
|--------------------------------|--|---------------------|-----------------------|---------------|
| Damper lock motor Right(ML1) | Measure the resistance I (Part temperature: 10°C | | | |
| Damper lock motor Left(ML2) | Color of the lead wire BRN-other one | Normal 235Ω~255Ω | | RED ROTOR |
| Damper motor | Measure the resistance I (Part temperature: 10°C | | ninals with a tester. | YLW BRN CONTO |
| (MV2) | Color of the lead wire BRN-other one | Normal 282Ω~306Ω | | ORN GRN |

3) If damper opens or closes, measure the voltage between CN1X1 (+) and (-) and the voltage between CN1Y1 (+) and (-) during the damper open by pressing VANE CONTROL button.

There is not 0V DC between CN1X1 (+) and (-). →Replace the damper limit switch (open)


There is not 5V DC between CN1X1 (+) and (-). →Replace the damper limit switch (close)

4) If damper opens or closes and voltages in 3) are normal, measure the voltage between CN1X1 (+) and (-) and the voltage between CN1Y1 (+) and (-) during the damper close by pressing VANE CONTROL button.

There is not 5V DC between CN1X1 (+) and (-). →Replace the damper limit switch (open)

There is not 0V DC between CN1X1 (+) and (-). →Replace the damper limit switch (close)

There is 5V DC between CN1X1 (+) and (-) and 0V DC between CN1X1 (+) and (-). →Replace the indoor electronic control P.C. board.



7-6-9 Error Codes [4220, 4225, 4226] Detail Code 108

1. Error code definition

Abnormal bus voltage drop (Detail code 108)

2. Error definition and error detection method

If Vdc 437V or less is detected during Inverter operation. (S/W detection)

3. Cause, check method and remedy

(1) Power supply environment

Find out if there was a (momentary) power failure.

Check whether the power voltage (Between L1 and L2, L2 and L3, and L1 and L3) is 518 V or less across all phases.

(2) Voltage drop detected

4220

- •Check the voltage between the FT-P and FT-N terminals on the INV board while the inverter is stopped and if it is 630 V or above, check the following items.
 - 1) Confirm on the LED monitor that the bus voltage is above 437 V.

Replace the INV board if it is below 437 V.

- 2) Check the voltage at CN503 on the control board. →Go to (3).
- 3) Check the noise filter coil connections and for coil burnout.
- 4) Check the wiring connections between the following sections

Between the noise filter board and INV board. Between the INV board and DCL.

Replace 52C if no problems are found.

- 5) Check the IGBT module resistance on the INV board. Refer to the following page(s). [8-10-14 Troubleshooting Problems with IGBT Module](page 292)
- •Check the voltage between the FT-P and FT-N terminals on the INV board while the inverter is stopped and if it is less than 630V, check the following items.
 - 1) Check the coil connections and for coil burnout on the noise filter.
 - 2) Check the wiring between the noise filter board and INV board.
 - 3) Check the connection to SC-L1 and SC-L2 on the INV board.
 - 4) Check the in-rush current resistor value.
 - 5) Check the 52C resistance value.
 - 6) Check the DCL resistance value.

Replace the INV board if no problems are found.

4225 (P120 and P144: The following applies to the bottom fan board in the sub box.)

- •Check the voltage at CNVDC on the Fan board while the inverter is stopped and if it is 630 V or above, check the following items.
 - 1) Check the voltage at CN503 on the control board. →Go to 3).
 - 2) Check the noise filter coil connections and for coil burnout.
 - 3) Check the wiring connections between the following sections

Between the noise filter board INV board and the Fan board.

4) Check contents 4220

Replace the Fan board if no problems are found.

- •Check the voltage at CNVDC on the Fan board while the inverter is stopped and if it is less than 630 V, check the following items
 - 1) Check the state of the wiring connections between the INV board and the Fan board.
 - 2) Check contents 4220

Replace the Fan board if no problems are found.

*Note) P72 and P96 models: Switch off the power, pivot the control box away from the unit on the hinges to access the components behind it, and switch the power back on. Measure the voltages on the fan controller board in the sub box.

In case of 4226 (P120 and P144: The following applies to the top fan board in the sub box.)

- •Check the voltage at CNVDC on the Fan board while the inverter is stopped and if it is 630 V or above, check the following items.
 - 1) Check the voltage at CN503 on the control board. →Go to 3).
 - 2) Check the noise filter coil connections and for coil burnout.
 - 3) Check the wiring connections between the following sections

Between the noise filter board, INV board, and the Fan board.

4) Check contents 4220

Replace the Fan board if no problems are found.

- •Check the voltage at CNVDC on the Fan board while the inverter is stopped and if it is less than 630 V, check the following items.
 - 1) Check between noise filter board, INV board, and fan board.
 - 2) Check contents 4220

Replace the Fan board if no problems are found.

(3) Control board failure

Check that 230VAC is applied to connector CN503 on the control board while the inverter is operating. If voltage is absent or the wrong voltage is applied, check the fuse F01. Replace the control board if no problems are found with the fuse.

Note

For inverter-related error codes, refer to the following page(s). [8-10 Troubleshooting Inverter Problems](page 284)

7-6-10 Error Codes [4220, 4225, 4226] Detail Code 109

1. Error code definition

Abnormal bus voltage rise (Detail code 109)

2. Error definition and error detection method

If Vdc ≥1010V is detected during inverter operation.

3. Cause, check method and remedy

(1) Different voltage connection

Check the power supply voltage on the power supply terminal block (TB1).

(2) INV board failure

If the problem recurs, replace the INV board or fan board.

In the case of 4220: INV board

In the case of 4225: Fan board (P120 and P144: Bottom fan board inside the sub box)

In the case of 4226: Fan board (P120 and P144: Top fan board inside the sub box)

Note

7-6-11 Error Codes [4220, 4225, 4226] Detail Code 111

1. Error code definition

Logic error (Detail code 111)

2. Error definition and error detection method

H/W error

If only the H/W error logic circuit operates, and no identifiable error is detected.

3. Cause, Check method and remedy

In the case of 4220

| Cause | | Check method and remedy |
|-------|-------------------|--|
| (1) | External noise | |
| (2) | INV board failure | Refer to the following page(s). [8-10-2 Checking the Inverter Board Error Detection Circuit](page 287) |

In the case of 4225 and 4226

| | Cause | Check method and remedy |
|-----|-------------------|---|
| (1) | External noise | |
| (2) | Fan board failure | Refer to the following page(s). [8-10-7 Checking the Fan Board Error Detection Circuit at No Load](page 289) [8-10-8 Checking the Fan Inverter for Damage at No Load](page 289) [8-10-9 Checking the Fan Inverter for Damage with Load](page 290) |

Note

7-6-12 Error Codes [4220, 4225, 4226] Detail Code 131

1. Error code definition

Low bus voltage at startup (Detail code 131)

2. Error definition and error detection method

When Vdc ≤437 V is detected just before the inverter operation.

3. Cause, check method and remedy

(1) Inverter main circuit failure

Same as detail code 108 of 4220 error

Note

For inverter-related error codes, refer to the following page(s). [8-10 Troubleshooting Inverter Problems](page 284)

7-6-13 Error Code [4230]

1. Error code definition

Heatsink overheat protection

2. Error definition and error detection method

When the heat sink temperature (THHS) remains at or above 105°C [221°F] is detected.

3. Cause, check method and remedy

| | Cause | | Check method and remedy |
|-----|--------------------------|----|---|
| (1) | Fan board failure | | Refer to the following page(s). [8-10-7 Checking the Fan Board Error Detection Circuit at No Load](page 289) [8-10-8 Checking the Fan Inverter for Damage at No Load](page 289) [8-10-9 Checking the Fan Inverter for Damage with Load](page 290) |
| (2) | Outdoor unit fan failure | | Check the outdoor unit fan operation. If any problem is found with the fan operation, check the fan motor. Refer to the following page(s). [8-10-6 Checking the Fan Motor for Ground Fault and Coil Resistance Problems](page 289) |
| (3) | Air passage blockage | | Check that the heat sink cooling air passage is not blocked |
| (4) | THHS failure | 1) | Check for proper installation of the INV board IGBT. (Check for proper installation of the IGBT heatsink.) |
| | | 2) | Check the THHS sensor reading on the LED monitor. →If an abnormal value appears, replace the INV board. |

Note

7-6-14 Error Code [4240]

1. Error code definition Overload protection

2. Error definition and error detection method

If the output current of "(lac) >Imax (Arms)" or "THHS > TOL" is continuously detected for 10 minutes or more during inverter operation.

Refer to the relevant pages for the details of model names and the specified values. [7-1-1 Inverter Protection Level Table](page 169)

3. Cause, check method and remedy

| | Cause | Check method and remedy |
|-----|--------------------------|---|
| (1) | Air passage blockage | Check that the heat sink cooling air passage is not blocked |
| (2) | Power supply environment | Power supply voltage is 518 V or above. |
| (3) | Inverter failure | Refer to the following page(s). [8-10 Troubleshooting Inverter Problems](page 284) |
| (4) | Compressor failure | Check that the compressor has not overheated during operation. → Check the refrigerant circuit (oil return section). Refer to the following page(s). [8-10-3 Checking the Compressor for Ground Fault and Coil Resistance Problems](page 287) |

Note

7-6-15 Error Codes [4250, 4255, 4256] Detail Code 101

1. Error code definition

IPM error (Detail code 101)

2. Error definition and error detection method

In the case of 4250

Overcurrent is detected by the overcurrent detection resistor (RSH) on the INV board.

In the case of 4255 and 4256

IPM error signal is detected.

3. Cause, check method and remedy

In the case of 4250

| Cause | Check method and remedy |
|-----------------------------|--|
| (1) Inverter output related | Refer to the following page(s). [8-10-2 Checking the Inverter Board Error Detection Circuit](page 287) [8-10-3 Checking the Compressor for Ground Fault and Coil Resistance Problems](page 287) [8-10-4 Checking the Inverter for Damage at No-Load](page 287) [8-10-5 Checking the Inverter for Damage during Compressor Operation](page 288) [8-10-10 Checking the Installation Conditions](page 290) Check the IGBT module resistance value of the INV board, if no problems are found. [8-10-14 Troubleshooting Problems with IGBT Module](page 292) |

In the case of 4255 and 4256

| | Cause | Check method and remedy |
|-----|-----------------------|---|
| (1) | Fan motor abnormality | Refer to the following page(s). [8-10-6 Checking the Fan Motor for Ground Fault and Coil Resistance Problems](page 289) |
| (2) | Fan board failure | Refer to the following page(s). [8-10-7 Checking the Fan Board Error Detection Circuit at No Load](page 289) [8-10-8 Checking the Fan Inverter for Damage at No Load](page 289) [8-10-9 Checking the Fan Inverter for Damage with Load](page 290) |

Note

7-6-16 Error Codes [4250, 4255, 4256] Detail Code 104

1. Error code definition

Short-circuited IPM/Ground fault (Detail code 104)

2. Error definition and error detection method

When IPM/IGBT short damage or grounding on the load side is detected just before starting the inverter.

3. Cause, check method and remedy

In the case of 4250

| | Cause | Check method and remedy |
|-----|----------------------------|---|
| (1) | Grounding fault compressor | Refer to the following page(s). [8-10-3 Checking the Compressor for Ground Fault and Coil Resistance Problems](page 287) |
| (2) | Inverter output related | Refer to the following page(s). [8-10-2 Checking the Inverter Board Error Detection Circuit](page 287) [8-10-3 Checking the Compressor for Ground Fault and Coil Resistance Problems](page 287) [8-10-4 Checking the Inverter for Damage at No-Load](page 287) [8-10-5 Checking the Inverter for Damage during Compressor Operation](page 288) [8-10-10 Checking the Installation Conditions](page 290) |

In the case of 4255 and 4256

| | Cause | Check method and remedy |
|-----|------------------------------|---|
| (1) | Grounding fault of fan motor | Refer to the following page(s). [8-10-6 Checking the Fan Motor for Ground Fault and Coil Resistance Problems](page 289) |
| (2) | Fan board fail- ure | Refer to the following page(s). [8-10-7 Checking the Fan Board Error Detection Circuit at No Load](page 289) [8-10-8 Checking the Fan Inverter for Damage at No Load](page 289) [8-10-9 Checking the Fan Inverter for Damage with Load](page 290) |

Note

For inverter-related error codes, refer to the following page(s).

[8-10 Troubleshooting Inverter Problems](page 284)

7-6-17 Error Codes [4250, 4255, 4256] Detail Code 105

1. Error code definition

Overcurrent error due to short-circuited motor (Detail code 105)

2. Error definition and error detection method

When a short is detected on the load side just before starting the inverter operation.

3. Cause, Check method and remedy

In the case of 4250

| | Cause | Check method and remedy |
|-----|------------------------------|--|
| (1) | Short - circuited compressor | Refer to the following page(s). [8-10-3 Checking the Compressor for Ground Fault and Coil Resistance Problems](page 287) |
| (2) | Output wiring | Check for a short circuit. |

In the case of 4255 and 4256

| | Cause | Check method and remedy |
|-----|-----------------------------|--|
| (1) | Short - circuited fan motor | Refer to the following page(s). [8-10-6 Checking the Fan Motor for Ground Fault and Coil Resistance Problems](page 289) |
| (2) | Output wiring | Check for a short circuit. |

Note

7-6-18 Error Code [4250] Detail Codes 106 and 107

1. Error code definition

Instantaneous overcurrent (Detail code 106) Overcurrent (effective value) (Detail code 107)

2. Error definition and error detection method

When a current above the specified value is detected by the electric current sensor.

Refer to the relevant pages for the details of model names and the specified values. [7-1-1 Inverter Protection Level Table](page 169)

3. Cause, check method and remedy

| | Cause | Check method and remedy |
|-----|-------------------------|--|
| (1) | Inverter output related | Refer to the following page(s). [8-10-2 Checking the Inverter Board Error Detection Circuit](page 287) [8-10-3 Checking the Compressor for Ground Fault and Coil Resistance Problems](page 287) [8-10-4 Checking the Inverter for Damage at No-Load](page 287) [8-10-5 Checking the Inverter for Damage during Compressor Operation](page 288) [8-10-10 Checking the Installation Conditions](page 290) Check the IGBT module resistance value of the INV board, if no problems are found. [8-10-14 Troubleshooting Problems with IGBT Module](page 292) |

Note

For inverter-related error codes, refer to the following page(s). [8-10 Troubleshooting Inverter Problems](page 284)

7-6-19 Error Code [4260]

1. Error code definition

Heatsink overheat protection at startup

2. Error definition and error detection method

The heatsink temperature (THHS) remains at or above 100°C [212°F] for 10 minutes or more at inverter startup.

3. Cause, check method and remedy

Same as 4230 error

7-7 Error Code Definitions and Solutions: Codes [5000 - 5999]

7-7-1 Error Codes [5101, 5102, 5103, 5104]

1. Error code definition

5101

Return air temperature sensor (TH21) fault (Indoor unit)

Return air temperature sensor (TH4) fault (OA processing unit)

5102

Pipe temperature sensor (TH22) fault (Indoor unit)

Pipe temperature sensor (TH2) fault (OA processing unit)

5103

Gas-side pipe temperature sensor (TH23) fault (Indoor unit)

Gas-side pipe temperature sensor (TH3) fault (OA processing unit)

5104

Intake air temperature sensor (TH1) fault (OA processing unit)

Intake air temperature sensor (TH24) fault (All-fresh (100% outdoor air) type indoor unit)

2. Error definition and error detection method

•If a short or an open is detected during thermostat ON, the outdoor unit turns to anti-restart mode for 3 minutes. When the error is not restored after 3 minutes (if restored, the outdoor unit runs normally), the outdoor unit makes an error stop.

Short: detectable at 90°C [194°F] or higher

Open: detectable at -40°C [-40°F] or lower

- •Sensor error at gas-side cannot be detected under the following conditions.
 - *During heating operation
 - *During cooling operation for 3 minutes after the compressor turns on.

| | Cause | Check method and remedy |
|-----|---|---|
| (1) | Thermistor failure | Check the thermistor resistor. |
| (2) | Connector contact failure | 0°C [32°F]: 15 kΩ 10°C [50°F]: 9.7 kΩ |
| (3) | Disconnected wire or partial disconnected thermistor wire | 20°C [68°F] : 6.4 kΩ 30°C [86°F] : 4.3 kΩ 40°C [104°F] : 3.1 kΩ |
| (4) | Unattached thermistor or contact failure | |
| (5) | Indoor board (detection circuit) failure | Check the connector contact. When no fault is found, the indoor board is a failure. |

7-7-2 Error Codes [5103, 5104, 5105, 5106, 5107]

1. Error code definition

Heat exchanger outlet temperature sensor (TH3) fault (Outdoor unit)

Discharge temperature sensor (TH4) fault (Outdoor unit)

Accumulator inlet temperature sensor (TH5) fault (Outdoor unit)

5106

Heat exchanger inlet temperature sensor (TH6) fault (Outdoor unit)

Outside temperature sensor (TH7) fault (Outdoor unit)

2. Error definition and error detection method

- •When a short (high temperature intake) or an open (low temperature intake) of the thermistor is detected (the first detection). the outdoor unit stops, turns to anti-restart mode for 3 minutes, and restarts when the detected temperature of the thermistor.
- . When a short or an open is detected again (the second detection) after the first restart of the outdoor unit, the outdoor unit stops, turns to anti-restart mode for 3 minutes, and restarts in 3 minutes when the detected temperature is within the normal
- •When a short or an open is detected again (the third detection) after the previous restart of the outdoor unit, the outdoor unit makes an error stop.
- •When a short or an open of the thermistor is detected just before the restart of the outdoor unit, the outdoor unit makes an error stop, and the error code "5102", "5103", 5104", "5105", "5106"or "5107" will appear.

 During 3-minute antirestart mode, preliminary errors will be displayed on the LED display.
- •A short or an open described above is not detected for 10 minutes after the compressor start, during defrost mode, or for 3 minutes after defrost mode.

3. Cause, check method and remedy

| | Cause | Check method and remedy |
|-----|---|--|
| (1) | Thermistor failure | Check thermistor resistance. |
| (2) | Pinched lead wire | Check for pinched lead wire. |
| (3) | Torn wire coating | Check for wire coating. |
| (4) | A pin on the male connector is missing or contact failure | Check connector. |
| (5) | Disconnected wire | Check for wire. |
| (6) | Thermistor input circuit failure on the control board | Check the intake temperature of the sensor with the LED monitor. When the temperature is far different from the actual temperature, replace the control board. |

<Reference>

| Short detection | Open detection |
|-----------------|----------------|
|-----------------|----------------|

| TH3 | 110 °C [230 °F] and above (0.4 kΩand below) | -40 °C [-40° F] and below (130 k Ωand above) |
|-----|--|---|
| TH4 | 240 $^{\circ}$ C [464 $^{\circ}$ F] and above (0.57 $k\Omega$ and below) | 0 $^{\circ}$ C [32 $^{\circ}$ F] and below (698 k Ω and above) |
| TH5 | 70 $^{\circ}$ C [158 $^{\circ}$ F] and above (0.4 $k\Omega$ and below) | -40 $^{\circ}$ C [-40 $^{\circ}$ F] and below (130 k $_{\Omega}$ and above) |
| TH6 | 70 $^{\circ}$ C [158 $^{\circ}$ F] and above (1.14 $k\Omega$ and below) | -40 $^{\circ}$ C [-40 $^{\circ}$ F] and below (130 k Ω and above) |
| TH7 | 110 °C [230 °F] and above (0.4 $k\Omega$ and below) | -40 °C [-40 °F] and below (130 $k\Omega$ and above) |

7-7-3 Error Code [5115]

1. Error code definition

5115

Compressor shell bottom temperature sensor (TH15) failure (Outdoor unit)

2. Error definition and error detection method

- •When a short (high temperature intake) or an open (low temperature intake) of the thermistor is detected (the first detection), the outdoor unit stops, turns to anti-restart mode for 3 minutes, and restarts when the detected temperature of the thermistor.
- •When a short or an open is detected again (the second detection) after the first restart of the outdoor unit, the outdoor unit stops, turns to anti-restart mode for 3 minutes, and restarts in 3 minutes when the detected temperature is within the normal range.
- •When a short or an open is detected again (the third detection) after the previous restart of the outdoor unit, the outdoor unit makes an error stop.
- •When a short or an open of the thermistor is detected just before the restart of the outdoor unit, the outdoor unit makes an error stop, and the error code "5115" will appear.
- •During 3-minute antirestart mode, preliminary errors will be displayed on the LED display.
- •A short or an open described above is not detected for 10 minutes after the compressor start, during defrost mode, or for 3 minutes after defrost mode.

3. Cause, check method and remedy

| | Cause | Check method and remedy |
|-----|---|---|
| (1) | Thermistor failure | Check thermistor resistance. |
| (2) | Pinched lead wire | Check for pinched lead wire. |
| (3) | Torn wire coating | Check for wire coating. |
| (4) | A pin on the male connector is missing or contact failure | Check connector. |
| (5) | Disconnected wire | Check for wire. |
| (6) | Thermistor input circuit failure on the control board | Check the intake temperature of the sensor with the LED monitor. When the temperature is far different from the actual temperature, replace the control board. |

<Reference>

Short detection Open detection

TH15 110 °C [230 °F] and above (0.4 k Ω and below) -40 °C [-40 °F] and below (130 k Ω and above)

7-7-4 Error Code [5110]

1. Error code definition

Heatsink temperature sensor (THHS) fault (Detail code 01)

2. Error definition and error detection method

When a short or an open of THHS is detected just before or during the inverter operation.

3. Cause, check method and remedy

| | Cause | Check method and remedy | |
|---|----------------------|---|--|
| (| 1) INV board failure | If the problem recurs when the unit is put into operation, replace the INV board. | |

Note

7-7-5 Error Codes [5111, 5112, 5115, 5116]

1. Error code definition

Liquid inlet temperature sensor (TH11) fault (BC controller)

Bypass outlet temperature sensor (TH12) fault (BC controller)

LEV3 outlet temperature sensor (TH15) fault (BC controller)

LEV3 inlet temperature sensor (TH16) fault (BC controller)

2. Error definition and error detection method

•If a shorted (high temperature intake) or open (low temperature intake) thermistor (TH11, TH12, TH15, or TH16) is detected during operation, the unit makes an error stop, and an error code "5111," "5112," "5115," or "5116" appears on the display.
•Detection of a short- or open-circuit as described above is suspended during the defrost cycle and for 3 minutes after the

operation mode is changed.

3. Cause, check method and remedy

| | Cause | Check method and remedy |
|-----|---|--|
| (1) | Thermistor failure | Check thermistor resistance. |
| (2) | Pinched lead wire | Check for pinched lead wire. |
| (3) | Torn wire coating | Check for wire coating. |
| (4) | A pin on the male connector is missing or contact failure | Check connector. |
| (5) | Disconnected wire | Check for wire. |
| (6) | Thermistor input circuit failure on the control board | Check the intake temperature of the sensor with the LED monitor. When the temperature is far different from the actual temperature, replace the control board. |

<Reference>

| | Short detection | Open detection |
|------|--|--|
| TH11 | 110 $^{\circ}$ C [230 $^{\circ}$ F] and above (0.4 k Ω) | -40 $^{\circ}$ C [-40 $^{\circ}$ F] and below (130 k $_{\Omega}$) |
| TH12 | 110 $^{\circ}$ C [230 $^{\circ}$ F] and above (0.4 k Ω) | -40 $^{\circ}$ C [-40 $^{\circ}$ F] and below (130 k $_{\Omega}$) |
| TH15 | 70 $^{\circ}$ C [158 $^{\circ}$ F] and above (0.4 k Ω) | -40 °C [-40 °F] and below (130 k Ω) |
| TH16 | 110 °C [230 °F] and above (0.4 k Ω) | -40 °C [-40 °F] and below (130 k Ω) |

7-7-6 Error Code [5201]

1. Error code definition

High-pressure sensor fault (63HS1)

2. Error definition and error detection method

- •If the high pressure sensor detects 0.098MPa [14psi] or less during the operation, the outdoor unit stops once, turns to antirestart mode for 3 minutes, and restarts after 3 minutes when the detected high pressure sensor is 0.098MPa [14psi] or more.
- •If the high pressure sensor detects 0.098MPa [14psi] or less just before the restart, the outdoor unit makes an error stop, and the error code "5201" will appear.
- •During 3-minute antirestart mode, preliminary errors will be displayed on the LED display.
- •A error is not detected for 3 minutes after the compressor start, during defrost operation, or 3 minutes after defrost operation.

3. Cause, check method and remedy

| | Cause | Check method and remedy |
|-----|---|---|
| (1) | High pressure sensor failure | Refer to the following page(s). [8-5-1 Comparing the High-Pressure Sensor Measurement and Gauge Pressure](page 259) |
| (2) | Pressure drop due to refrigerant leak | |
| (3) | Torn wire coating | |
| (4) | A pin on the male connector is missing or contact failure | |
| (5) | Disconnected wire | |
| (6) | High pressure sensor input circuit failure on the control board | |

7-7-7 Error Codes [5201, 5203]

1. Error code definition

5201

High-pressure sensor fault (Outdoor unit 63HS1/BC controller PS1)

5203

Intermediate pressure sensor fault (BC controller PS3)

2. Error definition and error detection method

When a pressure sensor reading of 4.06 MPa [589 psi] or above is detected, error codes "5201" and "5203" will appear. The unit will continue its operation by using other sensors as a backup.

| | Cause | Check method and remedy |
|-----|---|--|
| (1) | High pressure sensor failure | Refer to the following page(s). [8-5-1 Comparing the High-Pressure Sensor Measurement and Gauge Pressure](page 259) |
| (2) | Pressure drop due to refrigerant leak | Check for a refrigerant leak. |
| (3) | Torn wire coating | Check for damaged wire coating |
| (4) | A pin on the male connector is missing or contact failure | Check whether a connector pin is missing |
| (5) | Disconnected wire | Check for disconnected or broken wire |
| (6) | High pressure sensor input circuit failure on the control board | Check the temperature detected by the sensor from the LED monitor. If the temperature is significantly different from the actual temperature, replace the control board. |

7-7-8 Error Code [5301] Detail Code 115

1. Error code definition

ACCT sensor fault (Detail code 115)

2. Error definition and error detection method

When the formula "output current < 2 Arms" remains satisfied for 10 seconds while the inverter is in operation.

3. Cause, check method and remedy

| | Cause | Check method and remedy |
|-----|----------------------------|---|
| (1) | Inverter open output phase | Check the output wiring connections. |
| (2) | Compressor failure | Refer to the following page(s). [8-10-3 Checking the Compressor for Ground Fault and Coil Resistance Problems](page 287) |
| (3) | INV board failure | Refer to the following page(s). [8-10-2 Checking the Inverter Board Error Detection Circuit](page 287) [8-10-4 Checking the Inverter for Damage at No-Load](page 287) [8-10-5 Checking the Inverter for Damage during Compressor Operation](page 288) |

Note

For inverter-related error codes, refer to the following page(s). [8-10 Troubleshooting Inverter Problems](page 284)

7-7-9 Error Code [5301] Detail Code 117

1. Error code definition

ACCT sensor circuit fault (Detail code 117)

2. Error definition and error detection method

When an error value is detected with the ACCT detection circuit just before the inverter starts

3. Cause, check method and remedy

| | Cause | Check method and remedy |
|-----|--------------------|---|
| (1) | INV board failure | Refer to the following page(s). [8-10-2 Checking the Inverter Board Error Detection Circuit](page 287) [8-10-4 Checking the Inverter for Damage at No-Load](page 287) [8-10-5 Checking the Inverter for Damage during Compressor Operation](page 288) |
| (2) | Compressor failure | Refer to the following page(s). [8-10-3 Checking the Compressor for Ground Fault and Coil Resistance Problems](page 287) |

Note

7-7-10 Error Code [5301] Detail Code 119

1. Error code definition

Open-circuited IPM/Loose ACCT connector (Detail code 119)

2. Error definition and error detection method

Presence of enough current cannot be detected during the self-diagnostic operation immediately before inverter startup.

3. Cause, check method and remedy

| | Cause | Check method and remedy | | |
|-----|--------------------------------|--|--|--|
| (1) | Inverter output wiring problem | Check output wiring connections. Confirm that the U- and W-phase output cables are put through CT12 and CT22 on the INV board respectively. | | |
| (2) | Inverter failure | Refer to the following page(s). [8-10-4 Checking the Inverter for Damage at No-Load](page 287) [8-10-5 Checking the Inverter for Damage during Compressor Operation](page 288) | | |
| (3) | Compressor failure | Refer to the following page(s). [8-10-3 Checking the Compressor for Ground Fault and Coil Resistance Problems](page 287) | | |

Note

For inverter-related error codes, refer to the following page(s). [8-10 Troubleshooting Inverter Problems](page 284)

7-7-11 Error Code [5301] Detail Code 120

1. Error code definition

Faulty ACCT wiring (Detail code 120)

2. Error definition and error detection method

Presence of target current cannot be detected during the self-diagnostic operation immediately before startup.

3. Cause, check method and remedy

| Cause | | Check method and remedy | | |
|-------|--------------------------------|--|--|--|
| (1) | Inverter output wiring problem | Check output wiring connections. Confirm that the U- and W-phase output cables are put through CT12 and CT22 on the INV board respectively. | | |
| (2) | Inverter failure | Refer to the following page(s). [8-10-4 Checking the Inverter for Damage at No-Load](page 287) [8-10-5 Checking the Inverter for Damage during Compressor Operation](page 288) | | |
| (3) | Compressor failure | Refer to the following page(s). [8-10-3 Checking the Compressor for Ground Fault and Coil Resistance Problems](page 287) | | |

Note

For inverter-related error codes, refer to the following page(s). [8-10 Troubleshooting Inverter Problems](page 284)

7-7-12 Error Codes [5305, 5306] Detail Code 132

1. Error code definition

Position detection error at startup (Detail code 132)

2. Error definition and error detection method

When a motor sensor has detected an error within 10 seconds after the fan motor has gone into operation.

3. Cause, check method and remedy

| Cause | | Check method and remedy | | |
|-------|-------------------|--|--|--|
| | | Check the fan board connector CNINV and CNSNR for proper contacts. Check the wirign betweem the fan motor and fan board. | | |
| (2) | Fan board failure | Refer to the following page(s). [8-10-9 Checking the Fan Inverter for Damage with Load](page 290) | | |
| (3) | Fan motor error | Refer to the following page(s). [8-10-6 Checking the Fan Motor for Ground Fault and Coil Resistance Problems](page 289) | | |

Note

For inverter-related error codes, refer to the following page(s). [8-10 Troubleshooting Inverter Problems](page 284)

7-7-13 Error Codes [5305, 5306] Detail Code 133

1. Error code definition

Position detection error during operation (Detail code 133)

2. Error definition and error detection method

An error from a motor sensor is detected during fan moter operation.

3. Cause, check method and remedy

| Cause | | Check method and remedy | | |
|-------|---|--|--|--|
| (1) | Outdoor factors | Check that there is no wind (gust or strong wind). | | |
| (2) | Contact failure and faulty fan motor wiring | Check the fan board connector CNINV and CNSNR for proper contacts. Check the wirign betweem the fan motor and fan board. | | |
| (3) | Fan board failure | Refer to the following page(s). [8-10-8 Checking the Fan Inverter for Damage at No Load](page 289) [8-10-9 Checking the Fan Inverter for Damage with Load](page 290) | | |
| (4) | Fan motor error | Refer to the following page(s). [8-10-6 Checking the Fan Motor for Ground Fault and Coil Resistance Problems](page 289) | | |

Note

For inverter-related error codes, refer to the following page(s). [8-10 Troubleshooting Inverter Problems](page 284)

7-7-14 Error Codes [5305, 5306] Detail Code 134

1. Error code definition

RPM error before start up (Detail code 134)

2. Error definition and error detection method

The fan RPM will not drop to the set RPM.

3. Cause, check method and remedy

| Cause | | Check method and remedy | | |
|--|-------------------|--|--|--|
| (1) Outdoor factors Check that there is no wind (gust or strong wind). | | Check that there is no wind (gust or strong wind). | | |
| (2) | Fan board failure | Refer to the following page(s). [8-10-8 Checking the Fan Inverter for Damage at No Load](page 289) [8-10-9 Checking the Fan Inverter for Damage with Load](page 290) | | |
| (3) | Fan motor error | Refer to the following page(s). [8-10-6 Checking the Fan Motor for Ground Fault and Coil Resistance Problems](page 289) | | |

Note

For inverter-related error codes, refer to the following page(s). [8-10 Troubleshooting Inverter Problems](page 284)

7-7-15 Error Code [5401]

1. Error Code



Humidity sensor fault

2. Error definition and error detection method

•A short-circuit or an open-circuit of the humidity sensor is detected during operation.

| Cause | | | Check method and remedy |
|-------|---|----|--|
| (1) | Connector contact failure (CN30) (Loose connector) | 1) | Check the connector for proper contact. Reconnect the connector, and operate the unit to check for proper operation. |
| (2) | Broken or partially broken humidity sensor wire | 2) | Check for broken humidity sensor wire. |
| (3) | Humidity sensor fault | 3) | Check the output voltage across No. 1 and No. 3 pins of connector CN30 with the connector being connected to the indoor unit control board. 30%: 1.25V 40%: 1.52V 50%: 1.88V 60%: 2.19V 70%: 2.48V 80%: 2.79V |
| (4) | Indoor unit control board (detection circuit) fault | 4) | If the above items check out okay, replace the indoor unit control board. |

7-7-16 Error Code [5701]

1. Error code definition

Loose float switch connector

2. Error definition and error detection method

Detection of the disconnected float switch (open-phase condition) during operation

3. Cause, check method and remedy

(1) CN4F disconnection or contact failure

Check for disconnection of the connector (CN4F) on the indoor unit control board.

7-8 Error Code Definitions and Solutions: Codes [6000 - 6999]

7-8-1 Error Code [6201]

1. Error code definition

Remote controller board fault (nonvolatile memory error)

2. Error definition and error detection method

This error is detected when the data cannot be read out from the built-in nonvolatile memory on the remote controller.

3. Cause, check method and remedy

(1) Remote controller failure

Replace the remote controller.

7-8-2 Error Code [6202]

1. Error code definition

Remote controller board fault (clock IC error)

2. Error definition and error detection method

This error is detected when the built-in clock on the remote controller is not properly functioning.

3. Cause, check method and remedy

(1) Remote controller failure

Replace the remote controller.

7-8-3 Error Code [6600]

1. Error code definition Address overlaps

2. Error definition and error detection method

An error in which signals from more than one indoor units with the same address are received

Note

The address and attribute that appear on the remote controller indicate the controller that detected the error.

3. Cause, check method and remedy

| | Cause | Check method and remedy | |
|-----|--|--|--|
| (1) | (1) Two or more of the following have the same address: Outdoor units, BC controllers, indoor units, LOSSNAY units, controllers such as ME remote controllers. <example> 6600 "01" appears on the remote controller Unit #01 detected the error.</example> | Find the unit that has the same address as that of the error source. Once the unit is found, correct the address. Then, turn off the outdoor units, indoor units, BC controllers, and LOSSNAY units, keep them all turned off for at least five minutes, and turn them back on. | |
| | Two or more units in the system have 01 as their address. | When air conditioning units are operating normally despite the address overlap error | |
| (2) | Signals are distorted by the noise on the transmission line. | Check the transmission wave shape and noise on the transmission line. Refer to the following page(s). [8-4 Checking Transmission Waveform and for Electrical Noise Interference](page 256) | |

7-8-4 Error Code [6601]

1. Error code definition Polarity setting error

2. Error definition and error detection method

The error detected when transmission processor cannot distinguish the polarities of the M-NET transmission line.

| | Cause | Check method and remedy |
|-----|--|--|
| (1) | No voltage is applied to the M-NET transmission line that AE-200A/AE-50A/EW-50A/EB-50GU/AG-150A/GB-50ADA/GB-24A, PAC-YG50ECA, BAC-HD150 is connected to. | Check if power is supplied to the M-NET transmission line of the AE-200A/AE-50A/EW-50A/EB-50GU/AG-150A/GB-50ADA/GB-24A, PAC-YG50ECA, BAC-HD150, and correct any problem found. |
| (2) | M-NET transmission line to which AE-200A/AE-50A/EW-50A/EB-50GU/AG-150A/GB-50ADA/GB-24A, PAC-YG50ECA, BAC-HD150 is connected is short-circuited. | |
| (3) | When two or more power supplies are connected to the M-NET | |

7-8-5 Error Code [6602]

1. Error code definition

Transmission processor hardware error

2. Error definition and error detection method


Although "0" was surely transmitted by the transmission processor, "1" is displayed on the transmission line.

Note

The address/attribute appeared on the display on the remote controller indicates the controller where an error occurred.

3. Cause

- 1) When the wiring work of or the polarity of either the indoor or outdoor transmission line is performed or is changed while the power is on, the transmitted data will collide, the wave shape will be changed, and an error will be detected.
- 2) Grounding fault of the transmission line
- 3) When grouping the indoor units that are connected to different outdoor units, the male power supply connectors on the multiple outdoor units are connected to the female power supply switch connector (CN40).
- 4) When the power supply unit for transmission lines is used in the system connected with MELANS, the male power supply connector is connected to the female power supply switch connector (CN40) on the outdoor unit.
- 5) Controller failure of the source of the error
- 6) When the transmission data is changed due to the noise on the transmission line
- 7) Voltage is not applied on the transmission line for centralized control (in case of grouped indoor units connected to different outdoor units or in case of the system connected with MELANS)



7-8-6 Error Code [6603]

1. Error code definition

Transmission line bus busy error

2. Error definition and error detection method

- •Generated error when the command cannot be transmitted for 4-10 minutes in a row due to bus-busy
- •Generated error when the command cannot be transmitted to the transmission line for 4-10 minutes in a row due to noise

Note

The address/attribute appeared on the display on the remote controller indicates the controller where an error oc-

3. Cause, check method and remedy

| | Cause | Check method and remedy |
|-----|--|---|
| (1) | The transmission processor cannot be transmitted as the short-wavelength voltage like noise exists consecutively on the transmission line. | Check the transmission wave shape and noise on the transmission line. Refer to the following page(s). [8-4 Checking Transmission Waveform and for Electrical Noise Interference](page 256) → No noise indicates that the error source controller is a failure. → If noise exists, investigate the noise. |
| (2) | Error source controller failure | |

7-8-7 Error Code [6606]

1. Error code definition

Communication error between device and transmission processors

2. Error definition and error detection method

Communication error between the main microcomputer on the indoor unit board and the microcomputer for transmission

Note

The address/attribute appeared on the display on the remote controller indicates the controller where an error occurred.

| | Cause | Check method and remedy |
|-----|---|---|
| (1) | Data is not properly transmitted due to accidental erroneous operation of the controller of the error source. | Turn off the power source of the outdoor and the indoor units.(When the power source is turned off separately, the microcomputer will not be reset, and the error will not be |
| (2) | Error source controller failure | corrected.) → If the same error occurs, the error source controller is a failure. |

7-8-8 Error Code [6607] Error Source Address = Outdoor Unit (OC)

1. Error code definition No ACK error

2. Error definition and error detection method

The error is detected when no acknowledgement (ACK signal) is received after the transmission. (eg. When the data is transmitted six times in a row with 30 seconds interval, the error is detected on the transmission side.)

Note

The address/attribute appeared on the display on the remote controller indicates the controller which did not provide the response (ACK).

| | Cause | | Check method and remedy |
|-----|---|----|--|
| (1) | Incidental cause | 1) | Turn off the power source of the outdoor unit, and turn it on again. |
| (2) | Contact failure of transmission line of OC or IC | 2) | If the error is accidental, it will run normally. If not, |
| (3) | Decrease of transmission line voltage/signal by exceeding acceptable range of transmission wiring. Farthest: 200 m [656ft] or less Remote controller wiring: 10m [32ft] or less | | check the causes (2) - (5). |
| (4) | Erroneous sizing of transmission line (Not within the range below). Wire diameter: 1.25mm ² [AWG16] or more | | |
| (5) | Outdoor unit control board failure | | |

7-8-9 Error Code [6607] Error Source Address = BC Controller (BC)

1. Error code definition No ACK error

2. Error definition and error detection method

The error is detected when no acknowledgement (ACK signal) is received after the transmission. (eg. When the data is transmitted six times in a row with 30 seconds interval, the error is detected on the transmission side.)

Note

The address/attribute appeared on the display on the remote controller indicates the controller which did not provide the response (ACK).

| | Cause | | Check method and remedy |
|-----|---|----|---|
| (1) | Incidental cause | 1) | Turn off the power to the outdoor unit and the BC controller, leave them turned off for at least 5 minutes, and then turn them back on. |
| (2) | When BC controller address is changed or modified during operation. | 2) | If the error is accidental, it will run normally. If not, check the causes (2) - (5). |
| (3) | Faulty or disconnected transmission wiring of BC controller | | |
| (4) | Disconnected connector of BC controller (CN02) | | |
| (5) | Faulty control board of BC controller | | |

7-8-10 Error Code [6607] Error Source Address = Indoor Unit (IC)

1. Error code definition

No ACK error


2. Error definition and error detection method

The error is detected when no acknowledgement (ACK signal) is received after the transmission. (eg. When the data is transmitted six times in a row with 30 seconds interval, the error is detected on the transmission side.)

Note

The address/attribute appeared on the display on the remote controller indicates the controller which did not provide the response (ACK).

3. Cause, check method and remedy



(1) Troubleshooting problems for indoor units (A)

| | Cause | | Check method and remedy | |
|-----|---|----|---|--|
| (1) | Incidental cause | 1) | Turn off the outdoor/indoor units for 5 or more minutes, and turn them on again. | |
| (2) | When IC unit address is changed or modified during operation. | 2) | If the error is accidental, it will run normally. If not, check the causes (2) - (6). | |
| (3) | Faulty or disconnected IC transmission wiring | | | |
| (4) | Disconnected IC connector (CN2M) | | | |
| (5) | Indoor unit controller failure | | | |
| (6) | ME remote controller failure | | | |

(2) Troubleshooting problems for indoor units (B)

| | Cause | | Check method and remedy |
|-----|---|----|---|
| (1) | When the power supply unit for transmission lines is used and the male power supply connector is connected to the female power supply switch connector (CN40) for the transmission line for centralized control | 1) | Check voltage of the transmission line for centralized control. •20 V or more: Check (1) on the left. •Less than 20 V: Check (2) on the left. |
| (2) | Disconnection or shutdown of the power source of the power supply unit for transmission line | | |
| (3) | System controller (MELANS) malfunction | 2) | Check the causes of the error indicated by the error codes listed in items (1) through (3) in the "Cause" column. |

7-8-11 Error Code [6607] Error Source Address = LOSSNAY (LC)

1. Error code definition No ACK error


2. Error definition and error detection method

The error is detected when no acknowledgement (ACK signal) is received after the transmission. (eg. When the data is transmitted six times in a row with 30 seconds interval, the error is detected on the transmission side.)

Note

The address/attribute appeared on the display on the remote controller indicates the controller which did not provide the response (ACK).

3. Cause, check method and remedy



(1) Troubleshooting problems for LOSSNAY units

| | Cause | | Check method and remedy |
|-----|---|----|--|
| (1) | Incidental cause | 1) | Turn off the power source of LOSSNAY and turn it on again. |
| (2) | The power source of LOSSNAY has been shut off. | 2) | If the error is accidental, it will run normally. |
| (3) | When the address of LOSSNAY is changed in the middle of the operation | | If not, check the causes (2) - (6). |
| (4) | Faulty or disconnected transmission wiring of LOSSNAY | | |
| (5) | Disconnected connector (CN1) on LOSSNAY | | |
| (6) | Controller failure of LOSSNAY | | |

7-8-12 Error Code [6607] Error Source Address = ME Remote Controller

1. Error code definition

No ACK error

2. Error definition and error detection method


The error is detected when no acknowledgement (ACK signal) is received after the transmission. (eg. When the data is transmitted six times in a row with 30 seconds interval, the error is detected on the transmission side.)

Note

The address/attribute appeared on the display on the remote controller indicates the controller which did not provide the response (ACK).

3. Cause, check method and remedy

Error display



(1) Troubleshooting problems for ME remote controllers

| | Cause | | Check method and remedy |
|-----|--|----|--|
| (1) | Incidental cause | 1) | Turn off the power source of the outdoor unit for 5 minutes or more, and turn it on again. |
| (2) | Faulty transmission wiring at IC unit side. | 2) | If not, check the causes (2) - (5). |
| (3) | Faulty wiring of the transmission line for ME remote controller | | |
| (4) | When the address of ME remote controller is changed in the middle of the operation | | |
| (5) | ME remote controller failure | | |

7-8-13 Error Code [6607] Error Source Address = System Controller

1. Error code definition

No ACK error


2. Error definition and error detection method

The error is detected when no acknowledgement (ACK signal) is received after the transmission. (eg. When the data is transmitted six times in a row with 30 seconds interval, the error is detected on the transmission side.)

Note

The address/attribute appeared on the display on the remote controller indicates the controller which did not provide the response (ACK).

3. Cause, check method and remedy



(1) Troubleshooting problems for system controllers

| | Cause | | Check method and remedy |
|-----|--|----|--|
| (1) | Incidental cause | 1) | Turn off the power source of the outdoor unit for 5 minutes or more, and turn it on again. |
| (2) | Faulty wiring of the transmission line for ME remote controller | 2) | If not, check the causes (2) - (4). |
| (3) | When the address of ME remote controller is changed in the middle of the operation | | |
| (4) | ME remote controller failure | | |

7-8-14 Error Code [6607] All Error Source Addresses

1. Error code definition No ACK error

2. Error definition and error detection method

The error is detected when no acknowledgement (ACK signal) is received after the transmission. (eg. When the data is transmitted six times in a row with 30 seconds interval, the error is detected on the transmission side.)

Note

The address/attribute appeared on the display on the remote controller indicates the controller which did not provide the response (ACK).

3. Cause, check method and remedy

(1) Troubleshooting problems for all units (A)

| | Cause | | Check method and remedy |
|-----|--|----|--|
| (1) | Disconnection or short circuit of the transmission line for the outdoor unit on the terminal block for centralized con- trol line connection (TB7) | 1) | Check the causes of (1) - (4). If the cause is found, correct it. If no cause is found, check 2). |
| (2) | When multiple outdoor units are connected and the power source of one of the outdoor units has been shut off. | 2) | Check the LED displays for troubleshooting on other remote controllers whether an error occurs. |
| (3) | The male power supply connector of the outdoor unit is not connected to the female power supply switch connector (CN40). | | •When an error is present Check the causes of the error indicated by the error codes listed in item (4) in the "Cause" col- |
| (4) | The male power supply connectors on 2 or more outdoor units are connected to the female power supply switch connector (CN40) for centralized control. | | umn. •When no errors are present Indoor unit circuit board failure |
| | If an error occurs, after the unit runs normally once, the following causes may be considered. •Total capacity error (7100) •Capacity code error (7101) •Error in the number of connected units (7102) •Address setting error (7105) | | |

(2) Troubleshooting problems for all units (B)

| | Cause | | Check method and remedy |
|-----|--|----|--|
| (1) | Total capacity error (7100) | 1) | Check the LED display for troubleshooting on the |
| (2) | Capacity code error (7101) | | outdoor unit. •When an error is present |
| (3) | Error in the number of connected units (7102) | | Check the causes of the error indicated by the error codes listed in items (1) through (4) in the |
| (4) | Address setting error (7105) | | "Cause" column. |
| (5) | Disconnection or short circuit of the transmission line for the outdoor unit on the terminal block for centralized con- trol line connection (TB7) | | •When no errors are present Check the causes of the error indicated by the error codes listed in items (5) through (7) in the |
| (6) | Turn off the power source of the outdoor unit | | "Cause" column. |
| (7) | Malfunction of electrical system for the outdoor unit | | |

(3) Troubleshooting problems for all units (C)

| | Cause | Check method and remedy |
|-----|---|---|
| (1) | When the power supply unit for transmission lines is used and the male power supply connector is connected to the female power supply switch connector (CN40) for the transmission line for centralized control | Check the causes of the error indicated by the error codes listed in items (1) through (3) in the "Cause" column. |
| (2) | Disconnection or shutdown of the power source of the power supply unit for transmission line | |
| (3) | System controller (MELANS) malfunction | |

7-8-15 Error Code [6607] No Error Source Address

1. Error code definition No ACK error

2. Error definition and error detection method

The error is detected when no acknowledgement (ACK signal) is received after the transmission. (eg. When the data is transmitted six times in a row with 30 seconds interval, the error is detected on the transmission side.)

Note

The address/attribute appeared on the display on the remote controller indicates the controller which did not provide the response (ACK).

| | Cause | | Check method and remedy |
|-----|--|----|---|
| (1) | Although the address of ME remote controller has been changed after the group is set using ME remote controller, the indoor unit is keeping the memory of the previous address. The same symptom will appear for the registration with SC. | | Delete unnecessary information of non-existing address which some indoor units have. Use either of the following two methods for deletion. |
| (2) | Although the address of LOSSNAY has been changed after the interlock registration of LOSSNAY is made using ME remote controller, the indoor unit is keeping the memory of the previous address. | 1) | Address deletion by ME remote controller Delete unnecessary address information using the manual setting function of ME remote controller. For details, refer to the installation manual for ME Remote Controller. |
| | | 2) | Deletion of connection information of the outdoor unit by the deleting switch |
| | | | Note that the above method will delete all the group settings set via the ME remote controller and all the interlock settings between LOSSNAY units and indoor units. |
| | | | Procedures Turn off the power source of the outdoor unit, and wait for 5 minutes. Turn on the dip switch (SW5-2) on the outdoor unit control board. Turn on the power source of the outdoor unit, and wait for 5 minutes. Turn off the power source of the outdoor unit, and wait for 5 minutes. Turn off the dip switch (SW5-2) on the outdoor unit control board. Turn on the power source of the outdoor unit. |

7-8-16 Error Code [6608]

1. Error code definition

No response error

2. Error definition and error detection method

- •When no response command is returned although acknowledgement (ACK) is received after transmission, an error is detected
- •When the data is transmitted 10 times in a row with 3 seconds interval, an error is detected on the transmission side.

Note

The address/attribute appeared on the display on the remote controller indicates the controller where an error occurred.

3. Cause

- The transmission line work is performed while the power is on, the transmitted data will collide, and the wave shape will be changed.
- 2) The transmission is sent and received repeatedly due to noise.
- 3) Decrease of transmission line voltage/signal by exceeding acceptable range of transmission wiring.

Farthest:200m [656ft] or less

Remote controller wiring:12m [39ft] or less

4) The transmission line voltage/signal is decreased due to erroneous sizing of transmission line.

Wire diameter: 1.25mm²[AWG16] or more

4. Check method and remedy

- 1) When an error occurs during commissioning, turn off the power sources for the outdoor unit, indoor unit, BC controller, and LOSSNAY for 5 or more minutes, and then turn them on again.
 - When they return to normal operation, the cause of the error is the transmission line work performed with the power on.
 - If an error occurs again, check the cause 2).
- 2) Check 3) and 4) above.
 - *If the cause is found, correct it.
 - If no cause is found, check 3).
- (1) Check the transmission waveform, and check the transmission line for electrical noise. For details, refer to the following page(s). [8-4 Checking Transmission Waveform and for Electrical Noise Interference](page 256)

Noise is the most possible cause of the error "6608".

7-8-17 Error Code [6831]

1. Error code definition

MA controller signal reception error (No signal reception)

2. Error definition and error detection method

- *Communication between the MA remote controller and the indoor unit is not done properly.
- •No proper data has been received for 3 minutes.

3. Cause

- 1) Contact failure of the remote controller lines of MA remote controller or the indoor unit.
- 2) All the remote controllers are set to SUB.
- 3) Failure to meet wiring regulations
 - ·Wire length
 - ◆Wire size
 - *Number of remote controllers
 - Number of indoor units
- 4) The remote controller is removed after the installation without turning the power source off.
- 5) Noise interference on the remote controller transmission lines
- 6) Faulty circuit that is on the indoor board and performs transmission/ reception of the signal from the remote controller
- 7) Problems with the circuit on the remote controller that sends or receives the signals from the remote controller

- 1) Check for disconnected or loose transmission lines for the indoor units or MA remote controllers.
- 2) Confirm that the power is supplied to the main power source and the remote controller line.
- 3) Confirm that MA remote controller's capacity limit is not exceeded.
- 4) Check the sub/main setting of the MA remote controllers. One of them must be set to MAIN.
- 5) Diagnose the remote controller (described in the remote controller installation manual).
 - [OK]: no problems with the remote controller (check the wiring regulations)
 - [NG]: Replace the MA remote controller.
 - [6832, 6833, ERC]: Due to noise interference <Go to 6)>
- 6) Check the transmission waveform, and check the MA remote controller line for electrical noise. For details, refer to the following page(s). [8-4 Checking Transmission Waveform and for Electrical Noise Interference](page 256)
- 7) When no problems are found with items 1) through 6), replace the indoor unit board or the MA remote controller. The following status can be confirmed on LED1 and 2 on the indoor unit board.
 - •If LED1 is lit, the main power source of the indoor unit is turned on.
 - •If LED2 is lit, the MA remote controller line is being powered.

7-8-18 Error Code [6832]

1. Error code definition

MA remote controller signal transmission error (Synchronization error)

2. Error definition and error detection method

- •MA remote controller and the indoor unit is not done properly.
- •Failure to detect opening in the transmission path and unable to send signals
 - *Indoor unit: 3 minutes
 - *Remote controller: 6 seconds

3. Cause

- 1) Contact failure of the remote controller lines of MA remote controller or the indoor unit
- 2) 2 or more remote controllers are set to MAIN
- 3) Overlapped indoor unit address
- 4) Noise interference on the remote controller lines
- 5) Failure to meet wiring regulations
 - •Wire length
 - ◆Wire size
 - Number of remote controllers
 - Number of indoor units
- 6) Problems with the circuit on the remote controller that sends or receives the signals from the remote controller

- 1) Check for disconnected or loose transmission lines for the indoor units or MA remote controllers.
- 2) Confirm that the power is supplied to the main power source and the remote controller line.
- 3) Confirm that MA remote controller's capacity limit is not exceeded.
- 4) Check the sub/main setting of the MA remote controllers. One of them must be set to MAIN.
- 5) Diagnose the remote controller (described in the remote controller installation manual).
 - [OK]: no problems with the remote controller (check the wiring regulations)
 - [NG]: Replace the MA remote controller.
 - [6832, 6833, ERC]: Due to noise interference <Go to 6)>
- 6) Check the transmission waveform, and check the MA remote controller line for electrical noise. For details, refer to the following page(s). [8-4 Checking Transmission Waveform and for Electrical Noise Interference](page 256)
- 7) When no problems are found with items 1) through 6), replace the indoor unit board or the MA remote controller. The following status can be confirmed on LED1 and 2 on the indoor unit board.
 - •If LED1 is lit, the main power source of the indoor unit is turned on.
 - •If LED2 is lit, the MA remote controller line is being powered.

7-8-19 Error Code [6833]

1. Error code definition

MA remote controller signal transmission error (Hardware error)

2. Error definition and error detection method

- •Communication between the MA remote controller and the indoor unit is not done properly.
- •An error occurs when the transmitted data and the received data differ for 30 times in a row.

Cause

- 1) Contact failure of the remote controller lines of MA remote controller or the indoor unit
- 2) 2 or more remote controllers are set to MAIN
- 3) Overlapped indoor unit address
- 4) Noise interference on the remote controller lines
- 5) Failure to meet wiring regulations
 - •Wire length
 - ◆Wire size
 - Number of remote controllers
 - Number of indoor units
- 6) Problems with the circuit on the remote controller that sends or receives the signals from the remote controller

- 1) Check for disconnected or loose transmission lines for the indoor units or MA remote controllers.
- 2) Confirm that the power is supplied to the main power source and the remote controller line.
- 3) Confirm that MA remote controller's capacity limit is not exceeded.
- 4) Check the sub/main setting of the MA remote controllers. One of them must be set to MAIN.
- 5) Diagnose the remote controller (described in the remote controller installation manual).
 - [OK]: no problems with the remote controller (check the wiring regulations)
 - [NG]: Replace the MA remote controller.
 - [6832, 6833, ERC]: Due to noise interference <Go to 6)>
- 6) Check the transmission waveform, and check the MA remote controller line for electrical noise. For details, refer to the following page(s). [8-4 Checking Transmission Waveform and for Electrical Noise Interference](page 256)
- 7) When no problems are found with items 1) through 6), replace the indoor unit board or the MA remote controller. The following status can be confirmed on LED1 and 2 on the indoor unit board.
 - •If LED1 is lit, the main power source of the indoor unit is turned on.
 - •If LED2 is lit, the MA remote controller line is being powered.

7-8-20 Error Code [6834]

1. Error code definition

MA controller signal reception error (Start bit detection error)

2. Error definition and error detection method

- *Communication between the MA remote controller and the indoor unit is not done properly.
- •No proper data has been received for 2 minutes.

3. Cause

- 1) Contact failure of the remote controller lines of MA remote controller or the indoor unit.
- 2) All the remote controllers are set to SUB.
- 3) Failure to meet wiring regulations
 - ·Wire length
 - ◆Wire size
 - *Number of remote controllers
 - *Number of indoor units
- 4) The remote controller is removed after the installation without turning the power source off.
- 5) Noise interference on the remote controller transmission lines
- 6) Faulty circuit that is on the indoor board and performs transmission/ reception of the signal from the remote controller
- 7) Problems with the circuit on the remote controller that sends or receives the signals from the remote controller

- 1) Check for disconnected or loose transmission lines for the indoor units or MA remote controllers.
- 2) Confirm that the power is supplied to the main power source and the remote controller line.
- 3) Confirm that MA remote controller's capacity limit is not exceeded.
- 4) Check the sub/main setting of the MA remote controllers. One of them must be set to MAIN.
- 5) Diagnose the remote controller (described in the remote controller installation manual).
 - [OK]: no problems with the remote controller (check the wiring regulations)
 - [NG]: Replace the MA remote controller.
 - [6832, 6833, ERC]: Due to noise interference <Go to 6)>
- 6) Check the transmission waveform, and check the MA remote controller line for electrical noise. For details, refer to the following page(s). [8-4 Checking Transmission Waveform and for Electrical Noise Interference](page 256)
- 7) When no problems are found with items 1) through 6), replace the indoor unit board or the MA remote controller. The following status can be confirmed on LED1 and 2 on the indoor unit board.
 - •If LED1 is lit, the main power source of the indoor unit is turned on
 - •If LED2 is lit, the MA remote controller line is being powered.

7-8-21 Error Code [6840]

1. Error code definition

A control communication reception error

2. Error definition and error detection method

Indoor/outdoor unit communication error (Signal receiving error)

- Abnormal if indoor controller board could not receive any signal normally for 6 minutes after turning the power on
- •Abnormal if indoor controller board could not receive any signal normally for 3 minutes.
- •Consider the unit as abnormal under the following condition. When 2 or more indoor units are connected to an outdoor unit, indoor controller board could not receive a signal for 3 minutes from outdoor controller circuit board, a signal which allows outdoor controller circuit board to transmit signals.

3. Cause, check method and remedy

| | Cause | Check method and remedy |
|-----|---|---|
| (1) | Contact failure, short circuit or miswiring (converse wiring) of indoor/outdoor unit connecting wire. | Check disconnecting or looseness of indoor /outdoor unit connecting wire of indoor unit or outdoor unit. Check all the units in case of twin/triple/quadruple indoor unit system. |
| (2) | Defective transmitting receiving circuit of outdoor controller circuit board. | Turn the power off, and on again to check. If abnormality generates again, replace indoor controller board or outdoor controller circuit |
| (3) | Defective transmitting receiving circuit of indoor controller board. | board. |
| (4) | Noise has entered into indoor/outdoor unit connecting wire. | |
| (5) | Defective fan motor | Turn the power off, and detach fan motor from connector (CNF1, 2). Then turn the power on again. If abnormality is not displayed, replace fan motor. If abnormality is displayed, replace outdoor controller circuit board. |
| (6) | Defective rush current resistor of outdoor power circuit board | Check the rush current resistor on outdoor power circuit board with tester. If open is detected, replace the power circuit board. |

7-8-22 Error Code [6841]

1. Error code definition

A control communication synchronism not recover

2. Error definition and error detection method

Indoor/outdoor unit communication error (Transmitting error) (Outdoor unit)

- •Abnormal if "0" receiving is detected 30 times continuously though outdoor controller circuit board has transmitted "1".
- *Abnormal if outdoor controller circuit board could not find blank of transmission path for 3 minutes.

| | Cause | Check method and remedy |
|-----|--|--|
| (1) | Indoor/outdoor unit connecting wire has contact failure. | Check disconnection or looseness of indoor/ outdoor unit connecting wire. |
| (2) | Defective communication circuit of outdoor controller circuit board. | Turn the power off, and on again to check. Replace outdoor controller circuit board if ab- |
| (3) | Noise has entered power supply. | normality is displayed again. |
| (4) | Noise has entered indoor/outdoor unit connecting wire. | |

7-8-23 Error Code [6842]

1. Error code definition

A control communication transmission/reception hardware trouble

2. Error definition and error detection method

Indoor/outdoor unit communication error (Transmitting error)
Abnormal if "1" receiving is detected 30 times continuously though indoor controller board has transmitted "0".

| | Cause | Check method and remedy |
|-----|---|---|
| (1) | Defective transmitting receiving circuit of indoor controller board | Turn the power off, and on again to check. If |
| (2) | Noise has entered into power supply. | abnormality generates again, replace indoor controller board. |
| (3) | Noise has entered into outdoor control wire. | |

7-8-24 Error Code [6843]

1. Error code definition

A control communication start bit detection error

2. Error definition and error detection method

Indoor/outdoor unit communication error (Signal receiving error)

- *Abnormal if indoor controller board could not receive any signal normally for 6 minutes after turning the power on.
- •Abnormal if indoor controller board could not receive any signal normally for 3 minutes.
- •Consider the unit as abnormal under the following condition. When 2 or more indoor units are connected to an outdoor unit, indoor controller board could not receive a signal for 3 minutes from outdoor controller circuit board, a signal which allows outdoor controller circuit board to transmit signals.

3. Cause, check method and remedy

| | Cause | Check method and remedy | | |
|-----|---|---|--|--|
| (1) | Contact failure, short circuit or miswiring (converse wiring) of in- door/outdoor unit connecting wire | Check disconnecting or looseness of indoor /outdoor unit connecting wire of all indoor units or outdoor units. | | |
| (2) | Defective transmitting receiving circuit of outdoor controller circuit board. | abnormality generates again, replace indoor controller board or outdoor controller circuit board. | | |
| (3) | Defective transmitting receiving circuit of indoor controller board. | | | |
| (4) | Noise has entered into indoor/outdoor unit connecting wire. | Note: ther indoor controller board may have defect. | | |
| (5) | Defective fan motor | Turn the power off, and detach fan motor from connector (CNF1, 2). Then turn the power on again. If abnormality is not displayed, replace fan motor. If abnormality is displayed, replace outdoor controller circuit board. | | |
| (6) | Defective rush current resistor of outdoor power circuit board | Check the rush current resistor on outdoor power circuit board with tester. If open is detected, replace the power circuit board. | | |

1. Error code definition

A control communication start bit detection error

2. Error definition and error detection method

Indoor/outdoor unit communication error (Signal receiving error) (Outdoor unit)

Abnormal if outdoor controller circuit board could not receive anything normally for 3 minutes.

| | Cause | Check method and remedy |
|-----|---|---|
| (1) | Contact failure of indoor/outdoor unit connecting wire | Check disconnection or looseness of indoor/ outdoor unit connecting wire of indoor or out- door units. |
| (2) | Defective communication circuit of outdoor controller circuit board | Turn the power off, and on again to check. Replace indoor controller board or outdoor controller circuit board if abnormality is dis- |
| (3) | Defective communication circuit of indoor controller board | played again. |
| (4) | Noise has entered into indoor/outdoor unit connecting wire. | |

7-8-25 <u>Error Code [6846]</u>

1. Error code definition Start-up time over

2. Error definition and error detection method

Start-up time over The unit cannot finish start-up process within 4 minutes after power on.

| | Cause | Check method and remedy |
|-----|---|--|
| (1) | Contact failure of indoor/outdoor unit connecting wire | Check disconnection or looseness or polarity of indoor/outdoor unit connecting wire of indoor and outdoor units. |
| (2) | Diameter or length of indoor/outdoor unit connecting wire is out of specified capacity. | Check diameter and length of indoor/outdoor unit connecting wire. Total wiring length: 80 m (including wiring connecting each indoor unit and between indoor and outdoor unit) Also check if the connection order of flat cable is S1, S2, S3. |
| (3) | 2 or more outdoor units have refrigerant address "0". (In case of group control) | Check if refrigerant addresses are overlapping in case of group control system. |
| (4) | Noise has entered into power supply or indoor/outdoor unit connecting wire. | Check transmission path, and remove the cause. Note: The descriptions above, (1)-(4), are for EA, Eb and EC. *The check code in the parenthesis indicates PAR-30MAA model. |

7-9 Error Code Definitions and Solutions: Codes [7000 - 7999]

7-9-1 Error Code [7100]

1. Error code definition Total capacity error

2. Error definition and error detection method

The model total of indoor units in the system with one outdoor unit exceeds limitations.

3. Error source, cause, check method and remedy,

After troubleshooting the error using the check methods and remedies shown below, turn the power back on.

| Error source | Cause | | | | | | | | Check method and remedy |
|--------------|---|--|-------|--------|----------|---|--|----|---|
| Outdoor unit | (1) | The model total of indoor units in the system with one outdoor unit exceeds the following table. | | | | | | 1) | Check the model total (capacity code total) of indoor units connected. |
| | | | | | 2) | Check the model name (capacity code) of the | | | |
| | | Model | | | acity to | otal | | | connected indoor unit set by the switch (SW2 on |
| | | P72 mo | | | 108 | | | | indoor unit board). |
| | | P96 mo | del | | 144 | | | | When the model name set by the switch is differ- |
| | | P120 mc | del | | 180 | | | | ent from that of the unit connected, turn off the |
| | | P144 mc | del | | 216 | | | | power source of the outdoor and the indoor units, and change the setting of the model name (ca- |
| | | P168 mc | del | | 252 | | | | pacity code). |
| | | P192 mc | del | | 288 | | | | , , |
| | | P216 mc | del | | 324 | | | | |
| | | P240 mc | del | | 360 | | | | |
| | P264 model 396 P288 model 432 | | | | | | | | |
| | | | | | | | | | |
| | (0) | | | | | (0)4/5 | | | |
| | (2) | The model sele | | | | | | | Check the setting for the model selection switch on the outdoor unit (Dipswitches SW5-3 - 5-6 on the outdoor unit control board). |
| | | Model | | SV | V5 | | | | |
| | | Wodei | 3 | 4 | 5 | 6 | | | |
| | | 72 model | OFF | ON | OFF | OFF | | | |
| | | 96 model | ON | ON | OFF | OFF | | | |
| | | 120 model | OFF | OFF | ON | OFF | | | |
| | 144 model ON ON ON C | | OFF | | | | | | |
| | | | | | | | | | |
| | (3) | The outdoor ur (OS) that is cor are not properl | necte | d to t | he sa | | | | Confirm that the TB3 on the OC and OS are properly connected. |

7-9-2 Error Code [7101]

1. Error code definition Capacity code setting error

2. Error definition and error detection method

Connection of incompatible (wrong capacity code) indoor unit or outdoor unit

| Error source | Cause | | | | | | | | Check method and remedy |
|-----------------------------|-------|---|--|-----|-----|------------|----|---|---|
| Outdoor unit Indoor unit | (1) | the switch (S' *The capacity confirmed by | ame (capacity code) set by W2) is wrong. y of the indoor unit can be the self-diagnosis function on) of the outdoor unit. | | | be tion | 1) | Check the model name (capacity code) of the indoor unit which has the error source address set by the switch (SW2 on indoor unit board). When the model name set by the switch is different from that of the unit connected, turn off the power source of the outdoor and the indoor units, and change the setting of the capacity code. | |
| Outdoor unit | (2) | | selection switches (SW5-3 - outdoor unit are set incor- | | | | | | Check the setting for the model selection switch on the outdoor unit (Dipswitches SW5-3 - 5-6 on the outdoor unit control board). |
| | | Model | | SV | N5 | | | | |
| | | | 3 | 4 | 5 | 6 | | | |
| | | 72 model | OFF | ON | OFF | OFF | | | |
| | | 96 model | ON | ON | OFF | OFF | | | |
| | | 120 model | OFF | OFF | ON | OFF | | | |
| | | 144 model | ON ON OFF | | | | | | |
| | | | | | | | | | |

7-9-3 Error Code [7102]

1. Error code definition Wrong number of connected units

2. Error definition and error detection method

The number of connected indoor units is "0" or exceeds the allowable value.

| Error source | C | ause | Check method and remedy |
|--------------|--|--|--|
| Outdoor unit | terminal block (TB3 | nits connected to the outdoor) for indoor/ outdoor transmis- imitations described below. | Check whether the number of units connected to the outdoor terminal block (TB3) for indoor/ outdoor transmission lines does not exceed the limitation. (Set (1) and (2) on the left.) |
| | | 2) Check (2) - (3) on the left. | |
| | Number of units Total number of indoor units | Restriction on the number of units 1 - 18 : P72 model 1 - 24 : P96 model 1 - 30 : P120 model 1 - 36 : P144 model 1 - 42 : P168 model 1 - 48 : P192 model 2 - 50 : P216 model 2 - 50 : P240 model | Check whether the transmission line for the terminal block for centralized control (TB7) is not connected to the terminal block for the indoor/outdoor transmission line (TB3). Check the setting for the model selection switch on the outdoor unit (Dipswitches SW5-7 on the outdoor unit control board |
| | Number of BC controllers | 2 - 50 : P264 model 2 - 50 : P288 model | |
| | Number of Main BC controllers O or 1 Number of Sub BC controllers 0 11 | | |
| | | | |
| | Number of Sub BC controllers | 0 - 11 | |
| | Total number of LOSSNAY units (During auto address start-up only) | 0 or 1 | |
| | Total number of outdoor units | 1 : P72 - P144 models 2 : P168 - P288 models | |
| | unit or BC controller (3) Short-circuited trans | | |
| | •ME remote contro Nothing appears cause it is not po •MA remote contro "HO" or "PLEASE | | |
| | | n switch (SW5-7) on the out- FF. (Normally set to ON) | |
| | (5) Outdoor unit addres The outdoor units in not have sequential | the same refrigerant circuit do | |

7-9-4 Error Code [7105]

1. Error code definition Address setting error

2. Error definition and error detection method

Erroneous setting of OC unit address Erroneous setting of BC controller address

3. Cause, check method and remedy

| Error source | Cause | Check method and remedy |
|-------------------------------|---|---|
| Outdoor unit BC controller | Erroneous setting of OC unit address The address of outdoor unit is not being set to 51 - 100. The address of BC controller is not set to 51 - 100. | Check that the outdoor unit and BC controller addresses are set to 00 or a number between 51 and 100. If the outdoor unit address is out of the valid range, reset the address with the power to the outdoor unit turned off. If the BC controller address is out of the valid range, reset the address with the power to both the outdoor unit and BC controller turned off. |

7-9-5 Error Code [7106]

1. Error code definition Attribute setting error

2. Error definition and error detection method

| Error source | Cause | Check method and remedy |
|--------------|--|---|
| - | A remote controller for use with indoor units, such as the MA remote controller, is connected to the OA processing unit whose attribute is FU. | To operate the OA processing unit directly via a remote controller for use with indoor units, such as the MA remote controller, set the DIP SW 3-1 on the OA processing unit to ON. |
| | | Operation Method SW3-1 |
| | | Interlocked operation with the indoor unit OFF |
| | | Direct operation via the MA remote controller ON |

7-9-6 <u>Error Code [7107]</u>

1. Error code definition Port setting error

2. Error definition and error detection method

The port with wrong number is connected to the indoor unit. The model total connected to the port is greater than the specification.

3. Error source, cause, check method and remedy

After troubleshooting the error using the check methods and remedies shown below, turn the power back on.

| Error source | | Cause | Check method and remedy |
|---------------|-----|---|---|
| BC controller | (1) | Model total of indoor units per each port or per each port merge is greater than the specification. | Before resetting the port number using the port number setting switch or the model using the model (capacity code) |
| | | Total port number Model total | setting switch, turn off the power of the |
| | | Single branching 54 | outdoor unit, the BC controller and the indoor unit. |
| | | Two branches merge 96 | muoor unit. |
| | (2) | 4 or more indoor units are connected to the same port. | |
| | (3) | When two ports are used, the port with the smaller number is not connected to the indoor unit. | |
| | (4) | For the address of the BC controller (Sub 1 - 11), 50 is not added to the smallest indoor unit address, which is connected to the BC controller (Sub 1 - 11). | |
| | (5) | In the system to which multiple BC controllers are connected, the indoor unit address connected to the BC controller is not set as shown below. (i) The indoor unit address which is connected to the BC controller (main) (ii) The indoor unit address which is connected to the BC controller (Sub N) (iii) The indoor unit address which is connected to the BC controller (Sub N + 1) Address setting (i)<(ii)<(iiii) *(ii) and (iiii) can be reversed. | |
| | | Is there a BC YES controller (Sub)? | For the address of the BC controller (Sub) a Side do to the smallest indoor unit address, which is connected to the BC controller (Sub)? Change the BC controller (Sub)? |
| | | NO | YES YES |
| | | Are 4 or more indoor units YES YES | 1 |
| | | connected to the same port? Port No. setting error? Change the port No. | |
| | | NO NO | |
| | | Is the model total of indoor YES Adjust the piping connection to the port | Is the address of the indoor unit, which is connected to the the Change the indoor |
| | | units connected to the same port regreater than the item (1)? | BC controller (Main) , smaller than that of the indoor, which is |
| | | NO | connected to the BC controller controller address (Sub 1 - 11)? |
| | | ▼ | |
| | | Milhon his parts are used | , VES |
| | | When two ports are used, (s the port with the smallest number) Port No. setting error? YES Change the port No. | YES |
| | | is the port with the smallest number connected to the indoor unit? | YES |
| | | is the port with the smallest number Port No. setting error? YES Change the port No. | YES |
| | | s the port with the smallest number connected to the indoor unit? NO NO The wrong model YES Change the port No. Change the port No. Change the port No. Change the port No. | is the formula "Address of the |
| | | is the port with the smallest number connected to the indoor unit? NO NO NO NO NO NO NO NO NO N | is the formula "Address of the indoor unit connected to BC controller (set M) 1" Affonce unit |
| | | is the port with the smallest number connected to the indoor unit? NO The wrong model (capacity code) is set indoor unit model indoor unit model (capacity code) is set. | Is the formula "Address of the indoor unit connected to BC NO |

7-9-7 Error Code [7110]

1. Error code definition

Connection information signal transmission/reception error

2. Error definition and error detection method

The given indoor unit is inoperable because it is not properly connected to the outdoor unit in the same system.

3. Error source, cause, check method and remedy

| Error source | | Cause | | Check method and remedy |
|--------------|-----|--|----|--|
| Outdoor unit | (1) | Power to the transmission booster is cut off. | 1) | Confirm that the power to the transmission booster is not cut off by the booster being connected to the switch on the indoor unit. (The unit will not function properly unless the transmission booster is turned on.) |
| | (2) | Power resetting of the transmission booster and outdoor unit. | | →Reset the power to the outdoor unit. |
| | (3) | Wiring failure between OC and OS | 2) | Confirm that the TB3 on the OC and OS are properly connected. |
| | (4) | Broken wire between OC and OS. | 3) | Check the model selection switch on the out- |
| | (5) | The model selection switch (SW5-7) on the outdoor unit is set to OFF. (Normally set to ON) | | door unit (Dipswitch SW5-7 on the control board.). |

7-9-8 Error Code [7111]

1. Error code definition

Remote controller sensor fault

2. Error definition and error detection method

This error occurs when the temperature data is not sent although the remote controller sensor is specified.

| Error source | Cause | Check method and remedy |
|--|--|--|
| Indoor unit OA process- ing unit | The remote controller without the temperature sensor (the wireless remote controller or the ME compact remote controller (mounted type)) is used and the remote controller sensor for the indoor unit is specified. (SW1-1 is ON.) | Replace the remote controller with the one with built-in temperature sensor. |

7-9-9 Error Code [7113]

1. Error code definition Function setting error (improper connection of CNTYP)

| Error source | | Cause | | Check method and remedy |
|--------------|-----|--|-----|---|
| Outdoor unit | (1) | Wiring fault | (De | tail code 15) |
| | (2) | Loose connectors, short- circuit, contact failure | 1) | Check the connector CNTYP5 on the control board for proper connection. |
| | | | (De | tail code 14) |
| | (3) | Incompatible control board and INV board (replace- | 1) | Check the connector CNTYP5 on the control board for proper connection. |
| | | ment with a wrong circuit board) | 2) | Check the settings of SW5-3 through SW5-6 on the control board. |
| | (4) | DIP SW setting error on the | (De | tail code 12) |
| | | control board | 1) | Check the connector CNTYP2 on the control board for proper connection. |
| | | | 2) | Check the connector CNTYP5 on the control board for proper connection. |
| | | | 3) | Check the settings of SW5-3 through SW5-6 on the control board. |
| | | | (De | tail code 16) |
| | | | 1) | Check the connector CNTYP on the INV board for proper connection. |
| | | | 2) | Check the connector CNTYP5 on the control board for proper connection. |
| | | | 3) | Check the settings of SW5-3 through SW5-6 on the control board. |
| | | | 4) | Check the wiring between the control board and INV board. Refer to the following page(s). [7-2-1 Error Code [0403]](page 170) |
| | | | (De | tail code 0, 1, 5, 6) |
| | | | 1) | Check the wiring between the control board and INV board. Refer to the following page(s). [7-2-1 Error Code [0403]](page 170) |
| | | | 2) | Check the settings of SW5-3 through SW5-6 on the control board. |
| | | | 3) | Check the connector CNTYP5 on the control board for proper connection. |
| | | | (De | tail code Miscellaneous) |
| | | | | *If a set-model-name identification error occurs, check the detail code on the unit on which the error occurred. The detail code that appears on other units will be different from the ones shown above. |

7-9-10 <u>Error Code</u> [7117]

1. Error code definition Model setting error

| Error source | | Cause | Check method and remedy | | |
|--------------|------------------|--|-----------------------------|--|--|
| Outdoor unit | (1) Wiring fault | | (Detail code 15) | | |
| | (2) | Loose connectors, short-circuit, contact failure | 1) | Check the connector CNTYP5 on the control board for proper connection. | |
| | | | (Detail code 12) | | |
| | | | 1) | Check the connector CNTYP2 on the control board for proper connection. | |
| | | | 2) | Check the connector CNTYP5 on the control board for proper connection. | |
| | | | (Detail code 16) | | |
| | | | 1) | Check the connector CNTYP on the INV board for proper connection. | |
| | | | 2) | Check the connector CNTYP5 on the control board for proper connection. | |
| | | | 3) | Check the wiring between the control board and INV board. Refer to the following page(s). [7-2-1 Error Code [0403]](page 170) | |
| | | | (Detail code 0, 1, 5, 6) | | |
| | | | 1) | Check the wiring between the control board and INV board. Refer to the following page(s). [7-2-1 Error Code [0403]](page 170) | |
| | | | 2) | Check the settings of SW5-3 through SW5-6 on the control board. | |
| | | | 3) | Check the connector CNTYP5 on the control board for proper connection. | |
| | | | (Detail code Miscellaneous) | | |
| | | | | *If a set-model-name identification error occurs, check the detail code on the unit on which the error occurred. The detail code that appears on other units will be dif- ferent from the ones shown above. | |

7-9-11 <u>Error</u> Code [7130]

1. Error code definition Incompatible unit combination

2. Error definition and error detection method

The check code will appear when the indoor units and BC controller with different refrigerant systems are connected.

| Error source | Cause | | Check method and remedy | | |
|---------------|-------|--|-------------------------|--|--|
| Outdoor unit | (1) | Indoor units for use with different refrigerant systems The connected indoor unit is for use with R22 or R407C. Incorrect type of indoor units are connected. The M-NET connection adapter is connected to the indoor unit system in a system in which the Slim Model (A control) of units are connected to the M-NET. | 1) | Check the connected indoor unit model. Check whether the connecting adapter for M-NET is not connected to the indoor unit. (Connect the connecting adapter for M-NET to the outdoor unit.) | |
| | (2) | Combination of outdoor units Incorrect combination of outdoor units OC and OS. Only the combinations listed in [2-1 System Configurations] are allowed. In addition, the connected outdoor units cannot mix old and new model names. | 2) | Check the model name of the outdoor units (OC) and (OS). Check whether the combination of the outdoor units is as per [2-1 System Configurations]. | |
| BC controller | | Due to a function setting failure in the BC controller, the BC controller is recognized as intended for use with R22 or R407C only. | | Check the connector TYP1 on the control board of the BC controller. | |
| | (1) | Wiring fault | | | |
| | (2) | Loose connectors, short-circuit, contact failure | | | |

Chapter 8 Troubleshooting Based on Observed Symptoms

| 8-1 | MA Remote Controller Problems | 243 |
|---------------------------------------|--|-------------------|
| 8-1-1 | The LCD Does Not Light Up. | 243 |
| 8-1-2 | The LCD Momentarily Lights Up and Then Goes Off. | 244 |
| 8-1-3 | "HO" and "PLEASE WAIT" Do Not Go Off the Screen. | 245 |
| 8-1-4 | Air Conditioning Units Do Not Operate When the ON Button Is Pressed. | 246 |
| 8-2 | ME remote Controller Problems | 247 |
| 8-2-1 | The LCD Does Not Light Up. | 247 |
| 8-2-2 | The LCD Momentarily Lights Up and Then Goes Off. | 248 |
| 8-2-3 | "HO" Does Not Go Off the Screen. | 249 |
| 8-2-4 | "88" Appears on the LCD. | 250 |
| 8-3 | Refrigerant Control Problems | 251 |
| 8-3-1 | Units in the Cooling Mode Do Not Operate at Expected Capacity | 251 |
| 8-3-2 | Units in the Heating Mode Do Not Operate at Expected Capacity. | 253 |
| 8-3-3 | Outdoor Units Stop at Irregular Times. | 255 |
| 8-4 | Checking Transmission Waveform and for Electrical Noise Interference | 256 |
| 8-4-1 | M-NET | 256 |
| 8-4-2 | MA Remote Controller | 258 |
| 8-5 | Pressure Sensor Circuit Configuration and Troubleshooting Pressure Sensor Problems | 259 |
| 8-5-1 | Comparing the High-Pressure Sensor Measurement and Gauge Pressure | 259 |
| 8-5-2 | High-Pressure Sensor Configuration (63HS1, PS1, PS3) | 259 |
| 8-5-3 | Comparing the Low-Pressure Sensor Measurement and Gauge Pressure | 260 |
| 8-5-4 | Low-Pressure Sensor Configuration (63LS) | 260 |
| 8-6 | Troubleshooting Solenoid Valve Problems | 261 |
| 8-7 | Troubleshooting Outdoor Unit Fan Problems | 265 |
| 8-8 | Troubleshooting LEV Problems | 266 |
| 8-8-1 | General Overview on LEV Operation | 266 |
| 8-8-2 | Possible Problems and Solutions | 268 |
| 8-8-3 | Coil Removal Instructions | 269 |
| 8-9 8-9-1 | Troubleshooting Problems with Major Components on BC Controller | |
| 8-9-2 | Temperature Sensor | |
| 8-9-3 | Troubleshooting Flowchart for LEVs | |
| 8-9-4 | Troubleshooting Flowchart for Solenoid Valves | |
| 8-9-5 | BC Controller Transformer | |
| 8-10 | Troubleshooting Inverter Problems | |
| 8-10-1 | Inverter-Related Problems and Solutions | |
| 8-10-2 | | |
| | Checking the Compressor for Ground Fault and Coil Resistance Problems | |
| 8-10-4 | Checking the Inverter for Damage at No-Load | |
| 8-10-5 | Checking the Inverter for Damage during Compressor Operation | |
| | Checking the Fan Motor for Ground Fault and Coil Resistance Problems | |
| | Checking the Fan Board Error Detection Circuit at No Load | |
| 8-10-7 | | |
| | Checking the Fan Inverter for Damage at No Load | 289 |
| 8-10-8 | Checking the Fan Inverter for Damage at No Load | |
| 8-10-8 8-10-9 | Checking the Fan Inverter for Damage with Load | 290 |
| 8-10-8 8-10-9 8-10-10 | Checking the Fan Inverter for Damage with Load | 290 290 |
| 8-10-8 8-10-9 8-10-10 8-10-1 | Checking the Fan Inverter for Damage with Load | 290 290 291 |

| 8-10-13 | Simple Check on Inverter Circuit Components | 292 |
|---------|--|-----|
| 8-10-14 | Troubleshooting Problems with IGBT Module | 292 |
| 8-11 | Control Circuit | 294 |
| 8-11-1 | Control Power Supply Function Block | 294 |
| 8-11-2 | Troubleshooting Problems with Outdoor Unit Transmission Power Supply Circuit | 296 |
| 8-12 | Measures for Refrigerant Leakage | 297 |
| 8-13 | Compressor Replacement Instructions | 299 |
| 8-14 | Solenoid Valve Block and Check Valve Replacement Instructions | 301 |
| 8-15 | BC Controller Maintenance Instructions | 309 |
| 8-16 | Troubleshooting Problems Using the LED Status Indicators on the Outdoor Unit | |

8-1 MA Remote Controller Problems

8-1-1 The LCD Does Not Light Up.

1. Phenomena

Even if the operation button on the remote controller is pressed, the display remains unlit and the unit does not start running.(Power indicator ©does not appear on the screen.)

2. Cause

- 1) The power is not supplied to the indoor unit.
 - •The main power of the indoor unit is not on.
 - •The connector on the indoor unit board has come off.
 - •The fuse on the indoor unit board has melted.
 - •Transformer failure and disconnected wire of the indoor unit.
- 2) Incorrect wiring for the MA remote controller
 - *Disconnected wire for the MA remote controller or disconnected line to the terminal block.
 - *Short-circuited MA remote controller wiring
 - Incorrect wiring of the MA remote controller cables
 - •Incorrect connection of the MA remote wiring to the terminal block for transmission line (TB5) on the indoor unit
 - •Wiring mixup between the MA remote controller cable and power supply cable
 - •Reversed connection of the wire for the MA remote controller and the M-NET transmission line on the indoor unit
- 3) The number of the MA remote controllers that are connected to an indoor unit exceeds the allowable range (2 units).
- 4) The length or the diameter of the wire for the MA remote controller are out of specification.
- 5) Short circuit of the wire for the remote display output of the outdoor unit or reversed polarity connection of the relay.
- The indoor unit board failure
- 7) MA remote controller failure

- 1) Measure voltages of the MA remote controller terminal (among 1 to 3).
 - •If the voltage is between DC 9 and 12V, the remote controller is a failure.
 - •If no voltage is applied, check the causes 1) and 3) and if the cause is found, correct it.
 - If no cause is found, refer to 2).
- Remove the wire for the remote controller from the terminal block (TB15) on the MA remote controller for the indoor unit, and check voltage among 1 to 3.
 - •If the voltage is between DC 9 and 12 V, check the causes 2) and 4) and if the cause is found, correct it.
 - •If no voltage is applied, check the cause 1) and if the cause is found, correct it.
 - If no cause is found, check the wire for the remote display output (relay polarity).
 - If no further cause is found, replace the indoor unit board.

8-1-2 The LCD Momentarily Lights Up and Then Goes Off.

1. Phenomena


When the remote controller operation SW is turned on, the operation status briefly appears on the display, then it goes off, and the display lights out immediately, and the unit stops.

2. Cause

- 1) The power for the M-NET transmission line is not supplied from the outdoor unit. For details, refer to the following page(s). [8-11-2 Troubleshooting Problems with Outdoor Unit Transmission Power Supply Circuit](page 296)
- Short circuit of the transmission line.
- 3) Incorrect wiring of the M-NET transmission line on the outdoor unit.
 - *Disconnected wire for the MA remote controller or disconnected line to the terminal block.
 - •The indoor transmission line is connected incorrectly to the transmission terminal block for centralized controller (TB7).
 - •The male power supply connectors on the multiple outdoor units are connected to the female power supply switch connector (CN40).
 - In the system to which the power supply unit for transmission lines is connected, the male power supply connector is connected to the female power supply switch connector (CN40) on the outdoor unit.
- 4) Disconnected M-NET transmission line on the indoor unit side.
- 5) Disconnected wire between the terminal block for M-NET line (TB5) of the indoor unit and the indoor unit board (CN2M) or disconnected connector.

3. Check method and remedy

When 2) and 3) above apply, check code 7102 will be displayed on the self-diagnosis LED.



8-1-3 "HO" and "PLEASE WAIT" Do Not Go Off the Screen.

1. Phenomena


"HO" or "PLEASE WAIT" display on the remote controller does not disappear, and no operation is performed even if the button is pressed. ("HO" or "PLEASE WAIT" display will normally turn off 5 minutes later after the power on.)

2. Cause

- 1) The power for the M-NET transmission line is not supplied from the outdoor unit. For details, refer to the following page(s). [8-11-2 Troubleshooting Problems with Outdoor Unit Transmission Power Supply Circuit](page 296)
- Short-circuited transmission line
- 3) Incorrect wiring of the M-NET transmission line on the outdoor unit.
 - *Disconnected wire for the MA remote controller or disconnected line to the terminal block.
 - •The indoor transmission line is connected incorrectly to the transmission terminal block for centralized controller (TB7).
 - •The male power supply connectors on the multiple outdoor units are connected to the female power supply switch connector (CN40).
 - In the system to which the power supply unit for transmission lines is connected, the male power supply connector is connected to the female power supply switch connector (CN40) on the outdoor unit
- 4) Disconnected M-NET transmission line on the indoor unit.
- 5) Disconnected wire between the terminal block for M-NET line (TB5) of the indoor unit and the indoor unit board (CN2M) or disconnected connector.
- 6) Incorrect wiring for the MA remote controller
 - *Short-circuited wire for the MA remote controller
 - *Disconnected wire for the MA remote controller (No.2) and disconnected line to the terminal block.
 - •Reversed daisy-chain connection between groups
 - •Incorrect wiring for the MA remote controller to the terminal block for transmission line connection (TB5) on the indoor unit
 - •The M-NET transmission line is connected incorrectly to the terminal block (TB15) for the MA remote controller.
- 7) The sub/main setting of the MA remote controller is set to sub.
- 8) 2 or more main MA remote controllers are connected.
- 9) Indoor unit board failure (MA remote controller communication circuit)
- 10) Remote controller failure
- 11) Outdoor failure (Refer to the following page(s). [8-16 Troubleshooting Problems Using the LED Status Indicators on the Outdoor Unit](page 312))

3. Check method and remedy

1) When 2) and 3) above apply, check code 7102 will be displayed on the self-diagnosis LED.



8-1-4 Air Conditioning Units Do Not Operate When the ON Button Is Pressed.

1. Phenomena

Even if the operation button on the remote controller is pressed, the indoor and the outdoor units do not start running.

Troubleshooting Based on Observed Symptoms

8-2 ME remote Controller Problems

8-2-1 The LCD Does Not Light Up.

1. Phenomena

Even if the operation button on the remote controller is pressed, the display remains unlit and the unit does not start running. (Power indicator ©does not appear on the screen.)

2. Cause

- 1) The power for the M-NET transmission line is not supplied from the outdoor unit.
- 2) Short circuit of the transmission line.
- 3) Incorrect wiring of the M-NET transmission line on the outdoor unit.
 - *Disconnected wire for the MA remote controller or disconnected line to the terminal block.
 - •The indoor transmission line is connected incorrectly to the transmission terminal block for centralized controller (TB7).
- 4) Disconnected transmission line on the remote controller.
- 5) Remote controller failure
- 6) Outdoor unit failure (For details, refer to the following page(s). [8-16 Troubleshooting Problems Using the LED Status Indicators on the Outdoor Unit](page 312))

- 1) Check voltage of the transmission terminal block for of the ME remote controller.
 - *If voltage between is 17V and 30V \rightarrow ME remote controller failure
 - When voltage is 17V or less → For details, refer to the following page(s).
 - [8-11-2 Troubleshooting Problems with Outdoor Unit Transmission Power Supply Circuit](page 296)
- 2) When 2) and 3) above apply, check code 7102 will be displayed on the self-diagnosis LED.

8-2-2 The LCD Momentarily Lights Up and Then Goes Off.


1. Phenomena

When the remote controller operation SW is turned on, a temporary operation display is indicated, and the display lights out immediately.

2. Cause

- 1) The power is not supplied to the indoor unit.
 - •The main power of the indoor unit (AC208/230V) is not on.
 - *The connector on the indoor unit board has come off.
 - •The fuse on the indoor unit board has melted.
 - •Transformer failure and disconnected wire of the indoor unit
 - •The indoor unit board failure
- 2) The outdoor control board failure

As the indoor unit does not interact with the outdoor unit, the outdoor unit model cannot be recognized.



*1. Refer to the parts catalog "transformer check".

8-2-3 "HO" Does Not Go Off the Screen.

1. Phenomena

"HO" display on the remote controller does not disappear, and no operation is performed even if the button is pressed.

2. Cause

Without using MELANS

- 1) Outdoor unit address is set to "00"
- 2) A wrong address is set.
 - •The address of the indoor unit that is connected to the remote controller is incorrect. (It should equal the ME remote controller address plus 100.)
 - •A wrong address is set to the ME remote controller. (100 must be added to the address of the indoor unit.)
- 3) Faulty wiring of the terminal block for transmission line (TB5) of the indoor unit in the same group with the remote controller.
- 4) The centralized control switch (SW5-1) on the outdoor unit is set to ON.
- 5) Disconnection or faulty wiring of indoor unit transmission line.
- 6) Disconnection between the terminal block for M-NET line connection (TB5) of the indoor unit and the male connector (CN2M)
- 7) The male power supply connectors on 2 or more outdoor units are connected to the female power supply switch connector (CN40) for the transmission line for centralized control.
- 8) Outdoor unit control board failure
- 9) Indoor unit control board failure
- 10) Remote controller failure


Interlocking control with MELANS

- 1) No group registration is made using MELANS. (The indoor unit and the ME remote controller are not grouped.)
- 2) Disconnected transmission line for centralized control (TB7) of the outdoor unit
- 3) The male power supply connector is connected to CN40 on more than one outdoor unit, or the connector is connected to CN40 on the outdoor unit in the system to which a power supply unit for transmission line is connected.

Using MELANS

When MELANS is used, "HO" display on the remote controller will disappear when the indoor unit and the local remote controller (ME remote controller) are grouped.

If "HO" does not disappear after the registration, check items 1) through 3) in the "Cause" column of the section on interlocked control with MELANS.



^{*1.} When the indoor unit address is set to 1 - 50, the address will be forcibly set to 100.

8-2-4 "88" Appears on the LCD.

1. Phenomena

"88" appears on the remote controller when the address is registered or confirmed.

2. Cause, check method and remedy

| | Cause | | Check method and remedy |
|---|---|-----|---|
| An error occurs when the address is registered or confirmed. (common) | | | |
| 1. | A wrong address is set to the unit to be coupled. | (1) | Confirm the address of unit to be coupled. |
| 2. | The transmission line of the unit to be coupled is disconnected or is not connected. | (2) | Check the connection of transmission line. |
| 3. | Circuit board failure of the unit to be coupled | (3) | Check voltage of the terminal block for transmission line of the unit to be coupled. |
| | | 1) | Normal if voltage is between DC17 and 30V. |
| 4. | Improper transmission line work | 2) | Check (5) in case other than 1). |
| | rates at interlocking registration between SNAY and the indoor unit | | |
| 5. | The power of LOSSNAY is OFF. | (4) | Check for the main power of LOSSNAY. |
| syste | Generates at confirmation of controllers used in the system in which the indoor units connected to different outdoor units are grouped | | |
| 6. | The power of the outdoor unit to be confirmed has been cut off. | (5) | Check the power supply of the outdoor unit which is coupled with the unit to be confirmed. |
| 7. | Transmission line is disconnected from the terminal block for central control system connection (TB7) on the outdoor unit. | (6) | Check that the transmission line for centralized control (TB7) of the outdoor unit is not disconnected. |
| 8. | When the indoor units connected to different outdoor units are grouped without MELANS, the male power supply connector is not connected to the female power supply switch connector (CN40) for the transmission line for centralized control. | (7) | Check voltage of the transmission line for centralized control. |
| 9. | The male power supply connectors on 2 or more outdoor units are connected to the female power supply switch connector (CN40) for the transmission line for centralized control. | 1) | Normal when voltage is between 10V and 30V |
| 10. | In the system to which MELANS is connected, the male power supply connector is connected to the female power supply switch connector (CN40) for the transmission line for centralized control. | 2) | Check 8 - 11 described on the left in case other than 1). |
| 11. | Short circuit of the transmission line for centralized control | | |

8-3 Refrigerant Control Problems

8-3-1 Units in the Cooling Mode Do Not Operate at Expected Capacity.

1. Phenomena

Although cooling operation starts with the normal remote controller display, the capacity is not enough

2. Cause, check method and remedy

| | Cause | | Check method and remedy |
|----|--|-------|--|
| 1. | Compressor frequency does not rise sufficiently. •Faulty detection of pressure sensor. •Protection works and compressor frequency does not rise due to high discharge temperature •Protection works and compressor frequency does not rise due to high pressure •Pressure drops excessively. | (1) | Check pressure difference between the detected pressure by the pressure sensor and the actual pressure with self-diagnosis LED. → If the accurate pressure is not detected, check the pressure sensor. Refer to the following page(s). [8-5-1 Comparing the High-Pressure Sensor Measurement and Gauge Pressure](page 259) |
| | | Note: | Lower inlet pressure by the low pressure sensor than the actual pressure causes insufficient capacity. SW4 setting (SW6-10: OFF) |
| | | | High pressure sensor SW4 |
| | | | SW4 ON 1 2 3 4 5 6 7 8 9 10 |
| | | (2) | Check temperature difference between the evaporating temperature (Te) and the target evaporating temperature (Tem) with self-diagnosis LED. |
| | | Note: | Higher Te than Tem causes insufficient capacity. SW4 setting (SW6-10: OFF) |
| | | | Evaporating temperature Te SW4 ON 1 2 3 4 5 6 7 8 9 10 Target evaporating temperature Tem SW4 ON 1 2 3 4 5 6 7 8 9 10 |
| | | Note: | Protection works and compressor frequency does not rise even at higher Te than Tem due to high discharge temperature and high pressure. At high discharge temperature: Refer to the following page(s).[7-3-1 Error Code [1102]](page 173) At high pressure: Refer to the following page(s). [7-3-3 Error Code [1302] (during operation)](page 175) |



| | Cause | Check method and remedy |
|-----|--|--|
| 2. | Indoor unit LEV malfunction Insufficient refrigerant flows due to LEV malfunction (not enough opening) or protection works and compressor frequency does not rise due to pressure drop. Refrigerant leak from LEV on the stopping unit causes refrigerant shortage on the running unit. | Refer to the following page(s).[8-8 Troubleshooting LEV Problems](page 266) |
| 3. | RPM error of the outdoor unit FAN Motor failure or board failure, or airflow rate decrease due to clogging of the heat exchanger The fan is not properly controlled as the outdoor temperature cannot be precisely detected by the temperature sensor. The fan is not properly controlled as the pressure cannot be precisely detected by the pressure sensor. | Refer to the following page(s). [8-7 Troubleshooting Outdoor Unit Fan Problems](page 265) [7-7-2 Error Codes [5103, 5104, 5105, 5106, 5107]](page 200) [7-3-3 Error Code [1302] (during operation)](page 175) |
| 4. | Long piping length The cooling capacity varies greatly depending on the pressure loss. (When the pressure loss is large, the cooling capacity drops.) | Check the piping length to determine if it is contributing to performance loss. Piping pressure loss can be estimated from the temperature difference between the indoor unit heat exchanger outlet temperature and the saturation |
| 5. | Piping size is not proper (thin) | temperature (Te) of 63LS. →Correct the piping. |
| 6. | Insufficient refrigerant amount Protection works and compressor frequency does not rise due to high discharge temperature. | Refer to item 1 (Compressor frequency does not rise sufficiently.) on the previous page. (page 251) Refer to the following page(s).[6-3 Evaluating and Adjusting Refrigerant Charge](page 156) |
| 7. | Clogging by foreign object | Check the temperature difference between in front of and behind the place where the foreign object is clogging the pipe (upstream side and downstream side). When the temperature drops significantly, the foreign object may clog the pipe. → Remove the foreign object inside the pipe. |
| 8. | The indoor unit inlet temperature is excessively. (Less than 15°C [59°F] WB) | Check the inlet air temperature and for short cycling. Change the environment where the indoor unit is used. |
| 9. | Compressor failure The amount of circulating refrigerant decreases due to refrigerant leak in the compressor. | Check the discharge temperature to determine if the refrigerant leaks, as it rises if there is a leak. |
| 10. | BC controller LEV 3 actuation failure Sufficient liquid refrigerant is not be supplied to the indoor unit as sufficient sub cool cannot be secured due to LEV3 malfunction. | Refer to the following page(s).[8-8 Troubleshooting LEV Problems](page 266) It most likely happens when there is little difference or no difference between TH12 and TH15. |
| 11. | TH12, TH15 and 63HS1 sensor failure or faulty wiring LEV3 is not controlled normally. | ◆Check the thermistor. ◆Check wiring. |

8-3-2 Units in the Heating Mode Do Not Operate at Expected Capacity.

1. Phenomena

Although heating operation starts with the normal remote controller display, the capacity is not enough.

2. Cause, check method and remedy

| | Cause | | Check method and remedy |
|----|---|-------|---|
| 1. | Compressor frequency does not rise sufficiently. •Faulty detection of pressure sensor. •Protection works and compressor frequency does not rise due to high discharge temperature •Protection works and compressor frequency does not rise due to high pressure. | (1) | Check pressure difference between the detected pressure by the pressure sensor and the actual pressure with self-diagnosis LED. → If the accurate pressure is not detected, check the pressure sensor. Refer to the following page(s). [8-5-1 Comparing the High-Pressure Sensor Measurement and Gauge Pressure](page 259) |
| | | Note: | Higher inlet pressure by the high pressure sensor than the actual pressure causes insufficient capacity. SW4 setting (SW6-10: OFF) |
| | | | High pressure sensor SW4 |
| | | | Low pressure sensor SW4 ON 1 2 3 4 5 6 7 8 9 10 |
| | | (2) | Check the difference between the condensing temperature (Tc) and the target condensing temperature (Tcm) with self-diagnosis LED. |
| | | Note: | Higher Tc than Tcm causes insufficient capacity. SW4 setting (SW6-10: OFF) |
| | | | Condensing temperature Tc SW4 ON |
| | | | 1 2 3 4 5 6 7 8 9 10 Target condensing temperature Tcm SW4 ON 1 2 3 4 5 6 7 8 9 10 |
| | | Note: | Protection works and compressor frequency does not rise even at lower Tc than Tcm due to high discharge temperature and high pressure. At high discharge temperature: Refer to the following page(s).[7-3-1 Error Code [1102]](page 173) At high pressure: Refer to the following page(s).[7-3-3 Error Code [1302] (during operation)](page 175) |



| | Cause | Check method and remedy | |
|-----|--|---|--|
| 2. | Indoor unit LEV malfunction Insufficient refrigerant flows due to LEV malfunction (not enough opening). | Refer to the following page(s).[8-8 Troubleshooting LEV Problems](page 266) | |
| 3. | Temperature reading error on the indoor unit piping temperature sensor If the temperature reading on the sensor is higher than the actual temperature, it makes the subcool seem smaller than it is, and the LEV opening decreases too much. | Check the thermistor. | |
| 4 | RPM error of the outdoor unit FAN •Motor failure or board failure, or airflow rate decrease, pressure drop due to clogging of the heat exchanger leading to high discharge temperature •The fan is not properly controlled as the temperature cannot be precisely detected with the piping sensor. | Refer to the following page(s). [8-7 Troubleshooting Outdoor Unit Fan Problems](page 265) | |
| 5. | Insulation failure of the refrigerant piping | | |
| 6. | Long piping length Excessively long piping on the high pressure side causes pressure loss leading to increase in the high pressure. | Confirm that the characteristic of capacity drop due to piping length. → Change the pipe | |
| 7. | Piping size is not proper (thin) | | |
| 8. | Clogging by foreign object | Check the temperature difference between the upstream and the downstream of the pipe section that is blocked. Since blockage in the extended section is difficult to locate, operate the unit in the cooling cycle, and follow the same procedures that are used to locate the blockage of pipe during cooling operation. → Remove the blockage in the pipe. | |
| 9. | The indoor unit inlet temperature is excessively high.(exceeding 28°C [82°F]) | Check the inlet air temperature and for short cycling. Change the environment where the indoor unit is used. | |
| 10. | Insufficient refrigerant amount Protection works and compressor frequency does not rise due to low discharge temperature Refrigerant recovery operation is likely to start. | Refer to item 1 (Compressor frequency does not rise sufficiently.) on the previous page. (page 253) Refer to the following page(s).[6-3 Evaluating and Adjusting Refrigerant Charge](page 156) | |
| 11. | Compressor failure (same as in case of cooling) | Check the discharge temperature. | |
| 12. | BC controller LEV 3 actuation failure A drop in the low pressure that is caused either by a blockage of liquid pipe or by a pressure loss and the resultant slowing of refrigerant flow causes a tenden- cy for the discharge temperature to rise. | Refer to the following page(s).[8-8 Troubleshooting LEV Problems](page 266) | |

8-3-3 Outdoor Units Stop at Irregular Times.

1. Phenomena

Outdoor unit stops at times during operation.

2. Cause, check method and remedy

| | Cause | | Check method and remedy |
|--------|---|-----|---|
| | The first stop is not considered as an error, as the unit turns to anti-restart mode for 3 minutes as a preliminary error. | (1) | Check the mode operated in the past by displaying preliminary error history on LED display with SW4. |
| | Error mode | (2) | Reoperate the unit to find the mode that stops the |
| 1) | Abnormal high pressure | | unit by displaying preliminary error history on LED display with SW4. |
| 2) | Abnormal discharge air temperature | | Refer to the reference page for each error mode. |
| 3) | Heatsink thermistor failure | | *Display the indoor piping temperature table with SW4 to check whether the freeze proof operation runs properly, and check the temperature. |
| 4) | Thermistor failure | | Refer to the following page(s).9 LED Status Indica- |
| 5) | Pressure sensor failure | | tors on the Outdoor Unit Circuit Board(page 315) |
| 6) | Over-current break | | |
| 7) | Refrigerant overcharge | | |
| Note1: | Frost prevention tripping only under cooling mode may be considered in addition to the above. (Freeze protection is detected by one or all indoor units.) | | |
| Note2: | Even the second stop is not considered as an error when some specified errors occur. (eg. The third stop is considered as an error when the thermistor error occurs.) | | |

8-4 Checking Transmission Waveform and for Electrical Noise Interference


8-4-1 M-NET

Control is performed by exchanging signals between the outdoor unit and the indoor unit (ME remote controller) through M-NET transmission. Noise interference on the transmission line will interrupt the normal transmission, leading to erroneous operation.

(1) Symptoms caused by noise interference on the transmission line

| Cause | Erroneous operation | Error code | Error code definition |
|---|---|--------------|---|
| | Signal is transformed and will be misjudged as the signal of another address. | 6600 | Address overlap |
| | Transmission wave pattern is transformed due to the noise creating a new signal | 6602 | Transmission pro- cessor hardware er- ror |
| Noise interference on the transmission line | Transmission wave pattern is transformed due to the noise, and will not be received normally leading to no acknowledgement (ACK). | 6607 | No ACK error |
| | Transmission cannot be performed due to the fine noise. | 6603 | Transmission line bus busy error |
| | Transmission is successful; however, the acknowledgement (ACK) or the response cannot be received normally due to the noise. | 6607 6608 | No ACK error No response error |

(2) Wave shape check



Wave shape check

Check the wave pattern of the transmission line with an oscilloscope. The following conditions must be met.

- Small wave pattern (noise) must not exist on the transmission signal. (Minute noise (approximately 1V) can be generated by DC-DC converter or the inverter operation; however, such noise is not a problem when the shield of the transmission line is grounded.)
- 2) The sectional voltage level of transmission signal should be as follows.

| Logic | Voltage level of the transmission line |
|-------|--|
| 0 | V _{HL} = 2.5V or higher |
| 1 | V _{BN} = 1.3V or below |

(3) Check method and remedy

1) Measures against noise

Check the followings when noise exists on the wave or the errors described in (1) occur.

| | | Error code definition | Remedy |
|---|----|--|--|
| Check that the wiring work is performed according to wiring | 1. | The transmission line and the power line are not wired too closely. | Isolate the transmission line from the power line (5cm [1-31/32"] or more). Do not insert them in the same conduit. |
| specifications. | 2. | The transmission line is not bundled with that for another systems. | The transmission line must be isolated from another transmission line. When they are bundled, erroneous operation may be caused. |
| | 3. | The specified wire is used for the transmission line. | Use the specified transmission line. Type: Shielded wire CVVS/CPEVS/MVVS (For ME remote controller) Diameter: 1.25mm ² [AWG16] or more (Remote controller wire: 0.3 - 1.25mm ² [AWG22-16]) |
| | 4. | When the transmission line is daisy-chained on the indoor unit terminals, are the shields daisy-chained on the terminals, too? | The transmission is two-wire daisy-chained. The shielded wire must be also daisy-chained. When the shielded cable is not daisy-chained, the noise cannot be reduced enough. |
| Check that the grounding work is performed according to grounding specifications. | 5. | Is the shield of the indoor- outdoor transmission ca- ble grounded to the earth terminal on the outdoor unit? | Connect the shield of the indoor-outdoor transmission cable to the earth terminal (h) on the outdoor unit. If no grounding is provided, the noise on the transmission line cannot escape leading to change of the transmission signal. |
| | 6. | Check the treatment method of the shield of the transmission line (for centralized control). | The transmission cable for centralized control is less subject to noise interference if it is grounded to the outdoor unit whose power jumper cable was moved from CN41 to CN40 or to the power supply unit. The environment against noise varies depending on the distance of the transmission lines, the number of the connected units, the type of the controllers to be connected, or the environment of the installation site. Therefore, the transmission line work for centralized control must be performed as follows. |
| | | | When no grounding is provided: Ground the shield of the transmission cable by connecting to the outdoor unit whose power jumper connector was moved from CN41 to CN40 or to the power supply unit. |
| | | | When an error occurs even though one point grounding is provided: Ground the shield on all outdoor units. |

2) Check the followings when the error "6607" occurs, or "HO" appears on the display on the remote controller.

| | Error code definition | Remedy |
|-----|---|--|
| 7. | The farthest distance of transmission line is 200m [656ft] or longer. | Check that the farthest distance from the outdoor unit to the indoor unit and to the remote controller is within 200m [656ft]. |
| 8. | The types of transmission lines are different. | Use the specified transmission line. Type: Shielded wire CVVS/CPEVS/MVVS (For ME remote controller) Diameter: 1.25mm² [AWG16] or more (Remote controller wire: 0.3-1.25mm² [AWG22-16]) |
| 9. | Outdoor unit circuit board failure | Replace the outdoor unit control board or the power supply board for the transmission line. |
| 10. | Indoor unit circuit board failure or remote controller failure | Replace the indoor unit circuit board or the remote controller. |
| 11. | The MA remote controller is connected to the M-NET transmission line. | Connect the MA remote controller to the terminal block for MA remote controller (TB15). |


8-4-2 MA Remote Controller


The communication between the MA remote controller and the indoor unit is performed with current tone burst.

(1) Symptoms caused by noise interference on the transmission line

If noise is generated on the transmission line, and the communication between the MA remote controller and the indoor unit is interrupted for 3 minutes in a row, MA transmission error (6831) will occur.

(2) Confirmation of transmission specifications and wave pattern





Troubleshooting Based on Observed Symptoms

8-5 Pressure Sensor Circuit Configuration and Troubleshooting Pressure Sensor Problems

8-5-1 Comparing the High-Pressure Sensor Measurement and Gauge Pressure

By configuring the digital display setting switch (SW4 (when SW6-10 is set to OFF)) as shown in the figure below, the pressure as measured by the high-pressure sensor appears on the LED1 on the control board.





The figure at left shows that the switches 1 through 5 are set to ON and 6 through 10 are set to OFF.

- (1) While the sensor is stopped, compare the gauge pressure and the pressure displayed on self-diagnosis LED1.
- 1) When the gauge pressure is between 0 and 0.098MPa [14psi], internal pressure is caused due to gas leak.
- 2) When the pressure displayed on self-diagnosis LED1 is between 0 and 0.098MPa [14psi], the connector may be defective or be disconnected. Check the connector and go to (4).
- 3) When the pressure displayed on self-diagnosis LED1 exceeds 4.15MPa [601psi], go to (3).
- 4) If other than 1), 2) or 3), compare the pressures while the sensor is running. Go to (2).
- (2) Compare the gauge pressure and the pressure displayed on self-diagnosis LED1 while the sensor is running. (Compare them by MPa [psi] unit.)
- 1) When the difference between both pressures is within 0.098MPa [14psi], both the high pressure sensor and the control board are normal.
- 2) When the difference between both pressures exceeds 0.098MPa [14psi], the high pressure sensor has a problem. (performance deterioration)
- 3) When the pressure displayed on self-diagnosis LED1 does not change, the high pressure sensor has a problem.
- (3) Remove the high pressure sensor from the control board to check the pressure on the self-diagnosis LED1.
- 1) When the pressure displayed on self-diagnosis LED1 is between 0 and 0.098MPa [14psi], the high pressure sensor has a problem.
- 2) When the pressure displayed on self-diagnosis LED1 is approximately 4.15MPa [601psi], the control board has a problem.
- (4) Remove the high pressure sensor from the control board, and short-circuit between the No.2 and 3 connectors (63HS1, PS1, PS3) to check the pressure with self-diagnosis LED1.
- 1) When the pressure displayed on the self-diagnosis LED1 exceeds 4.15MPa [601psi], the high pressure sensor has a problem.
- 2) If other than 1), the control board has a problem.


8-5-2 High-Pressure Sensor Configuration (63HS1, PS1, PS3)


The high pressure sensor consists of the circuit shown in the figure below. If DC 5V is applied between the red and the black wires, voltage corresponding to the pressure between the white and the black wires will be output, and the value of this voltage will be converted by the microcomputer. The output voltage is 0.071V per 0.098MPa [14psi].

Note

The pressure sensor on the body side is designed to connect to the connector. The connector pin number on the body side is different from that on the control board side.

| Body side | | Control board side | |
|-----------|-------|--------------------|--|
| Vcc | Pin 1 | Pin 3 | |
| Vout | Pin 2 | Pin 2 | |
| GND | Pin 3 | Pin 1 | |





8-5-3 Comparing the Low-Pressure Sensor Measurement and Gauge Pressure

By configuring the digital display setting switch (SW4 (when SW6-10 is set to OFF)) as shown in the figure below, the pressure as measured by the low-pressure sensor appears on the LED1 on the control board.





The figure at left shows that the switches 1 through 5 are set to ON and 6 through 10 are set to OFF.

- (1) While the sensor is stopped, compare the gauge pressure and the pressure displayed on self-diagnosis LED1.
- 1) When the gauge pressure is between 0 and 0.098MPa [14psi], internal pressure is caused due to gas leak.
- 2) When the pressure displayed on self-diagnosis LED1 is between 0 and 0.098MPa [14psi], the connector may be defective or be disconnected. Check the connector and go to (4).
- 3) When the pressure displayed on self-diagnosis LED1 exceeds 1.7MPa [247psi], go to (3).
- 4) If other than 1), 2) or 3), compare the pressures while the sensor is running. Go to (2).
- (2) Compare the gauge pressure and the pressure displayed on self-diagnosis LED1 while the sensor is running.(Compare them by MPa [psi] unit.)
- 1) When the difference between both pressures is within 0.03MPa [4psi], both the low pressure sensor and the control board are normal.
- 2) When the difference between both pressures exceeds 0.03MPa [4psi], the low pressure sensor has a problem. (performance deterioration)
- 3) When the pressure displayed on the self-diagnosis LED1 does not change, the low pressure sensor has a problem.
- (3) Remove the low pressure sensor from the control board to check the pressure with the self-diagnosis LED1 display.
- 1) When the pressure displayed on the self-diagnosis LED1 is between 0 and 0.098MPa [14psi], the low pressure sensor has a problem.
- 2) When the pressure displayed on self-diagnosis LED1 is approximately 1.7MPa [247psi], the control board has a problem.
 - •When the outdoor temperature is 30°C [86°F] or less, the control board has a problem. •When the outdoor temperature exceeds 30°C [86°F], go to (5).
- (4) Remove the low pressure sensor from the control board, and short-circuit between the No.2 and 3 connectors (63LS:CN202) to check the pressure with the self-diagnosis LED1.
- 1) When the pressure displayed on the self-diagnosis LED1 exceeds 1.7MPa [247psi], the low pressure sensor has a problem.
- 2) If other than 1), the control board has a problem.
- (5) Remove the high pressure sensor (63HS1) from the control board, and insert it into the connector for the low pressure sensor (63LS) to check the pressure with the self-diagnosis LED1.
- 1) When the pressure displayed on the self-diagnosis LED1 exceeds 1.7MPa [247psi], the control board has a problem.
- 2) If other than 1), the control board has a problem.


8-5-4 Low-Pressure Sensor Configuration (63LS)


The low pressure sensor consists of the circuit shown in the figure below. If DC5V is applied between the red and the black wires, voltage corresponding to the pressure between the white and the black wires will be output, and the value of this voltage will be converted by the microcomputer. The output voltage is 0.173V per 0.098MPa [14psi].

Note

The pressure sensor on the body side is designed to connect to the connector. The connector pin number on the body side is different from that on the control board side.

| | Body side | Control board side |
|------|-----------|--------------------|
| Vcc | Pin 1 | Pin 3 |
| Vout | Pin 2 | Pin 2 |
| GND | Pin 3 | Pin 1 |





8-6 Troubleshooting Solenoid Valve Problems

Check whether the output signal from the control board and the operation of the solenoid valve match.

Setting the self-diagnosis switch (SW4) as shown in the figure below causes the ON signal of each relay to be output to the LED's. Each LED shows whether the relays for the following parts are ON or OFF. LEDs light up when relays are on.

Note |

The circuits on some parts are closed when the relays are ON. Refer to the following instructions.

| SW4 (SW6-10:OFF) | | Display | | | | | | | |
|----------------------|-------|---------|------|-------|------|------|------|-----|-----|
| 311 (3113 10:311 | , | LD1 | LD2 | LD3 | LD4 | LD5 | LD6 | LD7 | LD8 |
| | Upper | 21S4a | | | | SV1a | | | |
| SW4 | | | | | | | | | |
| 1 2 3 4 5 6 7 8 9 10 | Lower | | | 21S4b | SV5b | | | | |
| | | | | | | | | | |
| | Upper | SV4a | SV4b | SV4c | | | SV4d | SV9 | |
| SW4 | | | | | | | | | |
| 1 2 3 4 5 6 7 8 9 10 | Lower | | | | | | | | |
| | | | | | | | | | |

When a valve malfunctions, check if the wrong solenoid valve coil is not attached the lead wire of the coil is not disconnected, the connector on the board is not inserted wrongly, or the wire for the connector is not disconnected.



The figure at left shows that the switches 1 through 5 are set to ON and 6 through 10 are set to OFF.

(1) In case of 21S4a, 21S4b (4-way switching valve)

About this 4-way valve

When not powered:

Conducts electricity between the oil separator outlet and heat exchanger AND the gas ball valve (BV1) and the accumulator to complete the circuit for the cooling cycle.

When powered:

The electricity runs between the oil separator and the gas ball valve, and between the heat exchanger and the accumulator. This circulation is for heating.

Check the LED display and the intake and the discharge temperature for the 4-way valve to check whether the valve has no faults and the electricity runs between where and where. Do not touch the pipe when checking the temperature, as the pipe on the oil sep arator side will be hot.

Note

Do not give an impact from outside, as the outer hull will be deformed leading to the malfunction of the inner valve.


(2) In case of SV1a (Bypass valve)


This solenoid valve opens when powered (Relay ON).


- 1) At compressor start-up, the SV1a turns on for 4 minutes, and the operation can be checked by the self-diagnosis LED display and the closing sound.
- 2) To check whether the valve is open or closed, check the change of the SV1a downstream piping temperature while the valve is being powered. Even when the valve is closed, high-temperature refrigerant flows inside the capillary next to the valve. (Therefore, temperature of the downstream piping will not be low with the valve closed.)


(3) SV4a, 4b and 4d (P72, P96 models), SV4a - 4d (P120, P144 models) (Controls heat exchanger capacity)

- 1) Depending on the conditions during Cooling-only operation, at least one of the solenoid valves among SV4a through 4d turns on. Check for proper operation on the LED and by listening for the operation sound of the solenoid valve.
- 2) During Heating-only operation, SV4a through 4d all turn on. Check for proper operation on the LED and by listening for the operation sound of the solenoid valves.
- 3) Depending on the conditions during Cooling-main or Heating-main operation, at least one of the solenoid valves among SV4a through 4d turns on. Check for proper operation on the LED and by listening for the operation sound of the solenoid valve.
- 4) The diagram on the next page shows the refrigerant flow. This diagram shows the flow of the high-temperature (high-pressure) gas refrigerant in the Cooling-only and Cooling-main modes and the flow of the low-temperature gas/liquid refrigerant in the Heating-only and Heating-main modes. Refer to the refrigerant circuit diagram. Solenoid valves turns on and off according to such factors as the capacity of the indoor units in operation and outside temperature. Check the LED. Remove the SV coil, open the lid, and check the plunger. The type of pin face wrench that is listed in the service parts list is required to perform this task.









(4) In the case of SV5b (Bypass valve)

This solenoid valve closes when energized (when the relay is on).

This valve turns off during defrost cycle, or for five minutes after the completion of the defrost cycle, or when SV9 is on turned ON and the value of 63HS1 is greater than 3.5 MPa [507psi] during Heating-only or Heating-main operation at the minimum frequency. The valve position can be determined by measuring and monitoring the changes in the pipe temperature on the downstream of SV5b while the unit is de-energized. When the valve is open, high-temperature gas refrigerant passes through the pipe. Do not attempt to check the pipe temperature by touching the pipe.

(5) In the case of SV9 (Bypass valve)

This solenoid valve opens when energized (when the relay is on)


This valve turns on when the value of 63HS1 is greater than 3.5 MPa [507psi] during Heating-only or Heating-main operation at the minimum frequency. The valve position can be determined by measuring and monitoring the changes in the pipe temperature on the downstream of SV9 while the unit is energized. When the valve is open, high-temperature gas refrigerant passes through the pipe. Do not attempt to check the pipe temperature by touching the pipe.

8 Troubleshooting Based on Observed Symptoms

8-7 Troubleshooting Outdoor Unit Fan Problems

(1) Fan motor

- •To check the revolution of the fan, check the inverter output state on the self-diagnosis LED, as the inverter on the outdoor fan controls the revolutions of the fan. The revolution of the fan is approximately 780rpm(P72 model),740rpm(P96 model), 740rpm (P120, P144 models) at full speed.
- •When starting the fan, the fan runs at full speed for 5 seconds.
- •When setting the DIP SW4 (when SW6-10 is set to OFF) as shown in the figure below, the inverter output [%] will appear. 100% indicates the full speed and 0% indicates the stopping. (Fan 2 is only on the P120, P144 models.)





- •As the revolution of the fan changes under control, at the interphase or when the indoor unit operation capacity is low, the revolution of the fan may change.
- •If the fan does not move or it vibrates, Fan board problem or fan motor problem is suspected. For details, refer to the following page(s).
- [8-10-6 Checking the Fan Motor for Ground Fault and Coil Resistance Problems](page 289)
- [8-10-7 Checking the Fan Board Error Detection Circuit at No Load](page 289)
- [8-10-8 Checking the Fan Inverter for Damage at No Load](page 289)
- [8-10-9 Checking the Fan Inverter for Damage with Load](page 290)

8-8 Troubleshooting LEV Problems

8-8-1 General Overview on LEV Operation


LEV operation

LEV are stepping-motor-driven valves that operate by receiving the pulse signals from the indoor and outdoor unit control boards.

(1) Outdoor LEV (LEV5a,b), Indoor LEV and BC controller LEV


The valve opening changes according to the number of pulses.

1) Control boards (indoor unit and BC controller) and LEV (indoor unit LEV, and BC controller LEV1 (G1 type only) and LEV3)



Note. The connector numbers on the intermediate connector and the connector on the control board differ. Check the color of the lead wire to judge the number.

2) Control boards (indoor unit and BC controller), LEV (BC controller LEV1 (applicable only to the GA1 and HA1 types), and the outdoor unit LEV (LEV5a and 5b))



8 Troubleshooting Based on Observed Symptoms

3) Pulse signal output and valve operation

| Output (phase) | | Outp | out state | |
|----------------|-----|------|-----------|-----|
| number | 1 | 2 | 3 | 4 |
| ø1 | ON | OFF | OFF | ON |
| φ 2 | ON | ON | OFF | OFF |
| φ 3 | OFF | ON | ON | OFF |
| ø4 | OFF | OFF | ON | ON |


Output pulses change in the following orders when the

Valve is closed;
$$1 \rightarrow 2 \rightarrow 3 \rightarrow 4 \rightarrow 1$$

Valve is open; $4 \rightarrow 3 \rightarrow 2 \rightarrow 1 \rightarrow 4$

- *1. When the LEV opening angle does not change, all the output phases will be off.
- *2. When the output is open phase or remains ON, the motor cannot run smoothly, and rattles and vibrates.

4) LEV valve closing and opening operation



*When the power is turned on, the valve closing signal of 2200 pulses will be output from the indoor board to LEV to fix the valve position. It must be fixed at point (A).

When the valve operates smoothly, no sound from LEV or no vibration occurs, however, when the pulses change from E to A in the chart or the valve is locked, a big sound occurs.

*Whether a sound is generated or not can be determined by holding a screwdriver against it, then placing your ear against the handle.

8-8-2 Possible Problems and Solutions


| Malfunction mode | Judgment method | Remedy | LEV |
|--|---|--|---|
| Microcomput- er driver circuit failure | Disconnect the control board connector and connect the check LED as shown in the figure below. | When the drive circuit has a problem, replace the control board. | Indoor unit, Outdoor unit, and BC control- ler |
| | LED: DC15V 20mA or more When the main power is turned on, the indoor unit circuit board outputs pulse signals to the indoor unit LEV for 10 seconds. If any of the LED remains lit or unlit, the drive circuit is faulty. | | |
| LEV mecha- nism is locked | If the LEV is locked, the drive motor runs idle, and makes a small clicking sound. When the valve makes a closing and opening sound, the valve has a problem. | Replace the LEV. | Indoor unit, Outdoor unit, and BC control- ler |
| Disconnected or short-circuit- ed LEV motor coil | Measure resistance between the coils (red - white, red - orange, red - yellow, red - blue) using a tester. They are normal if resistance is $100\Omega \pm 10\%$. | Replace the LEV coils. | Outdoor unit (LEV5a,5b) and BC controller (LEV3, LEV1(G1 type)) |
| | Measure resistance between the coils (red - white, red - orange, brown - yellow, brown - blue) using a tester. They are normal if resistance is $150\Omega \pm 3\%$. | Replace the LEV coils. | Indoor unit and BC controller (LEV1(GA1,HA 1 type)) |
| Incomple seal- ing (leak from the valve) | When checking the refrigerant leak from the indoor LEV, run the target indoor unit in the fan mode, and the other indoor units in the cooling mode. Then, check the liquid temperature (TH22) with the self-diagnosis LED. When the unit is running in the fan mode, the LEV is fully closed, and the temperature detected by the thermistor is not low. If there is a leak, however, the temperature will be low. If the temperature is extremely low compared with the inlet temperature displayed on the remote controller, the LEV is not properly sealed, however, if there is a little leak, it is not necessary to replace the LEV when there are no effects to other parts. | If there is a large amount of leakage, re- place the LEV. | Indoor unit |
| | Thermistor (liquid piping temperature detection) Linear Expansion Valve | | |
| Faulty wire connections in the connector or faulty con- tact | Check for loose pins on the connector and check the colors of the lead wires visually Disconnect the control board's connector and conduct a continuity check using a tester. | Check the continuity at the points where an error occurs. | Indoor unit, Outdoor unit, and BC control- ler |

8-8-3 Coil Removal Instructions

(1) Removal procedure of outdoor unit LEV5a,b coils

1) Components


The outdoor unit LEV consists of a coil and a valve body that can be separated from each other.



2) Removing the coil

Securely hold the LEV at the bottom (as indicated by A in the figure), and turn the coil. After checking that the stopper is removed, pull up and out the coil.


When removing the coil, hold the LEV body securely to prevent undue force from being placed on the pipe and bending the pipe.



3) Installing the coil

Securely hold the bottom of the LEV (section A in the figure), insert the coil from above, and turn the coil until the coil stopper is properly installed on the LEV body.


When removing the coil, hold the LÉV body securely to prevent undue force from being placed on the pipe and bending the pipe.



8-9 Troubleshooting Problems with Major Components on BC Controller

8-9-1 Pressure Sensor

Troubleshooting flow chart for pressure sensor



Troubleshooting Based on Observed Symptoms

Note

1) BC controller: Phenomena when the pressure sensor is connected wrongly (reverse connection of P1 and P3) to the board.

| Symptoms | | | | | | | |
|--------------|----------------------|------------|---|--------------|--|--|--|
| Cooling-only | Cooling-main Heating | | ating only | Heating main | | | |
| Normal | Non-cooling | SC16 small | Indoor heating SC small Heating indoor Thermo ON Especially noise is large. | SC16 small | Non-cooling Indoor heating SC small Heating indoor Thermo ON Especially noise is large. | SC11 large SC16 small △PHM large | |

2) Check the self-diagnosis switch (Outdoor control board SW4 and SW6).

| • | | | | | <u> </u> |
|--|--------|------------------------------------|---|--------|------------------------------------|
| Measurement data | Symbol | SW4 setting value (SW6-10: OFF) | Measurement data | Symbol | SW4 setting value (SW6-10: OFF) |
| Outdoor high pressure | 63HS1 | ON | Sub BC controller pressure (intermediate part) (Sub 5) | PS3 | ON |
| Outdoor low pressure | 63LS | ON | Sub BC controller pressure (intermediate part) (Sub 6) | PS3 | ON |
| BC controller pressure (liquid side) | PS1 | ON | Sub BC controller pressure (intermediate part) (Sub 7) | PS3 | ON |
| BC controller pressure (intermediate part) | PS3 | ON | Sub BC controller pressure (intermediate part) (Sub 8) | PS3 | ON |
| Sub BC controller pressure (intermediate part) (Sub 1) | PS3 | ON | Sub BC controller pressure (intermediate part) (Sub 9) | PS3 | ON |
| Sub BC controller pressure (intermediate part) (Sub 2) | PS3 | ON | Sub BC controller pressure (intermediate part) (Sub 10) | PS3 | ON |
| Sub BC controller pressure (intermediate part) (Sub 3) | PS3 | ON | Sub BC controller pressure (intermediate part) (Sub 11) | PS3 | ON |
| Sub BC controller pressure (intermediate part) (Sub 4) | PS3 | ON | | | |

| ON | | | | | | | | | |
|----|-----|---|---|---|---|--------|----|---|--------|
| | П | | П | П | | \Box | | | \Box |
| - | 1-1 | - | - | - | | | ΙI | | |
| ш | Ш | | | Ш | | | ഥ | | |
| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 |
| _ | | | | | | | | | |


The figure at left shows that the switches 1 through 5 are set to ON and 6 through 10 are set to OFF.

Note

- Check whether CNP1 (liquid side) connector on the BC controller control board and the connector CNP2 (intermediate part) are not disconnected or not loose.
- 4) Check the pressure value on the self-diagnosis switch (same as note 2) with the connector of the applied pressure sensor is disconnected from the board.

8-9-2 Temperature Sensor

Troubleshooting instructions for thermistor




Note

- 1) For the connectors on the board, TH11 and TH12 are connected to CN10, and TH15 and TH16 are connected to CN11. Disconnect the connector in trouble, and check the sensor of each number.
- 2)
- •Pull out the sensor connector from the I/O board, Do not pull the sensor by holding the lead wire.
- •Measure the resistance with such as a tester.
- •Compare the measured value with that shown in the table below. When the result is $\pm 10\%$, it is normal.
- 3) Check the self-diagnosis switch (Outdoor control board SW4 and SW6).

| | Measurement data | Symbol | SW4 setting value (SW6-10: OFF) |
|-------------------|-----------------------------|--------|------------------------------------|
| | Liquid inlet temperature | TH11 | ON |
| J, JA, KA | Bypass outlet temperature | TH12 | ON 1 2 3 4 5 6 7 8 9 10 |
| (Standard / main) | Bypass inlet temperature | TH15 | ON 1 2 3 4 5 6 7 8 9 10 |
| | Bypass inlet temperature | TH16 | ON 1 2 3 4 5 6 7 8 9 10 |
| | Bypass outlet temperature | TH12 | ON |
| KB (Sub 1) | Bypass inlet temperature | TH15 | ON 1 2 3 4 5 6 7 8 9 10 |
| | Bypass inlet temperature | TH16 | ON |
| | Bypass outlet temperature | TH12 | ON |
| KB (Sub 2) | Bypass inlet temperature | TH15 | ON |
| | Bypass inlet temperature | TH16 | ON |
| | Bypass outlet temperature | TH12 | ON |
| KB (Sub 3) | Bypass inlet temperature | TH15 | ON |
| | Bypass inlet temperature | TH16 | ON |




| | Measurement data | Symbol | SW4 setting value (SW6-10: OFF) |
|---------------|---------------------------|--------|------------------------------------|
| | Bypass outlet temperature | TH12 | ON 1 2 3 4 5 6 7 8 9 10 |
| KB (Sub 4) | Bypass inlet temperature | TH15 | ON 1 2 3 4 5 6 7 8 9 10 |
| | Bypass inlet temperature | TH16 | ON 1 2 3 4 5 6 7 8 9 10 |
| | Bypass outlet temperature | TH12 | ON |
| KB (Sub 5) | Bypass inlet temperature | TH15 | ON |
| | Bypass inlet temperature | TH16 | ON 1 2 3 4 5 6 7 8 9 10 |
| | Bypass outlet temperature | TH12 | ON |
| KB (Sub 6) | Bypass inlet temperature | TH15 | ON |
| | Bypass inlet temperature | TH16 | ON |
| | Bypass outlet temperature | TH12 | ON |
| KB (Sub 7) | Bypass inlet temperature | TH15 | ON |
| | Bypass inlet temperature | TH16 | ON 1 2 3 4 5 6 7 8 9 10 |
| | Bypass outlet temperature | TH12 | ON |
| KB (Sub 8) | Bypass inlet temperature | TH15 | ON |
| | Bypass inlet temperature | TH16 | ON |



| | Measurement data | Symbol | SW4 setting value (SW6-10: OFF) |
|----------------|---------------------------|--------|------------------------------------|
| | Bypass outlet temperature | TH12 | ON |
| KB (Sub 9) | Bypass inlet temperature | TH15 | ON 1 2 3 4 5 6 7 8 9 10 |
| | Bypass inlet temperature | TH16 | ON 1 2 3 4 5 6 7 8 9 10 |
| | Bypass outlet temperature | TH12 | ON 1 2 3 4 5 6 7 8 9 10 |
| KB (Sub 10) | Bypass inlet temperature | TH15 | ON 1 2 3 4 5 6 7 8 9 10 |
| | Bypass inlet temperature | TH16 | ON |
| | Bypass outlet temperature | TH12 | ON 1 2 3 4 5 6 7 8 9 10 |
| KB (Sub 11) | Bypass inlet temperature | TH15 | ON 1 2 3 4 5 6 7 8 9 10 |
| | Bypass inlet temperature | TH16 | ON |



8-9-3 Troubleshooting Flowchart for LEVs



Note

1) BC controller: Phenomena when LEV is connected wrongly (reverse connection of LEV1 and LEV3 or LEV4) to the board.

| Phenomena | | | | | |
|---|--|---------------------------------------|--|--|--|
| Cooling-only | Cooling-main | Heating only | Heating main | | |
| Non-cooling SH12 small, SC11 small SC16 small, branch pipe SC small BC controller sound | Non-cooling and non-heating SH12 small, SC11 small SC16 large, but branch pipe SC small BC controller sound△PHM large | Indoor heating SC small △PHM large | Non-cooling Indoor heating SC small △PHM large | | |

2) BC controller: Phenomena when LEV is connected wrongly (reverse connection of LEV3 and LEV4) to the board

| Phenomena | | | | | |
|--|--|--------------|---------------------------------------|--|--|
| Cooling-only | Cooling-main | Heating only | Heating main | | |
| Non-cooling SH12 large, SC11 small SC16 small, branch pipe SC small | Non-cooling SH12 large, SC11 small SC16 small, branch pipe SC small | SH12 large | Non-cooling SH12 large, SC16 small | | |

- 3) Check method of fully open state or fully closed state of LEV
 - Check LEV opening (pulse) on the self-diagnosis LED (Outdoor control board SW1).
 Full open: 3000 pulses
 - Fully closed: 41 pulses (In the case of heating-only mode, however, the pulse may become 41 or more.)
 - •When LEV is fully open, measure the temperature at the upstream and downstream pipes of LEV, and make sure that there is no temperature difference.
 - •When LEV is fully closed, check that there is no refrigerant flowing sound.

4) Refer to the chart below to judge LEV opening controlled by the values of the differential pressure and of the superheat. (BC controller LEV basic operation characteristic)

| | Part | Malfunction mode | Operation mode | Content | Standards of judgment on unit stable operation |
|-----------|------------------------|-------------------|--|--|--|
| | | Inclined to close | Heating only | Difference between high pressure (P1) and intermediate pressure (P3) is large. | 0.3 to 0.4MPa |
| | LEV1 | Inclined to open | Heating-main Cooling-main | Difference between high pressure (P1) and intermediate pressure (P3) is small. | [44 to 58psi] |
| | | | Cooling-only Cooling-main | SH12 is large. | SH12 < 20°C [36°F] |
| J, JA, KA | LEV3 | Inclined to close | Heating only Heating-main | Difference between high pressure (P1) and intermediate pressure (P3) is small. | 0.3 to 0.4MPa [44 to 58psi] |
| type | | Inclined to open | Cooling-only Cooling-main | SC16 and SH12 are small. | SC16 > 3°C [5.4°F] SH12 > 3°C [5.4°F] |
| | | | Heating only Heating-main | Difference between high pressure (P1) and intermediate pressure (P3) is large. | 0.3 to 0.4MPa [44 to 58psi] |
| | | Inclined to close | Heating-only Heating-main | Difference between high pressure (P1) and intermediate pressure (P3) is small. | 0.3 to 0.4MPa [44 to 58 psi] |
| | (JA and KA types only) | | Cooling-only | SC16 is small. | SC16 > 3°C [5.4°F] |
| | types silly) | Inclined to open | Cooling-main Heating-only Heating-main | Difference between high pressure (P1) and intermediate pressure (P3) is large. | 0.3 to 0.4MPa [44 to 58 psi] |
| KB type | LEV3 | Inclined to close | Cooling-only Cooling-main | SH12 is large. | SH12 < 20°C [36°F] |
| No type | LLVJ | Inclined to open | Cooling-only Cooling-main | SH12 is small. | SH12 > 3°C [5.4°F] |


Self-diagnosis LED

| | Measurement data | Symbol | SW4 setting value (SW6-10: OFF) |
|----------------------|---|--------|------------------------------------|
| | LEV1 opening | - | ON |
| | LEV3 opening | - | ON 1 2 3 4 5 6 7 8 9 10 |
| J, JA, KA | LEV4 opening (JA and KA only) | - | ON |
| (Standard / main) | BC controller bypass outlet superheat | SH12 | ON 1 2 3 4 5 6 7 8 9 10 |
| | BC controller intermediate part subcool | SC16 | ON 1 2 3 4 5 6 7 8 9 10 |
| | BC controller liquid-side subcool | SC11 | ON |
| KB (Sub 1) | LEV3 opening | - | ON 1 2 3 4 5 6 7 8 9 10 |
| KB (Sub 2) | LEV3 opening | - | ON 1 2 3 4 5 6 7 8 9 10 |
| KB (Sub 3) | LEV3 opening | - | ON |
| KB (Sub 4) | LEV3 opening | - | ON |
| KB (Sub 5) | LEV3 opening | - | ON |
| KB (Sub 6) | LEV3 opening | - | ON |
| KB (Sub 7) | LEV3 opening | - | ON |
| KB (Sub 8) | LEV3 opening | - | ON 1 2 3 4 5 6 7 8 9 10 |
| KB (Sub 9) | LEV3 opening | - | ON |
| KB (Sub 10) | LEV3 opening | - | ON 1 2 3 4 5 6 7 8 9 10 |
| KB (Sub 11) | LEV3 opening | - | ON 1 2 3 4 5 6 7 8 9 10 |




The figure at left shows that the switches 1 through 5 are set to ON and 6 through 10 are set to OFF.

Troubleshooting Flowchart for LEV



8-9-4 Troubleshooting Flowchart for Solenoid Valves

(1) Solenoid valve (SVA, SVB, SVC)



Check whether the BC board output signal corresponds with the solenoid valve operation correspond.

Note

1) SVA, SVB, SVC

SVA, SVB, and SVC turn on or off according to the indoor unit operation mode.

| | | | | Mode | | |
|------|-----|---------|---------|---------|---------|-----|
| | | Cooling | Heating | Stopped | Defrost | Fan |
| | SVA | ON | OFF | OFF | OFF | OFF |
| Port | SVB | OFF | ON | OFF | OFF | OFF |
| | SVC | ON | OFF | OFF | OFF | ON |

SVM1, SVM1b


SVM1 and SVM1b turn on or off according to the indoor unit operation mode.

| Operation mode | Cooling only | Cooling main | Heating only | Heating main | Defrost | Stopped |
|----------------|--------------|--|--------------|--------------|---------|---------|
| SVM1, SVM1b | ON | Pressure dif- ferential con- trol OFF or ON | OFF | OFF | ON | OFF |


Note

2) SVA, SVB, SVC

Measure the temperature at the upstream and downstream pipes ①and ②of SVA. Measure the temperature at the upstream and downstream ①pipes and ③of SVB.



8-9-5 BC Controller Transformer



| | Normal | Abnormal |
|-------------|--------------|------------------------|
| CNTR(1)-(3) | about 58 Ω. | Open-phase or shorting |
| CN03(1)-(3) | about 1.6 Ω. | Open-phase of shorting |

^{*} Before measuring the resistance, pull out the connector.

8-10 Troubleshooting Inverter Problems

8-10-1 Inverter-Related Problems and Solutions

- •Replace only the compressor if only the compressor is found to be defective. (Overcurrent will flow through the inverter if the compressor is damaged, however, the power supply is automatically cut when overcurrent is detected, protecting the inverter from damage. Make sure that the model selection switches on the outdoor unit (Dip switches SW5-3 through 5-6 on the outdoor unit control board) are set correctly. For switch settings, refer to the following page(s). [7-9-2 Error Code [7101]](page 232)
- •Replace only the fan motor if only the fan motor is found to be defective. (Overcurrent will flow through the inverter if the fan motor is damaged, however, the power supply is automatically cut when overcurrent is detected, protecting the inverter from damage.)
- •Replace the defective components if the inverter is found to be defective.
- •If both the compressor and the inverter are found to be defective, replace the defective component(s) of both devices.

(1) Inverter-related problems: Troubleshooting and remedies

- 1) Before inspecting the inside of the control box, turn off the power, keep the unit off for at least 10 minutes, and confirm that the voltage between FT-P and FT-N on INV Board has dropped to DC20V or less. (It takes about 10 minutes to discharge electricity after the power supply is turned off.)
- 2) Before beginning service work, disconnect the fan board connector (CNINV) or the connectors (CN01 and CN11) on the INV board. Before disconnecting and connecting a connector, check that the outdoor fan is not rotating and that the voltage of the main circuit capacitor has decreased to 20 V DC or less. If the outdoor fan rotates due to a strong wind, there is a **risk of an electric shock** because the main circuit capacitor will be charged. Refer to the wiring nameplate for details.
- 3) To connect wiring to TB7, check that the voltage is 20 VDC or below.
- 4) When the service work is finished, reconnect the connector (CNINV) on the fan board and the connectors (CN01 and CN11) on the INV board.
- 5) The IPM on the inverter becomes damaged if there are loose screws are connectors. If a problem occurs after replacing some of the parts, mixed up wiring is often the cause of the problem. Check for proper connection of the wiring, screws, connectors, and Faston terminals.
- 6) To avoid damage to the circuit board, do not connect or disconnect the inverter-related connectors with the main power turned on.
- 7) Faston terminals have a locking function. Make sure the terminals are securely locked in place after insertion.

Press the tab on the terminals to remove them.



- 8) When the IPM or IGBT is replaced, apply a thin layer of heat radiation grease that is supplied evenly to these parts. Wipe off any grease that may get on the wiring terminal to avoid terminal contact failure.
- 9) Faulty wiring to the compressor damages the compressor. Connect the wiring in the correct phase sequence.
- 10) When the power is turned on, the heater is energized even while the compressor is not operating. Before turning on the power, disconnect all power supply wires from the compressor terminal block, and measure the insulation resistance of the compressor. Check the compressor for a ground fault. If the insulation resistance is $1.0~\mathrm{M}\Omega$ or below, connect all power supply wires to the compressor and turn on the power to the outdoor unit. (The liquid refrigerant in the compressor will evaporate by energizing the heater.)
- 11) When tightening the screws, take care that the screws are not loose or overtightened. A contact fault resulting from screw looseness may cause the generation of heat and fire. Refer to the following page(s). [1-4 Precautions for Wiring](page 14)
- 12) The control box contains high-temperature parts. Be careful even after shutting down the power.


plate all the way in.

(2) Pivoting the control box (main box) out (P72 model)


1) Remove the plastic clips holding the check joint from the control box (See Figure A-1).

Pinch the tips of the clips protruding on the inside of the control box with one hand, and pull them down and out with the other. (See Figure A-1.)


*Attempting to pivot the control box out without first removing the check joints from the control box can damage the pipes and cause **gas leak**.




2) Screw down the supplied fixing plate to the control box, using the supplied screw. (Figure A-2) *The fixing plate must be removed after completion of all work. (See step (4).)



3) Unscrew the six screws holding the control box (Figure A-3), and slowly pivot the control box to the left. Hold the control box in place with the fixing plate as shown in Figure A-4.
*When moving the control box, use caution not to strain the wires.





Frame on the unit

Fixing plate

Hold the edge of the frame between the two bent-up sections of the fixing plate so that the control box will not move.

Viewed from the direction of the arrow

*Applying excessive force on the wires can result in wire breakage, overheating, and resultant fire.

4) When done, remove the fixing plate, and fix the control box in its original position. (Figure A-5)





Figure A-5

*Installing the front panel on the outdoor unit without removing the fixing plate can deform the panel.

*Be sure to fix the check joint in its original position. (Figure A-6)



Check joint Figure A-6

| | Error display/failure condition | Measure/inspection item |
|------|--|---|
| [1] | Inverter related errors 4250, 4255, 4256, 4220, 4225, 4226, 4230, 4240, 4260, 5301, 5305, 5306, 0403 | Implement solutions that correspond to the error codes or preliminary error codes.[7-1 Error Code and Preliminary Error Code Lists](page 165) |
| [2] | Main power breaker trip Measure the secondary voltage of the main power breaker before checking because the main power breaker may have been broken. | Refer to the following page(s). [8-10-11 Solutions for the Main No-Fuse Breaker Trip](page 291) |
| [3] | Main power earth leakage breaker trip Measure the secondary voltage of the main power earth leakage breaker before checking because the main power earth leakage breaker may have been broken. | Refer to the following page(s). [8-10-12 Solutions for the Main Earth Leakage Breaker Trip](page 291) |
| [4] | Only the compressor does not operate. | Check the inverter frequency on the LED monitor. If the frequency indicates that the units are in operation, refer to the following page(s). [8-10-5 Checking the Inverter for Damage during Compressor Operation](page 288) |
| [5] | The compressor vibrates violently at all times or makes an abnormal sound. | Refer to the following page(s). [8-10-5 Checking the Inverter for Damage during Compressor Operation](page 288) |
| [6] | Compressor rotation speed does not reach the specified speed. | <1> Check for problems with compressor current and heatsink temperature. Refer to the following page(s). [7-1-1 Inverter Protection Level Table](page 169) |
| | | <2> Check for imbalance in power supply voltage. *Approximate target: 3% or less. |
| [7] | Only the fan motor does not operate. | Check the inverter frequency on the LED monitor. If the frequency indicates that the units are in operation, refer to the following page(s). [8-10-7 Checking the Fan Board Error Detection Circuit at No Load](page 289) [8-10-8 Checking the Fan Inverter for Damage at No Load](page 289) [8-10-9 Checking the Fan Inverter for Damage with Load](page 290) |
| [8] | The fan motor shakes violently at all times or makes an abnormal sound. | Check the inverter frequency on the LED monitor. If the frequency indicates that the units are in operation, refer to the following page(s). [8-10-7 Checking the Fan Board Error Detection Circuit at No Load](page 289) [8-10-8 Checking the Fan Inverter for Damage at No Load](page 289) [8-10-9 Checking the Fan Inverter for Damage with Load](page 290) |
| [9] | Noise is picked up by the peripheral device | <1> Check that power supply wiring of the peripheral device does not run close to the power supply wiring of the outdoor unit. |
| | | <2> Check if the inverter output wiring is not running parallel to the power supply wiring and the transmission lines. |
| | | <3> Check that the shielded wire is used as the transmission line when it is required, and check that the grounding work is performed properly on the shielded wire. |
| | | <4> Meg failure for electrical system other than the inverter |
| | | <5> Attach a ferrite core to the inverter output wiring. (Contact the factory for details of the service part settings.) |
| | | <6> Provide separate power supply to the air conditioner and other electric appliances. |
| | | <7> If the problem suddenly appeared, inverter output may have had a ground fault. For details, refer to the following page(s). [8-10-5 Checking the Invert- er for Damage during Compressor Operation](page 288) |
| | | *Contact the factory for cases other than those listed above. |
| [10] | Sudden malfunction (as a result of external noise.) | <1> Check that the grounding work is performed properly. |
| | | <2>Check that the shielded wire is used as the transmission line when it is required, and check that the grounding work is performed properly on the shielded wire. |
| | | <3>Check that neither the transmission line nor the external connection wiring does not run close to another power supply system or does not run through the same conduit pipe. |
| | | |

8-10-2 Checking the Inverter Board Error Detection Circuit

| | Items to be checked | Phenomena | | Remedy |
|-----|---|-----------|--|------------------------|
| (1) | Remove power supply. | 1) | Overcurrent error Error code: 4250 Detail code: No. 101, 104, 105, 106, and 107 | Replace the INV board. |
| (2) | Disconnect the inverter output wire from the terminals of the INV board (SC-U, SC-V, SC-W). | 2) | Logic error Error code: 4220 Detail code: No. 111 | Replace the INV board. |
| (3) | Apply power supply. | 3) | ACCT sensor circuit failure Error code: 5301 Detail code: No.117 | Replace the INV board. |
| (4) | Put the outdoor unit into operation. | 4) | IPM open Error code: 5301 Detail code: No.119 | Normal |

8-10-3 Checking the Compressor for Ground Fault and Coil Resistance Problems

| Items to be checked | Phenomena | Remedy |
|--|---|--|
| Disconnect the compressor wiring, and check the compressor Meg, and coil resistance. | Compressor Meg failure Error if less than 1 Mohm. | Check that there is no liquid refrigerant in the compressor. If there is none, replace the compressor. |
| | 2) Compressor coil resistance failure Coil resistance value of 0.71 ohm (20°C [68°F]): P72 - P96 models Coil resistance value of 0.32 ohm (20°C [68°F]): P120 - P144 models | Replace the compressor. |

8-10-4 Checking the Inverter for Damage at No-Load

| | Items to be checked | | Phenomena | Remedy | |
|-----|--|----|--|--|--|
| (1) | Remove power supply. | 1) | Inverter-related problems are detected. | Connect the short-circuit connector to CN6, and go to section 8-10-2. | |
| (2) | Disconnect the inverter output wire from the terminals of the INV board (SC-U, SC-V, SC-W). | 2) | Inverter voltage is not output at the terminals (SC-U, SC-V, and SC-W) | Replace the INV board. | |
| (3) | Disconnect the short-circuit connector from CN6 on the INV board. | 3) | There is an voltage imbalance between the wires. Greater than 5% imbalance or 5V | Replace the INV board. | |
| (4) | Apply power supply. | | | | |
| (5) | Put the outdoor unit into operation. Check the inverter output voltage after the inverter output frequency has stabilized. | 4) | There is no voltage imbalance between the wires. | Normal *Reconnect the short-circuit connector to CN6 after checking the voltage. | |

8-10-5 Checking the Inverter for Damage during Compressor Operation

| Items to be checked | | Phenomena | | Remedy |
|---|----|---|--------------------------------|---|
| Put the outdoor unit into operation. Check the inverter output voltage af- | 1) | Overcurrent-related problems occur immediately after compressor startup. | a. | Check items 8-10-2 through 8-10-4 for problems. |
| ter the inverter output frequency has stabilized. | | Error code : 4250 Detail code : 101, 102, 106, 107 | b. | Check that high and low pressures are balanced. |
| | | | c. | Check that no liquid refrigerant is present in the compressor. →Go to "d." when the problem persists after compressor start-up was repeated several times. If normal operation is restored, check the belt heater for problems. |
| | | | d. | Check that there is a pressure difference between high and low pressures after compressor startup. Check the high pressure with LED monitor for changes. Replace the compressor if there is no pressure difference. (the compressor may be locked.) |
| | 2) | There is a voltage imbalance between the wires after the inverter output voltage is stabilized. Greater than the larger of the following values: imbalance of 5% or 5V | vol Ch the →V refi | place the INV board if there is a tage imbalance. eck the belt heater for problems if re is no voltage imbalance. When the error occurred, liquid igerant may have been present he compressor. |

8-10-6 Checking the Fan Motor for Ground Fault and Coil Resistance Problems

| Items to be checked | | Phenomena | Remedy |
|--|---|--|-------------------|
| Remove fan motor winding. Check insulation resistance and coil resistance. | , | Fan motor insulation failure. If < 1 MΩ, Defect. | Change fan motor. |
| tance. | ′ | Fan motor wire failure. Normal coil resistance is a few ohms. (Changes with temperature) | Change fan motor. |

8-10-7 Checking the Fan Board Error Detection Circuit at No Load

| | Items to be checked | | Phenomena | Remedy |
|------------|--|----|--|---|
| (1) | Turn off breaker. *Turn power off without fail. | 1) | Electrical current over load error. Check code: 4255, 4256 Detail code: 101, 104 | Change fan board. |
| (2) | Remove fan board CNINV and CNSNR connectors. | 2) | Logic error Check code: 4225, 4256 Detail code:111 | Change fan board. |
| (3) (4) | Turn on breaker. Operate unit. | 3) | Position error on start up Check code: 5305, 5306 Detail code: 132 | Normal *After checking, return connector CNINV & CNSNR. |

8-10-8 Checking the Fan Inverter for Damage at No Load

| | Items to be checked | | Phenomena | Remedy |
|-----|--|----|---|--|
| (1) | Turn off breaker. *Turn power off without fail. | 1) | Within 30 seconds from the start of operation, an error other than a position error (5305, 5306) (detail code 132) is detected. | Change fan board. |
| (2) | Disconnect the connector CN-INV from the fan board. | 2) | Less than 5V unbalance in the wiring. | Change fan board. |
| (3) | Set fan board switch SW1-1 to ON. | 3) | No unbalanced voltage in the wiring. After 30 second, detail code 132 is | Normal *After checking, return SW1&CN- |
| (4) | Turn on breaker. | | produced and the system stops. | INV. |
| (5) | Operate unit. After about 30 seconds under no load with constant voltage output, the code below will be displayed indicating a position error (5305, 5306). Detail code: 132 Also, running with no load produces constant voltage of about 160V. | | | |

^{*}Notes on the P72 model: Switch off the power (as shown in step (1)), pivot the control box out to access the wires behind them, and then measure the voltages across the wires. When done, return the control box to its original position.

8-10-9 Checking the Fan Inverter for Damage with Load

| | Items to be checked | | Phenomena | Remedy |
|-----|---------------------|----|---|---|
| (1) | Turn off breaker. | 1) | After operation, electrical overload error or position detection error and unit stops within 10 seconds. Check code: 4255, 4256, 5305, 5306 Detail code: 101, 132 | Check for fan motor lock. →If locked, change for fan motor. If the same error is still present after changing fan motor, change Fan board. →If not locked, refer to 3) & 4). |
| (2) | Turn on breaker. | 2) | RPM error before stat-up Check code: 5305, 5306 Detail code: 134 | Change Fan board if the same error occurs after restart. |
| (3) | Operate unit. | 3) | Electrical current overload error during operation Check code: 4255, 4256 Detail code: 101 | a. Check for gusts or windy conditions. b. Go to 8-10-6 if not windy. c. After checking 8-10-6, and there is no problem, change Fan board. d. If replacing Fan board doesn't resolve issue, change fan motor. |
| | | 4) | Sensor error during operation Check code: 5305, 5306 Detail code: 132, 133 | a. Check for gusts or windy conditions. b. If no issues with wind, but the error is still present, change Fan board. c. Change fan motor if Fan board change doesn't resolve issue. |
| | | 5) | Voltage overload error Check code: 4225, 4226 Detail code: 109 | a. Check for gusts or windy conditions. b. Change Fan board if it is not windy. |
| | | 6) | Load short circuit Check code: 4255, 4256. Detail code: 105 | a. Check 8-10-7 and 8-10-8. If no problem, then check wiring forshort circuit. b. If there is no problem with item a. above, change fan motor. c. If same error after motor change, change Fan board. |
| | | 7) | After RPM has stabilized, voltage unbalance of 5%, or 5V. | a. If voltage is unbalanced, go to 8-10-6 b. After checking 8-10-6, and there is no problem, change Fan board. c. If replacing Fan board doesn't resolve issue, change fan motor. |

^{*}Notes on the P72 model: Switch off the power (as shown in step (1)), pivot the control box out to access the wires behind them, and then measure the voltages across the wires. When done, return the control box to its original position.

8-10-10 Checking the Installation Conditions

| | Items to be checked | Phenomena | Remedy |
|-----|---|---|---------------------------------------|
| (1) | Check refrigerant charge. | Overcharge of refrigerant | Return to correct refrigerant charge. |
| (2) | Check outdoor unit branch installation. | The branch approach <500 mm. | Make branch approach >500mm |
| | staliation. | Is the branch angle < ±15° to horizontal? | Make branch angle < ±15° |

8-10-11 Solutions for the Main No-Fuse Breaker Trip

| | Items to be checked | | Phenomena | Remedy |
|-----|--|----|--|---|
| [1] | Check the breaker capacity. | | Use of a non-specified breaker | Replace it with a specified breaker. |
| [2] | Perform Meg check between the terminals on the power terminal block TB1. | | Zero to several ohm, or Meg failure | Check each part and wiring. Refer to the following page(s).[8-10-13 Simple Check on Inverter Circuit Compo- |
| [3] | Turn on the power again and | 1) | Main power breaker trip | nents](page 292) *IGBT module |
| | check again. | 2) | No remote control display | Rush current protection resistor Electromagnetic relay DC reactor |
| [4] | Turn on the outdoor unit and check that it operates normally. | 1) | Operates normally without tripping the main breaker. | a) The wiring may have been short-circuited. Search for the wire that short-circuited |
| | | 2) | Main power breaker trip | ed, and repair it. b) If item a) above is not the cause of the problem, refer to 8-10-2 - 8-10-10 |

8-10-12 Solutions for the Main Earth Leakage Breaker Trip

| | Items to be checked | Phenomena | Remedy |
|-----|---|--|---|
| [1] | Check the earth leakage breaker capacity and the sensitivity current. | Use of a non-specified earth leakage breaker | Replace with a regulation earth leakage breaker. |
| [2] | Check the resistance at the power supply terminal block with a megger. | Failure resistance value | Check each part and wiring. Refer to the following page(s).[8-10-13 Simple Check on Inverter Circuit Components](page 292) •IGBT module •Rush current protection resistor •Electromagnetic relay •DC reactor |
| [3] | Disconnect the compressor wirings and check the resistance of the compressor with a megger. | Failure compressor if the insulating resistance value is not in specified range. Failure when the insulating resistance value is 1 M Ω or less. | Check that there is no liquid refrigerant in the compressor. If there is none, replace the compressor. |
| [4] | Disconnect the fan motor wirings and check the resistance of the fan motor with a megger. | Failure fan motor if the insulating resistance value is not in specified range. Failure when the insulating resistance value is 1 M Ω or less. | Replace the fan motor. |

Note

The insulation resistance could go down to close to 1 $M\Omega$ after installation or when the power is kept off for an extended period of time because of the accumulation of refrigerant in the compressor. If the earth leakage breaker is triggered, please use the following procedure to take care of this.

- •Disconnect the wires from the compressor's terminal block.
- •If the resistance is less than 1 M Ω , switch on the power for the outdoor unit with the wires still disconnected.
- •Leave the power on for at least 12 hours.
- •Check that the resistance has recovered to 1 $M\Omega$ or greater.

Earth leakage current measurement method

- •For easy on-site measurement of the earth leakage current, enable the filter with a measurement instrument that has filter functions as below, clamp all the power supply wires, and measure.
- Recommended measurement instrument: CLAMP ON LEAK HITESTER 3283 made by HIOKI E.E. CORPORATION
- When measuring one device alone, measure near the device's power supply terminal block.

8-10-13 Simple Check on Inverter Circuit Components

Note

Before inspecting the inside of the control box, turn off the power, keep the unit off for at least 10 minutes, and confirm that the voltage between FT-P and FT-N on INV Board has dropped to DC20V or less.

| Part name | Judgment method | | | | | | |
|---|--|--|--|--|--|--|--|
| IGBT module | Refer to the following page(s). [8-10-14 Troubleshooting Problems with IGBT Module](page 292) | | | | | | |
| Rush current protection resistor R1, R5 | Measure the resistance between terminals R1 and R5: 22 Ω±10% | | | | | | |
| Electromagnetic relay 52C | This electromagnetic relay is rated at 230VAC and is driven by a coil. Check the resistance between terminals Check point Checking criteria(W) Coil Between Terminals A1 and A2 Not to be short-circuited Contact Between Terminals 1 and 2 Between Terminals 5 and 6 Contact Between Terminals 5 and 6 | | | | | | |
| | | | | | | | |
| DC reactor DCL | Measure the resistance between terminals: 1Ω or lower (almost 0 Ω) Measure the resistance between terminals and the chassis: ∞ | | | | | | |

8-10-14 Troubleshooting Problems with IGBT Module

Measure the resistances between each pair of terminals on the IGBT with a tester, and use the results for troubleshooting. The terminals on the INV board are used for the measurement.

1) Notes on measurement

- •Check the polarity before measuring. (On the tester, black normally indicates plus.)
- •Check that the resistance is not open (∞ Ω) or not shorted (to 0 Ω).
- •The values are for reference, and the margin of errors is allowed.
- •The result that is more than double or half of the result that is measured at the same measurement point is not allowed.
- •Disconnect all the wiring connected the INV board, and make the measurement.

2) Tester restriction

- •Use the tester whose internal electrical power source is 1.5V or greater
- •Use the dry-battery-powered tester.

Note

(The accurate diode-specific resistance cannot be measured with the button-battery-powered card tester, as the applied voltage is low.)


•Use a low-range tester if possible. A more accurate resistance can be measured.

Judgment value (reference)

| | | | | Black (+) | | |
|---------|--------|--------|-----------|-----------|-----------|-----------|
| | | SC-P10 | SC-N | SC-L1 | SC-L2 | SC-L3 |
| | SC-P10 | - | - | 5 - 200 Ω | 5 - 200 Ω | 5 - 200 Ω |
| | SC-N | - | - | ∞ | ∞ | ∞ |
| Red (-) | SC-L1 | ∞ | 5 - 200 Ω | - | - | - |
| | SC-L2 | ∞ | 5 - 200 Ω | - | - | - |
| | SC-L3 | ∞ | 5 - 200 Ω | - | - | - |

| | | | | Black (+) | | |
|---------|-------|-------|-----------|-----------|-----------|-----------|
| | | SC-P2 | SC-N | SC-U | SC-V | SC-W |
| | SC-P2 | - | - | 5 - 200 Ω | 5 - 200 Ω | 5 - 200 Ω |
| | SC-N | - | - | ∞ | ∞ | ∞ |
| Red (-) | SC-U | ∞ | 5 - 200 Ω | - | - | - |
| | SC-V | ∞ | 5 - 200 Ω | - | - | - |
| | SC-W | ∞ | 5 - 200 Ω | - | - | - |


INV board external diagram



8-11 Control Circuit

8-11-1 Control Power Supply Function Block


1) PURY-P72, P96ZKMU



^{*} MA remote controllers and ME remote controllers cannot be used together.

(Both the ME and MA remote controller can be connected to a system with a system controller.)


2) PURY-P120, P144ZKMU



^{*1} MA remote controllers and ME remote controllers cannot be used together.

(Both the ME and MA remote controller can be connected to a system with a system controller.)

8-11-2 Troubleshooting Problems with Outdoor Unit Transmission Power Supply Circuit



8-12 Measures for Refrigerant Leakage

- 1. Leak spot: In the case of extension pipe for indoor unit (Cooling season)
- 1) Mount a pressure gauge on the service check joint (CJ2) on the low-pressure side.
- 2) Stop all the indoor units, and close the high-pressure side refrigerant service valve (BV2) on the outdoor unit while the compressor is being stopped.
- Stop all the indoor units; turn on SW4 (912) on the outdoor unit control board while the compressor is being stopped. (Pump down mode will start, and all the indoor units will run in cooling test run mode.)
- 4) In the pump down mode (SW4 (912)), all the indoor units and compressors will automatically stop when the low pressure (63LS) reaches 0.383MPa [55psi] or less or 15 minutes have passed after the pump mode started. Stop all the indoor units and compressors when the pressure indicated by the pressure gauge, which is on the check joint (CJ2) for low-pressure service, reaches 0.383MPa [55psi] or 20 minutes pass after the pump down operation is started.
- 5) Close the service ball valve (BV1) on the low-pressure pipe on the outdoor unit.
- 6) Collect the refrigerant that remains in the extended pipe for the indoor unit. Do not discharge refrigerant into the atmosphere when it is collected.
- 7) Repair the leak.
- 8) After repairing the leak, vacuum*1the extension pipe and the indoor unit.
- 9) To adjust refrigerant amount, open the ball valves (BV1 and BV2) inside the outdoor unit, and turn off SW4 (912).
- 2. Leak spot: In the case of outdoor unit (Cooling season)
- (1) Run all the indoor units in the cooling test run mode.
- 1) To run the indoor unit in test run mode, turn SW4 (769) on the outdoor unit control board to ON.
- Change the setting of the remote controller for all the indoor units to the cooling mode.
- 3) Check that all the indoor units are performing a cooling operation.
- (2) Check the SC16 value.

(This value can be displayed on the LED by setting the self-diagnosis switch SW4 (SW6-10: OFF) on the outdoor unit control board.)

- 1) When SC16 is 10°C [18°F] or above: Go to the next item (3).
- 2) When the SC16 value is below 10°C [18°F]: After the compressor has stopped, extract the refrigerant in the system, repair the leak, evacuate the air from the system *1, and charge the system with refrigerant. (If the leak is in the outdoor unit, follow the same procedure as listed under "heating season.")

SC16 self-diagnosis switch





The figure at left shows that the switches 1 through 5 are set to ON and 6 through 10 are set to OFF.

- (3) Stop all the indoor units, and stop the compressor.
- 1) To stop all the indoor units and the compressors, turn SW4 (769) on the outdoor control board from ON to OFF.
- 2) Check that all the indoor units are being stopped.
- (4) Close the ball valves (BV1 and BV2).
- (5) Collect the refrigerant that remains inside the outdoor unit. Do not discharge refrigerant into air into the atmosphere when it is collected.
- (6) Repair the leak.
- (7) After repairing the leak, replace the dryer with the new one, and perform evacuation*1 inside the outdoor unit.
- (8) To adjust refrigerant amount, open the ball valves (BV1 and BV2) inside the outdoor unit.

3. Leak spot: In the case of extension pipe for indoor unit (Heating season)

- (1) Run all the indoor units in heating test run mode.
- 1) To run the indoor unit in test run mode, set SW4 (769) on the outdoor unit control board to ON.
- 2) Change the setting of the remote controller for all the indoor units to the heating mode.
- 3) Check that all the indoor units are performing a heating operation.

(2) Stop all the indoor units, and stop the compressor.

- 1) To stop all the indoor units and the compressors, turn SW4 (769) on the outdoor control board from ON to OFF.
- 2) Check that all the indoor units are stopped.
- (3) Close the ball valves (BV1 and BV2).
- (4) Collect the refrigerant that remains inside the indoor unit. Do not discharge refrigerant into air into the atmosphere when it is collected.
- (5) Repair the leak.
- (6) After repairing the leak, perform evacuation of the extension pipe*1 for the indoor unit, and open the ball valves (BV1 and BV2) to adjust refrigerant.


4. Leak spot: In the case of outdoor unit (Heating season)

- 1) Collect the refrigerant in the entire system (outdoor unit, extended pipe and indoor unit). Do not discharge refrigerant into the atmosphere when it is collected.
- 2) Repair the leak.
- 3) Repair the leak, and evacuate the air from the entire system *1. Then, calculate the proper amount of refrigerant to be added (outdoor unit + extension pipe + indoor unit), and charge the system with that amount. For details, refer to the following page(s). [6-3-3 The Amount of Refrigerant to Be Added](page 157)

8-13 Compressor Replacement Instructions


[Compressor replacement procedures]

Follow the procedures below (Steps 1 through 6) to remove the compressor components and replace the compressor. Reassemble them in the reverse order after replacing the compressor.




1. Remove both the top and bottom service panels (front panels).


2. Remove the control box and the compressor cover (front).



3. Remove the wires that are secured to the frame, and remove the frame.








5. Remove the compressor wires and the compressor cover (right).

*Remove the thermistor (TH15) and Crankcase heater (CH11) if it is installed on the compressor.



- 6. Place protective materials on the insulation lining of the compressor cover and on the sealing material on the compressor suction pipe to protect them from the torch flame, debraze the pipe, and replace the compressor.
- 6. Place protective materials on the insulation lining of the compressor fixing bracket before the compressor cover and on the sealing material compressor needs replacing.

8-14 Solenoid Valve Block and Check Valve Replacement Instructions

R410A CITY MULTI R2 Solenoid valve block ASSY (SV4a, SV4b, SV4d) and check valve (CV4a, CV6a, CV8a, CV9a) replacement instructions

* Following instructions show procedures for replacing service parts for Solenoid valve block ASSY (SV4a, SV4b, SV4d) and check valves (CV4a, CV6a, CV8a, CV9a). Replace them properly according to the procedures.

1. Applicable models

PURY-P72, P96ZKMU

2. Parts to be serviced, Set-contents

Following instructions are applicable to the parts 1-4 in the table below.

| No. | Parts to be serviced | Required items for replacing | |
|------|--|--|-----|
| INO. | Faits to be serviced | Item | Qty |
| | | Solenoid valve block service parts set | 1 |
| 4 | Solenoid valve block ASSY | [Set-contents] | |
| ' | (SV4a, SV4b, SV4d) | Replacement instructions | 1 |
| | | Solenoid valve block ASSY | 1 |
| | Ob I I (O) (4 O) (9 -) | Service parts replacement instructions set | 1 |
| 3 | Check valve (CV4a, CV8a) | [Set-contents] | |
| 3 | Check valve (CV6a) Check valve (CV9a) | Replacement instructions | 1 |
| * | Clieck valve (CV9a) | Check valve | 1 |

3. Procedures


- * Precautions for starting replacement
- · Make sure that the main power is switched off.
- · Make sure that no refrigerant is in the outdoor unit.

Remove each part according to procedures 1)-3) in the figure above right before replacing the service parts.

Mount the removed parts back in place in a reversed procedure of 1)-3) in the figure above right after replacing the service parts.

(1) Solenoid valve block ASSY (SV4a, SV4b, SV4d) replacement procedures


- Removing Solenoid valve block ASSY
- ① Remove the solenoid valve block coil cover, solenoid valve coil, and peripheral cables.
- ② Remove the screw (M5) that fixes the supporting plate for solenoid valve block and the unit base.
- ③ Debraze parts A through F (total 6 places).
- ④ Do not damage heat exchanger fins and peripheral piping devices when removing the Solenoid valve block ASSY.
- (5) Remove the screw (M5) that fixes the solenoid valve block and the supporting plate for solenoid valve block.
- Installing Solenoid valve block ASSY
- (M5).
- ⑦ Mount the Solenoid valve block ASSY replacement to the unit with care not to damage heat exchanger fins and peripheral piping devices. Fix the supporting plate for solenoid valve block and the unit base with the fixing screw (M5).
- ® Braze parts A through F (total 6 places).
- Mount the solenoid valve block coil cover, solenoid valve coil, and peripheral cables back in place.
- * Precautions for replacing Solenoid valve block ASSY
- Be sure to perform no-oxidation brazing when brazing.
- Place a wet towel on the solenoid valve block when heating pipes to keep the temperature of the solenoid valve block from exceeding 120°C.
- · After brazing, check the condition around the brazing. After confirming no leakage, evacuate the air inside.
- Perform brazing with care of the flame direction so that it does not burn cables and plates etc. in the unit.
- Remove the brazing part protecting heat exchanger fins from burning, and replace the service parts.



^{*} Refer to the next page for check valve (CV4a, CV6a, CV8a, CV9a) replacement procedures.


(2) Check valve (CV4a, CV6a, CV8a, CV9a) replacement procedures

- ① Remove the Solenoid valve block ASSY following "(1) Solenoid valve block ASSY (SV4a, SV4b, SV4d) replacement procedures" on the previous page.
- 2) Debraze parts G through J (total 4 places), and remove the Check valve ASSY.
- ③ Replace the check valves (CV4a, CV6a, CV8a, CV9a) to be serviced with the Check valve ASSY being removed from the unit. After replacing the check valves (CV8a, CV9a), braze the pipes as they were according to the angle of the pipes in the figure below right (Figure as viewed from K).
- Mount the Solenoid valve block ASSY, coil cover, and peripheral cables back in place according to "(1) Solenoid valve block ASSY (SV4a, SV4b, SV4d) replacement procedures" on the previous page.



Part A (Refer to the next page.)

- * Precautions for replacing check valves
 - Be sure to perform no-oxidation brazing when brazing.
 - Place a wet towel on the check valves when heating pipes to keep the temperature of the check valves from exceeding 120°C.
 - After brazing, check the condition around the brazing. After confirming no leakage, evacuate the air inside.
 - Perform brazing with care of the flame direction so that it does not burn cables and plates etc. in the unit.
 - Remove the brazing part protecting heat exchanger fins from burning, and replace the service parts.



R410A CITY MULTI R2 Solenoid valve block ASSY (SV4a, SV4b, SV4d) and check valve (CV4a, CV6a, CV8a) replacement instructions

* Following instructions show procedures for replacing service parts for Solenoid valve block ASSY (SV4a, SV4b, SV4d) and check valves (CV4a, CV6a, CV8a). Replace them properly according to the procedures.

1. Applicable models

PURY-P120, P144ZKMU

2. Parts to be serviced, Set-contents

Following instructions are applicable to the parts 1-4 in the table below.

| No. | Parts to be serviced | Required items for replacing | |
|------|--|--|-----|
| INO. | Faits to be serviced | Item | Qty |
| | | Solenoid valve block service parts set | 1 |
| 4 | Solenoid valve block ASSY | [Set-contents] | |
| ' | (SV4a, SV4b, SV4d) | Replacement instructions | 1 |
| | | Solenoid valve block ASSY | 1 |
| | Ob In the (O) (4 -) | Service parts replacement instructions set | 1 |
| 3 | Check valve (CV4a) Check valve (CV6a) | [Set-contents] | |
| 3 | Check valve (CV6a) | Replacement instructions | 1 |
| 4 | Clieck valve (CVoa) | Check valve | 1 |

3. Procedures


- * Precautions for starting replacement
- · Make sure that the main power is switched off.
- . Make sure that no refrigerant is in the outdoor unit.

Remove each part according to procedures 1)-3) in the figure above right before replacing the service parts.

Mount the removed parts back in place in a reversed procedure of 1)-3) in the figure above right after replacing the service parts.

(1) Solenoid valve block ASSY (SV4a, SV4b, SV4d) replacement procedures


- Removing Solenoid valve block ASSY
- ① Remove the solenoid valve block coil cover, solenoid valve coil, and peripheral cables.
- ② Remove the screw (M5) that fixes the supporting plate for solenoid valve block and the unit base.
- ③ Debraze parts A through E (total 5 places).
- ④ Do not damage heat exchanger fins and peripheral piping devices when removing the Solenoid valve block ASSY.
- (5) Remove the screw (M5) that fixes the solenoid valve block and the supporting plate for solenoid valve block.
- Installing Solenoid valve block ASSY
- 6 Remove the pipe from the brazed part F.
- (7) Fix the Solenoid valve block ASSY and the supporting plate with the fixing screw (M5).
- ® Mount the Solenoid valve block ASSY replacement to the unit with care not to damage heat exchanger fins and peripheral piping devices. Fix the supporting plate for solenoid valve block and the unit base with the fixing screw (M5).
- Braze parts A through E (total 5 places).
- Mount the solenoid valve block coil cover, solenoid valve coil, and peripheral cables back in place.
- * Precautions for replacing Solenoid valve block ASSY
- Be sure to perform no-oxidation brazing when brazing.
- Place a wet towel on the solenoid valve block when heating pipes to keep the temperature of the solenoid valve block from exceeding 120°C.
- After brazing, check the condition around the brazing. After confirming no leakage, evacuate the air inside.
- Perform brazing with care of the flame direction so that it does not burn cables and plates etc. in the unit.
- Remove the brazing part protecting heat exchanger fins from burning, and replace the service parts.




* Refer to the next page for check valve (CV4a, CV6a, CV8a) replacement procedures.

(2) Check valve (CV4a, CV6a, CV8a) replacement procedures

- ① Remove the Solenoid valve block ASSY following "(1) Solenoid valve block ASSY (SV4a, SV4b, SV4d) replacement procedures" on the previous page.
- 2 Debraze parts G through J (total 4 places), and remove the Check valve ASSY.
- ③ Replace the check valves (CV4a, CV6a, CV8a) to be serviced with the Check valve ASSY being removed from the unit.
- 4 Mount the Solenoid valve block ASSY, coil cover, and peripheral cables back in place according to "(1) Solenoid valve block ASSY (SV4a, SV4b, SV4d) replacement procedures" on the previous page.



- * Precautions for replacing check valves
 - Be sure to perform no-oxidation brazing when brazing.
- Place a wet towel on the check valves when heating pipes to keep the temperature of the check valves from exceeding 120°C.
- After brazing, check the condition around the brazing. After confirming no leakage, evacuate the air inside.
- Perform brazing with care of the flame direction so that it does not burn cables and plates etc. in the unit.
- · Remove the brazing part protecting heat exchanger fins from burning, and replace the service parts.




8-15 BC Controller Maintenance Instructions

1. Service panel

*Special care must be taken when replacing heavy parts.

Work procedure Explanatory figure <KB type, J type, and 4-, 6-, 8-branch types> 1) Remove the control box by unscrewing the four fixing screws. (Figure 1) 2) Unscrew the four service panel fixing screws. (Figure 2) Control Box 3) Remove the top panel by unscrewing the nine fixing Ceiling panel screws. (Figure 2) (Figure 1) <For J-type, 12- and 16-branch types, JA-type, and KA-type> 1) Remove the service panel (1) by unscrewing the two fixing screws. (Figure 3) 2) Remove the control box by unscrewing the four fixing Service panel screws. (Figure 3) Remove the top panel by unscrewing the 10 fixing (Figure 2) screws. (Figure 4) 4) Remove the service panel (2) by unscrewing the two fixing screws. (Figure 4) Control Box (Figure 3) Service panel (1) Ceiling panel Service panel (2) (Figure 4)

2. Control box



3. Removing the drain pan

Work procedure


- Remove the fixing screw on the long side of the bottom panel.
 - (Four places encircled by circles in Figure 1)
- 2) To prevent the bottom panel from falling, of the four screws indicated with triangles in Figure 1, only loosen (but not remove) the two screws that are diagonally located or on the opposite ends of the long side of the panel (either (1) and (3), (2) and (4), (1) and (4), or (2) and (3)). Remove the two remaining screws.
- 3) As shown in the enlarged view of Figure 1, the fastening screw hole on the short side looks like two circles in different shape joined together (double-snowman shape). Slide the bottom panel in the direction of the arrow, and remove it in the downward direction. (Figure 2)
- 4) When removing the drain pan, hold the protruded area of the panel or the socket and pull it straight down, using caution not to let it come into contact with the sheet metal. (Figure 3) If the drain pan comes into contact with the sheet metal, the drain pan may be scraped, leading to water leakage.

Installing the bottom panel

- Of the four screws indicated with triangles in Figure 1, partially tighten the two screws that are diagonally located ed (either (1) and (3), or (2) and (4)).
- 2) Thread the screw into the double-snowman shaped hole, move the panel in the opposite direction as when it was removed in step 3) above, set the screw into the smaller circle, and tighten the screw to hold the panel in place.
- 3) Tighten the remaining screws.

Note

Do not stay directly underneath the unit when working with the bottom plate. Remove the drain piping to remove the drain pan. Check that no water has accumulated in the drain pan.



4. Thermistor (liquid pipe/gas pipe temperature detection)

*Special care must be taken when replacing heavy parts.

Work procedure Explanatory figure (1) Remove the service panel. 1) See the right figure and the section [3-5 External Appearance and Refrigerant Circuit Components of BC Controller] for information on TH11, TH12, TH15, and TH16. TH16 (2) Remove the lead wire of the piping sensor from the control board. 1) TH11.TH12 (CN10) 2) TH15,TH16 (CN11) TH12 (3) Pull out the temperature sensor from the temperature sensor housing, and replace the temperature **TH11** sensor with the new one. TH15 (4) Connect the lead wire of the temperature sensor securely on the control board. CMB-P1016NU-KA1/2

leak, and follow the instructions above if required.

5. Pressure sensor

Work procedure Explanatory figure (1) Remove the service panel. 1) See the right figure and the section [3-5 External Appearance and Refrigerant Circuit Components of BC Controller] for information on pressure sensors PS1 and PS3. (2) Remove the pressure sensor connector in trouble from the control board, and insulate the connector. 1) Liquid-side pressure sensor (CNP1) PS1 2) Intermediate-part pressure sensor (CNP3) (3) Attach a new pressure sensor to the place which is shown in the figure, and insert the connector to the CMB-P1016NU-KA1/2 control board. Note When gas leaks from the pressure sensor, repair the

6. LEV

| Work procedure | Explanatory figure |
|---|-----------------------------------|
| (1) Remove the service panel. (2) Replace the LEV in trouble. Note Secure enough service space in the ceiling for welding operation, and conduct the work carefully. If required, dismount the unit from the ceiling, and conduct the work. | LEV4 LEV1 LEV3 CMB-P1016NU-KA1/2 |

7. Solenoid valve

*Special care must be taken when replacing heavy parts.

| Work procedure | Explanatory figure |
|--|-----------------------------------|
| (1) Remove the service panel. (2) Remove the connector of the solenoid valve in trouble. (3) Remove the solenoid valve coil. 1) The coils on the solenoid valves SVA, SVB, SVC, SVM1, and SVM1b can be serviced through the inspection door. SVC is accessible for replacement by removing the drain pan. | Solenoid valve CMB-P1016NU-KA1/2 |

8-16 Troubleshooting Problems Using the LED Status Indicators on the Outdoor Unit

If the LED error display appear as follows while all the SW4 switches and SW6-10 are set to OFF, check the items under the applicable item numbers below.

- 1. Error code appears on the LED display.
 - Refer to the following page(s). [7-1 Error Code and Preliminary Error Code Lists](page 165)
- 2. LED is blank.
 - Take the following troubleshooting steps.
- (1) Refer to the section on troubleshooting the transmission power supply circuit, if the voltage across pins 1 through 3 of CNDC on the control panel is outside the range between 220 VDC and 380 VDC. [8-11-2 Troubleshooting Problems with Outdoor Unit Transmission Power Supply Circuit](page 296)
- (2) If the LED error display becomes lit when the power is turned on with all the connectors on the control board except CNDC disconnected, there is a problem with the wiring to those connectors or with the connectors themselves.
- (3) If nothing appears on the display under item (2) above AND the voltage between pins 1 and 3 of CNDC is within the range between 220 VDC and 380 VDC, control board failure is suspected.
- 3. Only the software version appears on the LED display.
- (1) Only the software version appears while the transmission cables to TB3 and TB7 are disconnected.
- 1) Wiring failure between the control board and the transmission line power supply board.(CN62, CNPS, CNIT, CNS2, CN102)
- 2) If item 1) checks out OK, the transmission line power supply board failure is suspected.
- 3) If items 1) and 2) check out OK, control board failure is suspected.
- (2) If the LED shows the same display as the initial display upon disconnection of transmission lines (TB3, TB7), there is a problem with the transmission lines or with the connected devices. [9-1-2 Initial LED Display](page 316)

Chapter 9 LED Status Indicators on the Outdoor Unit Circuit Board


| 9-1 | LED Status Indicators | 315 |
|-------|------------------------------|-----|
| | How to Read the LED | |
| 9-1-2 | Initial LED Display | 316 |
| 9-1-3 | Clock Memory Function | 317 |
| 9-2 | I ED Status Indicators Table | 318 |


HWE23040 - 314 - GB

9-1 LED Status Indicators

9-1-1 How to Read the LED

By setting the DIP SW 4-1 through 4-10 (Set SW6-10 to OFF.)(Switch number 10 is represented by 0), the operating condition of the unit can be monitored on the service monitor. (Refer to the table on the following pages for DIP SW settings.) The service monitor uses 4-digit 7-segment LED to display numerical values and other types of information.





- •SW4-10 is set to "0" on the LED Status Indicators Table.
- •In the example above, 1 through 9 are set to OFF, and 10 is set to ON.

Pressure and temperature are examples of numerical values, and operating conditions and the on-off status of solenoid valve are examples of flag display.

1) Display of numerical values

Example: When the pressure data sensor reads 18.8kg/cm² (Item No. 58)


- •The unit of pressure is in kg/cm²
- Use the following conversion formula to convert the displayed value into a value in SI unit.

Value in SI unit (MPa) = Displayed value (kg/cm²) x 0.098




Example: When 21S4a, 21S4b, SV1a are ON. (Item No. 3)





Example: 3-minutes restart mode (Item No. 14)



9-1-2 Initial LED Display

From power on until the completion of initial settings, the following information will be displayed on the monitor screen. (Displays No. 1 through No. 4 in order repeatedly.)

| No | Item | Display | Remarks |
|----|-----------------------|---------|---|
| 1 | Software version | | [0103] : Version 1.03 |
| 2 | Refrigerant type | | [410] : R410A |
| 3 | Model and capacity | | [H-20]: Cooling/Heating 20 HP For the first few minutes after power on, the capacity of each outdoor unit is displayed. Thereafter, the combined capacity is displayed. |
| 4 | Communication address | | [51] : Address 51 |

After the initial settings have been completed, the information on these items can be checked by making the switch setting that corresponds to No. 517 in the LED display table.

Note

Only item No. 1 "Software Version" appears on the display if there is a wiring failure between the control board and the transmission line power supply board or if the circuit board has failed. Or there may be no LED display.

•How to convert HP capacity to Model name

HP capacity is the capacity of outdoor unit that is shown on LED display at initial setting. Please refer to the following table to covert from HP capacity to Model name.

| HP | Model | HP | Model |
|----|-------|----|-------|
| 8 | P72 | 32 | P288 |
| 10 | P96 | 34 | - |
| 12 | P120 | 36 | - |
| 14 | - | 38 | - |
| 16 | P144 | 40 | - |
| 18 | P168 | 42 | - |
| 20 | P192 | 44 | - |
| 22 | P216 | 46 | - |
| 24 | P240 | 48 | - |
| 26 | - | 50 | - |
| 28 | P264 | 52 | - |
| 30 | - | 54 | - |

9-1-3 Clock Memory Function

The outdoor unit has a simple clock function that enables the unit to calculate the current time with an internal timer by receiving the time set by the system controller, such as AG-150A.

If an error (including a preliminary error) occurs, the error history data and the error detection time are stored into the service memory.

The error detection time stored in the service memory and the current time can be seen on the service LED.

Note |

- 1) Use the time displayed on the service LED as a reference.
- 2) The date and the time are set to "00" by default. If a system controller that sets the time, such as AG-150A is not connected, the elapsed time and days since the first power on will be displayed.
 - If the time set on a system controller is received, the count will start from the set date and the time.
- 3) The time is not updated while the power of the indoor unit is turned off. When the power is turned off and then on again, the count will resume from the time before the power was turned off. Thus, the time that differs the actual time will be displayed. (This also applies when a power failure occurs.)

The system controller, such as AG-150A, adjusts the time once a day. When the system controller is connected, the time will be automatically updated to the correct current time after the time set by the system controller is received. (The data stored into the memory before the set time is received will not be updated.)

(1) Reading the time data:

1) Time display


Example: 12 past 9



* Disappears if the time data is deviated due to a power failure, or if a system controller that sets the time is not connected.


2) Date display

•When the main controller that can set the time is connected Example: May 10, 2003



* Appears between the year and the month, and nothing appears when the date is displayed.

•When the main controller that can set the time is not connected Example: 52 days after power was turned on



LED Status Indicators Table

Current data

| | SW4 (When SW6- | | | | | i | | | | | Unit | ij | |
|--------------|-------------------|---|--------------------------|-----------|------------|-----------------|--|-------------|--|---|----------|------------|---|
| No. | 10 is set to OFF) | Item | | | | Įs Is | Display | | | | (A, B)*1 | * <u> </u> | Remarks |
| | 1234567890 | | LD1 | LD2 | FD3 | LD4 | FD5 | PD7 | LD7 | FD8 | 00 | SO | |
| c | 0000000 | Relay output display 1 Lighting | 1 Comp in op- eration | | | | 72C | | 00 | CPU in oper- ation | ∢ | ∢ | |
| > | | Check (error) display 1 OC/OS error | - | | 0000 to 99 | 99 (Address an | 0000 to 9999 (Address and error codes highlighted) | ighlighted) | | | В | В | |
| - | 1000000000 | Check (error) display 2 OC/OS error | 2 | | 0000 to 99 | 99 (Address an | 0000 to 9999 (Address and error codes highlighted) | ighlighted) | | | ∢ | ∢ | Display of the latest pre- liminary error If no preliminary errors are detected, "" ap- pears on the display. |
| 2 | 0100000000 | Check (error) display 3 (Including IC and BC) | 8 0 | | 0000 to 99 | 199 (Address an | 0000 to 9999 (Address and error codes highlighted) | ighlighted) | | | В | | If no errors are detected, "" appears on the display. |
| c | 40000000 | Relay out- Top | 21S4a | | | | SV1a | | | | < | < | |
| ກ | 000000011 | putdisplay Bottom 2 | | | 21S4b | SV5b | | | | | ∢ | ∢ | |
| 4 | 0010000000 | Relay out-putdisplay 3 | SV4a | SV4b | SV4c | | | SV4d | 6/\S | Power supply for indoor transmission line | 4 | ٨ | |
| | | Bottom | | | | | | | | | | | |
| 7 | 1110000000 | Special control | Retry opera- tion | Emergency | | | | | Communica- tion error be- tween the OC and OS | Communica- tion error 3-minute re- start delay mode | В | В | |
| 6 | 1001000000 | Communication de- mand capacity | | | | 0000 tr | 0000 to 9999 | | | | В | В | If not demanded controlled, "" [%] appears on the display. |
| 10 | 0101000000 | Contact point demand capacity | q | | |) 0000 t | 0000 to 9999 | | | | В | | If not demanded controlled, "" [%] appears on the display. |
| i | | | | | | | | | | | | | |

*1 A: The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerant system is displayed.

9-2

Remarks

9 LED Status Indicators on the Outdoor Unit Circuit Board

| HWE2 | Current data | ıt data | | | | | | | | | | | | |
|-------|--------------|---|--|-------------------|------------------------------|---|---------------------------|---|--|-------------|---|--|-------------------|------------|
| 23040 | No. | SW4 (When SW6- 10 is set to OFF) | Ite | ltem | | | | Disp | Display | | | | Unit (A, B) *1 | it) *1 |
| | | 1234567890 | 1 | | LD1 | LD2 | FD3 | LD4 | FD5 | 9G7 | LD7 | PD8 | 20 | SO |
| | 1 | 1101000000 | External signal (Open input contact point) | gnal t contact | Contact point de- mand | Low-noise mode (Capacity priority) | Snow sensor | Cooling- heating changeover (Cooling) | Cooling- heating changeover (Heating) | | | | ∢ | ∢ |
| | 12 | 0011000000 | External signal (Open input contact point) | ynal t contact | | | | | | | | Low-noise mode (Quiet priori- ty) | ∢ | ∢ |
| | 13 | 1011000000 | | | | | | | | | | | | |
| | 41 | 0111000000 | Outdoor unit operation status | it operation | BC opera- tion signal | Warm-up mode | 3-minutes restart mode | Compressor in operation | Preliminary error | Error | 3-minutes restart after instanta- neous power failure | Preliminary low pres- sure error | ∢ | ∢ |
| | 15 | 1111000000 | OC/OS identification | ntification | | | | /00 | so/00 | | | | ⋖ | ∢ |
| | 16 | 00001 | Indoorunit | Тор | Unit No. 1 | Unit No. 2 | Unit No. 3 | Unit No. 4 | Unit No. 5 | Unit No. 6 | Unit No. 7 | Unit No. 8 | В | |
| - 319 | 2 | 00000 | check | Bottom | Unit No. 9 | Unit No. 10 | Unit No. 11 | Unit No. 12 | Unit No. 13 | Unit No. 14 | Unit No. 15 | Unit No. 16 | | |
| 9 - | 17 | 100010000 | _ | Тор | Unit No. 17 | Unit No. 18 | Unit No. 19 | Unit No. 20 | Unit No. 21 | Unit No. 22 | Unit No. 23 | Unit No. 24 | | |
| | = | | | Bottom | Unit No. 25 | Unit No. 26 | Unit No. 27 | Unit No. 28 | Unit No. 29 | Unit No. 30 | Unit No. 31 | Unit No. 32 | | |
| | 42 | 0400000 | _ | Тор | Unit No. 33 | Unit No. 34 | Unit No. 35 | Unit No. 36 | Unit No. 37 | Unit No. 38 | Unit No. 39 | Unit No. 40 | | |
| | 2 | 0000 | | Bottom | Unit No. 41 | Unit No. 42 | Unit No.43 | Unit No. 44 | Unit No. 45 | Unit No. 46 | Unit No. 47 | Unit No. 48 | | |
| | 19 | 1100100000 | | Тор | Unit No. 49 | Unit No. 50 | | | | | | | | |
| | 2 | | | Bottom | | | | | | | | | | |
| | 20 | 001010000 | Indoorunit | Тор | Unit No. 1 | Unit No. 2 | Unit No. 3 | Unit No. 4 | Unit No. 5 | Unit No. 6 | Unit No. 7 | Unit No. 8 | В | |
| | 2.2 | | Operation | Bottom | Unit No. 9 | Unit No. 10 | Unit No. 11 | Unit No. 12 | Unit No. 13 | Unit No. 14 | Unit No. 15 | Unit No. 16 | | |
| | 21 | 101010000 | | Тор | Unit No. 17 | Unit No. 18 | Unit No. 19 | Unit No. 20 | Unit No. 21 | Unit No. 22 | Unit No. 23 | Unit No. 24 | | |
| | - | | | Bottom | Unit No. 25 | Unit No. 26 | Unit No. 27 | Unit No. 28 | Unit No. 29 | Unit No. 30 | Unit No. 31 | Unit No. 32 | | |
| | 22 | 011010000 | _ | Тор | Unit No. 33 | Unit No. 34 | Unit No. 35 | Unit No. 36 | Unit No. 37 | Unit No. 38 | Unit No. 39 | Unit No. 40 | | |
| | 77 | | | Bottom | Unit No. 41 | Unit No. 42 | Unit No.43 | Unit No. 44 | Unit No. 45 | Unit No. 46 | Unit No. 47 | Unit No. 48 | | |
| | 23 | 1110100000 | | Тор | Unit No. 49 | Unit No. 50 | | | | | | | | |
| | 2 | | | Bottom | | | | | | | | | | |
| • | *1 A: Tł | *1 A: The condition of either OC or OS is displayed | er OC or OS i | is displayed ii | ndividually. B: T | he condition of | the entire refrige | individually. B: The condition of the entire refrigerant system is displayed. | displayed. | | | | | |

The lamp that corresponds to the unit that came to an abnormal stop lights.

The lamp goes off when the error is reset.
Each unit that comes to an abnormal unit will be given a sequential number in ascending order starting with 1.

Lit during cooling
Blinking during heating
Unlit while the unit is
stopped or in the fan
mode

Current data

| ourient data | ıı data | | | | | | | | | | | | | |
|--------------|--|------------------------------|--------------------------------|---------------------|----------------------|--|---------------------|---------------------|-------------------|-------------|------------------------------------|-------------------|----|------------------------------|
| No. | SW4 (When SW6 - 10 is set to OFF) | | ltem | | | | Display | olay | | | | Unit (A, B) *1 | *1 | Remarks |
| | 1234567890 | 1 | | LD1 | LD2 | FD3 | LD4 | FD5 | PDP | LD7 | PD8 | 00 | SO | |
| 24 | 0000110000 | Indoorunit | t Top | Unit No. 1 | Unit No. 2 | Unit No. 3 | Unit No. 4 | Unit No. 5 | Unit No. 6 | Unit No. 7 | Unit No. 8 | В | | Lit when thermostat is on |
| t 7 | | stat | Bottom | Unit No. 9 | Unit No. 10 | Unit No. 11 | Unit No. 12 | Unit No. 13 | Unit No. 14 | Unit No. 15 | Unit No. 16 | | | Unlit when thermostat is off |
| 25 | 1001100000 | I | Тор | Unit No. 17 | Unit No. 18 | Unit No. 19 | Unit No. 20 | Unit No. 21 | Unit No. 22 | Unit No. 23 | Unit No. 24 | | | |
| 3 | | | Bottom | Unit No. 25 | Unit No. 26 | Unit No. 27 | Unit No. 28 | Unit No. 29 | Unit No. 30 | Unit No. 31 | Unit No. 32 | | | |
| 90 | 0404 | ı | Тор | Unit No. 33 | Unit No. 34 | Unit No. 35 | Unit No. 36 | Unit No. 37 | Unit No. 38 | Unit No. 39 | Unit No. 40 | | | |
| 0 4 | | | Bottom | Unit No. 41 | Unit No. 42 | Unit No.43 | Unit No. 44 | Unit No. 45 | Unit No. 46 | Unit No. 47 | Unit No. 48 | | | |
| 7.0 | 11011 | ı | Тор | Unit No. 49 | Unit No. 50 | | | | | | | | | |
| Ž | | | Bottom | | | | | | | | | | | |
| 37 | 1010010000 | BC operation mode | ion mode | Cooling-only ON | Cooling-only OFF | Heating-only ON | Heating-only OFF | Mixed-mode ON | Mixed-mode OFF | Fan | Stop | В | | |
| 39 | 1110010000 | Outdoor ur mode | Outdoor unit Operation mode | Permissible stop | Standby | Cooling | Cooling- main | Heating | Heating- main | | | ⋖ | ∢ | |
| 42 | 0101010000 | Outdoor unit control mode | nit control | Stop | Thermo OFF | Abnormal stop | Scheduled | Initial start up | Defrost | Oil balance | Low fre- quency oil recovery | ∢ | ⋖ | |
| 43 | 1101010000 | | | Warm-up mode | Refrigerant recovery | | | | | | | ∢ | ٧ | |
| 45 | 1011010000 | TH4 | | | | | -99.9 to | -99.9 to 999.9 | | | | 4 | A | The unit is [°C] |
| 46 | 0111010000 | TH3 | | | | | -99.9 to | -99.9 to 999.9 | | | | ٧ | 4 | |
| 47 | 1111010000 | TH7 | | | | | -99.9 to | -99.9 to 999.9 | | | | ∢ | 4 | |
| 48 | 0000110000 | TH6 | | | | | -99.9 to | -99.9 to 999.9 | | | | ∢ | ∢ | |
| 20 | 0100110000 | TH5 | | | | | -99.9 to | -99.9 to 999.9 | | | | 4 | A | |
| 26 | 0001110000 | THHS1 | | | | | -99.9 to | .99.9 to 999.9 | | | | 4 | A | The unit is [°C] |
| 28 | 0101110000 | High-press data | High-pressure sensor data | | | | -99.9 to | -99.9 to 999.9 | | | | ∢ | ٨ | The unit is [kgf/cm²] |
| 29 | 1101110000 | Low-pressi data | Low-pressure sensor data | | | | -99.9 to | .99.9 to 999.9 | | | | ⋖ | ⋖ | |
| 61 | 1011110000 | TH15 | | | | | -99.9 to | -99.9 to 999.9 | | | | ∢ | 4 | The unit is [°C] |
| 78 | 0111001000 | ΣØj | | | | | 0000 to 9999 | 6666 c | | | | В | В | |
| 62 | 1111001000 | Σ Qjc | | | | | 0000 to 9999 | 6666 с | | | | В | В | |
| *1 A: T | *1 A: The condition of either OC or OS is displayed individually B: The condition of | her OC or OS | is displayed ir | ndividually. B: Th | t condition of t | the entire refrigerant system is displayed | rant system is c | displayed | | | | | | |

| Curr | Current data | | | | | | | | | | | | |
|------|-----------------------------------|--|---------------------|---------------------|-----------|-------------------|-----------|-----|-----|-----|-------------------|-------------|---|
| No. | SW4 (When SW6 - 10 is set to OFF) | ltem | | | | Display | lay | | | | Unit (A, B) *1 | it .) *1 | Remarks |
| | 1234567890 | T | LD1 | LD2 | LD3 | LD4 | FD5 | PDP | LD7 | FD8 | 00 | SO | |
| 80 | 000101000 | ∑ Qjh | | | | 0000 to 9999 | 6666 | | | | В | В | |
| 81 | 1000101000 | Target Tc | | | | -99.9 to 999.9 | 6.666 | | | | В | | The unit is [°C] |
| 82 | 0100101000 | Target Te | | | | -99.9 to 999.9 | 6.666 | | | | В | | |
| 83 | 1100101000 | Tc | | | | -99.9 to 999.9 | 6.666 | | | | ∢ | ⋖ | |
| 84 | 0010101000 | Te | | | | -99.9 to 999.9 | 6.666 | | | | ∢ | ∢ | |
| 86 | 0110101000 | Total frequencies (OC+OS) | | | | 0000 to 9999 | 6666 | | | | В | | Control data [Hz] |
| 87 | 1110101000 | Total frequency of each unit | | | | 0000 to 9999 | 6666 | | | | ∢ | ∢ | |
| 88 | 0001101000 | COMP frequency | | | | 0000 to 9999 | 6666 | | | | ∢ | ∢ | |
| 91 | 1101101000 | COMP operating frequency | | | | 0000 to 9999 | 6666 | | | | ∢ | ∢ | The unit is [rps]Output frequency of the inverter depends on the type of compressor and equals the integer multiples (x1, |
| | | | | | | | | | | | | | x2 etc.) of the operating frequency of the compressor. |
| 92 | 0011101000 | Number of times error occurred during crank-case heating by compressor motor | | | | 0000 to 9999 | 6666 | | | | ⋖ | ⋖ | Number of times INV error occurred during IH crankcase heating by compressor motor |
| 93 | 1011101000 | All AK (OC+OS) | | | | 0000 to 9999 | 6666 | | | | В | | |
| 94 | 0111101000 | AK | | | | 0000 to 9999 | 6666 | | | | ∢ | ∢ | |
| 92 | 1111101000 | FAN1 | | | | 0000 to 9999 | 6666 | | | | ∢ | ∢ | Fan output [%] |
| 96 | 000011000 | Fan inverter output rpm (FAN1) | | | | 0000 to 9999 | 6666 | | | | ∢ | ⋖ | [mbu] |
| 97 | 1000011000 | FAN2 | | | | 0000 to 9999 | 6666 | | | | ∢ | ∢ | Fan output [%] |
| 86 | 0100011000 | Fan inverter output rpm (FAN2) | | | | 0000 to 9999 | 6666 | | | | ∢ | ∢ | [mdu] |
| 101 | 1010011000 | LEV5a | | | | 0000 to 9999 | 6666 | | | | ٨ | A | |
| 107 | 1101011000 | LEV5b | | | | 0000 to 9999 | 6666 | | | | A | ٧ | |
| 108 | 3 0011011000 | COMP operating current (DC) | | | | 00.0 to 999.9 | 6.666 | | | | A | A | Peak value[A] |
| * | The population of City | وز اوریزواهواله مز ۵۰ دو ۲۰۰ | T.O. Albaidada D. T | d+ to acitibace ed. | bo opting | o oi motovo taore | porclacit | | | | | | |

*1 A: The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerant system is displayed.

9 LED Status Indicators on the Outdoor Unit Circuit Board

| | ç | ١ | |
|---|---|---|--|
| • | į | ١ | |
| | • | | |
| | | | |
| | ì | | |
| | | | |
| • | | | |

| No. | SW4 (When SW6 - 10 is set to OFF) | Item | E | | | | Dis | Display | | | | Unit (A, B) *1 | t 1 | Remarks |
|---------|---|---|------------------------------------|---------------------------|-------------------------|------------------------|---|--|------------------------------|-----|-----|-------------------|--------|---|
| | 1234567890 | T | | LD1 | LD2 | FD3 | LD4 | FD5 | PDP | LD7 | PD8 | 00 | SO | |
| 111 | 1111011000 | COMP bus voltage | voltage | | | | 00.0 tc | 00.0 to 999.9 | | | | A | Α | The unit is [V] |
| 116 | 001111000 | Number of times the unit went into the mode to remedy wet vapor suction | imes the o the mode et vapor | | | | t 0000 | 0000 to 9999 | | | | В | | |
| 117 | 1010111000 | COMP Operation time Upper 4 digits | ation time ts | | | | t 0000 | 0000 to 9999 | | | | ∢ | ٨ | The unit is [h] |
| 118 | 0110111000 | COMP Operation time Lower 4 digits | ation time ts | | | | 1 0000 | 0000 to 9999 | | | | ∢ | ∢ | |
| 121 | 1001111000 | Backup mode | a P | Abnormal pressure rise | High-pres- sure drop | Low-pres- sure drop | Abnormal Td rise | High-pres- sure during defrost cycle | Control box temperature rise | | | < | ∢ | Stays lit for 90 seconds after the completion of backup control |
| 123 | 1101111000 | COMP number of start- stop events Upper 4 digits | ber of start- ts | | | | t 0000 | 0000 to 9999 | | | | < | ∢ | Count-up at start-up The unit is [Time] |
| 124 | 0011111000 | COMP number of start- stop events Lower 4 digits | ber of start- ts | | | | t 0000 | 0000 to 9999 | | | | ∢ | ∢ | |
| 129 | 1000000100 | Integrated operation time of compressor (for rotation purpose) | peration pressor (for pose) | | | | 3 0000 | 0000 to 9999 | | | | В | | The unit is [h] |
| 132 | 0010000100 | Relay out- | Top | SVM1 | SVM2 | SVM1b | SVM2b | 21S4a | | | | a | | The 21S4a value will be displayed only when a |
| | | bC(Main) | | | | | | | | | | | | wob is connected to the system. |
| 133 | 1010000100 | | Top | SVA1 | SVB1 | SVC1 | SVA2 | SVB2 | SVC2 | | | В | | |
| | | | Bottom | SVA3 | SVB3 | SVC3 | SVA4 | SVB4 | SVC4 | | | | | |
| 134 | 0110000100 | • | l op Bottom | SVA5 SVA7 | SVB5 SVB7 | SVC5 | SVA6 | SVB8 | SVC8 | | | Ф | | |
| 135 | 1110000100 | ı | Тор | SVA9 | SVB9 | 8AC9 | SVA10 | SVB10 | SVC10 | | | α | | |
| 3 | | | Bottom | SVA11 | SVB11 | SVC11 | SVA12 | SVB12 | SVC12 | | | ם | • | |
| 136 | 0010001000 | | Тор | SVA13 | SVB13 | SVC13 | SVA14 | SVB14 | SVC14 | | | В | | |
| 2 | | | Bottom | SVA15 | SVB15 | SVC15 | SVA16 | SVB16 | SVC16 | | | 1 | | |
| *1 A: T | *1 A: The condition of either OC or OS is displayed individually. B: The condition of | er OC or OS is | s displayed in | dividually. B: Th | he condition of t | he entire refrige | the entire refrigerant system is displayed. | displayed. | | | | | | |

HWE23040 - 322 -

Remarks

9 LED Status Indicators on the Outdoor Unit Circuit Board

| HWE2 | Current data | t data | | | | | | | | | | | | |
|-------|--------------|---|------------------------------|-----------------|-------|-------|-------|----------|----------------|-------|-----|-----|-------------------|------------|
| 23040 | No. | SW4 (When SW6 - 10 is set to OFF) | Item | Ē | | | | Disp | Display | | | | Unit (A, B) *1 | it) *1 |
| | | 1234567890 | T | | LD1 | LD2 | LD3 | LD4 | FD5 | 9G7 | LD7 | FD8 | 00 | SO |
| | 7 20 | 000000000000000000000000000000000000000 | Relay out- | Тор | SVA1 | SVB1 | SVC1 | SVA2 | SVB2 | SVC2 | | | ۵ | |
| | 8 | 0010001010 | putdisplay BC(Sub1) | Bottom | SVA3 | SVB3 | SVC3 | SVA4 | SVB4 | SVC4 | | | ۵ | |
| | 130 | 1101000100 | | Тор | SVA5 | SVB5 | SVC5 | SVA6 | SVB6 | SVC6 | | | α | |
| | 2 | | | Bottom | SVA7 | SVB7 | SVC7 | SVA8 | SVB8 | SVC8 | | | ם | |
| | 740 | 0044000400 | | Top | SVA9 | SVB9 | SVC9 | SVA10 | SVB10 | SVC10 | | | ۵ | |
| | 9 | 0010001 | | Bottom | SVA11 | SVB11 | SVC11 | SVA12 | SVB12 | SVC12 | | | ۵ | |
| | 7 | 4044000400 | | Top | SVA13 | SVB13 | SVC13 | SVA14 | SVB14 | SVC14 | | | ۵ | |
| | <u>-</u> | 0010001101 | | Bottom | SVA15 | SVB15 | SVC15 | SVA16 | SVB16 | SVC16 | | | ۵ | |
| | 4.0 | 444 | Relay out- | Top | SVA1 | SVB1 | SVC1 | SVA2 | SVB2 | SVC2 | | | ٥ | |
| | 3 | | putdisplay BC(Sub2) | Bottom | SVA3 | SVB3 | SVC3 | SVA4 | SVB4 | SVC4 | | | ۵ | |
| | 77 | 0000100100 | ı | Тор | SVA5 | SVB5 | SVC5 | SVA6 | SVB6 | SVC6 | | | ٥ | |
| - | <u> </u> | 0000 | | Bottom | SVA7 | SVB7 | SVC7 | SVA8 | SVB8 | SVC8 | | | ם | |
| 323 | 1 45 | 40004000 | 1 | Top | SVA9 | SVB9 | SVC9 | SVA10 | SVB10 | SVC10 | | | ٥ | |
| 3 - | 5 | 001001 | | Bottom | SVA11 | SVB11 | SVC11 | SVA12 | SVB12 | SVC12 | | | ۵ | |
| | 977 | 0400400 | ı | Тор | SVA13 | SVB13 | SVC13 | SVA14 | SVB14 | SVC14 | | | α | |
| | <u>-</u> | | | Bottom | SVA15 | SVB15 | SVC15 | SVA16 | SVB16 | SVC16 | | | נ | |
| | 149 | 1010100100 | BC(Main or standard) TH11 | standard) | | | | -99.9 tc | 99.9 to 999.9 | | | | В | |
| | 150 | 0110100100 | BC(Main)TH12 | 112 | | | | -99.9 tc | -99.9 to 999.9 | | | | В | |
| | 151 | 1110100100 | BC(Main)TH15 | 115 | | | | -99.9 tc | -99.9 to 999.9 | | | | В | |
| | 152 | 0001100100 | BC(Main)TH16 | 116 | | | | -99.9 tc | -99.9 to 999.9 | | | | В | |
| | 153 | 1001100100 | BC(Main)63HS1 | HS1 | | | | -99.9 tc | .99.9 to 999.9 | | | | В | |
| | 154 | 0101100100 | BC(Main)63HS3 | HS3 | | | | -99.9 tc | .99.9 to 999.9 | | | | В | |
| | 155 | 1101100100 | BC(Main)SC11 | 311 | | | | -99.9 tc | .99.9 to 999.9 | | | | В | |
| | 156 | 0011100100 | BC(Main)SH12 | 112 | | | | -99.9 tc | -99.9 to 999.9 | | | | В | |
| | 157 | 1011100100 | BC(Main)SH13 | 113 | | | | -99.9 tc | -99.9 to 999.9 | | | | В | |
| | 158 | 0111100100 | BC(Main)SC16 | 316 | | | | -99.9 tc | -99.9 to 999.9 | | | | В | |
| | i | | 000 | 1 1 1 1 1 1 1 1 | F 6 | | | .,,, | - | | | | | |

Current data

| No. | SW4 (When SW6- 10 is set to OFF) | | ltem | | | | Dist | Display | | | | Unit (A, B) *1 | <u>*</u> | Remarks |
|-------------|-------------------------------------|--------------|--------|-------|----------|-------|----------|----------------|-------|-------------|-----|-------------------|----------|------------------------------------|
| | 1234567890 | | | LD1 | TD2 | FD3 | FD7 | FD5 | PDP | 2 07 | FD8 | 20 | SO | |
| 159 | 1111100100 | BC(Main)LEV1 | LEV1 | | | | 0000 t | 0000 to 2000 | | | | В | | LEV1 opening (Fully open:2000) |
| 160 | 0000010100 | BC(Main)LEV3 | LEV3 | | | | 0000 t | 0000 to 2000 | | | | В | | LEV3 opening (Fully open:2000) |
| 161 | 1000010100 | BC(Sub1)TH12 | TH12 | | | | -99.9 tc | -99.9 to 999.9 | | | | В | | |
| 162 | 0100010100 | BC(Sub1)TH15 | TH15 | | | | -99.9 tc | -99.9 to 999.9 | | | | В | | |
| 163 | 1100010100 | BC(Sub1)LEV3 | LEV3 | | | | 0000 t | 0000 to 2000 | | | | В | | LEV3 opening (Fully open:2000) |
| 164 | 0010010100 | BC(Sub2)TH12 | TH12 | | | | -99.9 tc | -99.9 to 999.9 | | | | В | | |
| 165 | 1010010100 | BC(Sub2)TH15 | TH15 | | | | -99.9 tc | -99.9 to 999.9 | | | | В | | |
| 166 | 0110010100 | BC(Sub2)LEV3 | LEV3 | | | | 0000 t | 0000 to 2000 | | | | В | | LEV3a opening (Fully open:2000) |
| 167 | 1110010100 | BC(Main)LEV2 | LEV2 | | | | 0000 t | 0000 to 2000 | | | | 8 | | LEV2 opening (Fully open:2000) |
| 160 | 1001010100 | Relay out- | Top . | SVA9 | SVB9 | 62AS | SVA10 | SVB10 | SVC10 | | | а | | |
| | | BC(Sub3) | Bottom | SVA11 | SVB11 | SVC11 | SVA12 | SVB12 | SVC12 | | | נ | | |
| 176 | 0000110100 | | Тор | SVA13 | SVB13 | SVC13 | SVA14 | SVB14 | SVC14 | | | α | | |
| 2 | | | Bottom | SVA15 | SVB15 | SVC15 | SVA16 | SVB16 | SVC16 | | | נ | | |
| H . V . V . | 3. | (| F 0 | i | 14.3 (4) | | | 7 | | | | | | |

*1 A: The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerant system is displayed.

9 LED Status Indicators on the Outdoor Unit Circuit Board

| | | ١ | |
|---|---|---|---|
| | į | | |
| | | | |
| į | | 1 | į |
| | | | |
| (| | | |
| | | | |
| | | | |

| 5 | | | | | | | | | | | | • | |
|---------|-----------------------------------|---|-------------------|-------------------|-----------------|---------------------------------------|------------------|-----|-----|-----|-------------------|-------|---|
| , S | SW4 (When SW6 - 10 is set to OFF) | - Item | | | | Dis | Display | | | | Unit (A, B) *1 | ii (. | Remarks |
| | 1234567890 | | LD1 | LD2 | FD3 | LD4 | FD5 | PDP | LD7 | FD8 | 00 | SO | |
| 178 | 3 0100110100 | Error history 1 | | | | 0000 t | 0000 to 9999 | | | | В | 8 | Address and error codes |
| 179 | 9 1100110100 | Error details of inverter | | | Ш | Error details of inverter (0001-0120) | verter (0001-012 | (0; | | | ∢ | < | nigniigntea If no errors are detected, |
| 180 | 0010110100 | Error history 2 | | | | 0000 t | 0000 to 9999 | | | | В | В . | " " appears on the dis- |
| 181 | 1010110100 | Error details of inverter | | | Ш | Error details of inverter (0001-0120) | verter (0001-012 | (0; | | | ∢ | < | Preliminary error informa- |
| 182 | 0110110100 | Error history 3 | | | | 0000 t | 0000 to 9999 | | | | В | B T | tion of the OS does not appear on the OC. |
| 183 | 3 1110110100 | Error details of inverter | | | Ш | Error details of inverter (0001-0120) | verter (0001-012 | (02 | | | ∢ | ∢ | Neither preliminary error |
| 184 | 4 0001110100 | Error history 4 | | | | 0000 t | 0000 to 9999 | | | | В | В | error information of the IC |
| 185 | 5 1001110100 | Error details of inverter | | | Ш | Error details of inverter (0001-0120) | verter (0001-012 | (0; | | | ∢ | 4 | appears on the OS. |
| 186 | 0101110100 | Error history 5 | | | | 0000 t | 0000 to 9999 | | | | В | В | |
| 187 | 7 1101110100 | Error details of inverter | | | Ш | Error details of inverter (0001-0120) | verter (0001-012 | (0; | | | ∢ | 4 | |
| 188 | 3 0011110100 | Error history 6 | | | | 0000 t | 0000 to 9999 | | | | В | В | |
| 189 | 9 1011110100 | Error details of inverter | | | Ш | Error details of inverter (0001-0120) | verter (0001-012 | (0; | | | ∢ | ∢ | |
| 190 | 0111110100 | Error history 7 | | | | 0000 t | 0000 to 9999 | | | | В | В | |
| 191 | 1111110100 | Error details of inverter | | | Ш | Error details of inverter (0001-0120) | verter (0001-012 | (0) | | | ∢ | ∢ | |
| 192 | 2 00000001100 | Error history 8 | | | | 0000 t | 0000 to 9999 | | | | В | В | |
| 193 | 3 1000001100 | Error details of inverter | | | Ш | Error details of inverter (0001-0120) | verter (0001-012 | (0; | | | ∢ | ∢ | |
| 194 | 4 0100001100 | Error history 9 | | | | 0000 t | 0000 to 9999 | | | | В | В | |
| 195 | 5 1100001100 | Error details of inverter | | | Ш | Error details of inverter (0001-0120) | verter (0001-012 | (0) | | | ∢ | ∢ | |
| 196 | 3 0010001100 | Error history 10 | | | | 0000 t | 0000 to 9999 | | | | В | В | |
| 197 | 7 1010001100 | Error details of inverter | | | Ш | Error details of inverter (0001-0120) | verter (0001-012 | (02 | | | ∢ | < | |
| 198 | 3 0110001100 | Error history of inverter (At the time of last data backup before error) | | | | 0000 | 0000 to 9999 | | | | Ф | Ф | |
| 199 | 9 1110001100 | Error details of inverter | | | Ш | Error details of inverter (0001-0120) | verter (0001-012 | 50) | | | ∢ | ∢ | |
| *1 A | : The condition of eit | *1 A. The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerant system is displayed. | ndividually. B: T | he condition of t | he entire refri | gerant system is | displayed. | | | | | | |

| | (| 1 | |
|---|---|---|--|
| ١ | i | ١ | |
| ٠ | • | | |
| ١ | | | |
| | 1 | 1 | |
| | 1 | | |
| (| Ċ | | |
| | | | |

| current data | ı data | | | | | | | | | | | | | |
|--------------|-------------------------------------|------------------------|--------------------------|-------|-------|-------|---------|-------|-------|-----|-----|-------------------|----------|---------|
| N | SW4 (When SW6- 10 is set to OFF) | | ltem | | | | Display | ılay | | | | Unit (A, B) *1 | <u>*</u> | Remarks |
| | 1234567890 | ı | | LD1 | LD2 | FD3 | LD4 | FD5 | PD9 | LD7 | FD8 | 00 | SO | |
| 000 | 00010001 | Relay out- | Top | SVA1 | SVB1 | SVC1 | SVA2 | SVB2 | SVC2 | | | α | | |
| 200 | 001000 | putdisplay BC(Sub4) | Bottom | SVA3 | SVB3 | SVC3 | SVA4 | SVB4 | SVC4 | | | ם | | |
| 700 | 0011001100 | | Тор | SVA5 | SVB5 | SVC5 | SVA6 | SVB6 | SVC6 | | | ٥ | | |
| - F04 | 001 | | Bottom | SVA7 | SVB7 | SVC7 | SVA8 | SVB8 | SVC8 | | | ם | | |
| 202 | 111001100 | ı | Тор | SVA9 | SVB9 | SVC9 | SVA10 | SVB10 | SVC10 | | | ٥ | | |
| 707 | | | Bottom | SVA11 | SVB11 | SVC11 | SVA12 | SVB12 | SVC12 | | | ۵ | <u>!</u> | |
| 2,0 | 0000 | 1 | Тор | SVA13 | SVB13 | SVC13 | SVA14 | SVB14 | SVC14 | | | ٥ | | |
| 017 | 0010010 | | Bottom | SVA15 | SVB15 | SVC15 | SVA16 | SVB16 | SVC16 | | | ۵ | <u>I</u> | |
| 727 | 0007077 | Relay out- | Top | SVA1 | SVB1 | SVC1 | SVA2 | SVB2 | SVC2 | | | ٥ | | |
| 767 | 000 | putdisplay BC(Sub5) | Bottom | SVA3 | SVB3 | SVC3 | SVA4 | SVB4 | SVC4 | | | ۵ | | |
| 225 | 7707077 | | Тор | SVA5 | SVB5 | SVC5 | SVA6 | SVB6 | SVC6 | | | ٥ | | |
| | | | Bottom | SVA7 | SVB7 | SVC7 | SVA8 | SVB8 | SVC8 | | | ם | | |
| 236 | 001101100 | ı | Тор | SVA9 | SVB9 | SVC9 | SVA10 | SVB10 | SVC10 | | | α | | |
| 067 | | | Bottom | SVA11 | SVB11 | SVC11 | SVA12 | SVB12 | SVC12 | | | ם | | |
| 237 | 1011011100 | ı | Тор | SVA13 | SVB13 | SVC13 | SVA14 | SVB14 | SVC14 | | | α | | |
| 2 | | | Bottom | SVA15 | SVB15 | SVC15 | SVA16 | SVB16 | SVC16 | | | <u> </u> | | |
| 238 | 0411011100 | Relay out- | Тор | SVA1 | SVB1 | SVC1 | SVA2 | SVB2 | SVC2 | | | α | | |
| 969 | | putdisplay BC(Sub6) | Bottom | SVA3 | SVB3 | SVC3 | SVA4 | SVB4 | SVC4 | | | ם | l | |
| 230 | 1111011100 | | Тор | SVA5 | SVB5 | SVC5 | SVA6 | SVB6 | SVC6 | | | α | | |
| 253 | | | Bottom | SVA7 | SVB7 | SVC7 | SVA8 | SVB8 | SVC8 | | | ם | | |
| 240 | 0000111100 | I | Тор | SVA9 | SVB9 | 8AC9 | SVA10 | SVB10 | SVC10 | | | α | | |
| | | | Bottom | SVA11 | SVB11 | SVC11 | SVA12 | SVB12 | SVC12 | | | ם | | |
| 241 | 1000111100 | I | Тор | SVA13 | SVB13 | SVC13 | SVA14 | SVB14 | SVC14 | | | α | | |
| - | | | Bottom | SVA15 | SVB15 | SVC15 | SVA16 | SVB16 | SVC16 | | | נ | | |
| F | | | The second second second | i | | | | | | | | | | |

*1 A: The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerant system is displayed.

9 LED Status Indicators on the Outdoor Unit Circuit Board

| | • | 1 | |
|---|---|---|---|
| | ì | | |
| • | i | ١ | |
| ۰ | 7 | | į |
| | • | ۰ | |
| | | | |
| | i | | |
| | • | | |
| | ¢ | 1 | ľ |
| | 3 | | |
| | 3 | | |
| | • | • | |
| ı | : | | |
| 1 | | ľ | |
| | • | | |
| | | | |
| | | | |
| | | | |

| | current data | | | | | | | | | | | | | |
|------|--------------------------------------|------------------------|--------|-------|-------|-------|---------|-------|-------|-----|-----|-------------------|----------|---------|
| S | SW4 (When SW6 - 10 is set to OFF) | Tr. | Item | | | | Display | olay | | | | Unit (A, B) *1 | . | Remarks |
| | 1234567890 | ı | | LD1 | LD2 | FD3 | LD4 | FD5 | PDP | LD7 | LD8 | 00 | SO | |
| 040 | 0400444400 | Relay out- | Тор | SVA1 | SVB1 | SVC1 | SVA2 | SVB2 | SVC2 | | | α | | |
| 747 | 001 | putdisplay BC(Sub7) | Bottom | SVA3 | SVB3 | SVC3 | SVA4 | SVB4 | SVC4 | | | ۵ | | |
| 0.40 | 1100111100 | , | Тор | SVA5 | SVB5 | SVC5 | SVA6 | SVB6 | SVC6 | | | ٥ | | |
| 44 | | | Bottom | SVA7 | SVB7 | SVC7 | SVA8 | SVB8 | SVC8 | | | ۵ | | |
| 24.0 | 0010111100 | ı | Тор | SVA9 | SVB9 | SVC9 | SVA10 | SVB10 | SVC10 | | | ۵ | | |
| 7 | | | Bottom | SVA11 | SVB11 | SVC11 | SVA12 | SVB12 | SVC12 | | | ۵ | | |
| 376 | 10101 | ı | Тор | SVA13 | SVB13 | SVC13 | SVA14 | SVB14 | SVC14 | | | ۵ | | |
| 743 | | | Bottom | SVA15 | SVB15 | SVC15 | SVA16 | SVB16 | SVC16 | | | ۵ | | |
| 246 | 077 | Relay out- | Тор | SVA1 | SVB1 | SVC1 | SVA2 | SVB2 | SVC2 | | | ٥ | | |
| 740 | | putdisplay BC(Sub8) | Bottom | SVA3 | SVB3 | SVC3 | SVA4 | SVB4 | SVC4 | | | ۵ | ı | |
| 777 | 1110111100 | , | Тор | SVA5 | SVB5 | SVC5 | SVA6 | SVB6 | SVC6 | | | α | | |
| ř | | | Bottom | SVA7 | SVB7 | SVC7 | SVA8 | SVB8 | SVC8 | | | ם | I | |
| 307 | 0001111100 | ı | Тор | SVA9 | SVB9 | SVC9 | SVA10 | SVB10 | SVC10 | | | α | | |
| | | | Bottom | SVA11 | SVB11 | SVC11 | SVA12 | SVB12 | SVC12 | | | ۵ | | |
| 256 | 010000000 | ı | Тор | SVA13 | SVB13 | SVC13 | SVA14 | SVB14 | SVC14 | | | α | | |
| 9 | | | Bottom | SVA15 | SVB15 | SVC15 | SVA16 | SVB16 | SVC16 | | | ם | I | |
| 080 | 0010000010 | Relay out- | Тор | SVA1 | SVB1 | SVC1 | SVA2 | SVB2 | SVC2 | | | α | | |
| 9 | | putdisplay BC(Sub9) | Bottom | SVA3 | SVB3 | SVC3 | SVA4 | SVB4 | SVC4 | | | ם | I | |
| 261 | 101000010 | | Тор | SVA5 | SAB5 | SVC5 | SVA6 | 98/S | SVC6 | | | α | | |
| 200 | | | Bottom | SVA7 | 28AB7 | SVC7 | SVA8 | 8A/S | SVC8 | | | ם | | |
| 263 | 1110000010 | ı | Тор | SVA9 | SVB9 | SVC9 | SVA10 | SVB10 | SVC10 | | | α | | |
| 8 | | | Bottom | SVA11 | SVB11 | SVC11 | SVA12 | SVB12 | SVC12 | | | ם | I | |
| 280 | 00001100010 | | Тор | SVA13 | SVB13 | SVC13 | SVA14 | SVB14 | SVC14 | | | α | | |
| 200 | | | Bottom | SVA15 | SVB15 | SVC15 | SVA16 | SVB16 | SVC16 | | | ם | | |
| , F | | | - | [i | | | | | | | | | | |

Current data

| Current data | ıt data | | | | | | | | | | | | | |
|-----------------|--|------------------|-----------------|------------|---------------|-------------------|----------------|-----------|-------|-----|-----|-------------------|----|---------|
| No. | SW4 (When SW6 - 10 is set to OFF) | # | Item | | | | Display | ılay | | | | Unit (A, B) *1 | | Remarks |
| | 1234567890 | | | LD1 | LD2 | FD3 | LD4 | FD5 | 9D7 | LD7 | FD8 | 0 00 | so | |
| 281 | 1001100010 | Relay out- | Тор | SVA1 | SVB1 | SVC1 | SVA2 | SVB2 | SVC2 | | | α | | |
| 2 | | putdispiay BC | Bottom | SVA3 | SVB3 | SVC3 | SVA4 | SVB4 | SVC4 | | | <u> </u> | | |
| 283 | 1101100010 | (Sub10) | Тор | SVA5 | SVB5 | SVC5 | SVA6 | SVB6 | SVC6 | | | а | | |
| 207 | | | Bottom | SVA7 | SVB7 | SVC7 | SVA8 | SVB8 | SVC8 | | | <u> </u> | | |
| 707 | 00011100010 | T | Тор | SVA9 | SVB9 | SVC9 | SVA10 | SVB10 | SVC10 | | | ۵ | | |
| 70 7 | 01000 | | Bottom | SVA11 | SVB11 | SVC11 | SVA12 | SVB12 | SVC12 | | | ۵ | | |
| 205 | 1041100010 | | Тор | SVA13 | SVB13 | SVC13 | SVA14 | SVB14 | SVC14 | | | ۵ | | |
| 207 | | | Bottom | SVA15 | SVB15 | SVC15 | SVA16 | SVB16 | SVC16 | | | ۵ | | |
| 900 | 77 | Relay out- | Тор | SVA1 | SVB1 | SVC1 | SVA2 | SVB2 | SVC2 | | | c | | |
| 700 | 010001 | putdisplay BC | Bottom | SVA3 | SVB3 | SVC3 | SVA4 | SVB4 | SVC4 | | | ۵ | | |
| 700 | 7 | (Sub11) | Тор | SVA5 | SVB5 | SVC5 | SVA6 | SVB6 | SVC6 | | | 0 | | |
| 707 | | | Bottom | SVA7 | SVB7 | SVC7 | SVA8 | SVB8 | SVC8 | | | <u> </u> | | |
| 200 | 04000400 | | Тор | SVA9 | SVB9 | SVC9 | SVA10 | SVB10 | SVC10 | | | ٥ | | |
| 730 | | | Bottom | SVA11 | SVB11 | SVC11 | SVA12 | SVB12 | SVC12 | | | <u> </u> | | |
| 201 | 1100010010 | | Тор | SVA13 | SVB13 | SVC13 | SVA14 | SVB14 | SVC14 | | | α | | |
| 67 | | | Bottom | SVA15 | SVB15 | SVC15 | SVA16 | SVB16 | SVC16 | | | <u> </u> | | |
| 292 | 0010010010 | BC(Main)LEV4 | EV4 | | | | 0000 to 9999 | 6666 | • | | | В | | |
| 293 | 1010010010 | BC(Sub1)TH16 | TH16 | | | | -99.9 to 999.9 | 6.666 | | | | В | | |
| 296 | 0001010010 | BC(Sub1)PS3 | S3 | | | | -99.9 to 999.9 | 6.666 | | | | В | | |
| 297 | 1001010010 | BC(Sub2)TH16 | -H16 | | | | -99.9 to 999.9 | 6.666 | | | | В | | |
| 298 | 010101010 | BC(Sub2)PS3 | .83 | | | | -99.9 to 999.9 | 6.999.9 | | | | В | | |
| 299 | 110101010 | BC(Sub3)TH12 | TH12 | | | | -99.9 to 999.9 | 6.666 | | | | В | | |
| 306 | 0100110010 | BC(Sub3)TH15 | TH15 | | | | -99.9 to 999.9 | 6.666 | | | | В | | |
| 307 | 1100110010 | BC(Sub3)LEV3 | EV3 | | | | 0000 to 9999 | 6666 | | | | В | | |
| 308 | 0010110010 | BC(Sub3)TH16 | -H16 | | | | -99.9 to 999.9 | 6.999.9 | | | | В | | |
| 309 | 1010110010 | BC(Sub3)PS3 | 53 | | | | -99.9 to 999.9 | 6.999.9 | | | | В | | |
| 310 | 0110110010 | BC(Sub4)TH12 | TH12 | | | | -99.9 to 999.9 | 6.666 | | | | В | | |
| *1 A·Th | *1 A. The condition of either OC or OS is displayed individually. B. The condition of the entire refrinerant system is displayed | er OC or OS | is displayed in | IT :B: Tip | ondition of t | he entire refrice | rant system is | lisplayed | | | e e | 4 | = | 1 |

9 LED Status Indicators on the Outdoor Unit Circuit Board

| Remarks | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|-------------------------------------|------------|----------------|--------------|----------------|----------------|----------------|----------------|--------------|----------------|----------------|----------------|----------------|--------------|----------------|----------------|----------------|----------------|--------------|----------------|----------------|----------------|----------------|--------------|----------------|----------------|----------------|----------------|--------------|
| Unit (A, B) *1 | so | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 8 | В | В | В | В | В | В | В | В | В | В | В | В | В | В | В | В | В | В | В | В | В | В | В | В | В | В | Ф |
| | 8G7 | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | LD7 | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | PDP TDE | - | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ay | FD5 | 6.666 | 6666 | 6.666 | 6.666 | 6.666 | 6.666 | 6666 | 6.666 | 6.666 | 6.666 | 6.666 | 6666 | 6.666 | 6.666 | 6.666 | 6.666 | 6666 | 6.666 | 6.666 | 6.666 | 6.666 | 6666 | 6.666 | 6.666 | 6.666 | 6.666 | 6666 |
| Display | LD4 | -99.9 to 999.9 | 0000 to 9999 | -99.9 to 999.9 | -99.9 to 999.9 | -99.9 to 999.9 | -99.9 to 999.9 | 0000 to 9999 | -99.9 to 999.9 | -99.9 to 999.9 | -99.9 to 999.9 | -99.9 to 999.9 | 0000 to 9999 | -99.9 to 999.9 | -99.9 to 999.9 | -99.9 to 999.9 | -99.9 to 999.9 | 0000 to 9999 | -99.9 to 999.9 | -99.9 to 999.9 | -99.9 to 999.9 | -99.9 to 999.9 | 0000 to 9999 | -99.9 to 999.9 | -99.9 to 999.9 | -99.9 to 999.9 | -99.9 to 999.9 | 0000 to 9999 |
| | LD3 | - | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | LD2 | • | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | LD1 | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ltem | | BC(Sub4)TH15 | BC(Sub4)LEV3 | BC(Sub4)TH16 | BC(Sub4)PS3 | BC(Sub5)TH12 | BC(Sub5)TH15 | BC(Sub5)LEV3 | BC(Sub5)TH16 | BC(Sub5)PS3 | BC(Sub6)TH12 | BC(Sub6)TH15 | BC(Sub6)LEV3 | BC(Sub6)TH16 | BC(Sub6)PS3 | BC(Sub7)TH12 | BC(Sub7)TH15 | BC(Sub7)LEV3 | BC(Sub7)TH16 | BC(Sub7)PS3 | BC(Sub8)TH12 | BC(Sub8)TH15 | BC(Sub8)LEV3 | BC(Sub8)TH16 | BC(Sub8)PS3 | BC(Sub9)TH12 | BC(Sub9)TH15 | BC(Sub9)LEV3 |
| SW4 (When SW6- 10 is set to OFF) | 1234567890 | 1110110010 | 0001110010 | 1001110010 | 0101110010 | 1101110010 | 0011110010 | 1011110010 | 0111110010 | 1111110010 | 011000110 | 1110001010 | 0001001010 | 1001001010 | 1100101010 | 0010101010 | 1101101010 | 10111101010 | 0111101010 | 1000100110 | 0100100110 | 1100100110 | 0010100110 | 1010100110 | 0110100110 | 1110100110 | 0011111110 | 1011111110 |
| o, OZ | 1 | 311 | 312 | 313 | 314 | 315 | 316 | 317 | 318 | 319 | 326 | 327 | 328 | 329 | 339 | 340 | 347 | 349 | 350 | 401 | 402 | 403 | 404 | 405 | 406 | 407 | 208 | 609 |

| 1 | ľ | ١ | 3 |
|---|---|---|----|
| 4 | i | | j |
| ĺ | į | ١ | j |
| 7 | į | | į |
| | | | |
| ì | ί | | |
| í | Ċ | 1 | 5 |
| 1 | i | | _ |
| | į | | |
| ĺ | | | 7 |
| 2 | | | • |
| C | | i |) |
| 7 | | | |
| | | | 77 |

| N O | SW4 (When SW6- 10 is set to OFF) | Item | | | | | Display | | | | | Unit (A, B) *1 | it (: | Remarks |
|---------|-------------------------------------|---|-----------------|-----------------|--------------|-------------------|----------------|--------|-----|-----|-----|-------------------|-------|---------|
| | 1234567890 | Ī | LD1 | LD2 | FD3 | 3 LD4 | - | FD5 | PDP | LD7 | PD8 | 00 | so | |
| 510 | 011111110 | BC(Sub9)TH16 | | | |) ~~ | -99.9 to 999.9 | 6.6 | | 1 | | В | | |
| 511 | 111111110 | BC(Sub9)PS3 | | | |) T | -99.9 to 999.9 | 9.9 | | | | В | | |
| 521 | 1001000001 | BC(Sub10)TH12 | | | |) ~~ | .99.9 to 999.9 | 9.6 | | | | В | | |
| 522 | 0101000001 | BC(Sub10)TH15 | | | |) Y | -99.9 to 999.9 | 6.6 | | | | В | | |
| 673 | 1000010101 | BC(Sub10)LEV3 | | | | 0 | 0000 to 9999 | 66 | | | | В | | |
| 674 | 0100010101 | BC(Sub10)TH16 | | | | 7 | -99.9 to 999.9 | 6.6 | | | | В | | |
| 675 | 1100010101 | BC(Sub10)PS3 | | | | 7 | -99.9 to 999.9 | 6.6 | | | | В | | |
| 677 | 10100101 | BC(Sub11)TH12 | | | | 7 | -99.9 to 999.9 | 6.6 | | | | В | | |
| 829 | 0110010101 | BC(Sub11)TH15 | | | | 37 | -99.9 to 999.9 | 6.6 | | | | В | | |
| 681 | 1001010101 | BC(Sub11)LEV3 | | | | D | 0000 to 9999 | 66 | | | | В | | |
| 682 | 0101010101 | BC(Sub11)TH16 | | | | 7 | -99.9 to 999.9 | 6.6 | | | | В | | |
| 683 | 1101010101 | BC(Sub11)PS3 | | | | Ť | -99.9 to 999.9 | 6.6 | | | | В | | |
| *1 A: T | The condition of eith | *1 A: The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerant system is displayed. | ndividually. B: | The condition o | f the entire | refrigerant syste | em is disp | layed. | | | | | | |

HWE23040 - 330 -

9 LED Status Indicators on the Outdoor Unit Circuit Board

Data before error

| Data | Data perore error | | | | | | | | | | | | | |
|---------|--|-------------------------------------|-------------|--------------------------|----------------------|---------------------------|----------------------------|---------------------|-------------------|--|---|-------------------|-------|------------------|
| Š. | SW4 (When SW6- 10 is set to OFF) | Item | | | | | Disp | Display | | | | Unit (A, B) *1 | 3) *1 | Remarks |
| | 1234567890 | T | <u> </u> | LD1 | LD2 | FD3 | LD4 | FD5 | PDP | LD7 | 8GT | 00 | SO | |
| 201 | 1001001100 | Outdoor unit operation status | peration | BC opera- tion signal | Warm-up mode | 3-minutes restart mode | Compressor in operation | Preliminary | Error | 3-minutes restart after instanta-neous power failure | Preliminary low pres- sure error | ∢ | ∢ | |
| 202 | 0101001100 | OC/OS identification | cation | | | | OC/ | so/oo | | | | ٧ | 4 | |
| 203 | 1101001100 | BC operation mode | node | Cooling-only ON | Cooling-only OFF | Heating-only ON | Heating-only OFF | Mixed-mode ON | Mixed-mode OFF | Fan | Stop | ∢ | ∢ | |
| 205 | 1011001100 | Outdoor unit Operation mode | peration | Permissible stop | Standby | Cooling | Cooling- main | Heating | Heating- main | | | A | ⋖ | |
| 208 | 0000101100 | Outdoor unit control mode | ontrol | Stop | Thermo OFF | Abnormal stop | Scheduled | Initial start up | Defrost | Oil balance | Low fre- quency oil recovery | ∢ | ∢ | |
| 209 | 1000101100 | | | | Refrigerant recovery | | | | | | | ∢ | ⋖ | |
| 211 | 1100101100 | Relay output display 1 Lighting | isplay 1 | Comp in op- eration | | | | 72C | | 00 | Always lit | ∢ | ⋖ | |
| | | Relay out- To | Тор | 21S4a | | | | SV1a | | | | | | |
| 212 | 0010101100 | | Bottom | | | 21S4b | 95/S | | | | | А | 4 | |
| 213 | 1010101100 | Relay out- To putdisplay 3 Lighting | Тор | SV4a | SV4b | SV4c | | | SV4d | 6AS | Lit while power to the indoor units is being sup- plied | ∢ | ∢ | |
| | | Bc | Bottom | | | | | | | | | | | |
| 216 | 0001101100 | TH4 | | | | | -99.9 tc | -99.9 to 999.9 | | | | ∢ | ⋖ | The unit is [°C] |
| 217 | 1001101100 | TH3 | | | | | -99.9 tc | -99.9 to 999.9 | | | | Α | ∢ | |
| 218 | 0101101100 | TH7 | | | | | -99.9 tc | -99.9 to 999.9 | | | | Α | ∢ | |
| 219 | 1101101100 | ТН6 | | | | | -99.9 tc | -99.9 to 999.9 | | | | Α | ∢ | |
| 221 | 1011101100 | TH5 | | | | | -99.9 tc | -99.9 to 999.9 | | | | А | A | |
| 227 | 1100011100 | THHS1 | | | | | -99.9 tc | -99.9 to 999.9 | | | | Α | ٧ | The unit is [°C] |
| *1 A: T | *1 A: The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerant system is displayed | er OC or OS is di | isplayed in | dividually. B: Th | ne condition of t | the entire refrige | erant system is | displayed. | | | | | | |

Data before error

| No. | SW4 (When SW6 - 10 is set to OFF) | Item | | | | Dis | Display | | | | Unit (A, B) *1 | nit 3) *1 | Remarks |
|----------|--------------------------------------|--|---------------------|--------------------|--------------------|-----------------|----------------|-----|-----|-----|-------------------|--------------|---------------------------|
| | 1234567890 | I | LD1 | LD2 | FD3 | LD4 | FD5 | 9Q7 | LD7 | LD8 | 00 | SO | |
| 229 | 1010011100 | High-pressure sensor data | | | | -99.9 tr | .99.9 to 999.9 | | | | ∢ | ٨ | The unit is [kgf/cm²] |
| 230 | 0110011100 | Low-pressure sensor data | | | | 19.99- | -99.9 to 999.9 | | | | ∢ | ٧ | |
| 249 | 1001111100 | ΣQj | | | | 0000 | 0000 to 9999 | | | | В | В | |
| 250 | 0101111100 | Σ Qjc | | | | 0000 | 0000 to 9999 | | | | В | В | |
| 251 | 1101111100 | ∑ Qjh | | | | 0000 | 0000 to 9999 | | | | В | В | |
| 252 | 0011111100 | Target Tc | | | | -99.9 tc | -99.9 to 999.9 | | | | В | | The unit is [°C] |
| 253 | 1011111100 | Target Te | | | | -99.9 tc | -99.9 to 999.9 | | | | В | | |
| 254 | 0111111100 | Tc | | | | -99.9 te | .99.9 to 999.9 | | | | ∢ | Α | The unit is [°C] |
| 255 | 1111111100 | Te | | | | -99.9 tr | -99.9 to 999.9 | | | | ∢ | Α | |
| 257 | 100000010 | Total frequencies (OC+OS) | | | | 0000 t | 0000 to 9999 | | | | В | | Control data [Hz] |
| 258 | 0100000010 | Total frequency of each unit | | | | 0000 t | 0000 to 9999 | | | | ٧ | Α | |
| 259 | 1100000010 | COMP frequency | | | | 1 0000 | 0000 to 9999 | | | | ٧ | Α | |
| 264 | 00001000010 | All AK (OC+OS) | | | | 1 0000 | 0000 to 9999 | | | | В | | |
| 265 | 1001000010 | AK | | | | 0000 | 0000 to 9999 | | | | ٧ | Α | |
| 266 | 01000010 | FAN1 | | | | 0000 | 0000 to 9999 | | | | ∢ | Α | Fan inverter output [%] |
| 267 | 1101000010 | Fan inverter output rpm (FAN1) | | | | 0000 t | 0000 to 9999 | | | | ٧ | Α | [mdu] |
| 268 | 0011000010 | FAN2 | | | | 1 0000 | 0000 to 9999 | | | | ٧ | Α | Fan inverter output [%] |
| 269 | 1011000010 | Fan inverter output rpm (FAN2) | | | | 0000 t | 0000 to 9999 | | | | ∢ | ٨ | [mdu] |
| 272 | 0000100010 | LEV5a | | | | 0000 | 0000 to 9999 | | | | ٧ | Α | |
| 278 | 0110100010 | LEV5b | | | | 1 0000 | 0000 to 9999 | | | | ٧ | Α | |
| 279 | 1110100010 | COMP operating current (DC) | | | | 00.0 tc | 00.0 to 999.9 | | | | ٨ | А | Peak value[A] |
| 282 | 01001100010 | COMP bus voltage | | | | 00.0 tc | 00.0 to 999.9 | | | | ٧ | Α | The unit is [V] |
| *1 A: Th | he condition of eith | *1 A. The condition of either OC or OS is displayed individually. B. The condition of the entire refrigerant system is displayed | Tidiologically B. T | The condition of t | the entire refrige | erant system is | displayed | | | | | | |

*1 A: The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerant system is displayed.

9 LED Status Indicators on the Outdoor Unit Circuit Board

| ÷ |
|--------|
| 0 |
| _ |
| Ξ. |
| o |
| _ |
| œ |
| |
| 0 |
| ┺. |
| Ō |
| 2 |
| = |
| Œ |
| ± |
| ū |
| \Box |
| _ |
| |

| _ | LEDS | | us Indi | | lablej | | | 1 |
|---|-------------------------------------|------------|---------------------------------------|---------------------------------------|--|--|--|---|
| | Remarks | | The unit is [h] | | Count-up at start-up The unit is [Time] | | The unit is [h] | |
| | iit 3) *1 | SO | ⋖ | ∢ | ∢ | ∢ | | |
| | Unit (A, B) *1 | ၁၀ | ٧ | 4 | 4 | ٨ | В | |
| | | FD8 | | | | | | |
| | | LD7 | | | | | | |
| | | PDP | | | | | | |
| | Display | FD5 | 0000 to 9999 | 0000 to 9999 | 0000 to 9999 | 0000 to 9999 | 0000 to 9999 | 400000000000000000000000000000000000000 |
| | Dis | LD4 | 4 0000 | 0000 | 0000 | 0000 | 4 0000 | ei en eter e teren |
| | | FD3 | | | | | | . ming on it a coult |
| | | TD2 | | | | | | the meitibules and |
| | | LD1 | | | | | | F . C |
| | Item | | COMP Operation time Upper 4 digits | COMP Operation time Lower 4 digits | COMP number of start- stop events Upper 4 digits | COMP number of start- stop events Lower 4 digits | Integrated operation time of compressor (for rotation purpose) | |
| | SW4 (When SW6- 10 is set to OFF) | 1234567890 | 0000010010 | 1000010010 | 0110010010 | 1110010010 | 0011010010 | - 141 - 3 (31) |
| | No. | | 288 | 289 | 294 | 295 | 300 | T- 4 74 |

HWE23040 - 333 -

Data before error

| המומ ה | Data perore error | | | | | | | | | | | | |
|---------|-----------------------------------|---------------------------|---------------|---------------------|----------------|-------------------|-----------|-----|-----|-----|------------------------------|----|---------|
| Š | SW4 (When SW6 - 10 is set to OFF) | ltem | | | | Display | ılay | | | | Unit (A, B) ^{*1} | | Remarks |
| | 1234567890 | | LD1 | LD2 | FD3 | LD4 | FD5 | PD9 | LD7 | FD8 | 00 | SO | |
| 301 | 1011010010 | Power supply unit | | | | OC/OS <-> Address | * Address | | | | В | | |
| 302 | 0111010010 | Start-up unit | | | | OC/OS <-> Address | * Address | | | | В | | |
| 320 | 0000001010 | BC(Main)TH11 | | | | -99.9 to 999.9 | 6.666 | | | | В | | |
| 321 | 1000001010 | BC(Main)TH12 | | | | -99.9 to 999.9 | 6.666 | | | | В | | |
| 322 | 0100001010 | BC(Main)TH15 | | | | -99.9 to 999.9 | 6.666 | | | | В | | |
| 323 | 1100001010 | BC(Main)TH16 | | | | -99.9 to 999.9 | 939.9 | | | | В | | |
| 324 | 0010001010 | BC(Main)PS1 | | | | -99.9 to 999.9 | 6.666 | | | | В | | |
| 325 | 1010001010 | BC(Main)PS3 | | | | -99.9 to 999.9 | 6.666 | | | | В | | |
| 330 | 0101001010 | BC(Main)LEV1 | | | | 0000 to 2000 | 2000 | | | | В | | |
| 331 | 1101001010 | BC(Main)LEV3 | | | | 0000 to 2000 | 2000 | | | | В | | |
| 332 | 0011001010 | BC(Sub1)TH12 | | | | -99.9 to 999.9 | 6.666 | | | | В | | |
| 333 | 1011001010 | BC(Sub1)TH15 | | | | -99.9 to 999.9 | 6.666 | | | | В | | |
| 334 | 0111001110 | BC(Sub1)LEV3 | | | | 0000 to 2000 | , 2000 | | | | В | | |
| 335 | 1111001010 | BC(Sub2)TH12 | | | | -99.9 to 999.9 | 6.666 | | | | В | | |
| 336 | 0000101010 | BC(Sub2)TH15 | | | | -99.9 to 999.9 | 6.666 | | | | В | | |
| 337 | 1000101010 | BC(Sub2)LEV3 | | | | 0000 to 2000 | , 2000 | | | | В | | |
| 338 | 0100101010 | BC(Main)LEV2 | | | | 0000 to 2000 | , 2000 | | | | В | | |
| 684 | 0011010101 | BC(Sub1)TH16 | | | | -99.9 to 999.9 | 6.666 | | | | В | | |
| 685 | 1011010101 | BC(Sub1)PS3 | | | | -99.9 to 999.9 | 6.666 | | | | В | | |
| 989 | 0111010101 | BC(Sub2)TH16 | | | | -99.9 to 999.9 | 6.666 | | | | В | | |
| 289 | 1111010101 | BC(Sub2)PS3 | | | | -99.9 to 999.9 | 6.666 | | | | В | | |
| 712 | 0001001101 | BC(Sub3)TH12 | | | | -99.9 to 999.9 | 6.666 | | | | В | | |
| 713 | 1001001101 | BC(Sub3)TH15 | | | | -99.9 to 999.9 | 6.666 | | | | В | | |
| 898 | 0010011011 | BC(Sub3)LEV3 | | | | 0000 to 9999 | 6666 | | | | В | | |
| 869 | 1010011011 | BC(Sub3)TH16 | | | | -99.9 to 999.9 | 6.666 | | | | В | | |
| 870 | 0110011011 | BC(Sub3)PS3 | | | | -99.9 to 999.9 | 6.666 | | | | В | | |
| 874 | 0101011011 | BC(Sub4)TH12 | | | | -99.9 to 999.9 | 6.666 | | | | В | | |
| *1 ^. T | dio to acitibaco or | i boyclasib si SO 10 O 10 | a vilondividu | The condition of th | ropiro rofrigo | oi motovo tac. | hourdasi | | | | | | |

9 LED Status Indicators on the Outdoor Unit Circuit Board

| | 3 | | |
|---|---|---|---|
| | (| |) |
| | 1 | | |
| | 2 | | • |
| | • | 4 | į |
| | ć | 1 | 3 |
| | ì | Ī | _ |
| | (| • | 1 |
| | ú | | |
| | (| 1 | 1 |
| | į | Ė | 1 |
| ľ | | | |
| | Ç | ١ | į |
| • | • | | |
| | 5 | Ī | |
| ı | | | 1 |
| | | | |
| | | | |
| | | | |

| No. | SW4 (When SW6 - 10 is set to OFF) | Item | | | | Display | | | | Unit (A, B) ^{*1} | it 5)*1 | Remarks |
|----------|--------------------------------------|---|--------------------|----------------------|--------------------------|-----------------|-----|-----|-----|------------------------------|------------|---------|
| | 1234567890 | | LD1 | LD2 | LD3 LD4 | FD5 | PDP | LD7 | FD8 | 00 | SO | |
| 875 | 1101011011 | BC(Sub4)TH15 | | |)6- | -99.9 to 999.9 | | | | В | | |
| 882 | 0100111011 | BC(Sub4)LEV3 | | | 00 | 0000 to 9999 | | | | В | | |
| 883 | 1100111011 | BC(Sub4)TH16 | | |)6- | -99.9 to 999.9 | | | | В | | |
| 806 | 0011000111 | BC(Sub4)PS3 | | |)6- | -99.9 to 999.9 | | | | В | | |
| 606 | 1011000111 | BC(Sub5)TH12 | | |)6- | -99.9 to 999.9 | | | | В | | |
| 910 | 0111000111 | BC(Sub5)TH15 | | | 36- | -99.9 to 999.9 | | | | В | | |
| 911 | 11110001111 | BC(Sub5)LEV3 | | | 00 | 0000 to 9999 | | | | В | | |
| 912 | 0000100111 | BC(Sub5)TH16 | | |)6- | -99.9 to 999.9 | | | | В | | |
| 913 | 1000100111 | BC(Sub5)PS3 | | |) 6 - | -99.9 to 999.9 | | | | В | | |
| 914 | 0100100111 | BC(Sub6)TH12 | | |)6- | -99.9 to 999.9 | | | | В | | |
| 915 | 1100100111 | BC(Sub6)TH15 | | |)6- | -99.9 to 999.9 | | | | В | | |
| 916 | 0010100111 | BC(Sub6)LEV3 | | | 00 | 0000 to 9999 | | | | В | | |
| 917 | 101010111 | BC(Sub6)TH16 | | |)6- | -99.9 to 999.9 | | | | В | | |
| 918 | 0110100111 | BC(Sub6)PS3 | | |)6- | -99.9 to 999.9 | | | | В | | |
| 919 | 1110101111 | BC(Sub7)TH12 | | |)6- | -99.9 to 999.9 | | | | В | | |
| 920 | 0001100111 | BC(Sub7)TH15 | | |)6- | -99.9 to 999.9 | | | | В | | |
| 921 | 1001100111 | BC(Sub7)LEV3 | | | 00 | 0000 to 9999 | | | | В | | |
| 922 | 0101100111 | BC(Sub7)TH16 | | |)6- | -99.9 to 999.9 | | | | В | | |
| 923 | 1101100111 | BC(Sub7)PS3 | | |)6- | -99.9 to 999.9 | | | | В | | |
| 924 | 0011100111 | BC(Sub8)TH12 | | |)6- | -99.9 to 999.9 | | | | В | | |
| 925 | 1011100111 | BC(Sub8)TH15 | | |)6- | -99.9 to 999.9 | | | | В | | |
| 926 | 01111001111 | BC(Sub8)LEV3 | | | 00 | 0000 to 9999 | | | | В | | |
| 927 | 11111001111 | BC(Sub8)TH16 | | |)6- | .99.9 to 999.9 | | | | В | | |
| 928 | 0000010111 | BC(Sub8)PS3 | | |)6- | -99.9 to 999.9 | | | | В | | |
| 929 | 100001111 | BC(Sub9)TH12 | | |)6- | -99.9 to 999.9 | | | | В | | |
| 930 | 0100010111 | BC(Sub9)TH15 | | | 36- | -99.9 to 999.9 | | | | В | | |
| 931 | 1100010111 | BC(Sub9)LEV3 | | | 00 | 0000 to 9999 | | | | В | | |
| *1 A: Th | ne condition of eith | *1 A: The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerant system is displayed. | Tidividually. B: 1 | The condition of the | entire refrigerant syste | m is displayed. | | | | | | |

Data before error

| No. | SW4 (When SW6 - 10 is set to OFF) | ltem | | | | | Dis | Display | | | | Unit (A, B)*1 | nit 3)*1 | Remarks |
|----------|--------------------------------------|----------------------------|-------|---------------------------------------|------------|-----|---------|----------------|--------------|-----|-----|------------------|-------------|------------------|
| | 1234567890 | Ī | LD1 | | LD2 | LD3 | LD4 | FD5 | 9 0 7 | LD7 | FD8 | 00 | SO | |
| 932 | 0010010111 | BC(Sub9)TH16 | | | | | -99.9 t | -99.9 to 999.9 | | | | В | | |
| 933 | 1010010111 | BC(Sub9)PS3 | | | | | -99.9 t | .99.9 to 999.9 | | | | В | | |
| 934 | 0110010111 | BC(Sub10)TH12 | | | | | -99.9 t | -99.9 to 999.9 | | | | В | | |
| 935 | 1110010111 | BC(Sub10)TH15 | | | | | -99.9 | -99.9 to 999.9 | | | | В | | |
| 936 | 0001010111 | BC(Sub10)LEV3 | | | | | 0000 t | 0000 to 9999 | | | | В | | |
| 937 | 1001010111 | BC(Sub10)TH16 | | | | | -99.9 t | -99.9 to 999.9 | | | | В | | |
| 938 | 0101010111 | BC(Sub10)PS3 | | | | | -99.9 t | -99.9 to 999.9 | | | | В | | |
| 939 | 1101010111 | BC(Sub11)TH12 | | | | | 16:66- | .99.9 to 999.9 | | | | В | | |
| 940 | 0011010111 | BC(Sub11)TH15 | | | | | -99.9 t | -99.9 to 999.9 | | | | В | | |
| 941 | 1011010111 | BC(Sub11)LEV3 | | | | | 0000 t | 0000 to 9999 | | | | В | | |
| 942 | 01110101111 | BC(Sub11)TH16 | | | | | -99.9 t | -99.9 to 999.9 | | | | В | | |
| 943 | 11110101111 | BC(Sub11)PS3 | | | | | 16:66- | -99.9 to 999.9 | | | | В | | |
| 944 | 0000110111 | BC(Main)LEV4 | | | | | 0000 t | 0000 to 9999 | | | | В | | |
| 945 | 1000110111 | TH15 | | | | | 16:66- | -99.9 to 999.9 | | | | A | А | The unit is [°C] |
| T . V P* | -11: - 3 (1): | -: F -: : -: 30 : - 00 : - | F . C | 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 | 11.3 17.17 | | ., , | | | | | | | |

9 LED Status Indicators on the Outdoor Unit Circuit Board

Data on indoor unit system

| Remarks | | Displayed alternately ev- | ery 5 seconds | | | | | | | | | | | | | | | |
|--------------------------------------|------------|---------------------------|---------------------------|---------------------------|---------------------------|---------------------------|---------------------------|---------------------------|---------------------------|---------------------------|----------------------------|----------------------------|----------------------------|----------------------------|----------------------------|----------------------------|----------------------------|----------------------------|
| Unit (A, B) *1 | so | | | | | | | | | | | | | | | | | |
| J (A) | 00 | В | | | | | | | | | | | | | | | | |
| | PD8 | | | | | | | | | | | | | | | | | |
| | LD7 | 6666 | 6666 | 6666 | 6666 | 6666 | 6666 | 6666 | 6666 | 6666 | 6666 | 6666 | 6666 | 6666 | 6666 | 6666 | 6666 | 6666 |
| | PTP PTP | 0000 to 9999 | 0000 to 9999 | 0000 to 9999 | 0000 to 9999 | 0000 to 9999 | 0000 to 9999 | 0000 to 9999 | 0000 to 9999 |
| lay | FD5 | | | | | | | | | | | | | | | | | |
| Display | LD4 | | | | | | | | | | | | | | | | | |
| | LD3 | 6666 | 6666 | 6666 | 6666 | 6666 | 6666 | 6666 | 6666 | 6666 | 6666 | 6666 | 6666 | 6666 | 6666 | 6666 | 6666 | 6666 |
| | LD2 | 0000 to 9999 | 0000 to 9999 | 0000 to 9999 | 0000 to 9999 | 0000 to 9999 | 0000 to 9999 | 0000 to 9999 | 0000 to 9999 |
| | LD1 | | | | | | | | | | | | | | | | | |
| Item | • | IC1 Address/capacity code | IC2 Address/capacity code | IC3 Address/capacity code | IC4 Address/capacity code | IC5 Address/capacity code | IC6 Address/capacity code | IC7 Address/capacity code | IC8 Address/capacity code | IC9 Address/capacity code | IC10 Address/capacity code | IC11 Address/capacity code | IC12 Address/capacity code | IC13 Address/capacity code | IC14 Address/capacity code | IC15 Address/capacity code | IC16 Address/capacity code | IC17 Address/capacity code |
| SW4 (When SW6 - 10 is set to OFF) | 1234567890 | 1111101010 | 0000011010 | 1000011010 | 0100011010 | 1100011010 | 0010011010 | 1010011010 | 0110011010 | 1110011010 | 0001011010 | 1001011010 | 01011010 | 1101011010 | 0011011010 | 1011011010 | 0111011010 | 1111011010 |
| No. | • | 351 | 352 | 353 | 354 | 355 | 356 | 357 | 358 | 329 | 360 | 361 | 362 | 363 | 364 | 365 | 366 | 367 |

*1 A: The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerant system is displayed.

Data on indoor unit system

| | 6 | | | | | | | | | | | | |
|---------|-------------------------------------|---|-----------------|-------------------|-------------------|-----------------|--------|--------------|------|-----|-------------------|-------------|---------------------------|
| No. | SW4 (When SW6- 10 is set to OFF) | ltem | | | | Display | olay | | | | Unit (A, B) *1 | 1 .F | Remarks |
| | 1234567890 | | LD1 | LD2 | FD3 | LD4 | FD5 | 9G7 | LD7 | FD8 | 00 | SO | |
| 368 | 0000111010 | IC18 Address/capacity code | | 0000 | 0000 to 9999 | | | 0000 to 9999 | 6666 | | В | | Displayed alternately ev- |
| 369 | 1000111010 | IC19 Address/capacity code | | 0000 | 0000 to 9999 | | | 0000 to 9999 | 6666 | | | | ery 5 seconds |
| 370 | 0100111010 | IC20 Address/capacity code | | 0000 | 0000 to 9999 | | | 0000 to 9999 | 6666 | | | | |
| 371 | 1100111010 | IC21 Address/capacity code | | 0000 | 0000 to 9999 | | | 0000 to 9999 | 6666 | | | | |
| 372 | 0010111010 | IC22 Address/capacity code | | 0000 | 0000 to 9999 | | | 0000 to 9999 | 6666 | | | | |
| 373 | 1010111010 | IC23 Address/capacity code | | 0000 | 0000 to 9999 | | | 0000 to 9999 | 6666 | | | | |
| 374 | 011111010 | IC24 Address/capacity code | | 0000 | 0000 to 9999 | | | 0000 to 9999 | 6666 | | | | |
| 375 | 1110111010 | IC25 Address/capacity code | | 0000 | 0000 to 9999 | | | 0000 to 9999 | 6666 | | | | |
| 376 | 0001111010 | IC26 Address/capacity code | | 0000 | 0000 to 9999 | | | 0000 to 9999 | 6666 | | | | |
| 377 | 1001111010 | IC27 Address/capacity code | | 0000 | 0000 to 9999 | | | 0000 to 9999 | 6666 | | | | |
| 378 | 0101111010 | IC28 Address/capacity code | | 0000 | 0000 to 9999 | | | 0000 to 9999 | 6666 | | | | |
| 379 | 1101111010 | IC29 Address/capacity code | | 0000 | 0000 to 9999 | | | 0000 to 9999 | 6666 | | | | |
| 380 | 0011111010 | IC30 Address/capacity code | | 0000 | 0000 to 9999 | | | 0000 to 9999 | 6666 | | | | |
| 381 | 1011111010 | IC31 Address/capacity code | | 0000 | 0000 to 9999 | | | 0000 to 9999 | 6666 | | | | |
| 382 | 0111111010 | IC32 Address/capacity code | | 0000 | 0000 to 9999 | | | 0000 to 9999 | 6666 | | | | |
| 383 | 1111111010 | IC33 Address/capacity code | | 0000 | 0000 to 9999 | | | 0000 to 9999 | 6666 | | | | |
| 384 | 0000000110 | IC34 Address/capacity code | | 0000 | 0000 to 9999 | | | 0000 to 9999 | 6666 | | | | |
| 385 | 1000000110 | IC35 Address/capacity code | | 0000 | 0000 to 9999 | | | 0000 to 9999 | 6666 | | | | |
| 386 | 0100000110 | IC36 Address/capacity code | | 0000 | 0000 to 9999 | | | 0000 to 9999 | 6666 | | | | |
| 387 | 1100000110 | IC37 Address/capacity code | | 0000 | 0000 to 9999 | | | 0000 to 9999 | 6666 | | | | |
| 388 | 0010000110 | IC38 Address/capacity code | | 0000 | 0000 to 9999 | | | 0000 to 9999 | 6666 | | | | |
| 389 | 1010000110 | IC39 Address/capacity code | | 0000 | 0000 to 9999 | | | 0000 to 9999 | 6666 | | | | |
| 390 | 0110000110 | IC40 Address/capacity code | | 0000 | 0000 to 9999 | | | 0000 to 9999 | 6666 | | | | |
| 391 | 1110000110 | IC41 Address/capacity code | | 0000 | 0000 to 9999 | | | 0000 to 9999 | 6666 | | | | |
| 392 | 0001000110 | IC42 Address/capacity code | | 0000 | 0000 to 9999 | | | 0000 to 9999 | 6666 | | | | |
| 393 | 1001000110 | IC43 Address/capacity code | | 0000 | 0000 to 9999 | | | 0000 to 9999 | 6666 | | | | |
| 394 | 010000110 | IC44 Address/capacity code | | 0000 | 0000 to 9999 | | | 0000 to 9999 | 6666 | | | | |
| 395 | 1101000110 | IC45 Address/capacity code | | 0000 | 0000 to 9999 | | | 0000 to 9999 | 6666 | | | | |
| 1 A: Th | e condition of eith | 1 A: The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerant system is displayed | Ilv. B: The cor | ndition of the er | ntire refrigerant | system is displ | layed. | | | | | | |

*1 A: The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerant system is displayed.

Displayed alternately every 5 seconds

The unit is [°C]

ш

Remarks

SO

ဗ

LD8

LD7

PD6

Item

Data on indoor unit system

SW4 (When SW6-10 is set to OFF)

ģ

0000 to 9999

0000 to 9999

0000 to 9999

0000 to 9999

В

Unit (A, B) *1

9 LED Status Indicators on the Outdoor Unit Circuit Board

LD5 -99.9 to 999.9 -99.9 to 999.9 -99.9 to 999.9 -99.9 to 999.9 LD4 LD3 0000 to 9999 LD2 LD1 IC50 Address/capacity code IC47 Address/capacity code IC48 Address/capacity code IC49 Address/capacity code IC46 Address/capacity code IC3 Suction temperature IC4 Suction temperature IC1 Suction temperature IC2 Suction temperature 1101100110 1111000110 0000100110 0011000110 1011000110 0111000110 1001100110 0101100110 1234567890 0001100110 410 411 398 399 400 408 409 396 397

*1 A: The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerant system is displayed.

- 339 -

Data on indoor unit system

| | f | | | | | | | | | | | | |
|----------|-------------------------------------|---|-----------------|------------------|--------------------|------------------|---------|-----|-----|-----|-------------------|----------------|------------------|
| No. | SW4 (When SW6- 10 is set to OFF) | ltem | | | | Display | ılay | | | | Unit (A, B) *1 | . . | Remarks |
| | 1234567890 | ī | LD1 | LD2 | FD3 | LD4 | FD5 | 9Q7 | LD7 | PD8 | 00 | SO | |
| 412 | 0011100110 | IC5 Suction temperature | | | | -99.9 to 999.9 | 6.666 | | | | В | | The unit is [°C] |
| 413 | 1011100110 | IC6 Suction temperature | | | | -99.9 to 999.9 | 6.666 | | | | | | |
| 414 | 0111100110 | IC7 Suction temperature | | | | -99.9 to 999.9 | 6.666 | | | | | | |
| 415 | 1111100110 | IC8 Suction temperature | | | | -99.9 to 999.9 | 6.666 | | | | | | |
| 416 | 0000010110 | IC9 Suction temperature | | | | -99.9 to 999.9 | 6.666 | | | | | | |
| 417 | 1000010110 | IC10 Suction temperature | | | | -99.9 to 999.9 | 6.999.9 | | | | | | |
| 418 | 0100010110 | IC11 Suction temperature | | | | -99.9 to 999.9 | 6.666 | | | | | | |
| 419 | 1100010110 | IC12 Suction temperature | | | | -99.9 to 999.9 | 6.666 | | | | | | |
| 420 | 0010010110 | IC13 Suction temperature | | | | -99.9 to 999.9 | 6.999.9 | | | | | | |
| 421 | 1010010110 | IC14 Suction temperature | | | | -99.9 to 999.9 | 6.999.9 | | | | | | |
| 422 | 0110010110 | IC15 Suction temperature | | | | -99.9 to 999.9 | 6.999.9 | | | | | | |
| 423 | 1110010110 | IC16 Suction temperature | | | | -99.9 to 999.9 | 6.999.9 | | | | | | |
| 424 | 0001010110 | IC17 Suction temperature | | | | -99.9 to 999.9 | 6.999.9 | | | | | | |
| 425 | 1001010110 | IC18 Suction temperature | | | | -99.9 to 999.9 | 6.666 | | | | | | |
| 426 | 0101010110 | IC19 Suction temperature | | | | -99.9 to 999.9 | 6.999.9 | | | | | | |
| 427 | 1101010110 | IC20 Suction temperature | | | | -99.9 to 999.9 | 6.999.9 | | | | | | |
| 428 | 0011010110 | IC21 Suction temperature | | | | -99.9 to 999.9 | 6.999.9 | | | | | | |
| 429 | 1011010110 | IC22 Suction temperature | | | | -99.9 to 999.9 | 6.999.9 | | | | | | |
| 430 | 0111010110 | IC23 Suction temperature | | | | -99.9 to 999.9 | 6.666 | | | | | | |
| 431 | 1111010110 | IC24 Suction temperature | | | | -99.9 to 999.9 | 6.999.9 | | | | | | |
| 432 | 0000110110 | IC25 Suction temperature | | | | -99.9 to 999.9 | 6.999.9 | | | | | | |
| 433 | 1000110110 | IC26 Suction temperature | | | | -99.9 to 999.9 | 6.666 | | | | | | |
| 434 | 0100110110 | IC27 Suction temperature | | | | -99.9 to 999.9 | 6.666 | | | | | | |
| 435 | 1100110110 | IC28 Suction temperature | | | | -99.9 to 999.9 | 6.666 | | | | | | |
| *1 A: Th | e condition of eith | *1 A: The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerant system is displayed. | lly. B: The con | dition of the en | tire refrigerant s | system is displa | ayed. | | | | | | |

Data on indoor unit system

| חמום | Data on mucol unit system | etelli e | | | | | | | | | | | |
|----------|-------------------------------------|---|-----------------|------------------|--------------------|------------------|---------|------|-----|-----|-------------------|-----|------------------|
| o N | SW4 (When SW6- 10 is set to OFF) | ltem | | | | Display | ılay | | | | Unit (A, B) *1 | T.£ | Remarks |
| • | 1234567890 | 1 | LD1 | LD2 | FD3 | LD4 | LD5 | PTP6 | LD7 | PD8 | 00 | SO | |
| 436 | 0010110110 | IC29 Suction temperature | | | | -99.9 to 999.9 | 6.666 | | | | В | | The unit is [°C] |
| 437 | 1010110110 | IC30 Suction temperature | | | | -99.9 to 999.9 | 6.666 | | | | | | |
| 438 | 0110110110 | IC31 Suction temperature | | | | -99.9 to 999.9 | 6.666 | | | | | | |
| 439 | 1110110110 | IC32 Suction temperature | | | | -99.9 to 999.9 | 6.666 | | | | | | |
| 440 | 0001110110 | IC33 Suction temperature | | | | -99.9 to 999.9 | 6.666 | | | | | | |
| 441 | 1001110110 | IC34 Suction temperature | | | | -99.9 to 999.9 | 6.999.9 | | | | | | |
| 442 | 0101110110 | IC35 Suction temperature | | | | -99.9 to 999.9 | 6.999.9 | | | | | | |
| 443 | 1101110110 | IC36 Suction temperature | | | | -99.9 to 999.9 | 6.666 | | | | | | |
| 444 | 0011110110 | IC37 Suction temperature | | | | -99.9 to 999.9 | 6.666 | | | | | | |
| 445 | 1011110110 | IC38 Suction temperature | | | | -99.9 to 999.9 | 6.666 | | | | | | |
| 446 | 0111110110 | IC39 Suction temperature | | | | -99.9 to 999.9 | 6.666 | | | | | | |
| 447 | 1111110110 | IC40 Suction temperature | | | | -99.9 to 999.9 | 6.666 | | | | | | |
| 448 | 0000001110 | IC41 Suction temperature | | | | -99.9 to 999.9 | 6.999.9 | | | | | | |
| 449 | 1000001110 | IC42 Suction temperature | | | | -99.9 to 999.9 | 6.666 | | | | | | |
| 450 | 0100001110 | IC43 Suction temperature | | | | -99.9 to 999.9 | 6.666 | | | | | | |
| 451 | 1100001110 | IC44 Suction temperature | | | | -99.9 to 999.9 | 6.666 | | | | | | |
| 452 | 0010001110 | IC45 Suction temperature | | | | -99.9 to 999.9 | 6.666 | | | | | | |
| 453 | 1010001110 | IC46 Suction temperature | | | | -99.9 to 999.9 | 6.666 | | | | | | |
| 454 | 0110001110 | IC47 Suction temperature | | | | -99.9 to 999.9 | 6.666 | | | | | | |
| 455 | 1110001110 | IC48 Suction temperature | | | | -99.9 to 999.9 | 6.666 | | | | | | |
| 456 | 0001001110 | IC49Suction temperature | | | | -99.9 to 999.9 | 6.666 | | | | | | |
| 457 | 1001001110 | IC50 Suction temperature | | | | -99.9 to 999.9 | 6.666 | | | | | | |
| 458 | 0101001110 | IC1 Liquid pipe temperature | | | | -99.9 to 999.9 | 6.666 | | | | В | | The unit is [°C] |
| 459 | 1101001110 | IC2 Liquid pipe temperature | | | | -99.9 to 999.9 | 6.999.9 | | | | | | |
| 460 | 0011001110 | IC3 Liquid pipe temperature | | | | -99.9 to 999.9 | 6.666 | | | | | | |
| 461 | 1011001110 | IC4 Liquid pipe temperature | | | | -99.9 to 999.9 | 6.666 | | | | | | |
| 462 | 0111001110 | IC5 Liquid pipe temperature | | | | -99.9 to 999.9 | 6.666 | | | | | | |
| 463 | 1111001110 | IC6 Liquid pipe temperature | | | | -99.9 to 999.9 | 6.666 | | | | | | |
| ⁺1 A: Th | e condition of eith | 14 A: The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerant system is displayed. | lly. B: The con | dition of the en | tire refrigerant s | system is displa | ayed. | | | | | | |

The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerant system is displayed

9 LED Status Indicators on the Outdoor Unit Circuit Board

Data on indoor unit system

| שום סוו | sata on midoor dint system | lieis. | | | | | | | | | | | |
|----------|-------------------------------------|--|-----------------|------------------|--------------------|------------------|-------|---------|-----|-----|-------------------|-----------|------------------|
| ON | SW4 (When SW6- 10 is set to OFF) | ltem | | | | Display | lay | | | | Unit (A, B) *1 | it)*1 | Remarks |
| | 1234567890 | | LD1 | LD2 | FD3 | LD4 | FD5 | PTP 9G1 | LD7 | FD8 | 00 | SO | |
| 464 | 0000101110 | IC7 Liquid pipe temperature | | | | -99.9 to 999.9 | 6.666 | | | | В | | The unit is [°C] |
| 465 | 1000101110 | IC8 Liquid pipe temperature | | | | -99.9 to 999.9 | 6.666 | | | | | | |
| 466 | 0100101110 | IC9 Liquid pipe temperature | | | | -99.9 to 999.9 | 6.666 | | | | | | |
| 467 | 1100101110 | IC10 Liquid pipe temperature | | | | -99.9 to 999.9 | 6.666 | | | | | | |
| 468 | 0010101110 | IC11 Liquid pipe temperature | | | | -99.9 to 999.9 | 6.666 | | | | | | |
| 469 | 1010101110 | IC12 Liquid pipe temperature | | | | -99.9 to 999.9 | 6.666 | | | | | | |
| 470 | 0110101110 | IC13 Liquid pipe temperature | | | | -99.9 to 999.9 | 6.666 | | | | | | |
| 471 | 1110101110 | IC14 Liquid pipe temperature | | | | -99.9 to 999.9 | 6.666 | | | | | | |
| 472 | 0001101110 | IC15 Liquid pipe temperature | | | | -99.9 to 999.9 | 6.666 | | | | | | |
| 473 | 1001101110 | IC16 Liquid pipe temperature | | | | -99.9 to 999.9 | 6.666 | | | | | | |
| 474 | 0101101110 | IC17 Liquid pipe temperature | | | | -99.9 to 999.9 | 6.666 | | | | | | |
| 475 | 1101101110 | IC18 Liquid pipe temperature | | | | -99.9 to 999.9 | 6.666 | | | | | | |
| 476 | 0011101110 | IC19 Liquid pipe temperature | | | | -99.9 to 999.9 | 6.666 | | | | | | |
| 477 | 1011101110 | IC20 Liquid pipe temperature | | | | -99.9 to 999.9 | 6.666 | | | | | | |
| 478 | 0111101110 | IC21 Liquid pipe temperature | | | | -99.9 to 999.9 | 6.666 | | | | | | |
| 479 | 1111101110 | IC22 Liquid pipe temperature | | | | -99.9 to 999.9 | 6.666 | | | | | | |
| 480 | 0000011110 | IC23 Liquid pipe temperature | | | | -99.9 to 999.9 | 6.666 | | | | | | |
| 481 | 1000011110 | IC24 Liquid pipe temperature | | | | -99.9 to 999.9 | 6.666 | | | | | | |
| 482 | 0100011110 | IC25 Liquid pipe temperature | | | | -99.9 to 999.9 | 6.666 | | | | | | |
| 483 | 1100011110 | IC26 Liquid pipe temperature | | | | -99.9 to 999.9 | 6.666 | | | | | | |
| 484 | 0010011110 | IC27 Liquid pipe temperature | | | | -99.9 to 999.9 | 6.666 | | | | | | |
| 485 | 1010011110 | IC28 Liquid pipe temperature | | | | -99.9 to 999.9 | 6.666 | | | | | | |
| 486 | 01110011110 | IC29 Liquid pipe temperature | | | | -99.9 to 999.9 | 6.666 | | | | | | |
| 487 | 1110011110 | IC30 Liquid pipe temperature | | | | -99.9 to 999.9 | 6.666 | | | | | | |
| 488 | 0001011110 | IC31 Liquid pipe temperature | | | | -99.9 to 999.9 | 6.666 | | | | | | |
| 489 | 1001011110 | IC32 Liquid pipe temperature | | | | -99.9 to 999.9 | 6.666 | | | | | | |
| 490 | 0101011110 | IC33 Liquid pipe temperature | | | | -99.9 to 999.9 | 6.666 | | | | | | |
| 491 | 1101011110 | IC34 Liquid pipe temperature | | | | -99.9 to 999.9 | 6.666 | | | | | | |
| 1 A: The | s condition of eith | 1 A: The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerant system is displayed. | lly. B: The con | dition of the en | tire refrigerant s | system is displa | ayed. | | | | | | |

A: The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerant system is displaye

9 LED Status Indicators on the Outdoor Unit Circuit Board

| Remarks | | The unit is [°C] | | | | | | | | | | | | | | | |
|--------------------------------------|------------|------------------------------|------------------------------|------------------------------|------------------------------|------------------------------|------------------------------|------------------------------|------------------------------|------------------------------|------------------------------|------------------------------|------------------------------|------------------------------|------------------------------|------------------------------|------------------------------|
| nit 3) *1 | SO | | | | | | | | | | | | | | | | |
| Unit (A, B) *1 | 00 | В | | | | | | | | | | | | | | | |
| | 8GT | | | | | | | | | | | | | | | | |
| | LD7 | | | | | | | | | | | | | | | | |
| | 9G7 | | | | | | | | | | | | | | | | |
| Display | SQ7 | -99.9 to 999.9 |
| Dis | LD4 | -99.9 te | -99.9 t |
| | FD3 | | | | | | | | | | | | | | | | |
| | LD2 | | | | | | | | | | | | | | | | |
| | LD1 | | | | | | | | | | | | | | | | |
| ltem | | IC35 Liquid pipe temperature | IC36 Liquid pipe temperature | IC37 Liquid pipe temperature | IC38 Liquid pipe temperature | IC39 Liquid pipe temperature | IC40 Liquid pipe temperature | IC41 Liquid pipe temperature | IC42 Liquid pipe temperature | IC43 Liquid pipe temperature | IC44 Liquid pipe temperature | IC45 Liquid pipe temperature | IC46 Liquid pipe temperature | IC47 Liquid pipe temperature | IC48 Liquid pipe temperature | IC49 Liquid pipe temperature | IC50 Liquid pipe temperature |
| SW4 (When SW6 - 10 is set to OFF) | 1234567890 | 0011011110 | 1011011110 | 0111011110 | 1111011110 | 0000111110 | 1000111110 | 0100111110 | 1100111110 | 0010111110 | 1010111110 | 01111110 | 111011110 | 0001111110 | 1001111110 | 0101111110 | 1101111110 |
| | | 492 | 493 | 494 | 495 | 496 | 497 | 498 | 499 | 200 | 501 | 502 | 503 | - 34 | 202 | 206 | 202 |

*1 A: The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerant system is displayed.

Data on indoor unit system

Setting data

| N O | SW4 (When SW6 - 10 is set to OFF) | ltem | | | | Display | olay | | | | Unit (A, B)*1 | it ;)*1 | Remarks |
|--------|--------------------------------------|---|--------------------|-------------------|-------------------|--|-----------------|---|------------|-----|------------------|------------|---------|
| | 1234567890 | | LD1 | LD2 | rD3 | LD4 | FD5 | 907 | LD7 | FD8 | 00 | SO | |
| 512 | | 0000000001 Self-address | | | Alternate | Alternate display of self address and unit model | address and ur | ıit model | | | ∢ | ∢ | |
| 513 | | 1000000001 IC/FU address | | | Count-up | Count-up display of number of connected units | ber of connect | ed units | | | В | | |
| 514 | 0100000001 RC address | RC address | | | Count-up | Count-up display of number of connected units | ber of connect | ed units | | | В | | |
| 516 | 0010000001 OS address | OS address | | | Count-up | Count-up display of number of connected units | uber of connect | ed units | | | В | | |
| 517 | | 1010000001 Version/Capacity | | S/W version | ın → Refrigerant | t type → Model | and capacity – | \rightarrow Refrigerant type \rightarrow Model and capacity \rightarrow Communication address | on address | | ∢ | 4 | |
| 518 | 0110000001 OC address | OC address | | | | OC address display | ss display | | | | | В | |
| *1 A: | The condition of eith | *1 A: The condition of either OC or OS is displayed individually. B: The condition of the | ndividually. B: Ti | he condition of t | he entire refrige | entire refrigerant system is displayed. | displayed. | | | | | | |

HWE23040 - **344** -

9 LED Status Indicators on the Outdoor Unit Circuit Board

Data on indoor unit system

| Data o | Data on Indoor unit system | stem | | | | | | | | | | | |
|----------|-------------------------------------|---|-----------------|-----------------|--|-----------------|----------------|-----|-----|-----|-------------------|--------------|------------------|
| Š | SW4 (When SW6- 10 is set to OFF) | Item | | | | Dis | Display | | | | Unit (A, B) *1 | 1)t 3) *1 | Remarks |
| | 1234567890 | | LD1 | LD2 | грз | LD4 | FD5 | 9CT | LD7 | FD8 | ၁၀ | SO | |
| 523 | 110100001 | IC1 Gas pipe temperature | | | - | -99.9 | -99.9 to 999.9 | • | | | В | | The unit is [°C] |
| 524 | 0011000001 | IC2 Gas pipe temperature | | | | -99.9 | -99.9 to 999.9 | | | | I | | |
| 525 | 1011000001 | IC3 Gas pipe temperature | | | | -99.9 | -99.9 to 999.9 | | | | I | | |
| 526 | 0111000001 | IC4 Gas pipe temperature | | | | -99.9 | -99.9 to 999.9 | | | | 1 | | |
| 527 | 1111000001 | IC5 Gas pipe temperature | | | | -99.9 | -99.9 to 999.9 | | | | 1 | | |
| 528 | 0000100001 | IC6 Gas pipe temperature | | | | -99.9 | -99.9 to 999.9 | | | | ı | | |
| 529 | 1000100001 | IC7 Gas pipe temperature | | | | -99.9 | -99.9 to 999.9 | | | | ı | | |
| 230 | 0100100001 | IC8 Gas pipe temperature | | | | -99.9 | -99.9 to 999.9 | | | | 1 | | |
| 531 | 1100100001 | IC9 Gas pipe temperature | | | | -99.9 | -99.9 to 999.9 | | | | 1 | | |
| 532 | 0010100001 | IC10 Gas pipe temperature | | | | -99.9 | -99.9 to 999.9 | | | | ı | | |
| 533 | 1010100001 | IC11 Gas pipe temperature | | | | -99.9 | -99.9 to 999.9 | | | | I | | |
| 534 | 0110100001 | IC12 Gas pipe temperature | | | | -99.9 | -99.9 to 999.9 | | | | ı | | |
| 535 | 1110100001 | IC13 Gas pipe temperature | | | | -99.9 | -99.9 to 999.9 | | | | I | | |
| 536 | 0001100001 | IC14 Gas pipe temperature | | | | -99.9 | -99.9 to 999.9 | | | | I | | |
| 537 | 1001100001 | IC15 Gas pipe temperature | | | | 99.91 | -99.9 to 999.9 | | | | | | |
| 538 | 0101100001 | IC16 Gas pipe temperature | | | | -99.9 | -99.9 to 999.9 | | | | ı | | |
| 539 | 1101100001 | IC17 Gas pipe temperature | | | | 96.66- | -99.9 to 999.9 | | | | | | |
| 240 | 0011100001 | IC18 Gas pipe temperature | | | | -99.9 | -99.9 to 999.9 | | | | ı | | |
| 541 | 1011100001 | IC19 Gas pipe temperature | | | | -99.9 | -99.9 to 999.9 | | | | I | | |
| 542 | 0111100001 | IC20 Gas pipe temperature | | | | -99.9 | -99.9 to 999.9 | | | | ı | | |
| 543 | 1111100001 | IC21 Gas pipe temperature | | | | -99.9 | -99.9 to 999.9 | | | | I | | |
| 244 | 0000010001 | IC22 Gas pipe temperature | | | | -99.9 | -99.9 to 999.9 | | | | ı | | |
| 545 | 100010001 | IC23 Gas pipe temperature | | | | -99.9 | -99.9 to 999.9 | | | | ı | | |
| 546 | 0100010001 | IC24 Gas pipe temperature | | | | -99.9 | -99.9 to 999.9 | | | | I | | |
| 547 | 1100010001 | IC25 Gas pipe temperature | | | | -99.9 | -99.9 to 999.9 | | | | I | | |
| 548 | 0010010001 | IC26 Gas pipe temperature | | | | 99.91 | -99.9 to 999.9 | | | | | | |
| 549 | 1010010001 | IC27 Gas pipe temperature | | | | 6.66- | -99.9 to 999.9 | | | | | | |
| *1 A: TI | he condition of eith | *1 A: The condition of either OC or OS is displayed individually. B: The condition of t | ually. B: The c | ondition of the | ne entire refrigerant system is displayed. | system is displ | ayed. | | | | | | |

Data on indoor unit system

| | | | | | | | | | | | | | | | | | | | | | | | | | | _ |
|----------------------------|--------------------------------------|------------|--------------------------|---------------------------|---------------------------|---------------------------|---------------------------|---------------------------|---------------------------|---------------------------|---------------------------|---------------------------|---------------------------|---------------------------|---------------------------|---------------------------|---------------------------|---------------------------|---------------------------|---------------------------|---------------------------|---------------------------|---------------------------|---------------------------|---------------------------|---|
| | Remarks | | The unit is [°C] | | | | | | | | | | | | | | | | | | | | | | | |
| | nit 3) *1 | SO | | | | | | | | | | | | | | | | | | | | | | | | |
| | Unit (A, B) *1 | 00 | В | | | | | | | | | | | | | | | | | | | | | | | |
| | | FD8 | | | | | | | | | | | | | | | | | | | | | | | | |
| | | LD7 | | | | | | | | | | | | | | | | | | | | | | | | |
| | | PDG | | | | | | | | | | | | | | | | | | | | | | | | |
| | Я | LD5 | 6.99.9 | 6.666 | 6.666 | 9.99.9 | 6.99.9 | 6.99 | 6.99 | 6.99.9 | 6.666 | 6.666 | 6.99 | 6.666 | 6.99.9 | 6.666 | 6.666 | 6.99.9 | 6.666 | 6.666 | 6.99.9 | 6.99.9 | 6.666 | 6.666 | 6.666 | |
| | Display | LD4 | -99.9 to 999.9 | -99.9 to 999.9 | -99.9 to 999.9 | -99.9 to 999.9 | -99.9 to 999.9 | -99.9 to 999.9 | -99.9 to 999.9 | -99.9 to 999.9 | -99.9 to 999.9 | -99.9 to 999.9 | -99.9 to 999.9 | -99.9 to 999.9 | -99.9 to 999.9 | -99.9 to 999.9 | -99.9 to 999.9 | -99.9 to 999.9 | -99.9 to 999.9 | -99.9 to 999.9 | -99.9 to 999.9 | -99.9 to 999.9 | -99.9 to 999.9 | -99.9 to 999.9 | -99.9 to 999.9 | |
| | | LD3 | | | | | | | | | | | | | | | | | | | | | | | | |
| | | LD2 | | | | | | | | | | | | | | | | | | | | | | | | |
| | | LD1 | | | | | | | | | | | | | | | | | | | | | | | | i |
| | Item | l | IC28Gas pipe temperature | IC29 Gas pipe temperature | IC30 Gas pipe temperature | IC31 Gas pipe temperature | IC32 Gas pipe temperature | IC33 Gas pipe temperature | IC34 Gas pipe temperature | IC35 Gas pipe temperature | IC36 Gas pipe temperature | IC37 Gas pipe temperature | IC38 Gas pipe temperature | IC39 Gas pipe temperature | IC40 Gas pipe temperature | IC41 Gas pipe temperature | IC42 Gas pipe temperature | IC43 Gas pipe temperature | IC44 Gas pipe temperature | IC45 Gas pipe temperature | IC46 Gas pipe temperature | IC47 Gas pipe temperature | IC48 Gas pipe temperature | IC49 Gas pipe temperature | IC50 Gas pipe temperature | |
| Data on midool dimt system | SW4 (When SW6 - 10 is set to OFF) | 1234567890 | 0110010001 | 1110010001 | 0001010001 | 1001010001 | 0101010001 | 11010101001 | 0011010001 | 1011010001 | 0111010001 | 1111010001 | 0000110001 | 1000110001 | 0100110001 | 1100110001 | 0010110001 | 1010110001 | 0110110001 | 1110110001 | 0001110001 | 1001110001 | 0101110001 | 1101110001 | 0011110001 | |
| Data Oil | No. | <u> </u> | 220 | 551 | 552 | 553 | 554 | 255 | 929 | 222 | 258 | 559 | 260 | 561 | 562 | 563 | 564 | 565 | 999 | 292 | 268 | 699 | 220 | 571 | 572 | İ |

*1 A: The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerant system is displayed.

9 LED Status Indicators on the Outdoor Unit Circuit Board

| Ë |
|-----|
|)St |
| જ |
| ₹ |
| 3 |
| ō |
| 용 |
| .⊑ |
| Ë |
| ţ |
| Ħ |

| No. 1234567890 573 1011110001 574 0111110001 575 1010001001 576 0000001001 577 1000001001 578 0100001001 579 1100001001 580 0110001001 581 1010001001 583 1110001001 584 0001001001 585 1001001001 586 0101001001 | 990 1018H 1018H 1018H 1018H 1019H 101H 101 | LD1 | | - FD3 | Display LD4 LD9.9 to 999.9 | ay LD5 | 907 | LD7 | TD8 | Unit (A, B)*1 OC C | *1 0S | Remarks |
|---|--|-----|--|-------|------------------------------|--------|-----|-----|-----|--------------------------|----------|--------------------|
| | | TD1 | | - LD3 | -99.9 to | LD5 | PD9 | LD7 | FD8 | 20 4 | so | |
| | | | | | ot 6.99.9 to 9 | ט טטט | | | | c | | |
| | | | | | ot 6.66- | 999.9 | | | | מ | | The unit is [°C] |
| | | | | | | 6.666 | | | | | | |
| | | | | | -99.9 to 999.9 | 999.9 | | | | | | |
| | | | | | -99.9 to 999.9 | 6.666 | | | | | | |
| | | | | | -99.9 to 999.9 | 6.666 | | | | | | |
| | | | | | -99.9 to 999.9 | 6.666 | | | | | | |
| | | | | | -99.9 to 999.9 | 6.666 | | | | | | |
| | | | | | -99.9 to 999.9 | 999.9 | | | | | | |
| | | | | | -99.9 to 999.9 | 6.666 | | | | | | |
| | | | | | -99.9 to 999.9 | 6.666 | | | | | | |
| | | | | | -99.9 to 999.9 | 6.666 | | | | | | |
| | | | | | -99.9 to 999.9 | 999.9 | | | | | | |
| | | | | | -99.9 to 999.9 | 6.666 | | | | | | |
| | 001 IC14SH | | | | -99.9 to 999.9 | 6.666 | | | | | | |
| | 001 IC15SH | | | | -99.9 to 999.9 | 6.666 | | | | | | |
| 588 0011001001 | 001 IC16SH | | | | -99.9 to 999.9 | 6.666 | | | | | | |
| 1011001001 | 001 IC17SH | | | | -99.9 to 999.9 | 6.666 | | | | | | |
| 590 0111001001 | 001 IC18SH | | | | -99.9 to 999.9 | 6.666 | | | | | | |
| 591 1111001001 | 001 IC19SH | | | | -99.9 to 999.9 | 6.666 | | | | | | |
| 592 0000101001 | 101 IC20SH | | | | -99.9 to 999.9 | 6.666 | | | | | | |
| 1000101001 | 101 IC21SH | | | | -99.9 to 999.9 | 6.666 | | | | | | |
| 594 0100101001 | 101 IC22SH | | | | -99.9 to 999.9 | 6.666 | | | | | | |
| 1100101001 | 001 IC23SH | | | | -99.9 to 999.9 | 6.666 | | | | | | |
| 596 0010101001 | 101 IC24SH | | | | -99.9 to 999.9 | 999.9 | | | | | | |
| 597 1010101001 | 101 IC25SH | | | | -99.9 to 999.9 | 6.666 | | | | | | |
| 598 0110101001 | 101 IC26SH | | | | -99.9 to 999.9 | 6.666 | | | | | | |
| 1110101001 | 101 IC27SH | | | | -99.9 to 999.9 | 6.666 | | | | | | |

Data on indoor unit system

| טמום כי | Data on midool unit system | Stelli | | | | | | | | | | | |
|---------|-------------------------------------|--|-------------------|------------------|-----|--|-----------|-----|-----|-----|------------------|-----|--------------------|
| No. | SW4 (When SW6- 10 is set to OFF) | ltem | | | | Display | ılay | | | | Unit (A, B)*1 | ,*(| Remarks |
| | 1234567890 | T | LD1 | LD2 | FD3 | LD4 | FD5 | 9G7 | LD7 | FD8 | 00 | so | |
| 009 | 0001101001 | IC28SH | | | | -99.9 to 999.9 | 6.666 | | | | В | | The unit is [°C] |
| 601 | 1001101001 | IC29SH | | | | -99.9 to 999.9 | 6.666 | | | | | | |
| 602 | 0101101001 | IC30SH | | | | -99.9 to 999.9 | 6.666 | | | | | | |
| 603 | 11011011011 | IC31SH | | | | -99.9 to 999.9 | 6.666 | | | | | | |
| 604 | 0011101001 | IC32SH | | | | -99.9 to 999.9 | 6.666 | | | | | | |
| 909 | 1011101001 | IC33SH | | | | -99.9 to 999.9 | 6.666 | | | | | | |
| 909 | 0111101001 | IC34SH | | | | -99.9 to 999.9 | 6.999.9 | | | | | | |
| 209 | 1111101001 | IC35SH | | | | -99.9 to 999.9 | 6.666 | | | | | | |
| 809 | 0000011001 | IC36SH | | | | -99.9 to 999.9 | 6.999.9 | | | | | | |
| 609 | 1000011001 | IC37SH | | | | -99.9 to 999.9 | 6.999.9 | | | | | | |
| 610 | 0100011001 | IC38SH | | | | -99.9 to 999.9 | 6.666 | | | | | | |
| 611 | 1100011001 | IC39SH | | | | -99.9 to 999.9 | 6.666 | | | | | | |
| 612 | 0010011001 | IC40SH | | | | -99.9 to 999.9 | 6.666 | | | | | | |
| 613 | 1010011001 | IC41SH | | | | -99.9 to 999.9 | 6.666 | | | | | | |
| 614 | 0110011001 | IC42SH | | | | -99.9 to 999.9 | 6.999.9 | | | | | | |
| 615 | 1110011001 | IC43SH | | | | -99.9 to 999.9 | 6.666 | | | | | | |
| 616 | 0001011001 | IC44SH | | | | -99.9 to 999.9 | 6.666 | | | | | | |
| 617 | 10011011001 | IC45SH | | | | -99.9 to 999.9 | 6.666 | | | | | | |
| 618 | 0101011001 | IC46SH | | | | -99.9 to 999.9 | 6.666 | | | | | | |
| 619 | 1101011001 | IC47SH | | | | -99.9 to 999.9 | 6.666 | | | | | | |
| 620 | 0011011001 | IC48SH | | | | -99.9 to 999.9 | 6.666 | | | | | | |
| 621 | 1011011001 | IC49SH | | | | -99.9 to 999.9 | 6.666 | | | | | | |
| 622 | 0111011001 | IC50SH | | | | -99.9 to 999.9 | 6.666 | | | | | | |
| *1 A·Th | a condition of eith | *1 A: The condition of either OC or OS is displayed individually. B: The condition of th | T-dividually R. T | The condition of | 4 | Construction of motors that construction | 4ienlayed | | | | | | |

*1 A: The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerant system is displayed.

9 LED Status Indicators on the Outdoor Unit Circuit Board

| em |
|-----|
| yst |
| Ś |
| ፷ |
| ₹ |
| Ē |
| 8 |
| ŏ |
| ₽. |
| ⊑ |
| 0 |
| Þ |
| ā |

| | · [| | | | | | | | | | | | | |
|---------|--------------------------------------|--|-------------------|-------------------|---|-----------------|------------|-----|-----|-----|------------------|-------------|--------------------|--|
| No. | SW4 (When SW6 - 10 is set to OFF) | ltem | | | | Display | lay | | | | Unit (A, B)*1 | ** <u>`</u> | Remarks | |
| | 1234567890 | | LD1 | LD2 | FD3 | LD4 | FD5 | PD9 | LD7 | FD8 | 00 | SO | | |
| 623 | 1111011001 | IC1SC | | | | -99.9 to 999.9 | 6.666 | | | | В | | The unit is [°C] | |
| 624 | 0000111001 | IC2SC | | | | -99.9 to 999.9 | 6.666 | | | | | | | |
| 625 | 1000111001 | IC3SC | | | | -99.9 to 999.9 | 6.666 | | | | | | | |
| 626 | 0100111001 | IC4SC | | | | -99.9 to 999.9 | 6.666 | | | | | | | |
| 627 | 1100111001 | ICSSC | | | | -99.9 to 999.9 | 6.666 | | | | | | | |
| 628 | 0010111001 | Cesc | | | | -99.9 to 999.9 | 6.666 | | | | | | | |
| 629 | 1010111001 | IC7SC | | | | -99.9 to 999.9 | 6.666 | | | | | | | |
| 029 | 0110111001 | IC8SC | | | | -99.9 to 999.9 | 6.666 | | | | | | | |
| 631 | 1110111001 | 28621 | | | | -99.9 to 999.9 | 6.666 | | | | | | | |
| 632 | 0001111001 | IC10SC | | | | -99.9 to 999.9 | 6.666 | | | | | | | |
| 633 | 1001111001 | IC11SC | | | | -99.9 to 999.9 | 6.666 | | | | | | | |
| 634 | 0101111001 | IC12SC | | | | -99.9 to 999.9 | 6.666 | | | | | | | |
| 635 | 11011111001 | IC13SC | | | | -99.9 to 999.9 | 6.666 | | | | | | | |
| 929 | 0011111001 | IC14SC | | | | -99.9 to 999.9 | 6.666 | | | | | | | |
| 637 | 1011111001 | IC15SC | | | | -99.9 to 999.9 | 6.666 | | | | | | | |
| 638 | 0111111001 | IC16SC | | | | -99.9 to 999.9 | 6.666 | | | | | | | |
| 629 | 1111111001 | IC17SC | | | | -99.9 to 999.9 | 6.666 | | | | | | | |
| 640 | 0000000101 | IC18SC | | | | -99.9 to 999.9 | 6.666 | | | | | | | |
| 641 | 1000000101 | IC19SC | | | | -99.9 to 999.9 | 6.666 | | | | | | | |
| 642 | 0100000101 | IC20SC | | | | -99.9 to 999.9 | 6.666 | | | | | | | |
| 643 | 1100000101 | IC21SC | | | | -99.9 to 999.9 | 6.666 | | | | | | | |
| 644 | 0010000101 | IC22SC | | | | -99.9 to 999.9 | 6.666 | | | | | | | |
| 645 | 1010000101 | IC23SC | | | | -99.9 to 999.9 | 6.666 | | | | | | | |
| 646 | 0110000101 | IC24SC | | | | -99.9 to 999.9 | 6.666 | | | | | | | |
| 647 | 1110000101 | IC25SC | | | | -99.9 to 999.9 | 6.666 | | | | | | | |
| 648 | 0001000101 | IC26SC | | | | -99.9 to 999.9 | 6.666 | | | | | | | |
| 649 | 1001000101 | IC27SC | | | | -99.9 to 999.9 | 6.666 | | | | | | | |
| *1 A: T | he condition of eith | *1 A. The condition of either OC or OS is displayed individually. B. The condition of th | ndividually. B: T | he condition of t | the entire refrigerant system is displayed. | ant system is o | lisplayed. | | | | | | | |

Data on indoor unit system

| מפם | Data on midool unit system | | | | | | | | | | | | |
|---------|-------------------------------------|---|-------------------|------------------|-----|---|----------------|-----|-----|-----|------------------|-----|--------------------|
| No. | SW4 (When SW6- 10 is set to OFF) | Item | | | | Disk | Display | | | | Unit (A, B)*1 | **(| Remarks |
| | 1234567890 | | LD1 | LD2 | FD3 | LD4 | FD5 | PDP | LD7 | LD8 | 00 | SO | |
| 099 | 0101000101 | IC28SC | | | | -99.9 tc | -99.9 to 999.9 | | | | В | | The unit is [°C] |
| 651 | 1101000101 | IC29SC | | | | -99.9 tc | -99.9 to 999.9 | | | | | | |
| 652 | 0011000101 | IC30SC | | | | -99.9 tc | -99.9 to 999.9 | | | | | | |
| 653 | 1011000101 | IC31SC | | | | -99.9 tc | -99.9 to 999.9 | | | | | | |
| 654 | 0111000101 | IC32SC | | | | -99.9 tc | -99.9 to 999.9 | | | | | | |
| 655 | 1111000101 | IC33SC | | | | -99.9 tc | -99.9 to 999.9 | | | | | | |
| 929 | 0000100101 | IC34SC | | | | -99.9 tc | -99.9 to 999.9 | | | | | | |
| 259 | 1000100101 | IC35SC | | | | -99.9 tc | -99.9 to 999.9 | | | | | | |
| 859 | 0100100101 | IC36SC | | | | -99.9 tc | -99.9 to 999.9 | | | | | | |
| 629 | 1100100101 | IC37SC | | | | -99.9 tc | -99.9 to 999.9 | | | | | | |
| 099 | 0010100101 | IC38SC | | | | -99.9 tc | -99.9 to 999.9 | | | | | | |
| 661 | 101010101 | IC39SC | | | | -99.9 tc | -99.9 to 999.9 | | | | | | |
| 662 | 0110100101 | IC40SC | | | | -99.9 tc | -99.9 to 999.9 | | | | | | |
| 663 | 1110100101 | IC41SC | | | | -99.9 tc | -99.9 to 999.9 | | | | | | |
| 664 | 0001100101 | IC42SC | | | | -99.9 tc | -99.9 to 999.9 | | | | | | |
| 999 | 1001100101 | IC43SC | | | | -99.9 tc | -99.9 to 999.9 | | | | | | |
| 999 | 0101100101 | IC44SC | | | | -99.9 tc | -99.9 to 999.9 | | | | | | |
| 299 | 1101100101 | IC45SC | | | | -99.9 tc | -99.9 to 999.9 | | | | | | |
| 899 | 0011100101 | IC46SC | | | | -99.9 tc | -99.9 to 999.9 | | | | | | |
| 699 | 1011100101 | IC47SC | | | | -99.9 tc | -99.9 to 999.9 | | | | | | |
| 029 | 0111100101 | IC48SC | | | | -99.9 tc | -99.9 to 999.9 | | | | | | |
| 671 | 1111100101 | IC49SC | | | | -99.9 tc | -99.9 to 999.9 | | | | | | |
| 672 | 0000010101 | IC50SC | | | | -99.9 tc | -99.9 to 999.9 | | | | | | |
| *1 A. T | die of acition of | *1 A: The condition of either OC or OS is displayed individually. B: The condition of t | T -B VIIchidivibe | The condition of | 9 | beyolasib si metsys tacreprinter entire | dienloydd | | | | | | |

*1 A: The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerant system is displayed.

9 LED Status Indicators on the Outdoor Unit Circuit Board

Setting data

| 2304 | Setting data | | | | | | | | | | | | |
|----------|---------------------------------|--|---------|-----|---|--|----------------|-----|-----|-----|-------------------------------|-------------|--|
| o No. | SW4 (When SW6-10 is set to OFF) | ltem | | | | Display | olay | | | | Unit (A, B) ^{* 1} | it ;)* 1 | Remarks |
| | 1234567890 | | LD1 | TD2 | EQ7 | LD4 | FD5 | 9Q7 | LD7 | FD8 | 00 | SO | |
| 929 | 6 0010010101 | INV board S/W version | | | | 0.00 to | 0.00 to 99.99 | • | | | ∢ | Α | |
| 629 | 1110010101 | Fan board (address 5) S/W version | | | | 0.00 to 99.99 | 66.66 | | | | ∢ | ٨ | |
| 089 | 30 0001010101 | Fan board (address 6) S/W version | | | | 0.00 to 99.99 | 66.66 | | | | ∢ | ٧ | |
| 889 | 1010110101 | Current time | | | | 00:00 to 23:59 | 5 23:59 | | | | Α | Α | Hour: minute |
| 689 | 1000110101 | Current time -2 | | | | 00.00 to 99.12/1 to 31 | .12/1 to 31 | | | | | | Year and month, and date alternate display |
| 069 | 0100110101 | Time of error detection 1 | | | | 00:00 to | 00:00 to 23:59 | | | | | | Hour: minute |
| 691 | 1100110101 | Time of error detection 1-2 | | | | 00.00 to 99.12/1 to 31 | .12/1 to 31 | | | | | | Year and month, and date alternate display |
| 692 | 12 0010110101 | Time of error detection 2 | | | | 00:00 to 23:59 | 23:59 | | | | | | Hour: minute |
| 693 | 1010110101 | Time of error detection 2-2 | | | | 00.00 to 99.12/1 to 31 | .12/1 to 31 | | | | | | Year and month, and date alternate display |
| 51 - | 0110110101 | Time of error detection 3 | | | | 00:00 to | 00:00 to 23:59 | | | | | | Hour: minute |
| 969 | 1110110101 | Time of error detection 3-2 | | | | 00.00 to 99.12/1 to 31 | .12/1 to 31 | | | | | | Year and month, and date alternate display |
| 969 | 0001110101 | Time of error detection 4 | | | | 00:00 to | 00:00 to 23:59 | | | | | | Hour: minute |
| 269 | 1001110101 | Time of error detection 4-2 | | | | 00.00 to 99.12/1 to 31 | .12/1 to 31 | | | | | | Year and month, and date alternate display |
| 869 | 18 0101110101 | Time of error detection 5 | | | | 00:00 to | 00:00 to 23:59 | | | | | | Hour: minute |
| 669 | 11011110101 | Time of error detection 5-2 | | | | 00.00 to 99.12/1 to 31 | .12/1 to 31 | | | | | | Year and month, and date alternate display |
| 700 | 0011110101 | Time of error detection 6 | | | | 00:00 to | 00:00 to 23:59 | | | | | | Hour: minute |
| 701 | 10111110101 | Time of error detection 6-2 | | | | 00.00 to 99.12/1 to 31 | .12/1 to 31 | | | | | | Year and month, and date alternate display |
| * | . The paralities of eith | t to moitibance and to the contract of the con | The The | | Lovelacite of material transcriptor estate of | 0; 0; 0; 0; 0; 0; 0; 0; 0; 0; 0; 0; 0; 0 | 1000 | | | | | | |

*1 A: The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerant system is displayed.

| ٠, | u |
|-----|---|
| | _ |
| (| O |
| 7 | |
| - 1 | _ |
| 7 | |
| 7 | = |
| .: | |
| | - |
| • | _ |
| • | υ |
| " | ń |
| | |

| F | | | | | | | | | | | | | |
|--------|-------------------------------------|---|------------------|-----------------|---|-----------------|------------------------|-----|-----|-----|------------------|-----------|--|
| o N | SW4 (When SW6- 10 is set to OFF) | Item | | | | Dis | Display | | | | Unit (A, B)*1 | #*(: 1 | Remarks |
| | 1234567890 | | LD1 | LD2 | FD3 | LD4 | FD5 | 907 | LD7 | FD8 | 00 | SO | |
| 702 | 0111110101 | Time of error detection 7 | | | | 00:00 | 00:00 to 23:59 | | | | ∢ | 4 | Hour: minute |
| 703 | 1111110101 | Time of error detection 7-2 | | | | 00.00 to 9 | 00.00 to 99.12/1 to 31 | | | | | | Year and month, and date alternate display |
| 704 | 0000001101 | Time of error detection 8 | | | | 00:00 | 00:00 to 23:59 | | | | | | Hour: minute |
| 202 | 1000001101 | Time of error detection 8-2 | | | | 00.00 to 9 | 00.00 to 99.12/1 to 31 | | | | | | Year and month, and date alternate display |
| 902 | 0100001101 | Time of error detection 9 | | | | 00:00 | 00:00 to 23:59 | | | | | | Hour: minute |
| 707 | 1100001101 | Time of error detection 9-2 | | | | 00.00 to 9 | 00.00 to 99.12/1 to 31 | | | | | | Year and month, and date alternate display |
| 208 | 0010001101 | Time of error detection 10 | | | | 00:00 | 00:00 to 23:59 | | | | | | Hour: minute |
| 602 | 1010001101 | Time of error detection 10-2 | | | | 00.00 to 9 | 00.00 to 99.12/1 to 31 | | | | | | Year and month, and date alternate display |
| 710 | 0110001101 | Time of last data backup be- fore error | | | | 00:00 | 00:00 to 23:59 | | | | | | Hour: minute |
| 711 | 1110001101 | Time of last data backup before error -2 | | | | 00.00 to 9 | 00.00 to 99.12/1 to 31 | | | | | | Year and month, and date alternate display |
| A: The | s condition of either | *1 A: The condition of either OC or OS is displayed individually. B: The condition of the | ually. B: The co | ondition of the | entire refrigerant system is displayed. | nt system is di | splaved. | | | | | | |

9 LED Status Indicators on the Outdoor Unit Circuit Board

| tem |
|------|
| syst |
| ij |
| ٥٦ |
| ingo |
| 9 |
| Data |
| _ |

| | • | | | | | | | | | | | | | Ī |
|----------|--------------------------------------|---|-------------------|-------------------|---------------------|---------------|------------|---------|-----|-----|------------------|-------------|------------------|---|
| No. | SW4 (When SW6 - 10 is set to OFF) | Item | | | | Display | olay | | | | Unit (A, B)*1 | #* <u>`</u> | Remarks | |
| | 1234567890 | | LD1 | LD2 | FD3 | LD4 | FD5 | PDP PDP | LD7 | FD8 | 00 | SO | | |
| 714 | 0101001101 | IC1 LEV opening | | | | 0000 to 9999 | 6666 | | | | В | | Fully open: 2000 | |
| 715 | 1101001101 | IC2 LEV opening | | | | 0000 to 9999 | 6666 | | | | | | | |
| 716 | 0011001101 | IC3 LEV opening | | | | 0000 to 9999 | 6666 | | | | | | | |
| 717 | 1011001101 | IC4 LEV opening | | | | 0000 to 9999 | 6666 | | | | | | | |
| 718 | 0111001101 | IC5 LEV opening | | | | 0000 to 9999 | 6666 | | | | | | | |
| 719 | 1111001101 | IC6 LEV opening | | | | 0000 to 9999 | 6666 | | | | | | | |
| 720 | 0000101101 | IC7 LEV opening | | | | 0000 to 9999 | 6666 | | | | | | | |
| 721 | 1000101101 | IC8 LEV opening | | | | 0000 to 9999 | 6666 | | | | | | | |
| 722 | 0100101101 | IC9 LEV opening | | | | 0000 to 9999 | 6666 | | | | | | | |
| 723 | 1100101101 | IC10 LEV opening | | | | 0000 to 9999 | 6666 | | | | | | | |
| 724 | 0010101101 | IC11 LEV opening | | | | 0000 to 9999 | 6666 | | | | | | | |
| 725 | 1010101101 | IC12 LEV opening | | | | 0000 to 9999 | 6666 | | | | | | | |
| 726 | 0110101101 | IC13 LEV opening | | | | 0000 to 9999 | 6666 | | | | | | | |
| 727 | 1110101101 | IC14 LEV opening | | | | 0000 to 9999 | 6666 | | | | | | | |
| 728 | 0001101101 | IC15 LEV opening | | | | 0000 to 9999 | 6666 (| | | | | | | |
| 729 | 1001101101 | IC16 LEV opening | | | | 0000 to 9999 | 6666 | | | | | | | |
| 730 | 0101101101 | IC17 LEV opening | | | | 0000 to 9999 | 6666 | | | | | | | |
| 731 | 1101101101 | IC18 LEV opening | | | | 0000 to 9999 | 6666 | | | | | | | |
| 732 | 0011101101 | IC19 LEV opening | | | | 0000 to 9999 | 6666 | | | | | | | |
| 733 | 1011101101 | IC20 LEV opening | | | | 0000 to 9999 | 6666 | | | | | | | |
| 734 | 0111101101 | IC21 LEV opening | | | | 0000 to 9999 | 6666 (| | | | | | | |
| 735 | 1111101101 | IC22 LEV opening | | | | 0000 to 9999 | 6666 | | | | | | | |
| 736 | 0000011101 | IC23 LEV opening | | | | 0000 to 9999 | 6666 | | | | | | | |
| 737 | 1000011101 | IC24 LEV opening | | | | 0000 to 9999 | 6666 | | | | | | | |
| 738 | 0100011101 | IC25 LEV opening | | | | 0000 to 9999 | 6666 | | | | | | | |
| 739 | 1100011101 | IC26 LEV opening | | | | 0000 to 9999 | 6666 | | | | | | | |
| 740 | 0010011101 | IC27 LEV opening | | | | 0000 to 9999 | 6666 | | | | | | | |
| *1 A: Th | ne condition of eitl | *1 A: The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerant system is displayed. | ndividually. B: T | he condition of t | the entire refriger | ant system is | displayed. | | | | | | | |

HWE23040 - 353 -

Data on indoor unit system

| No. | SW4 (When SW6 - 10 is set to OFF) | ltem | | | Dis | Display | | | Unit (A, B) ^{* 1} | it)* 1 | Remarks | |
|----------|--------------------------------------|--|----------------------------|------------|--|--|-------|-----|-------------------------------|------------|------------------|--|
| | 1234567890 | | LD1 | LD2 | LD3 LD4 | 907 507 | LD7 | LD8 | 00 | SO | | |
| 741 | 1010011101 | IC28 LEV opening | | | 0000 | 0000 to 9999 | | | В | | Fully open: 2000 | |
| 742 | 0110011101 | IC29 LEV opening | | | 1 0000 | 0000 to 9999 | | | | | | |
| 743 | 1110011101 | IC30 LEV opening | | | 0000 | 0000 to 9999 | | | | | | |
| 744 | 0001011101 | IC31 LEV opening | | | 0000 | 0000 to 9999 | | | | | | |
| 745 | 1001011101 | IC32 LEV opening | | | 0000 | 0000 to 9999 | | | | | | |
| 746 | 0101011101 | IC33 LEV opening | | | 0000 | 0000 to 9999 | | | | | | |
| 747 | 1101011101 | IC34 LEV opening | | | 0000 | 0000 to 9999 | | | | | | |
| 748 | 0011011101 | IC35 LEV opening | | | 0000 | 0000 to 9999 | | | | | | |
| 749 | 1011011101 | IC36 LEV opening | | | 0000 | 0000 to 9999 | | | | | | |
| 750 | 0111011101 | IC37 LEV opening | | | 0000 | 0000 to 9999 | | | | | | |
| 751 | 1111011101 | IC38 LEV opening | | | 0000 | 0000 to 9999 | | | | | | |
| 752 | 0000111101 | IC39 LEV opening | | | 0000 | 0000 to 9999 | | | | | | |
| 753 | 1000111101 | IC40 LEV opening | | | 0000 | 0000 to 9999 | | | | | | |
| 754 | 0100111101 | IC41 LEV opening | | | 0000 | 0000 to 9999 | | | | | | |
| 755 | 1100111101 | IC42 LEV opening | | | 10000 | 0000 to 9999 | | | | | | |
| 756 | 0010111101 | IC43 LEV opening | | | 1 0000 | 0000 to 9999 | | | | | | |
| 757 | 1010111101 | IC44 LEV opening | | | 0000 | 0000 to 9999 | | | | | | |
| 758 | 0110111101 | IC45 LEV opening | | | 0000 | 0000 to 9999 | | | | | | |
| 759 | 1110111101 | IC46 LEV opening | | | 1 0000 | 0000 to 9999 | | | | | | |
| 092 | 0001111101 | IC47 LEV opening | | | 0000 | 0000 to 9999 | | | | | | |
| 761 | 1001111101 | IC48 LEV opening | | | 1 0000 | 0000 to 9999 | | | | | | |
| 762 | 0101111101 | IC49 LEV opening | | | 0000 | 0000 to 9999 | | | | | | |
| 763 | 1101111101 | IC50 LEV opening | | | 0000 | 0000 to 9999 | | | | | | |
| 764 | 0011111101 | IC1 Operation mode | | | | | | | В | | | |
| 292 | 1011111101 | IC2 Operation mode | | | | | | | | | | |
| 992 | 0111111101 | IC3Operation mode | | 0000 : Sto | p 0001 : Ventilation 0002 | : Stop 0001 : Ventilation 0002 : Cooling 0003 : Heating 0004 : Dry | : Dry | | | | | |
| 191 | 1111111101 | IC4 Operation mode | | | | | | | | | | |
| 892 | 000000011 | IC5 Operation mode | | | | | | | | | | |
| 1 A· The | e condition of eith | 1 A: The condition of either OC or OS is displayed individually. B: The condition of | dividually B. ⁷ | | the entire refrigerant system is displayed | disnlaved | | | | | | |

*1 A: The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerant system is displayed.

9 LED Status Indicators on the Outdoor Unit Circuit Board

| Data | Data on indoor unit system | stem | | | | | | | | | | | |
|-------|--------------------------------------|---|--------------------|-----------------|--------------------|--|----------------|----------------|-----|-----|-------------------------------|-------|---------|
| Š | SW4 (When SW6 - 10 is set to OFF) | ltem | | | | Display | lay | | | | Unit (A, B) ^{* 1} | s)* 1 | Remarks |
| | 1234567890 | | LD1 | LD2 | LD3 | LD4 | LD5 | PDP | LD7 | FD8 | 00 | SO | |
| 769 | 1000000011 | IC6 Operation mode | | | | | | | | | В | | |
| 770 | 0100000011 | IC7 Operation mode | | | | | | | | | | | |
| 771 | 1100000011 | IC8 Operation mode | | | | | | | | | | | |
| 772 | 001000011 | IC9 Operation mode | | | | | | | | | | | |
| 773 | 1010000011 | IC10 Operation mode | | | | | | | | | | | |
| 774 | 0110000011 | IC11 Operation mode | | | | | | | | | | | |
| 775 | 1110000011 | IC12 Operation mode | | | | | | | | | | | |
| 776 | 0001000011 | IC13 Operation mode | | | | | | | | | | | |
| 777 | 1001000011 | IC14 Operation mode | | | | | | | | | | | |
| 778 | 0101000011 | IC15 Operation mode | | | | | | | | | | | |
| 779 | 1101000011 | IC16 Operation mode | | | | | | | | | | | |
| 780 | 0011000011 | IC17 Operation mode | | | | | | | | | | | |
| 781 | 1011000011 | IC18 Operation mode | | | | | | | | | | | |
| 782 | 0111000011 | IC19 Operation mode | | 0000 | Stop 0001 - V | Stan 0001 - Ventilation 0002 - Cooling 0003 - Heating 0004 - Day | . Sooling 0003 | Heating 0004 | 2 | | | | |
| 783 | 1111000011 | IC20 Operation mode | | | . 1000 dois | | | . 1681119 0004 | à | | | | |
| 784 | 0000100011 | IC21 Operation mode | | | | | | | | | | | |
| 785 | 1000100011 | IC22 Operation mode | | | | | | | | | | | |
| 786 | 0100100011 | IC23 Operation mode | | | | | | | | | | | |
| 787 | 110010011 | IC24 Operation mode | | | | | | | | | | | |
| 788 | 0010100011 | IC25 Operation mode | | | | | | | | | | | |
| 789 | 1010100011 | IC26 Operation mode | | | | | | | | | | | |
| 790 | 0110100011 | IC27 Operation mode | | | | | | | | | | | |
| 791 | 1110100011 | IC28 Operation mode | | | | | | | | | | | |
| 792 | 0001100011 | IC29 Operation mode | | | | | | | | | | | |
| 793 | 10001100011 | IC30 Operation mode | | | | | | | | | | | |
| 794 | 0101100011 | IC31 Operation mode | | | | | | | | | | | |
| 795 | 11011100011 | IC32 Operation mode | | | | | | | | | | | |
| 796 | 0011100011 | IC33 Operation mode | | | | | | | | | | | |
| *1 A: | The condition of eith | *1 A. The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerant system is displayed. | ndividually. B: Ti | he condition of | the entire refrige | rant system is c | lisplayed. | | | | | | |

Data on indoor unit system

| 5 | ć | | | | | | | | | | | | |
|---------|-------------------------------------|---|-------------------|-------------------|------------------|--|-----------------|----------------|-----|-----|-------------------------------|----|--------------------------|
| No. | SW4 (When SW6- 10 is set to OFF) | Item | | | | Dis | Display | | | | Unit (A, B) ^{* 1} | it | Remarks |
| | 1234567890 | | LD1 | LD2 | FD3 | LD4 | FD5 | PDP TD9 | LD7 | FD8 | 00 | SO | |
| 797 | 1011100011 | IC34 Operation mode | | | | | | | | | В | | |
| 798 | 0111100011 | IC35 Operation mode | | | | | | | | | | | |
| 662 | 1111100011 | IC36 Operation mode | | | | | | | | | | | |
| 800 | 0000010011 | IC37 Operation mode | | | | | | | | | | | |
| 801 | 1000010011 | IC38 Operation mode | | | | | | | | | | | |
| 802 | 0100010011 | IC39 Operation mode | | | | | | | | | | | |
| 803 | 1100010011 | IC40 Operation mode | | | | | | | | | | | |
| 804 | 0010010011 | IC41 Operation mode | | | | | | | | | | | |
| 805 | 1010010011 | IC42 Operation mode | | 0000 | : Stop 0001 : | : Stop 0001 : Ventilation 0002 : Cooling 0003 : Heating 0004 : Dry | ?: Cooling 0003 | : Heating 0004 | Dry | | | | |
| 908 | 0110010011 | IC43 Operation mode | | | | | | | | | | | |
| 807 | 1110010011 | IC44 Operation mode | | | | | | | | | | | |
| 808 | 0001010011 | IC45 Operation mode | | | | | | | | | | | |
| 808 | 100101011 | IC46 Operation mode | | | | | | | | | | | |
| 810 | 0101010011 | IC47 Operation mode | | | | | | | | | | | |
| 811 | 110101011 | IC48 Operation mode | | | | | | | | | | | |
| 812 | 0011010011 | IC49 Operation mode | | | | | | | | | | | |
| 813 | 1011010011 | IC50 Operation mode | | | | | | | | | | | |
| 814 | 0111010011 | IC1 filter | | | | , 0000 | 0000 to 9999 | | | | В | | Hours since last mainte- |
| 815 | 1111010111 | IC2 filter | | | | 0000 | 0000 to 9999 | | | | | | nance [n] |
| 816 | 0000110011 | IC3 filter | | | | 0000 | 0000 to 9999 | | | | | | |
| 817 | 1000110011 | IC4 filter | | | | 0000 | 0000 to 9999 | | | | | | |
| 818 | 0100110011 | IC5 filter | | | | 0000 | 0000 to 9999 | | | | | | |
| 819 | 1100110011 | IC6 filter | | | | 1 0000 | 0000 to 9999 | | | | | | |
| 820 | 0010110011 | IC7 filter | | | | , 0000 | 0000 to 9999 | | | | | | |
| 821 | 1010110011 | IC8 filter | | | | , 0000 | 0000 to 9999 | | | | | | |
| 822 | 0110110011 | IC9 filter | | | | 0000 | 0000 to 9999 | | | | | | |
| 823 | 1110110011 | IC10 filter | | | | 0000 | 0000 to 9999 | | | | | | |
| 824 | 0001110011 | IC11 filter | | | | 0000 | 0000 to 9999 | | | | | | |
| 1 A: Th | e condition of eith | 1 A: The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerant system is displayed | ndividually. B: T | he condition of t | he entire refric | gerant system is | displayed. | | | | | | |

*1 A: The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerant system is displayed.

9 LED Status Indicators on the Outdoor Unit Circuit Board

| Cata | para on macor ann system | arenii - | | | | | | | | | | | |
|---------|-------------------------------------|---|-----------------|------------------|--------------------|---|-----------|-----|-----|-----|-------------------------------|------------|--------------------------|
| o N | SW4 (When SW6- 10 is set to OFF) | ltem | | | | Display | olay | | | | Unit (A, B) ^{* 1} | it)* 1 | Remarks |
| | 1234567890 | | LD1 | TD5 | FD3 | LD4 | FD5 | PD9 | LD7 | PD8 | 00 | SO | |
| 825 | 1001110011 | IC12 filter | | | | 0000 to 9999 | 6666 | • | | | В | | Hours since last mainte- |
| 826 | 0101110011 | IC13 filter | | | | 0000 to 9999 | 6666 | | | | | | nance [n] |
| 827 | 1101110011 | IC14 filter | | | | 0000 to 9999 | 6666 | | | | | | |
| 828 | 0011110011 | IC15 filter | | | | 0000 to 9999 | 6666 | | | | | | |
| 829 | 1011110011 | IC16 filter | | | | 0000 to 9999 | 6666 | | | | | | |
| 830 | 0111110011 | IC17 filter | | | | 0000 to 9999 | 6666 | | | | | | |
| 831 | 1111110011 | IC18 filter | | | | 0000 to 9999 | 6666 | | | | | | |
| 832 | 0000001011 | IC19 filter | | | | 0000 to 9999 | 6666 | | | | | | |
| 833 | 100000111 | IC20 filter | | | | 0000 to 9999 | 6666 | | | | | | |
| 834 | 0100001011 | IC21 filter | | | | 0000 to 9999 | 6666 | | | | | | |
| 835 | 110000111 | IC22 filter | | | | 0000 to 9999 | 6666 | | | | | | |
| 836 | 0010001011 | IC23 filter | | | | 0000 to 9999 | 6666 | | | | | | |
| 837 | 1010001011 | IC24 filter | | | | 0000 to 9999 | 6666 | | | | | | |
| 838 | 0110001011 | IC25 filter | | | | 0000 to 9999 | 6666 | | | | | | |
| 839 | 111000111 | IC26 filter | | | | 0000 to 9999 | 6666 | | | | | | |
| 840 | 0001001011 | IC27 filter | | | | 0000 to 9999 | 6666 | | | | | | |
| 841 | 1001001011 | IC28 filter | | | | 0000 to 9999 | 6666 | | | | | | |
| 842 | 0101001011 | IC29 filter | | | | 0000 to 9999 | 6666 | | | | | | |
| 843 | 1101001011 | IC30 filter | | | | 0000 to 9999 | 6666 | | | | | | |
| 844 | 0011001011 | IC31 filter | | | | 0000 to 9999 | 6666 | | | | | | |
| 845 | 1011001111 | IC32 filter | | | | 0000 to 9999 | 6666 | | | | | | |
| 846 | 0111001001 | IC33 filter | | | | 0000 to 9999 | 6666 | | | | | | |
| 847 | 1111001011 | IC34 filter | | | | 0000 to 9999 | 6666 | | | | | | |
| 848 | 0000101011 | IC35 filter | | | | 0000 to 9999 | 6666 | | | | | | |
| 849 | 1000101011 | IC36 filter | | | | 0000 to 9999 | 6666 | | | | | | |
| 850 | 0100101011 | IC37 filter | | | | 0000 to 9999 | 6666 | | | | | | |
| 851 | 1100101011 | IC38 filter | | | | 0000 to 9999 | 6666 | | | | | | |
| 852 | 0010101011 | IC39 filter | | | | 0000 to 9999 | 6666 | | | | | | |
| *1 A: T | he condition of eith | *1 A: The condition of either OC or OS is displayed individually. B: The condition of | ndividually. B: | The condition of | the entire refrige | the entire refrigerant system is displayed. | displayed | | | | | | |

Data on indoor unit system

| | | | ainte- | | | | | | | | | | |
|---|--------------------------------------|--------------|--------------------------|--------------|--------------|--------------|--------------|--------------|--------------|--------------|--------------|--------------|--------------|
| | Remarks | | Hours since last mainte- | nance [n] | | | | | | | | | |
| | nit 3)* 1 | SO | | | | | | | | | | | |
| | Unit (A, B)*1 | 00 | В | | | | | | | | | | |
| | | 8Q7 | | | | | | | | | | | |
| | | ZO7 | | | | | | | | | | | |
| | | 9 0 7 | | | | | | | | | | | |
| | olay | FD5 | 0000 to 9999 | 0000 to 9999 | 6666 | 6666 | 0000 to 9999 | 6666 | 0000 to 9999 | 6666 | 6666 | 6666 | 6666 |
| | Display | LD4 | 0000 tc | 0000 tc | 0000 to 9999 | 0000 to 9999 | 0000 tc | 0000 to 9999 | 0000 tc | 0000 to 9999 | 0000 to 9999 | 0000 to 9999 | 0000 to 9999 |
| | | EQ7 | | | | | | | | | | | |
| | | LD2 | | | | | | | | | | | |
| | | LD1 | | | | | | | | | | | |
| | Item | | IC40 filter | IC41 filter | IC42 filter | IC43 filter | IC44 filter | IC45 filter | IC46 filter | IC47 filter | IC48 filter | IC49 filter | IC50 filter |
| • | SW4 (When SW6 - 10 is set to OFF) | 1234567890 | 1010101011 | 0110101011 | 1110101011 | 0001101011 | 100110111 | 0101101011 | 110110111 | 0011101011 | 1011110111 | 0111101011 | 1111101011 |
| | ON | | 853 | 854 | 855 | 856 | 857 | 858 | 829 | 860 | 861 | 862 | 863 |

^{*1} A: The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerant system is displayed.

Other types of data

| Remarks | | The unit is [A] | | The unit is [deg] | The unit is [time] | | The unit is [time] | |
|-------------------------------------|--------------|-----------------------------------|--|---------------------------------|--------------------------------|------|--|--|
| Unit A, B)*1 | SO | ⋖ | ٧ | ٧ | ⋖ | ∢ | ٧ | 885 1010111011 Fan board (address 6) A A A |
| Unit (A, B)*1 | 20 | ∢ | ٧ | ٧ | ∢ | ∢ | ٧ | ٧ |
| | 8 0 7 | | | | | | | 1010111011 Fan board (address 6) 0 to 254 A A |
| | LD7 | | | | | | | |
| | 9GT | | | | | | | |
| Display | SQ1 | -99.9 to 999.9 | -99.9 to 999.9 | -99.9 to 999.9 | 0 to 254 | 254 | 254 | 254 |
| Dis | LD4 | -99.9 to | -99.9 to | -99.9 to | 0 to | 0 to | 0 to | 1010111011 Fan board (address 6) 0 to 254 A |
| | EQ7 | | | | | | | |
| | TD2 | | | | | | | |
| | LD1 | | | | | | | |
| ltem | | U-phase current effective value 1 | W-phase current effec- tive value 1 | Power factor phase an- gle 1 | Control board Reset counter | | Fan board (address 5) reset counter | Fan board (address 6) reset counter |
| SW4 (When SW6- 10 is set to OFF) | 1234567890 | 1110011011 | 0001011011 | 1001011011 | 0000111011 | | Keset counter Keset counter 0 to 254 A A 1010111011 Fan board (address 6) 0 to 254 A A 1010111011 Fan board (address 6) 0 to 254 A A | 1010111011 |
| O | | 871 | 872 | 873 | 880 | 881 | 884 | 0010111011 reset counter |

*1 A: The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerant system is displayed.

