

TECHNICAL & SERVICE MANUAL

<Outdoor unit>
[Model Name]

[Service Ref.]

PUMY-P36NKMU4

PUMY-P48NKMU4

PUMY-P60NKMU4

PUMY-HP36NKMU2

PUMY-HP42NKMU2


PUMY-HP48NKMU2

PUMY-P36NKMU4
PUMY-P48NKMU4
PUMY-P60NKMU4
PUMY-HP36NKMU2
PUMY-HP42NKMU2
PUMY-HP48NKMU2

Revision:

- Some descriptions have been revised in REVISED EDITION-D.

OCH811C is void.



CONTENTS

1. SAFETY PRECAUTION	2
2. OVERVIEW OF UNITS	5
3. SPECIFICATIONS	11
4. DATA	14
5. OUTLINES AND DIMENSIONS	36
6. WIRING DIAGRAM	37
7. NECESSARY CONDITIONS FOR SYSTEM CONSTRUCTION	40
8. TROUBLESHOOTING	55
9. ELECTRICAL WIRING	133
10. REFRIGERANT PIPING TASKS	139
11. DISASSEMBLY PROCEDURE	147
12. REMOTE CONTROLLER	168

PARTS CATALOG (OCB811)

1-1. ALWAYS OBSERVE FOR SAFETY

Before obtaining access to terminal, all supply circuit must be disconnected.

Preparation before the repair service

- Prepare the proper tools.
- Prepare the proper protectors.
- Provide adequate ventilation.
- After stopping the operation of the air conditioner, turn off the power-supply breaker.
- Discharge the condenser before the work involving the electric parts.

Precautions during the repair service

- Do not perform the work involving the electric parts with wet hands.
- Do not pour water into the electric parts.
- Do not touch the refrigerant.
- Do not touch the hot or cold areas in the refrigerating cycle.
- When the repair or the inspection of the circuit needs to be done without turning off the power, exercise great caution not to touch the live parts.
- When opening or closing the valve below freezing temperatures, refrigerant may spurt out from the gap between the valve stem and the valve body, resulting in injuries.

1-2. CAUTIONS RELATED TO NEW REFRIGERANT

Cautions for units utilizing refrigerant R410A

Use new refrigerant pipes.

Avoid using thin pipes.

Make sure that the inside and outside of refrigerant piping is clean and it has no contaminants such as sulfur, oxides, dirt, shaving particles, etc., which are hazard to refrigerant cycle. In addition, use pipes with specified thickness.

Contamination inside refrigerant piping can cause deterioration of refrigerant oil, etc.

Follow the instructions below to prevent abrasive components contained in sandpaper and cutting tools from entering the refrigerant circuit because those components can cause failures of the compressor and valves.

- To deburr pipes, use a reamer or other deburring tools, not sandpaper.
- To cut pipes, use a pipe cutter, not a grinder or other tools that use abrasive materials.
- When cutting or deburring pipes, do not allow cutting chips or other foreign matters to enter the pipes.
- If cutting chips or other foreign matters enter pipes, wipe them off the inside of the pipes.

Store the piping indoors, and keep both ends of the piping sealed until just before brazing. (Leave elbow joints, etc. in their packaging.)

If dirt, dust or moisture enters into refrigerant cycle, that can cause deterioration of refrigerant oil or malfunction of compressor.

Use a vacuum pump with a reverse flow check valve.

Vacuum pump oil may flow back into refrigerant cycle and that can cause deterioration of refrigerant oil, etc.

Use the following tools specifically designed for use with R410A refrigerant.

The following tools are necessary to use R410A refrigerant.

Tools for R410A	
Gauge manifold	Flare tool
Charge hose	Size adjustment gauge
Gas leak detector	Vacuum pump adaptor
Torque wrench	Electronic refrigerant charging scale

Handle tools with care.

If dirt, dust or moisture enters into refrigerant cycle, that can cause deterioration of refrigerant oil or malfunction of compressor.

Do not use a charging cylinder.

If a charging cylinder is used, the composition of refrigerant will change and the efficiency will be lowered.

Ventilate the room if refrigerant leaks during operation. If refrigerant comes into contact with a flame, poisonous gases will be released.

The refrigerant oil applied to flare and flange connections must be ester oil, ether oil or alkylbenzene oil in a small amount.

If large amount of mineral oil enters, that can cause deterioration of refrigerant oil, etc.

Charge refrigerant from liquid phase of gas cylinder.

If the refrigerant is charged from gas phase, composition change may occur in refrigerant and the efficiency will be lowered.

Do not use refrigerant other than R410A.

If other refrigerant (R22, etc.) is used, chlorine in refrigerant can cause deterioration of refrigerant oil, etc.

Use the specified refrigerant only.

Never use any refrigerant other than that specified.

Doing so may cause a burst, an explosion, or fire when the unit is being used, serviced, or disposed of. Correct refrigerant is specified in the manuals and on the spec labels provided with our products.

We will not be held responsible for mechanical failure, system malfunction, unit breakdown or accidents caused by failure to follow the instructions.

Do not pump down the system when a gas leak has been detected.

The intake of air or other gases causes abnormally high pressure in the refrigeration cycle, which may cause explosion or injury.


[1] Cautions for service

- (1) Perform service after recovering the refrigerant left in unit completely.
- (2) Do not release refrigerant in the air.
- (3) After completing service, charge the cycle with specified amount of refrigerant.
- (4) If moisture or foreign matter might have entered the refrigerant piping during service, ensure to remove them.

[2] Additional refrigerant charge

When charging directly from cylinder

- (1) Check that cylinder for R410A on the market is a syphon type.
- (2) Charging should be performed with the cylinder of syphon stood vertically. (Refrigerant is charged from liquid phase.)



[3] Service tools

Use the below service tools as exclusive tools for R410A refrigerant.

No.	Tool name	Specifications
①	Gauge manifold	· Only for R410A
		· Use the existing fitting specifications. (UNF1/2)
		· Use high-tension side pressure of 768.7 PSIG [5.3 MPaG] or over.
②	Charge hose	· Only for R410A
		· Use pressure performance of 738.2 PSIG [5.09 MPaG] or over.
③	Electronic weighing scale	—
④	Gas leak detector	· Use the detector for R134a, R407C or R410A.
⑤	Adaptor for reverse flow check	· Attach on vacuum pump.
⑥	Refrigerant charge base	—
⑦	Refrigerant cylinder	· Only for R410A · Top of cylinder (Pink)
		· Cylinder with syphon
⑧	Refrigerant recovery equipment	—

Cautions for refrigerant piping work

New refrigerant R410A is adopted for replacement inverter series. Although the refrigerant piping work for R410A is same as for R22, exclusive tools are necessary so as not to mix with different kind of refrigerant. Furthermore as the working pressure of R410A is 1.6 times higher than that of R22, their sizes of flared sections and flare nuts are different.

Thickness of pipes

Because the working pressure of R410A is higher compared to R22, be sure to use refrigerant piping with thickness shown below. (Never use pipes of 7/256 inch [0.7 mm] or below.)

① Diagram below: Piping diameter and thickness

Nominal dimensions (in.)	Outside diameter (mm)	Thickness : in. [mm]	
		R410A	R22
1/4	ø6.35	1/32 [0.8]	1/32 [0.8]
3/8	ø9.52	1/32 [0.8]	1/32 [0.8]
1/2	ø12.70	1/32 [0.8]	1/32 [0.8]
5/8	ø15.88	5/128 [1.0]	5/128 [1.0]
3/4	ø19.05	5/128 [1.0]*	5/128 [1.0]



*Use 1/2 H or H pipes.

② Dimensions of flare cutting and flare nut

The component molecules in HFC refrigerant are smaller compared to conventional refrigerants. In addition to that, R410A is a refrigerant, which has higher risk of leakage because its working pressure is higher than that of other refrigerants.

Therefore, to enhance airtightness and strength, flare cutting dimension of copper pipe for R410A has been specified separately from the dimensions for other refrigerants as shown below. The dimension B of flare nut for R410A also has partly been changed to increase strength as shown below. Set copper pipe correctly referring to copper pipe flaring dimensions for R410A below. For 1/2 and 5/8 inch pipes, the dimension B changes.

Use torque wrench corresponding to each dimension.



Flare cutting dimensions

Unit : in. [mm]

Nominal dimensions (in.)	Outside diameter (mm)	Dimension A ()	
		R410A	R22
1/4	ø6.35	11/32-23/64 [9.1]	9.0
3/8	ø9.52	1/2-33/64 [13.2]	13.0
1/2	ø12.70	41/64-21/32 [16.6]	16.2
5/8	ø15.88	49/64-25/32 [19.7]	19.4
3/4	ø19.05	—	23.3

Flare nut dimensions

Unit: in. [mm]

Nominal dimensions (in.)	Outside diameter (mm)	Dimension B	
		R410A	R22
1/4	ø6.35	43/64 [17.0]	17.0
3/8	ø9.52	7/8 [22.0]	22.0
1/2	ø12.70	1-3/64 [26.0]	24.0
5/8	ø15.88	1-9/64 [29.0]	27.0
3/4	ø19.05	—	36.0

③ Tools for R410A (The following table shows whether conventional tools can be used or not.)

Tools and materials	Use	R410A tools	Can R22 tools be used?	Can R407C tools be used?
Gauge manifold	Air purge, refrigerant charge and operation check	Tool exclusive for R410A	×	×
Charge hose		Tool exclusive for R410A	×	×
Gas leak detector	Gas leak check	Tool for HFC refrigerant	×	○
Refrigerant recovery equipment	Refrigerant recovery	Tool exclusive for R410A	×	×
Refrigerant cylinder	Refrigerant charge	Tool exclusive for R410A	×	×
Applied oil	Apply to flared section	Ester oil, ether oil and alkylbenzene oil (minimum amount)	×	Ester oil, ether oil: ○ Alkylbenzene oil: minimum amount
Safety charger	Prevent compressor malfunction when charging refrigerant by spraying liquid refrigerant	Tool exclusive for R410A	×	×
Charge valve	Prevent gas from blowing out when detaching charge hose	Tool exclusive for R410A	×	×
Vacuum pump	Vacuum drying and air purge	Tools for other refrigerants can be used if equipped with adopter for reverse flow check	△ (Usable if equipped with adopter for reverse flow)	△ (Usable if equipped with adopter for reverse flow)
Flare tool	Flaring work of piping	Tools for other refrigerants can be used by adjusting flaring dimension	△ (Usable by adjusting flaring dimension)	△ (Usable by adjusting flaring dimension)
Bender	Bend the pipes	Tools for other refrigerants can be used	○	○
Pipe cutter	Cut the pipes	Tools for other refrigerants can be used	○	○
Welder and nitrogen gas cylinder	Weld the pipes	Tools for other refrigerants can be used	○	○
Refrigerant charging scale	Refrigerant charge	Tools for other refrigerants can be used	○	○
Vacuum gauge or thermistor vacuum gauge and vacuum valve	Check the degree of vacuum. (Vacuum valve prevents back flow of oil and refrigerant to thermistor vacuum gauge)	Tools for other refrigerants can be used	○	○
Charging cylinder	Refrigerant charge	Tool exclusive for R410A	×	—

× : Prepare a new tool. (Use the new tool as the tool exclusive for R410A.)


△ : Tools for other refrigerants can be used under certain conditions.

○ : Tools for other refrigerants can be used.

2-1. Auxiliary HEATING ON/OFF CONTROL SET-UP

(1) Auxiliary heating operation controls another heat source that depends on the main system's operations, which means the interlock operation shown in "b)" will be possible.

- a) Indoor unit must be R410A UL model for this function to operate.
- b) Different Indoor unit applications that can be applied:



(2) **Outdoor unit DIPSW5-4 for auxiliary heating control:**

Set DIPSW5-4 when power is turned off at unit.

OFF: Disable auxiliary heating function (Initial setting)

ON: Enable auxiliary heating function

(3) **Determine required indoor fan speed during defrost mode:**

To set the fan speed, see the chapter referring to heater control in the indoor unit's Technical & Service Manual.

(4) Determine fan speed setting during indoor thermo-OFF conditions:


- a) These settings are done within Indoor DIPSW1-7 and DIPSW1-8, see chart below for options.
b) Recommended SW1-7 OFF and SW1-8 ON will determine airflow based on "Setting on the remote controller".

Auxiliary heating signal		Fan speed setting	Fan speed setting
Thermo contidion		OFF	ON
SW1-7	SW1-8		
OFF	OFF	Very low	Setting on remote controller
ON	OFF	Low	
OFF	ON	Setting on remote controller	
ON	ON	Stopped	

(5) Setting outdoor unit and auxiliary heat switch over temperatures

When the DIPSW 5-4 is set to "ON", the outdoor unit and the contact output operates as shown below.

- a) Outdoor default setting and operations are shown below:



When the set temperature ranges overlap, the previously set pattern (1, 2 or 3) has a priority.

The stage 1 has the highest priority, 2 the second and then 3.

- b) Based on above chart listed the sequence of operation on "On ambient decrease"

- Stage 1: ($TH7 \geq 50^{\circ}\text{F}$ [10°C]): the outdoor unit runs in HP mode.
- Stage 2: ($TH7 = 50$ to -13°F [10 to -25°C]): the outdoor unit runs in HP mode with auxiliary heating.
- Stage 3: ($TH7 \leq -13^{\circ}\text{F}$ [-25°C]): Auxiliary heating only (Outdoor unit is OFF).


- c) Based on above chart listed the sequence of operation on "On ambient increase"

- Stage 3: ($TH7 \leq 32^{\circ}\text{F}$ [0°C]): Auxiliary heating only (Outdoor unit is OFF).
- Stage 2: ($TH7 \geq 32$ to 68°F [0 to 20°C]): Auxiliary heating with outdoor unit in HP mode.
- Stage 1: ($TH7 \geq 68^{\circ}\text{F}$ [20°C]): Outdoor unit in HP mode only.

(6) Locally procured wiring

A basic connection method is shown.

(i.e. interlocked operation with the electric heater with the fan speed setting on high)



For relay X use the specifications given below operation coil

Rated voltage: 12 VDC

Power consumption: 0.9 W or less

*Use the diode that is recommended by the relay manufacturer at both ends of the relay coil.

The length of the electrical wiring for the PAC-YU24HT is 2 meters (6-1/2 ft)


To extend this length, use sheathed 2-core cable.


Control cable type: CVV, CVS, CPEV, or equivalent.

Cable size: 0.5 mm² to 1.25 mm² (AWG22 to AWG16)

Do not extend the cable more than 10 meters (32 ft).

Recommended circuit





2-2. SYSTEM CONSTRUCTION

Outdoor unit		4HP	4.5HP	5HP	7HP
		P36NKMU4 HP36NKMU2	HP42NKMU2	P48NKMU4 HP48NKMU2	P60NKMU4
Applicable indoor unit	Capacity	04 to 36	04 to 54		04 to 72
	Max. No. of units	11	12		
	Total system capacity range	50 to 130% of outdoor unit capacity			



Branch header	Model name	CMY-Y62-G-E	CMY-Y64-G-E	CMY-Y68-G-E
	Number of branches	2	4	8



Connectable indoor unit lineup																
Model type	Model name		04	05	06	08	12	15	18	24	27	30	36	48	54	72
Ceiling Cassette	4-way flow	PLFY-EP NEMU-E					●	●	●	●		●	●	●		
	2 by 2	PLFY-P NFMU-E		●		●	●	●	●							
	1-way flow	PMFY-P NBMU-E			●	●	●	●								
Ceiling Concealed	PEFY-P	NMAU-E			●	●	●	●	●	●	●	●	●	●	●	
		NMSU-E			●	●	●	●	●	●						
		NMHU-E						●	●	●	●	●	●	●	●	
		NMHSU-E														●*
Wall Mounted	PKFY-P	NKMU-E								●		●				
		NLMU-E	●		●	●	●	●	●							
Ceiling Suspended	PCFY-P	NKMU-E						●		●		●	●			
Floor standing	Exposed	PFFY-P NEMU-E			●	●	●	●	●	●						
	Concealed	NRMU-E			●	●	●	●	●	●						
Multi-position air handling unit	PVFY-P	NAMU-E				●	●		●	●		●	●	●	●	

* Only PUMY-P60 is connectable.



Remote controller	Name	M-NET remote controller	MA remote controller
	Model number	PAR-F27MEA-E, PAR-U01MEDU	PAR-21MAA, PAR-41MAA
	Functions	<ul style="list-style-type: none"> • A handy remote controller for use in conjunction with the Melans centralized management system. • Addresses must be set. 	<ul style="list-style-type: none"> • Addresses setting is not necessary.

2-3 SYSTEM CONSTRUCTION(BRANCH BOX SYSTEM)

Outdoor unit	Model name	P36NKMU4 HP36NKMU2	HP42NKMU2	P48NKMU4 HP48NKMU2	P60NKMU4
	Horse power	4HP	4.5HP	5HP	7HP
Applicable indoor unit	Capacity class	Type 06 to Type 36 Caution: The indoor unit which rated capacity exceeds 36 kBTu/h (Type 36) can NOT be connected.			
	Max. No. of units	4	5	8	8
	Total system capacity range	33 to 130% of outdoor unit capacity 12 to 46.8 kBTu/h	29 to 130% of outdoor unit capacity 12 to 54.6 kBTu/h	25 to 130% of outdoor unit capacity 12 to 62.4 kBTu/h	20 to 130% of outdoor unit capacity 12 to 78 kBTu/h
Branch box that can be connected	Number of units	1 or 2			

Connectable indoor unit lineups (Heat pump inverter type)										
Model type		Model name	06	09	12	15	18	24	30	36
Wall-mounted	Deluxe	MSZ-FH06/09/12/15NA, 18NA MSZ-FS•NA	●	●	●	●	●			
	Designer	MSZ-EF•NAW(B/S)		●	●	●	●			
	Standard	MSZ-GL•NA MSZ-GS•NA	●	●	●	●	●	●		
Ducted	Low static ^{*2 *3}	SEZ-KD•NA		●	●	●	●			
	P-series mid static ^{*2 *3}	PEAD-A•AA		●	●	●	●	●	●	●
1-way ceiling cassette		MLZ-KY06NA ^{*5} MLZ-KP09/12/18NA	●	●	●		●			
4-way ceiling cassette	P-series 22*22	SLZ-KF•NA		●	●	●				
	P-series 33*33	PLA-A•EA ^{*4}			●		●	●	●	●
Floor standing		MFZ-KJ•NA		●	●	●	●			
Standard Multi-position air handler ^{*1}		SVZ-KP•NA			●		●	●	●	●
A-coil		PAA-A•A ^{*4}					●	●	●	●

Branch box	PAC-MKA52/53BC	PAC-MKA32/33BC
Number of branches (Indoor unit that can be connected)	5 (MAX. 5 units)	3 (MAX. 3 units)

Note: A maximum of 2 Branch boxes can be connected to 1 outdoor unit.

2- Branch pipe (joint), Optional parts

	Model name	Note
Using 1 Branch box	No required	
Using 2 Branch boxes	MSDD-50AR-E	Connection method: flare
	MSDD-50BR-E	Connection method: brazing

Note: Select a model according to the connection method.

Option	Optional accessories for indoor units and outdoor units are available.
--------	--

^{*1} When connecting a multi-position unit(s), set additional constraints as follows. For connections other than those specified below, consult your dealer.

● **Models other than PUMY-P60NKMU4** (For each connected Branch box)

Number of connecting multi-position unit	Constraints
2	Any indoor units other than ducted units are not connectable.
1	<ul style="list-style-type: none"> The total system wide capacity should be 130% or below including the ducted unit. Only 1 ducted unit can be included in the connection.

● **PUMY-P60NKMU4** (For each connected Branch box)

Number of connecting multi-position unit	Constraints
2	Any indoor units other than ducted unit are not connectable.
1	<ul style="list-style-type: none"> The total system wide capacity should be 100% or below including the ducted unit. Only 1 ducted unit can be included in the connection.


^{*2} For PUMY-P60NKMU4: When connecting the SEZ and PEAD-series units, the total system wide capacity per 1 Branch box should be 100% or below including the ducted units. (Only if connecting to Branch box)

^{*3} When not outside units 60: A Branch box can connect to maximum 3 of the ducted units. When connecting with 3 of the ducted units per 1 Branch box, other indoor units cannot be connected. When outside units 60: A Branch box can connect to maximum 2 of the ducted units. When connecting with 1 and over 1 of the ducted units, the total ability including of the ducted units is 100% and below 100%.

^{*4} When 1 or more PLA-A•EA or PAA-AA units is connected, the number of the maximum connectable indoor units is decreased as follows:

3 for PUMY-(H)P36, 4 for PUMY-HP42, and 6 for PUMY-(H)P48 and PUMY-P60

^{*5} Only PUMY-(H)P36/42/48 are connectable.



2-4. SYSTEM SPECIFICATIONS


(1) Outdoor Unit

Outdoor unit	Model name	P36NKMU4	HP36NKMU2	HP42NKMU2	P48NKMU4	HP48NKMU2	P60NKMU4
Capacity	Cooling (kBtu/h)	36		42	48		60
	Heating (kBtu/h)	41	42	48	50	54	66

Cooling/Heating capacity indicates the maximum value at operation under the following condition.

Cooling	Indoor	D.B. 80°F/W.B. 67°F: [D.B. 26.7°C/W.B. 19.4°C]
	Outdoor	D.B. 95°F/W.B. 75°F: [D.B. 35°C/W.B. 23.9°C]
Heating	Indoor	D.B. 70°F/W.B. 60°F: [D.B. 21.1°C/W.B. 15.6°C]
	Outdoor	D.B. 47°F/W.B. 43°F: [D.B. 8.3°C/W.B. 6.1°C]

(2) Method for identifying



Service Ref.			PUMY-P36NKMU4			PUMY-P48NKMU4		
Indoor type			Non-Ducted	Mix	Ducted	Non-Ducted	Mix	Ducted
Cooling	Capacity Rated* ¹	Btu/h	36,000	36,000	36,000	48,000	48,000	48,000
	Rated power consumption* ¹	W	2,400	2,740	3,190	3,665	4,090	4,615
	Current input (208/230 V)	A	11.7/10.6	13.4/12.1	15.6/14.1	17.9/16.2	20.0/18.1	22.5/20.4
	EER2	Btu/h/W	15.00	13.15	11.30	13.10	11.75	10.40
	SEER2	-	23.00	19.30	15.60	23.00	18.85	14.70
Heating	Capacity Rated 47°F* ¹	Btu/h	41,000	41,000	41,000	50,000	50,000	50,000
	Capacity Max. 17°F* ²	Btu/h	36,000	36,000	36,000	43,000	43,000	43,000
	Capacity Max. 5°F	Btu/h	29,000	29,000	29,000	35,400	35,400	35,400
	Rated power consumption 47°F* ¹	W	3,005	3,250	3,535	3,665	4,075	4,580
	Current input (208/230 V)	A	14.7/13.3	15.9/14.3	17.3/15.6	17.9/16.2	19.9/18.0	22.4/20.2
	COP 47°F* ¹	W/W	4.00	3.70	3.40	4.00	3.60	3.20
HSPF2 IV/V		-	11.00/8.75	9.80/8.05	8.60/7.40	10.40/8.35	9.35/7.90	8.30/7.50
Power supply			1-phase 208/230 V, 60 Hz					
Breaker Size/Maximum over current protection			30 A/64 A (When power is supplied separately) 40 A/70 A (When power is supplied from the outdoor unit)					
Minimum circuit ampacity			36 A (When power is supplied separately) 42 A (When power is supplied from the outdoor unit)					
Indoor unit connectable	Total capacity		50 to 130% of outdoor unit capacity					
	Model/Quantity * ³	CITY MULTI	04 - 36/11			04 - 54/12		
		Branch box	06 - 36/4			06 - 36/8		
Sound pressure level (measured in anechoic room)		dB <A>	49/53			51/54		
Refrigerant piping diameter	Liquid pipe	in. (mm)	3/8 (ø9.52)					
	Gas pipe	in. (mm)	5/8 (ø15.88)					
Fan	Type × Quantity		Propeller fan × 2					
	Airflow rate	m³/min	110					
		L/s	1,834					
		cfm	3,885					
	Control, Driving mechanism		DC control					
	Motor output	kW	0.074 × 2					
	External static press.		0					
Compressor	Type × Quantity		Scroll hermetic compressor x 1					
	Manufacture		Mitsubishi Electric Corporation					
	Starting method		Inverter					
	Motor output	kW	2.8			3.4		
	Case heater	kW	0					
	Lubricant		FV50S 78oz. (2.3 L)					
External finish			Galvanized Steel Sheet <Munsell 3Y 7.8/ 1.1>					
External dimension H × W × D		mm	1,338 × 1,050 × 330 (+25)					
		in.	52-11/16 × 41-11/32 × 13 (+1)					
Protection devices	High pressure protection		High pressure switch					
	Inverter circuit (COMP./FAN)		Overcurrent detection, Overheat detection (Heat sink thermistor)					
	Compressor protection		Compressor thermo, Overcurrent detection					
	Fan motor protection		Overheating/Voltage protection					
Refrigerant	Type × original charge		R410A 10 lbs. 9 oz. (4.8 kg)					
	Control		Linear Expansion Valve					
Net weight		lb (kg)	271 (123)					
Heat exchanger			Cross fin and tube					
HIC circuit (HIC: Heat Inter-Changer)			HIC circuit					
Defrosting method			Reversed refrigerant circuit					
Guaranteed operation range		(Cooling)	D.B 23 to 115°F [D.B.-5 to 46°C] *4*5*6					
		(Heating)	W.B. -13 to 59°F [W.B. -25 to 15°C]					
Remarks			Details on foundation work, duct work, insulation work, electrical wiring, power source switch, and other items shall be referred to the Installation Manual. Due to continuing improvement, above specifications may be subject to change without notice.					

*¹ Rating conditions Cooling Indoor : D.B. 80°F/W.B. 67°F [D.B.26.7°C/W.B. 19.4°C]

Outdoor : D.B. 95°F [D.B. 35.0°C]

Heating Indoor : D.B. 70°F [D.B. 21.1°C]

Outdoor : D.B. 47°F/W.B. 43°F [D.B. 8.3°C/W.B. 6.1°C]

*² Conditions

Heating Indoor : D.B. 70°F [D.B. 21.1°C]

Outdoor : D.B. 17°F/W.B. 15°F [D.B. -8.3°C/W.B. -9.4°C]

*³ It cannot be connected mixed CITY MULTI indoor unit and Branch box indoor unit.

*⁴ D.B. 5 to 115°F [D.B. -15 to 46°C], when an optional Air Outlet Guide is installed.

However, this condition does not apply to the indoor units listed in *5.

*⁵ 50 to 115°F (10 to 46°C) D.B.: When connecting PKFY-P04/06/08/12NLMU, PFFY-P06/08/12NEMU, and PFFY-P06/08/12NRMU type indoor unit.

*⁶ When the temperature is below D.B. 50°F [D.B. 10°C] with Branch box system, noise could potentially occur.

Note: Refer to the indoor unit's service manual for the indoor units specifications.

Conversion formula:	kcal/h = kW × 860
	Btu/h = kW × 3412
	CFM = m ³ /min × 35.31

*1 Rating conditions	Cooling Indoor : D.B. 80°F/W.B. 67°F [D.B. 26.7°C/W.B. 19.4°C] Outdoor : D.B. 95°F [D.B. 35.0°C] Heating Indoor : D.B. 70°F [D.B. 21.1°C] Outdoor : D.B. 47°F/W.B. 43°F [D.B. 8.3°C/W.B. 6.1°C]	Conversion formula: kcal/h = kW × 860 Btu/h = kW × 3412 CFM = m³/min × 35.31
*2 Conditions	Heating Indoor : D.B. 70°F [D.B. 21.1°C] Outdoor : D.B. 17°F/W.B. 15°F [D.B. -8.3°C/W.B. -9.4°C]	
*3 It cannot be connected mixed CITY MULTI indoor unit and Branch box indoor unit.		
*4 D.B. 5 to 115°F [D.B. -15 to 46°C], when an optional Air Outlet Guide is installed. However, this condition does not apply to the indoor units listed in *5.		
*5 50 to 115°F (10 to 46°C) D.B.: When connecting PKFY-P04/06/08/12NLMU, PFFY-P06/08/12NEMU, and PFFY-P06/08/12NRMU type indoor unit.		
*6 When the temperature is below D.B. 50°F [D.B. 10°C] with Branch box system, noise could potentially occur.		
Note: Refer to the indoor unit's service manual for the indoor units specifications.		



Service Ref.			PUMY-P60NKMU4		
Indoor type			Non-Ducted	Mix	Ducted
Cooling	Capacity Rated*1	Btu/h	60,000	60,000	60,000
	Rated power consumption*1	W	4,515	5,065	5,770
	Current input (208/230 V)	A	21.9/19.8	24.6/22.3	28.0/25.4
	EER2	Btu/h/W	13.30	11.85	10.40
	SEER2	-	20.00	17.75	15.50
Heating	Capacity Rated 47°F*1	Btu/h	66,000	66,000	66,000
	Capacity Max. 17°F*2	Btu/h	65,000	65,000	65,000
	Capacity Max. 5°F	Btu/h	46,500	46,500	46,500
	Rated power consumption 47°F*1	W	4,720	5,175	5,690
	Current input (208/230 V)	A	22.9/20.7	25.2/22.8	27.7/25.0
	COP 47°F*1	W/W	4.10	3.74	3.40
HSPF2 I/ V		-	10.50/8.65	9.55/8.05	8.60/7.45
Power supply			1-phase 208/230 V, 60 Hz		
Breaker Size/Maximum over current protection			40 A/80 A (When power is supplied separately) 50 A/90 A (When power is supplied from the outdoor unit)		
Minimum circuit ampacity			45 A (When power is supplied separately) 55 A (When power is supplied from the outdoor unit)		
Indoor unit connectable	Total capacity		50 to 130% of outdoor unit capacity		
	Model/Quantity*3	CITY MULTI	04 - 72 /12		
		Branch box	06 - 36 / 8		
Sound pressure level (measured in anechoic room)		dB <A>	58/59		
Refrigerant piping diameter	Liquid pipe	in. (mm)	3/8 (ø9.52)		
	Gas pipe	in. (mm)	3/4 (ø19.05)		
Fan	Type × Quantity		Propeller fan × 2		
	Airflow rate	m³/min	138		
		L/s	2,300		
		cfm	4,879		
	Control, Driving mechanism		DC control		
	Motor output	kW	0.200 × 2		
	External static press.		0		
Compressor	Type × Quantity		Scroll hermetic compressor x 1		
	Manufacture		Mitsubishi Electric Corporation		
	Starting method		Inverter		
	Motor output	kW	3.9		
	Case heater	kW	0		
	Lubricant		FVC68D 78oz. (2.3 L)		
External finish			Galvanized Steel Sheet <Munsell 3Y 7.8/ 1.1>		
External dimension H × W × D		mm	1,338 × 1,050 × 330 (+25)		
		in.	52-11/16 × 41-11/32 × 13 (+1)		
Protection devices	High pressure protection		High pressure switch		
	Inverter circuit (COMP./FAN)		Overcurrent detection, Overheat detection(Heat sink thermistor)		
	Compressor protection		Compressor thermo, Overcurrent detection		
	Fan motor protection		Overheating/Voltage protection		
Refrigerant	Type x original charge		R410A 11 lbs. 4 oz. (5.1 kg)		
	Control		Linear Expansion Valve		
Net weight		lb (kg)	300 (136)		
Heat exchanger			Cross fin and tube		
HIC circuit (HIC: Heat Inter-Changer)			HIC circuit		
Defrosting method			Reversed refrigerant circuit		
Guaranteed operation range		(Cooling)	D.B 23 to 115°F [D.B.-5 to 46°C] *4*5*6		
		(Heating)	W.B. -13 to 59°F [W.B. -25 to 15°C]		
Remarks			Details on foundation work, duct work, insulation work, electrical wiring, power source switch, and other items shall be referred to the Installation Manual. Due to continuing improvement, above specifications may be subject to change without notice.		

*1 Rating conditions Cooling Indoor : D.B. 80°F/W.B. 67 °F [D.B.26.7°C/W.B. 19.4°C]
Outdoor : D.B. 95°F [D.B. 35.0°C]
Heating Indoor : D.B. 70°F [D.B. 21.1°C]
Outdoor : D.B. 47°F/W.B. 43°F [D.B. 8.3°C/W.B. 6.1°C]
*2 Conditions Heating Indoor : D.B. 70°F [D.B. 21.1°C]
Outdoor : D.B. 17°F/W.B. 15°F [D.B. -8.3°C/W.B. -9.4°C]


Conversion formula:	kcal/h = kW × 860
	Btu/h = kW × 3412
	CFM = m³/min × 35.31

*3 It cannot be connected mixed CITY MULTI indoor unit and Branch box indoor unit.
*4 D.B. 5 to 115°F [D.B. -15 to 46°C], when an optional Air Outlet Guide is installed.
However, this condition does not apply to the indoor units listed in *5.
*5 50 to 115°F (10 to 46°C) D.B.: When connecting PKFY-P04/06/08/12NLMU, PFFY-P06/08/12NEMU, and PFFY-P06/08/12NRMU type indoor unit.
*6 When the temperature is below D.B. 50°F [D.B. 10°C] with Branch box system, noise could potentially occur.
Note: Refer to the indoor unit's service manual for the indoor units specifications.

4-1. SELECTION OF COOLING/HEATING UNITS


How to determine the capacity when less than or equal 100% indoor model size units are connected in total:

The purpose of this flow chart is to select the indoor and outdoor units. For other purposes, this flow chart is intended only for reference.



How to determine the capacity when greater than 100% indoor model size units are connected in total:

The purpose of this flow chart is to select the indoor and outdoor units. For other purposes, this flow chart is intended only for reference.



<Cooling>

Design Condition	
Outdoor Design Dry Bulb Temperature	98.6°F (37.0°C)
Total Cooling Load	30.3 kBTu/h
Room1	
Indoor Design Dry Bulb Temperature	80.6°F (27.0°C)
Indoor Design Wet Bulb Temperature	68.0°F (20.0°C)
Cooling Load	13.6 kBTu/h
Room2	
Indoor Design Dry Bulb Temperature	75.2°F (24.0°C)
Indoor Design Wet Bulb Temperature	66.2°F (19.0°C)
Cooling Load	16.7 kBTu/h
<Other>	
Indoor/Outdoor Equivalent Piping Length	250 ft

Capacity of indoor unit

(kBTu/h)

<P•FY series>

Model Number for indoor unit	Model 04	Model 05	Model 06	Model 08	Model 12	Model 15	Model 18	Model 24	Model 27	Model 30	Model 36	Model 48	Model 54	Model 72
Model Capacity	4.0	5.0	6.0	8.0	12.0	15.0	18.0	24.0	27.0	30.0	36.0	48.0	54.0	72.0

<M,S,P series>

Model name	Capacity class							
	06	09	12	15	18	24	30	36
SVZ	-	-	12.0	-	18.0	24.0	30.0	36.0
SLZ-KF	-	8.4	11.1	15.0	-	-	-	-
SEZ-KD	-	8.1	11.5	14.1	17.2	-	-	-
MFZ-KJ	-	9.0	12.0	15.0	17.0	-	-	-
MLZ-KP	-	9.0	12.0	-	17.2	-	-	-
MLZ-KY	6.0	-	-	-	-	-	-	-
MSZ-FH	6.0	9.0	12.0	15.0	17.2	-	-	-
MSZ-FS	6.0	9.0	12.0	15.0	17.2	-	-	-
MSZ-GL	6.0	9.0	12.0	14.0	17.2	22.5	-	-
MSZ-GS	6.0	9.0	12.0	14.0	18.0	22.4	-	-
MSZ-EF	-	9.0	12.0	15.0	18.0	-	-	-
PEAD	-	9.0	12.0	15.0	18.0	24.0	30.0	36.0
PLA	-	-	12.0	-	18.0	24.0	30.0	36.0
PAA-A	-	-	-	-	18.0	24.0	30.0	36.0

1. Cooling Calculation

(1) Temporary Selection of Indoor Units

Room1	PEFY-P15	15.0 kBTu/h (Rated)
Room2	PEFY-P18	18.0 kBTu/h (Rated)

(2) Total Indoor Units Capacity

P15+ P18 = P33

(3) Selection of Outdoor Unit

The P36 outdoor unit is selected as total indoor units capacity is P33

PUMY-P36NKMU4 36.0 kBTu/h

(4) Total Indoor Units Capacity Correction Calculation

Room1	Indoor Design Wet Bulb Temperature Correction (68.0°F)	1.02 (Refer to Figure 1)
Room2	Indoor Design Wet Bulb Temperature Correction (66.2°F)	0.95 (Refer to Figure 1)

Total Indoor Units Capacity (CTi)

$$CTi = \Sigma (\text{Indoor Unit Rating} \times \text{Indoor Design Temperature Correction})$$

$$= 15.0 \times 1.02 + 18.0 \times 0.95$$

$$= 32.4 \text{ kBTu/h}$$

(5) Outdoor Unit Capacity Correction Calculation

Outdoor Design Dry Bulb Temperature Correction (98.6°F)	0.98 (Refer to Figure 2)
Piping Length Correction (250 ft)	0.93 (Refer to Figure 3)

Total Outdoor Unit Capacity (CTo)

$$CTo = \text{Outdoor Rating} \times G(CTi)^{*1} \times \text{Outdoor Design Temperature Correction}$$

$$\times \text{Piping Length Correction}$$

$$= 36.0 \times 0.98 \times 0.93$$

$$= 32.8 \text{ kBTu/h}$$

*1 G(CTi) is used only when greater than 100% indoor model size are connected in total, refer to STANDARD CAPACITY DIAGRAM.

(6) Determination of Maximum System Capacity

Comparison of Capacity between Total Indoor Units Capacity (CTi) and Total Outdoor Unit Capacity (CTo)

CTi = 32.4 < CTo = 32.8, thus, select CTi.

CTx = CTi = 32.4 kBTu/h




Figure 1 Indoor unit temperature correction
To be used to correct indoor unit only




Figure 2 Outdoor unit temperature correction
To be used to correct outdoor unit only




Figure 3 Correction of refrigerant piping length

(7) Comparison with Essential Load

Against the essential load 30.3 kBtu/h, the maximum system capacity is 32.4 kBtu/h: Proper outdoor units have been selected.

(8) Calculation of Maximum Indoor Unit Capacity of Each Room

CTx = CTi, thus, calculate by the calculation below

Room1

Indoor Unit Rating × Indoor Design Temperature Correction
 = 15.0 × 1.02
 = 15.3 kBtu/h **OK: fulfills the load 13.6 kBtu/h**

Room2

Indoor Unit Rating × Indoor Design Temperature Correction
 = 18.0 × 0.95
 = 17.1 kBtu/h **OK: fulfills the load 16.7 kBtu/h**

Go on to the heating trial calculation since the selected units fulfill the cooling loads of Room 1, 2.

<Heating>

Design Condition	
Outdoor Design Wet Bulb Temperature	35.6°F (2.0°C)
Total Heating Load	34.0 kBtu/h
Room1	
Indoor Design Dry Bulb Temperature	69.8°F (21.0°C)
Heating Load	16.3 kBtu/h
Room2	
Indoor Design Dry Bulb Temperature	73.4°F (23.0°C)
Heating Load	17.7 kBtu/h
<Other>	
Indoor/Outdoor Equivalent Piping Length	328 ft

Capacity of indoor unit

(kBtu/h)

<P•FY series>

Model Number for indoor unit	Model 04	Model 05	Model 06	Model 08	Model 12	Model 15	Model 18	Model 24	Model 27	Model 30	Model 36	Model 48	Model 54
Model Capacity	4.5	5.6	6.7	9.0	13.5	17.0	20.0	27.0	30.0	34.0	40.0	54.0	60.0

<M,S,P series>

Model name	Capacity class							
	06	09	12	15	18	24	30	36
SVZ	-	-	12.0	-	18.0	27.0	34.0	40.0
SLZ-KF	-	10.2	13.7	17.1	-	-	-	-
SEZ-KD	-	10.9	13.6	18.0	17.2	-	-	-
MFZ-KJ	-	10.9	13.0	18.0	21.0	-	-	-
MLZ-KP	-	10.9	13.0	-	21.0	-	-	-
MLZ-KY	7.2	-	-	-	-	-	-	-
MSZ-FH	8.7	10.9	13.6	18.0	20.3	-	-	-
MSZ-FS	8.7	10.9	13.6	18.0	20.3	-	-	-
MSZ-GL	7.2	10.9	14.4	18.0	21.6	27.6	-	-
MSZ-GS	7.2	10.9	14.4	18.0	21.6	27.6	-	-
MSZ-EF	-	10.9	13.0	18.0	21.0	-	-	-
PEAD	-	10.9	13.5	15.7	18.0	26.0	34.0	40.0
PLA	-	-	13.5	-	18.0	26.0	34.0	40.0
PAA-A	-	-	-	-	19.0	26.0	32.0	38.0

2. Heating Calculation

(1) Temporary Selection of Indoor Units

Room1
PEFY-P15 **17.0 kBtu/h (Rated)**

Room2
PEFY-P18 **20.0 kBtu/h (Rated)**

(2) Total Indoor Units Capacity

P15 + P18 = P33

(3) Selection of Outdoor Unit

The P36 outdoor unit is selected as total indoor units capacity is P33

PUMY-P36NKMU4 **41.0 kBtu/h**

(4) Total Indoor Units Capacity Correction Calculation

Room1
Indoor Design Dry Bulb Temperature Correction (69.8°F) 1.00 (Refer to Figure 4)

Room2
Indoor Design Dry Bulb Temperature Correction (73.4°F) 0.92 (Refer to Figure 4)

Total Indoor Units Capacity (CTi)

$$\begin{aligned} CT_i &= \Sigma (\text{Indoor Unit Rating} \times \text{Indoor Design Temperature Correction}) \\ &= 17.0 \times 1.00 + 20.0 \times 0.92 \\ &= 35.4 \text{ kBtu/h} \end{aligned}$$

(5) Outdoor Unit Correction Calculation

Outdoor Design Wet Bulb Temperature Correction (35.6°F) 1.0 (Refer to Figure 5)

Piping Length Correction (328 ft) 0.94 (Refer to Figure 6)

Defrost Correction 0.89 (Refer to Table 1)

Total Outdoor Unit Capacity (CTo)

$$\begin{aligned} CTo &= \text{Outdoor Unit Rating} \times G(CT_i)^{*1} \times \text{Outdoor Design Temperature Correction} \\ &\quad \times \text{Piping Length Correction} \times \text{Defrost Correction} \\ &= 41.0 \times 1.0 \times 0.94 \times 0.89 \\ &= 34.3 \text{ kBtu/h} \end{aligned}$$

*1 G(CTi) is used only when greater than 100% indoor model size are connected in total, refer to STANDARD CAPACITY DIAGRAM.

Table 1 Table of correction factor at frost and defrost

Outdoor Intake temperature <W.B. °F (°C)>	43(6)	37(4)	36(2)	32(0)	28(-2)	25(-4)	21(-6)	18(-8)	14(-10)	5(-15)	-4(-20)	-13(-25)
Correction factor	1.00	0.98	0.89	0.88	0.89	0.90	0.95	0.95	0.95	0.95	0.95	0.95

(6) Determination of Maximum System Capacity

Comparison of Capacity between Total Indoor Units Capacity (CTi) and Total Outdoor Unit Capacity (CTo)

CTi = 35.4 > CTo = 34.3, thus, select CTo.

CTx = CTo = 34.3 kBtu/h

(7) Comparison with Essential Load

Against the essential load 34.0 kBtu/h, the maximum system capacity is 34.3 kBtu/h: Proper outdoor units have been selected.

(8) Calculation of Maximum Indoor Unit Capacity of Each Room

CTx = CTo, thus, calculate by the calculation below

Room1

$$\begin{aligned} &\text{Maximum Capacity} \times \text{Room1 Capacity after the Temperature Correction} / (\text{Room1,2 Total Capacity after the Temperature Correction}) \\ &= 34.3 \times (17.0 \times 1.00) / (17.0 \times 1.00 + 20.0 \times 0.92) \\ &= 16.5 \text{ kBtu/h} \quad \text{OK: fulfills the load 16.3 kBtu/h} \end{aligned}$$

Room2

$$\begin{aligned} &\text{Maximum Capacity} \times \text{Room1 Capacity after the Temperature Correction} / (\text{Room1,2 Total Capacity after the Temperature Correction}) \\ &= 34.3 \times (20.0 \times 0.92) / (17.0 \times 1.00 + 20.0 \times 0.92) \\ &= 17.8 \text{ kBtu/h} \quad \text{OK: fulfills the load 17.7 kBtu/h} \end{aligned}$$

Completed selecting units since the selected units fulfill the heating loads of Room 1, 2.




Figure 4 Indoor unit temperature correction
To be used to correct indoor unit only




Figure 5 Outdoor unit temperature correction
To be used to correct outdoor unit only




Figure 6 Correction of refrigerant piping length

3. Power input of outdoor unit

Outdoor unit: PUMY-P36NKMU4

Indoor unit 1: PEFY-P15

Indoor unit 2: PEFY-P18

<Cooling>

(1) Rated power input of outdoor unit **2.40 kW**

(2) Calculation of the average indoor temperature power input coefficient

Coefficient of the outdoor unit for indoor unit 1 (Outdoor temp. 98.6°F [37.0°C] D.B., Indoor temp. 68.0°F [20.0°C] W.B.)

1.04 (Refer to "4-2. CORRECTION BY TEMPERATURE".)

Coefficient of the outdoor unit for indoor unit 2 (Outdoor temp. 98.6°F [37.0°C] D.B., Indoor temp. 64.4°F [18.0°C] W.B.)

0.85 (Refer to "4-2. CORRECTION BY TEMPERATURE".)

$$\text{Average indoor temp. power input coefficient } (C_{ave}) = \sum_{k=1}^n \{C_k \times (M_k / \sum_{k=1}^n M_k)\}$$

n: Total number of the indoor units

k: Number of the indoor unit

C_k : Outdoor unit power input coefficient of k indoor unit room temp.

M_k : Number part of the k indoor unit model (e.g. P80 → 80)

$$\begin{aligned} \text{Correction Coefficient of Indoor temperature} &= 1.04 \times 15 / (15 + 18) + 0.85 \times 18 / (15 + 18) \\ &= 0.94 \end{aligned}$$

(3) Coefficient of the partial load f (CTi)

Total Indoor units capacity

15 + 18 = 33, thus, f (CTi) = 0.9 (Refer to the tables in "4-4. STANDARD CAPACITY DIAGRAM".)

(4) Outdoor power input (Plo)

Maximum System Capacity (CTx) = Total Outdoor unit Capacity (CTo), so use the following formula

Plo = Outdoor unit Cooling Rated Power Input × Correction Coefficient of Indoor temperature × f (CTi)

$$= 2.40 \times 0.94 \times 0.9$$

$$= 2.03 \text{ kW}$$

<Heating>

(1) Rated power input of outdoor unit **3.01 kW**

(2) Calculation of the average indoor temperature power input coefficient

Coefficient of the outdoor unit for indoor unit 1 (Outdoor temp. 26.6°F [−3°C] W.B., Indoor temp. 70°F [21.1°C] D.B.)

1.16 (Refer to "4-2. CORRECTION BY TEMPERATURE".)

Coefficient of the outdoor unit for indoor unit 2 (Outdoor temp. 26.6°F [−3°C] W.B., Indoor temp. 78.8°F [26°C] D.B.)

1.09 (Refer to "4-2. CORRECTION BY TEMPERATURE".)

$$\text{Average indoor temp. power input coefficient } (C_{ave}) = \sum_{k=1}^n \{C_k \times (M_k / \sum_{k=1}^n M_k)\}$$

n: Total number of the indoor units

k: Number of the indoor unit

C_k : Outdoor unit power input coefficient of k indoor unit room temp.

M_k : Number part of the k indoor unit model (e.g. P80 → 80)

$$\begin{aligned} \text{Correction Coefficient of Indoor temperature} &= 1.16 \times 15 / (15 + 18) + 1.09 \times 18 / (15 + 18) \\ &= 1.12 \end{aligned}$$

(3) Coefficient of the partial load f (CTi)

Total indoor units capacity

15 + 18 = 33, thus, f (CTi) = 0.9 (Refer to the tables in "4-4. STANDARD CAPACITY DIAGRAM".)

(4) Outdoor power input (Plo)

Maximum System Capacity (CTx) = Total Indoor unit Capacity (CTi), so use the following formula

Plo = Outdoor unit Heating Rated Power Input × Correction Coefficient of Indoor temperature × f (CTi)

$$= 3.01 \times 1.12 \times 0.9$$

$$= 3.03 \text{ kW}$$

4-2. CORRECTION BY TEMPERATURE

CITY MULTI could have varied capacity at different designing temperature. Using the nominal cooling/heating capacity value and the ratio below, the capacity can be observed at various temperature.

<Cooling>

Figure 7 Indoor unit temperature correction

To be used to correct indoor unit capacity only





Figure 8 Outdoor unit temperature correction

To be used to correct outdoor unit capacity only



<Heating>

PUMY-P36NKMU4

PUMY-P48NKMU4

PUMY-P60NKMU4

Figure 9 Indoor unit temperature correction

To be used to correct indoor unit capacity only





Figure 10 Outdoor unit temperature correction

To be used to correct outdoor unit capacity only



<Heating>

PUMY-HP36NKMU2

PUMY-HP42NKMU2

PUMY-HP48NKMU2

Figure 11 Indoor unit temperature correction
To be used to correct indoor unit capacity only






Figure 12 Outdoor unit temperature correction
To be used to correct outdoor unit capacity only



4-3. STANDARD OPERATION DATA (REFERENCE DATA)

Operation				PUMY-P36NKMU4		PUMY-P48NKMU4		PUMY-P60NKMU4	
Operating conditions	Ambient temperature	Indoor	DB/WB	80°F/67°F [26.7°C / 19.4°C]	70°F/60°F [21.1°C/15.6°C]	80°F/67°F [26.7°C/19.4°C]	70°F/60°F [21.1°C/15.6°C]	80°F/67°F [26.7°C/19.4°C]	70°F/60°F [21.1°C/15.6°C]
		Outdoor		95°F/75°F [35.0°C/23.9°C]	47°F / 43°F [8.3°C/6.1°C]	95°F/ 75°F [35.0°C / 23.9°C]	47°F/43°F [8.3°C/6.1°C]	95°F/75°F [35.0°C/23.9°C]	47°F/43°F [8.3°C/6.1°C]
	Indoor unit	No. of connected units	Unit	3		4		4	
		No. of units in operation		3		4		4	
		Model		12 × 3		12 × 4		15 × 4	
	Piping	Main pipe	Ft (m)	9.84 (3)		9.84 (3)		9.84 (3)	
		Branch pipe		14.76 (4.5)		14.76 (4.5)		14.76 (4.5)	
		Total pipe length		54.13 (16.5)		68.90 (21)		68.90 (21)	
	Fan speed		—	Hi		Hi		Hi	
	Amount of refrigerant		LBS. OZ. (kg)	17 LBS. (7.7)		17 LBS. 3 OZ. (7.8)		19 LBS. 6 OZ. (8.8)	
Outdoor unit	Electric current		A	10.2	13.3	15.6	17.1	19.3	20.4
	Voltage		V	230		230		230	
	Compressor frequency		Hz	47	66	64	81	53	64
LEV opening	Indoor unit		Pulse	268	438	247	313	386	498
Pressure	High pressure/Low pressure		PSIG [MPaG]	370/159 [2.55/1.10]	306/104 [2.11/0.72]	415/159 [2.86/1.09]	315/97 [2.17/0.67]	397/144 [2.75/1.02]	330/98 [2.28/0.68]
Temp. of each section	Outdoor unit	Discharge	°F[°C]	139.1 [59.5]	118.9 [48.3]	149.5 [65.3]	135.9 [57.7]	143.2 [61.8]	121.1 [49.5]
		Heat exchanger outlet		101.3 [38.5]	34.3 [1.3]	102.2 [39.0]	32.2 [0.1]	102.9 [39.4]	32.9 [0.5]
		Accumulator inlet		56.7 [13.7]	33.4 [0.8]	57.6 [14.2]	31.3 [-0.4]	52.3 [11.3]	32.3 [0.1]
		Compressor inlet		62.8 [17.1]	33.6 [0.9]	60.4 [15.8]	32.7 [0.4]	53.8 [12.1]	31.6 [-0.2]
	Indoor unit	Lev inlet		73.8 [23.2]	81.4 [27.4]	68.4 [20.2]	75.2 [24.0]	85.3 [29.6]	84.6 [29.2]
		Heat exchanger inlet		68.2 [20.1]	71.4 [21.9]	67.9 [19.9]	127.8 [53.2]	84.2 [29.0]	113.9 [45.5]




Operation				PUMY-HP36NKMU2		PUMY-HP42NKMU2		PUMY-HP48NKMU2	
Operating conditions	Ambient temperature	Indoor	DB/WB	80°F/67°F [26.7°C/19.4°C]	70°F/60°F [21.1°C/15.6°C]	80°F/67°F [26.7°C/19.4°C]	70°F/60°F [21.1°C/15.6°C]	80°F/67°F [26.7°C/19.4°C]	70°F/60°F [21.1°C/15.6°C]
		Outdoor		95°F/75°F [35.0°C/23.9°C]	47°F / 43°F [8.3°C/6.1°C]	95°F/ 75°F [35.0°C/23.9°C]	47°F/43°F [8.3°C/6.1°C]	95°F/ 75°F [35.0°C/23.9°C]	47°F/43°F [8.3°C/6.1°C]
	Indoor unit	No. of connected units	Unit	3		3		4	
		No. of units in operation		3		3		4	
		Model		12 × 3		12 × 2 + 18 × 1		12 × 4	
	Piping	Main pipe	Ft (m)	9.84 (3)		9.84 (3)		9.84 (3)	
		Branch pipe		14.76 (4.5)		14.76 (4.5)		14.76 (4.5)	
		Total pipe length		54.13 (16.5)		68.90 (21)		68.90 (21)	
	Fan speed		—	Hi		Hi		Hi	
	Amount of refrigerant		LBS. OZ. (kg)	17 LBS. (7.7)		17 LBS. (7.7)		17 LBS. 3 OZ. (7.8)	
Outdoor unit	Electric current		A	10.2	13.3	13.4	14.8	15.6	17.1
	Voltage		V	230		230		230	
	Compressor frequency		Hz	47	66	58	70	64	81
LEV opening	Indoor unit		Pulse	268	438	299/414	348/520	247	313
Pressure	High pressure/Low pressure		PSIG [MPaG]	370/159 [2.55/1.10]	306/104 [2.11/0.72]	419/155 [2.89/1.17]	347/115 [2.39/0.79]	415/159 [2.86/1.09]	316/96 [2.18/0.66]
Temp. of each section	Outdoor unit	Discharge	°F[°C]	139.1 [59.5]	118.9 [48.3]	142.9 [61.6]	131.7 [55.4]	149.5 [65.3]	128.1 [53.4]
		Heat exchanger outlet		101.3 [38.5]	34.3 [1.3]	100.9 [38.3]	32.9 [0.5]	102.2 [39.0]	32.4 [0.2]
		Accumulator inlet		56.7 [13.7]	33.4 [0.8]	55.4 [13.0]	31.8 [-0.1]	57.6 [14.2]	32.0 [0.0]
		Compressor inlet		62.8 [17.1]	33.6 [0.9]	54.5 [12.5]	31.1 [-0.5]	60.4 [15.8]	32.7 [0.4]
	Indoor unit	Lev inlet		73.8 [23.2]	81.4 [27.4]	73.8 [23.2]	79.0 [26.1]	68.4 [20.2]	68.7 [20.4]
		Heat exchanger inlet		68.2 [20.1]	71.4 [21.9]	56.5 [13.6]	123.8 [51.0]	67.9 [19.9]	122.0 [50.0]



4-4. STANDARD CAPACITY DIAGRAM

Before calculating the sum of total capacity of indoor units, please convert the value into the kBTu/h model capacity following the formula on "4-1. Method for obtaining system cooling and heating capacity".

4-4-1. PUMY-P36NKMU4 PUMY-HP36NKMU2 <Cooling>





— 208, 230 V

4-4-2. PUMY-P36NKMU4

PUMY-HP36NKMU2




<Heating>





4-4-3. PUMY-HP42NKMU2




<Cooling>



— 208, 230 V

4-4-4. PUMY-HP42NKMU2

<Heating>






— 208, 230 V

4-4-5. PUMY-P48NKMU4

PUMY-HP48NKMU2

<Cooling>






— 208, 230 V


4-4-6. PUMY-P48NKMU4

PUMY-HP48NKMU2

<Heating>






208, 230 V






4-4-7. PUMY-P60NKMU4

<Cooling>



4-4-8. PUMY-P60NKMU4

<Heating>



4-5. CORRECTING CAPACITY FOR CHANGES IN THE LENGTH OF REFRIGERANT PIPING

- (1) During cooling, obtain the ratio (and the equivalent piping length) of the outdoor units rated capacity and the total in-use indoor capacity, and find the capacity ratio corresponding to the standard piping length from Figure 13 to 17. Then multiply by the cooling capacity from Figure 7 and 8 in "4-2. CORRECTION BY TEMPERATURE" to obtain the actual capacity.
- (2) During heating, find the equivalent piping length, and find the capacity ratio corresponding to standard piping length from Figure 18. Then multiply by the heating capacity from Figure 9 and 10 in "4-2. CORRECTION BY TEMPERATURE" to obtain the actual capacity.

(1) Capacity Correction Curve

Figure 13 PUMY-P36NKMU4 PUMY-HP36NKMU2 <Cooling>




Figure 14 PUMY-HP42NKMU2 <Cooling>




Figure 15 PUMY-P48NKMU4

PUMY-HP48NKMU2

<Cooling>




Figure 16 PUMY-P60NKMU4

<Cooling>




Figure 17 PUMY-P36NKMU4

PUMY-HP36NKMU2

PUMY-HP42NKMU2

PUMY-P48NKMU4

PUMY-HP48NKMU2

<Heating>





Figure 18 PUMY-P60NKMU4

<Heating>



(2) Method for Obtaining the Equivalent Piping Length

Equivalent length = (length of piping to farthest indoor unit) + (0.99 × number of bends in the piping) (ft)

4-5-1. Correction of Heating Capacity for Frost and Defrosting

If heating capacity has been reduced due to frost formation or defrosting, multiply the capacity by the appropriate correction factor from the following table to obtain the actual heating capacity.


Correction factor diagram

Outdoor Intake temperature <W.B.°F (°C)>	43(6)	37(4)	36(2)	32(0)	28(-2)	25(-4)	21(-6)	18(-8)	14(-10)	5(-15)	-4(-20)	-13(-25)
Correction factor	1.00	0.98	0.89	0.88	0.89	0.90	0.95	0.95	0.95	0.95	0.95	0.95

4-6. NOISE CRITERION CURVES


PUMY-P36NKMU4
PUMY-HP36NKMU2

MODE	SPL(dB)	LINE
COOLING	49	○—○
HEATING	53	●—●




PUMY-HP42NKMU2

MODE	SPL(dB)	LINE
COOLING	50	○—○
HEATING	54	●—●





PUMY-P48NKMU4
PUMY-HP48NKMU2


MODE	SPL(dB)	LINE
COOLING	51	○—○
HEATING	54	●—●



PUMY-P60NKMU4


MODE	SPL(dB)	LINE
COOLING	58	○—○
HEATING	59	●—●



Unit: mm
<in.>

PUMY-P36NKMU4


PUMY-P48NKMU4



[LEGEND]

SYMBOL	NAME	SYMBOL	NAME	SYMBOL	NAME
TB1	Terminal Block (Power Supply)	TH8	Thermistor (Heat Sink)	SW5	Switch (Function Selection)
TB1B	Terminal Block (Branch box)	TRS	Thermal Protector	SW6	Switch (Function Selection)
TB3	Terminal Block (Indoor/Outdoor, Branch box/Outdoor Transmission Line)	LEV-A, LEV-B	Linear Expansion Valve	SW7	Switch (Function Selection)
TB7	Terminal Block (Centralized Control Transmission Line)	DCL1, DCL2, DCL3	Reactor	SW8	Switch (Model Selection)
FUSE1, FUSE2	Fuse (T20A L250V)	P.B.	Power Circuit Board	SW9	Switch (Function/Model Selection)
MC	Motor for Compressor	U/V/W	Connection Terminal (U/V/W-Phase)	SWU1	Switch (Unit Address Selection, ones digit)
MF1, MF2	Fan Motor	LI	Connection Terminal (L1-Phase)	SWU2	Switch (Unit Address Selection, tens digit)
21S4	Solenoid Valve Coil (4-Way Valve)	NI	Connection Terminal (L2-Phase)	SS/BH	Connector (Connection for Option)
63H	High Pressure Switch	TB1A, TB2A, TB3A	Connection Terminal (Reactor)	CN3D	Connector (Connection for Option)
63HS	High Pressure Sensor	IC500	Converter	CN3S	Connector (Connection for Option)
63LS	Low Pressure Sensor	IC600	Inverter	CN3N	Connector (Connection for Option)
SV1	Solenoid Valve Coil (Bypass Valve)	E1, E3, E4	Connection Terminal (Electrical Parts Box)	CN51	Connector (Connection for Option)
TH2	Thermistor (HIC Pipe)	MULTI.B.	Multi Controller Circuit Board	LED1, LED2	LED (Operation Inspection Display)
TH3	Thermistor (Outdoor Liquid Pipe)	SW1	Switch (Display Selection)	LED3	LED (Power Supply to Main Microcomputer)
TH4	Thermistor (Compressor)	SW2	Switch (Function/Model Selection)	F1, F2	Fuse (T6.3A L250V)
TH6	Thermistor (Suction Pipe)	SW3	Switch (Test Run)	X501~X505	Relay
TH7	Thermistor (Ambient)	SW4	Switch (Model Selection)	M-NET P.B.	M-NET Power Circuit Board
				TB1	Connection Terminal (Electrical Parts Box)

PUMY-P60NKMU4




[LEGEND]

SYMBOL	NAME	SYMBOL	NAME	SYMBOL	NAME
TB1	Terminal Block (Power Supply)	TRS	Thermal Protector	SW4	Switch (Model Selection)
TB1B	Terminal Block (Branch box)	LEV-A, LEV-B	Linear Expansion Valve	SW5	Switch (Function Selection)
TB3	Terminal Block (Indoor/Outdoor, Branch box/Outdoor Transmission Line)	DCL1, DCL2, DCL3	Reactor	SW6	Switch (Function Selection)
TB7	Terminal Block (Centralized Control Transmission Line)	N.F.	Noise Filter Board	SW7	Switch (Function Selection)
FUSE1, FUSE2	Fuse (T20A L250V)	LI	Connection Terminal (L1-Phase)	SW8	Switch (Model Selection)
MC	Motor for Compressor	NI	Connection Terminal (L2-Phase)	SW9	Switch (Function/Model Selection)
MF1, MF2	Fan Motor	TB1, TB2	Connection Terminal (Power Circuit Board)	SWU1	Switch (Unit Address Selection, ones digit)
21S4	Solenoid Valve Coil (4-Way Valve)	EI, E3, E4	Connection Terminal (Electrical Parts Box)	SWU2	Switch (Unit Address Selection, tens digit)
63H	High Pressure Switch	P.B.	Power Circuit Board	SS/BH	Connector (Connection for Option)
63HS	High Pressure Sensor	TB3, TB4	Connection Terminal (Noise Filter Board)	CN3D	Connector (Connection for Option)
63LS	Low Pressure Sensor	U/V/W	Connection Terminal (U/V/W-Phase)	CN3S	Connector (Connection for Option)
SV1	Solenoid Valve Coil (Bypass Valve)	TB1A, TB2A, TB3A	Connection Terminal (Reactor)	CN3N	Connector (Connection for Option)
TH2	Thermistor (HIC Pipe)	TB1B, TB2B, TB3B		CN51	Connector (Connection for Option)
TH3	Thermistor (Outdoor Liquid Pipe)	IC500	Converter	LED1, LED2	LED (Operation Inspection Display)
TH4	Thermistor (Compressor)	IC600	Inverter	LED3	LED (Power Supply to Main Microcomputer)
TH6	Thermistor (Suction Pipe)	MULTI.B.	Multi Controller Circuit Board	F1, F2	Fuse (T6.3A L250V)
TH7	Thermistor (Ambient)	SW1	Switch (Display Selection)	X501~X505	Relay
TH8	Thermistor (Heat Sink)	SW2	Switch (Function/Model Selection)	M-NET P.B.	M-NET Power Circuit Board
		SW3	Switch (Test Run)	TB1	Connection Terminal (Electrical Parts Box)

PUMY-HP36NKMU2

PUMY-HP42NKMU2

PUMY-HP48NKMU2



*1 MODEL SELECTION

The black square (■) indicates a switch position.

MODEL	SW2	SW4	SW8	SW9	MODEL	SW2	SW4	SW8	SW9	MODEL	SW2	SW4	SW8	SW9
PUMY-HP36NKMU2	ON OFF	ON OFF	ON OFF	ON OFF	PUMY-HP42NKMU2	ON OFF	ON OFF	ON OFF	ON OFF	PUMY-HP48NKMU2	ON OFF	ON OFF	ON OFF	ON OFF
	1 2 3 4 5 6	1 2 3 4 5 6	1 2 3 4 5 6	1 2 3 4 5 6		1 2 3 4 5 6	1 2 3 4 5 6	1 2 3 4 5 6	1 2 3 4 5 6		1 2 3 4 5 6	1 2 3 4 5 6	1 2 3 4 5 6	1 2 3 4 5 6

*2 Use copper supply wires.


Utiliser des fils d'alimentation en cuivre.

*3 When a Branch box is connected, SW2-5 should be ON.

[LEGEND]

SYMBOL	NAME	SYMBOL	NAME	SYMBOL	NAME
TB1	Terminal Block (Power Supply)	TH7	Thermistor (Ambient)	SW3	Switch (Test Run)
TB1B	Terminal Block (Branch box)	TH8	Thermistor (Heat Sink)	SW4	Switch (Model Selection)
TB3	Terminal Block (Indoor/Outdoor, Branch box/Outdoor Transmission Line)	TRS	Thermal Protector<Compressor>	SW5	Switch (Function Selection)
TB7	Terminal Block (Centralized Control Transmission Line)	LEV-A, LEV-B	Linear Expansion Valve	SW6	Switch (Function Selection)
		DCL1, DCL2, DCL3	Reactor	SW7	Switch (Function Selection)
FUSE1, FUSE2	Fuse (T20A L250V)	N.F.	Noise Filter Board	SW8	Switch (Model Selection)
MC	Motor for Compressor	LI	Connection Terminal (L1-Phase)	SW9	Switch (Function/Model Selection)
MF1, MF2	Fan Motor	NI	Connection Terminal (L2-Phase)	SWU1	Switch (Unit Address Selection, ones digit)
21S4	Solenoid Valve Coil (4-Way Valve)	TB1, TB2	Connection Terminal (Power Circuit Board)	SWU2	Switch (Unit Address Selection, tens digit)
63H	High Pressure Switch	E1, E3, E4	Connection Terminal (Electrical Parts Box)	SS/BH	Connector (Connection for Option)
63HS	High Pressure Sensor	P.B.	Power Circuit Board	CN3D	Connector (Connection for Option)
63LS	Low Pressure Sensor	TB3, TB4	Connection Terminal (Noise Filter Board)	CN3S	Connector (Connection for Option)
SV1	Solenoid Valve Coil (Bypass Valve)	U/V/W	Connection Terminal (U/V/W-Phase)	CN3N	Connector (Connection for Option)
SV2	Solenoid Valve Coil (Switching Valve)	TB1A, TB2A, TB3A	Connection Terminal (Reactor)	CN51	Connector (Connection for Option)
BH	Base Heater	TB1B, TB2B, TB3B	Connection Terminal (Reactor)	LED1, LED2	LED (Operation Inspection Display)
THP	Thermal Protector<Base Heater>	IC500	Converter	LED3	LED (Power Supply to Main Microcomputer)
TH2	Thermistor (HIC Pipe)	IC600	Inverter	F1, F2	Fuse (T6.3A L250V)
TH3	Thermistor (Outdoor Liquid Pipe)	MULTI.B.	Multi Controller Circuit Board	X501~X505	Relay
TH4	Thermistor (Compressor)	SW1	Switch (Display Selection)	M-NET P.B.	M-NET Power Circuit Board
TH6	Thermistor (Suction Pipe)	SW2	Switch (Function/Model Selection)	TB1	Connection Terminal (Electrical Parts Box)

7-1. TRANSMISSION SYSTEM SETUP




7-2. Special Function Operation and Settings for M-NET Remote Controller

For the detailed procedure of "group settings" and "paired settings", refer to the remote controller's manuals.

7-3. REFRIGERANT SYSTEM DIAGRAM


PUMY-P36NKMU4

PUMY-P48NKMU4




Capillary tube for oil separator [in. (mm)]: $\varnothing 0.098 \times \varnothing 0.031 \times L39.37$ ($\varnothing 2.5 \times \varnothing 0.8 \times L1000$)

PUMY-HP36NKMU2
PUMY-HP42NKMU2
PUMY-HP48NKMU2



Capillary tube for oil separator [in. (mm)]: $\varnothing 0.098 \times \varnothing 0.031 \times L39.37$ ($\varnothing 2.5 \times \varnothing 0.8 \times L1000$)

PUMY-P60NKMU4




Capillary tube for oil separator [in. (mm)]: $\varnothing 0.098 \times \varnothing 0.031 \times L31.50$ ($\varnothing 2.5 \times \varnothing 0.8 \times L800$)

Capillary tube for solenoid valve [in. (mm)]: $\varnothing 0.157 \times \varnothing 0.117 \times L19.685$ ($\varnothing 4.0 \times \varnothing 3.0 \times L500$)

PUMY-P36NKMU4

PUMY-P48NKMU4




Unit: in. (mm)

	Capillary tube 1 (For return of oil from oil separator)	Capillary tube 2 behind LEV (in cooling mode)
Outdoor unit	$\varnothing 0.098 \times \varnothing 0.031 \times L(39-1/2)$ ($\varnothing 2.5 \times \varnothing 0.8 \times L1000$)	—
Branch box	—	$(\varnothing 0.157 \times \varnothing 0.117 \times L(5-1/8)) \times 5$ ($(\varnothing 4.0 \times \varnothing 3.0 \times L130) \times 5$)
	—	$(\varnothing 0.157 \times \varnothing 0.117 \times L(5-1/8)) \times 3$ ($(\varnothing 4.0 \times \varnothing 3.0 \times L130) \times 3$)

PUMY-HP36NKMU2

PUMY-HP42NKMU2


PUMY-HP48NKMU2



Unit: in. (mm)

	Capillary tube 1 (For return of oil from oil separator)	Capillary tube 2 behind LEV (in cooling mode)
Outdoor unit	$\varnothing 0.098 \times \varnothing 0.031 \times L(39-1/2)$ ($\varnothing 2.5 \times \varnothing 0.8 \times L1000$)	—
Branch box	—	$(\varnothing 0.157 \times \varnothing 0.117 \times L(5-1/8)) \times 5$ ($(\varnothing 4.0 \times \varnothing 3.0 \times L130) \times 5$)
	—	$(\varnothing 0.157 \times \varnothing 0.117 \times L(5-1/8)) \times 3$ ($(\varnothing 4.0 \times \varnothing 3.0 \times L130) \times 3$)

PUMY-P60NKMU4






	Capillary tube 1 (For return of oil from oil separator)	Capillary tube 2 (For solenoid valve (SV1))	Capillary tube 3 behind LEV (in cooling mode)
Outdoor unit	$\varnothing 0.098 \times \varnothing 0.031 \times L(39-1/2)$ ($\varnothing 2.5 \times \varnothing 0.8 \times L800$)	$\varnothing 0.157 \times \varnothing 0.117 \times L(19-5/8)$ ($\varnothing 4.0 \times \varnothing 3.0 \times L500$)	———
Branch box	———	———	$(\varnothing 0.157 \times \varnothing 0.117 \times L(5-1/8)) \times 5$ ($(\varnothing 4.0 \times \varnothing 3.0 \times L130) \times 5$)
	———	———	$(\varnothing 0.157 \times \varnothing 0.117 \times L(5-1/8)) \times 3$ ($(\varnothing 4.0 \times \varnothing 3.0 \times L130) \times 3$)

7-4. SYSTEM CONTROL

7-4-1. Example for the System




- Example for wiring control cables, wiring method and address setting, permissible lengths, and the constraint items are listed in the standard system with detailed explanation.

A. Example of an M-NET remote controller system (address setting is necessary.)


Example of wiring control cables		Wiring Method and Address Setting																
<div>1. Standard operation</div> <div></div> <div><ul style="list-style-type: none">• 1 M-NET remote controller for each CITY MULTI series indoor unit• There is no need for setting the 100 position on the M-NET remote controller.</div>		<div>a. Use feed wiring to connect terminals M1 and M2 on transmission cable block (TB3) for the outdoor unit (OC) to terminals M1 and M2 on the transmission cable block (TB5) of each CITY MULTI series indoor unit (M-IC). Use non-polarized 2-core wire.</div> <div>b. Connect terminals M1 and M2 on transmission cable terminal block (TB5) for each indoor unit with the terminal block (TB6) for M-NET the remote controller (M-NET RC).</div> <div>c. Set the address setting switch (on outdoor unit P.C.B) as shown below.</div> <table><tr><th>Unit</th><th>Range</th><th>Setting Method</th></tr><tr><td>CITY MULTI series indoor unit (M-IC)</td><td>001 to 050</td><td>—</td></tr><tr><td>Outdoor unit (OC)</td><td>051 to 100</td><td>Use the smallest address of all the indoor unit plus 50.</td></tr><tr><td>M-NET Remote controller (M-NET RC)</td><td>101 to 150</td><td>Indoor unit address plus 100</td></tr></table>		Unit	Range	Setting Method	CITY MULTI series indoor unit (M-IC)	001 to 050	—	Outdoor unit (OC)	051 to 100	Use the smallest address of all the indoor unit plus 50.	M-NET Remote controller (M-NET RC)	101 to 150	Indoor unit address plus 100			
Unit	Range	Setting Method																
CITY MULTI series indoor unit (M-IC)	001 to 050	—																
Outdoor unit (OC)	051 to 100	Use the smallest address of all the indoor unit plus 50.																
M-NET Remote controller (M-NET RC)	101 to 150	Indoor unit address plus 100																
<div>2. Operation using 2 M-NET remote controllers</div> <div></div> <div><ul style="list-style-type: none">• Using 2 M-NET remote controllers for each CITY MULTI series indoor unit.</div>		<div>a. Same as above 1.a</div> <div>b. Same as above 1.b</div> <div>c. Set address switch (on outdoor unit P.C.B) as shown below.</div> <table><tr><th>Unit</th><th>Range</th><th>Setting Method</th></tr><tr><td>CITY MULTI series indoor unit (M-IC)</td><td>001 to 050</td><td>—</td></tr><tr><td>Outdoor unit (OC)</td><td>051 to 100</td><td>Use the smallest address of all the indoor units plus 50.</td></tr><tr><td>Main M-NET Remote Controller (M-NET RC)</td><td>101 to 150</td><td>Indoor unit address plus 100</td></tr><tr><td>Sub M-NET Remote Controller (M-NET RC)</td><td>151 to 200</td><td>Indoor unit address plus 150</td></tr></table>		Unit	Range	Setting Method	CITY MULTI series indoor unit (M-IC)	001 to 050	—	Outdoor unit (OC)	051 to 100	Use the smallest address of all the indoor units plus 50.	Main M-NET Remote Controller (M-NET RC)	101 to 150	Indoor unit address plus 100	Sub M-NET Remote Controller (M-NET RC)	151 to 200	Indoor unit address plus 150
Unit	Range	Setting Method																
CITY MULTI series indoor unit (M-IC)	001 to 050	—																
Outdoor unit (OC)	051 to 100	Use the smallest address of all the indoor units plus 50.																
Main M-NET Remote Controller (M-NET RC)	101 to 150	Indoor unit address plus 100																
Sub M-NET Remote Controller (M-NET RC)	151 to 200	Indoor unit address plus 150																
<div>3. Group operation</div> <div></div> <div><ul style="list-style-type: none">• Multiple CITY MULTI series indoor units operated together by 1 M-NET remote controller</div> <div>Combinations of 1 through 3 above are possible.</div>		<div>a. Same as above 1.a</div> <div>b. Connect terminals M1 and M2 on transmission cable terminal block (TB5) of the M-IC main unit with the most recent address within the same CITY MULTI series indoor unit (M-IC) group to terminal block (TB6) on the M-NET remote controller.</div> <div>c. Set the address setting switch (on outdoor unit P.C.B) as shown below.</div> <table><tr><th>Unit</th><th>Range</th><th>Setting Method</th></tr><tr><td>M-IC (Main)</td><td>001 to 050</td><td>Use the smallest address within the same group of CITY MULTI series indoor units.</td></tr><tr><td>M-IC (Sub)</td><td>001 to 050</td><td>Use an address, other than that of the M-IC (Main) from among the units within the same group of indoor units. This must be in sequence with the M-IC (Main).</td></tr><tr><td>Outdoor unit</td><td>051 to 100</td><td>Use the smallest address of all the CITY MULTI series indoor units plus 50.</td></tr><tr><td>Main M-NET Remote Controller (M-NET RC)</td><td>101 to 150</td><td>Set at an M-IC (Main) address within the same group plus 100.</td></tr></table> <div>d. Use the CITY MULTI series indoor unit (M-IC) within the group with the most functions as the M-IC (Main) unit.</div>		Unit	Range	Setting Method	M-IC (Main)	001 to 050	Use the smallest address within the same group of CITY MULTI series indoor units.	M-IC (Sub)	001 to 050	Use an address, other than that of the M-IC (Main) from among the units within the same group of indoor units. This must be in sequence with the M-IC (Main).	Outdoor unit	051 to 100	Use the smallest address of all the CITY MULTI series indoor units plus 50.	Main M-NET Remote Controller (M-NET RC)	101 to 150	Set at an M-IC (Main) address within the same group plus 100.
Unit	Range	Setting Method																
M-IC (Main)	001 to 050	Use the smallest address within the same group of CITY MULTI series indoor units.																
M-IC (Sub)	001 to 050	Use an address, other than that of the M-IC (Main) from among the units within the same group of indoor units. This must be in sequence with the M-IC (Main).																
Outdoor unit	051 to 100	Use the smallest address of all the CITY MULTI series indoor units plus 50.																
Main M-NET Remote Controller (M-NET RC)	101 to 150	Set at an M-IC (Main) address within the same group plus 100.																

• Name, Symbol and the Maximum Remote controller Units for Connection

Name	Symbol	Maximum units for connection
Outdoor unit	OC	—
CITY MULTI series indoor unit	M-IC	Refer to "3. SPECIFICATIONS".
M-NET remote controller	M-NET RC	Maximum 2 M-NET RC for 1 indoor unit, Maximum 12 M-NET RC for 1 OC

Permissible Lengths	Constraint items
<p>Indoor/outdoor transmission line</p> <p>Maximum length</p> <p>AWG 16 [1.25 mm²]</p> <p>$L_1 + L_2 \leq 656 \text{ ft [200 m]}$</p> <p>M-NET Remote controller cable length</p> <p>1. If AWG 20 to AWG 16 [0.5 to 1.25 mm²]</p> <p>$l_1, l_2 \leq 33 \text{ ft [10 m]}$</p> <p>2. If the length exceeds 33ft [10 m], the exceeding section should be AWG 16 [1.25 mm²] and that section should be a value within the total extension length of the transmission cable and maximum transmission cable length. (L3)</p>	<ul style="list-style-type: none"> M-NET remote controller (M-NET RC) and MA remote controller (MA RC) cannot be used together. Do not connect anything with TB15 of CITY MULTI series indoor unit (M-IC). 
Same as above	 <ol style="list-style-type: none"> ① Use the CITY MULTI series indoor unit (M-IC) address plus 150 as the sub M-NET remote controller address. In this case, it should be 152. ② 3 or more M-NET remote controllers (M-NET RC) cannot be connected to 1 CITY MULTI series indoor unit.
Same as above	 <ol style="list-style-type: none"> ① The M-NET remote controller address is the CITY MULTI series indoor unit main address plus 100. In this case, it should be 101.

- B. Example of a group operation system with 2 or more outdoor units and an M-NET remote controller.
(Address settings are necessary.)







• Name, Symbol, and the Maximum Units for Connection

Permissible Length	<ul style="list-style-type: none"> Maximum line length via outdoor unit: $L_1+L_2+L_3+L_4$, $L_3+L_4+L_5+L_6$, $L_1+L_2+L_5+L_6 \leq 1640$ ft [500 m] (AWG16 [1.25 mm²]) Indoor/outdoor transmission line Maximum length: L_1, L_3+L_4, L_2+L_5, $L_6 \leq 656$ ft [200 m] (AWG16 [1.25 mm²]) M-NET Remote controller cable length: $l_1, l_2 + l_3 \leq 33$ ft [10 m] (AWG20 to AWG16 [0.5 to 1.25 mm²]) <p>If the length exceeds 33 ft [10 m], use an AWG16 [1.25 mm²] shielded wire. The section of the cable that exceeds 33 ft [10 m] must be included in the max length via outdoor units and max transmission cable length.</p>
Prohibited items	<p> (A) : Group (B) : Group (C) : Group (D) : Shielded Wire (E) : Sub M-NET Remote Controller () : Address example </p> <ul style="list-style-type: none"> Never connect together the terminal blocks (TB5) for transmission wires for CITY MULTI series indoor unit (M-IC) that have been connected to different outdoor units (OC). Set all addresses to ensure that they are not overlapped. M-NET remote controller and MA remote controller cannot be connected with the CITY MULTI series indoor unit of the same group wiring together.

C. Example of an MA remote controller system (address setting is not necessary.)


NOTE: In the case of same group operation, need to set the address that is only main CITY MULTI series indoor unit.

Example of wiring control cables	Wiring Method and Address Setting
<p>1. Standard operation</p>  <p>• 1 MA remote controller for each indoor unit</p>	<p>a. Use feed wiring to connect terminals M1 and M2 on transmission cable block (TB3) for the outdoor unit (OC) to terminals M1 and M2 on the transmission cable block (TB5) of each CITY MULTI series indoor unit (M-IC). Use non-polarized 2-core wire.</p> <p>b. Connect terminals 1 and 2 on transmission cable terminal block (TB15) for each CITY MULTI series indoor unit with the terminal block for the MA remote controller (MA-RC).</p>
<p>2. Operation using 2 remote controllers</p>  <p>• Using 2 MA remote controllers for each CITY MULTI series indoor unit</p>	<p>a. The same as above a</p> <p>b. The same as above b</p> <p>c. In the case of using 2 remote controllers, connect terminals 1 and 2 on transmission cable terminal block (TB15) for each indoor unit with the terminal block for 2 MA remote controllers.</p> <p>• Set either one of the controllers to "sub remote controller".</p> <p>Refer to the installation manual of MA remote controller.</p>
<p>3. Group operation</p>  <p>• Multiple indoor units operated together by 1 MA remote controller</p>	<p>a. The same as above a</p> <p>b. The same as above b</p> <p>c. In the case of group operation using MA remote controller (MA-RC), connect terminals 1 and 2 on transmission cable terminal block (TB15) of each CITY MULTI series indoor unit. Use non-polarized 2-core wire.</p> <p>d. In the case of same group operation, need to set the address that is only main CITY MULTI series indoor unit. Please set the smallest address within number 01–50 of the CITY MULTI series indoor unit with the most functions in the same group.</p>
<p>Combinations of 1 through 3 above are possible.</p>	



Permissible Lengths	Prohibited items
<p>Indoor/outdoor transmission line Maximum length: $L_1 + L_2 \leq 656 \text{ ft [200 m]}$ (AWG 16 [1.25 mm²]) MA remote controller cable length: $\ell_1, \ell_2 \leq 656 \text{ ft [200 m]}$ (AWG 22 to AWG 16 [0.3 to 1.25 mm²])</p>	<p>The MA remote controller and the M-NET remote controller cannot be used together with the CITY MULTI series indoor unit of the same group. M-NET remote controller cannot be connected without address setting.</p>
<p>Indoor/outdoor transmission line Maximum length: $L_1 + L_2 \leq 656 \text{ ft [200 m]}$ (AWG 16 [1.25 mm²]) MA remote controller cable length: $\ell_3 + \ell_4, \ell_5 \leq 656 \text{ ft [200 m]}$ (AWG 22 to AWG 16 [0.3 to 1.25 mm²])</p>	<p>3 MA remote controllers or more cannot be connected with the CITY MULTI series indoor unit of the same group.</p>
<p>Indoor/outdoor transmission line Maximum length: $L_1 + L_2 \leq 656 \text{ ft [200 m]}$ (AWG 16 [1.25 mm²]) MA remote controller cable length: $\ell_6 + \ell_7 \leq 656 \text{ ft [200 m]}$ (AWG 22 to AWG 16 [0.3 to 1.25 mm²])</p>	<p>The second MA remote controller is connected with the terminal block (TB15) for the MA remote controller of the same CITY MULTI series indoor unit (M-IC) as the first MA remote control.</p>


D. Example of a group operation with 2 or more outdoor units and an MA remote controller.
(Address settings are necessary.)



• Name, Symbol, and the Maximum Units for Connection

Permissible Length	<p>Maximum line length via outdoor unit (M-NET cable): $L_1+L_2+L_3+L_4$ and $L_1+L_2+L_6+L_7 \leq 1640$ ft [500 m] (AWG 16 [1.25 mm²] or more)</p> <p>Indoor/outdoor transmission line Maximum length (M-NET cable): L_1 and L_3+L_4 and L_2+L_6 and $L_7 \leq 656$ ft [200 m] (AWG 16 [1.25 mm²] or more)</p> <p>MA Remote controller cable length: m_1 and $m_1+m_2+m_3$ and $m_1+m_2+m_3+m_4 \leq 656$ ft [200 m] (AWG 22 to AWG 16 [0.3 to 1.25 mm²])</p>
Prohibited items	<p> (A) : Group (B) : Group (C) : Group (D) : Shielded Wire (E) : Sub MA Remote Controller () : Address example </p> <ul style="list-style-type: none"> • Never connect together the terminal blocks (TB5) for transmission wires for CITY MULTI series indoor unit (M-IC) that have been connected to different outdoor units (OC). • M-NET remote controller and MA remote controller cannot be connected with the CITY MULTI series indoor unit of the same group wiring together.

E. Example of a system using Branch Box and A-Control indoor unit




• Name, Symbol, and the Maximum Units for Connection

Permissible Length

Maximum line length via outdoor unit (M-NET cable): $L_1+L_2+L_3+L_4+L_5 \leq 1640$ ft [500 m] (AWG16 [1.25 mm²] or more)
 Branch box/outdoor transmission line Maximum length (M-NET cable): $L_1+L_2, L_3+L_4, L_5 \leq 656$ ft [200 m] (AWG16 [1.25 mm²] or more)
 Indoor/Branch box transmission line Maximum length (A-Control cable): $L_6 \leq 82$ ft [25 m] (AWG14 [1.5 mm²])
 Remote controller cable length: $m_1 \leq 656$ ft [200 m] (AWG22 to AWG16 [0.3 to 1.25 mm²])

Constraint items



- Plural indoor units cannot be operated by an MA single remote controller.
- Different refrigerant systems cannot be connected together.
- M-NET Remote controller cannot be connected to this system.

8-1. CHECKPOINTS FOR TEST RUN

8-1-1. Procedures before test run

- (1) Before a test run, make sure that the following work is completed.
 - Installation related:
 - Make sure that the panel of cassette type and electrical wiring are done.
 - Otherwise electrical functions like auto vane will not operate normally.
 - Piping related:
 - Perform leakage test of refrigerant and drain piping.
 - Make sure that all joints are perfectly insulated.
 - Check stop valves on both liquid and gas side for full open.
 - Electrical wiring related:
 - Check ground wire, transmission cable, remote controller cable, and power supply cable for secure connection.
 - Make sure that all switch settings of address or adjustments for special specification systems are correctly settled.
- (2) Safety check:
 - With the insulation tester of 500 V, inspect the insulation resistance.
 - Do not touch the transmission cable and remote controller cable with the tester.
 - The resistance should be over 1.0 MΩ. Do not proceed inspection if the resistance is less than 1.0 MΩ.
 - Inspect between the outdoor unit power supply terminal block and ground first, metallic parts like refrigerant pipes or the electrical box next, then inspect all electrical wiring of outdoor unit, indoor unit, and all linked equipment.
- (3) Before operation:
 - a) Turn the power supply switch of the outdoor unit to on for compressor protection. For a test run, wait at least 12 hours from this point.
 - b) Register control systems into remote controller(s). Never touch the ON/OFF switch of the remote controller(s). Refer to "7-2. Special Function Operation and Settings for M-NET Remote Controller" as for settings. In MA remote controller(s), this registration is unnecessary.
- (4) More than 12 hours later from power supply to the outdoor unit, turn all power switch to on for the test run. Perform test run according to the "Operation procedure" table of the bottom of this page. While test running, make test run reports.

8-1-1-1. Test run for M-NET Remote controller

Refer to "12-4. TEST RUN" for operation procedure.

8-1-2. Countermeasures For Error During Test Run

If a problem occurs during test run, a code number will appear on the remote controller (or LED on the outdoor unit), and the air conditioning system will automatically cease operating.

Determine the nature of the abnormality and apply corrective measures.

Check code (2 digits)	Check code (4 digits)	Trouble	Detected Unit			Remarks
			Indoor	Outdoor	Remote Controller	
Ed	0403	Serial communication error or Model selection SW error		○		Outdoor unit Multi controller board–Power board communication trouble
U2	1102	Compressor temperature trouble		○		Check delay code 1202
UE	1302	High pressure trouble or thermal protector trouble		○		Check delay code 1402
U7	1500	Superheat due to low discharge temperature trouble		○		Check delay code 1600
U2	1501	Refrigerant shortage trouble		○		Check delay code 1601
		Closed valve in cooling mode		○		Check delay code 1501
P6	1503	Freeze protection of Branch box or Indoor unit	○			
EF	1508	4-way valve trouble in heating mode		○		Check delay code 1608
L6	2135	Circulation water freeze protection	○			
PA	2500	Water leakage	○			
P5	2502	Drain overflow protection	○			
P4	2503	Drain sensor abnormality	○			
-	3121	Out-of-range outside air temperature		○		
UF	4100	Compressor current interruption (Locked compressor)		○		Check delay code 4350
Pb	4114	Fan trouble (Indoor)	○			
UP	4210	Compressor overcurrent interruption/failure in 12 VDC power supply circuit on power circuit board		○		
U9	4220	Voltage shortage/overvoltage/PAM error/L1 open phase/power synchronization signal error		○		Check delay code 4320
U5	4230	Heat sink temperature trouble		○		Check delay code 4330
U6	4250	Power module trouble or overcurrent trouble		○		Check delay code 4350
U8	4400	Fan trouble (Outdoor)		○		Check delay code 4500
U3	5101	Air inlet thermistor (TH21) open/short	○			
		Compressor temperature thermistor (TH4) open/short		○		Check delay code 1202
U4	5102	Liquid pipe temperature thermistor (TH22) open/short	○			
		Suction pipe temperature thermistor (TH6) open/short		○		Check delay code 1211
U4	5103	Gas pipe temperature thermistor (TH23) open/short	○			
U4	5105	Outdoor liquid pipe temperature thermistor (TH3) open/short		○		Check delay code 1205
U4	5106	Ambient temperature thermistor (TH7) open/short		○		Check delay code 1221
U4	5109	HIC pipe temperature thermistor (TH2) open/short		○		Check delay code 1222
U4	5110	Heat sink temperature thermistor (TH8) open/short		○		Check delay code 1214
F5	5201	High pressure sensor (63HS) trouble		○		Check delay code 1402
F3	5202	Low pressure sensor (63LS) trouble		○		Check delay code 1400
UH	5300	Primary current error		○		Check delay code 4310
P4	5701	Contact failure of drain float switch	○			
A0	6600	Duplex address error	○	○	○	Only M-NET Remote controller is detected.
A2	6602	Transmission processor hardware error	○	○	○	Only M-NET Remote controller is detected.
A3	6603	Transmission bus BUSY error	○	○	○	Only M-NET Remote controller is detected.
A6	6606	Signal communication error with transmission processor	○	○	○	Only M-NET Remote controller is detected.
A7	6607	No ACK error	○		○	Only M-NET Remote controller is detected.
A8	6608	No response frame error	○		○	Only M-NET Remote controller is detected.
E0/E4	6831	MA communication receive error	○		○	Only MA Remote controller is detected.
E3/E5	6832	MA communication send error	○		○	Only MA Remote controller is detected.
E3/E5	6833	MA communication send error	○		○	Only MA Remote controller is detected.
E0/E4	6834	MA communication receive error	○		○	Only MA Remote controller is detected.
EF	7100	Total capacity error		○		
EF	7101	Capacity code error	○	○		
EF	7102	Connecting excessive number of units and Branch boxes		○		
EF	7105	Address setting error		○		
EF	7130	Incompatible unit combination error		○		

NOTES:

- When the outdoor unit detects No ACK error/No response error, an object indoor unit is treated as a stop, and not assumed to be abnormal.
- The check codes displayed on the units may be different between the error source and others. In that case, please refer to the check code of error source by displayed attribute and address.
- Refer to the service manual of indoor unit or remote controller for the detail of error detected in indoor unit or remote controller.

• Self-diagnosis function


The indoor and outdoor units can be diagnosed automatically using the self-diagnosis switch (SW1) and LED indication (LED1, LED2) found on the outdoor multi controller circuit board.
LED indication : Set all contacts of SW1 to OFF.

• During normal operation

The LED indicates the drive state of outdoor unit.

[Example]

When the compressor and SV1 are on during cooling operation.



Bit	1	2	3	4	5	6	7	8
Indication	Compressor operated	52C	21S4	SV1	(SV2)	—	—	Always lit

8-1-3. SELF-DIAGNOSIS ACTION BY FLOWCHART

Check code	
0403 (Ed)	Serial communication error or Model selection SW error

Abnormal points and detection methods	Causes and checkpoints
If serial communication between the outdoor multi controller circuit board and outdoor power circuit board is defective.	① Wire breakage or contact failure of connector CN2 or CN4 ② Malfunction of communication circuit to power circuit board on outdoor multi controller circuit board ③ Malfunction of communication circuit on outdoor power circuit board

●Diagnosis of defects

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.

Diagnosis	Remedy
<div> <p>Check the connection of the communication line (CN2 and CN4) between the outdoor controller board and power board.</p> <p>Are they connected normally?</p> <p>No</p> <p>Yes</p> <p>Check the wiring.</p> <p>Are they connected normally?</p> <p>No</p> <p>Yes</p> </div>	
	<p>Connect the CN2 and CN4 properly. Replace them in the case of breakage.</p>
	<p>Connect the wiring properly. Replace them in the case of breakage.</p>
	<p>The communication circuit of either the outdoor controller board or power board is defective. If unable to identify the defective circuit; ①Replace the outdoor controller board if it does not recover, ②Replace the outdoor power board.</p>


Compressor temperature trouble

Chart 1 of 2

Abnormal points and detection methods	Causes and checkpoints
<p>(1) If the TH4 temperature becomes conditions as follows:</p> <ul style="list-style-type: none"> ●exceeds 230°F [110°C] continuously for 5 minutes ●exceeds 257°F [125°C] <p>(2) If a pressure detected by the high pressure sensor and converted to saturation temperature exceeds 104°F [40°C] during defrosting, and TH4 exceeds 230°F [110°C].</p> <p>TH4: Thermistor <Compressor> LEV: Linear expansion valve</p>	<p>① Malfunction of stop valve</p> <p>② Over-heated compressor operation caused by shortage of refrigerant</p> <p>③ Defective thermistor</p> <p>④ Defective outdoor controller board</p> <p>⑤ LEV performance failure</p> <p>⑥ Defective indoor controller board</p> <p>⑦ Clogged refrigerant system caused by foreign object</p> <p>⑧ Refrigerant shortage while in heating operation (Refrigerant liquid accumulation in compressor while indoor unit is OFF/thermo-OFF.)</p>

●Diagnosis of defects

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.




Compressor temperature trouble

Chart 2 of 2

●Diagnosis of defects


Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.



Abnormal points and detection methods	Causes and checkpoints
<p>(1) High pressure abnormality (63H operation) If 63H operates(*) during compressor operation. (*602 PSIG [4.15 MPaG])</p> <p>(2) High pressure abnormality (63HS detected) 1. If a pressure detected by 63HS is 625 PSIG [4.31 MPaG] or more during compressor operation. 2. If a pressure detected by 63HS is 600 PSIG [4.14 MPaG] or more for 3 minutes during compressor operation.</p> <p>(3) Compressor temperature abnormality (TRS operation) If TRS operates(*) during compressor operation. (*266°F[130°C])</p> <p>63H : High pressure switch 63HS: High pressure sensor LEV : Linear expansion valve SV1 : Solenoid valve TH4 : Thermistor <Compressor> TH7 : Thermistor <Ambient> TRS : Thermal protector</p>	<p>① Defective operation of stop valve (not fully open) ② Clogged or broken pipe ③ Malfunction or locked outdoor fan motor ④ Short-cycle of outdoor unit ⑤ Dirt of outdoor heat exchanger ⑥ Remote controller transmitting error caused by noise interference ⑦ Contact failure of the outdoor controller board connector ⑧ Defective outdoor controller board ⑨ Short-cycle of indoor unit ⑩ Decreased airflow, clogged filter, or dirt on indoor unit. ⑪ Malfunction or locked indoor fan motor ⑫ Decreased airflow caused by defective inspection of outdoor temperature thermistor (It detects lower temperature than actual temperature.) ⑬ Indoor LEV performance failure ⑭ Malfunction of fan driving circuit ⑮ SV1 performance failure ⑯ Defective high pressure sensor ⑰ Defective high pressure sensor input circuit on outdoor controller board ⑱ Defective Thermistor<Compressor> ⑲ Over-heated compressor operation caused by shortage of refrigerant</p>

●Diagnosis of defects

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.




High pressure trouble or thermal protector trouble

Chart 2 of 4


●Diagnosis of defects

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.



•Diagnosis of defects

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.




High pressure trouble or thermal protector trouble

Chart 4 of 4

●Diagnosis of defects

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.




Superheat due to low discharge temperature trouble

Chart 1 of 2

Abnormal points and detection methods	Causes and checkpoints
<p>If the discharge superheat is continuously detected -27°F [-15°C](*) or less for 5 minutes even though the indoor LEV has minimum open pulse after the compressor starts operating for 10 minutes.</p> <p>LEV : Linear expansion valve TH4 : Thermistor <Compressor> 63HS: High pressure sensor</p> <p>*At this temperature, conditions for the abnormality detection will not be satisfied if no abnormality is detected on either TH4 or 63HS.</p>	<p>① Disconnection or loose connection of TH4 ② Defective holder of TH4 ③ Disconnection of LEV coil ④ Disconnection of LEV connector ⑤ LEV performance failure</p>

●Diagnosis of defects

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.




Superheat due to low discharge temperature trouble

Chart 2 of 2

●Diagnosis of defects

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.




Refrigerant shortage trouble

Chart 1 of 2

Abnormal points and detection methods	Causes and checkpoints
<p>(1) When all of the following conditions have been satisfied for 15 consecutive minutes:</p> <ol style="list-style-type: none"> 1. The compressor is operating in HEAT mode. 2. Discharge super heat is 176°F [80°C] or more. 3. Difference between TH7 and the TH3 applies to the formula of $(TH7 - TH3 < 9°F [5°C])$. 4. The saturation temperature converted from a high pressure sensor detects below 95°F [35°C]. <p>(2) When all of the following conditions have been satisfied:</p> <ol style="list-style-type: none"> 1. The compressor is in operation. 2. When cooling, discharge superheat is 144°F [80°C] or more, and the saturation temperature converted from a high pressure sensor is over -40°F [-40°C]. When heating, discharge superheat is 162°F [90°C] or more. 	<ol style="list-style-type: none"> ① Defective operation of stop valve (not fully open) ② Defective thermistor ③ Defective outdoor controller board ④ Indoor LEV performance failure ⑤ Gas leakage or shortage ⑥ Defective 63HS <p>TH3 : Thermistor <Outdoor liquid pipe> TH7 : Thermistor <Ambient> LEV : Linear expansion valve 63HS: High pressure sensor</p>

●Diagnosis of defects

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.




Refrigerant shortage trouble

Chart 2 of 2

●Diagnosis of defects

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.



Closed valve in cooling mode

Abnormal points and detection methods	Causes and checkpoints
<p>If stop valve is closed during cooling operation.</p> <p>When both of the following temperature conditions have been satisfied for 20 minutes or more during cooling operation.</p> <ol style="list-style-type: none"> 1. TH22j - TH21j \geq -3.6°F [-2°C] 2. TH23j - TH21j \geq -3.6°F [-2°C] <p>Note: For indoor unit, the abnormality is detected if an operating unit satisfies the condition.</p>	<ol style="list-style-type: none"> ① Outdoor liquid/gas valve is closed. ② Multifunction of outdoor LEV (LEV-A) (blockage) <p>TH21: Indoor intake temperature thermistor TH22: Indoor liquid pipe temperature thermistor TH23: Indoor gas pipe temperature thermistor LEV: Linear expansion valve</p>

●Diagnosis of defects

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.


Diagnosis	Remedy
<pre> graph TD Q1{{Is the outdoor stop valve (liquid/gas) fully open?}} Q1 -- No --> R1[Open the outdoor stop valve (liquid/gas) fully.] Q1 -- Yes --> P1[Disconnect the outdoor LEV wiring to check the resistance.] P1 --> Q2{{Is the resistance detected?}} Q2 -- No --> R2[Replace the outdoor LEV.] Q2 -- Yes --> R3[Replace the outdoor controller board.] </pre>	

Freeze protection of Branch box or Indoor unit

Abnormal points and detection methods	Causes and checkpoints
<p>The purpose of the check code is to prevent indoor unit from freezing or dew condensation which is caused when a refrigerant keeps flowing into the unit in STOP.</p> <p>When all of the following conditions are satisfied:</p> <ol style="list-style-type: none"> 1. The compressor is operating in COOL mode. 2. 15 minutes have passed after the startup of the compressor, or the change in the number of operating indoor units is made (including a change by turning thermo-ON/OFF). 3. After the condition 2 above is satisfied, the thermistor of indoor unit in STOP detects TH22j $\leq 23^{\circ}\text{F}$ [-5°C] for 5 consecutive minutes. 	<ol style="list-style-type: none"> ① Wrong piping connection between indoor unit and Branch box ② Miswiring between indoor unit and Branch box ③ Miswiring of LEV in Branch box ④ Malfunction of LEV in Branch box <p>LEV: Linear expansion valve TH22: Indoor liquid pipe temperature thermistor</p>

●Diagnosis of defects

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.




4-way valve trouble in heating mode

Abnormal points and detection methods	Causes and checkpoints
<p>If 4-way valve does not operate during heating operation.</p> <p>When any of the following temperature conditions is satisfied for 3 minutes or more during heating operation when the outdoor temperature is -4°F [-20°C] or more:</p> <ol style="list-style-type: none"> 1. $\text{TH22j} - \text{TH21j} \leq -18^{\circ}\text{F}$ [-10°C] 2. $\text{TH23j} - \text{TH21j} \leq -18^{\circ}\text{F}$ [-10°C] 3. $\text{TH22j} \leq 37.4^{\circ}\text{F}$ [3°C] 4. $\text{TH23j} \leq 37.4^{\circ}\text{F}$ [3°C] <p>Note: For indoor unit, the abnormality is detected if an operating unit satisfies the condition.</p>	<ol style="list-style-type: none"> ① 4-way valve failure ② Disconnection or failure of 4-way valve coil ③ Clogged drain pipe ④ Disconnection or loose connection of connectors ⑤ Malfunction of input circuit on outdoor multi controller circuit board ⑥ Defective outdoor power circuit board <p>TH21: Indoor intake temperature thermistor (RT11 or TH1) TH22: Indoor liquid pipe temperature thermistor (RT13 or TH2) TH23: Indoor gas pipe temperature thermistor (TH-A to E)</p>

●Diagnosis of defects

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.



Out-of-range outside air temperature

Abnormal points and detection methods	Causes and checkpoints
① When the thermistor temperature of -24°F[-31.1°C] or below has continuously been detected for 3 minutes during heating operation (during compressor operation), the unit makes an error stop and "3121" appears on the LED1 and LED2. ② The compressor restarts when the thermistor temperature is -14°F [-25.6°C] or above. ③ If the unit is turned OFF, the outdoor temperature error will be canceled.	① Outdoor air temperature ② Thermistor failure ③ Wire failure ④ Defective outdoor controller board TH7: Thermistor <Ambient>

●Diagnosis of defects

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.

Diagnosis	Remedy
<pre> graph TD A[Check the outdoor air temperature.] --> B{Is the outdoor air temperature -24°F [-31.1°C] or higher?} B -- No --> C[Use in operation range, which is -14°F [-25.6°C] or more in heating mode.] B -- Yes --> D[Check the resistance of TH7.] D --> E{Is the resistance normal?} E -- No --> F[Replace the TH7.] E -- Yes --> G[Check for pinched lead wire, condition of wire coating and disconnected wire.] G --> H{Is wire condition normal?} H -- No --> I[Remove the abnormal point.] H -- Yes --> J[Replace the outdoor controller board.] </pre>	


Compressor current interruption (Locked compressor)

Chart 1 of 2

Abnormal points and detection methods	Causes and checkpoints
If overcurrent of DC bus or compressor is detected before 30 seconds after the compressor starts operating.	① Closed stop valve ② Decrease of power supply voltage ③ Looseness, disconnection, or wrong phase of compressor wiring connection ④ Incorrect DIP-SW setting of model selection on the outdoor controller board ⑤ Defective compressor ⑥ Defective outdoor power circuit board

●Diagnosis of defects

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.




Compressor current interruption (Locked compressor)

Chart 2 of 2

●Diagnosis of defects

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.



Compressor overcurrent interruption/failure in 12 VDC power supply circuit on power circuit board

Chart 1 of 2

Abnormal points and detection methods	Causes and checkpoints
<p>① If overcurrent of compressor is detected after 30 seconds since the compressor starts operating.</p> <p>② If 12 VDC power is not supplied from the 12 VDC supply circuit on the power circuit board.</p>	<p>① Closed outdoor stop valve</p> <p>② Decrease of power supply voltage</p> <p>③ Looseness, disconnection or reverse phase of compressor wiring connection</p> <p>④ Malfunction of indoor/outdoor fan</p> <p>⑤ Short-cycle of indoor/outdoor unit</p> <p>⑥ Model selection error upon replacement of outdoor multi controller circuit board</p> <p>⑦ Malfunction of input circuit on outdoor multi controller circuit board</p> <p>⑧ Defective compressor</p> <p>⑨ Defective outdoor power circuit board</p>

•Diagnosis of defects

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.


Diagnosis	Remedy
<pre> graph TD A[Check the outdoor stop valve.] --> B{Is the stop valve (liquid/gas) fully open?} B -- No --> C[Open the stop valve (liquid/gas) fully.] B -- Yes --> D[Check whether the power supply voltage is normal or not.] D --> E{Is the power supply voltage normal?} E -- No --> F[Check the power supply facility (check for power supply open phase).] E -- Yes --> G[Check whether the model selection switch is set correctly on the outdoor multi controller circuit board or not.] G --> H{Are they set properly?} H -- No --> I[Set the model selection correctly.] H -- Yes --> J[Turn the power OFF to check for looseness, disconnection or converse phases of the compressor wiring.] J --> K[Continue to the next page.] </pre>	

Compressor overcurrent interruption/failure in 12 VDC power supply circuit on power circuit board

Chart 2 of 2

●Diagnosis of defects

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.



Voltage shortage /Overvoltage/PAM error/L1 open phase/ Primary current sensor error/Power synchronization signal error

Chart 1 of 2

Abnormal points and detection methods	Causes and checkpoints
<p>If any of following symptoms are detected;</p> <ul style="list-style-type: none"> ●Decrease of DC bus voltage to 200 V (1-phase), 350 V (3-phase) ●Increase of DC bus voltage to 400 V (1-phase), 760 V (3-phase) ●DC bus voltage stays at 310 V or less for consecutive 30 seconds when the operational frequency is over 20 Hz. ●When any of following conditions is satisfied while the detections value of primary current is 0.1 A or less. <ul style="list-style-type: none"> 1. The operational frequency is 40 Hz or more. 2. The compressor current is 6 A or more. 	<ul style="list-style-type: none"> ① Decrease/increase of power supply voltage ② L1 open-phase (3-phase only) ③ Primary current sensor failure ④ Disconnection of compressor wiring ⑤ Malfunction of 52C relay ⑥ Defective outdoor power circuit board ⑦ Malfunction of 52C relay driving circuit on outdoor multi controller circuit board ⑧ Disconnection of CN5 (3-phase only) ⑨ Disconnection of CN2 ⑩ Malfunction of primary current detecting circuit on outdoor power circuit board ⑪ Malfunction of resistor connected to 52C relay on outdoor power circuit board (3-phase only)


Diagnosis of defects

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.

Single phase: single phase model

3-phase: three phase for wire model

The black square (■) indicates a switch position.




Voltage shortage/overvoltage/PAM error/L1 open phase/primary current sensor error/power synchronization signal error

Chart 2 of 2

●Diagnosis of defects

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.

The black square (■) indicates a switch position.




Heat sink temperature trouble

Abnormal points and detection methods	Causes and checkpoints
<p>If TH8 detects a temperature outside the specified range during compressor operation.</p> <p>TH8: Thermistor <Heat sink></p>	<ul style="list-style-type: none"> ① Blocked outdoor fan ② Malfunction of outdoor fan motor ③ Blocked airflow path ④ Rise of ambient temperature ⑤ Characteristic defect of thermistor ⑥ Malfunction of input circuit on outdoor power board ⑦ Malfunction of outdoor fan driving circuit

●Diagnosis of defects

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.



Power module trouble or overcurrent trouble

Abnormal points and detection methods	Causes and checkpoints
If overcurrent of DC bus or compressor is detected 30 seconds after the compressor starts operating. To determine the source of abnormality, either the compressor or the power module, drive the power module forcibly.	① Closed outdoor stop valve ② Decrease of power supply voltage ③ Disconnection, looseness or conversed connection of compressor wiring ④ Defective compressor ⑤ Defective outdoor power circuit board

●Diagnosis of defects

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.


Diagnosis	Remedy
<p>Check the outdoor stop valve.</p> <p>Is the stop valve (liquid/gas) fully open?</p> <p>Yes</p> <p>Check whether the power supply voltage is normal or not.</p> <p>Is the power supply voltage normal?</p> <p>Yes</p> <p>Turn the power OFF to check for looseness, disconnection or phases of the compressor wiring.</p> <p>Are the wirings normal?</p> <p>Yes</p> <p>Disconnect the wiring to check the power module.</p> <p>Does it operate normally?</p> <p>Yes</p>	<p>Open the stop valve (liquid/gas) fully.</p> <p>Ensure power supply from facility.</p> <p>Connect the compressor wiring (U, V and W phase) properly, then turn the power back ON.</p> <p>Replace the outdoor power circuit board or outdoor multi controller circuit board (Defective power circuit board).</p> <p>Replace the compressor (Defective compressor).</p>

Fan trouble

Abnormal points and detection methods	Causes and checkpoints
If no rotational frequency is detected, or detected a value outside the specified range during fan motor operation.	① Malfunction of fan motor ② Disconnection of CNF connector ③ Defective outdoor controller board

●Diagnosis of defects

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.



Compressor temperature thermistor (TH4) open/short


<Detected in outdoor unit>

Abnormal points and detection methods	Causes and checkpoints
<p>If TH4 detects to be open/short. (The open/short detection is disabled for 10 minutes after compressor starts, during defrosting operation, or for 10 minutes after returning from the defrosting operation. The detection is also disabled when the outdoor temperature is 41°F [5°C] or less in cooling operation, and -4°F [-20°C] or less in heating.) Open: 37.4°F [3°C] or less Short: 422.6°F [217°C] or more TH4: Thermistor <Compressor></p>	<p>① Disconnection or contact failure of connectors ② Characteristic defect of thermistor ③ Defective outdoor controller board</p>

●Diagnosis of defects

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.

The black square (■) indicates a switch position.



Suction pipe temperature thermistor (TH6) open/short

<Detected in outdoor unit>

Abnormal points and detection methods	Causes and checkpoints
<p>If TH6 detects to be open/short. (The open/short detection is disabled during 10 seconds to 10 minutes. after compressor starts, during defrosting operation, or for 10 minutes after returning from the defrosting operation.) Open: -40°F [-40°C] or less Short: 194°F [90°C] or more TH6: Thermistor <Suction pipe></p>	<p>① Disconnection or contact failure of connectors ② Characteristic defect of thermistor ③ Defective outdoor controller board</p>

●Diagnosis of defects

Make sure to turn the power OFF before connecting/disconnecting
 any connectors, or replacing boards.

The black square (■) indicates a switch position.

Diagnosis	Remedy								
<div>Check the wiring and connector connection of TH6.</div> <div>Is there any abnormality such as disconnection, looseness or breakage?</div> <div>No</div> <div>Disconnect the connector to check the resistance of TH6 using a multimeter.</div> <div>Is the detected resistance normal?</div> <div>Yes</div> <div>Check the temperature of TH6.</div> <div>Is the detected temperature normal?</div> <div>Yes</div>	<div>Connect the wiring/connector properly. Replace it in the case of breakage.</div> <div>Replace the thermistor.</div> <div><div>The detected temperature of TH6 can be displayed by an operation of SW1 on the outdoor controller board.</div><table><tr><th>SW1 Setting</th><th>Display on LED1,2</th><th>Unit</th></tr><tr><td>ON</td><td><div><div>1</div><div>2</div><div>3</div><div>4</div><div>5</div><div>6</div><div>7</div><div>8</div></div></td><td rowspan="2">-99.9~999.9 °F</td></tr><tr><td>OFF</td><td></td></tr></table></div> <div>Replace the controller board (Malfunction of thermistor circuit).</div> <div>No abnormality (A connector contact failure is suspected).</div>	SW1 Setting	Display on LED1,2	Unit	ON	<div><div>1</div><div>2</div><div>3</div><div>4</div><div>5</div><div>6</div><div>7</div><div>8</div></div>	-99.9~999.9 °F	OFF	
SW1 Setting	Display on LED1,2	Unit							
ON	<div><div>1</div><div>2</div><div>3</div><div>4</div><div>5</div><div>6</div><div>7</div><div>8</div></div>	-99.9~999.9 °F							
OFF									


Outdoor liquid pipe temperature thermistor (TH3) open/short

Abnormal points and detection methods	Causes and checkpoints
<p>If TH3 detects to be open/short. (The open/short detection is disabled during 10 seconds to 10 minutes. after compressor starts, during defrosting operation, or for 10 minutes after returning from the defrosting operation.) Open: -40°F [-40°C] or less Short: 194°F [90°C] or more TH3: Thermistor <Outdoor liquid pipe></p>	<p>① Disconnection or contact failure of connectors ② Characteristic defect of thermistor ③ Defective outdoor controller board</p>

●Diagnosis of defects

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.

The black square (■) indicates a switch position.




Ambient temperature thermistor (TH7) open/short

Abnormal points and detection methods	Causes and checkpoints
If TH7 detects to be open/short Open: -40°F [-40°C] or less Short: 194°F [90°C] or more TH7: Thermistor <Ambient>	① Disconnection or contact failure of connectors ② Characteristic defect of thermistor ③ Defective outdoor controller board

●Diagnosis of defects

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.

The black square (■) indicates a switch position.




HIC pipe temperature thermistor (TH2) open/short

Abnormal points and detection methods	Causes and checkpoints
If TH2 detects to be open/short. Open: -40°F [-40°C] or less Short: 194°F [90°C] or more TH2: Thermistor <HIC pipe>	① Disconnection or contact failure of connectors ② Characteristic defect of thermistor ③ Defective outdoor controller board

●Diagnosis of defects

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.

The black square (■) indicates a switch position.




Heat sink temperature thermistor(TH8) open/short

Abnormal points and detection methods	Causes and checkpoints
<p>If TH8 detects to be open/short. Open: -31.2°F [-35.1°C] or less Short: 338.5°F [170.3°C] or more</p> <p>TH8: Thermistor <Heat sink></p>	<p>① Disconnection or contact failure of connectors ② Characteristic defect of thermistor ③ Defective outdoor controller board</p>

●Diagnosis of defects

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.

The black square (■) indicates a switch position.




High pressure sensor (63HS) trouble

Abnormal points and detection methods	Causes and checkpoints
<p>① When the detected pressure in the high pressure sensor is 14 PSIG or less during operation, the compressor stops operation and enters into an anti-restart mode for 3 minutes.</p> <p>② When the detected pressure is 14 PSIG or less immediately before restarting, the compressor falls into an abnormal stop with a check code <5201>.</p> <p>③ For 3 minutes after compressor restarting, during defrosting operation, and for 3 minutes after returning from defrosting operation, above mentioned symptoms are not determined as abnormal.</p>	<p>① Defective high pressure sensor</p> <p>② Decrease of internal pressure caused by gas leakage</p> <p>③ Disconnection or contact failure of connector</p> <p>④ Malfunction of input circuit on outdoor controller board</p>

●Diagnosis of defects

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.

The black square (■) indicates a switch position.




Low pressure sensor (63LS) trouble

Abnormal points and detection methods	Causes and checkpoints
<p>① When the detected pressure in the low pressure sensor is -33 PSIG or less, or 329 PSIG or more during operation, the compressor stops operation with a check code <5202>.</p> <p>② For 3 minutes after compressor restarting, during defrosting operation, and for 3 minutes after returning from defrosting operation, above mentioned symptoms are not determined as abnormal.</p>	<p>① Defective low pressure sensor</p> <p>② Decrease of internal pressure caused by gas leakage</p> <p>③ Disconnection or contact failure of connector</p> <p>④ Malfunction of input circuit on outdoor controller board</p>

●Diagnosis of defects

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.

The black square (■) indicates a switch position.



Primary current error

Abnormal points and detection methods

If any of the following conditions is detected:

- ① Primary current sensor detects any of the following conditions (single phase unit only):

Model name	10 consecutive-second detection	One-time detection
PUMY-P36/48NKMU4	34 A	38 A
PUMY-HP36/42/48NKMU2 PUMY-P60NKMU4	37 A	40 A

- ② Secondary current sensor detects 25 A or more.

- ③ Secondary current sensor detects 1.0 A or less.

Causes and checkpoints


- ① Decrease/trouble of power supply voltage
- ② Disconnection of compressor wiring
- ③ Current sensor trouble on outdoor power circuit board
- ④ Wiring through current sensor (penetration type) is not done.

● Diagnosis of defects

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.

Diagnosis

Remedy




Duplex address error

Abnormal points and detection methods	Causes and checkpoints
If 2 or more units with the same address are existing.	① There are 2 units or more with the same address in their controller among outdoor unit, indoor unit, Fresh Master, Lossnay or remote controller ② Noise interference on indoor/outdoor connectors

●Diagnosis of defects

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.

Diagnosis	Remedy
 <pre> graph TD A[Search for a unit with the same address as the source of abnormality.] --> B{Is there any unit with the same address?} B -- Yes --> C[Correct the address, and turn the power OFF of indoor/outdoor unit, Fresh Master or Lossnay simultaneously for 2 minutes or more, then turn the power back ON.] B -- No --> D[Turn the power back ON.] D --> E{Does it operate normally?} E -- No --> F[Malfunction of sending/receiving circuit on indoor/outdoor unit is suspected.] E -- Yes --> G[There is no abnormality on the AC unit. It might be caused by an external noise, so check the transmission line to remove the factor(s).] </pre>	

Transmission processor hardware error

Abnormal points and detection methods	Causes and checkpoints
If the transmission line shows "1" although the transmission processor transmitted "0".	① A transmitting data collision occurred because of a wiring work or polarity change has performed while the power is ON on either of the indoor/outdoor unit, Fresh Master or Lossnay ② Malfunction of transmitting circuit on transmission processor ③ Noise interference on indoor/outdoor connectors

●Diagnosis of defects

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.


Diagnosis	Remedy
<pre> graph TD A{{A wiring work was performed while the power OFF.}} -- No --> B[If the wiring work was performed while the power ON, turn the power OFF of indoor/outdoor unit, Fresh Master or Lossnay simultaneously for 2 minutes or more, then turn the power back ON.] A -- Yes --> C[Turn the power back ON.] C --> D{{Does it operate normally?}} D -- No --> E[Replace the indoor/outdoor controller board.] D -- Yes --> F[There is no abnormality on the AC unit. It might be caused by an external noise, so check the transmission line to remove the factor(s).] </pre>	<p>If the wiring work was performed while the power ON, turn the power OFF of indoor/outdoor unit, Fresh Master or Lossnay simultaneously for 2 minutes or more, then turn the power back ON.</p> <p>Replace the indoor/outdoor controller board.</p> <p>There is no abnormality on the AC unit. It might be caused by an external noise, so check the transmission line to remove the factor(s).</p>

Transmission bus BUSY error

Abnormal points and detection methods	Causes and checkpoints
<p>① An abnormality when no transmission status caused by transmitting data collision continues for 8 to 10 minutes.</p> <p>② An abnormality when data cannot be output on the transmission line consecutively because of noise etc. for 8 to 10 minutes.</p>	<p>① The transmission processor is unable to transmit due to a short-cycle voltage such as noise is mixed on the transmission line.</p> <p>② The transmission processor is unable to transmit due to an increase of transmission data amount caused by a miswiring of the terminal block (transmission line) (TB3) and the terminal block (centralized control line) (TB7) on the outdoor unit.</p> <p>③ The share on transmission line becomes high due to a mixed transmission caused by a malfunction of repeater on the outdoor unit, which is a function to connect/disconnect transmission from/to control system and centralized control system.</p>

●Diagnosis of defects

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.



Signal communication error with transmission processor

Abnormal points and detection methods	Causes and checkpoints
① If the data of unit/transmission processor were not normally transmitted. ② If the address transmission from the unit processor was not normally transmitted.	① Accidental disturbance such as noise or lightning surge ② Hardware malfunction of transmission processor

●Diagnosis of defects

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.

Diagnosis	Remedy
<div data-bbox="304 634 730 725" style="border: 1px solid black; padding: 5px; margin-bottom: 10px;"> Turn the power OFF of indoor/outdoor unit, Fresh Master, Lossnay and remote controller simultaneously for 2 minutes or more, then turn the power back ON. </div> <div data-bbox="304 874 730 966" style="border: 1px solid black; padding: 10px; margin-bottom: 10px;"> Does it operate normally? </div> <div data-bbox="485 987 541 1017" style="border: 1px solid black; padding: 2px; display: inline-block; margin-bottom: 10px;"> Yes </div> <div data-bbox="746 902 802 932" style="border: 1px solid black; padding: 2px; display: inline-block;"> No </div>	<div data-bbox="970 874 1391 966" style="border: 1px solid black; padding: 5px; margin-bottom: 10px;"> Replace the controller (Defect of error source controller). </div> <div data-bbox="970 1008 1391 1100" style="border: 1px solid black; padding: 5px;"> There is no abnormality on the AC unit. It might be caused by an external noise, so check the transmission line to remove the factor(s). </div>

No ACK error

Chart 1 of 4

Abnormal points and detection methods	Causes and checkpoints
<p>① Represents a common error detection An abnormality detected by the sending side controller when receiving no ACK from the receiving side, though signal was once sent. The sending side searches the error in 30 seconds interval for 6 times continuously.</p>	<p>① The previous address unit does not exist since the address switch was changed while in electric continuity status. ② Decline of transmission voltage/signal caused by tolerance over on transmission line ·At the furthest end: 656 ft [200 m] ·On remote controller line: 39 ft [12 m] ③ Decline of transmission voltage/ signal due to unmatched transmission line types ·Types for shield line: CVVS, CPEVS, or MVVS ·Line diameter: AWG 16 [1.25 mm²] ④ Decline of transmission voltage/ signal due to excessive number of connected units ⑤ Malfunction due to accidental disturbance such as noise or lightning surge ⑥ Defect of error source controller</p>
<p>② The cause of displayed address and attribute is on the outdoor unit side. An abnormality detected by the indoor unit if receiving no ACK when transmitting signal from the indoor unit to the outdoor unit.</p>	<p>① Contact failure of indoor/outdoor unit transmission line ② Disconnection of transmission connector (CN2M) on indoor unit ③ Malfunction of sending/receiving circuit on indoor/outdoor unit ④ Disconnection of the connectors on the circuit board ⑤ Cut off of power supply for outdoor unit caused by high pressure protection(63H).</p>
<p>③ The cause of displayed address and attribute is on the indoor unit side. An abnormality detected by the remote controller if receiving no ACK when sending data from the remote controller to the indoor unit.</p>	<p>① While operating with multi refrigerant system indoor units, an abnormality is detected when the indoor unit transmit signal to the remote controller during the other refrigerant-system outdoor unit is turned OFF, or within 2 minutes after it turned back ON. ② Contact failure of indoor unit or remote controller transmission line ③ Disconnection of transmission connector (CN2M) on indoor unit ④ Malfunction of sending/receiving circuit on indoor unit or remote controller</p>
<p>④ The cause of the displayed address and attribute is on the remote controller side An abnormality detected by the indoor unit if receiving no ACK when transmitting signal from the indoor unit to the remote controller.</p>	<p>① While operating with multi refrigerant system indoor units, an abnormality is detected when the indoor unit transmit signal to the remote controller during the other refrigerant-system outdoor unit is turned OFF, or within 2 minutes after it turned back ON. ② Contact failure of indoor unit or remote controller transmission line ③ Disconnection of transmission connector (CN2M) on indoor unit ④ Malfunction of sending/receiving circuit on indoor unit or remote controller</p>

No ACK error

Chart 2 of 4

Abnormal points and detection methods	Causes and checkpoints
<p>⑤ The cause of displayed address and attribute is on the Fresh Master side. An abnormality detected by the indoor unit if receiving no ACK when transmitting signal from the indoor unit to the Fresh Master.</p>	<p>① While the indoor unit is operating with multi refrigerant system Fresh Master, an abnormality is detected when the indoor unit transmits signal to the remote controller while the outdoor unit with the same refrigerant system as the Fresh Master is turned OFF, or within 2 minutes after it turned back ON.</p> <p>② Contact failure of indoor unit or Fresh Master transmission line</p> <p>③ Disconnection of transmission connector (CN2M) on indoor unit or Fresh Master</p> <p>④ Malfunction of sending/receiving circuit on indoor unit or Fresh Master</p>
<p>⑥ The cause of displayed address and attribute is on Lossnay side. An abnormality detected by the indoor unit if receiving no ACK when the indoor unit transmit signal to the Lossnay.</p>	<p>① An abnormality is detected when the indoor unit transmits signal to Lossnay while the Lossnay is turned OFF.</p> <p>② While the indoor unit is operating with the other refrigerant Lossnay, an abnormality is detected when the indoor unit transmits signal to the Lossnay while the outdoor unit with the same refrigerant system as the Lossnay is turned OFF, or within 2 minutes after it turned back ON.</p> <p>③ Contact failure of indoor unit or Lossnay transmission line</p> <p>④ Disconnection of transmission connector (CN2M) on indoor unit</p> <p>⑤ Malfunction of sending/receiving circuit on indoor unit or Lossnay</p>
<p>⑦ The controller of displayed address and attribute is not recognized.</p>	<p>① The previous address unit does not exist since the address switch was changed while in electric continuity status.</p> <p>② An abnormality detected at transmitting from the indoor unit since the Fresh Master/Lossnay address are changed after synchronized setting of Fresh Master/Lossnay by the remote controller.</p>

No ACK error


Chart 3 of 4

●Diagnosis of defects

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.

Note:

When the address of the outdoor unit is displayed as abnormal, the outdoor circuit board may be faulty. If the unit is not restored after conducting the following procedure, check the outdoor circuit board.




No ACK error

Chart 4 of 4

●Diagnosis of defects

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.



No response frame error

Abnormal points and detection methods	Causes and checkpoints
<p>If receiving no response command while already received ACK. The sending side searches the error in 30 seconds interval for 6 times continuously.</p>	<p>① Continuous failure of transmission due to noise etc ② Decline of transmission voltage/signal caused by tolerance over on transmission line ·At the furthest end: 656 ft [200 m] ·On remote controller line: 39 ft [12 m] ③ Decline of transmission voltage/signal due to unmatched transmission line types ·Types for shield line: CVVS, CPEVS, or MVVS ·Line diameter: AWG 16 [1.25 mm²] ④ Accidental malfunction of error source controller</p>

●Diagnosis of defects

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.

Diagnosis	Remedy
<p>Turn the power OFF of indoor/outdoor unit, Fresh Master, Lossnay and remote controller simultaneously for 2 minutes or more, then turn the power back ON.</p> <p>Does it operate normally?</p> <p>No</p> <p>Replace the controller board (Defect of the controller which the displayed address/attribute belong to).</p> <p>Yes</p> <p>Check the transmission line for a disconnection and looseness (on the terminal board and connector).</p> <p>The transmission line is connected properly.</p> <p>No</p> <p>Connect the transmission line properly.</p> <p>Yes</p> <p>Check the transmission line whether it exceeds the tolerance(*) or not.</p> <p>*For the tolerance, refer to the Installation Manual.</p> <p>It is not exceeding the tolerance.</p> <p>No</p> <p>Correct it within the tolerance.</p> <p>Yes</p> <p>Check whether the correct kind of transmission line is used or not.</p> <p>Is correct kind of transmission line used?</p> <p>No</p> <p>Replace it with the correct kind of transmission line.</p> <p>Yes</p> <p>There is no abnormality on the AC unit. Check the transmission line for transmission wave and noise.</p>	


MA communication receive error

Chart 1 of 2

Abnormal points and detection methods	Causes and checkpoints
<p>Detected in remote controller or indoor unit:</p> <ol style="list-style-type: none"> ① When the main or sub remote controller cannot receive signal from indoor unit which has the "0" address. ② When the sub remote controller cannot receive signal. ③ When the indoor controller board cannot receive signal from remote controller or another indoor unit. ④ When the indoor controller board cannot receive signal. 	<ol style="list-style-type: none"> ① Contact failure of remote controller wirings ② Irregular Wiring (A wiring length, number of connecting remote controllers or indoor units, or a wiring thickness does not meet the conditions specified in the chapter "Electrical Work" in the indoor unit Installation Manual.) ③ Malfunction of the remote controller sending/receiving circuit on indoor unit with the LED2 is blinking. ④ Malfunction of the remote controller sending/receiving circuit ⑤ Remote controller transmitting error caused by noise interference

●Diagnosis of defects

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards



MA communication receive error

Chart 2 of 2

●Diagnosis of defects

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards

Diagnosis	Remedy
<p>Continued from the previous page.</p> <pre>graph TD; A[Continued from the previous page.] --> B[Refer to the chapter "Electrical Work".]; B --> C{Is the wiring connected properly, meeting the condition?}; C -- No --> D[Connect the wiring properly as specified in the chapter "Electrical Work" in the indoor unit Installation Manual.]; C -- Yes --> E[No abnormality It might be caused by an external noise, so check the transmission line to remove the factor(s).];</pre>	<p>Connect the wiring properly as specified in the chapter "Electrical Work" in the indoor unit Installation Manual.</p> <p>No abnormality It might be caused by an external noise, so check the transmission line to remove the factor(s).</p>


MA communication send error

Chart 1 of 2

Abnormal points and detection methods	Causes and checkpoints
Detected in remote controller or indoor unit.	① There are 2 remote controllers set as main. ② Malfunction of remote controller sending/receiving circuit ③ Malfunction of sending/receiving circuit on indoor controller board ④ Remote controller transmitting error caused by noise interference

●Diagnosis of defects

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards



MA communication send error

Chart 2 of 2

●Diagnosis of defects

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards


Diagnosis	Remedy
<p>Continued from the previous page.</p> <pre> graph TD Start([Continued from the previous page.]) --> Box[Refer to the chapter "Electrical Work".] Box --> Decision{Is the wiring connected properly, meeting the condition?} Decision -- No --> Remedy1[Connect the wiring properly as specified in the chapter "Electrical Work" in the indoor unit Installation Manual.] Decision -- Yes --> Remedy2[No abnormality It might be caused by an external noise, so check the transmission line to remove the factor(s).] </pre>	<div data-bbox="967 768 1391 859"> <p>Connect the wiring properly as specified in the chapter "Electrical Work" in the indoor unit Installation Manual.</p> </div> <div data-bbox="967 880 1378 981"> <p>No abnormality It might be caused by an external noise, so check the transmission line to remove the factor(s).</p> </div>

Total capacity error

Abnormal points and detection methods	Causes and checkpoints
When the total capacity of connected indoor units exceeds the specified capacity (130% of the outdoor unit capacity), a check code <7100> is displayed.	<p>① The total capacity of connected indoor units exceeds the specified capacity (without Branch Box / with Branch Box).</p> <ul style="list-style-type: none"> · (H)P36: up to code 32/29 · HP42: up to code 39/35 · (H)P48: up to code 43/40 · P60: up to code 56/53 <p>② The model name code of the outdoor unit is registered wrongly.</p>

●Diagnosis of defects

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.



Capacity code error

Abnormal points and detection methods

When the capacity of connected indoor unit is over, check code <7101> is displayed.

Causes and checkpoints

The model name of connected indoor unit (model code) is read as incompatible.

●Diagnosis of defects

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.

Diagnosis

Check the model selection switch (SW4 on the indoor controller board) of the connected indoor unit.

Is it set properly?

No

Yes

Remedy

Set the switch properly.

The model code of the connected indoor unit can be displayed by an operation of SW1 on the outdoor unit.

Connecting excessive number of units and Branch boxes

Abnormal points and detection methods	Causes and checkpoints
When the connected indoor units exceed the limit, a check code <7102> is displayed.	<p>Connecting more indoor units than the limit. Abnormal if connecting status does not comply with the following limit;</p> <p>① Maximum connectable indoor unit. ② Connect at least 1 indoor unit (Abnormal if connected none). ③ Connectable up to 2 Branch boxes.</p>

●Diagnosis of defects

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.

Diagnosis	Remedy
<pre> graph TD A[Check whether the connecting unit exceeds the limit or not.] --> B{Does it exceed the limit?} B -- Yes --> C[Connect less number of units than the limit.] B -- No --> D[Check if at least 1 indoor unit is connected.] D --> E{Is an indoor unit connected?} E -- No --> F[Connect indoor unit.] E -- Yes --> G[Check whether the M-NET line to the indoor unit is connected or not.] </pre>	

Address setting error

Abnormal points and detection methods	Causes and checkpoints
The address setting of outdoor unit or Branch box is wrong.	Wrongly set address of Branch box The outdoor unit is not set in 000, or in the range of 51 to 100.

●Diagnosis of defects

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.

Diagnosis	Remedy
<p><Outdoor unit></p> <pre> graph TD A[Check whether the outdoor unit address is set in 000, or in the range of 51 to 100.] --> B{Is the address setting correct?} B -- No --> C[Set the address properly, then turn the power OFF of indoor/outdoor unit, Fresh Master, Lossnay and remote controller simultaneously for 2 minutes or more, and turn the power back ON.] B -- Yes --> D[Replace the outdoor controller board.] </pre>	<p>Set the address properly, then turn the power OFF of indoor/outdoor unit, Fresh Master, Lossnay and remote controller simultaneously for 2 minutes or more, and turn the power back ON.</p> <p>Replace the outdoor controller board.</p>
<p><Branch box></p> <pre> graph TD E[Check whether the Branch box address is set in 000, or in the range of 001 to 050.] --> F{Is the address setting correct?} F -- No --> G[Set the address properly, then turn the power OFF of indoor/outdoor unit, Branch box, Fresh Master, Lossnay, and remote controller simultaneously for 2 minutes or more, and turn the power back ON.] F -- Yes --> H[Replace the Branch box controller board.] </pre>	<p>Set the address properly, then turn the power OFF of indoor/outdoor unit, Branch box, Fresh Master, Lossnay, and remote controller simultaneously for 2 minutes or more, and turn the power back ON.</p> <p>Replace the Branch box controller board.</p>
<p>Note: Branch box address When setting the address, use a number within the range of 1–50. Ex. The set address is (47) and there are 5 indoor units (A, B, C, D, and E). If A: (47), B: (48), C: (49), D: (50), and E: (51), E is incorrect because it exceeds 50.</p>	

Incompatible unit combination error

Abnormal points and detection methods	Causes and checkpoints
When the connected indoor unit is not compatible with the outdoor unit, the outdoor unit detects the error at startup.	Connecting indoor unit(s) which is not authorized to connect to the outdoor unit.

●Diagnosis of defects

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.

Diagnosis	Remedy
<p>Refer to the service manual of the outdoor unit or the connected indoor unit for the authorized combination.</p> <pre> graph TD A[Refer to the service manual of the outdoor unit or the connected indoor unit for the authorized combination.] --> B{Is the indoor unit authorized to connect with the outdoor unit?} B -- No --> C[Replace the indoor unit(s) to the one that is compatible.] B -- Yes --> D{Check whether the model selection switch is set correctly. Are they correct?} D -- No --> E[Set the model selection switch correctly, then restart.] D -- Yes --> F[Replace the outdoor controller board.] </pre>	

8-2. REMOTE CONTROLLER DIAGNOSIS

Refer to "12-8. REMOTE CONTROLLER CHECK" for MA remote controller system.




8-3. REMOTE CONTROLLER TROUBLE

For the troubleshooting, refer to the remote controller's manuals.

8-4. THE FOLLOWING SYMPTOM DO NOT REPRESENT TROUBLE (EMERGENCY)

Symptom	Display of remote controller	CAUSE
Even the cooling (heating) operation selection button is pressed, the indoor unit cannot be operated.	"Cool (Heat)" blinks	The indoor unit cannot cool (Heat) if other indoor units are heating (Cooling).
The auto vane runs freely.	Normal display	Because of the control operation of auto vane, it may change over to horizontal blow automatically from the downward blow in cooling because the downward blow operation has been continued for 1 hour. At defrosting in heating, hot adjusting and thermostat OFF, it automatically changes over to horizontal blow.
Fan setting changes during heating.	Normal display	Ultra-low speed operation is commenced at thermostat OFF. Light air automatically change over to set value by time or piping temperature at thermostat ON.
Fan stops during heating operation.	"Heat Defrost ⚙ "	The fan stops during defrosting.
Fan does not stop while operation has been stopped.	Light out	Fan runs for 1 minute after stopping to exhaust residual heat (only in heating).
No setting of fan while start SW has been turned on.	"Heat Standby ⚙ "	Ultra-low speed operation for 5 minutes after SW ON or until piping temperature reaches 95°F [35°C]. Then low speed operates for 2 minutes and operates at the normal set air volume. (Hot adjust control)
Indoor unit remote controller shows "Please Wait" indicator for about 2 minutes when turning ON power supply.	"Please Wait" blinks	The system is in the process of startup. Operate remote controller again after "Please Wait" disappears.
Drain pump does not stop while unit has been stopped.	Light out	After a stop of cooling operation, unit continues to operate drain pump for 3 minutes and then stops.
Drain pump continues to operate while unit has been stopped.	—	Unit continues to operate drain pump if drainage is generated, even during a stop.

8-5. INTERNAL SWITCH FUNCTION TABLE

The black square (■) indicates a switch position.					
Switch	Step	Function	Operation in Each Switch Setting		Remarks
			ON	OFF	
SWU1 ones digit SWU2 tens digit	Rotary switch		Before turning the power ON		<Initial settings>  (lens digit) (ones digit)
	Rotary switch		Can be set either during operation or not.		<Initial settings>  (lens digit) (ones digit)
SW1 Digital Display Switch	1-8		ON OFF 1 2 3 4 5 6 7 8		ON OFF 1 2 3 4 5 6 7 8
	1	Selects operating system startup	With centralized controller	Without centralized controller	Turn ON when the centralized controller is connected to the outdoor unit.
SW2 Function Switch	2	Connection Information Clear Switch	Clear	Do not clear	When relocating units or connecting additional units.
	3	Abnormal data clear switch input	Clear abnormal data	Normal	To delete an error history.
	4	Pump down	ON	OFF	To facilitate outdoor unit the pumping down operation. Frequency = Fixed to 65 Hz Indoor-linear expansion valve = Fully open Outdoor fan step = Fixed to 10
	5	Connect Branch box	Connect	Not connect	—
	6	—	—	—	—
SW2/ SW4/ SW8/ SW9 Model Switch	1-6		MODEL SELECTION 1:ON 0:OFF 		—
	1-6		Before the power is turned ON.		<Initial settings> Set for each capacity.
SW3 Trial operation	1	ON/OFF from outdoor unit	ON	OFF	<Initial settings> ON OFF 1 2
	2	Mode setting	Heating	Cooling	—
SW5 Function switch	1	Change the indoor unit's LEV opening at startup	Enable	Normal	To set the LEV opening at startup higher than usual. (+150 pulses) To improve the operation with the LEV almost clogged.
	2	—	—	—	—
	3	Auxiliary heater	Enable	Disable	Turn ON when an auxiliary heater is connected. (It transmits a connection permission signal of the auxiliary heater to the connected CITY MULTI indoor unit.)
	4	Change the indoor unit's LEV opening at defrost	Enable	Normal	To set the LEV opening higher than usual during defrosting operation. (Only Q ₁ ≤ 10 is valid, + 300 pulses) To avoid the discharge temperature increase and provide efficient defrosting operation.
	5	Switching the target sub cool (Heating mode)	Enable	Normal	To decrease the target sub cool value. To reduce the discharge temperature decrease due to refrigerant liquid accumulation in the units.
	6	—	—	—	—

Switch	Step	Function	Operation in Each Switch Setting		Remarks	Purpose	Additional Information
			ON	OFF			
SW5 Function switch	7	While the outdoor unit is in HEAT operation, additionally increase about 50 to 70 pulses of the LEV opening on the indoor unit which is in FAN, STOP, COOL or thermo-OFF*1.	Active	Inactive	Can be set when OFF or during operation	To additionally increase about 50 to 70 pulses of the LEV opening for units other than in HEAT operation. To avoid a refrigerant shortage (less capacity) due to refrigerant liquid accumulation in the units which is not in operation.	A refrigerant flow noise might be generated in units other than the one in operation.
	8	While the outdoor unit is in HEAT operation, fully close the linear expansion valve on the indoor unit which is in FAN or COOL.*2	Enable	Normal	Before turning the power ON.	To reduce the room temperature increase by setting the LEV opening lower for the indoor units in FAN or COOL operation.	The refrigerant is more likely to collect in the indoor units in FAN or COOL operation, which can cause refrigerant shortage of units. (Results in less capacity and increase of discharge temperature.)
	1	—	—	—	—	—	—
SW6 Function switch	2	—	—	—	—	—	—
	3	—	—	—	—	—	—
	4	Change of defrosting control	Enable (For high humidity)	Normal	Can be set when OFF or during operation	To shorten the defrosting prohibition time in high humidity (or heavy snow) region, in order to reduce malfunctions caused by frost.	The performance of the HEAT operation is somewhat reduced since the defrosting operation is frequently performed.
	5	—	—	—	—	—	—
	6	Switching the target discharge pressure (Pdm)	Enable	Normal	Can be set when OFF or during operation	To raise the performance by setting the Pdm higher during HEAT operation.	Power consumption is raised due to a higher frequency. (The performance would not be raised at the maximum operating frequency.)
	7	Switching (1) the target evaporation temperature (ETm)	Enable	Normal	SW6-7	To raise/reduce the performance by changing the target ETm during COOL operation.	Switching it to raise the performance, it raises the power consumption, and produces more dew condensation. Switching it to reduce the performance, it makes the performance insufficient.
	8	Switching (2) the target evaporation temperature (ETm)	Enable	Normal	SW6-8	Switch to raise the performance: raises the performance	Switching it to reduce the performance, it makes the performance insufficient.
	1	Ignore current sensor abnormality and rotational frequency abnormality of outdoor fan motor	Enable	Normal	Target ETm (°F/°C)	To perform a test run for electrical parts alone without running the compressor. Also, to perform the troubleshooting of electrical parts without operating the outdoor unit's fan.	Make sure to connect the connectors to the compressor after checking the electrical parts. Be careful not to get electrical shock while working on electrical parts.
	2	Setting to energize the freeze stat heater (optional part)	During heating operation only*3	Include when the heating operation is OFF.*4	Can be set when OFF or during operation	It reduces snow on the base, even it blows inside the unit, by setting the base heater ON while the HEAT operation is stopped.	Power consumption raises while the operation is stopped.
	3	High heating performance mode (except for NAMH22 model)	Enable	Normal	Anytime	To raise the performance of HEAT operation if it is insufficient.	The performance may not be raised depending on the capacity of indoor units in operation, or outside air temperature.
SW7 Function switch	4	Maximum frequency down at 1 hour after COOL operation	Enable	Normal	Can be set when OFF or during operation	To reduce dew condensation on the indoor unit by lowering the frequency.	The performance might be insufficient.
	5	Simultaneous cooling and heating with external heater	Enable	Disable	Anytime	The simultaneous operation of cooling and heating will be possible by installing an external heater to the CITY MULTI indoor unit.	For the installation of external heater and the indoor unit setting, refer to the indoor unit service manual.
	6	Manual defrost	Manual defrost	Normal	During compressor running in HEAT mode.	Turn ON when it is necessary to perform the defrosting operation forcibly. (Effective only at startup, or 10 minutes after the last defrosting operation)	It performs the defrosting operation forcibly. (HEAT operation is stopped temporarily.)
	1	Auto change over from remote controller (IC with the minimum address)	Enable	Disable	Before turning the power ON	Enables the indoor unit with the minimum address to select AUTO mode, and switches the operation mode of the other indoor units to the same mode.	Cannot be set when the centralized control is ON.
	2	Switching the Silent/ Demand mode	Demand control	Silent mode	Can be set when OFF or during operation	—	About the Silent mode/Demand control setting, refer to "8-6. OUTDOOR UNIT INPUT/OUTPUT CONNECTOR".
	3	—*5	—	—	—	—	—
SW9 Function Switch	4	—	—	—	—	—	—
	5	—	—	—	—	—	—
	6	—	—	—	—	—	—

*1 SW5-7 Opens the indoor-linear expansion valve as a countermeasure against the indoor unit in FAN, COOL, STOP, or thermo-OFF operation with refrigerant-shortage status due to an accumulation of liquid refrigerant in the indoor unit.

*2 SW5-8 Countermeasure against room temperature rise for indoor unit in FAN and COOL mode.


*3 During heating operation and the ambient temperature is 39°F (4°C) or below, the freeze prevention heater is energized.

*4 During heating mode is OFF (include thermo-OFF in cooling mode), and the ambient temperature is 39°F (4°C) or below, the freeze prevention heater is energized.

*5 Use it for Model Switch. ((H)P36/48)

8-6. OUTDOOR UNIT INPUT/OUTPUT CONNECTOR

• State (CN51)




A Distant control board
 B Relay circuit
 C External output adapter
 (PAC-SA88HA-E)
 D Outdoor unit control board

E Lamp power supply
 F Procure locally
 G Max. 33 ft [10 m]

L1: Error display lamp
 L2: Compressor operation lamp
 X, Y: Relay (coil rating: ≤ 0.9 W, 12 VDC)

• Auto change over (CN3N)




A Remote control panel
 B Relay circuit
 C External input adapter
 (PAC-SC36NA-E)
 D Outdoor unit control board

E Relay power supply
 F Procure locally
 G Max. 33 ft [10 m]

SW1: Switch
 SW2: Switch
 X, Y: Relay (contact rating: ≥ 0.1 A, 15 VDC)
 (min. applicable load: ≤ 1 mA)

	ON	OFF
SW1	Heating	Cooling
SW2	Validity of SW1	Invalidity of SW1

• Silent Mode/Demand Control (CN3D)



A Remote control panel
 B Relay circuit
 C External input adapter
 (PAC-SC36NA-E)
 D Outdoor unit control board





E Relay power supply
 F Procure locally
 G Max. 33 ft [10 m]

SW1: Switch
 SW2: Switch
 X, Y: Relay (contact rating: ≥ 0.1 A, 15 VDC)
 (min. applicabl load: ≤ 1 mA)

The silent mode and the demand control are selected by switching the DIP switch 9-2 on outdoor controller board. It is possible to set it to the following power consumption (compared with ratings) by setting SW1, 2.

	Outdoor controller board DIP SW9-2	SW1	SW2	Function
Silent mode	OFF	ON	—	Silent mode operation
Demand control	ON	OFF	OFF	100% (Normal)
		ON	OFF	75%
		ON	ON	50%
		OFF	ON	0% (Stop)

8-7. HOW TO CHECK PARTS

Parts name	Checkpoints																							
Thermistor (TH2) <Hic pipe> Thermistor (TH3) <Outdoor liquid pipe> Thermistor (TH4) <Compressor> Thermistor (TH6) <Suction pipe> Thermistor (TH7) <Ambient> Thermistor (TH8) <Heat sink>	Disconnect the connector then measure the resistance with a multimeter. (At the ambient temperature 50 to 80°F [10 to 30°C]) <table><tr><td></td><td>Normal</td><td>Abnormal</td></tr><tr><td>TH4</td><td>160 to 410 kΩ</td><td rowspan="4">Open or short</td></tr><tr><td>TH2 TH3 TH6 TH7</td><td>4.3 to 9.6 kΩ</td></tr><tr><td>TH8</td><td>39 to 105 kΩ</td></tr><tr><td></td><td></td></tr></table>		Normal	Abnormal	TH4	160 to 410 kΩ	Open or short	TH2 TH3 TH6 TH7	4.3 to 9.6 kΩ	TH8	39 to 105 kΩ													
	Normal	Abnormal																						
TH4	160 to 410 kΩ	Open or short																						
TH2 TH3 TH6 TH7	4.3 to 9.6 kΩ																							
TH8	39 to 105 kΩ																							
Fan motor (MF1, MF2) 	Measure the resistance between the connector pins with a multimeter. (At the ambient temperature 68°F [20°C]) <table><tr><td colspan="4">Normal</td><td>Abnormal</td><td>Model name of fan motor *</td></tr><tr><td>1 - 4</td><td>5 - 4</td><td>6 - 4</td><td>7 - 4</td><td rowspan="2">Open or short (Short, for 7 - 4)</td><td>SIC-82XX / SIC-88XX</td></tr><tr><td>1.1 ± 0.05 MΩ</td><td>40 ± 4 kΩ</td><td>220 ± 22 kΩ</td><td>Open</td><td>SIC-71XX / SIC-81XX</td></tr><tr><td>Open</td><td>150 ± 15kΩ</td><td>55 ± 11 kΩ</td><td>Open</td><td></td><td></td></tr></table> <p>* See the spec name plate indicated in the diagram for the model name of fan motor * Where "X" in model name of fan motor represents numbers and letters</p>	Normal				Abnormal	Model name of fan motor *	1 - 4	5 - 4	6 - 4	7 - 4	Open or short (Short, for 7 - 4)	SIC-82XX / SIC-88XX	1.1 ± 0.05 MΩ	40 ± 4 kΩ	220 ± 22 kΩ	Open	SIC-71XX / SIC-81XX	Open	150 ± 15kΩ	55 ± 11 kΩ	Open		
Normal				Abnormal	Model name of fan motor *																			
1 - 4	5 - 4	6 - 4	7 - 4	Open or short (Short, for 7 - 4)	SIC-82XX / SIC-88XX																			
1.1 ± 0.05 MΩ	40 ± 4 kΩ	220 ± 22 kΩ	Open		SIC-71XX / SIC-81XX																			
Open	150 ± 15kΩ	55 ± 11 kΩ	Open																					
Solenoid valve coil <4-way valve> (21S4)	Measure the resistance between the terminals with a multimeter. (At the ambient temperature 68°F [20°C]) <table><tr><td>Normal</td><td>Abnormal</td></tr><tr><td>1567.5 ± 156.8 Ω</td><td>Open or short</td></tr></table>	Normal	Abnormal	1567.5 ± 156.8 Ω	Open or short																			
Normal	Abnormal																							
1567.5 ± 156.8 Ω	Open or short																							
Motor for compressor (MC) 	Measure the resistance between the terminals with a multimeter. (Winding temperature 68°F [20°C]) <table><tr><td>Normal</td><td>Abnormal</td></tr><tr><td>0.305 ± 0.015 Ω</td><td>Open or short</td></tr></table>	Normal	Abnormal	0.305 ± 0.015 Ω	Open or short																			
Normal	Abnormal																							
0.305 ± 0.015 Ω	Open or short																							
Solenoid valve coil <Bypass valve> (SV1) <Switching valve> (SV2)*2 *2 Only NAMHZ2 model.	Measure the resistance between the terminals with a multimeter. (At the ambient temperature 68°F [20°C]) <table><tr><td>Normal</td><td>Abnormal</td></tr><tr><td>1197 ± 10 Ω</td><td>Open or short</td></tr></table>	Normal	Abnormal	1197 ± 10 Ω	Open or short																			
Normal	Abnormal																							
1197 ± 10 Ω	Open or short																							
Linear Expansion Valve (LEV A) 	<table><tr><td colspan="4">Normal</td><td>Abnormal</td></tr><tr><td>Gray - Black</td><td>Gray - Red</td><td>Gray - Yellow</td><td>Gray - Orange</td><td rowspan="2">Open or short</td></tr><tr><td colspan="4">46 ± 3 Ω</td></tr></table>	Normal				Abnormal	Gray - Black	Gray - Red	Gray - Yellow	Gray - Orange	Open or short	46 ± 3 Ω												
Normal				Abnormal																				
Gray - Black	Gray - Red	Gray - Yellow	Gray - Orange	Open or short																				
46 ± 3 Ω																								
Linear Expansion Valve (LEV B) 	<table><tr><td colspan="4">Normal</td><td>Abnormal</td></tr><tr><td>Red - White</td><td>Red - Orange</td><td>Red - Yellow</td><td>Red - Blue</td><td rowspan="2">Open or short</td></tr><tr><td colspan="4">46 ± 4 Ω</td></tr></table>	Normal				Abnormal	Red - White	Red - Orange	Red - Yellow	Red - Blue	Open or short	46 ± 4 Ω												
Normal				Abnormal																				
Red - White	Red - Orange	Red - Yellow	Red - Blue	Open or short																				
46 ± 4 Ω																								


Check method of DC fan motor (fan motor/outdoor multi controller circuit board)

1. Notes

- High voltage is applied to the connector (CNF1, 2) for the fan motor. Pay attention to the service.
- Do not pull out the connector (CNF1, 2) for the motor with the power supply on.
(It causes trouble of the outdoor multi controller circuit board and fan motor.)

2. Self check



Symptom: The outdoor fan cannot rotate.




Note: Turn SW7-1 OFF after the troubleshooting completes.

The fan sometimes starts on-off cycle operation during low-load operation or cooling at low ambient temperature.
It is not abnormal; the operation ensures reliability of the product.

Check method of multi controller circuit board





Check method of power circuit board





**PUMY-P60NKMU4
PUMY-HP36NKMU2
PUMY-HP42NKMU2
PUMY-HP48NKMU2**

Power circuit board


Noise filter circuit board



Multi controller circuit board



U-V 10–180 VAC
V-W 10–180 VAC
W-U 10–180 VAC



208/230 VAC
± 10%

208/230 VAC
10%

208/230 VAC
± 10%


208/230 VAC
± 10%

208/230 VAC
± 10%



208/230 VAC
± 10%

208/230 VAC
± 10%

PUMY-P36NKMU4 PUMY-P48NKMU4



Check method of M-NET power circuit board



8-8. HOW TO CHECK COMPONENTS

<Thermistor feature chart>

Low temperature thermistors


- Thermistor <Hic pipe> (TH2)
- Thermistor <Outdoor liquid pipe> (TH3)
- Thermistor <Suction pipe> (TH6)
- Thermistor <Ambient> (TH7)

Thermistor R0 = 15 kΩ ± 3%

B constant = 3480 ± 1%

$$R_t = 15 \exp\left\{3480 \left(\frac{1}{273+t} - \frac{1}{273} \right)\right\}$$

32°F [0°C]	15 kΩ	86°F [30°C]	4.3 kΩ
50°F [10°C]	9.6 kΩ	104°F [40°C]	3.0 kΩ
68°F [20°C]	6.3 kΩ		
77°F [25°C]	5.2 kΩ		



Medium temperature thermistor


- Thermistor <Heat sink> (TH8)

Thermistor R50 = 17 kΩ ± 2%

B constant = 4150 ± 3%

$$R_t = 17 \exp\left\{4150 \left(\frac{1}{273+t} - \frac{1}{323} \right)\right\}$$

32°F [0°C]	180 kΩ
77°F [25°C]	50 kΩ
122°F [50°C]	17 kΩ
158°F [70°C]	8 kΩ
194°F [90°C]	4 kΩ



High temperature thermistor


- Thermistor <Compressor> (TH4)

Thermistor R120 = 7.465 kΩ ± 2%

B constant = 4057 ± 2%

$$R_t = 7.465 \exp\left\{4057 \left(\frac{1}{273+t} - \frac{1}{393} \right)\right\}$$

68°F [20°C]	250 kΩ	158°F [70°C]	34 kΩ
86°F [30°C]	160 kΩ	176°F [80°C]	24 kΩ
104°F [40°C]	104 kΩ	194°F [90°C]	17.5 kΩ
122°F [50°C]	70 kΩ	212°F [100°C]	13.0 kΩ
140°F [60°C]	48 kΩ	230°F [110°C]	9.8 kΩ



<LOW PRESSURE SENSOR>

• Comparing the Low Pressure Sensor Measurement and Gauge Pressure

By configuring the digital display setting switch (SW1) as shown in the figure below, the pressure as measured by the low pressure sensor appears on the LED1 on the control board.



The figure at left shows that the switches 1 through 4 are set to ON and 5 through 8 are set to OFF.

(1) While the outdoor unit is stopped, compare the gauge pressure and the pressure displayed on self-diagnosis LED1, 2.

- 1) When the gauge pressure is between 0 and 14 PSIG [0.098 MPaG], internal pressure is caused due to gas leak.
- 2) When the pressure displayed on self-diagnosis LED1, 2 is between 0 and 14 PSIG [0.098 MPaG], the connector may be defective or be disconnected. Check the connector and go to (4).
- 3) When the outdoor temperature is 86°F [30°C] or less, and the pressure displayed on self-diagnosis LED1, 2 exceeds 247 PSIG [1.7 MPaG], go to (3).
When the outdoor temperature exceeds 86°F [30°C], and the pressure displayed on self-diagnosis LED1, 2 exceeds 247 PSIG [1.7 MPaG], go to (5).
- 4) If other than 1), 2) or 3), compare the pressures while the sensor is running. Go to (2).

(2) Compare the gauge pressure and the pressure displayed on self-diagnosis LED1, 2 after 15 minutes have passed since the start of operation. (Compare them by PSIG [MPaG] unit.)

- 1) When the difference between both pressures is within 29 PSIG [0.2MPaG], both the low pressure sensor and the control board are normal.
- 2) When the difference between both pressures exceeds 29 PSIG [0.2MPaG], the low pressure sensor has a problem. (performance deterioration)
- 3) When the pressure displayed on the self-diagnosis LED1, 2 does not change, the low pressure sensor has a problem.

(3) Remove the low pressure sensor from the control board to check the pressure with the self-diagnosis LED1, 2 display.

- 1) When the pressure displayed on the self-diagnosis LED1,2 is between 0 and 14 PSIG [0.098 MPaG], the low pressure sensor has a problem.
- 2) When the pressure displayed on self-diagnosis LED1, 2 is approximately 247 PSIG [1.7 MPaG], the control board has a problem.

(4) Remove the low pressure sensor from the control board, and short-circuit between the pin 2 and pin 3 connectors (63LS) to check the pressure with the self-diagnosis LED1, 2.

- 1) When the pressure displayed on the self-diagnosis LED1, 2 exceeds 247 PSIG [1.7 MPaG], the low pressure sensor has a problem.
- 2) If other than 1), the control board has a problem.

(5) Remove the high pressure sensor (63HS) from the control board, and insert it into the connector for the low pressure sensor (63LS) to check the pressure with the self-diagnosis LED1, 2.

- 1) When the pressure displayed on the self-diagnosis LED1, 2 exceeds 247 PSIG [1.7 MPaG], the control board has a problem.
- 2) If other than 1), go to (2).


• Low Pressure Sensor Configuration (63LS)

The low pressure sensor consists of the circuit shown in the figure below. If 5 VDC is applied between the red and the black wires, voltage corresponding to the pressure between the white and the black wires will be output, and the value of this voltage will be converted by the microcomputer. The output voltage is 0.173 V per 14 PSIG [0.098 MPaG].

Note:


The pressure sensor on the unit side is designed to connect to the connector. The connector pin number on the unit side is different from that on the control board side.

	Unit side	Control board side
Vcc	Pin 1	Pin 3
Vout	Pin 2	Pin 2
GND	Pin 3	Pin 1



- ③-①: 5 V (DC)
②-①: Output Vout (DC)


Pressure: 0-247 PSIG [1.7 MPaG]
Vout: 0.5-3.5 V
0.173 V/14 PSIG [0.098 MPaG]



<HIGH PRESSURE SENSOR>

• Comparing the High Pressure Sensor Measurement and Gauge Pressure

By configuring the digital display setting switch (SW1) as shown in the figure below, the pressure as measured by the high pressure sensor appears on the LED1, 2 on the control board.



The figure at left shows that the switches 1 through 4 are set to ON and 5 through 8 are set to OFF.

(1) While the outdoor unit is stopped, compare the gauge pressure and the pressure displayed on self-diagnosis LED1, 2.

- 1) When the gauge pressure is between 0 and 14 PSIG [0.098 MPaG], internal pressure is caused due to gas leak.
- 2) When the pressure displayed on self-diagnosis LED1, 2 is between 14 PSIG [0.098 MPaG], the connector may be defective or be disconnected. Check the connector and go to (4).
- 3) When the pressure displayed on self-diagnosis LED1, 2 exceeds 725 PSIG [5.0 MPaG], go to (3).
- 4) If other than 1), 2) or 3), compare the pressures while the sensor is running. Go to (2).

(2) Compare the gauge pressure and the pressure displayed on self-diagnosis LED1,2 after 15 minutes have passed since the start of operation. (Compare them by PSIG [MPaG] unit.)

- 1) When the difference between both pressures is within 36 PSIG [0.25 MPaG], both the high pressure sensor and the control board are normal.
- 2) When the difference between both pressures exceeds 36 PSIG [0.25 MPaG], the high pressure sensor has a problem. (performance deterioration)
- 3) When the pressure displayed on self-diagnosis LED1, 2 does not change, the high pressure sensor has a problem.

(3) Remove the high pressure sensor from the control board to check the pressure on the self-diagnosis LED1, 2.

- 1) When the pressure displayed on self-diagnosis LED1, 2 is between 0 and 14 PSIG [0.098 MPaG], the high pressure sensor has a problem.
- 2) When the pressure displayed on self-diagnosis LED1, 2 is approximately 725 PSIG [5.0 MPaG], the control board has a problem.

(4) Remove the high pressure sensor from the control board, and short-circuit between the pin 2 and pin 3 connectors (63HS) to check the pressure with self-diagnosis LED1, 2.

- 1) When the pressure displayed on the self-diagnosis LED1, 2 exceeds 725 PSIG [5.0 MPaG], the high pressure sensor has a problem.
- 2) If other than 1), the control board has a problem.


• High Pressure Sensor Configuration (63HS)

The high pressure sensor consists of the circuit shown in the figure below. If 5 V DC is applied between the white and the black wires, voltage corresponding to the pressure between the blue and the black wires will be output, and the value of this voltage will be converted by the microcomputer. The output voltage is 0.078 V per 14 PSIG [0.098 MPaG].


Note:

The pressure sensor on the body side is designed to connect to the connector. The connector pin number on the body side is different from that on the control board side.

	Body side	Control board side
Vcc	Pin 1	Pin 3
Vout	Pin 2	Pin 2
GND	Pin 3	Pin 1




- ③-① : 5 V (DC)
②-① : Output Vout (DC)



8-9. TEST POINT DIAGRAM

Outdoor multi controller circuit board

<CAUTION> TEST POINT ① is high voltage.



Outdoor power circuit board

PUMY-P60NKMU4
PUMY-HP36NKMU2
PUMY-HP42NKMU2
PUMY-HP48NKMU2

Brief Check of POWER MODULE

If they are short-circuited, it means that they are broken.
 Measure the resistance in the following points (connectors, etc.).

1. Check of POWER MODULE

① Check of DIODE circuit

R - **L1**, **S** - **L1**, **R** - **N1**, **S** - **N1**


② Check of IGBT circuit

L2 - **N1**

③ Check of INVERTER circuit

P - **U**, **P** - **V**, **P** - **W**, **N1** - **U**, **N1** - **V**, **N1** - **W**

Note: The marks **R**, **S**, **L1**, **L2**, **P**, **N1**, **U**, **V** and **W** shown in the diagram are not actually printed on the board.



Outdoor power circuit board

PUMY-P36NKMU4 PUMY-P48NKMU4

CN2

Connect to the outdoor multi controller circuit board (CN2)

- ①-⑤: Transmitting signal to outdoor controller circuit board (0-5 VDC)
- ②-⑤: Zero cross signal (0-5 VDC)
- ③-④: 15 VDC
- ⑥-⑤: 15 VDC
- ⑦-⑤: 15 VDC

TB1B, TB3B, TB2B, TB1A, TB2A, TB3A
Connect to DCL

CNDC
290-380 VDC (①+, ③-)
Connect to the outdoor controller circuit board (CNDC)

Brief Check of POWER MODULE

If they are short-circuited, it means that they are broken.
Measure the resistance in the following points (connectors, etc.).

1. Check of POWER MODULE

① Check of DIODE circuit

R - P1 S - P1 R - N1 S - N1


② Check of IGBT circuit

P2 - L1 P2 - L2 N2 - L1 N2 - L2

③ Check of INVERTER circuit

P3 - U, P3 - V, P3 - W, N3 - U, N3 - V, N3 - W

Note: The marks R, S, L1, L2, P1, N1, U, V and W shown in the diagram are not actually printed on the board.



CN6
Thermistor (TH8)

CN4
Connect to the outdoor multi controller circuit board (CN4)

U/V/W
Connect to the compressor (MC)
Voltage among phases: 10-180 VAC

CNAC2
208/230 VAC
Connect to the outdoor multi controller circuit board (CNAC)

CNAC1
208/230 VAC
Connect to the M-NET power circuit board (CN1)

R/LI, S/NI
Voltage of 208/230 VAC is input
(Connect to the terminal block (TB1))

EI, E3, E4
Connect to the electrical parts box

Outdoor noise filter circuit board

PUMY-P60NKMU4
PUMY-HP36NKMU2
PUMY-HP42NKMU2
PUMY-HP48NKMU2


LI, NI
 POWER SUPPLY
 Voltage of 208/230 VAC is input
 (Connect to the terminal block (TB1))
 M6 2.8±0.2 N·m


CNAC1
 208/230 VAC
 Connect to the M-NET
 power circuit board (CN1)

CNAC2
 208/230 VAC
 Connect to the outdoor
 multi controller circuit
 board (CNAC)

E1, E3, E4
 Connect to the electrical
 parts box

TB1, TB2
 POWER SUPPLY
 Voltage of 208/230 VAC
 (Connect to the outdoor
 power circuit board (TB3,
 TB4) M6 2.8±0.2 N·m





CN2
Connect to the outdoor multi controller circuit board (CN102)

- : 24–30 VDC
- : 24–30 VDC

CN1 /
Connect to the outdoor
power circuit board (CNAC1)
①—③: 208/230 VAC

8-10. OUTDOOR UNIT FUNCTIONS

SW: setting
0...OFF
1...ON

No.	SW1 setting 12345678	Display mode	Display on the LED1, 2 (display data)								Notes
			1	2	3	4	5	6	7	8	
0	00000000	Relay output display	Compressor operation	52C	21S4	SV1	(SV2)			Always lighting	ON: light on OFF: light off
1	10000000	Check display	0000-9999 (Alternating display of addresses and check code)	No.2 unit check	No.3 unit check	No.4 unit check	No.5 unit check	No.6 unit check	No.7 unit check	No.8 unit check	•When abnormality occurs, check display. Light on at time of abnormality
2	01000000	Indoor unit check status	No.1 unit check	Superheat due to low discharge temperature	Compressor shell temperature abnormality	TH4 abnormality	TH3 abnormality	Outdoor fan rotation frequency abnormality	TH7 abnormality	TH8 abnormality	
3	11000000	Protection input	High pressure abnormality	Compressor over current interception	Voltage abnormality	Insufficient refrigerant amount abnormality	Current sensor/primary current abnormality	63LS abnormality	63HS abnormality	start over current interception abnormality delay	Display detected microprocessor protection or abnormality
4	00100000	Protection input	Heat sink overheating	Address double setting abnormality	Indoor unit capacity error	Over capacity	Indoor unit address error	Outdoor unit address error	Current sensor open/short	serial communication abnormality (outdoor unit)	
5	10100000	Abnormality delay display 1	Abnormality in the number of indoor units	Superheat due to low discharge temperature delay	Compressor shell temperature abnormality delay	TH4 abnormality delay	TH3 abnormality delay	Outdoor fan rotation frequency abnormality delay	TH7 abnormality delay	TH8 abnormality delay	Display all abnormalities remaining in abnormality delay
6	01100000	Abnormality delay display 2	High pressure abnormality delay	Compressor over current interception delay	Voltage abnormality delay	Insufficient refrigerant amount abnormality delay	Current sensor/primary current abnormality delay	63LS abnormality delay	63HS abnormality delay	start over current interception abnormality delay	
7	11100000	Abnormality delay display 3	Heat sink overheating delay	TH2 abnormality delay	4-way valve abnormality delay	Delay caused by blocked valve in cooling mode	Power module abnormality delay	TH6 abnormality delay	Current sensor open/short delay		
8	00010000	Abnormality delay history 1	63LS abnormality delay	Superheat due to low discharge temperature delay	Compressor shell temperature abnormality delay	TH4 abnormality delay	TH3 abnormality delay	Outdoor fan rotation frequency abnormality delay	TH7 abnormality delay	TH8 abnormality delay	
9	10010000	Abnormality delay history 2	High pressure abnormality delay	Compressor over current interception delay	Voltage abnormality delay	Insufficient refrigerant amount abnormality delay	Current sensor/primary current abnormality delay	63LS abnormality delay	63HS abnormality delay	start over current interception abnormality delay	Display all abnormalities remaining in abnormality delay
10	01010000	Abnormality delay history 3	Heat sink overheating delay	TH2 abnormality delay	4-way valve abnormality delay	Delay caused by blocked valve in cooling mode	Power module abnormality delay	TH6 abnormality delay	Current sensor open/short delay		
11	11010000	Abnormality code history 1 (the latest)	63LS abnormality delay	Superheat due to low discharge temperature delay	Compressor shell temperature abnormality delay	TH4 abnormality delay	TH3 abnormality delay	Outdoor fan rotation frequency abnormality delay	TH7 abnormality delay	TH8 abnormality delay	
12	00110000	Abnormality code history 2	High pressure abnormality delay	Compressor over current interception delay	Voltage abnormality delay	Insufficient refrigerant amount abnormality delay	Current sensor/primary current abnormality delay	63LS abnormality delay	63HS abnormality delay	start over current interception abnormality delay	
13	10110000	Abnormality code history 3	Heat sink overheating delay	TH2 abnormality delay	4-way valve abnormality delay	Delay caused by blocked valve in cooling mode	Power module abnormality delay	TH6 abnormality delay	Current sensor open/short delay		
14	01110000	Abnormality code history 4	63LS abnormality delay	Superheat due to low discharge temperature delay	Compressor shell temperature abnormality delay	TH4 abnormality delay	TH3 abnormality delay	Outdoor fan rotation frequency abnormality delay	TH7 abnormality delay	TH8 abnormality delay	
15	11110000	Abnormality code history 5	High pressure abnormality delay	Compressor over current interception delay	Voltage abnormality delay	Insufficient refrigerant amount abnormality delay	Current sensor/primary current abnormality delay	63LS abnormality delay	63HS abnormality delay	start over current interception abnormality delay	
16	00001000	Abnormality code history 6	Heat sink overheating delay	TH2 abnormality delay	4-way valve abnormality delay	Delay caused by blocked valve in cooling mode	Power module abnormality delay	TH6 abnormality delay	Current sensor open/short delay		
17	10001000	Abnormality code history 7	63LS abnormality delay	Superheat due to low discharge temperature delay	Compressor shell temperature abnormality delay	TH4 abnormality delay	TH3 abnormality delay	Outdoor fan rotation frequency abnormality delay	TH7 abnormality delay	TH8 abnormality delay	
18	01001000	Abnormality code history 8	High pressure abnormality delay	Compressor over current interception delay	Voltage abnormality delay	Insufficient refrigerant amount abnormality delay	Current sensor/primary current abnormality delay	63LS abnormality delay	63HS abnormality delay	start over current interception abnormality delay	
19	11001000	Abnormality code history 9	Heat sink overheating delay	TH2 abnormality delay	4-way valve abnormality delay	Delay caused by blocked valve in cooling mode	Power module abnormality delay	TH6 abnormality delay	Current sensor open/short delay		
20	00101000	Abnormality code history 10 (the oldest)	63LS abnormality delay	Superheat due to low discharge temperature delay	Compressor shell temperature abnormality delay	TH4 abnormality delay	TH3 abnormality delay	Outdoor fan rotation frequency abnormality delay	TH7 abnormality delay	TH8 abnormality delay	
21	10101000	Cumulative time	0-9999 (unit: 1 hour)								
22	01101000	Cumulative time	0-9999 (unit: 10 hour)								
23	11101000	Outdoor unit operation display	Compressor energizing	Compressor operating prohibition	Compressor in operation	Abnormality detection					Display of cumulative compressor operating time
24	00011000	Indoor unit operation mode	No.1 unit mode	No.2 unit mode	No.3 unit mode	No.4 unit mode	No.5 unit mode	No.6 unit mode	No.7 unit mode	No.8 unit mode	Light ON/Light OFF
25	10011000	Indoor unit operation display	No.1 unit operation	No.2 unit operation	No.3 unit operation	No.4 unit operation	No.5 unit operation	No.6 unit operation	No.7 unit operation	No.8 unit operation	Cooling: light on, Heating: light blinking Stop fan: light off Thermo ON: light on Thermo OFF: light off

• Display abnormalities up to present (including abnormality terminals)
• History record in 1 is the latest; records become older in sequence; history record in 10 is the oldest.

No.		SW1 setting	Display mode	Display on the LED1, 2 (display data)								Notes
		12345678		1	2	3	4	5	6	7	8	
26	01011000		Capacity code (No. 1 indoor unit)	0-255								•Display of indoor unit capacity code •The No. 1 unit will start from the M-NET address with the lowest number
27	11011000		Capacity code (No. 2 indoor unit)									
28	00111000		Capacity code (No. 3 indoor unit)									
29	10111000		Capacity code (No. 4 indoor unit)									
30	01111000		Capacity code (No. 5 indoor unit)									
31	11111000		IC1 operation mode	STOP	Fan	Cooling thermo-ON	Cooling thermo-OFF	Heating thermo-ON	Heating thermo-OFF			•Display of indoor unit operating mode
32	00000100		IC2 operation mode									
33	10000100		IC3 operation mode									
34	01000100		IC4 operation mode									
35	11000100		IC5 operation mode									
36	00100100		OC operation mode	Compressor ON/OFF CN3N1-3 input	Heating/Cooling CN3N1-2 input	Abnormal/normal CN3S1-2 input	DEFROST/NO CN3D1-3 input	Refrigerant pull back/no CN3D1-2 input	Excitation current/no	3-min delay/no	Light on/light off Input: light on No input: light off	
37	10100100		External connection status									
38	01100100		Communication demand capacity									
39	11100100		Number of compressor ON/OFF	0000-9999 (unit: x10)								Display a count of compressor operation/stop
40	00010100		Compressor operating current	0-999.9 (Arms)								Display detected current
41	10010100		Input current of outdoor unit									
42	01010100		Thermo-ON operating time	0000-9999 (unit: x10)								Display cumulative time of thermo-ON operation
43	11010100		Total capacity of thermo-ON	0-255								Display total capacity code of indoor units inthermo-ON
44	00110100		Number of indoor units	0-255								Display number of connected indoor units
45	10110100		DC bus voltage	0-999.9 (V)								Display bus voltage
46	01110100		State of LEV control	Td over heat prevention	SHd decrease prevention	Min.Sj correction depends on Td	Min.Sj correction depends on SHd	LEV opening correction depends on Pd	LEV opening correction depends on Td	Correction of high compression ratio prevention	Display active LEV control	
47	11110100		State of compressor frequency control 1	Condensing temperature limit control	Compressor temperature control		Discharge temp. (heating) backup control	Pd abnormality (heating) control	Pd Back up control(heating)		Freeze prevention control at the beginning of SHd	
48	00001100		State of compressor frequency control 2	Heat sink over heat prevention control	Secondary current control	Input current control		Frequency restrain of receipt voltage change	Low pressure decrease prevention	HZ-up inhibit control at the beginning of SHd	Display active compressor frequency control	
49	10001100		Protection input	63LS abnormality	HIC abnormality		Frozen protection	4-way valve disconnection abnormality	Delay caused by blocked valve in cooling mode	TH6 abnormality	Power module abnormality	
50	01001100		The second current value when microprocessor of POWER BOARD abnormality is detected	0-999.9[Arms]								Display data at time of abnormality
51	11001100		Heatsink temperature when microprocessor of POWER BOARD abnormality is detected	-99.9-999.9 (°F)								
			State of compressor frequency(Hz) control		Content							
			Discharge pressure control		Hz control by pressure limitation							
			Compressor temperature control		Hz control by discharge temperature limitation							
			SV control		Hz control by bypass valve							
			Abnormal rise of Pd control		Control that restrains abnormal rise of discharge pressure							
			Heat sink over heat prevention control		Heat sink over heat prevention control							
			Secondary current control		Secondary current control							
			Input current control		Input current control							
			Hz correction of receipt voltage decrease prevention		Max.Hz correction control due to voltage decrease							
			Hz restrain of receipt voltage change		Max.Hz correction control due to receipt voltage change							

State of compressor frequency(Hz) control	Content
Discharge pressure control	Hz control by pressure limitation
Compressor temperature control	Hz control by discharge temperature limitation
SV control	Hz control by bypass valve
Abnormal rise of Pd control	Control that restrains abnormal rise of discharge pressure
Heat sink over heat prevention control	Heat sink over heat prevention control
Secondary current control	Secondary current control
Input current control	Input current control
Hz correction of receipt voltage decrease prevention	Max.Hz correction control due to voltage decrease
Hz restrain of receipt voltage change	Max.Hz correction control due to receipt voltage change

No.	SW1 setting 12345678	Display mode	Display on the LED1, 2 (display data)								Notes
			1	2	3	4	5	6	7	8	
52	00101100	Outdoor LEV-A opening pulse	0-2000 (pulse)								Display of opening pulse of outdoor LEV
53	10101100	Outdoor LEV-A opening pulse abnormality delay									
54	01101100	Outdoor LEV-A opening pulse abnormality									
55	11101100	Outdoor LEV-B opening pulse									
56	00011100	Outdoor LEV-B opening pulse abnormality delay									
57	10011100	Outdoor LEV-B opening pulse abnormality									
58	01011100	63LS (Low pressure)									
59	11011100	63LS abnormality delay	-99.9-999.9 (PSIG)								Display of data from sensor and thermistor
60	00111100	63 LS abnormality									
61	10111100	TH2 (Hic pipe)									
62	01111100	TH2(Hic) abnormality delay									
63	11111100	TH2 (Hic) abnormality	-99.9-999.9 (°F)								Display of actual operating frequency
64	00000010	Operational frequency	0-255 (Hz)								
65	10000010	Target frequency	0-255 (Hz)								
66	01000010	Outdoor fan control step number	0-15								
69	10100010	IC1 LEV Opening pulse	0-2000 (pulse)								Display of opening pulse of indoor LEV
70	01100010	IC2 LEV Opening pulse									
71	11100010	IC3 LEV Opening pulse									
72	00010010	IC4 LEV Opening pulse									
73	10010010	IC5 LEV Opening pulse									
74	01010010	High pressure sensor (Pd)	-99.9-999.9 (PSIG)								Display detected data of outdoor unit sensors and thermistors
75	11010010	TH4(Compressor) (Td) data									
76	00110010	TH6(Suction pipe) (ET) data									
77	10110010	TH7(Ambient) data									
78	01110010	TH3(Outdoor liquid pipe) data	-99.9-999.9 (°F)								Display detected data of indoor unit thermistor
80	00001010	TH8(Heat sink) data									
81	10001010	IC1 TH23 (Gas)									
82	01001010	IC2 TH23 (Gas)									
83	11001010	IC3 TH23 (Gas)									
84	00101010	IC4 TH23 (Gas)	-99.9-999.9 (°F) (When indoor unit is not connected, it is displayed as 0.)								
85	10101010	IC5 TH23 (Gas)									

No.	SW1 setting 12345678	Display mode	Display on the LED1, 2 (display data)								Notes
			1	2	3	4	5	6	7	8	
86	01101010	IC1 TH22 (Liquid)	-99.9~999.9 (°F) (When the indoor unit is not connected, it is displayed as 0.)								Display detected data of indoor unit thermistors
87	11101010	IC2 TH22 (Liquid)									
88	00011010	IC3 TH22 (Liquid)									
89	10011010	IC4 TH22 (Liquid)									
90	01011010	IC5 TH22 (Liquid)									
91	11011010	IC1 TH21 (Intake)									
92	00111010	IC2 TH21 (Intake)									
93	10111010	IC3 TH21 (Intake)									
94	01111010	IC4 TH21 (Intake)									
95	11111010	IC5 TH21 (Intake)									
96	00000110	Outdoor SC (cooling)	-99.9~999.9 (°C) -2~4								Display of outdoor subcool (SC) data
97	10000110	Target subcool step									Display of target subcool step data
98	01000110	IC1 SC/SH	-99.9~999.9 (°C) during heating: subcool (SC)/during cooling: superheat (SH) (Fixed to "0" during cooling operation)								Display of indoor SC/SH data
99	11000110	IC2 SC/SH									
100	00100110	IC3 SC/SH									
101	10100110	IC4 SC/SH									
102	01100110	IC5 SC/SH									
103	11100110	Discharge superheat (SHd)	-99.9~999.9 (°C) PdM (0.0~30.0) (kgf/cm²) ETm (-2.0~23.0) (°C) SCm (0.0~20.0) (°C)								Display of outdoor discharge superheat (SHd) data
105	10010110	Target Pd display /heating /kgf									
106	01010110	Target ET display (cooling)									
107	11010110	Target outdoor SC (cooling)									
108	00110110	Target indoor SC/SH (IC1)	SCm/SHm (0.0~20.0) (°C)								Display of all control target data
109	10110110	Target indoor SC/SH (IC2)									
110	01110110	Target indoor SC/SH (IC3)									
111	11110110	Target indoor SC/SH (IC4)									
112	00001110	Target indoor SC/SH (IC5)									
113	10001110	Indoor unit check status (IC9-12)	No. 9 unit check	No. 10 unit check	No. 11 unit check	No. 12 unit check					Light on at time of abnormality
114	01001110	Indoor unit operation mode (IC9-12)	No. 9 unit mode	No. 10 unit mode	No. 11 unit mode	No. 12 unit mode					COOL/DRY: light on HEAT: light blinking FAN/STOP: light off
115	11001110	Indoor unit operation display (IC9-12)	No. 9 unit operation	No. 10 unit operation	No. 11 unit operation	No. 12 unit operation					Thermo-ON: light on Thermo-OFF: light off
116	00101110	IC9 operation mode	STOP	Fan	Cooling Thermo-ON	Cooling thermo-OFF	Heating thermo-ON	Heating thermo-OFF			Display of indoor unit operation mode
117	10101110	IC10 operation mode									
118	01101110	IC11 operation mode									
119	11101110	IC12 operation mode									
120	00011110	Target indoor SC/SH (IC9)	SCm/SHm (0.0~20.0) (°C)								Display of all control target data
121	10011110	Target indoor SC/SH (IC10)									
122	01011110	Target indoor SC/SH (IC11)									
123	11011110	Target indoor SC/SH (IC12)									
124	00111110	IC9 LEV opening pulse abnormality delay	0~2000 (pulse)								Display of opening pulse of indoor LEV at time of abnormality delay
125	10111110	IC10 LEV opening pulse abnormality delay									
126	01111110	IC11 LEV opening pulse abnormality delay									
127	11111110	IC12 LEV opening pulse abnormality delay									

No.	SW1 setting	Display mode	Display on the LED1, 2 (display data)								Notes
			1	2	3	4	5	6	7	8	
128	00000001	Actual frequency of abnormality delay	0-255 (Hz)								Display of actual frequency at time of abnormality delay
129	10110001	Fan step number at time of abnormality delay	0-15								Display of fan step number at time of abnormality delay
131	11000001	IC1 LEV opening pulse abnormality delay	0-2000 (pulse)								Delay of opening pulse of indoor LEV at time of abnormality delay
132	00100001	IC2 LEV opening pulse abnormality delay									
133	10100001	IC3 LEV opening pulse abnormality delay									
134	01100001	IC4 LEV opening pulse abnormality delay									
135	11100001	IC5 LEV opening pulse abnormality delay									
136	00010001	High pressure sensor data at time of abnormality delay kgf/cm2	-99.9-999.9 (PSIG)								
137	10010001	TH4 (Compressor) sensor data at time of abnormality delay °C	-99.9-999.9 (°F)								
138	01010001	TH6 (Suction pipe) sensor data at time of abnormality delay °C									
139	11010001	TH3 (Outdoor liquid pipe) sensor data at time of abnormality delay °C									
140	00110001	TH8 (Heat sink) sensor data at time of abnormality delay °C									
141	10110001	OC SC (cooling) at time of abnormality delay °C	-99.9-999.9(°C) During heating: subcool (SC) During cooling: superheat (SH) (Fixed to "0" during cooling operation)								Display of data from High pressure sensor, all thermistors, and SC/SH at time of abnormality delay
142	01110001	IC1 SC/SH at time of abnormality delay °C									
143	11110001	IC2 SC/SH at time of abnormality delay °C									
144	00001001	IC3 SC/SH at time of abnormality delay °C									
145	10001001	IC4 SC/SH at time of abnormality delay °C									
146	01001001	IC5 SC/SH at time of abnormality delay °C									
147	11001001	IC9 SC/SH at time of abnormality delay °C									
148	00100001	IC10 SC/SH at time of abnormality delay °C									
149	10101001	IC11 SC/SH at time of abnormality delay °C									
150	01101001	IC12 SC/SH at time of abnormality delay °C									


No.	SW1 setting 12345678	Display mode	Display on the LED1, 2 (display data)								Notes
			1	2	3	4	5	6	7	8	
151	11101001	IC9 LEV opening pulse at time of abnormality	0-2000 (pulse)								Display of opening pulse of indoor LEV at time of abnormality
152	00011001	IC10 LEV opening pulse at time of abnormality									
153	10011001	IC11 LEV opening pulse at time of abnormality									
154	01011001	IC12 LEV opening pulse at time of abnormality									
155	11011001	IC9 SC/SH at time of abnormality	-99.9-999.9(°C) During heating: subcool (SC) During cooling: superheat (SH) (Fixed to "0" during cooling operation)								Display of indoor SC/SH data at time of abnormality
156	00111001	IC10 SC/SH at time of abnormality									
157	10111001	IC11 SC/SH at time of abnormality									
158	01111001	IC12 SC/SH at time of abnormality									
159	11111001	IC9 Capacity code	0-255								Display of indoor unit capacity code The No.1 unit will start from the M-NET address with the lowest number
160	00000101	IC10 Capacity code									
161	10000101	IC11 Capacity code									
162	01000101	IC12 Capacity code									
163	11000101	IC9 SC/SH	-99.9-999.9(°C) During heating: subcool (SC) During cooling: superheat (SH) (Fixed to "0" during cooling operation)								Display of indoor SC/SH data
164	00100101	IC10 SC/SH									
165	10100101	IC11 SC/SH									
166	01100101	IC12 SC/SH									
170	01010101	ROM version monitor	0.00-99.99 (ver)								Display of version data of ROM
171	11010101	ROM type									
172	00110101	Check sum mode	0000-FFFF								Display of ROM type Display of check sum code of ROM
173	10110101	IC9 TH23 (Gas)									
174	01110101	IC10 TH23 (Gas)									
175	11110101	IC11 TH23 (Gas)									
176	00001101	IC12 TH23 (Gas)									
177	10001101	IC9 TH22 (Liquid)									
178	01001101	IC10 TH22 (Liquid)									
179	11001101	IC11 TH22 (Liquid)									
180	00101101	IC12 TH22 (Liquid)									
181	10101101	Backup heating determination value "a"									
182	01101101	Backup heating determination value "b"									
183	11101101	Backup heating determination value "c"									
184	00011101	Backup heating determination value "d"									
185	10011101	IC9 TH21 (Intake)	-99.9-999.9 (°F)								Display detected data of indoor unit thermistors
186	01011101	IC10 TH21 (Intake)									
187	11011101	IC11 TH21 (Intake)									
188	00111101	IC12 TH21 (Intake)									

No.	SW1 setting	Display mode	Display on the LED1, 2 (display data)								Notes
			1	2	3	4	5	6	7	8	
189	10111101	History of voltage error (U9/4220)	-	-	PAM error	Converter Fault	Power synchronization signal error	L1 open phase error	Under voltage error	Over voltage error	
190	01111101	External connection status at time of abnormality delay	CN3N 1-3 input	CN3N 1-2 input	CN3S 1-2 input	CN3D 1-3 input	CN3D 1-2 input				
191	11111101	External connection status at time of abnormality	CN3N 1-3 input	CN3N 1-2 input	CN3S 1-2 input	CN3D 1-3 input	CN3D 1-2 input				
192	00000011	Actual frequency of abnormality	0-255 (Hz)								Display of actual frequency at time of abnormality
193	10000011	Fan step number at time of abnormality	0-15								Display of fan step number at time of abnormality
195	11000011	IC1 LEV opening pulse at time of abnormality	0-2000 (pulse)								Display of opening pulse of indoor LEV at time of abnormality
196	00100011	IC2 LEV opening pulse at time of abnormality									
197	10100011	IC3 LEV opening pulse at time of abnormality									
198	01100011	IC4 LEV opening pulse at time of abnormality									
199	11100011	IC5 LEV opening pulse at time of abnormality									
200	00010011	High pressure sensor data at time of abnormality	-99.9-999.9 (PSIG)								Display of data from High pressure sensor, all thermistors, and SC/SH at time of abnormality.
201	10010011	TH4 (Compressor) sensor data at time of abnormality									
202	01010011	TH6 (Suction pipe) sensor data at time of abnormality									
203	11010011	TH3 (Outdoor liquid pipe) sensor data at time of abnormality									
204	00110011	TH8 (Heat sink) sensor data at time of abnormality									
205	10110011	OC SC (cooling) at time of abnormality	-99.9-999.9(°C) During heating: subcool (SC) During cooling: superheat (SH) (Fixed to "0" during cooling operation)								Display of indoor SC/SH data at time of abnormality
206	01110011	IC1 SC/SH at time of abnormality									
207	11110011	IC2 SC/SH at time of abnormality									
208	00001011	IC3 SC/SH at time of abnormality									
209	10001011	IC4 SC/SH at time of abnormality									
210	01001011	IC5 SC/SH at time of abnormality	0-255								Display of indoor unit capacity code The No.1 unit will start from the M-NET address with the lowest number
211	11001011	IC6 Capacity code									
212	00101011	IC7 Capacity code									
213	10101011	IC8 Capacity code									
214	01101011	IC6 operation mode	STOP	Fan	Cooling thermo-ON	Cooling thermo-OFF	Heating thermo-ON	Heating thermo-OFF			Display of indoor unit operation mode
215	11101011	IC7 operation mode									
216	00011011	IC8 operation mode									

No.	SW1 setting	Display mode	Display on the LED1, 2 (display data)								Notes
			1	2	3	4	5	6	7	8	
217	10011011	IC6 LEV opening pulse	0-2000 (pulse)								Display of opening pulse of indoor LEV
218	01011001	IC7 LEV opening pulse									
219	11011001	IC8 LEV opening pulse									
220	00111011	IC6 TH23 (Gas)									
221	10111011	IC7 TH23 (Gas)	-99.9~999.9 (°F)								Display detected data of indoor unit thermistor
222	01111011	IC8 TH23 (Gas)									
223	11111011	IC6 TH22 (liquid)									
224	00001111	IC7 TH22 (liquid)									
225	10001111	IC8 TH22(liquid)	-99.9~999.9 (°C) during heating: subcool (SC)/during cooling: superheat (SH) (Fixed to "0" during cooling operation)								Display of indoor SC/SH data
226	01000111	IC6 TH21 (intake)									
227	11000111	IC7 TH21 (intake)									
228	00100111	IC8 TH21 (intake)									
229	10100111	IC6 SC/SH	SCm/SHm (0.0~20.0) (°C)								Display of all control target data
230	01100111	IC7 SC/SH									
231	11100111	IC8 SC/SH									
232	00010111	Target indoor SC/SH (IC6)									
233	10010111	Target indoor SC/SH (IC7)	0-2000 (pulse)								Display of opening pulse of indoor LEV at time of abnormality delay
234	01010111	Target indoor SC/SH (IC8)									
235	11010111	IC6 LEV opening pulse abnormality delay									
236	00110111	IC7 LEV opening pulse abnormality delay									
237	10110111	IC8 LEV opening pulse abnormality delay	-99.9~999.9 (°C) During heating: subcool (SC) During cooling: superheat (SH) (Fixed to "0" during cooling operation)								Display of indoor SC/SH data at time of abnormality delay
238	01110111	IC6 SC/SH at time of abnormality delay									
239	11110111	IC7 SC/SH at time of abnormality delay									
240	00001111	IC8 SC/SH at time of abnormality delay									
241	10001111	IC6 LEV opening pulse at time of abnormality	0-2000 (pulse)								Display of opening pulse of indoor LEV at time of abnormality
242	01001111	IC7EV opening pulse at time of abnormality									
243	11001111	IC8 LEV opening pulse at time of abnormality									
244	00101111	IC6 SC/SH at time of abnormality									
245	10101111	IC7 SC/SH at time of abnormality	-99.9~999.9 (°C) During heating: subcool (SC) During cooling: superheat (SH) (Fixed to "0" during cooling operation)								Display of indoor SC/SH data at time of abnormality delay
246	01101111	IC8 SC/SH at time of abnormality									
250	01011111	IC9 LEV opening pulse									
251	11011111	IC10 LEV opening pulse									
252	00111111	IC11 LEV opening pulse	0-2000 (pulse)								Display of opening pulse of indoor LEV
253	10111111	IC12 LEV opening pulse									


ELECTRICAL WIRING

9-1. OVERVIEW OF POWER WIRING


-  **Warning:**
- Be sure to use specified wires to connect so that no external force is imparted to terminal connections. If connections are not fixed firmly, it may cause heating or fire.
 - Be sure to use the appropriate type of overcurrent protection switch. Note that generated overcurrent may include some amount of direct current.

- ## 9-2. WIRING OF MAIN POWER SUPPLY AND EQUIPMENT CAPACITY

■ Schematic Drawing of Wiring : When NOT using a Branch Box (example)



<When power is supplied to outdoor unit and Branch box separately>



9-2-2. Cross section area of Wire for Main Power and ON/OFF capacities

Thickness of Wire for Main Power Supply and On/Off Capacities

<When power is supplied separately>

Model		Power Supply	Minimum Wire Thickness (mm ² [AWG])		Conduit size	Breaker for Wiring*1	Breaker for Current Leakage (If you use)	Minimum circuit ampacity	Maximum rating of over current protector device
			Main Cable*2	Ground					
Outdoor Unit	P36/48NKMU4	208/230 VAC, 60 Hz	5.3 [AWG10]	5.3 [AWG10]	1 *3	30 A	30 A, 30 mA 0.1 second or less	36 A	64 A
	HP36/42/48NKMU2		8.4 [AWG8]	8.4 [AWG8]	1 *3	40 A	40 A, 30 mA 0.1 second or less	45 A	80 A
	P60NKMU4		8.4 [AWG8]	8.4 [AWG8]	1 *3	40 A	40 A, 30 mA 0.1 second or less	45 A	80 A
Branch Box		Refer to installation manual of Branch Box.							

<When power is supplied from the outdoor unit>

Model		Power Supply	Minimum Wire Thickness (mm ² [AWG])		Conduit size	Breaker for Wiring*1	Breaker for Current Leakage (If you use)	Minimum circuit ampacity	Maximum rating of over current protector device
			Main Cable*2	Ground					
Outdoor Unit	P36/48NKMU4	208/230 VAC, 60 Hz	8.4 [AWG8]	8.4 [AWG8]	1 *3	40 A	40 A, 30 mA 0.1 second or less	42 A	70 A
	HP36/42/48NKMU2		13.3 [AWG6]	13.3 [AWG6]	1	45 A	45 A, 30 mA 0.1 second or less	51 A	86 A
	P60NKMU4		13.3 [AWG6]	13.3 [AWG6]	1	50 A	50 A, 30 mA 0.1 second or less	55 A	90 A
Branch Box		Refer to installation manual of Branch Box.							

*1 Please follow applicable federal, state, or local codes to prevent potential leakage/electric shock. Or install a ground fault interrupt for the prevention of leakage and electric shock.

IMPORTANT

If a current leakage breaker is used, it should be compatible with higher harmonics as this unit is equipped with an inverter. The use of an inadequate breaker can cause the incorrect operation of inverter.

*2 Use copper supply wires. Use the electric wires over the rating voltage 300 V.

*3 Although the conduit size is larger than the size specified for the wire thickness according to UL standards, use a conduit size of 1 inch.

Total operating current of the indoor unit	Minimum wire thickness (mm ² /AWG)			Ground-fault interrupter *1 (If you use)	Local switch (A)		Breaker for wiring (NFB)
	Main Cable	Branch	Ground		Capacity	Fuse	
F0 = 15 A or less *2	2.1/14	2.1/14	2.1/14	15 A current sensitivity *3	15	15	15
F0 = 20 A or less *2	3.3/12	3.3/12	3.3/12	20 A current sensitivity *3	20	20	20
F0 = 30 A or less *2	5.3/10	5.3/10	5.3/10	30 A current sensitivity *3	30	30	30

Apply to IEC61000-3-3 about max. permissive system impedance.

*1 The Ground-fault interrupter should support inverter circuit.

The Ground-fault interrupter should combine using of local switch or wiring breaker.

*2 Please take the larger of F1 or F2 as the value for F0.

F1 = Total operating maximum current of the indoor units × 1.2

F2 = {V1 × (Quantity of Type1)/C} + {V1 × (Quantity of Type2)/C} + {V1 × (Quantity of Type3)/C} + {V1 × (Quantity of Type4)/C} + ... + {V1 × (Quantity of Type14)/C}

Indoor unit		V1	V2
Type 1	PEAD-A-AA9	30.1	2.2
Type 2	PEAD-A-AA8, SVZ-KP-NA, PAA-A-A	26.9	
Type 3	PLA-A-EA7, SEZ-KD-NA	19.8	
Type 4	SLZ-KF-NA, PLA-A-EA8	17.1	
Type 5	MLZ-KP-NA(2)	9.9	2.4
Type 6	MFZ-KJ-NA, MSZ-GL-NA, MSZ-FS-NA, MSZ-GS-NA, MLZ-KY-NA, MXZ-EF-NA2W(B)(S)-U1	7.4	
Type 7	MSZ-FH-NA, MSZ-FH-NA2, MSZ-EF-NAW(B)(S)-U1	6.8	
Type 8	Branch box	5.1	3.0
Type 9	PEFY-P-NMAU-E3, PVFY-P-NAMU	38.0	1.6
Type 10	PKFY-P-NKMU, PEFY-P-NMSU, PCFY-P-NKMU, PLFY-EP-NEMU, PLFY-P-NFMU, PMFY-P-NBMU-ER5, PKFY-P-NLMU	19.8	2.4
Type 11	PEFY-P-NMHU, PFFY-P-NEMU, PFFY-P-NRMU	0.0	0.0
Type 12	PEFY-P-NMHSU (connected to MXZ-SM60 only)	13.8	4.8
Type 13	PEFY-P-NMAU-E4, PEFY-P-NMAU-E5	18.6	3.0
Type 14	PMFY-P-NBMU-ER6	9.9	2.4

C: Multiple of tripping current at tripping time 0.01s

Please pick up "C" from the tripping characteristic of the breaker.

<Example of "F2" calculation>

• Condition PEFY-NMSU × 4 + PEFY-NMAU-E3 × 1, C = 8 (refer to right sample chart)

F2 = 19.8 × 4/8 + 38 × 1/8

= 14.65

→ 16 A breaker (Tripping current = 8 × 16 A at 0.01 s)

*3 Current sensitivity is calculated using the following formula.

G1 = V2 × (Quantity of Type1) + V2 × (Quantity of Type2) + V2 × (Quantity of Type3) + ... + V2 × (Quantity of Type14) + V3 × (Wire length [km])

G1	Current sensitivity
30 or less	30 mA 0.1 second or less
100 or less	100 mA 0.1 second or less

Wire thickness (mm ² /AWG)	V3
2.1/14	48
3.3/12	56
5.3/10	66

1. Use a separate power supply for the outdoor unit and indoor unit.
2. Bear in mind ambient conditions (ambient temperature, direct sunlight, rain water etc.) when proceeding with the wiring and connections.
3. The wire size is the minimum value for metal conduit wiring. The power cord size should be 1 rank thicker consideration of voltage drops. Make sure the power-supply voltage does not drop more than 10%.
4. Specific wiring requirements should adhere to the wiring regulations of the region.
5. Power supply cords of parts of appliances for outdoor use shall not be lighter than polychloroprene sheathed flexible cord (design 60245 IEC57). For example, use wiring such as YZW.
6. Install an earth line longer than power cables.


9-3. DESIGN FOR CONTROL WIRING

Please note that the types and numbers of control wires needed by MULTI-S series depend on the remote controllers and whether they are linked with the system or not.

9-3-1. Selection number of control wires

		M-NET remote controller	
Use		Remote controller used in system control operations • Group operation involving different refrigerant systems • Linked operation with upper control system	
Remote controller → indoor unit		2-core wire (non-polar)	
Transmission wires	Wires connecting → indoor units		
	Wires connecting → indoor units with outdoor unit		
	Wires connecting → outdoor units		

Sample chart



9-4. WIRING TRANSMISSION CABLES

9-4-1. Types of control cables

1. Wiring transmission cables

Types of transmission cables	Shielded wire CVVS, CPEVS, or MVVS
Cable diameter	More than 13.5 ft ² [1.25 mm ²]
Maximum wiring length	Within 656 ft [200 m]

2. M-NET Remote control cables

Types of remote control cable	Shielded wire (2-core) CVVS, CPEVS, or MVVS
Cable diameter	AWG 20 to AWG 16 [0.5 to 1.25 mm ²]
Remarks	When 10 m is exceeded, use a cable with the same specifications as transmission line wiring.

3. MA Remote control cables

Type of remote control cable	Sheathed 2-core cable (unshielded) CVV
Cable diameter	AWG 22 to AWG 16 [0.3 to 1.25 mm ²] AWG 18 to AWG 16 [0.75 to 1.25 mm ²]*
Remarks	Within 656 ft [200 m]

* Connected with simple remote controller.

9-4-2. Wiring examples

- Controller name, symbol and allowable number of controllers.

Name		Symbol	Allowable number of controllers	
Outdoor unit controller		OC	—	
Indoor unit controller	CITY MULTI series	M-IC	P36	Refer to 2-2. SYSTEM CONSTRUCTION
			(H)P42/48/60	
	M, S, P series	A-IC	(H)P36	Refer to 2-3. SYSTEM CONSTRUCTION (BRANCH BOX SYSTEM)
			HP42	
			(H)P48	
			P60	
Branch box		BC	—	0 to 2 units per 1 OC ^{*1}
Remote controller		RC	M-NET RC ^{*2}	Maximum of 12 controllers for 1 OC ^{*1}
			MA-RC	Maximum of 2 per group

Note:

^{*1} The number of connectable units may be limited by some conditions such as an indoor unit's capacity or each unit's equivalent power consumption.


^{*2} Don't use the Lossnay controller (PZ-61DR-E, PZ-43SMF-E, PZ-52SF-E, PZ-60DR-E).

9-5. SYSTEM SWITCH SETTING


In order to identify the destinations of signals to the outdoor units, indoor units, and remote controller of MULTI-S series, each microprocessor must be assigned an identification number (address). The addresses of outdoor units, indoor units, and remote controller must be set using their settings switches. Please consult the installation manual that comes with each unit for detailed information on setting procedures.

9-6. EXAMPLE OF EXTERNAL WIRING DIAGRAM FOR A BASIC SYSTEM


■ Example of system when using an M-NET controller



■ Example of system when using a Branch Box <When power is supplied to outdoor unit and Branch box separately>



<When power is supplied to Branch box from the outdoor unit>



9-7. METHOD FOR OBTAINING ELECTRICAL CHARACTERISTICS WHEN A CAPACITY AGREEMENT IS TO BE SIGNED WITH AN ELECTRIC POWER COMPANY

The electrical characteristics of connected indoor unit system for air conditioning systems, including CITY MULTI series, depend on the arrangement of the indoor and outdoor units.

First read the data on the selected indoor and outdoor units and then use the following formulas to calculate the electrical characteristics before applying for a capacity agreement with the local electric power company.

9-7-1. Obtaining the electrical characteristics of CITY MULTI series system

(1) Procedure for obtaining total power consumption

	Page numbers in this technical manual	Power consumption
Total power consumption of each indoor unit	See the technical manual of each indoor unit.	①
Power consumption of outdoor unit*	Standard capacity diagram— Refer to 4-4.	②
Total power consumption of system	See the technical manual of each indoor unit.	① + ② <kW>

*The power consumption of the outdoor unit will vary depending on the total capacity of the selected indoor units.

(2) Method of obtaining total current

	Page numbers in this technical manual	Subtotal
Total current through each indoor unit	See the technical manual of each indoor unit.	①
Current through outdoor unit*	Standard capacity diagram— Refer to 4-4.	②
Total current through system	See the technical manual of each indoor unit.	① + ② <A>

The current through the outdoor unit will vary depending on the total capacity of the selected indoor units.

(3) Method of obtaining system power factor

Use the following formula and the total power and current obtained in parts ① and ② on the above tables to calculate the system power factor.

$$\text{System power factor} = \frac{(\text{Total system power consumption})}{(\text{Total system current} \times \text{voltage})} \times 100 \%$$

9-7-2. Applying to an electric power company for power and total current

Calculations should be performed separately for heating and cooling employing the same methods; use the largest resulting value in your application to the electric power company.


10-1. REFRIGERANT PIPING SYSTEM

10-1-1. PUMY-P36NKMU4 PUMY-HP36NKMU2

PUMY-HP42NKMU2

PUMY-P48NKMU4

PUMY-HP48NKMU2

Line-Branch Method
 Connection Examples
 (Connecting to 4 Indoor Units)


Permissible Length	Total Piping Length	$A+B+C+a+b+c+d \leq 984 \text{ ft [300 m]}$
	Farthest Piping Length (L)	$A+B+C+d \leq 492 \text{ ft [150 m]}$
	Farthest Piping Length After First Branch (Q)	$B+C+d \leq 98 \text{ ft [30 m]}$
Permissible High/Low Difference	High/Low Difference in Indoor/Outdoor Section (H)	The outdoor unit is upper: 164 ft [50 m] or less The outdoor unit is lower: 131 ft [40 m] or less (98 ft [30 m] or less if PKFY-P04/06/08/12NLMU, PFFY-P06/08/12NEMU, and PFFY-P06/08/12NRMU are included.)
	High/Low Difference in Indoor/Indoor Section (h)	49 ft [15 m]

■ Selecting the Refrigerant Branch Kit

Use an optional Branch piping kit (CMY-Y62-G-E).

■ Select Each Section of Refrigerant Piping

- (1) Section From Outdoor Unit to First Branch (A)
 (2) Sections From Branch to Indoor Unit (a,b,c,d)
 (3) Section From Branch to Branch (B,C)
- Each Section of Piping

Select the size from the table to the right.

- (1) Refrigerant Piping Diameter In Section From Outdoor Unit to First Branch (Outdoor Unit Piping Diameter)
 (2) Refrigerant Piping Diameter In Section From Branch to Indoor Unit (Indoor Unit Piping Diameter)

Model	Piping Diameter (in. [mm])	Model number	Piping Diameter (in. [mm])
PUMY-(H)P36/42/48	Liquid Line 3/8 [ø9.52]	18 or lower	Liquid Line 1/4 [ø6.35]
	Gas Line 5/8 [ø15.88]		Gas Line 1/2 [ø12.7]
		24 to 54	Liquid Line 3/8 [ø9.52]
			Gas Line 5/8 [ø15.88]

- (3) Refrigerant Piping Diameter In Section From Branch to Branch

Liquid Line (in. [mm])	Gas Line (in. [mm])
3/8 [ø9.52]	5/8 [ø15.88]

■ Additional refrigerant charge

Refrigerant for the extended piping is not included in the outdoor unit when the unit is shipped from the factory. Therefore, charge each refrigerant piping system with additional refrigerant at the installation site. In addition, in order to carry out service, enter the size and length of each liquid pipe and additional refrigerant charge amounts in the spaces provided on the "Refrigerant amount" plate on the outdoor unit.

Calculation of additional refrigerant charge

- Calculate the additional charge using the liquid pipe size and length of the extended piping and total capacity of connected indoor units.
- Calculate the additional refrigerant charge using the procedure shown to the right, and charge with the additional refrigerant.
- For amounts less than 0.2 lb [0.1 kg], round up the calculated additional refrigerant charge. (For example, if the calculated charge is 13.2 lb [6.01 kg], round up the charge to 13.4 lb [6.1 kg].)

<Additional Charge>
Calculation of refrigerant charge

Pipe size Liquid pipe		Pipe size Liquid pipe		Total capacity of connected indoor units	Amount for the indoor units
ø6.35	+	ø9.52	+	- 27 kBTu/h	53 oz (1.5 kg)
[ft] × 0.21 [oz/ft] (m) × 19.0 [g/m]		[ft] × 0.55 [oz/ft] (m) × 50.0 [g/m]		28 - 54 kBTu/h	88 oz (2.5 kg)
				55 - 62 kBTu/h	106 oz (3.0 kg)

Included refrigerant amount when shipped from the factory

Included refrigerant amount
10 LBS. 9 OZ. (4.8 kg)

<Example>

Outdoor model : P48

Indoor 1 : P24 (24 kBTu/h)

2 : P15 (15 kBTu/h)

3 : P08 (8 kBTu/h)

4 : P06 (6 kBTu/h)

A : ø9.52	66 ft [20 m]
B : ø9.52	16 ft [5 m]
C : ø9.52	16 ft [5 m]
a : ø9.52	49 ft [15 m]
b : ø6.35	33 ft [10 m]
c : ø6.35	33 ft [10 m]
d : ø6.35	66 ft [20 m]

At the conditions below:

The total length of each liquid line is as follows:

 [3/8"] ø9.52 : $A + B + C + a = 20 + 5 + 5 + 15 = 147 \text{ ft [45 m]}$

 [1/4"] ø6.35 : $b + c + d = 10 + 10 + 20 = 132 \text{ ft [40 m]}$


The total capacity of connected indoor unit is as follows:

 $24 + 15 + 08 + 06 = 53$
<Calculation example>

Additional refrigerant charge

 $132 \text{ ft} \times 0.21 \text{ oz} + 147 \text{ ft} \times 0.55 \text{ oz} + 88 \text{ oz} = 197 \text{ oz}$
 $\left[40 \times \frac{19.0}{1000} + 45 \times \frac{50.0}{1000} + 2.5 = 5.6 \text{ kg (rounded up)} \right]$


Header-Branch Method
Connection Examples
(Connecting to 4 Indoor Units)



Permissible Length	Total Piping Length	A+a+b+c+d ≤ 984 ft [300 m]													
	Farthest Piping Length (L)	A+d ≤ 492 ft [150 m]													
	Farthest Piping Length After First Branch (ℓ)	d ≤ 98 ft [30 m]													
Permissible High/Low Difference	High/Low Difference in Indoor/Outdoor Section (H)	The outdoor unit is upper: 164 ft [50 m] or less The outdoor unit is lower: 131 ft [40 m] or less (98 ft [30 m] or less if PKFY-P04/06/08/12NLMU, PFFY-P06/08/12NEMU, and PFFY-P06/08/12NRMU are included.)													
	High/Low Difference in Indoor/Indoor Section (h)	49 ft [15 m]													
■ Selecting the Refrigerant Branch Kit		Please select branching kit, which is sold separately, from the table below. (The kit comprises sets for use with liquid pipes and for use with gas pipes.) <table><tr><td>Branch header (4 branches)</td><td>Branch header (8 branches)</td></tr><tr><td>CMY-Y64-G-E</td><td>CMY-Y68-G-E</td></tr></table>	Branch header (4 branches)	Branch header (8 branches)	CMY-Y64-G-E	CMY-Y68-G-E									
Branch header (4 branches)	Branch header (8 branches)														
CMY-Y64-G-E	CMY-Y68-G-E														
■ Select Each Section of Refrigerant Piping		(1) Refrigerant Piping Diameter In Section From Outdoor Unit to First Branch (Outdoor Unit Piping Diameter) <table><tr><td>Model</td><td>Piping Diameter (in. [mm])</td></tr><tr><td rowspan="2">PUMY-(H)P36/42/48</td><td>Liquid Line 3/8 [ø9.52]</td></tr><tr><td>Gas Line 5/8 [ø15.88]</td></tr></table> (2) Refrigerant Piping Diameter In Section From Branch to Indoor Unit (Indoor Unit Piping Diameter) <table><tr><td>Model number</td><td>Piping Diameter (in. [mm])</td></tr><tr><td rowspan="2">18 or lower</td><td>Liquid Line 1/4 [ø6.35]</td></tr><tr><td>Gas Line 1/2 [ø12.7]</td></tr><tr><td rowspan="2">24 to 54</td><td>Liquid Line 3/8 [ø9.52]</td></tr><tr><td>Gas Line 5/8 [ø15.88]</td></tr></table>	Model	Piping Diameter (in. [mm])	PUMY-(H)P36/42/48	Liquid Line 3/8 [ø9.52]	Gas Line 5/8 [ø15.88]	Model number	Piping Diameter (in. [mm])	18 or lower	Liquid Line 1/4 [ø6.35]	Gas Line 1/2 [ø12.7]	24 to 54	Liquid Line 3/8 [ø9.52]	Gas Line 5/8 [ø15.88]
Model	Piping Diameter (in. [mm])														
PUMY-(H)P36/42/48	Liquid Line 3/8 [ø9.52]														
	Gas Line 5/8 [ø15.88]														
Model number	Piping Diameter (in. [mm])														
18 or lower	Liquid Line 1/4 [ø6.35]														
	Gas Line 1/2 [ø12.7]														
24 to 54	Liquid Line 3/8 [ø9.52]														
	Gas Line 5/8 [ø15.88]														
(1) Section From Outdoor Unit to First Branch (A) (2) Sections From Branch to Indoor Unit (a,b,c,d) Each Section of Piping Select the size from the table to the right.		(3) Refrigerant Piping Diameter In Section From Branch to Branch <table><tr><td>Liquid Line (in. [mm])</td><td>Gas Line (in. [mm])</td></tr><tr><td>3/8 [ø9.52]</td><td>5/8 [ø15.88]</td></tr></table>	Liquid Line (in. [mm])	Gas Line (in. [mm])	3/8 [ø9.52]	5/8 [ø15.88]									
Liquid Line (in. [mm])	Gas Line (in. [mm])														
3/8 [ø9.52]	5/8 [ø15.88]														
■ Additional refrigerant charge		Refer to the same section in the previous page.													

Method of Combined Branching of Lines and Headers

Connection Examples
(Connecting to 5 Indoor Units)




Permissible Length	Total Piping Length	A+B+C+a+b+c+d+e ≤ 984 ft [300 m]			
	Farthest Piping Length (L)	A+B+b ≤ 492 ft [150 m]			
	Farthest Piping Length After First Branch (ℓ)	B+b ≤ 98 ft [30 m]			
Permissible High/Low Difference	High/Low Difference in Indoor/Outdoor Section (H)	The outdoor unit is upper: 164 ft [50 m] or less The outdoor unit is lower: 131 ft [40 m] or less (98 ft [30 m] or less if PKFY-P04/06/08/12NLMU, PFFY-P06/08/12NEMU, and PFFY-P06/08/12NRMU are included.)			
	High/Low Difference in Indoor/Indoor Section(h)	49 ft [15 m]			
■ Selecting the Refrigerant Branch Kit		Please select branching kit, which is sold separately, from the table below. (The kit comprises sets for use with liquid pipes and for use with gas pipes.)			
		Branch Joint	Branch Header (4 branches)	Branch Header (8 branches)	
		CMY-Y62-G-E	CMY-Y64-G-E	CMY-Y68-G-E	
■ Select Each Section of Refrigerant Piping		(1) Refrigerant Piping Diameter In Section From Outdoor Unit to First Branch (Outdoor Unit Piping Diameter)			
<div>(1) Section From Outdoor Unit to First Branch (A)</div> <div>(2) Sections From Branch to Indoor Unit (a,b,c,d,e)</div> <div>(3) Section From Branch to Branch (B,C)</div> <div>Each Section of Piping</div>		Model		Piping Diameter (in. [mm])	
		PUMY-(H)P36/42/48		Liquid Line	3/8 [ø9.52]
				Gas Line	5/8 [ø15.88]
		(2) Refrigerant Piping Diameter In Section From Branch to Indoor Unit (Indoor Unit Piping Diameter)			
		Model number	Piping Diameter(in. [mm])		
		18 or lower	Liquid Line	1/4 [ø6.35]	
			Gas Line	1/2 [ø12.7]	
		24 to 54	Liquid Line	3/8 [ø9.52]	
			Gas Line	5/8 [ø15.88]	
Select the size from the table to the right.		(3) Refrigerant Piping Diameter In Section From Branch to Branch			
		Liquid Line (in. [mm])		Gas Line (in. [mm])	
		3/8 [ø9.52]		5/8 [ø15.88]	
■ Additional refrigerant charge		Refer to the same section in the previous page.			

10-1-2. PUMY-P60NKMU4

Line-Branch Method

Connection Examples
(Connecting to 4 Indoor Units)



Permissible Length	Total Piping Length	$A+B+C+a+b+c+d \leq 492 \text{ ft [150 m]}$
	Farthest Piping Length (L)	$A+B+C+d \leq 262 \text{ ft [80 m]}$
	Farthest Piping Length After First Branch (ℓ)	$B+C+d \leq 98 \text{ ft [30 m]}$
Permissible High/Low Difference	High/Low Difference in Indoor/Outdoor Section (H)	164 ft [50 m] (If the outdoor unit is lower, 131 ft [40 m])
	High/Low Difference in Indoor/Indoor Section (h)	49 ft [15 m]

■ Selecting the Refrigerant Branch Kit

Use an optional Branch piping kit (CMY-Y62-G-E).

■ Select Each Section of Refrigerant Piping

- (1) Section From Outdoor Unit to First Branch (A)
(2) Sections From Branch to Indoor Unit (a,b,c,d)
(3) Section From Branch to Branch (B,C)
- Each Section of Piping

Select the size from the table to the right.

(1) Refrigerant Piping Diameter In Section From Outdoor Unit to First Branch (Outdoor Unit Piping Diameter)		(2) Refrigerant Piping Diameter In Section From Branch to Indoor Unit (Indoor Unit Piping Diameter)	
Model	Piping Diameter (in. [mm])	Model number	Piping Diameter (in. [mm])
PUMY-P60	Liquid Line	18 or lower	Liquid Line 1/4 [ø6.35]
	Gas Line		Gas Line 1/2 [ø12.7]
		24 to 54	Liquid Line 3/8 [ø9.52]
			Gas Line 5/8 [ø15.88]
		72	Liquid Line 3/8 [ø9.52]
			Gas Line 3/4 [ø19.05]

(3) Refrigerant Piping Diameter In Section From Branch to Branch	
Liquid Line (in. [mm])	Gas Line (in. [mm])
3/8 [ø9.52]	3/4 [ø19.05]

■ Additional refrigerant charge

Refrigerant for the extended piping is not included in the outdoor unit when the unit is shipped from the factory. Therefore, charge each refrigerant piping system with additional refrigerant at the installation site. In addition, in order to carry out service, enter the size and length of each liquid pipe and additional refrigerant charge amounts in

the spaces provided on the "Refrigerant amount" plate on the outdoor unit.

Calculation of additional refrigerant charge

- Calculate the additional charge using the liquid pipe size and length of the extended piping and total capacity of connected indoor units.
- Calculate the additional refrigerant charge using the procedure shown to the right, and charge with the additional refrigerant.
- For amounts less than 0.2 lb [0.1 kg], round up the calculated additional refrigerant charge.
(For example, if the calculated charge is 13.2 lb [6.01 kg], round up the charge to 13.4 lb [6.1 kg].)
- The amount of additional refrigerant for PUMY-P60 which is calculated from the total capacity of indoor units and the combination of extended pipes must not be over 28.4 lb [12.9 kg].

<Additional Charge>

Calculation of refrigerant charge

Pipe size Liquid pipe		Pipe size Liquid pipe		Total capacity of connected indoor units	Amount for the indoor units
ø6.35	+	ø9.52	+	– 27 kBTu/h	53 oz (1.5 kg)
[ft] × 0.29 [oz/ft]		[ft] × 0.75 [oz/ft]		28 – 54 kBTu/h	88 oz (2.5 kg)
(m) × 27.0 (g/m)		(m) × 70.0 (g/m)		55 – 78 kBTu/h	106 oz (3.0 kg)

Included refrigerant amount when shipped from the factory

Included refrigerant amount
11 LBS. 4 OZ. (5.1 kg)

<Example>

Outdoor model : P60
Indoor 1 : P24 (24 kBTu/h)
2 : P15 (15 kBTu/h)
3 : P08 (8 kBTu/h)
4 : P06 (6 kBTu/h)

A : ø9.52 66 ft [20 m]	At the conditions below:
B : ø9.52 16 ft [5 m]	
C : ø9.52 16 ft [5 m]	
a : ø9.52 49 ft [15 m]	
b : ø6.35 33 ft [10 m]	
c : ø6.35 33 ft [10 m]	
d : ø6.35 66 ft [20 m]	

The total length of each liquid line is as follows:

[3/8"] ø9.52 : $A + B + C + a = 20 + 5 + 5 + 15 = 147 \text{ ft [45 m]}$

[1/4"] ø6.35 : $b + c + d = 10 + 10 + 20 = 132 \text{ ft [40 m]}$

The total capacity of connected indoor unit is as follows:


24 + 15 + 08 + 06 = 53

<Calculation example>

Additional refrigerant charge


$132 \text{ ft} \times 0.29 \text{ oz} + 147 \text{ ft} \times 0.75 \text{ oz} + 88 \text{ oz} = 237 \text{ oz}$
 $40 \times \frac{27.0}{1000} + 45 \times \frac{70.0}{1000} + 2.5 = 6.8 \text{ kg (rounded up)}$

Header-Branch Method
Connection Examples
(Connecting to 4 Indoor Units)



Permissible Length	Total Piping Length	A+a+b+c+d ≤ 492 ft [150 m]			
	Farthest Piping Length (L)	A+d ≤ 262 ft [80 m]			
	Farthest Piping Length After First Branch (ℓ)	d ≤ 98 ft [30 m]			
Permissible High/Low Difference	High/Low Difference in Indoor/Outdoor Section (H)	164 ft [50 m] (If the outdoor unit is lower, 131 ft [40 m])			
	High/Low Difference in Indoor/Indoor Section (h)	49 ft [15 m]			
■ Selecting the Refrigerant Branch Kit		Please select branching kit, which is sold separately, from the table below. (The kit comprises sets for use with liquid pipes and for use with gas pipes.)			
		Branch header (4 branches)		Branch header (8 branches)	
		CMY-Y64-G-E		CMY-Y68-G-E	
■ Select Each Section of Refrigerant Piping		(1) Refrigerant Piping Diameter In Section From Outdoor Unit to First Branch (Outdoor Unit Piping Diameter)			
(1) Section From Outdoor Unit to First Branch (A) (2) Sections From Branch to Indoor Unit (a,b,c,d)		Each Section of Piping		(2) Refrigerant Piping Diameter In Section From Branch to Indoor Unit (Indoor Unit Piping Diameter)	
		Model		Piping Diameter (in. [mm])	
		PUMY-60		Liquid Line	3/8 [ø9.52]
				Gas Line	3/4 [ø19.05]
		(3) Refrigerant Piping Diameter In Section From Branch to Branch			
		Liquid Line (in. [mm])		Gas Line (in. [mm])	
		3/8 [ø9.52]		3/4 [ø19.05]	
Select the size from the table to the right.					
■ Additional refrigerant charge		Refer to the same section in the previous page.			

Method of Combined Branching of Lines and Headers
Connection Examples
(Connecting to 5 Indoor Units)



Permissible Length	Total Piping Length	A+B+C+a+b+c+d+e is 492 ft [150 m]
	Farthest Piping Length (L)	A+B+b is 262 ft [80 m]
	Farthest Piping Length After First Branch (l)	B+b ≤ 98 ft [30 m]
Permissible High/Low Difference	High/Low Difference in Indoor/Outdoor Section (H)	164 ft [50 m] (If the outdoor unit is lower, 131 ft [40 m] or less)
	High/Low Difference in Indoor/Indoor Section (h)	49 ft [15 m]

■ **Selecting the Refrigerant Branch Kit**

Please select branching kit, which is sold separately, from the table below.
(The kit comprises sets for use with liquid pipes and for use with gas pipes.)

Branch Joint	Branch Header (4 branches)	Branch Header (8 branches)
CMY-Y62-G-E	CMY-Y64-G-E	CMY-Y68-G-E

■ **Select Each Section of Refrigerant Piping**

- (1) Section From Outdoor Unit to First Branch (A)
(2) Sections From Branch to Indoor Unit (a,b,c,d,e)
(3) Section From Branch to Branch (B,C)
- Each Section of Piping

Select the size from the table to the right.


(1) Refrigerant Piping Diameter In Section From Outdoor Unit to First Branch (Outdoor Unit Piping Diameter)			(2) Refrigerant Piping Diameter In Section From Branch to Indoor Unit (Indoor Unit Piping Diameter)		
Model	Piping Diameter (in. [mm])		Model number	Piping Diameter (in. [mm])	
PUMY-P60	Liquid Line	3/8 [ø9.52]	18 or lower	Liquid Line	1/4 [ø6.35]
	Gas Line	3/4 [ø19.05]		Gas Line	1/2 [ø12.7]
			24 to 54	Liquid Line	3/8 [ø9.52]
				Gas Line	5/8 [ø15.88]
			72	Liquid Line	3/8 [ø9.52]
				Gas Line	3/4 [ø19.05]

(3) Refrigerant Piping Diameter In Section From Branch to Branch	
Liquid Line (in. [mm])	Gas Line (in. [mm])
3/8 [ø9.52]	3/4 [ø19.05]

■ **Additional refrigerant charge**

Refer to the same section in the previous page.

Branch box Method
Connection Examples
(Connecting to 8 Indoor Units)



Permissible length (One-way)	Total piping length	$A + B + C + a + b + c + d + e + f + g + h \leq 492 \text{ ft [150 m]}$
	Farthest piping length (L)	$A + C + h \leq 262 \text{ ft [80 m]}$
	Piping length between outdoor unit and Branch boxes	$A + B + C \leq 180 \text{ ft [55 m]}$
	Farthest piping length after Branch box (l)	$l \leq 82 \text{ ft [25 m]}$
	Total piping length between Branch boxes and indoor units	$a + b + c + d + e + f + g + h \leq 312 \text{ ft [95 m]}$
Permissible height difference (One-way)	In indoor/outdoor section (H)*1	$H \leq 164 \text{ ft [50 m]}$ (In the case of that outdoor unit is set higher than indoor unit) $H \leq 131 \text{ ft [40 m]}$ (In the case of that outdoor unit is set lower than indoor unit)
	In Branch box/indoor unit section (h1)	$h1 + h2 \leq 49 \text{ ft [15 m]}$
	In each Branch unit (h2)	$h2 \leq 49 \text{ ft [15 m]}$
	In each indoor unit (h3)	$h3 \leq 39 \text{ ft [12 m]}$
	Number of bends	≤ 15

*1 Branch box should be placed within the level between the outdoor unit and indoor units.

■ **Select Each Section of Refrigerant Piping**

- (1) Section From Outdoor Unit to Branch box (A, B, C)
(2) Sections From Branch box to Indoor Unit (a to h)

Each Section of Piping

Select the size from the table to the right.

(1) Refrigerant Piping Diameter In Section From Outdoor Unit to Branch box (Outdoor Unit Piping Diameter)

Model	Piping Diameter (in. [mm])
PUMY-(H)P36/42/48	Liquid Line 3/8 [ø9.52]
	Gas Line 5/8 [ø15.88]
PUMY-P60	Liquid Line 3/8 [ø9.52]
	Gas Line 3/4 [ø19.05]

(2) Refrigerant Piping Diameter In Section From Branch box to Indoor Unit (Indoor Unit Piping Diameter)

Indoor unit series	Model number	A Liquid pipe (in. [mm])	B Gas pipe (in. [mm])
M series or S series	12 or lower	1/4 [ø6.35]	3/8 [ø9.52]
	15, 18		1/2 [ø12.7]
	24 or higher	3/8 [ø9.52]	5/8 [ø15.88]
P series	18 or lower	1/4 [ø6.35]	1/2 [ø12.7]
	24 or higher	3/8 [ø9.52]	5/8 [ø15.88]

When both of following bullet are satisfied gas piping diagram size shall be increased by one size.

- Indoor units which connected are all of A-COIL type (PAA-A).
- Total piping length is 33 ft (10 m) or less.

■ **Additional refrigerant charge**

Refer to the constraint below and the same section in the previous page.
When connecting a PAA-series unit(s), set additional constraints on the amount of additional refrigerant as follow.

Number of connecting PAA-A • A	PUMY-(H)P36/42/48	PUMY-P60
1 unit	7.7 kg 27 1oz	11.2 kg 395 oz
2 units	6.7 kg 236 oz	10.2 kg 359 oz
3 units	6.7 kg 236 oz	9.7 kg 342 oz

10-2. PRECAUTIONS AGAINST REFRIGERANT LEAKAGE

10-2-1. Introduction


R410A refrigerant of this air conditioner is non-toxic and non-flammable but leaking of large amount from an indoor unit into the room where the unit is installed may be deleterious. To prevent possible injury, the rooms should be large enough to keep the R410A concentration specified by ISO 5149-1 as follows.

Maximum concentration

Maximum refrigerant concentration of R410A of a room is 0.44kg/m^3 accordance with ISO 5149-1.
To facilitate calculation, the maximum concentration is expressed in units of kg/m^3 [lbs/ft³] (kg [lbs] of R410A per m³ [ft³])

Maximum concentration of R410A: 0.027 lbs/ft^3 [0.44 kg/m^3]

(ISO 5149-1)



10-2-2. Confirming procedure of R410A concentration

Follow (1) to (3) to confirm the R410A concentration and take appropriate treatment, if necessary.

(1) Calculate total refrigerant amount by each refrigerant system. Total refrigerant amount is precharged refrigerant at ex-factory plus additional charged amount at field installation.


Note:

When the air conditioning system consists of several independent refrigerant system, figure out the total refrigerant amount by each independent refrigerant system.


(2) Calculate room volumes (m³) and find the room with the smallest volume

The part with represents the room with the smallest volume.


(a) Situation in which there are no partitions



(b) There are partitions, but there are openings that allow the effective mixing of air.



(c) If the smallest room has mechanical ventilation apparatus that is linked to a household gas detection and alarm device, the calculations should be performed for the second smallest room.



(3) Use the results of calculations (1) and (2) to calculate the refrigerant concentration:

$$\frac{\text{Total refrigerant in the refrigerating unit (lbs [kg])}}{\text{The smallest room in which an indoor unit has been installed (ft}^3 \text{ [m}^3\text{])}} \leq \text{Maximum concentration (lbs/ft}^3 \text{ [kg/m}^3\text{])}$$

The smallest room in which an indoor unit has been installed (ft³ [m³])

Maximum concentration of R410A: 0.027 lbs/ft^3 [0.44 kg/m^3]

If the calculation results do not exceed the maximum concentration, perform the same calculations for the larger second and third room, etc., until it has been determined that nowhere the maximum concentration will be exceeded.

PUMY-P36NKMU4 PUMY-P48NKMU4

→ : Indicates the visible parts in the photos/figures.

Note: Turn OFF the power supply before disassembly.


OPERATING PROCEDURE

1. Removing the service panel and top panel

- (1) Remove 3 service panel fixing screws (5 × 12) and slide the hook on the right downward to remove the service panel.
- (2) Remove screws (2 for front, 3 for rear/5 × 12) of the top panel and remove it.

PHOTOS/FIGURES

Photo 1



2. Removing the fan motor (MF1, MF2)

- (1) Remove the service panel. (See Photo 1)
- (2) Remove the top panel. (See Photo 1)
- (3) Remove 4 fan grille fixing screws (5 × 12) to detach the fan grille. (See Photo 1)
- (4) Remove a nut (for right handed screw of M6) to detach the propeller. (See Photo 2)
- (5) Disconnect the connectors, CNF1 and CNF2 on multi controller circuit board in electrical parts box.
- (6) Remove 4 fan motor fixing screws (5 × 20) to detach the fan motor. (See Photo 3)

Note: Tighten the propeller fan with a torque of 5.7 ± 0.3 N·m [4.2 ± 0.2 ft = lbs]

Photo 2





Photo 3



3. Removing the electrical parts box

- (1) Remove the service panel. (See Photo 1)
- (2) Remove the top panel. (See Photo 1)
- (3) Disconnect the connecting wire from terminal block.
- (4) Remove all the following connectors from multi controller circuit board;

<Diagram symbol in the connector housing>

- Fan motor (CNF1, CNF2)
- Thermistor <HIC pipe> (TH2)
- Thermistor <Outdoor liquid pipe> (TH3)
- Thermistor <Compressor> (TH4)
- Thermistor <Suction pipe/Ambient, Outdoor> (TH7/6)
- High pressure switch (63H)
- High pressure sensor (63HS)
- Low pressure sensor (63LS)
- 4-way valve (21S4)
- Bypass valve (SV1)
- Linear expansion valve (LEV-A, LEV-B)

Pull out the disconnected wire from the electrical parts box.

- (5) Remove the terminal cover and disconnect the compressor lead wire from the comp. terminal. (See Figure 1)

Note: The terminal cover can be easily removed by using a blade of flathead screwdriver.

Figure 1













Photo 4



From the previous page.

OPERATING PROCEDURE	PHOTOS/FIGURES
<p>(6) Remove 2 electrical parts box fixing screws (4 × 10) and detach the electrical parts box by pulling it upward. The electrical parts box is fixed with 2 hooks on the left and 1 hook on the right.</p>	<p>Photo 5</p> 
<p>4. Removing the thermistor <Suction pipe> (TH6)</p> <ol style="list-style-type: none"> (1) Remove the service panel. (See Photo 1) (2) Remove the top panel. (See Photo 1) (3) Disconnect the connector, TH7/6 (red), on the multi controller circuit board in the electrical parts box. (4) Loosen the wire clamps on top of the electrical parts box. (5) Pull out the thermistor <Suction pipe> (TH6) from the sensor holder. (See Photo 7) <p>Note: When replacing thermistor <Suction pipe> (TH6), replace it together with thermistor <Ambient> (TH7) since they are combined together. Refer to procedure No.5 below to remove thermistor <Ambient> (TH7).</p>	<p>Photo 6</p>  <p>Photo 7</p> 
<p>5. Removing the thermistor <Ambient> (TH7)</p> <ol style="list-style-type: none"> (1) Remove the service panel. (See Photo 1) (2) Remove the top panel. (See Photo 1) (3) Disconnect the connector TH7/6 (red) on the multi controller circuit board in the electrical parts box. (4) Loosen the wire clamps on top of the electrical parts box. (See Photo 6) (5) Pull out the thermistor <Ambient> (TH7) from the sensor holder. <p>Note: When replacing thermistor <Ambient> (TH7), replace it together with thermistor <Suction pipe> (TH6), since they are combined together. Refer to procedure No.4 above to remove thermistor <Suction pipe> (TH6).</p>	<p>Photo 8</p> 

OPERATING PROCEDURE	PHOTOS/FIGURES
<p>6. Removing the thermistor <Outdoor liquid pipe> (TH3) and thermistor <Compressor> (TH4), thermistor <HIC pipe> (TH2)</p> <ol style="list-style-type: none"> (1) Remove the service panel. (See Photo 1) (2) Disconnect the connectors, TH3 (white) and TH4 (white), TH2 (black) on the multi controller circuit board in the electrical parts box. (3) Pull out the thermistor <Outdoor liquid pipe> (TH3) and thermistor <Compressor> (TH4) from the sensor holder. (See Photo 7 and 9) 	<p>Photo 9</p>  <p>Thermistor <Outdoor liquid pipe> (TH3)</p>
<p>7. Removing the 4-way valve coil (21S4)</p> <ol style="list-style-type: none"> (1) Remove the service panel. (See Photo 1) (2) Remove 4-way valve coil fixing screw (M5 × 7). (3) Remove the 4-way valve coil by sliding the coil to the right. (4) Disconnect the connector 21S4 (green) on the multi controller circuit board in the electrical parts box. 	<p>Photo 10</p>  <p>4-way valve coil (21S4) 4-way valve</p> <p>4-way valve coil fixing screw</p>
<p>8. Removing the 4-way valve</p> <ol style="list-style-type: none"> (1) Remove the service panel. (See Photo 1) (2) Remove the top panel. (See Photo 1) (3) Remove the electrical parts box (See Photo 5) (4) Remove 3 valve bed fixing screws (4 × 10) and 4 ball valve and stop valve fixing screws (5 × 16), then remove the valve bed. (See Photo 4 and 7) (5) Remove 2 cover panel fixing screws (5 × 12), then slide the cover panel (front) upward to remove it. (The cover panel (front) is fixed to the cover panel (rear) with a hook on the rear side. (See Photo 4) (6) Remove the cover panel (rear) fixing screws (2 for right side and 2 for rear/ 5 × 12), then slide the cover panel (rear) upward to remove it. (The cover panel (rear) is fixed to the side panel (R) with 2 screws.) (7) Remove 3 side panel (R) fixing screws (5 × 12) in the rear of the unit, then slide the side panel (R) upward to remove it. (The side panel (R) is fixed to the side plate with hooks on the rear side.) (8) Remove the 4-way valve coil. (See Photo 10) (9) Recover refrigerant. (10) Remove the welded part of 4-way valve. <p>Notes:</p> <ol style="list-style-type: none"> 1. Recover refrigerant without spreading it in the air. 2. The welded part can be removed easily by removing the side panel (R). 3. When installing the 4-way valve, cover it with a wet cloth to prevent it from heating (248°F [120°C] or more), then braze the pipes so that the inside of pipes are not oxidized. 	

OPERATING PROCEDURE	PHOTOS/FIGURES
<p>9. Removing bypass valve coil (SV1) and bypass valve</p> <ol style="list-style-type: none"> (1) Remove the service panel. (See Photo 1) (2) Remove the top panel. (See Photo 1) (3) Remove the cover panel (front). (Refer to procedure 8 (5)) (4) Remove the cover panel (rear). (Refer to procedure 8 (6)) (5) Remove the side panel (R). (Refer to procedure 8 (7)) (6) Remove the bypass valve coil fixing screw (M4 × 6). (7) Remove the bypass valve coil by sliding the coil upward. (8) Disconnect the connector SV1 (gray) on the multi controller circuit board in the electrical parts box. (9) Remove the electrical parts box. (See Photo 5) (10) Recover refrigerant. (11) Remove the welded part of bypass valve. <p>Refer to the notes below.</p>	<p>Photo 11</p> 
<p>10. Removing the high pressure switch (63H) and high pressure sensor (63HS)</p> <ol style="list-style-type: none"> (1) Remove the service panel. (See Photo 1) (2) Remove the top panel. (See Photo 1) (3) Remove the cover panel (front). (Refer to procedure 8 (5)) (4) Remove the cover panel (rear). (Refer to procedure 8 (6)) (5) Remove the side panel (R). (Refer to procedure 8 (7)) (6) Pull out the lead wire of high pressure switch and high pressure sensor. (7) Remove the electrical parts box. (See Photo 5) (8) Recover refrigerant. (9) Remove the welded part of high pressure switch and high pressure sensor. <p>Refer to the notes below.</p>	<p>Photo 12</p> 
<p>11. Removing the low pressure sensor (63LS)</p> <ol style="list-style-type: none"> (1) Remove the service panel. (See Photo 1) (2) Remove the top panel. (See Photo 1) (3) Remove the cover panel (front). (Refer to procedure 8 (5)) (4) Remove the cover panel (rear). (Refer to procedure 8 (6)) (5) Remove the side panel (R). (Refer to procedure 8 (7)) (6) Disconnect the connector 63LS (blue) on the multi controller circuit board in the electrical parts box. (7) Remove the electrical parts box. (See Photo 5) (8) Recover refrigerant. (9) Remove the welded part of low pressure sensor. <p>Refer to the notes below.</p>	<p>Notes:</p> <ol style="list-style-type: none"> 1. Recover refrigerant without spreading it in the air. 2. The welded part can be removed easily by removing the side panel (R). 3. When installing the following parts, cover it with a wet cloth to prevent it from heating as the temperature below, then braze the pipes so that the inside of pipes are not oxidized; <ul style="list-style-type: none"> • Bypass valve (procedure 9), 248°F [120°C] or more • High pressure switch and high pressure sensor (procedure 10), 212°F [100°C] or more • Low pressure sensor (procedure 11), 212°F [100°C] or more • LEV (procedure 12), 248°F [120°C] or more
<p>12. Removing linear expansion valve (LEV-A, LEV-B)</p> <ol style="list-style-type: none"> (1) Remove the service panel. (See Photo 1) (2) Remove the top panel. (See Photo 1) (3) Remove the cover panel (front). (Refer to procedure 8 (5)) (4) Remove the cover panel (rear). (Refer to procedure 8 (6)) (5) Remove the side panel (R). (Refer to procedure 8 (7)) (6) Remove the linear expansion valve coil. (See Photo 11,12) (7) Remove the electrical parts box. (See Photo 5) (8) Recover refrigerant. (9) Remove the welded part of linear expansion valve. <p>Refer to the notes on the right.</p>	

OPERATING PROCEDURE

13. Removing the compressor (MC)

- (1) Remove the service panel. (See Photo 1)
- (2) Remove the top panel. (See Photo 1)
- (3) Remove the cover panel (front). (Refer to procedure 8(5))
- (4) Remove the cover panel (rear) (Refer to procedure 8(6))
- (5) Remove the side panel (R). (Refer to procedure 8 (7))
- (6) Remove 2 front cover panel fixing screws (5 × 12) and remove the cover panel (front). (See Photo 4)
- (7) Remove the electrical parts box. (See Photo 5)
- (8) Remove the valve bed. (Refer to procedure 8 (4))
- (9) Remove 3 separator fixing screws (4 × 10) and remove the separator. (See Figure 2)
- (10) Remove the comp felt covering the compressor, and remove the thermistor <Compressor> (TH4), thermal protector (TRS), and the lead wires. (See Photo 7 and 13)
- (11) Recover refrigerant.
- (12) Remove the 3 compressor fixing nuts for motor using spanner or adjustable wrench.
- (13) Remove the welded pipe of compressor inlet and outlet and then remove the compressor.

Note: Recover refrigerant without spreading it in the air.

PHOTOS/FIGURES

Photo 13





Figure 2



14. Removing the accumulator

- (1) Remove the service panel. (See Photo 1)
- (2) Remove the top panel. (See Photo 1)
- (3) Remove the cover panel (front). (Refer to procedure 8 (5))
- (4) Remove the cover panel (rear). (Refer to procedure 8 (6))
- (5) Remove the side panel (R). (Refer to procedure 8 (7))
- (6) Remove the electrical parts box. (See Photo 5)
- (7) Remove the valve bed. (Refer to procedure 8 (4))
- (8) Recover refrigerant.
- (9) Remove 4 welded pipes of accumulator inlet and outlet.
- (10) Remove 2 accumulator leg fixing screws (4 × 10). (See Photo 15)

Note: Recover refrigerant without spreading it in the air.

Photo 14












Photo 15





OPERATING PROCEDURE	PHOTOS/FIGURES
<p>15. Removing the reactor (DCL)</p> <ol style="list-style-type: none">(1) Remove the service panel. (See Photo 1)(2) Remove the top panel. (See Photo 1)(3) Remove the electrical parts box (See photo 5)(4) Remove 6 screws (4 x 10) for reactors to remove the reactors. (See Figure 3)	<p>Figure 3</p>  <p>The diagram shows a top-down view of a rectangular metal housing. On the left side, there are two vertical assemblies labeled 'Reactors'. Arrows point from the label 'Screws for reactors' to six screws that secure these assemblies to the housing. The bottom of the housing shows several vertical slots and internal components.</p>
<p>16. Changing the fusible plug</p> <p>See the following descriptions.</p> <ul style="list-style-type: none">• Be careful not to expose the fusible plug to the braze torch flame or transfer heat to it. (See Photo 16)• The temperature of the fusible plug must not become 140°F (60°C) or more while working. Protect the fusible plug with a wet cloth when necessary. (The fusible plug breaks at 158°F [70°C]).• Tighten the screw in 14 - 18 N·m* (11-13 lbf·ft) with 2 wrenches. <p>*1 N·m ≈ 10 kgf·cm</p>	<p>Photo 16</p>  <p>The photograph shows a close-up of a reactor assembly. A white, cylindrical fusible plug is located on a vertical pipe. An arrow points from the label 'Fusible plug' to this component. The background shows other parts of the machinery, including a large cylindrical tank and various pipes.</p>








OPERATING PROCEDURE	PHOTOS/FIGURES
<p>17. Removing the thermal protector (TRS))</p> <ol style="list-style-type: none">(1) Remove the service panel. (See Photo 1)(2) Remove the cover panel front. (See Photo 1)(3) Pull out the lead wire of high pressure switch and disconnect the connector, 63H (yellow) from the multi controller board in the electrical parts box. (See Photo 11)(4) Remove the comp felt covering the compressor. (See Photo 13)(5) Loosen the clamp or band for the lead wire of the electrical parts box and separator.(6) Pull out the thermal protector (TRS) from the holder. (See Photo 17)	<p>Photo 17</p> <p>Thermal protector (TRS)</p> 
<p>18. Removing the fuse holders</p> <ol style="list-style-type: none">(1) Remove the service panel. (See photo 1)(2) Remove the fuse covers. (See Figure 4)(3) Remove 2 screws (3 x 12) for fuse holders to remove the fuse holders. (See Figure 4 and Photo 18) <p>Notes:</p> <ol style="list-style-type: none">1. Bracket, circuit board and other parts can get deformed when inserting and removing the fuse cover.2. Remove the fuse cover in the way that surrounding parts will not be affected.	<p>Photo 18</p> <p>Fuse holders</p>  <p>Figure 4</p>  <p>Fuse covers</p> <p>screws for fuse folders (3×12)</p>





PUMY-P60NKMU4




→ : Indicates the visible parts in the photos/figures.



Note: Turn OFF the power supply before disassembly.

OPERATING PROCEDURE	PHOTOS/FIGURES
<p>1. Removing the service panel and top panel</p> <ol style="list-style-type: none"> (1) Remove 3 service panel fixing screws (5 × 12) and slide the hook on the right downward to remove the service panel. (2) Remove screws (2 for front, 3 for rear/5 × 12) of the top panel and remove it. 	<p>Photo 1</p> 
<p>2. Removing the fan motor (MF1, MF2)</p> <ol style="list-style-type: none"> (1) Remove the service panel. (See Photo 1) (2) Remove 4 fan grille fixing screws (5 × 12) to detach the fan grille. (See Photo 1) (3) Remove a nut (for right handed screw of M6) to detach the propeller. (See Photo 2) (4) Disconnect the connectors, CNF1 and CNF2 on multi controller board in electrical parts box. (5) Remove 4 fan motor fixing screws (5 × 20) to detach the fan motor. (See Photo 3) <p>Note: Tighten the propeller fan with a torque of 5.7 ± 0.3 N·m [4.2 ± 0.2 ft = lbs]</p>	<div style="display: flex; justify-content: space-around;"> <div data-bbox="766 766 1053 1127"> <p>Photo 2</p>  </div> <div data-bbox="1085 766 1428 1127"> <p>Photo 3</p>  </div> </div>
<p>3. Removing the electrical parts box</p> <ol style="list-style-type: none"> (1) Remove the service panel. (See Photo 1) (2) Remove the top panel. (See Photo 1) (3) Disconnect the connecting wire from terminal block. (See Photo 5) (4) Remove all the following connectors from outdoor multi controller circuit board; <ul style="list-style-type: none"> <Diagram symbol in the connector housing> • Fan motor (CNF1, CNF2) • Thermistor <HIC pipe> (TH2) • Thermistor <Outdoor liquid pipe> (TH3) • Thermistor <Compressor> (TH4) • Thermistor <Suction pipe/Ambient, Outdoor> (TH7/6) • High pressure switch (63H) • High pressure sensor (63HS) • Low pressure sensor (63LS) • 4-way valve (21S4) • Bypass valve (SV1) • Linear expansion valve (CNLVA/CNLVB) Pull out the disconnected wire from the electrical parts box. (5) Remove the terminal cover and disconnect the compressor lead wire. <p>Note: The terminal cover can be easily removed by using a blade of flathead screwdriver.</p> <p>Figure 1</p> 	<p>Photo 4</p> 

From the previous page.

OPERATING PROCEDURE	PHOTOS/FIGURES
<p>(6) Remove 2 electrical parts box fixing screws (4 × 10) then detach the electrical parts box by pulling it upward. The electrical parts box is fixed with 2 hooks on the left and 1 hook on the right.</p>	<p>Photo 5</p> 
<p>4. Removing the thermistor <Suction pipe> (TH6)</p> <ol style="list-style-type: none"> (1) Remove the service panel. (See Photo 1) (2) Remove the top panel. (See Photo 1) (3) Disconnect the connectors, TH7/6 (red), on the multi controller circuit board in the electrical parts box. (4) Loosen the wire clamps on the back of electrical parts box. (5) Pull out the thermistor <Suction pipe> (TH6) from the sensor holder. (See Photo 7) <p>Note: When replacing thermistor <Suction pipe> (TH6), replace it together with thermistor <Ambient> (TH7) since they are combined together. Refer to procedure No.5 below to remove thermistor <Ambient> (TH7).</p>	<p>Photo 6</p> 
<p>5. Removing the thermistor <Ambient> (TH7)</p> <ol style="list-style-type: none"> (1) Remove the service panel. (See Photo 1) (2) Remove the top panel. (See Photo 1) (3) Disconnect the connector TH7/6 (red) on the multi controller circuit board in the electrical parts box. (4) Loosen the wire clamps on top of the electrical parts box. (See Photo 6.) (5) Pull out the thermistor <Ambient> (TH7) from the sensor holder. <p>Note: When replacing thermistor <Ambient> (TH7), replace it together with thermistor <Suction pipe> (TH6), since they are combined together. Refer to procedure No.4 above to remove thermistor <Suction pipe> (TH6).</p>	<p>Photo 7</p> 
	<p>Photo 8</p> 

OPERATING PROCEDURE	PHOTOS/FIGURES
<p>6. Removing the thermistor <Outdoor liquid pipe> (TH3) and thermistor <Compressor> (TH4), thermistor <HIC pipe> (TH2)</p> <ol style="list-style-type: none"> (1) Remove the service panel. (See Photo 1) (2) Disconnect the connectors, TH3 (white) and TH4 (white), TH2 (black) on the multi controller circuit board in the electrical parts box. (3) Pull out the thermistor <Outdoor liquid pipe> (TH3) and thermistor <Compressor> (TH4) from the sensor holder. (See Photo 9-1 and 9-2) 	<p>Photo 9-1</p>  <p>Thermistor <Hic pipe> (TH2)</p> <p>Thermistor <Compressor> (TH4)</p> <p>Ball valve and stop valve fixing screws</p> <p>Photo 9-2</p>  <p>Thermistor <Outdoor liquid pipe> (TH3)</p>
<p>7. Removing the 4-way valve coil (21S4)</p> <ol style="list-style-type: none"> (1) Remove the service panel. (See Photo 1) (2) Remove 4-way valve coil fixing screw (M5 × 7). (3) Remove the 4-way valve coil by sliding the coil to the right. (4) Disconnect the connector 21S4 (green) on the multi controller circuit board in the electrical parts box. 	<p>Photo 10</p>  <p>4-way valve coil (21S4)</p> <p>4-way valve</p> <p>4-way valve coil fixing screw</p>
<p>8. Removing the 4-way valve</p> <ol style="list-style-type: none"> (1) Remove the service panel. (See Photo 1) (2) Remove the top panel. (See Photo 1) (3) Remove the electrical parts box (See Photo 5) (4) Remove 3 valve bed fixing screws (4 × 10) and 4 ball valve and stop valve fixing screws (5 × 16), then remove the valve bed. (See Photo 4 and 7) (5) Remove 2 cover panel fixing screws (5 × 12), then slide the cover panel (front) upward to remove it. (The cover panel (front) is fixed to the cover panel (rear) with a hook on the rear side. (See Photo 4) (6) Remove the cover panel (rear) fixing screws (2 for right side and 2 for rear/ 5 × 12), then slide the cover panel (rear) upward to remove it. (The cover panel (rear) is fixed to the side panel (R) with 2 screws.) (7) Remove 3 side panel (R) fixing screws (5 × 12) in the rear of the unit, then slide the side panel (R) upward to remove it. (The side panel (R) is fixed to the side plate with hooks on the rear side.) (8) Remove the 4-way valve coil. (See Photo 10) (9) Recover refrigerant. (10) Remove the welded part of 4-way valve. <p>Notes:</p> <ol style="list-style-type: none"> 1. Recover refrigerant without spreading it in the air. 2. The welded part can be removed easily by removing the side panel (R). 3. When installing the 4-way valve, cover it with a wet cloth to prevent it from heating (248°F [120°C] or more), then braze the pipes so that the inside of pipes are not oxidized. 	

OPERATING PROCEDURE	PHOTOS/FIGURES
<p>9. Removing bypass valve coil (SV1) and bypass valve</p> <ol style="list-style-type: none"> (1) Remove the service panel. (See Photo 1) (2) Remove the top panel. (See Photo 1) (3) Remove the cover panel (front). (Refer to procedure 8(5)) (4) Remove the cover panel (rear) (Refer to procedure 8(6)) (5) Remove the side panel (R). (Refer to procedure 8 (7)) (6) Remove the bypass valve coil fixing screw (M4 × 6). (7) Remove the bypass valve coil by sliding the coil upward. (8) Disconnect the connector SV1 (gray) on the multi controller circuit board in the electrical parts box. (9) Remove the electrical parts box. (See Photo 5) (10) Recover refrigerant. (11) Remove the welded part of bypass valve. <p>Refer to the notes below.</p>	<p>Photo 11</p> 
<p>10. Removing the high pressure switch (63H) and high pressure sensor (63HS)</p> <ol style="list-style-type: none"> (1) Remove the service panel. (See Photo 1) (2) Remove the top panel. (See Photo 1) (3) Remove the cover panel (front). (Refer to procedure 8(5)) (4) Remove the cover panel (rear) (Refer to procedure 8(6)) (5) Remove the side panel (R). (Refer to procedure 8 (7)) (6) Pull out the lead wire of high pressure switch and high pressure sensor. (7) Remove the electrical parts box. (See Photo 5) (8) Recover refrigerant. (9) Remove the welded part of high pressure switch and high pressure sensor. <p>Refer to the notes below.</p>	<p>Photo 12</p> 
<p>12. Removing linear expansion valve (LEV-A, LEV-B)</p> <ol style="list-style-type: none"> (1) Remove the service panel. (See Photo 1) (2) Remove the top panel. (See Photo 1) (3) Remove the cover panel (front). (Refer to procedure 8(5)) (4) Remove the cover panel (rear) (Refer to procedure 8(6)) (5) Remove the side panel (R). (Refer to procedure 8 (7)) (6) Remove the linear expansion valve coil. (See Photo 12) (7) Remove the electrical parts box. (See Photo 5) (8) Recover refrigerant. (9) Remove the welded part of linear expansion valve. 	<p>Notes:</p> <ol style="list-style-type: none"> 1. Recover refrigerant without spreading it in the air. 2. The welded part can be removed easily by removing the right side panel. 3. When installing the following parts, cover it with a wet cloth to prevent it from heating as the temperature below, then braze the pipes so that the inside of pipes are not oxidized; <ul style="list-style-type: none"> • Bypass valve (procedure 9), 248°F [120°C] or more • High pressure switch and high pressure sensor (procedure 10), 212°F [100°C] or more • Low pressure sensor (procedure 11), 100°C or more • LEV (procedure 12), 248°F [120°C] or more

OPERATING PROCEDURE

13. Removing the compressor (MC)

- (1) Remove the service panel. (See Photo 1)
- (2) Remove the top panel. (See Photo 1)
- (3) Remove the cover panel (front). (Refer to procedure 8(5))
- (4) Remove the cover panel (rear) (Refer to procedure 8(6))
- (5) Remove the side panel (R). (Refer to procedure 8 (7))
- (6) Remove 2 front cover panel fixing screws (5 × 12) and remove the front cover panel. (See Photo 4)
- (7) Remove the electrical parts box. (See Photo 5)
- (8) Remove the valve bed. (Refer to procedure 8 (4))
- (9) Remove 3 separator fixing screws (4 × 10) and remove the separator. (See Figure 2)
- (10) Remove the comp felt covering the compressor, and remove the thermistor <Compressor> (TH4), thermal protector (TRS), and the lead wires. (See Photo 7 and 14)
- (11) Recover refrigerant.
- (12) Remove the 3 compressor fixing nuts for motor using spanner or adjustable wrench.
- (13) Remove the welded pipe of compressor inlet and outlet and then remove the compressor.

Note: Recover refrigerant without spreading it in the air.

PHOTOS/FIGURES

Photo 13




Figure 2





Photo 14



OPERATING PROCEDURE

14. Removing the accumulator

- (1) Remove the service panel. (See Photo 1)
- (2) Remove the top panel. (See Photo 1)
- (3) Remove the electrical parts box. (See Photo 5)
- (4) Remove the valve bed. (See procedure 8 (4))
- (5) Remove the cover panel (front). (Refer to procedure 8(5))
- (6) Remove the cover panel (rear) (Refer to procedure 8(6))
- (7) Remove the side panel (R). (Refer to procedure 8 (7))
- (8) Recover refrigerant.
- (9) Remove 2 welded pipes of accumulator inlet and outlet.
- (10) Remove 2 accumulator leg fixing screws (4 × 10). (See Photo 16)

Note: Recover refrigerant without spreading it in the air.

PHOTOS/FIGURES

Photo 15






Photo 16









15. Removing the reactor (DCL)

- (1) Remove the service panel. (See Photo 1)
- (2) Remove the top panel. (See Photo 1)
- (3) Remove the electrical parts box (See photo 5)
- (4) Remove 6 screws (4 × 10) for reactors to remove the reactors. (See Figure 3)






Figure 3









OPERATING PROCEDURE	PHOTOS/FIGURES
<p>16. Changing the fusible plug</p> <p>See the following descriptions.</p> <ul style="list-style-type: none">• Be careful not to expose the fusible plug to the braze torch flame or transfer heat to it. (See Photo 17)• The temperature of the fusible plug must not become 140°F (60°C) or more while working. Protect the fusible plug with a wet cloth when necessary. (The fusible plug breaks at 158°F [70°C]).• Tighten the screw in 14 - 18 N·m* (11-13 lbf·ft) with 2 wrenches. <p>*1 N·m ≈ 10 kgf·cm</p>	<p>Photo 17</p>  <p>Fusible plug</p>
<p>17. Removing the thermal protector (TRS)</p> <ol style="list-style-type: none">(1) Remove the service panel. (See Photo 1)(2) Remove the cover panel front. (See Photo 1)(3) Pull out the lead wire of high pressure switch and disconnect the connector, 63H (yellow) from the multi controller board in the electrical parts box. (See Photo 11)(4) Remove the comp felt covering the compressor. (See Photo 14)(5) Loosen the clamp or band for the lead wire of the electrical parts box and separator.(6) Pull out the thermal protector (TRS) from the holder. (See Photo 18)	<p>Photo 18</p>  <p>Thermal protector (TRS)</p>
<p>18. Removing the fuse holders</p> <ol style="list-style-type: none">(1) Remove the service panel. (See Photo 1)(2) Remove 2 screws (4 x 10) for cont base to remove the cont base. (See Figure 4)(3) Remove the fuse covers. (See Figure 5)(4) Remove screws (3 x 12) for fuse holders to remove the fuse holders. (See Figure 4 and Photo 19) <p>Notes:</p> <ol style="list-style-type: none">1. Bracket, circuit board and other parts can get deformed when inserting and removing the fuse cover.2. Remove the fuse cover in the way that surrounding parts will not be affected.	<p>Photo 19</p>  <p>Fuse holders</p> <p>Figure 4</p>  <p>cont base</p> <p>screws for cont base (4×10)</p> <p>Figure 5</p>  <p>fuse covers</p> <p>screws for fuse holders (3×12)</p>



→ : Indicates the visible parts in the photos/figures.



OPERATING PROCEDURE	PHOTOS/FIGURES
<p>1. Removing the service panel and top panel</p> <ol style="list-style-type: none"> (1) Remove 3 service panel fixing screws (5 × 12), then slide the hook on the right downward to remove the service panel. (2) Remove screws (2 for front, 3 for rear/5 × 12) of the top panel and remove it. 	<p>Photo 1</p> 
<p>2. Removing the fan motor (MF1, MF2)</p> <ol style="list-style-type: none"> (1) Remove the service panel. (See Photo 1) (2) Remove the top panel. (See Photo 1) (3) Remove 4 fan grille fixing screws (5 × 12) to detach the fan grille. (See Photo 1) (4) Remove a nut (for right handed screw of M6) to detach the propeller. (See Photo 2) (5) Disconnect the connectors, CNF1 and CNF2 on the multi controller circuit board in the electrical parts box. (6) Remove 4 fan motor fixing screws (5 × 20) to detach the fan motor. (See Photo 3) <p>Note: Tighten the propeller fan with a torque of $5.7 \pm 0.3 \text{ N}\cdot\text{m}$. [$4.2 \pm 0.2 \text{ ft} \cdot \text{lbs}$]</p>	<p>Photo 2</p>  <p>Photo 3</p> 
<p>3. Removing the electrical parts box</p> <ol style="list-style-type: none"> (1) Remove the service panel. (See Photo 1) (2) Remove the top panel. (See Photo 1) (3) Disconnect the connecting wire from terminal block. (4) Remove all of the following connectors from multi controller circuit board; <p><Diagram symbol in the connector housing></p> <ul style="list-style-type: none"> • Fan motor (CNF1, CNF2) • Thermistor <HIC pipe> (TH2) • Thermistor <Outdoor liquid pipe> (TH3) • Thermistor <Compressor> (TH4) • Thermistor <Suction pipe/Ambient, Outdoor> (TH7/6) • High pressure switch (63H) • High pressure sensor (63HS) • Low pressure sensor (63LS) • 4-way valve (21S4) • Bypass valve (SV1, SV2) • Linear expansion valve (LEV-A, LEV-B) • Base heater (SS) <p>Pull out the disconnected wire from the electrical parts box.</p> <ol style="list-style-type: none"> (5) Remove the terminal cover and disconnect the compressor lead wire from the comp. terminal. (See Figure 1) <p>Note: The terminal cover can be easily removed by using a blade of flathead screwdriver.</p> <p>Figure 1</p> 	<p>Photo 4</p> 

Continue to the next page.

From the previous page.

OPERATING PROCEDURE	PHOTOS/FIGURES
<p>(6) Remove 2 electrical parts box fixing screws (4 × 10), then detach the electrical parts box by pulling it upward. The electrical parts box is fixed with 2 hooks on the left and 1 hook on the right.</p>	<p>Photo 5</p>  <p>Electrical parts box Hook Electrical parts box fixing screws Hooks</p>
<p>4. Removing the thermistor <Suction pipe> (TH6)</p> <ol style="list-style-type: none"> (1) Remove the service panel. (See Photo 1) (2) Remove the top panel. (See Photo 1) (3) Disconnect the connector, TH7/6 (red), on the multi controller circuit board in the electrical parts box. (4) Loosen the wire clamps on the top of the electrical parts box. (See Photo 6) (5) Pull out the thermistor <Suction pipe> (TH6) from the sensor holder. (See Photo 7) <p>Note: When replacing thermistor <Suction pipe> (TH6), replace it together with thermistor <Ambient> (TH7) since they are combined together. Refer to procedure No.5 below to remove thermistor <Ambient> (TH7).</p>	<p>Photo 6</p>  <p>Electrical parts box Clamps</p> <p>Photo 7</p>  <p>High pressure switch (63H) Thermistor <Suction pipe> (TH6) Thermistor <Hic pipe> (TH2) Ball valve and stop valve fixing screws Thermistor <Compressor> (TH4)</p>
<p>5. Removing the thermistor <Ambient> (TH7)</p> <ol style="list-style-type: none"> (1) Remove the service panel. (See Photo 1) (2) Remove the top panel. (See Photo 1) (3) Disconnect the connector TH7/6 (red) on the multi controller circuit board in the electrical parts box. (4) Loosen the wire clamps on top of the electrical parts box. (See Photo 6) (5) Pull out the thermistor <Ambient> (TH7) from the sensor holder. <p>Note: When replacing thermistor <Ambient> (TH7), replace it together with thermistor <Suction pipe> (TH6), since they are combined together. Refer to procedure No.4 above to remove thermistor <Suction pipe> (TH6).</p>	<p>Photo 8</p>  <p>Lead wire of thermistor <Ambient> (TH7) Sensor holder</p>

OPERATING PROCEDURE	PHOTOS/FIGURES
<p>6. Removing the thermistor <Outdoor liquid pipe> (TH3) and thermistor <Compressor> (TH4), thermistor <HIC pipe> (TH2)</p> <ol style="list-style-type: none"> (1) Remove the service panel. (See Photo 1) (2) Disconnect the connectors, TH3 (white) and TH4 (white), TH2 (black) on the multi controller circuit board in the electrical parts box. (3) Pull out the thermistor <Outdoor liquid pipe> (TH3) and thermistor <Compressor> (TH4) from the sensor holder. (See Photo 7 and 9) 	<p>Photo 9</p>  <p>Thermistor <Outdoor liquid pipe> (TH3)</p>
<p>7. Removing the 4-way valve coil (21S4)</p> <ol style="list-style-type: none"> (1) Remove the service panel. (See Photo 1) (2) Remove 4-way valve coil fixing screw (M5 × 7). (3) Remove the 4-way valve coil by sliding the coil to the right. (4) Disconnect the connector 21S4 (green) on the multi controller circuit board in the electrical parts box. 	<p>Photo 10</p>  <p>4-way valve coil (21S4) 4-way valve</p> <p>4-way valve coil fixing screw</p>
<p>8. Removing the 4-way valve</p> <ol style="list-style-type: none"> (1) Remove the service panel. (See Photo 1) (2) Remove the top panel. (See Photo 1) (3) Remove the electrical parts box (See Photo 5) (4) Remove 3 valve bed fixing screws (4 × 10) and 4 ball valve and stop valve fixing screws (5 × 16), then remove the valve bed. (See Photo 4 and 7) (5) Remove 2 cover panel fixing screws (5 × 12), then slide the cover panel (front) upward to remove it. (The cover panel (front) is fixed to the cover panel (rear) with a hook on the rear side. (See Photo 4) (6) Remove the cover panel (rear) fixing screws (2 for right side and 2 for rear/ 5 × 12), then slide the cover panel (rear) upward to remove it. (The cover panel (rear) is fixed to the side panel (R) with 2 screws.) (7) Remove 3 side panel (R) fixing screws (5 × 12) in the rear of the unit, then slide the side panel (R) upward to remove it. (The side panel (R) is fixed to the side plate with hooks on the rear side.) (8) Remove the 4-way valve coil. (See Photo 10) (9) Recover refrigerant. (10) Remove the welded part of 4-way valve. <p>Notes:</p> <ol style="list-style-type: none"> 1. Recover refrigerant without spreading it in the air. 2. The welded part can be removed easily by removing the side panel (R). 3. When installing the 4-way valve, cover it with a wet cloth to prevent it from heating (248°F [120°C] or more), then braze the pipes so that the inside of pipes are not oxidized. 	

OPERATING PROCEDURE	PHOTOS/FIGURES
<p>9. Removing bypass valve coil (SV1, SV2) and bypass valve</p> <ol style="list-style-type: none"> (1) Remove the service panel. (See Photo 1) (2) Remove the top panel. (See Photo 1) (3) Remove the cover panel (front). (Refer to procedure 8(5)) (4) Remove the cover panel (rear) (Refer to procedure 8(6)) (5) Remove the side panel (R). (Refer to procedure 8 (7)) (6) Remove the bypass valve coil fixing screw (M4 × 6). (7) Remove the bypass valve coil by sliding the coil upward. (8) Disconnect the connector SV1 (gray) or SV2 (blue) on the multi controller circuit board in the electrical parts box. (9) Remove the electrical parts box. (See Photo 5) (10) Recover refrigerant. (11) Remove the welded part of bypass valve. <p>Refer to the notes below.</p>	<p>Photo 11</p> 
<p>10. Removing the high pressure switch (63H) and high pressure sensor (63HS)</p> <ol style="list-style-type: none"> (1) Remove the service panel. (See Photo 1) (2) Remove the top panel. (See Photo 1) (3) Remove the cover panel (front). (Refer to procedure 8(5)) (4) Remove the cover panel (rear) (Refer to procedure 8(6)) (5) Remove the side panel (R). (Refer to procedure 8 (7)) (6) Pull out the lead wire of high pressure switch and high pressure sensor. (7) Remove the electrical parts box. (See Photo 5) (8) Recover refrigerant. (9) Remove the welded part of high pressure switch and high pressure sensor. <p>Refer to the notes below.</p>	<p>Photo 12</p> 
<p>11. Removing the low pressure sensor (63LS)</p> <ol style="list-style-type: none"> (1) Remove the service panel. (See Photo 1) (2) Remove the top panel. (See Photo 1) (3) Remove the cover panel (front). (Refer to procedure 8(5)) (4) Remove the cover panel (rear) (Refer to procedure 8(6)) (5) Remove the side panel (R). (Refer to procedure 8 (7)) (6) Disconnect the connector 63LS (blue) on the multi controller circuit board in the electrical parts box. (7) Remove the electrical parts box. (See Photo 5) (8) Recover refrigerant. (9) Remove the welded part of low pressure sensor. <p>Refer to the notes below.</p>	<p>Notes:</p> <ol style="list-style-type: none"> 1. Recover refrigerant without spreading it in the air. 2. The welded part can be removed easily by removing the side panel (R). 3. When installing the following parts, cover it with a wet cloth to prevent it from heating as the temperature below, then braise the pipes so that the inside of pipes are not oxidized; <ul style="list-style-type: none"> • Bypass valve (procedure 9), 248°F [120°C] or more • High pressure switch and high pressure sensor (procedure 10), 212°F [100°C] or more • Low pressure sensor (procedure 11), 212°F [100°C] or more • LEV (procedure 12), 248°F [120°C] or more
<p>12. Removing linear expansion valve (LEV-A, LEV-B)</p> <ol style="list-style-type: none"> (1) Remove the service panel. (See Photo 1) (2) Remove the top panel. (See Photo 1) (3) Remove the cover panel (front). (Refer to procedure 8(5)) (4) Remove the cover panel (rear) (Refer to procedure 8(6)) (5) Remove the side panel (R). (Refer to procedure 8 (7)) (6) Remove the linear expansion valve coil. (See Photo 11,12) (7) Remove the electrical parts box. (See Photo 5) (8) Recover refrigerant. (9) Remove the welded part of linear expansion valve. <p>Refer to the notes on the right.</p>	

OPERATING PROCEDURE

13. Removing the compressor (MC)

- (1) Remove the service panel. (See Photo 1)
- (2) Remove the top panel. (See Photo 1)
- (3) Remove the cover panel (front). (Refer to procedure 8(5))
- (4) Remove the cover panel (rear). (Refer to procedure 8(6))
- (5) Remove the side panel (R). (Refer to procedure 8 (7))
- (6) Remove 2 front cover panel fixing screws (5 × 12) and remove the cover panel (front). (See Photo 4)
- (7) Remove the electrical parts box. (See Photo 5)
- (8) Remove the valve bed. (Refer to procedure 8 (4))
- (9) Remove 3 separator fixing screws (4 × 10) and remove the separator. (See Figure 2)
- (10) Remove the comp felt covering the compressor, and remove the thermistor <Compressor> (TH4), thermal protector (TRS), and the lead wires. (See Photo 7 and 13)
- (11) Recover refrigerant.
- (12) Remove the 3 compressor fixing nuts for motor using spanner or adjustable wrench.
- (13) Remove the welded pipe of compressor inlet and outlet and then remove the compressor.

Note: Recover refrigerant without spreading it in the air.

PHOTOS/FIGURES

Photo 13





Figure 2



14. Removing the accumulator

- (1) Remove the service panel. (See Photo 1)
- (2) Remove the top panel. (See Photo 1)
- (3) Remove the cover panel (front). (Refer to procedure 13 (3))
- (4) Remove the cover panel (rear). (Refer to procedure 13 (5))
- (5) Remove the side panel (R). (Refer to procedure 8 (7))
- (6) Remove the electrical parts box. (See Photo 5)
- (7) Remove the valve bed. (See procedure 8 (4))
- (8) Recover refrigerant.
- (9) Remove 4 welded pipes of accumulator inlet and outlet.
- (10) Remove 2 accumulator leg fixing screws (4 × 10). (See Photo 15)

Note: Recover refrigerant without spreading it in the air.

Photo 14













Photo 15




OPERATING PROCEDURE	PHOTOS/FIGURES
<p>15. Removing the reactor (DCL)</p> <ol style="list-style-type: none"> (1) Remove the service panel. (See Photo 1) (2) Remove the top panel. (See Photo 1) (3) Remove the electrical parts box (See Photo 5) (4) Remove 6 screws (4 x 10) for reactor to remove the reactors. (See Figure 3) 	<p>Figure 3</p> 
<p>16. Removing the base heater</p> <ol style="list-style-type: none"> (1) Remove the service panel. (See Photo 1) (2) Remove the top panel. (See Photo 1) (3) Remove 4 fan grille fixing screws (5 x 12) to detach the fan grille. (See Photo 1) (4) Remove a nut (for right handed screw of M6) to detach the propeller. (See Photo 2) (5) Remove all of the following connectors from multi controler circuit board; <Diagram symbol in the connector housing> <ul style="list-style-type: none"> • Fan motor (CNF1, CNF2) • Base heater (SS) Pull out the disconnected wire from the electrical parts box. (See Photo 4) (6) Loosen the wire clamps on the side of the motor support and separator. (7) Remove 2 motor support fixing screws (5 x 12), then remove the motor support with fan motor still attached. (See Photo 16) (8) Remove 4 base heater cover fixing screws (4 x 10), then remove the base heater cover. (9) Remove the base heater. (See Photo 17) 	<p>Photo 16</p> 
<p>Notes:</p> <ol style="list-style-type: none"> 1. Tighten the propeller fan with a torque of 5.7 ± 0.3 N·m [4.2 ± 0.2 ft = lbs] 2. Rotate the propeller fan and make sure that the base heater and the lead wires do not interfere with the movement of the propeller fan. 	<p>Photo 17</p> 

OPERATION PROCEDURE	PHOTOS/FIGURES
<p>17. Changing the fusible plug</p> <p>See the following descriptions.</p> <ul style="list-style-type: none"> • Be careful not to expose the fusible plug to the braze torch flame or transfer heat to it. (See Photo 18) • The temperature of the fusible plug must not become 140°F (60°C) or more while working. Protect the fusible plug with a wet cloth when necessary. • (The fusible plug breaks at 158°F [70°C]). • Tighten the screw in 14 - 18 N·m* (11-13 lbf·ft) with 2 wrenches. <p>*1 N·m ≈ 10 kgf·cm</p>	<p>Photo 18</p>  <p>Fusible plug</p>
<p>18. Removing the thermal protector (TRS))</p> <ol style="list-style-type: none"> (1) Remove the service panel. (See Photo 1) (2) Remove the cover panel front. (See Photo 1) (3) Pull out the lead wire of high pressure switch and disconnect the connector, 63H (yellow) from the multi controller board in the electrical parts box. (See Photo 11) (4) Remove the comp felt covering the compressor. (See Photo 13) (5) Loosen the clamp or band for the lead wire of the electrical parts box and separator. (6) Pull out the thermal protector (TRS) from the holder. (See Photo 19) 	<p>Photo 19</p>  <p>Thermal protector (TRS)</p>
<p>19. Removing the fuse holders</p> <ol style="list-style-type: none"> (1) Remove the service panel. (See Photo 1) (2) Remove 2 screws (4 x 10) for cont base to remove the cont base. (See Figure 4) (3) Remove the fuse covers. (See Figure 5) (4) Remove screws (3 x 12) for fuse holders to remove the fuse holders. (See Figure 5 and Photo 20) <p>Notes:</p> <ol style="list-style-type: none"> 1. Bracket, circuit board and other parts can get deformed when inserting and removing the fuse cover. 2. Remove the fuse cover in the way that surrounding parts will not be affected. 	<p>Photo 20</p>  <p>Fuse holders</p> <p>Figure 4</p>  <p>cont base</p> <p>screws for cont base (4x10)</p> <p>Figure 5</p>  <p>fuse covers</p> <p>screws for fuse holders (3x12)</p> <p>screws for cont base (4x10)</p>

12-1. REMOTE CONTROLLER FUNCTIONS

<PAR-41MAA>

Controller interface




The functions of the function buttons change depending on the screen.


Refer to the button function guide that appears at the bottom of the LCD for the functions they serve on a given screen.

When the system is centrally controlled, the button function guide that corresponds to the locked button will not appear.


Main display



Main menu



Menu screen



Function guide

① [ON/OFF] button

Press to turn ON/OFF the indoor unit.

② [SELECT/HOLD] button

Press to save the setting.

When the Main menu is displayed, pressing this button will enable/disable the HOLD function.

③ [RETURN] button

Press to return to the previous screen.

④ [MENU] button

Press to bring up the Main menu.

⑤ Backlit LCD

Operation settings will appear.

When the backlight is off, pressing any button turns the backlight on and it will stay lit for a certain period of time depending on the screen.

When the backlight is off, pressing any button turns the backlight on and does not perform its function. (except for the [ON/OFF] button)

⑥ ON/OFF lamp

This lamp lights up in green while the unit is in operation. It blinks while the remote controller is starting up or when there is an error.

⑦ Function button [F1]

Main display: Press to change the operation mode.

Menu screen: The button function varies with the screen.

⑧ Function button [F2]

Main display: Press to decrease temperature.

Main menu: Press to move the cursor left.

Menu screen: The button function varies with the screen.

⑨ Function button [F3]

Main display: Press to increase temperature.

Main menu: Press to move the cursor right.

Menu screen: The button function varies with the screen.

⑩ Function button [F4]

Main display: Press to change the fan speed.


Menu screen: The button function varies with the screen.

Display


The main display can be displayed in two different modes: "Full" and "Basic". The initial setting is "Full". To switch to the "Basic" mode, change the setting on the Main display setting. (Refer to operation manual included with remote controller.)

<Full mode>

All icons are displayed for explanation.



<Basic mode>



① Operation mode

② Preset temperature

③ Clock

④ Fan speed

⑤ Button function guide

Functions of the corresponding buttons appear here.



Appears when the ON/OFF operation is centrally controlled.



Appears when the operation mode is centrally controlled.



Appears when the preset temperature is centrally controlled.



Appears when the filter reset function is centrally controlled.



Indicates when filter needs maintenance.

⑪ Room temperature



Appears when the buttons are locked.



Appears when the On/Off timer or Auto-off timer function is enabled.

⌚ appears when the timer is disabled by the centralized control system.

⌚ appears when the HOLD function is enable.



Appears when the Weekly timer is enabled.



Appears while the units are operated in the energy saving mode. (Will not appear on some models of indoor units)



Appears while the outdoor units are operated in the silent mode.



Appears when the built-in thermistor on the remote controller is activated to monitor the room temperature (⑪).

⌚ appears when the thermistor on the indoor unit is activated to monitor the room temperature.



Indicates the vane setting.



Indicates the louver setting.



Indicates the ventilation setting.



Appears when the preset temperature range is restricted.



Appears when an energy saving operation is performed using a "3D i-see Sensor" function.

②③ Centrally controlled

Appears for a certain period of time when a centrally-controlled item is operated.


②④ Preliminary error display

A check code appears during the preliminary error.

Most settings (except ON/OFF, mode, fan speed, temperature) can be made from the Main menu.


*1 These functions are not applied to the floor standing models.

Menu structure



Not all functions are available on all models of indoor units.

Continue from the previous page.



Not all functions are available on all models of indoor units.




Main menu list

Main menu	Setting and display items		Setting details
Operation	Vane · Louver · Vent. (Lossnay)		Use to set the vane angle. <ul style="list-style-type: none"> Select a desired vane setting. Use to turn ON/OFF the louver. <ul style="list-style-type: none"> Select a desired setting from "ON" and "OFF." Use to set the amount of ventilation. <ul style="list-style-type: none"> Select a desired setting from "Off," "Low," and "High."
	High power ^{*3}		Use to reach the comfortable room temperature quickly. <ul style="list-style-type: none"> Units can be operated in the High-power mode for up to 30 minutes.
	Comfort	Manual vane angle	Use to fix each vane angle.
		3D i-see Sensor	Use to set the following functions for 3D i-see Sensor. <ul style="list-style-type: none"> Air distribution Energy saving option Seasonal airflow
Timer	Timer	ON/OFF timer ^{*1}	Use to set the operation ON/OFF times. <ul style="list-style-type: none"> Time can be set in 5-minute increments.
		Auto-Off timer	Use to set the Auto-Off time. <ul style="list-style-type: none"> Time can be set to a value from 30 to 240 in 10-minute increments.
	Weekly timer ^{*1, *2}		Use to set the weekly operation ON/OFF times. <ul style="list-style-type: none"> Up to 8 operation patterns can be set for each day. (Not valid when the ON/OFF timer is enabled.)
	OU silent mode ^{*1, *3}		Use to set the time periods in which priority is given to quiet operation of outdoor units over temperature control. Set the Start/Stop times for each day of the week. <ul style="list-style-type: none"> Select the desired silent level from "Normal," "Middle," and "Quiet."
Energy saving	Restriction	Temp. range ^{*2}	Use to restrict the preset temperature range. <ul style="list-style-type: none"> Different temperature ranges can be set for different operation modes.
		Operation locked	Use to lock selected functions. <ul style="list-style-type: none"> The locked functions cannot be operated.
	Energy saving	Auto return ^{*2}	Use to get the units to operate at the preset temperature after performing energy saving operation for a specified time period. <ul style="list-style-type: none"> Time can be set to a value from 30 and 120 in 10-minute increments. (This function will not be valid when the preset temperature ranges are restricted.)
		Schedule ^{*1, *3}	Set the start/stop times to operate the units in the energy saving mode for each day of the week, and set the energy saving rate. <ul style="list-style-type: none"> Up to 4 energy saving operation patterns can be set for each day. Time can be set in 5-minute increments. Energy saving rate can be set to a value from 0% or 50 to 90% in 10% increments.
Initial setting	Basic setting	Main/Sub	When connecting 2 remote controllers, one of them needs to be designated as a sub controller.
		Clock	Use to set the current time.
		Daylight saving time	Set the daylight saving time.
		Administrator password	The administrator password is required to make the settings for the following items. <ul style="list-style-type: none"> Timer setting Energy saving setting Weekly timer setting Restriction setting Outdoor unit silent mode setting

^{*1} Clock setting is required.

^{*2} 2°F (1°C) increments.


^{*3} This function is available only when certain outdoor units are connected.



Main menu	Setting and display items		Setting details
Initial setting	Display setting	Main display	Use to switch between "Full" and "Basic" modes for the Main display, and use to change the background colors of the display to black.
		Display details	Make the settings for the remote controller related items as necessary. Clock: The initial settings are "Yes" and "24h" format. Temperature: Set either Celsius (°C) or Fahrenheit (°F). Room temp.: Set Show or Hide. Auto mode: Set Auto mode display or Only Auto display.
		Contrast • Brightness	Use to adjust screen contrast and brightness.
		Language selection	Use to select the desired language.
	Operation setting	Auto mode	Whether or not to use Auto mode can be selected by using the button. This setting is valid only when indoor units with Auto mode function are connected.
		Setback mode	Whether or not to use the Setback mode can be selected by using the button. This setting is valid only when indoor units with the Setback mode function are connected.
Maintenance	Error information		Use to check error information when an error occurs. • Check code, error source, refrigerant address, model name, manufacturing number, contact information (dealer's phone number) can be displayed. (The model name, manufacturing number, and contact information need to be registered in advance to be displayed.)
	Filter information		Use to check the filter status. • The filter sign can be reset.
	Cleaning	Auto descending panel	Use to lift and lower the auto descending panel (Optional parts).
Service	Test run		Select "Test run" from the Service menu to bring up the Test run menu. • Test run • Drain pump test run
	Input maintenance		Select "Input maintenance Info." from the Service menu to bring up the Maintenance information screen. The following settings can be made from the Maintenance Information screen. • Model name input • Serial No. input • Dealer information input • Initialize maintenance info.
	Settings	Function setting	Make the settings for the indoor unit functions via the remote controller as necessary.
	Check	Error history	Display the error history and execute "delete error history".
		Diagnosis	Self check: Error history of each unit can be checked via the remote controller. Remote controller check: When the remote controller does not work properly, use the remote controller checking function to troubleshoot the problem.
		Smooth maintenance *1	Use to display the maintenance data of indoor/outdoor units.
		Request code *1	Use to check operation data such as thermistor temperature and error information.
	Others	Maintenance password	Use to change the maintenance password.
		Initialize remote controller	Use to initialize the remote controller to the factory shipment status.
		Remote controller information	Use to display the remote controller model name, software version, and serial number.

*1 This function is available only when certain outdoor units are connected.


<PAR-FL32MA>



- When using the wireless remote controller, point it towards the receiver on the indoor unit.
- If the remote controller is operated within approximately two minutes after power is supplied to the indoor unit, the indoor unit may beep twice as the unit is performing the initial automatic check.
- The indoor unit beeps to confirm that the signal transmitted from the remote controller has been received. Signals can be received up to approximately 7 meters in a direct line from the indoor unit in an area 45° to the left and right of the unit. However, illumination such as fluorescent lights and strong light can affect the ability of the indoor unit to receive signals.
- If the operation lamp near the receiver on the indoor unit is blinking, the unit needs to be inspected. Consult your dealer for service.
- Handle the remote controller carefully. Do not drop the remote controller or subject it to strong shocks. In addition, do not get the remote controller wet or leave it in a location with high humidity.
- To avoid misplacing the remote controller, install the holder included with the remote controller on a wall and be sure to always place the remote controller in the holder after use.

<PAR-SL101A-E>


Controller interface



Note:

* This button is enabled or disabled depending on the model of the indoor unit.

Display



12-2. ERROR INFORMATION

When an error occurs, the following screen will appear.
Check the error status, stop the operation, and consult your dealer.

1. Check code, error unit, refrigerant address, model name, and serial number will appear.
The model name and serial number will appear only if the information has been registered.

Press the [F1] or [F2] button to go to the next page.

Contact information (dealer's phone number) will appear if the information has been registered.

Error information 1/2

Error code	A3
Error unit	IU 8 Unit#1
Time Occurred	02/01 4:48
Model name	
Serial No.	

Reset error: Reset button

▼ Page ▲ Reset

F1 F2 F3 F4 blinks

MENU RETURN SELECT HOLD

ON OFF

Error information 2/2

Contact information

Dealer

Tel

Reset error: Reset button

▼ Page ▲ Reset

2. Press the [F4] button or the [ON/OFF] button to reset the error that is occurring.

Errors cannot be reset while the ON/OFF operation is prohibited.

Error information 1/2

Error code	A3
Error unit	IU 8 Unit#1
Time Occurred	02/01 4:48
Model name	
Serial No.	

Reset error: Reset button

▼ Page ▲ Reset

F1 F2 F3 F4 blinks

MENU RETURN SELECT HOLD

ON OFF

Error reset

Reset current error?

Cancel OK

F1 F2 F3 F4

Error reset

Error reset


Main menu: MENU


Select "OK" with the [F4] button.

Navigating through the screens
• To go back to the Service menu [MENU] button

· Checking the error information

While no errors are occurring, page 2/2 of the error information can be viewed by selecting "Error information" from the Maintenance menu. Errors cannot be reset from this screen.






12-3. SERVICE MENU

Maintenance password is required

1. Select "Service" from the Main menu, and press the [SELECT] button.

*At the main display, the menu button and select "Service" to make the maintenance setting.



2. When the Service menu is selected, a window will appear asking for the password.


To enter the current maintenance password (4 numerical digits), move the cursor to the digit you want to change with the [F1] or [F2] button.



Set each number (0 through 9) with the [F3] or [F4] button.



Then, press the [SELECT] button.



Note: The initial maintenance password is "9999". Change the default password as necessary to prevent unauthorized access. Have the password available for those who need it.

If you forget your maintenance password, you can initialize the password to the default password "9999" by pressing and holding the [F1] button for 10 seconds on the maintenance password setting screen.

3. If the password matches, the Service menu will appear.


Note: Air conditioning units may need to be stopped to make only at "Settings". There may be some settings that cannot be made when the system is centrally controlled.



A screen will appear that indicates the setting has been saved.

Navigating through the screens

- To go back to the Service menu [MENU] button
- To return to the previous screen..... [RETURN] button




12-4. TEST RUN

12-4-1. PAR-41MAA


1. Select "Service" from the Main menu, and press the [SELECT] button.



Select "Test run" with the [F1] or [F2] button, and press the [SELECT] button.



2. Select "Test run" with the [F1] or [F2] button, and press the [SELECT] button.



Test run operation


Press the [F1] button to go through the operation modes in the order of "Cool and Heat".

Cool mode: Check if the cold air blows out.
Heat mode: Check if the heat blows out.

Check the operation of the outdoor unit's fan.



Press the [SELECT] button and open the Vane setting screen.



Auto vane check

Check the auto vane with the [F1] [F2] buttons.




Press the [RETURN] button to return to "Test run operation".



Press the [ON/OFF] button.











When the test run is completed, the "Test run menu" screen will appear.
The test run will automatically stop after 2 hours.

*The function is available only for the model with vanes.




12-4-2. PAR-FL32MA

Measure an impedance between the power supply terminal block on the outdoor unit and ground with a 500 V Megger and check that it is equal to or greater than 1.0 MΩ.















- ① Turn on the main power to the unit.
- ② Press the  button twice continuously.
(Start this operation from the status of remote controller display turned off.)
A  and current operation mode are displayed.
- ③ Press the  () button to activate  mode, then check whether cool air blows out from the unit.
- ④ Press the  () button to activate  mode, then check whether warm air blows out from the unit.
- ⑤ Press the  button and check whether strong air blows out from the unit.
- ⑥ Press the  button and check whether the auto vane operates properly.
- ⑦ Press the ON/OFF button to stop the test run.


Note:

- Point the remote controller towards the indoor unit receiver while following steps ② to ⑦.
- It is not possible to run in FAN, DRY or AUTO mode.



12-4-3. PAR-SL101A-E

- ① Press the  button ① to stop the air conditioner.
 - If the weekly timer is enabled ( is on), press the  button ③ to disable it ( is off).
- ② Press the  button ② for 5 seconds.
 -  comes on and the unit enters the service mode.
- ③ Press the  button ②.
 -  ⑥ comes on and the unit enters the test run mode.
- ④ Press the following buttons to start the test run.
 - : Switch the operation mode between cooling and heating and start the test run.
 - : Switch the fan speed and start the test run.
 - : Switch the airflow direction and start the test run.
 - : Switch the louver and start the test run.
 - : Start the test run.
- ⑤ Stop the test run.
 - Press the  button ① to stop the test run.
 - After 2 hours, the stop signal is transmitted.




12-5. FUNCTION SETTING

12-5-1. PAR-41MAA

1. Select "Service" from the Main menu, and press the [SELECT] button.

Select "Setting" from the Service menu, and press the [SELECT] button.


Select "Function setting", and press the [SELECT] button.




2. Set the indoor unit refrigerant addresses and unit numbers with the [F1] through [F4] buttons, and then press the [SELECT] button to confirm the current setting.

Note: Checking the indoor unit No.


When the [SELECT] button is pressed, the target indoor unit will start fan operation. If the unit is common or when running all units, all indoor units for the selected refrigerant address will start fan operation.



3. When data collection from the indoor units is completed, the current settings appears highlighted.
Non-highlighted items indicate that no function settings are made.
Screen appearance varies depending on the "Unit No." setting.




4. Use the [F1] or [F2] button to move the cursor to select the mode number, and change the setting number with the [F3] or [F4] button.



5. When the settings are completed, press the [SELECT] button to send the setting data from the remote controller to the indoor units.
When the transmission is successfully completed, the screen will return to the Function setting screen.

Note: • Make the above settings only on Mr. Slim units as necessary.


- The above function settings are not available for the CITY MULTI units.
- Refer to the indoor unit Installation Manual for the detailed information about initial settings, mode numbers, and setting numbers for the indoor units.
- Be sure to write down the settings for all functions if any of the initial settings has been changed after the completion of installation work.



12-5-2. PAR-FL32MA


Functions can be selected with the wireless remote controller. Function selection using wireless remote controller is available only for refrigerant system with wireless function. Refrigerant address cannot be specified by the wireless remote controller.

[Flow of function selection procedure]



Flow of function selection procedure

The flow of the function selection procedure is shown below. This example shows how to turn off the function that raises the set temperature by 4 degrees during HEAT operation. The procedure is given after the flow chart.



[Operating instructions]

① Check the function settings.

② Press the button twice continuously. → is lit and "00" blinks.

Press the TEMP button once to set "50". Direct the IR wireless remote controller toward the receiver of the indoor unit and press the button.

③ Set the unit number.

Press the TEMP button to set the unit number. (Press "01" to specify the indoor unit whose unit number is 01.)

Direct the IR wireless remote controller toward the receiver of the indoor unit and press the button.

(By setting unit number with the button, specified indoor unit starts performing fan operation.

Detect which unit is assigned to which number using this function. If unit number is set to AL, all the indoor units in same refrigerant system start performing fan operation simultaneously.

Notes:

1. If a unit number that cannot be recognized by the unit is entered, 3 beeps of 0.4 seconds will be heard. Reenter the unit number setting.
2. If the signal was not received by the sensor, you will not hear a beep or a "double ping sound" may be heard. Reenter the unit number setting.

④ Select a mode.

Press the TEMP button to set a mode. Press "24" to turn on the function that raises the set temperature by 4 degrees during heat operation. Direct the IR wireless remote controller toward the sensor of the indoor unit and press the button.

→ The sensor-operation indicator will blink and beeps will be heard to indicate the current setting number.

Current setting number: 1 = 1 beep (one second)
2 = 2 beeps (one second each)
3 = 3 beeps (one second each)

Notes:

1. If a mode number that cannot be recognized by the unit is entered, 3 beeps of 0.4 seconds will be heard. Reenter the mode number.
2. If the signal was not received by the sensor, you will not hear a beep or a "double ping sound" may be heard. Reenter the mode number.

⑤ Select the setting number.

Press the TEMP button to select the setting number. (02: Not available)

Direct the IR wireless remote controller toward the receiver of the indoor unit and press the button.

→ The sensor-operation indicator will blink and beeps will be heard to indicate the setting number.

Setting number: 1 = 2 beeps (0.4 seconds each)
2 = 2 beeps (0.4 seconds each, repeated twice)
3 = 2 beeps (0.4 seconds each, repeated 3 times)

Notes:

1. If a setting number that cannot be recognized by the unit is entered, the setting will turn back to the original setting.
2. If the signal was not received by the sensor, you will not hear a beep or a "double ping sound" may be heard. Reenter the setting number.

⑥ Repeat steps ④ and ⑤ to make an additional setting without changing unit number.

⑦ Repeat steps ③ to ⑤ to change unit number and make function settings on it.

⑧ Complete the function settings

Press button.

Do not use the wireless remote controller for 30 seconds after completing the function setting.

12-5-3. PAR-SL101A-E




Fig. 1

1. Going to the function select mode

Press the **[MENU]** button between of 5 seconds.

(Start this operation from the status of remote controller display turned off.)

[CHECK] is lit and "00" blinks. (Fig. 1)

Press the **[DOWN]** button to set the "50".

Direct the wireless remote controller toward the receiver of the indoor unit and press the **[SET]** button.




Fig. 2

2. Setting the unit number

Press the **[DOWN]** button to set unit number ①. (Fig. 2)

Direct the wireless remote controller toward the receiver of the indoor unit and press the **[SET]** button.




Fig. 3

3. Select a mode

Press the **[DOWN]** button to set Mode number ②. (Fig. 3)

Direct the wireless remote controller toward the receiver of the indoor unit and press the **[SET]** button.

Current setting number:

1=1 beep (1 second)

2=2 beeps (1 second each)

3=3 beeps (1 second each)




Fig. 4

4. Selecting the setting number

Use the **[DOWN]** button to change the Setting number ③. (Fig. 4)

Direct the wireless remote controller toward the receiver of the indoor unit and press the **[SET]** button.

5. To select multiple functions continuously

Repeat select ③ and ④ to change multiple function settings continuously.

6. Complete function selection


Direct the wireless remote controller toward the sensor of the indoor unit and press the **[OFF/ON]** button.

Note: Be sure to write down the settings for all functions if any of the initial settings has been changed after the completion of installation work.


12-6. ERROR HISTORY

1. Select "Service" from the Main menu, and press the [SELECT] button.

Select "Check" with the [F1] or [F2] button, and press the [SELECT] button.




2. Select "Error history" with the [F1] or [F2] button, and press the [SELECT] button.



3. 16 error history records will appear.

4 records are shown per page, and the top record on the first page indicates the latest error record.




4. Deleting the error history

To delete the error history, press the [F4] button (Delete) on the screen that shows error history. A confirmation screen will appear asking if you want to delete the error history.

Press the [F4] button (OK) to delete the history.

"Error history deleted" will appear on the screen.

Press the [RETURN] button to go back to the Check menu screen.



12-7. SELF-DIAGNOSIS


12-7-1. PAR-41MAA

1. Select "Service" from the Main menu,
and press the [SELECT] button.


Select "Check" from the Service menu,
and press the [SELECT] button.

Select "Diagnosis" from the Check menu,
and press the [SELECT] button.


Select "Self check" with the [F1] or [F2] button,
and press the [SELECT] button.




2. With the [F1] or [F2] button, enter the refrigerant address, and press the [SELECT] button.



3. Check code, unit number, attribute will appear.
"-" will appear if no error history is available.



When there is no error history





4. Resetting the error history

Press the [F4] button (Reset) on the screen that shows the error history.

A confirmation screen will appear asking if you want to delete the error history.

Press the [F4] button (OK) to delete the error history.

If deletion fails, "Request rejected" will appear.
"Unit not exist" will appear if no indoor units that are correspond to the entered address are found.




Navigating through the screens

- To go back to the Service menu [MENU] button
- To return to the previous screen..... [RETURN] button

12-7-2. PAR-FL32MA

When a malfunction occurs to air conditioner, both indoor unit and outdoor unit will stop and operation lamp blinks to inform unusual stop.

<Malfunction-diagnosis method at maintenance service>




[Procedure]

1. Press the CHECK button twice.
 - "CHECK" lights, and refrigerant address "00" blinks.
 - Check that the remote controller's display has stopped before continuing.
2. Press the TEMP (up/down) buttons.
 - Select the refrigerant address of the indoor unit for the self-diagnosis.

Note: Set refrigerant address using the outdoor unit's DIP switch (SW1). (For more information, see the outdoor unit installation manual.)
3. Point the remote controller at the sensor on the indoor unit and press the HOUR button.
 - If an air conditioner error occurs, the indoor unit's sensor emits an intermittent buzzer sound, the operation light blinks, and the check code is output. (It takes 3 seconds at most for check code to appear.)
4. Point the remote controller at the sensor on the indoor unit and press the ON/OFF button.
 - The check mode is cancelled.

12-7-3. PAR-SL101A-E



[Procedure]

1. Press the [ON/OFF] button ① to stop the air conditioner.
 - If the weekly timer is enabled (WEEKLY is on), press the [ON/OFF WEEKLY] button ③ to disable it (WEEKLY is off).
2. Press the [MENU] button ② for 5 seconds.
 - [CHECK] (A) comes on and the unit enters the self-check mode.
3. Press the [UP/DOWN] button ⑤ to select the refrigerant address (M-NET address) ⑥ of the indoor unit for which you want to perform the self-check.
4. Press the [SET] button ④.
 - If an error is detected, the check code is indicated by the number of beeps from the indoor unit and the number of blinks of the OPERATION INDICATOR lamp.
5. Press the [ON/OFF] button ①.
 - [CHECK] (A) and the refrigerant address (M-NET address) ⑥ go off and the self-check is completed.

12-8. REMOTE CONTROLLER CHECK


If operations cannot be completed with the remote controller, diagnose the remote controller with this function.

1. Select "Service" from the Main menu, and press the [SELECT] button.

Select "Check" from the Service menu, and press the [SELECT] button.

Select "Diagnosis" from the Check menu, and press the [SELECT] button.


Select "Remote controller check" with the **F1** or **F2** button, and press the [SELECT] button.



2. Select "Remote controller check" from the Diagnosis menu, and press the [SELECT] button to start the remote controller check and see the check results.


To cancel the remote controller check and exit the "Remote controller check" menu screen, press the [MENU] or the [RETURN] button.

The remote controller will not reboot itself.



3.
 - OK: No problems are found with the remote controller. Check other parts for problems.
 - E3, 6832: There is noise on the transmission line, or the indoor unit or another remote controller is faulty. Check the transmission line and the other remote controllers.
 - NG (ALL0, ALL1): Send-receive circuit fault. The remote controller needs replacing.
 - ERC: The number of data errors is the discrepancy between the number of bits in the data transmitted from the remote controller and that of the data that was actually transmitted over the transmission line. If data errors are found, check the transmission line for external noise interference.

Remote controller check results screen



If the [SELECT] button is pressed after the remote controller check results are displayed, remote controller check will end, and the remote controller will automatically reboot itself.


Check the remote controller display and see if anything is displayed (including lines). Nothing will appear on the remote controller display if the correct voltage (8.5–12 VDC) is not supplied to the remote controller. If this is the case, check the remote controller wiring and indoor units.

12-9. SMOOTH MAINTENANCE

1. Select "Service" from the Main menu, and press the [SELECT] button.

Select "Check" with the [F1] or [F2] button, and press the [SELECT] button.

Select "Smooth maintenance" with the [F1] or [F2] button, and press the [SELECT] button.



2. Set each item.


Select the item to be changed with the [F1] or [F2] button.

Select the required setting with the [F3] or [F4] button.

- <Ref.address>setting [0] – [15]
- <Stable mode>setting [Cool] / [Heat] / [Normal]

Press the [SELECT] button, Fixed operation will start.

Note: Stable mode will take approx. 20 minutes.




3. The operation data will appear.

The Compressor-Accumulated operating (COMP. run) time is 10-hour unit, and the Compressor-Number of operation times (COMP. ON/OFF) is a 100-time unit (fractions discarded).

Navigating through the screens

- To go back to the Service menu [MENU] button
- To return to the previous screen [RETURN] button




■ Refrigerant address

Single refrigerant system


In the case of single refrigerant system, the refrigerant address is "00" and no operation is required.

Simultaneous twin, triple units belong to this category (single refrigerant system).



Multi refrigerant system (group control)

Up to 16 refrigerant systems (16 outdoor units) can be connected as a group by 1 remote controller. To check or set the refrigerant addresses.




12-10. REQUEST CODE

Details on the operation data including each thermistor temperature and error history can be confirmed with the remote controller.

1. Select "Service" from the Main menu, and press the [SELECT] button.

Select "Check" with the [F1] or [F2] button, and press the [SELECT] button.

Select "Request code" with the [F1] or [F2] button, and press the [SELECT] button.




2. Set the Refrigerant address and Request code.

Select the item to be changed with the [F1] or [F2] button.


Select the required setting with the [F3] or [F4] button.

- <Ref.address>setting [0] – [15]
- <Request code>setting



Press the [SELECT] button, Data will be collected and displayed.

Request code: 004
Discharge temperature: 69°C



mitsubishi electric corporation

HEAD OFFICE: TOKYO BUILDING, 2-7-3, MARUNOUCHI, CHIYODA-KU, TOKYO100-8310, JAPAN

©Copyright 2023 MITSUBISHI ELECTRIC CORPORATION

Issued: Nov. 2024 No. OCH811D
Issued: Sep. 2024 No. OCH811C
Issued: Dec. 2023 No. OCH811B
Issued: Sep. 2023 No. OCH811A
Published: Mar. 2023 No. OCH811
Made in Japan

Specifications are subject to change without notice.