

# TECHNICAL & SERVICE MANUAL

## Series SLZ Ceiling Cassettes R410A

Indoor unit  
[Model Name]

[Service Ref.]

SLZ-KF09NA

**SLZ-KF09NA.TH**

SLZ-KF12NA

**SLZ-KF12NA.TH**

SLZ-KF15NA

**SLZ-KF15NA.TH**


SLZ-KF18NA

**SLZ-KF18NA.TH**


Revision:

- Some descriptions have been modified in REVISED EDITION-A.

OCH669 is void.



INDOOR UNIT


WIRELESS REMOTE  
CONTROLLER  
(Optional)

WIRED REMOTE CONTROLLER  
(Optional)

## CONTENTS

1. REFERENCE MANUAL .....	2
2. SAFETY PRECAUTION .....	2
3. PARTS NAMES AND FUNCTIONS.....	4
4. SPECIFICATIONS .....	9
5. OUTLINES AND DIMENSIONS.....	11
6. WIRING DIAGRAM.....	13
7. REFRIGERANT SYSTEM DIAGRAM .....	14
8. TROUBLESHOOTING .....	15
9. SPECIAL FUNCTION .....	28
10. 4-WAY AIRFLOW SYSTEM .....	30
11. DISASSEMBLY PROCEDURE .....	32

## PARTS CATALOG (OCB669)

## OUTDOOR UNIT'S SERVICE MANUAL

Service Ref.	Service Manual No.
MXZ-2C20NA2-U1	OBH702/OBB702

## 2-1. ALWAYS OBSERVE FOR SAFETY

**Before obtaining access to terminal, all supply circuits must be disconnected.**

## 2-2. CAUTIONS RELATED TO NEW REFRIGERANT

Cautions for units utilizing refrigerant R410A

**Use new refrigerant pipes.**

In case of using the existing pipes for R22, be careful with the following:

- Change flare nut to the one provided with this product.  
Use a newly flared pipe.
- Avoid using thin pipes.

**Make sure that the inside and outside of refrigerant piping is clean and it has no contaminants such as sulfur, oxides, dirt, shaving particles, etc., which are hazardous to the refrigerant cycle. In addition, use pipes with specified thickness.**

Contamination inside refrigerant piping can cause deterioration of refrigerant oil, etc.

**Store the piping indoors, and keep both ends of the piping sealed until just before brazing. (Leave elbow joints, etc. in their packaging.)**

If dirt, dust or moisture enters into refrigerant cycle, that can cause deterioration of refrigerant oil or malfunction of compressor.

**The refrigerant oil applied to flare and flange connections must be ether oil or alkylbenzene oil in a small amount.**

If large amount of mineral oil enters, that can cause deterioration of refrigerant oil, etc.

**Charge refrigerant in liquid form.**

If the refrigerant is charged from gas phase, composition change may occur in refrigerant and the efficiency will be lowered.

**Do not use refrigerant other than R410A.**

If other refrigerant (R22, etc.) is used, chlorine in refrigerant can cause deterioration of refrigerant oil, etc.

**Use a vacuum pump with a reverse flow check valve.**

Vacuum pump oil may flow back into refrigerant cycle and that can cause deterioration of refrigerant oil, etc.

**Use the following tools specifically designed for use with R410A refrigerant.**

The following tools are necessary to use R410A refrigerant.

Tools for R410A	
Gauge manifold	Flare tool
Charge hose	Size adjustment gauge
Gas leak detector	Vacuum pump adaptor
Torque wrench	Electronic refrigerant charging scale

**Handle tools with care.**

If dirt, dust or moisture enters into refrigerant cycle, that can cause deterioration of refrigerant oil or malfunction of compressor.

**Do not use a charging cylinder.**

If a charging cylinder is used, the composition of refrigerant will change and the efficiency will be lowered.

**Use the specified refrigerant only.****Never use any refrigerant other than that specified.**

Doing so may cause a burst, an explosion, or fire when the unit is being used, serviced, or disposed of.

Correct refrigerant is specified in the manuals and on the spec labels provided with our products.

We will not be held responsible for mechanical failure, system malfunction, unit breakdown or accidents caused by failure to follow the instructions.

**Ventilate the room if refrigerant leaks during operation. If refrigerant comes into contact with a flame, poisonous gases will be released.**


### [1] Cautions for service

- (1) Perform service after recovering the refrigerant left in unit completely.
- (2) Do not release refrigerant in the air.
- (3) After completing service, charge the system with specified amount of refrigerant.

### [2] Additional refrigerant charge

#### When charging directly from cylinder

- Check that cylinder for R410A available on the market is a syphon type.
- Charging should be performed with the cylinder of syphon stood vertically. (Refrigerant is charged in liquid phase.)



### [3] Service tools

Use the below service tools as exclusive tools for R410A refrigerant.

No.	Tool name	Specifications
①	Gauge manifold	· Only for R410A
		· Use the existing fitting specifications. (UNF1/2)
		· Use high-tension side pressure of 5.3MPa-G or over.
②	Charge hose	· Only for R410A
		· Use pressure performance of 5.09MPa-G or over.
③	Electronic weighing scale	—
④	Gas leak detector	· Use the detector for R134a, R407C or R410A.
⑤	Adaptor for reverse flow check	· Attach on vacuum pump.
⑥	Refrigerant charge base	—
⑦	Refrigerant cylinder	· Only for R410A      · Top of cylinder (Pink)
		· Cylinder with syphon
⑧	Refrigerant recovery equipment	—

## 3-1. INDOOR UNIT

**Horizontal Air Outlet**

Sets horizontal airflow automatically during cooling or dehumidifying.

**Filter**


Removes dust and pollutants from drawn in air.

**Grille****Auto Air Swing Vane**



Disperses airflow up and down and adjusts the angle of airflow direction.

**Air Intake**



Draws in air from room.



## 3-2. WIRELESS REMOTE CONTROLLER (Option)




**Temperature setting**  
The units of temperature can be changed. For details, refer to the Installation Manual.



**Not available**  
Appears when a non-supported function is selected.

**Battery replacement indicator**  
Appears when the remaining battery power is low.




### 3-3. Wired remote controller (Option) PAR-33MAA

The functions which can be used are restricted according to each model.


#### Display

The main display can be displayed in 2 different modes: "Full" and "Basic."  
The initial setting is "Full."

<Full mode>



<Basic mode>



Note: All icons are displayed for explanation.

#### 1 Operation mode

Indoor unit operation mode appears here.

#### 2 Preset temperature

Preset temperature appears here.

#### 3 Clock

(See the Installation Manual.)

Current time appears here.

#### 4 Fan speed

Fan speed setting appears here.

#### 5 Button function guide

Functions of the corresponding buttons appear here.

#### 6

Appears when the ON/OFF operation is centrally controlled.

#### 7

Appears when the operation mode is centrally controlled.

#### 8

Appears when the preset temperature is centrally controlled.

#### 9

Appears when the filter reset function is centrally controlled.

#### 10

Indicates when filter needs maintenance.

#### 11 Room temperature

(See the Installation Manual.)

Current room temperature appears here.

#### 12

Appears when the buttons are locked.

#### 13

Appears when the On/Off timer or Night setback function is enabled.

#### 14

Appears when the Weekly timer is enabled.

#### 15

Appears while the units are operated in the energy-saving mode.

#### 16

Appears while the outdoor units are operated in the silent mode.

#### 17

Appears when the built-in thermistor on the remote controller is activated to monitor the room temperature (a).

appears when the thermistor on the indoor unit is activated to monitor the room temperature.

#### 18

Appears when the units are operated in the energy-saving mode with 3D i-see Sensor.

#### 19

Indicates the vane setting.

#### 20

Indicates the louver setting.


#### 21

Indicates the ventilation setting.

#### 22

Appears when the preset temperature range is restricted.

#### Controller interface



- When the backlight is off, pressing any button turns the backlight on and does not perform its function. (except for the **ON/OFF** button)
- Most settings (except ON/OFF, mode, fan speed, temperature) can be made from the Menu screen.

#### 1 **ON/OFF** button

Press to turn ON/OFF the indoor unit.

#### 2 **SELECT** button

Press to save the setting.

#### 3 **RETURN** button

Press to return to the previous screen.

#### 4 **MENU** button

Press to bring up the Main menu.


#### 5 Backlit LCD

Operation settings will appear. When the backlight is off, pressing any button turns the backlight on and it will stay lit for a certain period of time depending on the screen.

#### 6 ON/OFF lamp

This lamp lights up in green while the unit is in operation. It blinks while the remote controller is starting up or when there is an error.

The functions of the function buttons change depending on the screen. Refer to the button function guide that appears at the bottom of the LCD for the functions they serve on a given screen. When the system is centrally controlled, the button function guide that corresponds to the locked button will not appear.



#### 7 Function button **F1**

Main display: Press to change the operation mode.

Main menu: Press to move the cursor down.

#### 8 Function button **F2**

Main display: Press to decrease temperature.

Main menu: Press to move the cursor up.

#### 9 Function button **F3**

Main display: Press to increase temperature.


Main menu: Press to go to the previous page.

#### 10 Function button **F4**

Main display: Press to change the fan speed.

Main menu: Press to go to the next page.

## Menu structure



## Main menu list

Setting and display items		Setting details
Vane · Louver · Vent. (Lossnay)		<b>Use to set the vane angle.</b> <ul style="list-style-type: none"> <li>Select a desired vane setting from 5 different settings.</li> </ul> <b>Use to turn ON/OFF the louver.</b> <ul style="list-style-type: none"> <li>Select a desired setting from "ON" and "OFF."</li> </ul> <b>Use to set the amount of ventilation.</b> <ul style="list-style-type: none"> <li>Select a desired setting from "OFF," "Low," and "High."</li> </ul>
High power**		<b>Use to reach the comfortable room temperature quickly.</b> <ul style="list-style-type: none"> <li>Units can be operated in the High-power mode for up to 30 minutes.</li> </ul>
Timer	ON/OFF timer*	<b>Use to set the operation ON/OFF times.</b> <ul style="list-style-type: none"> <li>Time can be set in 5-minute increments.</li> </ul>
	Auto-Off timer	<b>Use to set the Auto-OFF time.</b> <ul style="list-style-type: none"> <li>Time can be set to a value from 30 to 240 in 10-minute increments.</li> </ul>
Filter information		<b>Use to check the filter status.</b> <ul style="list-style-type: none"> <li>The filter sign can be reset.</li> </ul>
Error information		<b>Use to check error information when an error occurs.</b> <ul style="list-style-type: none"> <li>Check code, error source, refrigerant address, unit model, manufacturing number, contact information (dealer's phone number) can be displayed. (The unit model, manufacturing number, and contact information need to be registered in advance to be displayed.)</li> </ul>
Weekly timer*		<b>Use to set the weekly operation ON/OFF times.</b> <ul style="list-style-type: none"> <li>Up to 8 operation patterns can be set for each day. (Not valid when the ON/OFF timer is enabled.)</li> </ul>
OU silent mode**		<b>Use to set the time periods in which priority is given to quiet operation of outdoor units over temperature control. Set the Start / Stop times for each day of the week.</b> <ul style="list-style-type: none"> <li>Select the desired silent level from "Normal," "Middle," and "Quiet."</li> </ul>
Energy saving	Auto return	<b>Use to get the units to operate at the preset temperature after performing energy-saving operation for a specified time period.</b> <ul style="list-style-type: none"> <li>Time can be set to a value from 30 and 120 in 10-minute increments. (This function will not be valid when the preset temperature ranges are restricted.)</li> </ul>
	Schedule*	<b>Set the start/stop times to operate the units in the energy-saving mode for each day of the week, and set the energy-saving rate.</b> <ul style="list-style-type: none"> <li>Up to 4 energy-saving operation patterns can be set for each day.</li> <li>Time can be set in 5-minute increments.</li> <li>Energy-saving rate can be set to a value from 0% and 50 to 90% in 10% increments.</li> </ul>
Night setback*		<b>Use to make Night setback settings.</b> <ul style="list-style-type: none"> <li>Select "Yes" to enable the setting, and "No" to disable the setting. The temperature range and the start/stop times can be set.</li> </ul>
Restriction	Temp. range	<b>Use to restrict the preset temperature range.</b> <ul style="list-style-type: none"> <li>Different temperature ranges can be set for different operation modes.</li> </ul>
	Operation lock	<b>Use to lock selected functions.</b> <ul style="list-style-type: none"> <li>The locked functions cannot be operated.</li> </ul>
Maintenance	Auto descending panel	<b>Auto descending panel (Optional parts) can be operated UP/DOWN .</b>
	Manual vane angle	<b>Use to set the vane angle for each vane to a fixed position.</b>
	3D i-See sensor	<b>Use to set the following functions for 3D i-See sensor.</b> <ul style="list-style-type: none"> <li>Air distribution • Energy-saving option • Seasonal airflow</li> </ul>
Initial setting	Main/Sub	<b>When connecting 2 remote controllers, one of them needs to be designated as a sub controller.</b>
	Clock	<b>Use to set the current time.</b>
	Main display	<b>Use to switch between "Full" and "Basic" modes for the Main display.</b> <ul style="list-style-type: none"> <li>The initial setting is "Full."</li> </ul>
	Contrast	<b>Use to adjust screen contrast.</b>
	Display details	<b>Make the settings for the remote controller related items as necessary.</b> <p><b>Clock:</b> The initial settings are "Yes" and "24h" format.</p> <p><b>Temperature:</b> Set either Celsius (°C) or Fahrenheit (°F).</p> <p><b>Room temp. :</b> Set Show or Hide.</p> <p><b>Auto mode:</b> Set the Auto mode display or Only Auto display.</p>
	Auto mode	<b>Whether or not to use the AUTO mode can be selected by using the button.</b> <p>This setting is valid only when indoor units with the AUTO mode function are connected.</p>
	Administrator password	<b>The administrator password is required to make the settings for the following items.</b> <ul style="list-style-type: none"> <li>Timer setting • Energy-saving setting • Weekly timer setting</li> <li>Restriction setting • Outdoor unit silent mode setting • Night set back</li> </ul>
	Language selection	<b>Use to select the desired language.</b>
	Daylight saving time	<b>Sets the daylight saving time.</b>

\* Clock setting is required.

\*\* This function can only be set when certain outdoor units are connected.





Setting and display items		Setting details
Service	Test run	Select "Test run" from the Service menu to bring up the Test run menu. • Test run • Drain pump test run
	Input maintenance	Select "Input maintenance Info." from the Service menu to bring up the Maintenance information screen. The following settings can be made from the Maintenance Information screen. • Model name input • Serial No. input • Dealer information input
	Function setting	Make the settings for the indoor unit functions via the remote controller as necessary.
	LOSSNAY setting (CITY MULTI only)	This setting is required only when the operation of CITY MULTI units is interlocked with LOSSNAY units.
	Check	Error history: Display the error history and execute "delete error history". Refrigerant leak check (**): Refrigerant leaks can be judged. Smooth maintenance (**): The indoor and outdoor maintenance data can be displayed. Request code (**): Details of the operation data including each thermistor temperature and error history can be checked.
	Self check	Error history of each unit can be checked via the remote controller.
	Maintenance password	Use to change the maintenance password.
	Remote controller check	When the remote controller does not work properly, use the remote controller checking function to trouble-shoot the problem.

\*\* This function can only be set when certain outdoor units are connected.

## 4 SPECIFICATIONS

Indoor unit service ref.			SLZ-KF09NA.TH		SLZ-KF12NA.TH		SLZ-KF15NA.TH		SLZ-KF18NA.TH	
Mode			Cooling	Heating	Cooling	Heating	Cooling	Heating	Cooling	Heating
Power supply (phase, cycle, voltage)			Single phase 208/230 V, 60Hz							
Electrical data	Input	[kW]	0.02	0.02	0.02	0.02	0.03	0.03	0.04	0.04
	Current*	[A]	0.20	0.15	0.24	0.19	0.32	0.27	0.43	0.38
	Fan motor output*	[kW]	0.05		0.05		0.05		0.05	
Airflow rate (Low/Medium/High)		[m³/min]	6.5/7.5/8.5		6.5/8.0/9.5		7.0/9.0/11.5		8.5/12.0/13.5	
		[CFM]	230/265/300		230/280/335		245/315/405		300/420/475	
Noise level (Low/Medium/High)		[dB]	25/28/31		25/30/34		27/34/39		32/40/43	
Dimensions	Width	in (mm)	UNIT: 22-7/16 (570) PANEL: 24-19/32 (625)							
	Depth	in (mm)	UNIT: 22-7/16 (570) PANEL: 24-19/32 (625)							
	Height	in (mm)	UNIT: 9-21/32 (245) PANEL: 13/32 (10)							
Weight		lb (kg)	UNIT: 30.6 (13.9) PANEL: 6.6 (3)							

NOTE : Test conditions are based on ISO 5151.

Nominal cooling condition	Nominal heating condition
Indoor : 81°FDB/66°F WB (27°CDB/19°CWB)	68°FDB/59°F WB (20°CDB/15°CWB)
Outdoor : 95°FDB (35°CDB)	45°FDB/43°F WB (7°CDB/6°CWB)
Pipe length : 24-9/16 ft (7.5m)	24-9/16 ft (7.5 m)

\*Measured under rated operating frequency

### Specifications and rating conditions of main electric parts


#### INDOOR UNIT

Service ref.		SLZ-KF09NA.TH	SLZ-KF12NA.TH	SLZ-KF15NA.TH	SLZ-KF18NA.TH
Item					
Fuse	(FUSE)	250V 6.3A			
Vane motor	(MV)	MSBPC20M32 (Green label), MSBPC20M33 (Blue label): 12 V 300 Ω			
Terminal block	(TB)	TO OUTDOOR UNIT: 3P TO WIRED REMOTE CONTROLLER: 2P			

## NOISE CRITERION CURVES


SLZ-KF09NA.TH

<60Hz>		
NOTCH	SPL(dB)	LINE
High	31	○—○
Medium	28	△—△
Low	25	□—□




SLZ-KF12NA.TH

<60Hz>		
NOTCH	SPL(dB)	LINE
High	34	○—○
Medium	30	△—△
Low	25	□—□





SLZ-KF15NA.TH

<60Hz>		
NOTCH	SPL(dB)	LINE
High	39	○—○
Medium	34	△—△
Low	27	□—□



SLZ-KF18NA.TH

<60Hz>		
NOTCH	SPL(dB)	LINE
High	43	○—○
Medium	40	△—△
Low	32	□—□



**NOTE:** The sound level is measured in an anechoic room where echoes are few, when compressor stops. The sound may be bigger than the indicated level in actual use due to surrounding echoes. The sound level can be higher by about 2 dB than the indicated level during cooling and heating operation.


SLZ-KF09NA.TH

SLZ-KF12NA.TH

SLZ-KF15NA.TH


SLZ-KF18NA.TH

Unit: inch (mm)



## WIRELESS REMOTE CONTROLLER


### PAR-SL100A-E



## WIRED REMOTE CONTROLLER


### PAR-33MAA

Unit: inch (mm)







## WIRING DIAGRAM

SLZ-KF18NA.TH





SYMBOL	NAME
I.B	INDOOR CONTROLLER BOARD
CN2L	CONNECTOR (LOSSNAY)
CN24	CONNECTOR (BACK-UP HEATING)
CN32	CONNECTOR (REMOTE SWITCH)
CN41	CONNECTOR (HA TERMINAL-A)
CN51	CONNECTOR (CENTRALLY CONTROL)
CN105	CONNECTOR
F1	FUSE (UL 6.3A 250V AC)
J41	JUMPER WIRE (PAIR NUMBER SETTING WITH WIRELESS REMOTE CONTROLLER)
J42	
LED1	POWER SUPPLY (I.B)
LED2	POWER SUPPLY (WIRED REMOTE CONTROLLER)
LED3	COMMUNICATION (INDOOR-OUTDOOR)
SW1	DIP SWITCH (MODEL SELECTION)
SW2	DIP SWITCH (CAPACITY CODE)
SWE	JUMPER SWITCH (EMERGENCY OPERATION)
DP	DRAIN PUMP
FS	FLOAT SWITCH
MF	FAN MOTOR
MV	VANE MOTOR
TB4	TERMINAL BLOCK (INDOOR/OUTDOOR CONNECTING LINE)
TB5, TB6	TERMINAL BLOCK (REMOTE CONTROLLER TRANSMISSION LINE)
TH1	ROOM TEMP. THERMISTOR
TH2	PIPE TEMP. THERMISTOR/LIQUID
TH5	CONDENSER / EVAPORATOR TEMP. THERMISTOR
OPTION PART	
W.B	WIRELESS REMOTE CONTROLLER BOARD
BZ	BUZZER
LED1	OPERATION (GREEN)
LED2	DEFROST/STAND BY (ORANGE)
RU	RECEIVING UNIT
SW1	EMERGENCY OPERATION (HEAT)
SW2	EMERGENCY OPERATION (COOL)
MT	I-SEE SENSOR MOTOR
R. R	WIRED RF/MQTF CONTROLLER

MODELS	SW2	MODELS	SW2
KF09	 ON OFF 1 2 3 4 5	KF15	 ON OFF 1 2 3 4 5
KF12	 ON OFF 1 2 3 4 5	KF18	 ON OFF 1 2 3 4 5

The black square (■) indicates a switch position.

**NOTES:**

1. Since the outdoor side electric wiring may change be sure to check the outdoor unit electric wiring for servicing.
2. Indoor and outdoor connecting wires are made with polarities, make wiring matching terminal numbers (S1, S2, S3).
3. Symbols used in wiring diagram are,  
 Connector,  Terminal (block)
4. For details on how to operate self-diagnosis refer to the technical manuals etc.


\*1. Use copper supply wires.  
Utilisez des fils d'alimentation en cuivre.

SLZ-KF09NA.TH

SLZ-KF12NA.TH

SLZ-KF15NA.TH

SLZ-KF18NA.TH



Unit: inch(mm)

	SLZ-KF09/12NA.TH	SLZ-KF15/18NA.TH
Gas pipe	φ3/8(9.52)	φ1/2 (12.7)
Liquid pipe	φ1/4(6.35)	φ1/4 (6.35)

## 8-1. TROUBLESHOOTING

### <Check code displayed by self-diagnosis and actions to be taken for service (summary)>

Present and past check codes are logged, and they can be displayed on the wired remote controller or controller board of outdoor unit. Actions to be taken for service, which depends on whether or not the trouble is reoccurring in the field, are summarized in the table below. Check the contents below before investigating details.


Unit conditions at service	Check code	Actions to be taken for service (summary)
The trouble is reoccurring.	Displayed	Judge what is wrong and take a corrective action according to "8-3. SELF-DIAGNOSIS ACTION TABLE".
	Not displayed	Conduct troubleshooting and ascertain the cause of the trouble according to "8-4. TROUBLESHOOTING OF PROBLEMS".
The trouble is not reoccurring.	Logged	① Consider the temporary defects such as the work of protection devices in the refrigerant circuit including compressor, poor connection of wiring, noise, etc. Re-check the symptom, and check the installation environment, refrigerant amount, weather when the trouble occurred, matters related to wiring, etc. ② Reset check code logs and restart the unit after finishing service. ③ There is no abnormality in electrical component, controller board, remote controller, etc.
	Not logged	① Re-check the abnormal symptom. ② Conduct troubleshooting and ascertain the cause of the trouble according to "8-4. TROUBLESHOOTING OF PROBLEMS". ③ Continue to operate unit for the time being if the cause is not ascertained. ④ There is no abnormality concerning of parts such as electrical component, controller board, remote controller, etc.

## 8-2. MALFUNCTION-DIAGNOSIS METHOD BY REMOTE CONTROLLER

### <In case of trouble during operation>

When a malfunction occurs to air conditioner, both indoor unit and outdoor unit will stop and operation lamp blinks to inform unusual stop.


#### <Self-check>




- Press the button ① to stop the air conditioner.
  - If the weekly timer is enabled (**WEEKLY** is on), press the button ③ to disable it (**WEEKLY** is off).
- Press the button ② for 5 seconds.
  - ④ comes on and the unit enters the self-check mode.
- Press the button ⑤ to select the refrigerant address (M-NET address) ⑥ of the indoor unit for which you want to perform the self-check.
- Press the button ④.
  - If an error is detected, the check code is indicated by the number of beeps from the indoor unit and the number of blinks of the OPERATION INDICATOR lamp.
- Press the button ①.
  - ④ and the refrigerant address (M-NET address) ⑥ go off and the self-check is completed.

Refer to the following tables for details on the check codes.

[Output pattern A]



[Output pattern B]



[Output pattern A] Errors detected by indoor unit

Wireless remote controller	Wired remote controller	Symptom	Remark
Beeper sounds/OPERATION INDICATOR lamp blinks (Number of times)	Check code		
1	P1	Intake sensor error	
2	P2, P9	Pipe (liquid or 2-phase pipe) sensor error	
3	E6, E7	Indoor/outdoor unit communication error	
4	P4	Float switch connector open	
5	P5	Drain pump error	
	PA	Forced compressor error	
6	P6	Freezing (during cooling operation)/Overheating protection operation (during heating operation)	
7	EE	Assembly error (system error)	
8	P8	Pipe temperature error	
9	E4	Communication error between wired remote controller and indoor unit	
10	—	—	
11	PB(Pb)	Indoor unit fan motor error	
12	FB(Fb)	Indoor unit control system error (memory error, etc.)	
14	PL	Refrigerant circuit abnormal	

[Output pattern B] Errors detected by unit other than indoor unit (outdoor unit, etc.)

Note: The supported check codes may vary depending on the connected outdoor unit.

Wireless remote controller	Wired remote controller	Symptom	Remark
Beeper sounds/OPERATION INDICATOR lamp blinks (Number of times)	Check code		
1	E9	Indoor/outdoor unit communication error	For details, check the LED display of the outdoor controller board.
2	UP	Compressor overcurrent interruption	
3	U3, U4	Open/short of outdoor unit thermistors	
4	UF	Compressor overcurrent interruption (When compressor locked)	
5	U2	Abnormal high discharging temperature/49C worked/insufficient refrigerant	
6	U1, Ud	Abnormal high pressure (63H worked)/Overheating protection operation	
7	U5	Abnormal temperature of heat sink	
8	U8	Outdoor unit fan protection stop	
9	U6	Compressor overcurrent interruption/Abnormal of power module	
10	U7	Abnormality of super heat due to low discharge temperature	
11	U9, UH	Abnormality such as overvoltage or voltage shortage and abnormal synchronous signal to main circuit/Current sensor error	
12	—	—	
13	—	—	
14	Others	Other errors (Refer to the technical manual for the outdoor unit.)	

Notes:

- If the beeper does not sound again after the initial 2 beeps to confirm the self-check start signal was received and the OPERATION INDICATOR lamp does not come on, there are no error records.
  - If the beeper sounds 3 times continuously "beep, beep, beep (0.4 + 0.4 + 0.4 seconds)" after the initial 2 beeps to confirm the self-check start signal was received, the specified refrigerant address is incorrect.
- On wireless remote controller  
The continuous buzzer sounds from receiving section of indoor unit.  
Blink of operation lamp
  - On wired remote controller  
Check code displayed in the LCD.

Continued to the next page



- If the unit cannot be operated properly after the test run, refer to the following table to find out the cause.

Symptom		Cause
Wired remote controller		
PLEASE WAIT	For about 3 minutes after power-on	•For about 3 minutes after power-on, operation of the remote controller is not possible due to system startup. (Correct operation)
PLEASE WAIT → check code	Subsequent to about 3 minutes after power-on	•Connector for the outdoor unit's protection device is not connected. •Reverse or open phase wiring for the outdoor unit's power terminal block
No messages appear even when operation switch is turned ON (operation lamp does not light up).		•Incorrect wiring between indoor and outdoor units. (incorrect polarity of S1, S2, S3) •Remote controller wire short

On the wireless remote controller with condition above, following phenomena take place.

- No signals from the remote controller can be received.
- Operation lamp is blinking.
- The buzzer makes a short ping sound.

**Note:**

**Operation is not possible for about 30 seconds after cancellation of function selection. (Correct operation)**

For description of each LED (LED1, 2, 3) provided on the indoor controller board, refer to the following table.

LED1 (power for microprocessor)	Indicates whether control power is supplied. Make sure that this LED is always lit.
LED2 (power for remote controller)	Indicates whether power is supplied to the remote controller. This LED lights only in the case of the indoor unit which is connected to the outdoor unit refrigerant address "0".
LED3 (communication between indoor and outdoor units)	Indicates state of communication between the indoor and outdoor units. Make sure that this LED is always blinking.

Note: Errors to be detected in outdoor unit, such as codes starting with F, U or E (excluding E0 to E7), are not covered in this document. Please refer to the outdoor unit's service manual for the details.

### 8-3. SELF-DIAGNOSIS ACTION TABLE

Check code	Abnormal point and detection method	Cause	Countermeasure
P1	<b>Room temperature thermistor (TH1)</b> ① The unit is in 3-minute resume prevention mode if short/open of thermistor is detected. Abnormal if the unit does not reset normally after 3 minutes. (The unit returns to normal operation, if it has been reset normally.)  ② Constantly detected during cooling, drying and heating operation Short: 194°F or more Open: -40°F or less	① Defective thermistor characteristics  ② Contact failure of connector (CN20) on the indoor controller board (Insert failure) ③ Breaking of wire or contact failure of thermistor wiring ④ Defective indoor controller board	①—③ Check resistance value of thermistor. 30°F.....15.8kΩ 50°F.....9.6 kΩ 70°F.....6.0 kΩ 90°F.....3.9 kΩ 100°F.....3.2 kΩ  If you put force on (draw or bend) the lead wire with measuring resistance value of thermistor, breaking of wire or contact failure can be detected. ② Check contact failure of connector (CN20) on the indoor controller board. Refer to "8-5. TEST POINT DIAGRAM". Turn the power back on and check restart after inserting connector again. ④ Check room temperature display on remote controller. Replace indoor controller board if there is abnormal difference with actual room temperature.  Turn the power off, and on again to operate after checking.
P2	<b>Pipe temperature thermistor/Liquid (TH2)</b> ① The unit is in 3-minute resume prevention mode if short/open of thermistor is detected. Abnormal if the unit does not reset normally after 3 minutes. (The unit returns to normal operation, if it has been reset normally.) ② Constantly detected during cooling, drying, and heating (except defrosting) operation. Short: 194°F or more Open: -40°F or less	① Defective thermistor characteristics ② Contact failure of connector (CN44) on the indoor controller board (Insert failure) ③ Breaking of wire or contact failure of thermistor wiring ④ Defective refrigerant circuit is causing thermistor temperature of 194°F or more or -40°F or less. ⑤ Defective indoor controller board	①—③ Check resistance value of thermistor. For characteristics, refer to (P1) above. ② Check contact failure of connector (CN44) on the indoor controller board. Refer to "8-5. TEST POINT DIAGRAM". Turn the power on and check restart after inserting connector again. ④ Check pipe <liquid> temperature with remote controller in test run mode. If pipe <liquid> temperature is extremely low (in cooling mode) or high (in heating mode), refrigerant circuit may have defect. ⑤ Check pipe <liquid> temperature with remote controller in test run mode. If there is extreme difference with actual pipe <liquid> temperature, replace indoor controller board. Turn the power off, and on again to operate after checking.
P4	<b>Contact failure of drain float switch (CN4F)</b> • Extract when the connector of drain float switch is disconnected. (③ and ④ of connector CN4F is not short-circuited.) • Constantly detected during operation	① Contact failure of connector (Insert failure)  ② Defective indoor controller board	① Check contact failure of float switch connector. Turn the power on again and check after inserting connector again. ② Operate with connector (CN4F) short-circuited. Replace indoor controller board if abnormality reappears.
P5	<b>Drain overflow protection operation</b> ① Suspected abnormality, if drain float switch is detected to be underwater for 1 minute and 30 seconds continuously with drain pump on. Compressor and indoor fan will be turned off. ② Drain pump is abnormal if the condition above is detected during suspensive abnormality. ③ Constantly detected during drain pump operation	① Malfunction of drain pump ② Defective drain Clogged drain pump Clogged drain pipe ③ Defective drain float switch Jamming of the drain float switch or malfunction of moving parts causing the drain float switch to be detected under water (Switch closed) ④ Defective indoor controller board	① Check if drain pump works. ② Check drain function.  ③ Remove drain float switch connector CN4F and check if it is short (Switch closed) with the moving part of float switch UP, or OPEN with the moving part of float switch down. Replace float switch if it is closed with the moving part of float switch down. ④ Replace indoor controller board if it is short-circuited between ③—④ of the drain float switch connector CN4F and abnormality reappears.  It is not abnormal if there is no problem about the above-mentioned ①—④. Turn the power off, and on again to operate after check.

\*1: only P-series outdoor unit

Check code	Abnormal point and detection method	Cause	Countermeasure
P5	<b>Drain pump lock protection operation</b> ① Suspected abnormality, if drain pump stops for 5 seconds continuously with drain pump on. Drain pump will be restarted after turning off for 10 seconds. ② Drain pump is abnormal if the condition above is detected 4 times during operation.	① Malfunction of drain pump ② Clogged drain pump ③ Disconnected drain pump ④ Defective indoor controller board	①② Check if drain pump works. ③ Check if connector (CNP) is connected. ④ Turn the emergency operation switch (SWE) on and check the voltage between CNP ①—③. • Replace drain pump if the output is 13V DC. • Replace indoor controller board if the output is under 13V DC.
P6	<b>Freezing/overheating protection is operating</b> ① Freezing protection (Cooling mode) The unit is in 6-minute resume prevention mode if pipe <liquid or condenser/evaporator> temperature stays under 5°F for 3 minutes after the compressor started. Abnormal if it stays under 5°F for 3 minutes again within 16 minutes after 6-minute resume prevention mode. ② Overheating protection (Heating mode) The units is in 6-minute resume prevention mode if pipe <condenser/evaporator> temperature is detected as over 158°F after the compressor started. Abnormal if the temperature of over 158°F is detected again within 30 minutes after 6-minute resume prevention mode.	(Cooling or drying mode) ① Clogged filter (reduced airflow) ② Short cycle of air path ③ Low-load (low temperature) operation out of the tolerance range ④ Defective indoor fan motor • Fan motor is defective. • Indoor controller board is defective. ⑤ Defective outdoor fan control ⑥ Overcharge of refrigerant ⑦ Defective refrigerant circuit (clogging) (Heating mode) ① Clogged filter (reduced airflow) ② Short cycle of air path ③ Overload (high temperature) operation out of the tolerance range ④ Defective indoor fan motor • Fan motor is defective. • Indoor controller board is defective. ⑤ Defective outdoor fan control ⑥ Overcharge of refrigerant ⑦ Defective refrigerant circuit (restriction) ⑧ Bypass circuit of outdoor unit is defective.	(Cooling or drying mode) ① Check cleanliness of the filter. ② Remove blockage. ④ Refer to "8-7-2. DC Fan Motor (Fan Motor / Indoor Controller Board)". ⑤ Check outdoor fan motor. ⑥⑦ Check operating condition of refrigerant circuit. (Heating mode) ① Check cleanliness of the filter. ② Remove blockage. ④ Refer to "8-7-2. DC Fan Motor (Fan Motor / Indoor Controller Board)". ⑤ Check outdoor fan motor. ⑥—⑧ Check operating condition of refrigerant circuit.
P8	<b>Pipe temperature</b> <Cooling mode> Detected as abnormal when the pipe temperature is not in the cooling range 3 minutes after compressor start and 6 minutes after the liquid or condenser/evaporator pipe is out of cooling range. Note 1: It takes at least 9 minutes to detect. Note 2: Abnormality P8 is not detected in drying mode. Cooling range: $-5.4 \text{ deg} \geq (\text{TH}-\text{TH1})$ TH: Lower temperature between liquid pipe temperature (TH2) and condenser/evaporator temperature (TH5) TH1: Intake temperature <Heating mode> When 10 seconds have passed after the compressor starts operation and the hot adjustment mode has finished, the unit is detected as abnormal when condenser/evaporator pipe temperature is not in heating range within 20 minutes. Note 3: It takes at least 27 minutes to detect abnormality. Note 4: It excludes the period of defrosting (Detection restarts when defrosting mode is over) Heating range: $5.4 \text{ deg} \leq (\text{TH5}-\text{TH1})$	① Slight temperature difference between indoor room temperature and pipe <liquid or condenser/evaporator> temperature thermistor • Shortage of refrigerant • Disconnected holder of pipe <liquid or condenser/evaporator> thermistor • Defective refrigerant circuit ② Converse connection of extension pipe (on plural units connection) ③ Converse wiring of indoor/outdoor unit connecting wire (on plural units connection) ④ Defective detection of indoor room temperature and pipe <condenser/evaporator> temperature thermistor ⑤ Stop valve is not opened completely.	①—④ Check pipe <liquid or condenser/evaporator> temperature with room temperature display on remote controller and outdoor controller circuit board. Pipe <liquid or condenser/evaporator> temperature display is indicated by setting SW2 of outdoor controller circuit board as follows. *1 (Conduct temperature check with outdoor controller circuit board after connecting 'A-Control Service Tool (PAC-SK52ST)'). ②③ Check converse connection of extension pipe or converse wiring of indoor/outdoor unit connecting wire.

\*1: only P-series outdoor unit

Check code	Abnormal point and detection method	Cause	Countermeasure
P9	<b>Pipe temperature thermistor/Condenser / Evaporator (TH5)</b> ① The unit is in 3-minute resume protection mode if short/open of thermistor is detected. Abnormal if the unit does not get back to normal within 3 minutes. (The unit returns to normal operation, if it has been reset normally.) ② Constantly detected during cooling, drying, and heating operation (except defrosting) Short: 194°F or more Open: -40°F or less	① Defective thermistor characteristics ② Contact failure of connector (CN44) on the indoor controller board (Insert failure) ③ Breaking of wire or contact failure of thermistor wiring ④ Temperature of thermistor is 194°F or more or -40°F or less caused by defective refrigerant circuit. ⑤ Defective indoor controller board	①—③ Check resistance value of thermistor. For characteristics, refer to (P1) above. ② Check contact failure of connector (CN44) on the indoor controller board. Refer "8-5. TEST POINT DIAGRAM". Turn the power on and check restart after inserting connector again. ④ Operate in test run mode and check pipe <condenser/evaporator> temperature with outdoor controller circuit board. If pipe <condenser/evaporator> temperature is extremely low (in cooling mode) or high (in heating mode), refrigerant circuit may have defect. ⑤ Operate in test run mode and check pipe <condenser/evaporator> temperature with outdoor control circuit board. If there is extreme difference with actual pipe <condenser/evaporator> temperature replace indoor controller board. There is no abnormality if none of the above comes within the unit. Turn the power off and on again to operate. *1 ( In case of checking pipe temperature with outdoor controller circuit board, be sure to connect A-control service tool (PAC-SK52ST). )
PL	<b>Abnormal refrigerant circuit</b> During Cooling, Dry, or Auto Cooling operation, the following conditions are regarded as failures when detected for 1 second. a) The compressor continues to run for 30 or more seconds. b) The liquid pipe temperature (TH2) or the condenser/evaporator temperature (TH5) is 167°F or more. <u><b>These detected errors will not be cancelled until the power source is reset.</b></u>	① Abnormal operation of 4-way valve ② Disconnection of or leakage in refrigerant pipes ③ Air into refrigerant piping ④ Abnormal operation (no rotation) of indoor fan · Defective fan motor · Defective indoor control board ⑤ Defective refrigerant circuit (restriction)	① <b><u>When this error occurs, be sure to replace the 4-way valve.</u></b> ② Check refrigerant pipes for disconnection or leakage. ③ After the recovery of refrigerant, vacuum dry the whole refrigerant circuit. ④ Refer to section "8-7. TROUBLESHOOTING OF MAIN PARTS". ⑤ Check refrigerant circuit for operation. <b><u>To avoid entry of moisture or air into refrigerant circuit which could cause abnormal high pressure, purge air in refrigerant circuit or replace refrigerant.</u></b>
E0 or E4 (6831 or 6834)	<b>Remote controller transmission error(E0)/ signal receiving error(E4)</b> ① Abnormal if main or sub remote controller cannot receive any transmission normally from indoor unit of refrigerant address "0" for 3 minutes. (Check code : E0) ② Abnormal if sub-remote controller could not receive for any signal for 2 minutes. (Check code: E0) ① Abnormal if indoor controller board cannot receive normally any data from remote controller board or from other indoor controller board for 3 minutes. (Check code: E4) ② Indoor controller board cannot receive any signal from remote controller for 2 minutes. (Check code: E4)	① Contact failure at transmission wire of remote controller ② All remote controllers are set as "sub" remote controller. In this case, E0 is displayed on remote controller, and E4 is displayed at LED (LED1, LED2) on the outdoor controller circuit board. ③ Miswiring of remote controller ④ Defective transmitting/receiving circuit of remote controller ⑤ Defective transmitting/receiving circuit of indoor controller board of refrigerant address "0" ⑥ Noise has entered into the transmission wire of remote controller.	① Check disconnection or looseness of indoor unit or transmission wire of remote controller. ② Set one of the remote controllers "main", if there is no problem with the action above. ③ Check wiring of remote controller. • Total wiring length: max. 500 m (Do not use cable of 3 wire or more) • The number of connecting indoor units: max. 16 units • The number of connecting remote controller: max. 2 units If the cause of trouble is not in above ①—③, ④ Diagnose remote controllers. a) When "RC OK" is displayed, remote controllers have no problem. Turn the power off, and on again to check. If abnormality generates again, replace indoor controller board. b) When "RC NG" is displayed, replace remote controller. c) When "RC E3" or "ERC 00-66" is displayed, noise may be causing abnormality.

Check code	Abnormal point and detection method	Cause	Countermeasure
E3 or E5 (6832 or 6833)	<b>Remote controller transmission error(E3)/ signal receiving error(E5)</b> ① Abnormal if remote controller could not find blank of transmission path for 6 seconds and could not transmit. (Check code: E3) ② Remote controller receives transmitted data at the same time, compares the data, and when detecting it, judges different data to be abnormal 30 continuous times. (Check code: E3) ① Abnormal if indoor controller board could not find blank of transmission path. (Check code: E5) ② Indoor controller board receives transmitted data at the same time, compares the data, and when detecting it, judges different data to be abnormal 30 continuous times. (Check code: E5)	① 2 remote controllers are set as "main." (In case of 2 remote controllers) ② Remote controller is connected with 2 indoor units or more. ③ Repetition of refrigerant address ④ Defective transmitting/receiving circuit of remote controller ⑤ Defective transmitting/receiving circuit of indoor controller board ⑥ Noise has entered into transmission wire of remote controller.	① Set a remote controller to main, and the other to sub. ② Remote controller is connected with only one indoor unit. ③ The address changes to a separate setting. ④—⑥ Diagnose remote controller. a) When "RC OK" is displayed, remote controllers have no problem. Turn the power off, and on again to check. When becoming abnormal again, replace indoor controller board. b) When "RC NG" is displayed, replace remote controller. c) When "RC E3" or "ERC 00-66" is displayed, noise may be causing abnormality.
E6	<b>Indoor/outdoor unit communication error (Signal receiving error)</b> ① Abnormal if indoor controller board cannot receive any signal normally for 6 minutes after turning the power on. ② Abnormal if indoor controller board cannot receive any signal normally for 3 minutes. ③ Consider the unit abnormal under the following condition: When 2 or more indoor units are connected to one outdoor unit, indoor controller board cannot receive a signal for 3 minutes from outdoor controller circuit board, a signal which allows outdoor controller circuit board to transmit signals.	① Contact failure, short circuit or, miswiring (converse wiring) of indoor/outdoor unit connecting wire ② Defective transmitting/receiving circuit of indoor controller board ③ Defective transmitting/receiving circuit of indoor controller board ④ Noise has entered into indoor/outdoor unit connecting wire.	① Check disconnection or looseness of indoor/outdoor unit connecting wire of indoor unit or outdoor unit. Check all the units in case of twin indoor unit system. ②—④ Turn the power off, and on again to check. If abnormality generates again, replace indoor controller board or outdoor controller circuit board. Note: Other indoor controller board may have defect in case of twin indoor unit system.
E7	<b>Indoor/outdoor unit communication error (Transmitting error)</b> Abnormal if "1" receiving is detected 30 times continuously though indoor controller board has transmitted "0".	① Defective transmitting receiving circuit of indoor controller board ② Noise has entered into power supply. ③ Noise has entered into outdoor control wire.	①—③ Turn the power off, and on again to check. If abnormality generates again, replace indoor controller board.
FB(Fb)	<b>Indoor controller board</b> Abnormal if data cannot be normally read from the nonvolatile memory of the indoor controller board.	① Defective indoor controller board	① Replace indoor controller board.
E1 or E2 (6201 or 6202)	<b>Remote controller control board</b> ① Abnormal if data cannot be normally read from the nonvolatile memory of the remote controller control board. (Check code: E1) ② Abnormal if the clock function of remote controller cannot be normally operated. (Check code: E2)	① Defective remote controller	① Replace remote controller.

Check code	Abnormal point and detection method	Cause	Countermeasure
PA	<b>Forced compressor stop (due to water leakage abnormality)</b> ① The unit has a water leakage abnormality when the following conditions, a) and b), are satisfied while the above-mentioned detection is performed. a) The intake temperature subtracted with liquid pipe temperature detects to be less than 14°F [-10°C] for a total of 30 minutes. (When the drain float switch is detected to be NOT soaked in the water, the detection record of a) and b) will be cleared.) b) Drain float switch detects to be in the water for more than 15 minutes. Note: Once the water leakage abnormality is detected, abnormality state will not be released until the main power is reset.	① Drain pump trouble ② Drain defective · Drain pump clogging · Drain pipe clogging ③ Open circuit of float switch ④ Contact failure of float switch connector ⑤ Dew condensation on float switch · Drain water trickles down lead wire · Drain water ripples due to filter being clogged ⑥ Extension piping connection difference at twin, triple or quadruple system ⑦ Miswiring of indoor/outdoor connecting at twin, triple, quadruple system ⑧ Room temperature thermistor/ liquid pipe temperature thermistor detection is defective.	① Check the drain pump. ② Check whether water can be drained. ③ Check the resistance of the float switch. ④ Check the connector contact failure. ⑤ Check the float switch leadwire mounted. Check the filter cleanliness. ⑥ Check the piping connection. ⑦ Check the indoor/outdoor connecting wires. ⑧ Check the room temperature display of remote controller. Check the indoor liquid pipe temperature display of outdoor controller board.
PB(Pb)	<b>Fan motor trouble</b>	① Defective fan motor ② Defective indoor controller board ③ Contact failure of fan motor connector	①-③ Refer to "8-7-2. DC Fan Motor (Fan Motor/Indoor Controller Board)".



## 8-4. TROUBLESHOOTING OF PROBLEMS

Note: Refer to the manual of outdoor unit for the detail of remote controller.

\*1: only P-series outdoor unit

Phenomena	Cause	Countermeasure
(1) LED2 on indoor controller board is off.	<ul style="list-style-type: none"> <li>When LED1 on indoor controller board is also off.</li> </ul> <ol style="list-style-type: none"> <li>Power supply of rated voltage is not supplied to outdoor unit.</li> <li>Defective outdoor controller circuit board</li> <li>Power supply of 220–240 V AC is not supplied to indoor unit.</li> <li>Defective indoor controller board</li> </ol>	<ol style="list-style-type: none"> <li>Check the voltage of outdoor power supply terminal block (L, N) or (L<sub>3</sub>, N). <ul style="list-style-type: none"> <li>When 220–240 V AC is not detected, check the power wiring to outdoor unit and the breaker.</li> <li>When 220–240 V AC is detected, check ② (below).</li> </ul> </li> <li>Check the voltage between outdoor terminal block S1 and S2. <ul style="list-style-type: none"> <li>When 220–240 V AC is not detected, —check the fuse on outdoor controller circuit board.</li> <li>—check the wiring connection.</li> <li>When 220–240 V AC is detected, check ③ (below).</li> </ul> </li> <li>Check the voltage between indoor terminal block S1 and S2. <ul style="list-style-type: none"> <li>When 220–240 V AC is not detected, check indoor/outdoor unit connecting wire for miswiring.</li> <li>When 220–240 V AC is detected, check ④ (below).</li> </ul> </li> <li>Check the wiring connection between TB4 and CN01. Check the fuse on indoor controller board. If no problems are found, indoor controller board is defective.</li> </ol>
	<ul style="list-style-type: none"> <li>When LED1 on indoor controller board is lit.</li> </ul> <ol style="list-style-type: none"> <li>Mis-setting of refrigerant address for outdoor unit (There is no unit corresponding to refrigerant address "0".) *1</li> </ol>	<ol style="list-style-type: none"> <li>Check the setting of refrigerant address for outdoor unit. Set the refrigerant address to "0". (For grouping control system under which 2 or more outdoor units are connected, set one of the units to "0".) Set refrigerant address using SW1 (3-6) on outdoor controller circuit board.*1</li> </ol>
(2) LED2 on indoor controller board is blinking.	<ul style="list-style-type: none"> <li>When LED1 on indoor controller board is also blinking. Connection failure of indoor/outdoor unit connecting wire</li> <li>When LED1 is lit</li> </ul> <ol style="list-style-type: none"> <li>Miswiring of remote controller wires Under twin indoor unit system, 2 or more indoor units</li> <li>Refrigerant address for outdoor unit is wrong or not set. Under grouping control system, there are some units whose refrigerant address is 0. *1</li> <li>Short-cut of remote controller wires</li> <li>Defective remote controller</li> </ol>	<p>Check indoor/outdoor unit connecting wire for connection failure.</p> <ol style="list-style-type: none"> <li>Check the connection of remote controller wires in case of twin triple indoor unit system. When 2 or more indoor units are wired in one refrigerant system, connect remote controller wires to one of those units.</li> <li>Check the setting of refrigerant address in case of grouping control system. If there are some units whose refrigerant addresses are 0 in one group, set one of the units to 0 using SW1 (3-6) on outdoor controller circuit board. *1</li> <li>③④ Remove remote controller wires and check LED2 on indoor controller board. <ul style="list-style-type: none"> <li>When LED2 is blinking, check the condition of the remote controller wires, to see if they are shorted.</li> <li>When LED2 is lit, connect remote controller wires again and: if LED2 is blinking, remote controller is defective; if LED2 is lit, connection failure of remote controller terminal block, etc. has returned to normal.</li> </ul> </li> </ol>

## 8-5. TEST POINT DIAGRAM

### 8-5-1. Indoor controller board

#### SLZ-KF09NA.TH

#### SLZ-KF12NA.TH

#### SLZ-KF15NA.TH

#### SLZ-KF18NA.TH

CN22  
Connect to the terminal block (TB5)  
(Remote controller transmission line)  
10.4–14.6 V DC

CN5Y  
i-see Sensor motor (MT)  
12 V pulse output

CNV  
Vane motor (MV)  
12 V pulse output

CN90  
Connect to the wireless  
remote controller board (CNB)

LED2  
Power supply  
(Wired remote controller)

CN44  
Pipe temperature thermistor  
①–②: Liquid (TH2)  
③–④: Condenser/Evaporator (TH5)

CN20  
Room temperature thermistor  
(TH1)

CN4F  
Drain float switch (FS)

CN105  
IT

CN4Z  
i-see Sensor (Sensor)

CN24  
Back-up heating

CNP  
Drain pump (DP)  
①–③: 13 V DC

Vsp  
Voltage between pins of C626  
0 V DC (FAN stop)  
1–6.5 V DC (FAN operation)  
(Same as ⑥(+)-④(-) of CNMF)

CNMF  
Fan motor (MF)  
①–④: 310–340 V DC  
⑤–④: 15 V DC

SW1  
Model selection  
J41, J42  
Jumper wire  
(Pair No. setting with  
wireless remote controller)

SW2  
Capacity setting  
LED3  
Communication  
(Indoor-outdoor)

SWE  
Jumper switch  
(Emergency operation)

CN32  
Remote switch

CN51  
Centrally control  
①–②: Control signal  
13 V DC pulse input (①: +)  
③–④: Operation indicator  
13 V DC (③: +)  
③–⑤: Malfunction indicator  
13 V DC (③: +)

CN41  
HA terminal-A


CN2L  
Lossnay

LED1  
Power supply (I.B)

CN3C  
Connect to the terminal block  
(TB4)  
(Indoor/outdoor connecting line)  
0–24 V DC (Communication)

CN01  
Connect to the terminal block  
(TB4)  
(Indoor/outdoor connecting line)  
③–⑥: 220–240 V AC

F1  
FUSE  
(6.3A/250V)





## 8-6. FUNCTION OF DIP SWITCH

Each function is controlled by the DIP switch on the indoor controller board.

Model setting and capacity setting are preset in the nonvolatile memory of the indoor controller board.

The black square (■) indicates a switch position.

Switch	Functions	Setting by the DIP switch and jumper wire	Remarks																	
SW1	Model settings	<div><div><div><div></div><div></div><div></div><div></div><div></div><div></div></div><div><div></div><div></div><div></div><div></div><div></div><div></div></div></div><div>ON OFF</div><div>1 2 3 4 5 6</div></div>																		
SW2	Capacity setting	<table><tr><th>MODELS</th><th>SW2</th><th>MODELS</th><th>SW2</th></tr><tr><td>KF09</td><td><div><div><div><div></div><div></div><div></div><div></div><div></div></div><div><div></div><div></div><div></div><div></div><div></div></div></div><div>ON OFF</div><div>1 2 3 4 5</div></div></td><td>KF15</td><td><div><div><div><div></div><div></div><div></div><div></div><div></div></div><div><div></div><div></div><div></div><div></div><div></div></div></div><div>ON OFF</div><div>1 2 3 4 5</div></div></td></tr><tr><td>KF12</td><td><div><div><div><div></div><div></div><div></div><div></div><div></div></div><div><div></div><div></div><div></div><div></div><div></div></div></div><div>ON OFF</div><div>1 2 3 4 5</div></div></td><td>KF18</td><td><div><div><div><div></div><div></div><div></div><div></div><div></div></div><div><div></div><div></div><div></div><div></div><div></div></div></div><div>ON OFF</div><div>1 2 3 4 5</div></div></td></tr></table>	MODELS	SW2	MODELS	SW2	KF09	<div><div><div><div></div><div></div><div></div><div></div><div></div></div><div><div></div><div></div><div></div><div></div><div></div></div></div><div>ON OFF</div><div>1 2 3 4 5</div></div>	KF15	<div><div><div><div></div><div></div><div></div><div></div><div></div></div><div><div></div><div></div><div></div><div></div><div></div></div></div><div>ON OFF</div><div>1 2 3 4 5</div></div>	KF12	<div><div><div><div></div><div></div><div></div><div></div><div></div></div><div><div></div><div></div><div></div><div></div><div></div></div></div><div>ON OFF</div><div>1 2 3 4 5</div></div>	KF18	<div><div><div><div></div><div></div><div></div><div></div><div></div></div><div><div></div><div></div><div></div><div></div><div></div></div></div><div>ON OFF</div><div>1 2 3 4 5</div></div>						
MODELS	SW2	MODELS	SW2																	
KF09	<div><div><div><div></div><div></div><div></div><div></div><div></div></div><div><div></div><div></div><div></div><div></div><div></div></div></div><div>ON OFF</div><div>1 2 3 4 5</div></div>	KF15	<div><div><div><div></div><div></div><div></div><div></div><div></div></div><div><div></div><div></div><div></div><div></div><div></div></div></div><div>ON OFF</div><div>1 2 3 4 5</div></div>																	
KF12	<div><div><div><div></div><div></div><div></div><div></div><div></div></div><div><div></div><div></div><div></div><div></div><div></div></div></div><div>ON OFF</div><div>1 2 3 4 5</div></div>	KF18	<div><div><div><div></div><div></div><div></div><div></div><div></div></div><div><div></div><div></div><div></div><div></div><div></div></div></div><div>ON OFF</div><div>1 2 3 4 5</div></div>																	
J41 J42	Pair number setting with IR wireless remote controller	<table><tr><th rowspan="2">Wireless remote controller setting</th><th colspan="2">Control PCB setting</th></tr><tr><th>J41</th><th>J42</th></tr><tr><td>0</td><td>○</td><td>○</td></tr><tr><td>1</td><td>×</td><td>○</td></tr><tr><td>2</td><td>○</td><td>×</td></tr><tr><td>3 to 9</td><td>×</td><td>×</td></tr></table>	Wireless remote controller setting	Control PCB setting		J41	J42	0	○	○	1	×	○	2	○	×	3 to 9	×	×	<Initial setting> IR wireless remote controller: 0 Control PCB: ○ (for both J41 and J42) 4 pair number settings are supported. The pair number settings of the wireless remote controller and indoor control PCB (J41/J42) are given in the table on the left. ('×' in the table indicates the jumper wire is disconnected.)
Wireless remote controller setting	Control PCB setting																			
	J41	J42																		
0	○	○																		
1	×	○																		
2	○	×																		
3 to 9	×	×																		





## 8-7. TROUBLESHOOTING OF MAIN PARTS

SLZ-KF09NA.TH

SLZ-KF12NA.TH

SLZ-KF15NA.TH

SLZ-KF18NA.TH

Parts name	Check method and criterion			
Room temperature thermistor (TH1)	Measure the resistance with a tester. (Parts temperature 50 to 86°F)			
Pipe temperature thermistor/liquid (TH2)				
Condenser/evaporator temperature thermistor (TH5)				
(Refer to "8-7-1. Thermistor Characteristic Graph")				
Vane motor (MV)	Measure the resistance between the terminals with a tester. (At the ambient temperature 68 to 86°F)			
	Connector	Normal		
	Red–Yellow (⑤–③, ⑩–⑧, ⑮–⑬, ⑳–⑱)	300 Ω±7% (at 77°F)		
	Red–Blue (⑤–①, ⑩–⑥, ⑮–⑪, ⑳–⑫)			
	Red–Orange (⑤–④, ⑩–⑨, ⑮–⑭, ⑳–⑯)			
	Red–White (⑤–②, ⑩–⑦, ⑮–⑫, ⑳–⑰)			
Drain pump (DP)	<div>① Check if the drain float switch works properly.</div> <div>② Check if the drain pump works and drains water properly in dry mode.</div> <div>③ If no water drains, confirm that the check code P5 will be displayed 10 minutes after the operation starts.</div> <div>Note: The DC volt drain pump motor for this model is driven by the control board, so it is not possible to measure resistance between the wires leading to the pump motor.</div> <div>Normal</div> <div>Red–Black: Input 13 V DC → The pump starts to rotate.</div> <div>Purple–Black: Abnormal (check code P5) if it outputs 0–13 V square wave (5 pulses/rotation), and the number of rotation is not normal.</div>			
Drain float switch (FS)	Measure the resistance between the terminals with a tester.			
	State of moving part	Normal	Abnormal	
	UP	Closed	Other than short	
	DOWN	Open	Other than open	
	Turn the power ON while the i-see Sensor connector is connected to the CN4Z on indoor controller board. A communication between the indoor controller board and i-see Sensor board is made to detect the connection.			
	Normal: When the operation starts, the motor for i-see Sensor is driven to rotate the i-see Sensor.			
	Abnormal: The motor for i-see Sensor is not driven when the operation starts.			
Note: The voltage between the terminals cannot be measured accurately since it is pulse output.				
i-see Sensor motor *	Measure the resistance between the terminals with a tester. (At the ambient temperature 68 to 86°F)			
	Normal			
	Red–Yellow	Red–Blue	Red–Orange	Red–White
	250 Ω±7% (at 77°F)			

\* i-see Sensor is available with optional "i-see Sensor corner panel" (SLP-18FAEU).

## 8-7-1. Thermistor Characteristic Graph

<Thermistor characteristic graph>

Thermistor for lower temperature

Room temperature thermistor (TH1)  
Pipe temperature thermistor/liquid (TH2)  
Condenser/evaporator temperature thermistor (TH5)

Thermistor  $R_0 = 15 \text{ k}\Omega \pm 3\%$

Fixed number of  $B = 3480 \pm 2\%$

$$T(^{\circ}\text{F}) R_t = 15 \exp \left\{ 3480 \left( \frac{1}{273 + \frac{T-32}{1.8}} - \frac{1}{273} \right) \right\}$$

30°F 15.8 kΩ


50°F 9.6 kΩ

70°F 6.0 kΩ

80°F 4.8 kΩ

90°F 3.9 kΩ

100°F 3.2 kΩ



## 8-7-2. DC Fan Motor (Fan Motor/Indoor Controller Board)


### Check method of DC fan motor (fan motor/indoor controller circuit board)

#### ① Notes

- High voltage is applied to the connector (CNMF) for the fan motor. Pay attention to the service.
- Do not pull out the connector (CNMF) for the motor with the power supply on.  
(It causes trouble of the indoor controller circuit board and fan motor.)

#### ② Self check

Symptom : The indoor fan cannot rotate.



## BACK-UP HEATING FUNCTION

### 9-1. Operation

The back-up heater turns ON when both of the following conditions have been satisfied:


A) When the room temperature has not risen after the heater ON delay time has passed.

Note: The heater ON delay time starts when the condition of “set temperature – room temperature > 1°F [0.5°C]” has been satisfied.

B) Set temperature – room temperature  $\geq$  3°F [1.5°C]

The back-up heater turns OFF when the following condition has been satisfied:

- Set temperature – room temperature  $\leq$  1°F [0.5°C]



### 9-2. How to change the heater ON delay time

You can set these functions by wired remote controller (Request code).

Note that the change can be made only by the wired remote controller PAR-33MAA.

Notes:

1. If using a twin indoor unit system, both main and sub unit should be set in the same setting.
2. Every time replacing indoor controller board for serving, the function should be set again.
3. Stop the air-conditioner operation before changing the heater ON delay time.

### Request code list

Setting No. (Request code)	Setting contents	Initial setting
No.1 (390)	Monitoring the request code of current setting	
No.2 (391)	10 minutes	
No.3 (392)	15 minutes	
No.4 (393)	20 minutes	○
No.5 (394)	25 minutes	


### 9-3. How to connect

When connecting to the connector CN24 of the indoor unit, use PAC-SE56RA-E (optional parts).

Note: If using a twin indoor unit system, connect to the CN24 of the indoor unit that the remote controller is connected to.

## 9-4. How to send the Request code


### PAR-3xMAA ("x" represents 0 or later)



- ① Press the button.
- ② Select "Service" with the [Cursor] buttons ( and ) or the [Page] buttons ( and ), and press the button.
- ③ Enter the current maintenance password (4 numerical digits).
  - Move cursor to the digit you want to change with the or button.
  - Set each number (0 through 9) with the or button.  
(Note: The initial maintenance password is "9999".)
- ④ Then, press the button.
- ⑤ Select "Check" with the or button, and press the button.
- ⑥ Select "Request code" with the or button, and press the button.
- ⑦ Set the Refrigerant address and Request code.
  - Select the item to be changed with the or button.
  - Select the required setting with the or button.
- ⑧ Press the or button to set the Refrigerant address "0".
- ⑨ Press the or button to set the desired request code No.
- ⑩ Press the button. Data will be collected and displayed.
- ⑪ To return to the Main menu, press the button.


### 10-1. FRESH AIR INTAKE (LOCATION FOR INSTALLATION)

At the time of installation, use the duct holes (cut out) located at the positions shown in following diagram, as and when required.




### 10-2. FRESH AIR INTAKE AMOUNT & STATIC PRESSURE CHARACTERISTICS

#### Taking air into the unit



**NOTE:** Fresh air intake amount should be 10% or less of whole air amount to prevent dew dripping.

#### How to read curves



- Q...Designed amount of fresh air intake  
<CMM (CFM)>
- A...Static pressure loss of fresh air intake duct system with air flow amount Q  
<Pa (in.W.G. × 10<sup>-2</sup>)>
- B...Forced static pressure at air conditioner inlet with airflow amount Q  
<Pa (in.W.G. × 10<sup>-2</sup>)>
- C...Static pressure of booster fan with air flow amount Q  
<Pa (in.W.G. × 10<sup>-2</sup>)>
- D...Static pressure loss increase amount of fresh air intake duct system for air flow amount Q  
<Pa (in.W.G. × 10<sup>-2</sup>)>
- E...Static pressure of indoor unit with air flow amount Q  
<Pa (in.W.G. × 10<sup>-2</sup>)>
- Qa...Estimated amount of fresh air intake without D  
<CMM (CFM)>

### 10-3. OPERATION IN CONJUNCTION WITH DUCT FAN (BOOSTER FAN)

- Whenever the indoor unit operates, the duct fan operates.


(1) Connect the optional multiple remote controller adapter (PAC-SA88HA-E) to the connector CN51 on the indoor controller board.

(2) Drive the relay after connecting the 12 V DC relay between the Yellow and Orange connector wires.


Use a relay of 1W or smaller.

MB: Electromagnetic switch power relay for duct fan.

X: Auxiliary relay (12 V DC LY-1F)



Multiple remote controller adapter PAC-SA88HA-E




Distance between indoor controller board and relay must be within 10m.

## 10-4. FIXING HORIZONTAL VANE


Horizontal vane of each air outlet can be fixed according to the environment where it is installed.

### Setting procedure

- 1) Turn off the main power supply (Turn off the breaker).
- 2) Remove the vane motor connector in the direction of the arrow shown below with pressing the unlocking button as in the figure below.  
Insulate the disconnected connector with the plastic tape.



- 3) Set the vertical vane of the air outlet by hand slowly within the range in the table below.



<Set range>

Standard of horizontal position	Angle $\theta = 21^\circ$ (Horizontal)	Angle $\theta = 24^\circ$	Angle $\theta = 39^\circ$	Angle $\theta = 42^\circ$	Angle $\theta = 45^\circ$ (Downward)
Dimension A	1-9/16 inch 39 mm	1-5/8 inch 41 mm	1-7/8 inch 47 mm	1-29/32 inch 48 mm	1-15/16 inch 49 mm

Note: Dimension between 1-9/16 inch (39 mm) and 1-15/16 inch (49 mm) can be arbitrarily set.

### Caution



Do not set the dimension out of the range.

Erroneous setting could cause dew drips or malfunction of unit.

SLZ-KF09NA.TH

SLZ-KF12NA.TH

SLZ-KF15NA.TH

SLZ-KF18NA.TH

Be careful when removing heavy parts.


## OPERATING PROCEDURE

## 1. Removing the air intake grille and air filter

- (1) Slide the knob of air intake grille to the direction of the arrow ① to open the air intake grille.
- (2) Remove the grille hook from the panel to prevent the grille from dropping.
- (3) Slide the hinge of the intake grille to the direction of the arrow ② and remove the air filter.

## PHOTOS/FIGURES

Figure 1



## 2. Removing the panel

- (1) Remove the air intake grille. (Refer to procedure 1)

**Connector box (See Photo 1)**

- (2) Remove the screw of the connector cover.
- (3) Slide the connector cover to the direction of the arrow to open the cover.
- (4) Disconnect all the connectors, then pull out the connectors that are coming from panel side from the connector box.

**Corner panel (See Figure 2 and Photo 2)**

- (5) Loosen the screw from the corner of the corner panel.
- (6) Slide the corner panel as indicated by the arrow.
- (7) Remove the safety strap from the hook, then remove the corner panel from the panel.  
(The safety strap is not equipped for the signal receiver panel and i-see Sensor corner panel.)
- (8) Remove the fastener (\*), then remove the corner panel.

**Panel (See Photo 3)**

- (9) Remove the 4 screws.
- (10) Unlatch the 2 hooks.

\* Fastener is only for the signal receiver and i-see Sensor corner panel.

Photo 1




Figure 2




Photo 2









Photo 3





OPERATING PROCEDURE	PHOTOS/FIGURES
<p><b>3. Removing the electrical parts</b></p> <ol style="list-style-type: none"> <li>(1) Loosen the 2 screws on the control box cover.</li> <li>(2) Slide the control box cover as indicated by the arrow to remove.</li> </ol> <p>&lt;Electrical parts in the control box&gt;</p> <ul style="list-style-type: none"> <li>• Indoor controller board (I.B)</li> <li>• Terminal block (TB4)</li> <li>• Terminal block (TB5)</li> </ul>	<p><b>Photo 4</b></p>  <p>Control box cover</p> <p>Screws</p> <p><b>Photo 5</b></p>  <p>Indoor controller board (I.B)</p> <p>Terminal block (TB5)</p> <p>Terminal block (TB4)</p>
<p><b>4. Removing the room temperature thermistor (TH1)</b></p> <ol style="list-style-type: none"> <li>(1) Remove the panel. (Refer to procedure 2)</li> </ol> <p><b>Room temperature thermistor (TH1) (See Photo 6)</b></p> <ol style="list-style-type: none"> <li>(2) Remove the 2 lead wire cover fixing screws. (See Photo 6)</li> <li>(3) Open the lead wire cover, then remove the connector cover from the connector box.</li> <li>(4) Remove the band that fixes the room temperature thermistor (TH1) to the connector box.</li> <li>(5) Remove the room temperature thermistor (TH1) from the connector box.</li> <li>(6) Remove the connector (CN20) from the indoor controller board, and disconnect the room temperature thermistor (TH1).</li> </ol> <p><b>Note: When fixing the thermistor, make sure to fix it to the connector box using a band.</b></p>	<p><b>Photo 6</b></p>  <p>Lead wire cover</p> <p>Lead wire cover fixing screws</p> <p>Room temperature thermistor (TH1)</p> <p>Connector cover</p>
<p><b>5. Removing the drain pan</b></p> <ol style="list-style-type: none"> <li>(1) Remove the panel. (Refer to procedure 2)</li> <li>(2) Remove the room temperature thermistor (TH1). (Refer to procedure 4)</li> </ol> <p><b>Connector box (See Photo 7)</b></p> <ol style="list-style-type: none"> <li>(3) Remove the connector box fixing screw.</li> <li>(4) Slide the connector box as indicated by the arrow ①, then remove from bell mouth.</li> </ol> <p><b>Bell mouth (See Photo 7)</b></p> <ol style="list-style-type: none"> <li>(5) Remove the 4 bell mouth fixing screws, then remove the bell mouth.</li> </ol> <p><b>Drain pan (See Photo 7)</b></p> <ol style="list-style-type: none"> <li>(6) Remove the 4 drain pan fixing screws, then remove the drain pan.</li> </ol>	<p><b>Photo 7</b></p>  <p>Drain pan fixing screws</p> <p>Connector box fixing screw</p> <p>Bell mouth fixing screws</p> <p>Drain pan fixing screws</p>

## OPERATING PROCEDURE

### 6. Removing the pipe temperature thermistor/liquid (TH2) and pipe temperature thermistor/gas (TH5)

- (1) Remove the panel. (Refer to procedure 2)
- (2) Remove the room temperature thermistor (TH1). (Refer to procedure 4)
- (3) Remove the drain pan. (Refer to procedure 5)

#### Pipe temperature thermistor/liquid (TH2) and pipe temperature thermistor/gas (TH5) (See Photo 8)

- (4) Remove the control box cover. (Refer to procedure 3)
- (5) Disconnect the thermistor connectors from the CN44 on the indoor controller board.
- (6) Cut the band fixing the thermistor connectors to the fan motor cable.
- (7) Remove the thermistors from the holders on heat exchanger.

**Note:** When re-attaching the thermistor connectors to the fan motor cable, make sure to put the fixed band into the groove. (See Photo 8-1)

### 7. Removing the fan motor (MF)

- (1) Remove the panel. (Refer to procedure 2)
- (2) Remove the room temperature thermistor (TH1). (Refer to procedure 4)
- (3) Remove the drain pan. (Refer to procedure 5)

#### Turbo fan (See Photo 3)

- (4) Remove the nut and washer from the turbo fan.
- (5) Remove the turbo fan from the motor shaft.


< Nut and washer >



**Note 1:** When assembling the turbo fan, attach it so that its tabs fit the holes of washer.

**Note 2:** Nut tightening torque:  $4.5 \pm 0.5$  Nm.

Turbo fan



#### Fan motor (See Photo 9)

- (6) Remove the control box cover. (Refer to procedure 3)
- (7) Disconnect the fan motor cable from the CNMF on the indoor controller board.
- (8) Remove the 2 motor lead cover fixing screws, then remove the motor lead cover.
- (9) Loosen the 3 clamps fixing the fan motor cable.
- (10) Cut the band.
- (11) Remove the 3 nuts and washers, then remove the fan motor.
- (12) Remove the 3 motor mounts.

**Note 1:** When re-attaching the motor mount, make sure that the thicker end faces the motor shaft. (See Photo 10-1)

**Note 2:** When re-attaching the turbo fan, make sure that the tightening torque for nuts is 5 N·m or lower.

## PHOTOS/FIGURES

Photo 8




Photo 8-1




Photo 9









Photo 10



Photo 10-1



OPERATING PROCEDURE	PHOTOS/FIGURES
<p><b>8. Removing the drain pump (DP) and float switch (FS)</b></p> <ol style="list-style-type: none"> <li>(1) Remove the panel. (Refer to procedure 2)</li> <li>(2) Remove the room temperature thermistor (TH1). (Refer to procedure 4)</li> <li>(3) Remove the control box cover. (Refer to procedure 3)</li> <li>(4) Remove the drain pan. (Refer to procedure 5)</li> </ol> <p><b>Drain pump (See Photo 11 and 12)</b></p> <ol style="list-style-type: none"> <li>(5) Disconnect the drain pump connector from the CNP and float switch connector from CN4F on the indoor controller board.</li> <li>(6) Loosen the clamp fixing the connectors on the side of the control box.</li> <li>(7) Cut the hose band and release the hose.</li> <li>(8) Remove the 2 screws fixing the drain pump and float switch to the inner cover.</li> <li>(9) Slide the base plate of the drain pump and float switch as indicated by the arrow ① to remove.</li> <li>(10) Cut the band. (See Photo 12)</li> <li>(11) Remove the 3 drain pump fixing screws, then remove the drain pump. (See Photo 12)</li> </ol> <p><b>Notes:</b></p> <ol style="list-style-type: none"> <li>1. When re-attaching the drain pump, make sure to use a band to fix the connector to the base plate.</li> <li>2. Do not give a shock to the float switch. Otherwise it can cause damage or malfunction.</li> </ol>	<p><b>Photo 11</b></p>  <p><b>Photo 12</b></p> 
<p><b>9. Removing the heat exchanger</b></p> <ol style="list-style-type: none"> <li>(1) Remove the panel. (Refer to procedure 2)</li> <li>(2) Remove the room temperature thermistor (TH1). (Refer to procedure 4)</li> <li>(3) Remove the drain pan. (Refer to procedure 5)</li> <li>(4) Remove the turbo fan and fan motor. (Refer to procedure 7)</li> </ol> <p><b>Heat exchanger (See Photo 13 and 14)</b></p> <ol style="list-style-type: none"> <li>(5) Remove the 3 pipe cover fixing screws to remove the pipe cover.</li> <li>(6) Remove the 2 coil plate fixing screws.</li> <li>(7) Remove the coil support fixing screw, then remove the coil support.</li> <li>(8) Remove the heat exchanger.</li> </ol>	<p><b>Photo 13</b></p>  <p><b>Photo 14</b></p> 

# mitsubishi electric corporation

HEAD OFFICE : TOKYO BUILDING, 2-7-3, MARUNOUCHI, CHIYODA-KU, TOKYO 100-8310, JAPAN

---