

INDOOR UNIT


No. OBH968
REVISED EDITION-B

SERVICE MANUAL

Models

MFZ-KX09NL - CA1, CA2
MFZ-KX12NL - CA1, CA2
MFZ-KX15NL - CA1, CA2
MFZ-KX18NL - CA1, CA2

Outdoor unit service manual
 MXZ-D•NL Series (OBH962)
 MXZ-SM•NL Series
 MXZ-SM•NLHZ Series
 SUZ-AA•NL Series



CONTENTS

1. TECHNICAL CHANGES	2
2. SAFETY PRECAUTION	3
3. PART NAMES AND FUNCTIONS	8
4. SPECIFICATIONS	9
5. OUTLINES AND DIMENSIONS	11
6. WIRING DIAGRAM	12
7. REFRIGERANT SYSTEM DIAGRAM	13
8. SERVICE FUNCTIONS	14
9. MICROPROCESSOR CONTROL	18
10. TROUBLESHOOTING	28
11. DISASSEMBLY INSTRUCTIONS	46

PARTS CATALOG (OBB968)

Use the specified refrigerant only

Never use any refrigerant other than that specified.

Doing so may cause a burst, an explosion, or fire when the unit is being used, serviced, or disposed of.

Correct refrigerant is specified in the manuals and on the spec labels provided with our products.

We will not be held responsible for mechanical failure, system malfunction, unit breakdown or accidents caused by failure to follow the instructions.

<Preparation before the repair service>

- Prepare the proper tools.
- Prepare the proper protectors.
- Provide adequate ventilation.
- After stopping the operation of the air conditioner, turn off the power-supply breaker and pull the power plug.
- Discharge the capacitor before the work involving the electric parts.

<Precautions during the repair service>

- Do not perform the work involving the electric parts with wet hands.
- Do not pour water into the electric parts.
- Do not touch the refrigerant.
- Do not touch the hot or cold areas in the refrigeration cycle.
- When the repair or the inspection of the circuit needs to be done without turning off the power, exercise great caution not to touch the live parts.

WARNING

- When the refrigerant circuit has a leak, do not execute pump down with the compressor.
- When pumping down the refrigerant, stop the compressor before disconnecting the refrigerant pipes. The compressor may burst if air etc. get into it.
- When opening or closing the valve below freezing temperatures, refrigerant may spurt out from the gap between the valve stem and the valve body, resulting in injuries.

Revision A:

- Some descriptions have been changed.

Revision B:

- MFZ-KX09/12/15/18NL -  have been added.

1 TECHNICAL CHANGES

MFZ-KX09NL - 

MFZ-KX12NL - 

MFZ-KX15NL - 

MFZ-KX18NL - 

1. New model

MFZ-KX09NL -  → **MFZ-KX09NL** - 

MFZ-KX12NL -  → **MFZ-KX12NL** - 

MFZ-KX15NL -  → **MFZ-KX15NL** - 

MFZ-KX18NL -  → **MFZ-KX18NL** - 

1. Model name has been changed.

MEANINGS OF SYMBOLS DISPLAYED ON THE UNIT

	Refrigerant Safety Group A2L	WARNING (Risk of fire)	This unit uses a flammable refrigerant. If the refrigerant leaks and comes in contact with fire or a heating part, it will create a harmful gas and there is a risk of fire.
	Read the OPERATION MANUAL carefully before operation.		
	Service personnel are required to carefully read the OPERATION MANUAL and INSTALLATION MANUAL before operation.		
	Further information is available in the OPERATION MANUAL, INSTALLATION MANUAL, and the like.		

2-1. ALWAYS OBSERVE FOR SAFETY

Before obtaining access to terminal, all supply circuits must be disconnected.

2-2. CAUTIONS RELATED TO NEW REFRIGERANT

Cautions for units utilizing refrigerant R454B

Do not use the existing refrigerant piping.

The old refrigerant and lubricant in the existing piping contains a large amount of chlorine which may cause the lubricant deterioration of the new unit.

Make sure that the inside and outside of refrigerant piping is clean and it has no contaminants such as sulfur, oxides, dirt, shaving particles, etc., which are hazard to refrigerant cycle. In addition, use pipes with specified thickness.

Contamination inside refrigerant piping can cause deterioration of refrigerant oil, etc.

Store the piping indoors, and keep both ends of the piping sealed until just before brazing. (Leave elbow joints, etc. in their packaging.)

If dirt, dust or moisture enters into refrigerant cycle, that can cause deterioration of refrigerant oil or malfunction of compressor.

The refrigerant oil applied to flare and flange connections must be ester oil, ether oil or alkylbenzene oil in a small amount.

If large amount of mineral oil enters, that can cause deterioration of refrigerant oil, etc.

Charge refrigerant from liquid phase of gas cylinder.

If the refrigerant is charged from gas phase, composition change may occur in refrigerant and the efficiency will be lowered.

Ventilate the room if refrigerant leaks during operation. If refrigerant comes into contact with a flame, poisonous gases will be released.

Use a vacuum pump with a reverse flow check valve.

Vacuum pump oil may flow back into refrigerant cycle and that can cause deterioration of refrigerant oil, etc.

Use the following tools specifically designed for use with R454B refrigerant.

The following tools are necessary to use R454B refrigerant.

Tools for R454B	
Gauge manifold	Flare tool
Charge hose	Size adjustment gauge
Gas leak detector	Vacuum pump adaptor
Torque wrench	Electronic refrigerant charging scale

Handle tools with care.

If dirt, dust or moisture enters into refrigerant cycle, that can cause deterioration of refrigerant oil or malfunction of compressor.

Do not use a charging cylinder.

If a charging cylinder is used, the composition of refrigerant will change and the efficiency will be lowered.

Use the specified refrigerant only.**Never use any refrigerant other than that specified.**

Doing so may cause a burst, an explosion, or fire when the unit is being used, serviced, or disposed of. Correct refrigerant is specified on name plate of outdoor unit.

If other refrigerant (R22, etc.) is used, chlorine in refrigerant can cause deterioration of refrigerant oil, etc. We will not be held responsible for mechanical failure, system malfunction, unit breakdown or accidents caused by failure to follow the instructions.

1. Warning for service

- (1) Do not alter the unit.
- (2) For installation and relocation work, follow the instructions in the Installation Manual and use tools and pipe components specifically made for use with refrigerant specified in the outdoor unit installation manual.
- (3) Ask a dealer or an authorized technician to install, relocate and repair the unit.
- (4) This unit should be installed in rooms which exceed the floor space specified in outdoor unit installation manual. Refer to outdoor unit installation manual.
- (5) Refrigerant pipes connection shall be accessible for maintenance purposes.
- (6) If the air conditioner is installed in a small room or closed room, measures must be taken to prevent the refrigerant concentration in the room from exceeding the safety limit in the event of refrigerant leakage. Should the refrigerant leak and cause the concentration limit to be exceeded, hazards due to lack of oxygen in the room may result.
- (7) Keep gas-burning appliances, electric heaters, and other fire sources (ignition sources) away from the location where installation, repair, and other air conditioner work will be performed.
If refrigerant comes into contact with a flame, poisonous gases will be released.
- (8) When installing or relocating, or servicing the air conditioner, use only the specified refrigerant written on outdoor unit to charge the refrigerant lines.
Do not mix it with any other refrigerant and do not allow air to remain in the lines.
If air is mixed with the refrigerant, then it can be the cause of abnormal high pressure in the refrigerant line, and may result in an explosion and other hazards.
- (9) After installation has been completed, check for refrigerant leaks. If refrigerant leaks into the room and comes into contact with the flame of a heater or portable cooking range, poisonous gases will be released.
- (10) Do not use low temperature solder alloy in case of brazing the refrigerant pipes.
- (11) When performing brazing work, be sure to ventilate the room sufficiently. Make sure that there are no hazardous or flammable materials nearby.
When performing the work in a closed room, small room, or similar location, make sure that there are no refrigerant leaks before performing the work.
If refrigerant leaks and accumulates, it may ignite or poisonous gases may be released.
- (12) Do not install the unit in places where refrigerant may build-up or places with poor ventilation such as a semi-basement or a sunken place in outdoor: Refrigerant is heavier than air, and inclined to fall away from the leak source.
- (13) Do not use means to accelerate the defrosting process or to clean, other than those recommended by the manufacturer.
- (14) The appliance shall be stored in a room without continuously operating ignition sources (for example: open flames, an operating gas appliance or an operating electric heater).
- (15) Do not pierce or burn.
- (16) Be aware that refrigerants may not contain an odour.
- (17) Pipe-work shall be protected from physical damage.
- (18) The installation of pipe-work shall be kept to a minimum.
- (19) Compliance with national gas regulations shall be observed.
- (20) Keep any required ventilation openings clear of obstruction.
- (21) Servicing shall be performed only as recommended by the manufacturer.
- (22) The appliance shall be stored in a well-ventilated area where the room size corresponds to the room area as specified for operation.
- (23) Maintenance, service and repair operations shall be performed by authorized technician with required qualification.
- (24) Pipe-work including piping material, pipe routing, and installation shall include protection from physical damage in operation and service, and be in compliance with national and local codes and standards, such as ASHRAE 15, ASHRAE 15.2, IAPMO Uniform Mechanical Code, ICC International Mechanical Code, or CSA B52.
- (25) All field joints shall be accessible for inspection prior to being covered or enclosed.

2. Cautions for service

1. Perform service after recovering the refrigerant left in unit completely.
2. Do not release refrigerant in the air.
3. After completing service, charge the cycle with specified amount of refrigerant.
4. When performing service, install a filter drier simultaneously.
Be sure to use a filter drier for new refrigerant.

3. Additional refrigerant charge

When charging directly from cylinder

1. Check that cylinder for R454B available on the market is a syphon type.
2. Charging should be performed with the cylinder of syphon stood vertically. (Refrigerant is charged from liquid phase.)

4. Cautions for the unit using R454B refrigerant

Basic work procedures are the same as those for conventional units using refrigerant R410A. However, pay careful attention to the following points.

■ Information on servicing

1. Checks to the area

Prior to beginning work on systems containing FLAMMABLE REFRIGERANTS, safety checks are necessary to ensure that the risk of ignition is minimized. For repair to the REFRIGERATING SYSTEM, 2 to 6 below shall be completed prior to conducting work on the system.

2. Work procedure

Work shall be undertaken under a controlled procedure so as to minimize the risk of a flammable gas or vapour being present while the work is being performed.

3. General work area

All maintenance staff and others working in the local area shall be instructed on the nature of work being carried out. Work in confined spaces shall be avoided.

4. Checking for presence of refrigerant

The area shall be checked with an appropriate refrigerant detector prior to and during work, to ensure the technician is aware of potentially toxic or flammable atmospheres. Ensure that the leak detection equipment being used is suitable for use with all applicable refrigerants, i.e. non-sparking, adequately sealed or intrinsically safe.

5. Presence of fire extinguisher

If any hot work is to be conducted on the refrigerating equipment or any associated parts, appropriate fire extinguishing equipment shall be available to hand. Have a dry powder or CO2 fire extinguisher adjacent to the charging area.

6. No ignition sources

No person carrying out work in relation to a REFRIGERATING SYSTEM which involves exposing any pipe work shall use any sources of ignition in such a manner that it may lead to the risk of fire or explosion. All possible ignition sources, including cigarette smoking, should be kept sufficiently far away from the site of installation, repairing, removing and disposal, during which refrigerant can possibly be released to the surrounding space. Prior to work taking place, the area around the equipment is to be surveyed to make sure that there are no flammable hazards or ignition risks. "No Smoking" signs shall be displayed.

7. Ventilated area

Ensure that the area is in the open or that it is adequately ventilated before breaking into the system or conducting any hot work. A degree of ventilation shall continue during the period that the work is carried out. The ventilation should safely disperse any released refrigerant and preferably expel it externally into the atmosphere.

8. Checks to the refrigerating equipment

Where electrical components are being changed, they shall be fit for the purpose and to the correct specification. At all times the manufacturer's maintenance and service guidelines shall be followed. If in doubt, consult the manufacturer's technical department for assistance. The following checks shall be applied to installations using FLAMMABLE REFRIGERANTS:

- the actual REFRIGERANT CHARGE is in accordance with the room size within which the refrigerant containing parts are installed;
- the ventilation machinery and outlets are operating adequately and are not obstructed;
- marking to the equipment continues to be visible and legible. Markings and signs that are illegible shall be corrected;
- refrigerating pipe or components are installed in a position where they are unlikely to be exposed to any substance which may corrode refrigerant containing components, unless the components are constructed of materials which are inherently resistant to being corroded or are suitably protected against being so corroded.

9. Checks to electrical devices

Repair and maintenance to electrical components shall include initial safety checks and component inspection procedures. If a fault exists that could compromise safety, then no electrical supply shall be connected to the circuit until it is satisfactorily dealt with. If the fault cannot be corrected immediately but it is necessary to continue operation, an adequate temporary solution shall be used. This shall be reported to the owner of the equipment so all parties are advised.

Initial safety checks shall include:

- that capacitors are discharged: this shall be done in a safe manner to avoid possibility of sparking;
- that no live electrical components and wiring are exposed while charging, recovering or purging the system;
- that there is continuity of earth bonding.

■ Repairs to sealed components

Sealed electrical components shall be replaced.

■ Repair to intrinsically safe components

Intrinsically safe components must be replaced.

■ Cabling

Check that cabling will not be subject to wear, corrosion, excessive pressure, vibration, sharp edges or any other adverse environmental effects. The check shall also take into account the effects of aging or continual vibration from sources such as compressors or fans.

■ Detection of flammable refrigerants

Under no circumstances shall potential sources of ignition be used in the searching for or detection of refrigerant leaks. A halide torch (or any other detector using a naked flame) shall not be used.

The following leak detection methods are deemed acceptable for all refrigerant systems.

Electronic leak detectors may be used to detect refrigerant leaks but, in the case of FLAMMABLE REFRIGERANTS, the sensitivity may not be adequate, or may need re-calibration. (Detection equipment shall be calibrated in a refrigerant-free area.)

Ensure that the detector is not a potential source of ignition and is suitable for the refrigerant used.

Leak detection equipment shall be set at a percentage of the LFL of the refrigerant and shall be calibrated to the refrigerant employed, and the appropriate percentage of gas (25 % maximum) is confirmed.

Leak detection fluids are also suitable for use with most refrigerants but the use of detergents containing chlorine shall be avoided as the chlorine may react with the refrigerant and corrode the copper pipe-work.

If a leak is suspected, all naked flames shall be removed/extinguished.

If a leakage of refrigerant is found which requires brazing, all of the refrigerant shall be recovered from the system, or isolated (by means of shut off valves) in a part of the system remote from the leak.

■ Removal and evacuation

When breaking into the refrigerant circuit to make repairs - or for any other purpose -conventional procedures shall be used.

However, for flammable refrigerants it is important that best practice be followed, since flammability is a consideration.

The following procedure shall be adhered to:

- safely remove refrigerant following local and national regulations;
- evacuate;
- purge the circuit with inert gas;
- evacuate;
- continuously flush or purge with inert gas when using flame to open circuit; and
- open the circuit.

The refrigerant charge shall be recovered into the correct recovery cylinders if venting is not allowed by local and national codes.

For appliances containing flammable refrigerants, the system shall be purged with oxygen-free nitrogen to render the appliance safe for flammable refrigerants. This process might need to be repeated several times.

Compressed air or oxygen shall not be used for purging refrigerant systems.

For appliances containing flammable refrigerants, refrigerants purging shall be achieved by breaking the vacuum in the system with oxygen-free nitrogen and continuing to fill until the working pressure is achieved, then venting to atmosphere, and finally pulling down to a vacuum.

This process shall be repeated until no refrigerant is within the system. When the final oxygen-free nitrogen charge is used, the system shall be vented down to atmospheric pressure to enable work to take place.

The outlet for the vacuum pump shall not be close to any potential ignition sources, and ventilation shall be available.

■ Charging procedures

In addition to conventional charging procedures, the following requirements shall be followed.

- Ensure that contamination of different refrigerants does not occur when using charging equipment. Hoses or lines shall be as short as possible to minimize the amount of refrigerant contained in them.
- Cylinders shall be kept in an appropriate position according to the instructions.
- Ensure that the REFRIGERATING SYSTEM is earthed prior to charging the system with refrigerant.
- Label the system when charging is complete (if not already).
- Extreme care shall be taken not to overfill the REFRIGERATING SYSTEM.

Prior to recharging the system, it shall be pressure-tested with the appropriate purging gas. The system shall be leak-tested on completion of charging but prior to commissioning. A follow up leak test shall be carried out prior to leaving the site.

■ Decommissioning

Before carrying out this procedure, it is essential that the technician is completely familiar with the equipment and all its detail. It is recommended good practice that all refrigerants are recovered safely. Prior to the task being carried out, an oil and refrigerant sample shall be taken in case analysis is required prior to re-use of recovered refrigerant. It is essential that electrical power is available before the task is commenced.

- Become familiar with the equipment and its operation.
- Isolate system electrically.
- Before attempting the procedure, ensure that:
 - mechanical handling equipment is available, if required, for handling refrigerant cylinders;
 - all personal protective equipment is available and being used correctly;
 - the recovery process is supervised at all times by a competent person;
 - recovery equipment and cylinders conform to the appropriate standards.
- Pump down refrigerant system, if possible.
- If a vacuum is not possible, make a manifold so that refrigerant can be removed from various parts of the system.
- Make sure that cylinder is situated on the scales before recovery takes place.
- Start the recovery machine and operate in accordance with instructions.
- Do not overfill cylinders (no more than 80 % volume liquid charge).
- Do not exceed the maximum working pressure of the cylinder, even temporarily.
- When the cylinders have been filled correctly and the process completed, make sure that the cylinders and the equipment are removed from site promptly and all isolation valves on the equipment are closed off.
- Recovered refrigerant shall not be charged into another REFRIGERATING SYSTEM unless it has been cleaned and checked.

■ Labelling

Equipment shall be labelled stating that it has been de-commissioned and emptied of refrigerant. The label shall be dated and signed. For appliances containing FLAMMABLE REFRIGERANTS, ensure that there are labels on the equipment stating the equipment contains FLAMMABLE REFRIGERANT.

■ Recovery

When removing refrigerant from a system, either for servicing or decommissioning, it is recommended good practice that all refrigerants are removed safely.

When transferring refrigerant into cylinders, ensure that only appropriate refrigerant recovery cylinders are employed. Ensure that the correct number of cylinders for holding the total system charge is available.

All cylinders to be used are designated for the recovered refrigerant and labelled for that refrigerant (i.e., special cylinders for the recovery of refrigerant). Cylinders shall be complete with pressure-relief valve and associated shut-off valves in good working order.

Empty recovery cylinders are evacuated and, if possible, cooled before recovery occurs.

The recovery equipment shall be in good working order with a set of instructions concerning the equipment that is at hand and shall be suitable for the recovery of the flammable refrigerant.


If in doubt, the manufacturer should be consulted. In addition, a set of calibrated weighing scales shall be available and in good working order. Hoses shall be complete with leak-free disconnect couplings and in good condition.

The recovered refrigerant shall be processed according to local legislation in the correct recovery cylinder, and the relevant waste transfer note arranged. Do not mix refrigerants in recovery units and especially not in cylinders.

If compressors or compressor oils are to be removed, ensure that they have been evacuated to an acceptable level to make certain that FLAMMABLE REFRIGERANT does not remain within the lubricant.

The compressor body shall not be heated by an open flame or other ignition sources to accelerate this process. When oil is drained from a system, it shall be carried out safely.

MFZ-KX09NL MFZ-KX12NL MFZ-KX15NL MFZ-KX18NL



4

SPECIFICATIONS

1. Single connection

Indoor model			MFZ-KX09NL	MFZ-KX12NL	MFZ-KX15NL	MFZ-KX18NL
Power supply	V, phase, Hz		208/230, 1, 60			
Disconnect switch	A		15			
Airflow Super High - High - Med. - Low - Quiet	COOL Dry	CFM (m³/min)	417 - 360 - 272 - 198 - 138 (11.8 - 10.2 - 7.7 - 5.6 - 3.9)		431 - 392 - 311 - 254 - 198 (12.2 - 11.1 - 8.8 - 7.2 - 5.6)	491 - 420 - 328 - 254 - 198 (13.9 - 11.9 - 9.3 - 7.2 - 5.6)
	COOL Wet	CFM (m³/min)	354 - 306 - 231 - 168 - 117 (10.0 - 8.7 - 6.5 - 4.8 - 3.3)		366 - 333 - 264 - 216 - 168 (10.4 - 9.4 - 7.5 - 6.1 - 4.8)	417 - 357 - 279 - 216 - 168 (11.8 - 10.1 - 7.9 - 6.1 - 4.8)
	HEAT Dry	CFM (m³/min)	417 - 328 - 254 - 191 - 138 (11.8 - 9.3 - 7.2 - 5.4 - 3.9)		470 - 399 - 328 - 268 - 212 (13.3 - 11.3 - 9.3 - 7.6 - 6.0)	
Sound level Super High - High - Med. - Low - Quiet	Cooling	dB (A)	46 - 41 - 34 - 27 - 21		47 - 43 - 38 - 33 - 28	50 - 45 - 39 - 33 - 28
	Heating	dB (A)	46 - 40 - 34 - 27 - 21		49 - 45 - 40 - 35 - 29	49 - 45 - 40 - 35 - 29
Cond. drain connection O.D.		in. (mm)	5/8 (16)			
Dimensions	W		29-1/2 (750)			
	D	in. (mm)	8-7/16 (215)			
	H		23-5/8 (600)			
Weight		lb. (kg)	33 (15)			
External finish			White			
Control voltage (by built-in transformer)			12 - 24 V DC			

NOTE: Test conditions are based on AHRI 210/240.

2. Multi connection

Indoor model			MFZ-KX09NL	MFZ-KX12NL	MFZ-KX15NL	MFZ-KX18NL
Power supply	V, phase, Hz		208/230, 1, 60			
Disconnect switch		A	15			
Airflow Super High - High - Med. - Low - Quiet	COOL Dry	CFM (m³/min)	275 - 251 - 208 - 173 - 138 (7.8 - 7.1 - 5.9 - 4.9 - 3.9)		374 - 328 - 282 - 237 - 198 (10.6 - 9.3 - 8.0 - 6.7 - 5.6)	
	COOL Wet	CFM (m³/min)	234 - 213 - 177 - 147 - 117 (6.6 - 6.0 - 5.0 - 4.2 - 3.3)		318 - 279 - 240 - 201 - 168 (9.0 - 7.9 - 6.8 - 5.7 - 4.8)	
	HEAT Dry	CFM (m³/min)	343 - 219 - 180 - 159 - 138 (9.7 - 6.2 - 5.1 - 4.5 - 3.9)		470 - 325 - 290 - 254 - 212 (13.3 - 9.2 - 8.2 - 7.2 - 6.0)	
Sound level Super High - High - Med. - Low - Quiet	Cooling	dB (A)	38 - 34 - 30 - 25 - 21		43 - 40 - 36 - 31 - 28	
	Heating	dB (A)	41 - 32 - 27 - 24 - 21		49 - 39 - 36 - 34 - 29	
Cond. drain connection O.D.		in. (mm)	5/8 (16)			
Dimensions	W	in. (mm)	29-1/2 (750)			
	D		8-7/16 (215)			
	H		23-5/8 (600)			
Weight		lb. (kg)	33 (15)			
External finish			White			
Control voltage (by built-in transformer)			12 - 24 V DC			

NOTE: Test conditions are based on AHRI 210/240.

4-1. OPERATING RANGE

(1) POWER SUPPLY

	Rated voltage	Guaranteed voltage (V)
Indoor unit	208/230 V 1 phase 60 Hz	Min. 187 208 230 Max. 253 ----- ----- ----- -----

(2) OPERATION

Mode	Condition	Intake air temperature °F (°C)			
		Indoor		Outdoor	
		DB	WB	DB	WB
Cooling	Standard temperature	80 (26.7)	67 (19.4)	95 (35.0)	—
	Maximum temperature	90 (32.2)	73 (22.8)	115 (46.1)	—
	Minimum temperature	67 (19.4)	57 (13.9)	14 (-10.0)	—
	Maximum humidity	78%		—	
Heating	Standard temperature	70 (21.1)	60 (15.6)	47 (8.3)	43 (6.1)
	Maximum temperature	80 (26.7)	67 (19.4)	75 (23.9)	65 (18.3)
	Minimum temperature	70 (21.1)	60 (15.6)	-13 (-25.0)	-14 (-25.6)

4-2. OUTLET AIR SPEED AND COVERAGE RANGE

1. Single connection

Model	Mode	Function	Airflow CFM (m³/min)	Air speed ft./s. (m/s)	Coverage ft (m)
MFZ-KX09NL MFZ-KX12NL	HEAT	Dry	417 (11.8)	20.3 (6.18)	29.6 (9.04)
	COOL	Dry	417 (11.8)	20.3 (6.18)	29.6 (9.04)
		Wet	354 (10.0)	17.2 (5.26)	25.3 (7.72)
MFZ-KX15NL	HEAT	Dry	470 (13.3)	22.9 (6.97)	33.3 (10.16)
	COOL	Dry	431 (12.2)	21.0 (6.39)	30.6 (9.33)
		Wet	366 (10.4)	17.8 (5.43)	26.2 (7.97)
MFZ-KX18NL	HEAT	Dry	470 (13.3)	22.9 (6.97)	33.3 (10.16)
	COOL	Dry	491 (13.9)	23.9 (7.28)	34.8 (10.59)
		Wet	417 (11.8)	20.3 (6.19)	29.7 (9.05)

- The air coverage range is the figure up to the position where the air speed is 1 ft./sec., when air is blown out horizontally from the unit properly at the High speed position. The coverage range should be used only as a general guideline since it varies depending on the size of the room and furniture arrangement.

2. Multi connection

Model	Mode	Function	Airflow CFM (m³/min)	Air speed ft./s. (m/s)	Coverage ft (m)
MFZ-KX09NL MFZ-KX12NL	HEAT	Dry	343 (9.7)	16.7 (5.09)	24.5 (7.48)
	COOL	Dry	275 (7.8)	13.4 (4.09)	19.8 (6.05)
		Wet	234 (6.6)	11.4 (3.47)	16.9 (5.17)
MFZ-KX15NL MFZ-KX18NL	HEAT	Dry	470 (13.3)	22.9 (6.97)	33.3 (10.16)
	COOL	Dry	374 (10.6)	18.2 (5.55)	26.7 (8.14)
		Wet	318 (9.0)	15.5 (4.72)	22.8 (6.96)


MFZ-KX09NL


MFZ-KX12NL

MFZ-KX15NL

MFZ-KX18NL


Unit: inch (mm)



MFZ-KX09NL - [CA1] MFZ-KX12NL - [CA1] MFZ-KX15NL - [CA1] MFZ-KX18NL - [CA1]


SYMBOL SYMBOLE	NAME NOM
MF	FAN MOTOR MOTEUR DE VENTILATEUR
MV1	HORIZONTAL VANE MOTOR (FRONT) MOTEUR DE L'AILETTE HORIZONTALE (AVANT)
MV2	HORIZONTAL VANE MOTOR (BACK) MOTEUR DE L'AILETTE HORIZONTALE (ARRIÈRE)
MV3	MULTI-FLOW VANE MOTOR MOTEUR D'AILETTE MULTI-FLUX
F11	FUSE (T6.3AL250V) FUSIBLE (T6.3AL250V)
T111	TRANSFORMER TRANSFORMATEUR
TB	TERMINAL BLOCK BORNIER
RT11	ROOM TEMP. THERMISTOR THERMISTANCE DE TEMP. AMBIANTE
RT12	COIL TEMP. THERMISTOR (MAIN) THERMISTANCE DE TEMP. DE BOBINE (PRINCIPALE)
RT13	COIL TEMP. THERMISTOR (SUB) THERMISTANCE DE TEMP. DE BOBINE (SECONDAIRE)
NR11	VARISTOR VARISTANCE
R111	RESISTOR RÉSISTANCE
CN105	IT TERMINAL TERMINAL INFORMATIQUE


NOTES:
1.About the outdoor side electric wiring refer to the outdoor unit electric wiring diagram for servicing.
2.Use copper conductors only. (For field wiring)
3.Symbols below indicate.



REMARQUES :
1.Pour le câblage électronique côté extérieur, se reporter au schéma d'entretien du câblage électronique de l'appareil extérieur.
2.Utiliser des fils d'alimentation en cuivre.
3.Les symboles ont les significations suivantes.




This refrigerant sensor shall only be replaced with manufacturer approved sensor.
Ce capteur de réfrigérant ne doit être remplacé que par un capteur approuvé par le fabricant.


MFZ-KX09NL - [CA2] MFZ-KX12NL - [CA2] MFZ-KX15NL - [CA2] MFZ-KX18NL - [CA2]


SYMBOL SYMBOLE	NAME NOM
MF	FAN MOTOR MOTEUR DE VENTILATEUR
MV1	HORIZONTAL VANE MOTOR MOTEUR À PALETTE HORIZONTAL
MV2	VERTICAL VANE MOTOR MOTEUR À PALETTE VERTICAL
MV3	MULTI-FLOW VANE MOTOR MOTEUR D'AILETTE MULTI-FLUX
F11	FUSE (T6.3AL250V) FUSIBLE (T6.3AL250V)
T111	TRANSFORMER TRANSFORMATEUR
TB	TERMINAL BLOCK BORNIER
RT11	ROOM TEMP. THERMISTOR THERMISTANCE DE TEMP. AMBIANTE
RT12	COIL TEMP. THERMISTOR (MAIN) THERMISTANCE DE TEMP. DE BOBINE (PRINCIPALE)
RT13	COIL TEMP. THERMISTOR (SUB) THERMISTANCE DE TEMP. DE BOBINE (SECONDAIRE)
NR11	VARISTOR VARISTANCE
R111	RESISTOR RÉSISTANCE
CN105	IT TERMINAL TERMINAL INFORMATIQUE

NOTES:
1.About the outdoor side electric wiring refer to the outdoor unit electric wiring diagram for servicing.
2.Use copper conductors only. (For field wiring)
3.Symbols below indicate.



REMARQUES :
1.Pour le câblage électronique côté extérieur, se reporter au schéma d'entretien du câblage électronique de l'appareil extérieur.
2.Utiliser des fils d'alimentation en cuivre.
3.Les symboles ont les significations suivantes.



This refrigerant sensor shall only be replaced with manufacturer approved sensor.
Ce capteur de réfrigérant ne doit être remplacé que par un capteur approuvé par le fabricant.


MFZ-KX09NL

MFZ-KX12NL

MFZ-KX15NL

MFZ-KX18NL

Unit: inch (mm)



8-1. TIMER SHORT MODE

For service, the following set time can be shortened by bridging the timer short mode point on the electronic control P.C. board. The time will be shortened as follows. (Refer to 10-7.)

Set time : 1-minute → 1-second

Set time : 3-minute → 3-second (It takes 3 minutes for the compressor to start operation. However, the starting time is shortened by short circuit-of the timer short mode point.)

8-2. HOW TO SET REMOTE CONTROLLER EXCLUSIVELY FOR A PARTICULAR INDOOR UNIT

A maximum of 4 indoor units with wireless remote controllers can be used in a room.

To operate the indoor units individually with each remote controller, assign a number to each remote controller according to the number of the indoor unit.

This setting can be set only if all the following conditions are met.:


- The remote controller is powered OFF.
- Weekly timer is not set.
- Weekly timer is not being edited.

1. How to modify the electronic control P.C. board

Turn off the power supply before modification. To assign a number to each indoor unit, cut off "JR05" and "JR06" on the electronic control P.C. board as shown in Table 1. (Refer to 10-7.)

Table 1

	JR05	JR06
Unit No. 1	No modification	No modification
Unit No. 2	Cut off JR05	No modification
Unit No. 3	No modification	Cut off JR06
Unit No. 4	Cut off JR05	Cut off JR06



2. How to set the remote controller

- (1) Hold down **[1~4]** button on the remote controller for 2 seconds to enter the pairing mode.
- (2) Press **[1~4]** button again and assign a number for each remote controller.
Each press of **[1~4]** button advances the number in the following order: 1 → 2 → 3 → 4.
- (3) Press **EDIT/SEND SET** button to complete the pairing setting.

8-3. AUTO RESTART FUNCTION


The operation mode, the set temperature, and the fan speed are memorized by the indoor electronic control P.C. board when the indoor unit is controlled with the remote controller. "AUTO RESTART FUNCTION" automatically starts operation in the same mode just before the shutoff of the main power.

Operation

- (1) If the main power has been cut, the operation settings remain.
- (2) After the power is restored, the unit restarts automatically according to the memory.
(However, it takes at least 3 minutes for the compressor to start running.)

How to disable "AUTO RESTART FUNCTION"

- (1) Turn off the main power of the unit.
- (2) Cut the jumper wire to JR77 on the indoor electronic control P.C. board. (Refer to 10-7.)



NOTE:

- The operation settings will be memorized 10 seconds after the indoor unit starts operating with the remote controller.
- If main power is turned off or a power failure occurs while AUTO START/STOP timer is active, the timer setting is cancelled.
- If the unit has been off with the remote controller before power failure, the auto restart function does not work as the power button of the remote controller is off.
- To prevent breaker off due to inrush current at start up, systematize other home appliance not to turn on at the same time.
- When some air conditioners are connected to the same supply system, the starting current of all the compressors may flow simultaneously at restart if they are operated before power failure.

Therefore, the special counter measures are required to prevent the main voltage-drop or the rush of the starting current by adding to the system that allows the units to start one by one.

8-4. APP CONTROL

1. Radio wave usage precautions

For **MFZ-KX09/12/15/18NL** - [CA1]

Contains FCC ID: NKR-MB43

Contains IC: 4441A-MB43

For **MFZ-KX09/12/15/18NL** - [CA2]

Contains FCC ID: NKR-MB20

Contains IC: 4441A-MB20

 CAUTION	
	Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device must not be co-located or operating in conjunction with any other antenna or transmitter.
	This device complies with FCC/IC radiation exposure limits set forth for an uncontrolled environment and meets the FCC radio frequency (RF) Exposure Guidelines and RSS-102 of the IC radio frequency (RF) Exposure rules. This device should be installed and operated keeping the radiator at least 7-7/8 in. (20 cm) or more away from person's body.
	This device complies with part 15 of the FCC Rules and Industry Canada license-exempt RSSs. Operation is subject to the following two conditions: (1) This device may not cause harmful interference; and (2) This device must accept any interference received, including interference that may cause undesired operation.
	NOTE: This device has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: - Reorient or relocate the receiving antenna. - Increase the separation between the equipment and receiver. - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. - Consult the dealer or an experienced radio/TV technician for help.

2. Wireless interface introduction (-[CA1] only)

This wireless interface, communicates the status information and controls the commands from the kumo cloud® by connecting to an indoor unit.

3. Setting up

"Visit <https://www.mitsubishitechinfo.ca/>. Find the link to download the application and create your account. Also refer to the link for more detailed instructions on how to set up the application."

4. When it doesn't connect well

Check the following, and pair the wireless interface and the router.

- Verify that the indoor unit is operational by turning it on and sending a command with the handheld remote controller.
- Verify that the router is connected to the internet.
- Verify that the wireless interface is not located too far away from the router. The signal strength will be shown in the app when attempting to connect.
- Verify that the wireless interface is connected to a 2.4 GHz network or dual band network. The wireless interface cannot be connected to 5 GHz only networks.
- Verify that the number of connected devices to the Router does not exceed the limit.


4-1. Reconnect the Wireless Network

The wireless interface will automatically enter network configuration mode when powered on for the first time. To restart network configuration mode after the timer has expired, follow the steps below using the handheld remote controller

included with the indoor unit. These steps can also be used to connect the wireless interface to a new router when replacing an existing router.

Sending "3" with the remote controller switches the connection mode.

- Press  to stop the operation.
- Hold down the [TEMP]  for 5 seconds.
- Select "3" by pressing [TEMP]  and .
- Point the remote controller toward the indoor unit and press the .



NOTE:

The connection modes and the lighting/blinking state of each mode can change due to an update. Refer to the latest operation manual of the app.


5. Checking the wireless setting status

You can check the transmission conditions with operation indicator lamp on indoor unit. Follow the procedure below when you cannot connect the wireless interface to the wireless network or transmission error occurs.

5-1. Wireless status display mode

- Press  to stop the operation.
- Hold down the [TEMP]  for 5 seconds.
- Select "9" by pressing [TEMP]  and .
- Point the remote controller toward the indoor unit and press the .

- Refer to the operation manual of the app for operation indicator lamp on indoor unit.



NOTE:

- When operating the air conditioner from a position where you cannot see it, check the air conditioner, its surroundings, and the conditions of people in the room in advance.
- When there are people in the room, let them know in advance that you will be operating the air conditioner from a distance.
- Ensure that the router supports the WPA2-AES encryption setting before starting the wireless interface setup.
- The end user should read and accept the terms and conditions of the app service before using this wireless interface.
- Use of the wireless interface implies acceptance of our terms and conditions.
- To complete connection to the app physical access to the access point may be required.
- This wireless interface will not commence transmission of any operational data from the system until the end user registers and accepts the terms and conditions of the Wi-Fi service.
- This wireless interface should not be connected to any Mitsubishi Electric system which is to provide cooling or heating to critical applications.
- Mitsubishi Electric's wireless interface is designed for communication to Mitsubishi Electric's app. Mitsubishi Electric is not responsible for any (i) underperformance of a system or any product; (ii) system or product fault; or (iii) loss or damage to any system or product; which is caused by or arises from connection to and/or use of any third party wireless interface or any third party wireless or Wi-Fi service with Mitsubishi Electric equipment.

The wireless interface uses Open Source Software. To view the Open Source software license(s), please refer to the Licenses.
https://docs.kumocloud.com/software_licenses.pdf

"Wi-Fi", "WPA2" are trademarks or registered trademarks of the Wi-Fi Alliance.

6. Specifications

Wireless interface specifications

For **MFZ-KX09/12/15/18NL** - [CA1]


Wireless LAN-compatible standard	IEEE802.11b/g/n
RF channel	1 ch to 11 ch
Frequency Band	2.4GHz only
Security	WPA2 only
FCC ID	NKR-MB43
IC	4441A-MB43

For **MFZ-KX09/12/15/18NL** - [CA2]

Wireless LAN-compatible standard	IEEE802.11b/g/n
RF channel	1 ch to 11 ch (2412 to 2462 MHz) 0 ch to 39 ch (2402 to 2480 MHz)
Frequency Band	2.4GHz only
Security	WPA2-PSK
FCC ID	NKR-MB20
IC	4441A-MB20

MFZ-KX09NL MFZ-KX12NL MFZ-KX15NL MFZ-KX18NL

WIRELESS REMOTE CONTROLLER, OPTION



* The backlight turns on when using the remote controller.

The backlight goes off if the remote controller is not used for a while.

NOTE: Last setting will be saved after the unit is turned off with the remote controller. The indoor unit beeps when it receives the signal.

INDOOR UNIT DISPLAY SECTION

Operation indicator lamp

The operation indicator at the right side of the indoor unit indicates the operation state.

• The following indication applies regardless of shape of the indication.

Indication	Operation state	Room temperature
● ●	The unit is operating to reach the set temperature	About 4°F (2°C) or more away from set temperature
● ○	The room temperature is approaching the set temperature	About 2 to 4°F (1 to 2°C) from set temperature
● ●	Standby mode (Refer to multi system operation)	—

● Lit ● Blinking ○ Not Lit

9-1. COOL (COOL) OPERATION

- (1) Press OFF/ON (stop/operate) button.
Operation indicator lamp of the indoor unit turns on with a beep tone.
- (2) Select COOL mode with Operation select button.
- (3) Press Temperature buttons TEMP  or  button to select the desired temperature. The setting range is 61 – 88°F (16 – 31°C).

1. Coil frost prevention

The compressor operational frequency is controlled by the temperature of the indoor heat exchanger to prevent the coil from frosting.

When the temperature of the indoor heat exchanger becomes too low, the coil frost prevention mode starts operating. The indoor fan operates at the set speed and the compressor stops. This mode continues until the temperature of the indoor heat exchanger rises.

2. Low outside temperature operation

When the outside temperature is lower, low outside temperature operation starts, and the outdoor fan slows or stops.

3. Indoor fan speed control

When the thermostat turns OFF, the indoor fan operates at the setting fan speed.

9-2. DRY (DRY) OPERATION

- (1) Press OFF/ON (stop/operate) button.
Operation indicator lamp of the indoor unit turns on with a beep tone.
- (2) Select DRY mode with Operation select button.
- (3) The set temperature is determined from the initial room temperature.

1. Coil frost prevention

Coil frost prevention works the same way as that in COOL mode. (9-1.1.)

2. Low outside temperature operation

Low outside temperature operation works the same way as that in COOL mode. (9-1.2.)

3. Indoor fan speed control

Indoor fan speed control works the same way as that in COOL mode. (9-1.3.)

However in AUTO setting, the fan speed changes.

9-3. FAN (FAN) OPERATION

- (1) Press OFF/ON (stop/operate) button.
Operation indicator lamp of the indoor unit turns on with a beep tone.
- (2) Select FAN mode with Operation select button.
- (3) Select the desired fan speed. When AUTO, it becomes Low.

Only the indoor fan operates.

The outdoor unit does not operate.

NOTE: Temperature cannot be set during FAN mode.

9-4. HEAT (HEAT) OPERATION

- (1) Press OFF/ON (stop/operate) button.
Operation indicator lamp of the indoor unit turns on with a beep tone.
- (2) Select HEAT mode with Operation select button.
- (3) Press Temperature buttons TEMP  or  button to select the desired temperature. The setting range is 50 – 88°F (10 – 31°C).

1. Cold air prevention control

When the compressor is not operating or is starting, and the temperature of the indoor heat exchanger and/or the room temperature is low or when defrosting is being done, the indoor fan will stop or rotate at Very Low speed.

2. High pressure protection

The compressor operational frequency is controlled by the temperature of the indoor heat exchanger to prevent the condensing pressure from increasing excessively.

When the temperature of indoor heat exchanger becomes too high, the high pressure protection works.

This mode continues until the temperature of indoor heat exchanger falls.

3. Defrosting

Defrosting starts when the temperature of the outdoor heat exchanger becomes too low.

The compressor stops once, the indoor/outdoor fans stop, the 4-way valve reverses, and the compressor re-starts.

This mode continues until the temperature of the outdoor heat exchanger rises or the fixed time passes.

9-5. AUTO CHANGE OVER ... AUTO MODE OPERATION

Once desired temperature is set, unit operation is switched automatically between COOL and HEAT operation.

1. Mode selection

(1) Initial mode

At first indoor unit operates only indoor fan with outdoor unit off for 3 minutes to detect present room temperature.

Following the conditions below, operation mode is selected.

- ① If the room temperature thermistor RT11 reads more than set temperature, COOL mode is selected.
- ② If the room temperature thermistor RT11 reads set temperature or less, HEAT mode is selected.

(2) Mode change

In case of the following conditions the operation mode is changed.

- ① During cooling operation, if the room temperature remains 4°F (2°C) or lower than the set temperature for approximately 15 minutes, the system switches to heating operation.
- ② During heating operation, if the room temperature remains 4°F (2°C) or higher than the set temperature for approximately 15 minutes, the system switches to cooling operation.

In the other cases than the above conditions, the present operation mode is continued.

NOTE 1: Mode selection is performed when multi standby (refer to **NOTE 2**) is released and the unit starts operation with ON-timer.

NOTE 2: If 2 or more indoor units are operating in multi system, there might be a case that the indoor unit, which is operating in **AUTO** (AUTO), cannot change over the other operating mode (COOL ↔ HEAT) and switches to standby mode.

NOTE 3: At the beginning of AUTO mode, the air flow direction and the fan speed are set to AUTO and the air outlet selection is set to 2 FLOW.


9-6. AUTO VANE OPERATION

1. Horizontal/Vertical vanes (Horizontal/Vertical vanes, Multi-flow vane)

(1) Vane motor drive

These models are equipped with a stepping motors for the horizontal/vertical vanes. The rotating direction, speed, and angle of the motor are controlled by pulse signals (approximately 12 V DC) transmitted from the indoor microprocessor.

(2) The horizontal vane angle and mode change as follows by pressing VANE control () button.



(3) Positioning


The vane presses the vane stopper once to confirm the standard position and then moves to the set angle. Confirming of the standard position is performed in case of follows.

- (a) The power supply turns on
- (b) The operation starts or finishes (including timer operation)
- (c) The test run starts
- (d) The multi-standby starts or finishes
- (e) Every time the vane has swung more than the specified numbers of times
- (f) The horizontal/vertical vanes vane automatically moves in certain intervals to determine its position, and then it returns to set position.
- (g) The vane operates for preventing condensation.

(4) Air outlet selection

The air outlet(s) can be selected by pressing to VANE control () button.

When 2 FLOW is selected, air blows from the top and the front of the unit. When 1 FLOW is selected, air blows only from the top of the unit.



The multi-flow vane is automatically set to the appropriate position.

In HEAT operation, the multi-flow vane automatically changes its position according to the indoor fan speed.

Even if 2 FLOW is selected, air will blow only from the top of the unit in the following conditions:

- During COOL/DRY operation: The room temperature is close to set temperature.
The air conditioner has operated for 0.5 to 1 hour.
- During HEAT operation: The air flow temperature is low. (During defrosting operation, start of operation, etc.)

NOTE:

Movement at the start of the 2 FLOW operation

- COOL/DRY, HEAT operation: It takes 0.5 to 1 minute to start the 2 FLOW operation.
- HEAT operation: When cold air blows out from the air outlet, the multi-flow vane may stop moving for up to 10 minutes until warm air blows out.

(5) VANE AUTO (🌀) mode

In VANE AUTO mode, the microprocessor automatically determines the horizontal vane angle to make the optimum room temperature distribution.

In COOL, DRY and FAN operation

2 FLOW: Vane angle is fixed to position 2.



1 FLOW: Vane angle is fixed to position 1.



In HEAT operation

2 FLOW: Vane angle is fixed to position 2.



1 FLOW: Vane angle is fixed to position 3.



(6) STOP (operation OFF) and ON TIMER standby

In the following cases, the horizontal/vertical vanes return to the closed position.

(a) When OFF/ON (stop/operate) button is pressed (POWER OFF).

(b) When the operation is stopped by the emergency operation.

(c) When ON TIMER is ON standby.

(7) Condensation prevention

During COOL or DRY operation with the vane angle at Angle 3 or 4 when the compressor cumulative operation time exceeds 1 hour, the vane angle automatically changes to Angle 1 for preventing condensation.

(8) SWING (🌀) mode

By selecting SWING mode with VANE control button, the horizontal vane swings vertically.

The remote controller displays "🌀". SWING mode is cancelled when VANE control button is pressed once again.

(9) Cold air prevention in HEAT operation

The horizontal vane position is set to upward.

(10) ECONO COOL (🌿) operation (ECONOmical operation)

When ECONO COOL button is pressed in COOL mode, the set temperature is automatically set 4 °F (2°C) higher by the microprocessor. However, the temperature on the LCD screen on the remote controller is not changed. Also, the horizontal vane swings in various cycle.

SWING operation makes you feel cooler than set temperature. So, even though the set temperature is higher, the air conditioner can keep comfort. As a result, energy can be saved.

To cancel this operation, select a different mode or press one of the following buttons in ECONO COOL operation: ECONO COOL, VANE control, POWERFUL button.

(11) POWERFUL (🔥) operation

The air conditioner automatically adjusts the fan speed and the set temperature, and operates the POWERFUL mode.

The POWERFUL mode is cancelled automatically 15 minutes after operation starts, or when POWERFUL button is pressed once again within 15 minutes after operation starts. The operation mode returns to the mode prior to POWERFUL operation. To cancel this operation manually, select a different mode or press one of the following buttons within 15 minutes after operation starts: OFF/ON (stop/operate), ECONO COOL, FAN speed control, SLEEP or SMART SET button.

9-7. TIMER OPERATION

1. How to set the time

- (1) Check that the current time is set correctly.

NOTE: Timer operation will not work without setting the current time. Initially "0:00" blinks at the current time display of TIME MONITOR, so set the current time correctly with CLOCK button.

How to set the current time

- Press the CLOCK button.
 - Press the TIME set buttons ($\square\wedge$ and $\square\vee$) to set the current time.
 - Each time Increase time button ($\square\wedge$) is pressed, the set time increases by 1 minute, and each time Decrease time button ($\square\vee$) is pressed, the set time decreases by 1 minute.
 - Pressing those buttons longer, the set time increases/decreases by 10 minutes.
 - Press the CLOCK set button.
- (2) Press OFF/ON (stop/operate) button to start the air conditioner.
- (3) Set the time of timer.

ON timer setting

- Press ON TIMER button ($\odot\text{ON}$) during operation.
- Set the time of the timer using TIME set buttons ($\square\wedge$ and $\square\vee$). *

OFF timer setting

- Press OFF TIMER button ($\odot\text{OFF}$) during operation.
- Set the time of the timer using TIME set buttons ($\square\wedge$ and $\square\vee$). *

* Each time Increase time button ($\square\wedge$) is pressed, the set time increases by 10 minutes; each time Decrease time button ($\square\vee$) is pressed, the set time decreases by 10 minutes.

2. To release the timer

To release ON timer, press ON TIMER button ($\odot\text{ON}$).

To release OFF timer, press OFF TIMER button ($\odot\text{OFF}$).


TIMER is cancelled and the display of set time disappears.

PROGRAM TIMER

- OFF timer and ON timer can be used in combination. The set time that is reached first will operate first.
- " $\leftarrow$ " and " $\rightarrow$ " display shows the order of OFF timer and ON timer operation.


(Example 1) The current time is 8:00 PM.

The unit turns off at 11:00 PM, and on at 6:00 AM.



(Example 2) The current time is 11:00 AM.

The unit turns on at 5:00 PM, and off at 9:00 PM.




NOTE: If the main power is turned off or a power failure occurs while ON/OFF timer is activated, the timer setting is cancelled. As these models are equipped with an auto restart function, the air conditioner starts operating with timer cancelled when power is restored.

9-8. WEEKLY TIMER OPERATION

- A maximum of 4 ON or OFF timers can be set for individual days of the week.
- A maximum of 28 ON or OFF timers can be set for a week.

E.g. : Runs at 75°F (24°C) from waking up to leaving home, and runs at 81°F (27°C) from getting home to going to bed on weekdays.

Runs at 81°F (27°C) from waking up late to going bed early on weekends.




NOTE:

- The simple ON/OFF timer setting is available while the weekly timer is on. In this case, the ON/OFF timer has priority over the weekly timer, the weekly timer operation will start again after the simple ON/OFF timer is complete.
- When the weekly timer is set, temperature cannot be set to 50°F (10°C).
- The weekly timer operation and SMART SET operation cannot be used together.


1. How to set the weekly timer

* Make sure that the current time and day are set correctly.


(1) Press **EDIT/SEND** **SET** button to enter the weekly timer setting mode.



(2) Press **DAY** and **1~4** buttons to select setting day and number.



(3) Press **ON/OFF**, **TIME**, and **TEMP** buttons to set ON/OFF, time, and temperature.



* Hold down the button to change the time quickly.

* The temperature can be set between 61°F and 88°F (16°C and 31°C) for weekly timer.

Press **DAY** and **1~4** buttons to continue setting the timer for other days and/or numbers.

- (4) Press  button to complete and transmit the weekly timer setting.



*  which was blinking goes out, and the current time will be displayed.

NOTE:

- Press  button to transmit the setting information of weekly timer to the indoor unit. Point the remote controller toward the indoor unit for 3 seconds.
- When setting the timer for more than one day of the week or one number,  button does not have to be pressed per each setting. Press  button once after all the settings are complete. All the weekly timer settings will be saved.
- Press  button to enter the weekly timer setting mode, and press and hold  button for 5 seconds to erase all weekly timer settings. Point the remote controller toward the indoor unit.

- (5) Press  button to turn the weekly timer on. ( lights.)

- When the weekly timer is on, the day of the week whose timer setting is complete, will light.

Press  button again to turn the weekly timer off. ( goes out.)

NOTE:

The saved settings will not be cleared when the weekly timer is turned off.

2. Checking weekly timer setting

- (1) Press  button to enter the weekly timer setting mode.

*  blinks.

- (2) Press  or  buttons to view the setting of the particular day or number.
- (3) Press  button to exit the weekly timer setting.

NOTE:

When all days of the week are selected to view the settings and a different setting is included among them, --:-- --°F will be displayed.

9-9. SLEEP (S) OPERATION

1. How to set SLEEP operation

- (1) Press OFF/ON (stop/operate) button.
- (2) Select COOL, DRY, HEAT or FAN mode.
- (3) Press SLEEP () button.
- (4) Press Temperature buttons [ (Increase) and  (Decrease)] to set the temperature of SLEEP operation.

Fan speed: AUTO


Horizontal vane: Position set on the remote controller

Operation indicator lamp: Dimly lit

- Once the above procedure is completed, the settings will be saved.
- After the settings are saved, a single push of SLEEP () button during operation activates SLEEP operation with the same settings every time.
- Temperature for SLEEP operation cannot be set during DRY or FAN mode.

Set temperature for SLEEP operation

For about 30 minutes after SLEEP (SLEEP) button is pressed, the set temperature remains as set for the operation running when the SLEEP button is pressed. It will change to the set temperature for SLEEP operation in about 30 minutes. Press SLEEP (SLEEP) button again to return to the previous setting.



NOTE:

- ON/OFF timer is available during SLEEP operation.
- When a preset ON time for the weekly timer arrives during SLEEP operation, the weekly timer operation has priority. SLEEP operation will be cancelled, and the operation set on the weekly timer will start.

2. How to cancel operation

- Press SLEEP (SLEEP) button again.
- The operation returns to the previous settings.
- SLEEP operation is also cancelled when the FAN button is pressed or the operation mode is changed.

NOTE: SLEEP operation and SMART SET operation cannot be set at same time.

9-10. SMART SET (SMART SET) OPERATION

1. How to set SMART SET operation

- (1) Press OFF/ON (stop/operate) button.
- (2) Select COOL, HEAT or ECONO COOL mode.
- (3) Press SMART SET button.
- (4) Set the temperature, fan speed, and airflow direction for SMART SET operation.

NOTE:

- SMART SET operation cannot be selected during DRY or AUTO mode operation.
- The setting range of HEAT mode SMART SET operation is 50 – 88°F (10 – 31°C).
- 2 groups of setting can be saved. (One for COOL/ECONO COOL, one for HEAT)
- SMART SET operation and the weekly timer operation cannot be used together.
- SMART SET operation and SLEEP operation cannot be set at the same time.

2. How to cancel operation

- Press SMART SET button again.
- SMART SET operation can also be cancelled by pressing Operation select button to change the operation mode. The same setting is selected from the next time by simply pressing SMART SET button.

9-11. SELF CLEAN OPERATION

SELF CLEAN operation helps to keep the unit clean by performing FAN operation for about 40 minutes. It is recommended to keep SELF CLEAN operation active at all times.

- (1) Press SELF CLEAN button to activate SELF CLEAN operation.
 - The unit performs SELF CLEAN operation when it is stopped with the OFF/ON (stop/operate) button or OFF timer after COOL/DRY operation. Operation indicator lamp turns on. (Display section)
 - SELF CLEAN operation is not performed when: COOL/DRY is operated less than 3 minutes.
- (2) Press SELF CLEAN button again to deactivate SELF CLEAN operation.
 - Pressing OFF/ON (stop/operate) button does not deactivate SELF CLEAN operation.

NOTE:

- Fan is stopped for the first 3 minutes of SELF CLEAN operation.
- During multi system operation, air from the unit may become warm. In this case, SELF CLEAN operation is cancelled automatically to prevent undesirable rise in room temperature.

9-12. EMERGENCY/TEST OPERATION

In the case of test run operation or emergency operation, use the emergency operation switch on the right side of the indoor unit.

Emergency operation is available when the remote controller is missing or has failed, or when the batteries in the remote controller are running out. The unit will start and operation indicator lamp will light up.

The first 30 minutes of operation is the test run operation. This operation is for servicing. The indoor fan runs at High speed and the temperature control does not work. In COOL/HEAT MODE, the air outlet selection is set to 2 FLOW during the test run operation. However, 2 FLOW operation in HEAT MODE is the same operation as the case that 2 FLOW operation is selection by the remote controller.

After 30 minutes of test run operation, the system shifts to EMERGENCY COOL/HEAT MODE with a set temperature of 75°F (24°C). The fan speed shifts to Medium.

In EMERGENCY COOL/HEAT MODE, the air outlet selection is set to 2 FLOW. 2 FLOW operation is the same operation as the case that 2 FLOW operation is selected by the remote controller.

The coil frost prevention works even in the test run or the emergency operation.

In the test run or emergency operation, the horizontal vane operates in VANE AUTO (Ⓢ) mode.



Emergency operation continues until the emergency operation switch is pressed once or twice or the unit receives any signal from the remote controller. In the latter case, normal operation will start.

NOTE: Do not press the emergency operation switch during normal operation.

Operation mode	COOL/HEAT
Set temperature	75°F (24°C)
Fan speed	Medium
Horizontal vane	Auto
Air outlet	2 FLOW

The operation mode is indicated by the operation indicator lamp as following

Operation indicator lamp




9-13. 3-MINUTE TIME DELAY OPERATION

When the system turns OFF, compressor will not restart for 3 minutes as 3-minute time delay function operates to protect compressor from overload.

9-14. Changing temperature indication (°F/°C)

- The preset unit is °F.
- °F → °C / °C → °F : Press RESET button while Temperature buttons are pressed.



Press RESET button gently using a fine-tipped object.

10-1. CAUTIONS ON TROUBLESHOOTING

1. Before performing troubleshooting, check the following

- 1) Check the power supply voltage.
- 2) Check the indoor/outdoor connecting wire for miswiring.

2. Take care of the following during servicing

- 1) Before servicing the air conditioner, be sure to turn off the main unit first with the remote controller. Then, turn OFF the breaker and/or disconnect the power plug after confirming the horizontal/vertical vanes are closed.
- 2) Be sure to turn off the power supply before removing the front panel, the cabinet, the top panel, and the P.C. board.
- 3) When removing the P.C. board, hold the edge of the board with care NOT to apply stress on the components.
- 4) When connecting or disconnecting the connectors, hold the connector housing. DO NOT pull the lead wires.

<Incorrect>



Lead wiring

<Correct>



Connector housing

3. Troubleshooting procedure


- 1) Check if the operation indicator lamp on the indoor unit is blinking ON and OFF to indicate an abnormality. Check how many times the operation indicator lamp is blinking ON and OFF before starting service work.
- 2) Before servicing, make sure to check all the connectors and terminals are connected properly.
- 3) When the electronic control P.C. board seems to be defective, check for disconnection of the copper foil pattern and burnt or discolored components.
- 4) When troubleshooting, Refer to 10-2, 10-3 and 10-4.

4. How to replace batteries


Weak batteries may cause the remote controller malfunction.

In this case, replace the batteries to operate the remote controller normally.

- ① Remove the front lid and insert batteries. Then reattach the front lid.



- ② Press RESET button with a fine-tipped object before use.



NOTE: 1. If RESET button is not pressed, the remote controller may not operate correctly.

2. This remote controller has a circuit to reset the microprocessor automatically when batteries are replaced.

This function is equipped to prevent the microprocessor from malfunctioning due to the voltage drop caused by the battery replacement.

3. Do not use the leaking batteries.

5. Description of multi system air conditioner

OUTDOOR UNIT: MXZ series

The multi system outdoor unit can be connected to 2 or more indoor units.

- The units do not operate and the operation indicator lamp blinks as shown in the figure below when the total capacity of the indoor units exceed the capacity of the outdoor unit. Do not connect the indoor units beyond the outdoor unit capacity.
- When operating 2 or more indoor units connected to a multi system outdoor unit, set all the indoor units to the same operation mode. If the COOL and the HEAT modes are selected for those indoor units, the indoor unit which has started operation first has a priority. The other indoor units set to the different operation mode later do not start operation and the operation indicator lamp blinks as shown in the figure below.

OPERATION INDICATOR

- | | |
|---|------------------|
|  | Lit (Green) |
|  | Blinking (Green) |
|  | Not Lit |

- When the indoor units start operating while the outdoor unit is in defrost mode, it takes a few minutes (up to 10 minutes) to blow out warm air.
- In the heating operation, the indoor unit that is not in operation may get warm or the refrigerant flow noise may be heard. The reason is that the refrigerant continuously flows; therefore, they are not malfunction.

10-2. FAILURE MODE RECALL FUNCTION AND ERROR CODE DISPLAY MODE

Outline of the function

This air conditioner can memorize the failure which has occurred last time.

Even though LED indication listed on the troubleshooting check table (10-4.) disappears, the memorized failure can be recalled.

Also, error code can be checked on the display of remote controller while the left operation indicator lamp on the indoor unit is blinking.


1. Flow chart of failure mode recall function for the indoor/outdoor unit

Operational procedure

The cause of abnormality cannot be identified because the error code does not appear again.


Setting up the failure mode recall function (Figure 1)



Turn on the power supply.
 <Preparation of the remote controller>
 ① While pressing Operation select button and TEMP $\oplus$ button on the remote controller at the same time, press RESET button.
 ② First, release RESET button.
 Hold down the other 2 buttons for another 3 seconds. Make sure that the indicators on the LCD display shown in Figure 1 have all appeared. ("00" is shown in the display.) Then release the buttons.



An example of error code (00)

Figure 1







NOTE: 1. Make sure to release the failure mode recall function after it is set up, otherwise the unit cannot operate properly.
2. If the abnormal condition is not deleted from the memory, the last abnormal condition is kept memorized.

*1. Regardless of normal or abnormal condition, a short beep is emitted when the signal is received.

*2. Blinking pattern when the indoor unit is abnormal:




*3. Blinking pattern when the outdoor unit is abnormal:



2. Flow chart of error code display mode

This explains how customers can check the error code on their own.
This is included in OPERATING INSTRUCTIONS.

Operational procedure




3. Table of indoor unit failure mode recall function

Left OPERATION INDICATOR lamp	Error code	Abnormal point (Failure mode)	Condition	Remedy
Not blink	00	Normal	—	—
1-time blink every 0.5-second	P1	Room temperature thermistor	The room temperature thermistor short or open circuit is detected every 8 seconds during operation.	Refer to the characteristics of the room temperature thermistor (10-7.).
2-time blink 2.5-second OFF	P2 Pg	Indoor coil thermistor (Main and sub)	The indoor coil thermistor short or open circuit is detected every 8 seconds during operation.	Refer to the characteristics of the main indoor coil thermistor, the sub indoor coil thermistor (10-7.).
3-time blink 2.5-second OFF	E6 E7	Serial signal	The serial signal from outdoor unit is not received for a maximum time of 6 minutes.	- Refer to 10-6.⑩ "How to check miswiring and serial signal error". - Refer to "Check of compressor protector" of outdoor unit service manual.
7-time blink 2.5-second OFF	EE	Combination of indoor and outdoor units	The refrigerant types specified for the indoor and outdoor units do not match.	The refrigerant types specified for the indoor and outdoor units do not match.
11-time blink 2.5-second OFF	Pb	Indoor fan motor	The rotational frequency feedback signal is not emitted for the 12 seconds after the indoor fan is operated.	Refer to 10-6.④ "Check of the indoor fan motor".
12-time blink 2.5-second OFF	Fb	Indoor control system	It cannot properly read data in the nonvolatile memory of the indoor electronic control P.C. board.	Replace the indoor electronic control P.C. board. "EE" error may be detected together with "Fb" error for the outdoor unit. When the indoor and outdoor units are connected in the allowed combination, respond only to "Fb" error.
14-time blink	FL	Refrigerant leakage Abnormal if refrigerant leakage detected by a refrigerant sensor.	1. Refrigerant leaks from the piping or the heat exchanger in the indoor unit. 2. The following items are used around the indoor unit. - Spray (LP gas including Freon, and whose main ingredient is propane and butane) - Aerosol insecticide (including ethanol) - Air spray painting (including dichloromethane) - Charcoal (charcoal fire) - Chemicals (such as ethanol) 3. Refrigerant leaks from piping or heat exchangers, or sensor errors in indoor units in other rooms.	- While the error message is displayed, the indoor unit continues fan operation. - Please turn off the power supply after ventilating the room sufficiently and confirming that there is no ignition source. - Check the indoor unit to detect the part where refrigerant leaks. - Repair the part where refrigerant leaks. - Turn on the power again. - Replace the refrigerant sensor if the problem is not fixed.
	FH	Refrigerant sensor error Abnormal if refrigerant sensor cannot detect errors normally. (Sensor detection)	1. The refrigerant sensor mounted on the indoor unit does not work. 2. The refrigerant sensor is not connected properly or the wire is broken.	- Connect the connector of the refrigerant sensor properly. - Replace the refrigerant sensor.

NOTE: Blinking patterns of this mode differ from the ones of TROUBLESHOOTING CHECK TABLE (10-4.).

10-3. INSTRUCTION OF TROUBLESHOOTING

1. Check of the unit



*1 "Test Run operation" means the operation within 30 minutes after the emergency operation switch is pressed.

*2 There is a possibility that diesel explosion may occur due to the air mixed in the refrigerant circuit.

First, ensure that there are no leakage points on the valves, flare connections, etc. that allow the air to flow into the refrigerant circuit, or no blockage points (e.g. clogged or closed valves) in the refrigerant circuit that cause an increase in pressure.


If there is no abnormal point like above and the system operates cooling and heating modes normally, the indoor thermistor might have a problem, resulting in false detection.

Check both the indoor coil thermistor and the room temperature thermistor, and replace faulty thermistor(s), if any.

NOTE: Do not start the operation again without repair to prevent hazards.

2. Check of Wireless Interface

Follow the procedure below if the air conditioner cannot be monitored or controlled with a device such as a smartphone.



10-4. TROUBLESHOOTING CHECK TABLE

Before taking measures, make sure that the symptom reappears for accurate troubleshooting.

When the indoor unit has started operation and detected an abnormality of the following condition (the first detection after the power on), the indoor fan motor turns off and the operation indicator lamp blinks.


OPERATION INDICATOR



No.	Abnormal point	Operation indicator lamp	Symptom	Condition	Remedy
1	Miswiring or serial signal	Left lamp blinks. 0.5-second ON ●○○●○○●○○ 0.5-second OFF	Indoor unit and outdoor unit do not operate.	The serial signal from the outdoor unit is not received for a maximum of 6 minutes.	• Refer to 10-6.⑥ "How to check miswiring and serial signal error".
2	Indoor coil thermistor Room temperature thermistor	Left lamp blinks. 2-time blink ●○○○○○○○○●○○○○ 2.5-second OFF	Indoor unit and outdoor unit do not operate.	The indoor coil or the room temperature thermistor is short or open circuit.	• Refer to the characteristics of indoor coil thermistor, and the room temperature thermistor on 10-7.
3	Indoor fan motor	Left lamp blinks. 3-time blink ●○○●○○○○○○●○○●○○○○ 2.5-second OFF	Indoor unit and outdoor unit do not operate.	The rotational frequency feedback signal is not emitted during the indoor fan operation.	• Refer to 10-6.⑦ "Check of the indoor fan motor".
4	Indoor control system	Left lamp blinks. 4-time blink ●○○●○○○○○○●○○●○○○○●○○ 2.5-second OFF	Indoor unit and outdoor unit do not operate.	It cannot properly read data in the nonvolatile memory of the indoor electronic control P.C. board.	• Replace the indoor electronic control P.C. board.
5	Outdoor power system	Left lamp blinks. 5-time blink ●○○●○○○○○○●○○●○○○○●○○ 2.5-second OFF	Indoor unit and outdoor unit do not operate.	It consecutively occurs 3 times that the compressor stops for overcurrent protection or start-up failure protection within 1 minute after start-up.	• Refer to "Check of inverter/compressor". Refer to the outdoor unit service manual. Check the stop valve.
6	Outdoor thermistors	Left lamp blinks. 6-time blink ●○○●○○○○○○●○○●○○○○●○○ 2.5-second OFF	Indoor unit and outdoor unit do not operate.	The outdoor thermistors short or open circuit during the compressor operation.	• Refer to "Check of outdoor thermistor". Refer to the outdoor unit service manual.
7	Outdoor control system	Left lamp blinks. 7-time blink ●○○●○○○○○○●○○●○○○○●○○ 2.5-second OFF	Indoor unit and outdoor unit do not operate.	It cannot properly read data in the nonvolatile memory of the inverter P.C. board or the outdoor electronic control P.C. board.	• Replace the inverter P.C. board or the outdoor electronic control P.C. board. Refer to the outdoor unit service manual.
8	Other abnormality	Left lamp blinks. 14-time blink or more ●○○●○○○○○○●○○●○○○○●○○ 2.5-second OFF	Indoor unit and outdoor unit do not operate.	An abnormality other than above mentioned is detected.	• Check the stop valve. • Check the 4-way valve. • Check the abnormality in detail using the failure mode recall function. Refer to the outdoor unit service manual.
9	Outdoor control system	Left lamp lights up. ●	Outdoor unit does not operate.	It cannot properly read data in the nonvolatile memory of the inverter P.C. board or the outdoor electronic control P.C. board.	• Check the blinking pattern of the LED on the inverter P.C. board or the outdoor electronic control P.C. board.
10	Refrigerant leakage (Sensor detection)	Left lamp blinks 3 times, then right lamp lights on. Left lamp ●○○●○○○○○○●○○ Right lamp ○○○○●●●●●○○○ 3.0-second OFF 3.0-second ON	• The buzzer sounds. • FAN operation starts, and the air blows upward from the horizontal vane. • It cannot be controlled by the remote controller.	1. Refrigerant leaks from the piping or the heat exchanger in the indoor unit. 2. The following items are used around the indoor unit. • Spray (LP gas including Freon, and whose main ingredient is propane and butane) • Aerosol insecticide (including ethanol) • Air spray painting (including dichloromethane) • Charcoal (charcoal fire) • Chemicals (such as ethanol) 3. Refrigerant leaks from piping or heat exchangers.	• Press the emergency operation button to turn off the buzzer. • While the error message is displayed, the indoor unit continues fan operation. • Please turn off the power supply after ventilating the room sufficiently and confirming that there is no ignition source. • Check the indoor unit to detect the part where refrigerant leaks. • Repair the part where refrigerant leaks. • Turn on the power again. • Replace the refrigerant sensor if the problem is not fixed.

No.	Abnormal point	Operation indicator lamp	Symptom	Condition	Remedy
11	Refrigerant sensor error	Left lamp blinks twice, then right lamp lights on. Left lamp                                     			


10-5. TROUBLESHOOTING CRITERIA OF MAIN PARTS

Part name	Check method and criteria	Figure				
Room temperature thermistor (RT11)	Measure the resistance with a multimeter.					
Indoor coil thermistor (RT12 (MAIN 1), RT13 (SUB))	Refer to 10-7. "Test point diagram and voltage", "Indoor electronic control P.C. board", for the chart of thermistor.					
Indoor fan motor (MF)	Check 10-6.Ⓐ "Check of the indoor fan motor" and Ⓒ "Check of indoor electronic control P.C. board and indoor fan motor".					
Horizontal vane motor (MV1)	Measure the resistance between the terminals with a multimeter. (Part temperature: 50°F – 86°F (10°C – 30°C)) <table><tr><td>Color of the lead wire</td><td>Normal</td></tr><tr><td>BRN-other one (250 Ω)</td><td>219 Ω – 273 Ω</td></tr></table>	Color of the lead wire	Normal	BRN-other one (250 Ω)	219 Ω – 273 Ω	
Color of the lead wire	Normal					
BRN-other one (250 Ω)	219 Ω – 273 Ω					
Vertical vane motor (MV2)	Measure the resistance between the terminals with a multimeter. (Part temperature: 50°F – 86°F (10°C – 30°C)) <table><tr><td>Color of the lead wire</td><td>Normal</td></tr><tr><td>BRN-other one (250 Ω)</td><td>219 Ω – 273 Ω</td></tr></table>	Color of the lead wire	Normal	BRN-other one (250 Ω)	219 Ω – 273 Ω	
Color of the lead wire	Normal					
BRN-other one (250 Ω)	219 Ω – 273 Ω					
Multi-flow vane motor (MV3)	Measure the resistance between the terminals with a multimeter. (Part temperature: 50°F – 86°F (10°C – 30°C)) <table><tr><td>Color of the lead wire</td><td>Normal</td></tr><tr><td>BRN-other one (350 Ω)</td><td>306 Ω – 382 Ω</td></tr></table>	Color of the lead wire	Normal	BRN-other one (350 Ω)	306 Ω – 382 Ω	
Color of the lead wire	Normal					
BRN-other one (350 Ω)	306 Ω – 382 Ω					


10-6. TROUBLESHOOTING FLOW

A Check of the indoor fan motor

The indoor fan motor error has occurred, and the indoor fan does not operate.




The indoor fan motor error has occurred, and the indoor fan repeats "12-second ON and 30-second OFF" 3 times, and then stops.





B Check of remote controller, display receiver P.C. board and indoor control P.C. board

* Check if the remote controller is exclusive for this air conditioner.




© Check of indoor electronic control P.C. board and the indoor fan motor




When the left lamp of operation indicator lamp blinks ON and OFF in every 0.5-second, outdoor unit does not operate.

D How to check miswiring and serial signal error



E Electromagnetic noise enters into TV sets or radios



10-7. TEST POINT DIAGRAM AND VOLTAGE


MFZ-KX09NL - [CA1]

MFZ-KX12NL - [CA1]

MFZ-KX15NL - [CA1]

MFZ-KX18NL - [CA1]

Indoor electronic control P.C. board



10-7. TEST POINT DIAGRAM AND VOLTAGE


MFZ-KX09NL - [CA2]

MFZ-KX12NL - [CA2]

MFZ-KX15NL - [CA2]

MFZ-KX18NL - [CA2]

Indoor electronic control P.C. board



<Detaching method of the terminal with locking mechanism>

The terminal which has the locking mechanism can be detached as shown below.



There are 2 types of the terminal with locking mechanism.

The terminal without locking mechanism can be detached by pulling it out.

Check the shape of the terminal before detaching.

(1) Slide the sleeve and check if there is a locking lever or not.

(2) The terminal with this connector shown below has the locking mechanism.

**11-1. MFZ-KX09NL MFZ-KX12NL MFZ-KX15NL MFZ-KX18NL**

NOTE: Turn off the power supply before disassembly.

—→: Indicates the visible parts in the photos/figures.

---→: Indicates the invisible parts in the photos/figures.

OPERATING PROCEDURE	PHOTOS/FIGURES
1. Removing the panel (1) Push down the tabs on the both sides of the unit. (2) Open the front panel towards the front and pull it out upwards. (3) Remove the screws of the panel. (4) Open the vertical vane and push the ▼ marks on the top of the panel, and pull the panel toward you. (5) Lift up the panel and remove it from the unit.	Photo 1 Tabs of the unit Photo 2 Push the ▼ marks. Screw of the panel Screw of the panel
2. Removing the electrical box (1) Remove the panel. (Refer to section 1.) (2) Remove the screw of the V.A. clamp cover and remove the V.A. clamp cover. (3) Remove the screw of the electrical cover and remove the electrical cover. (4) Remove the screw of the indoor/outdoor connecting wire, and then the indoor/outdoor connecting wire. (5) Remove the screws of the conduit box, and remove the conduit box. (6) Remove the ground wire connected to the indoor heat exchanger. (Photo 4) (7) Remove the screw of the electrical box. (Photo 5) (8) Disconnect the following connectors on the electronic control P.C. board. • Fan motor connector <CN211> (Photo 5) • Indoor coil thermistor connector <CN112> (Photo 5) (9) Rotate the display receiver P.C. board holder to the right side and disconnect the vane motor relay connector. (Photo 6) (10) Disengage the electrical box from the upper catch and pull out the electrical box from the box.	Photo 3 Screw of the electrical cover Screw of the V.A. clamp cover Conduit box Screws of the conduit box

OPERATING PROCEDURE

3. Removing the electronic control P.C. board and the display receiver P.C. board

- (1) Remove the panel. (Refer to section 1.)
- (2) Remove the electrical box. (Refer to section 2.)
- (3) Remove the ground wire connected to the electronic control P.C. board.
- (4) Disconnect all the connectors on the electronic control P.C. board.
- (5) Pull out the electronic control P.C. board from the electrical box.
- (6) Disengage the catches on the lead guide.
- (7) Disengage the display receiver P.C. board holder from the catch on the electrical box.
- (8) Open the display receiver P.C. board holder and pull out the display receiver P.C. board.

* Attaching the connectors

Run the lead wires with the connectors as they were before the disassembly.

4. Removing the nozzle assembly

- (1) Remove the panel. (Refer to section 1.)
- (2) Rotate the display receiver P.C. board holder to the right side and disconnect the vane motor relay connector.
- (3) Remove the fixed screws on the both sides of the nozzle.
- (4) Disengage the catches on the nozzle from the box.
- (5) Hold the both sides of the nozzle. Rotate the nozzle towards the front around the right and left ribs to remove it.

Photo 7





Photo 8



PHOTOS/FIGURES

Photo 4




Photo 5






Photo 6




How to remove the multi-flow vane and the horizontal/vertical vanes




(1) Removing the horizontal/vertical vanes

(1)-1. See the figure below and push to open the indicated places on the horizontal vane and vertical vane (the places between them) with your fingers so that you can access 4 vane shafts positioned on the back of the horizontal/vertical vanes. (vane shafts on each vane)




(1)-2. Insert a tool such as a precision screwdriver in the opening on the vane shaft and lift the catch of the vane shaft in arrow 1 direction to detach it from the rib on the horizontal/vertical vanes. Slide the vane shaft in arrow 2 direction and separate it from the unit body.



(1)-3. Remove the axial rods on the both ends of the horizontal/vertical vanes from the unit body.


(2) Removing the multi-flow vane

(2)-1. Open the horizontal/vertical vanes by following (1)-1. Make sure that 3 vane shafts are on the back of the multi-flow vane.



Top down view from the back of the unit

(2)-2. Insert a tool such as a precision screwdriver in the gap between the multi-flow vane and the vane shaft, and lift the catch of the vane shaft in the direction of the arrow 1 to detach it from the rib on the multi-flow vane. Slide the vane shaft in the direction of the arrow 2 and separate it from the unit body.



(2)-3. Remove the axial rod on the one end of the multi-flow vane from the unit body.

OPERATING PROCEDURE

5. Removing the horizontal/vertical vane motors

- (1) Remove the panel. (Refer to section 1.)
- (2) Remove the screws of the vane motor support and pull out the vane motor support from the nozzle.
- (3) Remove the screws of the horizontal/vertical vane motors.
- (4) Remove the horizontal/vertical vane motors from the vane motor support.
- (5) Disconnect the connectors from the horizontal/vertical vane motors.


* Installing the horizontal/vertical vane motors

Connect the connectors to the horizontal/vertical vane motors by referring to the colors, red and white, noted on the vane motor support.

6. Removing the multi-flow vane motor unit

- (1) Remove the panel. (Refer to section 1.)
- (2) Disconnect the connector from the multi-flow vane motor unit.
- (3) Remove the screws of the multi-flow vane motor unit and pull out the multi-flow vane motor unit from the nozzle.

Photo 12 Screws of the multi-flow vane motor unit



PHOTOS/FIGURES

Photo 9




Photo 10





Photo 11



OPERATING PROCEDURE

7. Removing the line flow fan and the indoor fan motor

- (1) Remove the panel. (Refer to section 1.)
- (2) Remove the electrical box. (Refer to section 2.)
- (3) Remove the nozzle. (Refer to section 4.)
- (4) Disengage the water cover from the catches. (Photo 9)
- (5) Remove the screws fixing the motor bed.
- (6) Loosen the screw fixing the line flow fan.
- (7) Remove the motor bed together with the indoor fan motor and the motor band.
- (8) Disengage the catches on the motor band and remove the motor band, and pull out the indoor fan motor.
- (9) Remove the screws fixing the both sides of the heat exchanger.
- (10) Disengage the catch on the right side on the heat exchanger.
- (11) Lift the heat exchanger, and pull out the line flow fan upward.

Photo 13

Screw of the line flow fan




Photo 14

Screws of the motor bed




Photo 15

Screws of the heat exchanger





Photo 16



Screw of the heat exchanger

Photo 17

Catches of the heat exchanger



OPERATING PROCEDURE

8. Removing the refrigerant sensor

- (1) Remove the panel. (Refer to section 1.)
- (2) Loosen the screw of the refrigerant sensor plate, and take the refrigerant sensor plate.
- (3) Cut the band fixing the lead wire.
- (4) Disengage the refrigerant sensor cover from the refrigerant sensor plate.
- (5) Disengage the catches to open the refrigerant sensor cover.
- (6) Take the refrigerant sensor, then disconnect the lead wire.

Photo 20





Photo 21



PHOTOS/FIGURES

Photo 18





Photo 19




OPERATING PROCEDURE

9. Removing the Wireless Interface

- (1) Remove the panel. (Refer to section 1.)
- (2) Removing the electrical box. (Refer to section 2.)
- (3) Disconnect the following connectors on the electronic control P.C. board.
 - Indoor coil thermistor connector <CN112>
 - Fan motor connector <CN211>
 - Wireless Interface connector <CN110>
- (4) Remove the releasable cable tie securing the lead wires.
- (5) Cut the cable tie binding the cable of the Wireless Interface.
- (6) Remove the cable of the Wireless Interface from the cable guide of the Wireless Interface holder.
- (7) Remove the Wireless Interface from the Wireless Interface holder.

PHOTOS/FIGURES

Photo 22



Wireless Interface connector (CN110)

Indoor coil thermistor connector (CN112)

Fan motor connector (CN211)

Photo 23



Releasable cable tie securing the lead wires

Cable tie binding the cable of the Wireless Interface

MITSUBISHI ELECTRIC CORPORATION

HEAD OFFICE: TOKYO BUILDING, 2-7-3, MARUNOUCHI, CHIYODA-KU, TOKYO 100-8310, JAPAN

© Copyright 2025 MITSUBISHI ELECTRIC CORPORATION

Issued: Jul. 2026 No. OBH968 REVISED EDITION-B

Issued: Jun. 2025 No. OBH968 REVISED EDITION-A

Published: Jan. 2025 No. OBH968

Made in Japan

Specifications are subject to change without notice.