


STRUCTURAL PARTS

PUZ-A18NHA


PUY-A12NHA

PUY-A18NHA



No.	Part No.				Part Name	Specification	Q'ty/set		Remarks (Drawing No.)	Wiring Diagram Symbol	Recom- mended Q'ty
							PUZ, PUY-A				
							12	18			
							NHA				
1	R01	E10	691	GRILLE		1	1				
2	R01	E02	668	FRONT PANEL		1	1				
3	R01	E16	686	BASE ASSY		1	1				
4	T7W	E00	617	CONDUIT PLATE		1	1				
5	T7W	E03	667	SERVICE PANEL		1	1				
6	R01	E00	518	SERVICE PANEL (FOR CHARGE PLUG)		1	1				
7	T7W	E00	649	CORD COVER		1	1				
8	T7W	E08	682	BACK PANEL		1	1				
9	R01	E23	130	MOTOR SUPPORT		1					
	R01	E21	130	MOTOR SUPPORT			1				
10	R01	E00	684	CONDENSER NET		1					
	R01	E01	684	CONDENSER NET			1				
11	T7W	E01	641	TOP PANEL		1	1				

STRUCTURAL PARTS
PUZ-A24/30/36NHA
PUY-A24/30/36NHA




Part number that is circled is not shown in the figure.

No.	Part No.	Part Name	Specification	Q'ty/set	Remarks (Drawing No.)	Wiring Diagram Symbol	Recom- mended Q'ty
				PUZ, PUY-A 24, 30, 36 NHA			
1	R01 E01 662	SIDE PANEL (L)		1			
2	T7W E02 691	FAN GRILLE		1			
3	T7W E01 667	FRONT PANEL		1			
4	R01 E17 686	BASE ASSY		1			
5	T7W E07 130	MOTOR SUPPORT		1			
6	R01 30L 655	HANDLE		2			
7	R01 E12 658	COVER PANEL (FRONT)		1			
8	R01 E11 658	COVER PANEL (REAR)		1			
9	R01 E03 661	SIDE PANEL (R)		1			
10	T7W E07 668	SERVICE PANEL		1			
11	R01 E00 698	REAR GUARD		1			
12	R01 E04 641	TOP PANEL		1			
13	R01 E00 655	HANDLE		1			
⑭	T7W E01 617	CONDUIT PLATE		1			

STRUCTURAL PARTS

PUZ-A42NHA


PUY-A42NHA



Part number that is circled is not shown in the figure.

No	Part No.	Part Name	Specification	Q'ty/set	Remarks (Drawing No.)	Wiring Diagram Symbol	Recom- mended Q'ty
				PUZ, PUY-A			
				42 NHA			
1	T7W E02 662	SIDE PANEL (L)		1			
2	T7W E02 691	FAN GRILLE		2			
3	T7W E02 667	FRONT PANEL		1			
4	R01 E18 686	BASE ASSY		1			
5	R01 E25 130	MOTOR SUPPORT		1			
6	R01 30L 655	HANDLE		2			
7	R01 E13 658	COVER PANEL (FRONT)		1			
8	R01 E11 658	COVER PANEL (REAR)		1			
9	T7W E15 661	SIDE PANEL (R)		1			
10	T7W E08 668	SERVICE PANEL		1			
11	R01 E01 698	REAR GUARD		1			
12	R01 E04 641	TOP PANEL		1			
13	R01 E00 655	HANDLE		1			
14	T7W E01 617	CONDUIT PLATE		1			


FUNCTIONAL PARTS
PUZ-A18NHA
PUY-A12NHA
PUY-A18NHA



Part numbers that are circled are not shown in the figure.

No.	Part No.				Part Name	Specification	Q'ty/set			Remarks (Drawing No.)	Wiring Diagram Symbol	Recom- mended Q'ty
							PUZ-A 18	PUY-A				
								12	18			
1	R01	E40	221	FAN MOTOR		1	1	1		MF1		
2	R01	E02	115	PROPELLER FAN		1	1	1				
3	R01	E04	097	NUT		1	1	1				
4	R01	E07	201	THERMISTOR (DISCHARGE)		1	1	1		TH4		
5	T92	570	280	COMPRESSOR	SNB130FPBM1 Including RUBBER MOUNT	1	1	1		MC		
6	R01	30L	450	STRAINER		1	1	1				
7	T7W	E03	410	STOP VALVE (GAS)	1/2	1	1	1				
8	R01	E08	411	STOP VALVE (LIQUID)	1/4	1	1	1				
9	R01	E56	202	THERMISTOR (OUTDOOR PIPE)		1		1		TH3		
	R01	E78	202	THERMISTOR (OUTDOOR PIPE)			1			TH3		
10	R01	E32	440	ACCUMULATOR		1	1	1				
11	R01	E75	401	EXPANSION VALVE		1	1	1				
12	R01	E36	242	LINEAR EXPANSION VALVE COIL		1	1	1		LEV-A		
13	R01	E12	413	CHARGE PLUG		1	1	1				
14	T7W	E05	208	HIGH PRESSURE SWITCH		1	1	1		63H		
15	R01	E69	202	THERMISTOR (OUTDOOR 2-PHASE PIPE, OUTDOOR)		1	1	1		TH6,7		
16	R01	E25	403	FOUR-WAY VALVE		1						
17	T7W	E14	242	SOLENOID VALVE COIL (FOUR-WAY VALVE)		1				21S4		
18	T7W	E25	716	TERMINAL BLOCK	6P(L1,L2,GR,S1,S2,S3)	1	1	1		TB1		
19	T7W	E34	315	CONTROLLER CIRCUIT BOARD		1	1	1		C.B.		
20	R01	E06	259	REACTOR		1	1	1		ACL		
21	T7W	E11	346	NOISE FILTER		1	1	1		N.F.		
22	T7W	E19	313	POWER CIRCUIT BOARD		1	1	1		P.B.		
23	T7W	E35	408	HEAT EXCHANGER			1					
	T7W	E28	408	HEAT EXCHANGER		1		1				
24	T7W	E04	467	MUFFLER		1						
25	R01	E65	202	THERMISTOR (HEATSINK)		1	1	1		TH8		

FUNCTIONAL PARTS
PUZ-A24/30/36NHA
PUY-A24/30/36NHA




These figures show about
 PUZ-A30/36NHA.

Part numbers that are circled are not shown in the figure.

No.	Part No.				Part Name	Specification	Q'ty/set				Remarks (Drawing No.)	Wiring Diagram Symbol	Recom- mended Q'ty	
							PUZ-A		PUY-A					
							24	30,36	24	30,36				
								NHA						
1	T7W	E28	763	FAN MOTOR		1	1	1	1		MF1			
2	R01	E01	115	PROPELLER FAN		1	1	1	1					
3	R01	E02	097	NUT		1	1	1	1					
4	T7W	E20	242	SOLENOID VALVE COIL <FOUR-WAY VALVE>		1	1				21S4			
5	T7W	E19	242	SOLENOID VALVE COIL <BYPASS VALVE>		1	1	1	1		SV			
6	R01	E12	413	CHARGE PLUG		2	2	1	1					
7	R01	E11	428	BYPASS VALVE		1	1	1	1					
8	T92	501	801	COMPRESSOR	TNB220FLDM Including RUBBER MOUNT	1	1	1	1		MC			
9	T7W	E04	410	STOP VALVE	3/8	1	1	1	1					
10	R01	E01	411	BALL VALVE	5/8	1	1	1	1					
11	R01	E30	440	ACCUMULATOR		1	1	1	1					
12	R01	E03	450	STRAINER		1	1	1	1					
13	R01	30W	413	CHARGE PLUG				1	1					
14	R01	E54	401	EXPANSION VALVE		1	1	1	1					
15	T7W	E22	242	LINEAR EXPANSION VALVE COIL		1	1	1	1		LEV-A			
16	R01	E23	403	FOUR-WAY VALVE		1	1							
17	T7W	E43	202	THERMISTOR (OUTDOOR 2-PHASE PIPE, OUTDOOR)		1	1	1	1		TH6,7			
18	T7W	E06	255	FAN CAPACITOR	3.5μF 440V	1	1	1	1		C1			
19	T7W	E01	234	RESISTOR			1		1		RS			
20	T7W	E26	716	TERMINAL BLOCK	6P(L1,L2,GR,S1,S2,S3)	1	1	1	1		TB1			
21	T7W	E09	259	REACTOR			1		1		DCL			
22	T7W	E20	313	POWER CIRCUIT BOARD		1		1			P.B.			
	T7W	E25	313	POWER CIRCUIT BOARD			1		1		P.B.			
23	T7W	E01	233	ACT MODULE			1		1		ACTM			
24	T7W	E13	346	NOISE FILTER CIRCUIT BOARD		1		1			N.F.			
	T7W	E14	346	NOISE FILTER CIRCUIT BOARD			1		1		N.F.			
25	T7W	E35	315	CONTROLLER CIRCUIT BOARD		1	1	1	1		C.B.			
26	T7W	E36	408	HEAT EXCHANGER		1		1						
	T7W	E37	408	HEAT EXCHANGER			1		1					
27	R01	17T	201	THERMISTOR (DISCHARGE)		1	1	1	1		TH4			
28	T7W	E05	208	HIGH PRESSURE SWITCH		1	1	1	1		63H			
29	R01	E17	259	REACTOR		1		1			ACL			
30	R01	E65	202	THERMISTOR (HEATSINK)		1	1	1	1		TH8			
31	T7W	E04	467	MUFFLER		1	1							
32	T7W	E02	259	52C Relay			1		1		52C			
33	R01	E71	202	THERMISTOR (OUTDOOR PIPE)		1		1			TH3			
	R01	E78	202	THERMISTOR (OUTDOOR PIPE)			1		1		TH3			

FUNCTIONAL PARTS
PUZ-A42NHA
PUY-A42NHA




Part numbers that are circled are not shown in the figures.

No.	Part No.				Part Name	Specification	Q'ty/set		Remarks (Drawing No.)	Wiring Diagram Symbol	Recom- mended Q'ty
							PUZ-A	PUY-A			
							42				
							NHA				
1	R01	E44	221	FAN MOTOR		2	2		MF1,2		
2	R01	E01	115	PROPELLER FAN		2	2				
3	R01	E02	097	NUT		2	2				
4	T7W	E38	408	HEAT EXCHANGER		1	1				
5	T7W	E21	242	SOLENOID COIL <FOUR-WAY VALVE>		1			21S4		
6	T7W	E05	403	FOUR-WAY VALVE		1					
7	T7W	E05	467	MUFFLER		1					
8	R01	17T	201	THERMISTOR (DISCHARGE)		1	1		TH4		
9	T7W	E04	410	STOP VALVE	3/8	1	1				
10	T97	410	740	COMPRESSOR	ANV33FDDMT Including RUBBER MOUNT	1	1		MC		
11	R01	E31	440	ACCUMULATOR		1	1				
12	R01	E01	411	BALL VALVE	5/8	1	1				
13	R01	E03	450	STRAINER		1	1				
14	R01	E13	413	CHARGE PLUG		1	1				
15	R01	E55	401	EXPANSION VALVE		1	1				
16	T7W	E22	242	LINEAR EXPANSION VALVE COIL		1	1		LEV-A		
17	T7W	E05	208	HIGH PRESSURE SWITCH		1	1		63H		
18	R01	30W	413	CHARGE PLUG		1	1				
19	T7W	E43	202	THERMISTOR (OUTDOOR 2-PHASE PIPE, OUTDOOR)		1	1		TH6,7		
20	T7W	E26	716	TERMINAL BLOCK	6P(L1,L2,GR,S1,S2,S3)	1	1		TB1		
21	T7W	E02	259	52C RELAY		1	1		52C		
22	T7W	E01	234	RESISTOR		1	1		RS		
23	T7W	E09	259	REACTOR		1	1		DCL		
24	T7W	E21	313	POWER CIRCUIT BOARD		1	1		P.B.		
25	T7W	E36	315	CONTROLLER CIRCUIT BOARD		1	1		C.B.		
26	R01	E65	202	THERMISTOR (HEATSINK)		1	1		TH8		
27	T7W	E01	233	ACTIVE FILTER MODULE		1	1		ACTM		
28	T7W	E14	346	NOISE FILTER CIRCUIT BOARD		1	1		N.F.		
29	R01	25T	209	LOW PRESSURE SWITCH		1	1		63L		
30	R01	E66	202	THERMISTOR (OUTDOOR PIPE)		1	1		TH3		
31	T7W	E09	254	MAIN SMOOTHING CAPACITOR		1	1		CB		

FUNCTIONAL PARTS

PUZ-A18NHA


PUZ-A18NHA-BS

PUY-A12NHA₁PUY-A12NHA₁-BSPUY-A18NHA₁PUY-A18NHA₁-BS

Part numbers that are circled are not shown in the figure.

No.	RoHS	Part No.	Part Name	Specification	Q'ty/set			Remarks (Drawing No.)	Wiring Diagram Symbol	Recom- mended Q'ty
					PUZ-A	PUY-A				
					18	12	18			
					NHA (-BS)	NHA ₁ (-BS)				
1	G	R01 E47 221	FAN MOTOR		1	1	1		MF1	
2	G	R01 E07 115	PROPELLER FAN		1	1	1			
3	G	R01 E08 097	NUT		1	1	1			
4	G	R01 E08 201	THERMISTOR (DISCHARGE)		1	1	1		TH4	
5	G	T92 570 280	COMPRESSOR	SNB130FPBM1 Including RUBBER MOUNT	1	1	1		MC	
6	G	R01 31L 450	STRAINER		1	1	1			
7	G	T7W E03 410	STOP VALVE (GAS)	1/2	1	1	1			
8	G	R01 E10 411	STOP VALVE (LIQUID)	1/4	1	1	1			
9	G	R01 N01 202	THERMISTOR (OUTDOOR PIPE)			1			TH3	
	G	R01 E98 202	THERMISTOR (OUTDOOR PIPE)		1		1		TH3	
10	G	R01 E45 440	ACCUMULATOR		1	1	1			
11	G	R01 E75 401	EXPANSION VALVE		1	1	1			
12	G	R01 E36 242	LINEAR EXPANSION VALVE COIL		1	1	1		LEV-A	
13	G	R01 E12 413	CHARGE PLUG		1	1	1			
14	G	T7W E07 208	HIGH PRESSURE SWITCH		1	1	1		63H	
15	G	R01 E97 202	THERMISTOR (OUTDOOR 2-PHASE PIPE, OUTDOOR)		1	1	1		TH6,7	
16	G	R01 E30 403	FOUR-WAY VALVE		1					
17	G	T7W E33 242	SOLENOID VALVE COIL (FOUR-WAY VALVE)		1				21S4	
18	G	T7W E39 716	TERMINAL BLOCK	6P(L1,L2,GR,S1,S2,S3)	1	1	1		TB1	
19	G	T7W E46 315	CONTROLLER CIRCUIT BOARD		1	1	1		C.B.	
20	G	R01 E22 259	REACTOR		1	1	1		ACL	
21	G	T7W E17 346	NOISE FILTER		1	1	1		N.F.	
22	G	T7W E34 313	POWER CIRCUIT BOARD		1	1	1		P.B.	
23	G	T7W E35 408	HEAT EXCHANGER			1				
	G	T7W E40 408	HEAT EXCHANGER		1		1			
24	G	T7W E04 467	MUFFLER		1					
25	G	R01 E99 202	THERMISTOR (HEATSINK)		1	1	1		TH8	

FUNCTIONAL PARTS
PUZ-A24/30/36NHA
PUZ-A24/30/36NHA-BS
PUY-A24/30/36NHA₁
PUY-A24/30/36NHA₁-BS



These figures show about
 PUZ-A30/36NHA(-BS).

Part numbers that are circled are not shown in the figure.

No.	RoHS	Part No.	Part Name	Specification	Q'ty/set				Remarks (Drawing No.)	Wiring Diagram Symbol	Recom- mended Q'ty
					PUZ-A		PUY-A				
					24 NHA(-BS)	30, 36	24 NHA ₁ (-BS)	30, 36			
1	G	T7W E28 763	FAN MOTOR		1	1	1	1		MF1	
2	G	R01 E08 115	PROPELLER FAN		1	1	1	1			
3	G	R01 E09 097	NUT		1	1	1	1			
4	G	T7W E20 242	SOLENOID VALVE COIL <FOUR-WAY VALVE>		1	1				21S4	
5	G	T7W E19 242	SOLENOID VALVE COIL <BYPASS VALVE>		1	1	1	1		SV	
6	G	R01 E12 413	CHARGE PLUG		2	2	1	1			
7	G	R01 E13 428	BYPASS VALVE		1	1	1	1			
8	G	T92 506 801	COMPRESSOR	TNB220FLDM Including RUBBER MOUNT	1	1	1	1		MC	
9	G	T7W E04 410	STOP VALVE	3/8	1	1	1	1			
10	G	R01 E12 411	BALL VALVE	5/8	1	1	1	1			
11	G	R01 E46 440	ACCUMULATOR		1	1	1	1			
12	G	R01 E06 450	STRAINER		1	1	1	1			
13	G	R01 E15 413	CHARGE PLUG				1	1			
14	G	R01 H22 401	EXPANSION VALVE		1	1	1	1			
15	G	R01 E50 242	LINEAR EXPANSION VALVE COIL		1	1	1	1		LEV-A	
16	G	R01 E28 403	FOUR-WAY VALVE		1	1					
17	G	R01 E94 202	THERMISTOR (OUTDOOR 2-PHASE PIPE, OUTDOOR)		1	1	1	1		TH6,7	
18	G	T7W E14 255	FAN CAPACITOR	3.5 μ F 440V	1	1	1	1		C1	
19	G	R01 E00 234	RESISTOR			1		1		RS	
20	G	T7W E40 716	TERMINAL BLOCK	6P(L1,L2,GR,S1,S2,S3)	1	1	1	1		TB1	
21	G	T7W E09 259	REACTOR			1		1		DCL	
22	G	T7W E29 313	POWER CIRCUIT BOARD		1		1			P.B.	
	G	T7W E36 313	POWER CIRCUIT BOARD			1		1		P.B.	
23	G	T7W E01 233	ACT MODULE			1		1		ACTM	
24	G	T7W E18 346	NOISE FILTER CIRCUIT BOARD		1		1			N.F.	
	G	T7W E16 346	NOISE FILTER CIRCUIT BOARD			1		1		N.F.	
25	G	T7W E47 315	CONTROLLER CIRCUIT BOARD		1	1	1	1		C.B.	
26	G	T7W E36 408	HEAT EXCHANGER		1		1				
	G	T7W E37 408	HEAT EXCHANGER			1		1			
27	G	R01 E09 201	THERMISTOR (DISCHARGE)		1	1	1	1		TH4	
28	G	T7W E07 208	HIGH PRESSURE SWITCH		1	1	1	1		63H	
29	G	R01 E22 259	REACTOR		1		1			ACL	
30	G	R01 E99 202	THERMISTOR (HEATSINK)		1	1	1	1		TH8	
31	G	T7W E04 467	MUFFLER		1	1					
32	G	T7W E10 259	52C Relay			1		1		52C	
33	G	R01 N03 202	THERMISTOR (OUTDOOR PIPE)		1		1			TH3	
	G	R01 N01 202	THERMISTOR (OUTDOOR PIPE)			1		1		TH3	


FUNCTIONAL PARTS

PUZ-A42NHA

PUZ-A42NHA-BS

PUY-A42NHA

PUY-A42NHA-BS



Part numbers that are circled are not shown in the figures.

No.	RoHS	Part No.			Part Name	Specification	Q'ty/set		Remarks (Drawing No.)	Wiring Diagram Symbol	Recom- mended Q'ty
							PUZ-A	PUY-A			
							42				
							NHA,NHA-BS				
1	G	R01	E44	221	FAN MOTOR		2	2		MF1,2	
2	G	R01	E08	115	PROPELLER FAN		2	2			
3	G	R01	E09	097	NUT		2	2			
4	G	T7W	E38	408	HEAT EXCHANGER		1	1			
5	G	T7W	E21	242	SOLENOID COIL <FOUR-WAY VALVE>		1			21S4	
6	G	T7W	E05	403	FOUR-WAY VALVE		1				
7	G	T7W	E05	467	MUFFLER		1				
8	G	R01	E09	201	THERMISTOR (DISCHARGE)		1	1		TH4	
9	G	T7W	E04	410	STOP VALVE	3/8	1	1			
10	G	T97	410	740	COMPRESSOR	ANV33FDDMT Including RUBBER MOUNT	1	1		MC	
11	G	R01	E47	440	ACCUMULATOR		1	1			
12	G	R01	E12	411	BALL VALVE	5/8	1	1			
13	G	R01	E06	450	STRAINER		1	1			
14	G	R01	E13	413	CHARGE PLUG		1	1			
15	G	R01	H20	401	EXPANSION VALVE		1	1			
16	G	R01	E50	242	LINEAR EXPANSION VALVE COIL		1	1		LEV-A	
17	G	T7W	E07	208	HIGH PRESSURE SWITCH		1	1		63H	
18	G	R01	E15	413	CHARGE PLUG		1	1			
19	G	R01	E94	202	THERMISTOR (OUTDOOR 2-PHASE PIPE, OUTDOOR)	6P(L1,L2,GR,S1,S2,S3)	1	1		TH6,7	
20	G	T7W	E40	716	TERMINAL BLOCK		1	1		TB1	
21	G	T7W	E10	259	52C RELAY		1	1		52C	
22	G	R01	E00	234	RESISTOR		1	1		RS	
23	G	T7W	E09	259	REACTOR		1	1		DCL	
24	G	T7W	E30	313	POWER CIRCUIT BOARD		1	1		P.B.	
25	G	T7W	E36	315	CONTROLLER CIRCUIT BOARD		1	1		C.B.	
26	G	R01	E99	202	THERMISTOR (HEATSINK)		1	1		TH8	
27	G	T7W	E01	233	ACTIVE FILTER MODULE		1	1		ACTM	
28	G	T7W	E16	346	NOISE FILTER CIRCUIT BOARD		1	1		N.F.	
29	G	R01	E00	209	LOW PRESSURE SWITCH		1	1		63L	
30	G	R01	H00	202	THERMISTOR (OUTDOOR PIPE)		1	1		TH3	
31	G	R01	E20	254	MAIN SMOOTHING CAPACITOR		1	1		CB	

STRUCTURAL PARTS

PUZ-A18NHA


PUZ-A18NHA-BS

PUY-A12NHA₁

PUY-A12NHA₁-BS


PUY-A18NHA₁

PUY-A18NHA₁-BS



No.	RoHS	Part No.			Part Name	Specification	Q'ty/set		Remarks (Drawing No.)	Wiring Diagram Symbol	Recom- mended Q'ty
							PUZ-A-NHA(-BS) PUY-A-NHA1(-BS)				
							12	18			
1	G	R01	E30	691	GRILLE		1	1			
2	G	R01	E09	668	FRONT PANEL		1	1			
3	G	R01	E34	686	BASE ASSY		1	1			
4	G	T7W	E00	617	CONDUIT PLATE		1	1			
5	G	T7W	E03	667	SERVICE PANEL		1	1			
6	G	R01	E02	518	SERVICE PANEL (FOR CHARGE PLUG)		1	1			
7	G	T7W	E00	649	CORD COVER		1	1			
8	G	T7W	E08	682	BACK PANEL		1	1			
9	G	R01	E32	130	MOTOR SUPPORT		1				
	G	R01	E29	130	MOTOR SUPPORT			1			
10	G	R01	E03	684	CONDENSER NET		1				
	G	R01	E02	684	CONDENSER NET			1			
11	G	T7W	E05	641	TOP PANEL		1	1			

STRUCTURAL PARTS
PUZ-A24/30/36NHA(-BS)
PUY-A24/30/36NHA₁(-BS)



Part number that is circled is not shown in the figure.

No.	RoHS	Part No.	Part Name	Specification	Q'ty/set	Remarks (Drawing No.)	Wiring Diagram Symbol	Recom- mended Q'ty
					PUZ-A-NHA(-BS) PUY-A-NHA ₁ (-BS)			
					24, 30, 36			
1	G	R01 E16 662	SIDE PANEL (L)		1			
2	G	T7W E03 691	FAN GRILLE		1			
3	G	T7W E05 667	FRONT PANEL		1			
4	G	R01 E33 686	BASE ASSY		1			
5	G	T7W E07 130	MOTOR SUPPORT		1			
6	G	R01 E01 655	HANDLE		2			
7	G	R01 E12 658	COVER PANEL (FRONT)		1			
8	G	R01 E11 658	COVER PANEL (REAR)		1			
9	G	R01 E31 661	SIDE PANEL (R)		1			
10	G	T7W E07 668	SERVICE PANEL		1			
11	G	R01 E06 698	REAR GUARD		1			
12	G	R01 E14 641	TOP PANEL		1			
13	G	R01 E02 655	HANDLE		1			
⑭	G	T7W E01 617	CONDUIT PLATE		1			


STRUCTURAL PARTS

PUZ-A42NHA

PUZ-A42NHA-BS

PUY-A42NHA

PUY-A42NHA-BS



Part number that is circled is not shown in the figure.

No	RoHS	Part No.	Part Name	Specification	Q'ty/set	Remarks (Drawing No.)	Wiring Diagram Symbol	Recom- mended Q'ty
					PUZ, PUY-A			
					42 NHA, NHA-BS			
1	G	T7W E03 662	SIDE PANEL (L)		1			
2	G	T7W E03 691	FAN GRILLE		2			
3	G	T7W E06 667	FRONT PANEL		1			
4	G	R01 E31 686	BASE ASSY		1			
5	G	R01 E27 130	MOTOR SUPPORT		1			
6	G	R01 E01 655	HANDLE		2			
7	G	R01 E13 658	COVER PANEL (FRONT)		1			
8	G	R01 E11 658	COVER PANEL (REAR)		1			
9	G	R01 E34 661	SIDE PANEL (R)		1			
10	G	T7W E08 668	SERVICE PANEL		1			
11	G	R01 E07 698	REAR GUARD		1			
12	G	R01 E14 641	TOP PANEL		1			
13	G	R01 E02 655	HANDLE		1			
⑭	G	T7W E01 617	CONDUIT PLATE		1			

Mr. SLIM™



HEAD OFFICE : TOKYO BLDG., 2-7-3, MARUNOUCHI, CHIYODA-KU, TOKYO 100-8310, JAPAN

©Copyright 2006 MITSUBISHI ELECTRIC ENGINEERING CO., LTD.
Distributed in Jun. 2007 No.OC367 REVISED EDITION-C PDF 9
Distributed in Nov. 2006 No.OC367 REVISED EDITION-B PDF 9
Distributed in Aug. 2006 No.OC367 REVISED EDITION-A PDF 9
Distributed in Feb. 2006 No.OC367 PDF 10
Made in Japan

New publication, effective Jun. 2007
Specifications subject to change without notice