

# Package air conditioner Optional parts Installation Manual for Windscreen

### Always observe for safety

- Carefully read this section [Always observe for safety] and securely install the optional parts.
- Be sure to observe the cautions described here: They include critical contents for safety.
- The following indications show the classifications for danger, and possible consequences following incorrect handling.

 ⚠ WARNING
 Incorrect handling could lead to death or serious injury.

 ⚠ CAUTION
 Incorrect handling could lead to injury or damage to house and household articles.

■ After installation perform a test run and make sure that there is no abnormality and ask your customer to keep this installation sheet with the instruction manual at all times. Also ask the customer to transfer these manuals to a new user if the user changes.

## **! WARNING**

#### Ask the dealer or specialist for installation

■ If installed incorrectly by the user, water leak, electric shock, fire, etc. could result

Carefully install the panel according to this installation sheet

■ Incorrect installation could cause water leak, electric shock, fire,etc.

#### Before performing installation (moving) and electrical work:

# **!** CAUTION

#### Do not place polyethylene bags in reach of young children

■ Putting them over the head will block breathing passages, which could result in suffocation.

If electrical work is necessary, use only specified electric wires adapted with current capacity

■ Use of unsuitable wire could cause electric leak, overheating or fire.

Securely apply heat insulation to refrigerant pipe so that no condensation occurs

If heat-insulation is inadequate, condensation could occur on the surface of pipes and dewdrops could accumulate on ceiling, floor or important goods. Securely perform drain piping work according to the installation manual so that no condensation occurs.

If piping work is incorrect, water leak may occur and ceiling, furniture, etc. may get wet.

This Air Guide prevents reverse rotation of outdoor unit fan when it enters low speed rotation mode with fan controller being operated. It is also used for protection of fan when strong winds, such as in typhoon, wind blowing through tall buildings, etc., strike directly the air outlet. In addition, installation of this product is necessary when cooling operation is to be performed in outside-air temperature of -5° C or lower (down to -15°C).

Pay attention to the following points when installing this product:

- 1) To eliminate the effects of external winds, be sure to install this unit with back surface facing wall side.
- 2) Do not install this unit in such orientation where wind blows directly at the back of the unit.
- 3) Installation of this product will reduce the capacity of the unit (approx. 2 or 3%) and increase the noise of outdoor unit (approx 1 or 2dB)
- 4) Do not use this product where there is any obstacle at either side or above the outdoor unit (discharged air will be blocked). This may cause a short cycle.

#### 1 Checking parts

#### Make sure that all the following parts, in addition to this manual, are in this box:

Front Panel <b>1</b>		Side Panel	2	Corner gusset	2	Blocker	1	Insta	allation Hardware	
								SPECIAL SCREW 6 PCS	14 PCS 2 PCS  2 PCS 2 PCS 2 PCS	



## PSD-24-30 (SIDE WINDSCREEN)

### **INSTALLATION PROCEDURE**

#1 - Install the side panels as shown with special screws (6 pcs) provided.



#4 - Secure Safety Cables to the Cabinet chassis with existing cabinet screws (as shown) and tighten up the 2 screws already installed on the Front Face Panel

#2 - Install two corner gussets using the screws supplied



#3 - Install the Front Face Panel onto the side panels and the corner gussets as shown with screws provided.





Location of existing cabinet screws to tie the Safety Cable-



2 screws on the Front Panel connected to the Safety Cable-



#5 -If required secure side blocker (s) to the side of the wind screen where there is direct exposure to wind. Use predrilled holes and screws provided to secure to screen.



**NOTE:** Wind Blockers are used to prevent direct wind exposure to the heat exchanger. Windscreens are needed for the operation where the ambient temperature falls below -5° Celsius.